

bq34110

Technical Reference Manual



Literature Number: SLUUBF7A
November 2016—Revised August 2018

| | |
|--|----------|
| Preface | 6 |
| 1 General Description | 7 |
| 2 Functional Description | 9 |
| 2.1 Device Configuration | 9 |
| 2.1.1 Operation Config A | 9 |
| 2.1.2 Manufacturer Testing | 10 |
| 2.1.3 Manufacturing Status Init | 10 |
| 2.2 Pin Controls | 11 |
| 2.2.1 Pin Control Config | 11 |
| 2.3 Voltage Measurement and Calibration | 15 |
| 2.3.1 1S Example | 16 |
| 2.3.2 7S Example | 16 |
| 2.3.3 Hardware Considerations for High Voltage Packs | 16 |
| 2.3.4 Parameter Configuration Considerations for High Voltage Applications | 17 |
| 2.3.5 Considerations for High-Current Systems (> ±32 767 mA) | 17 |
| 2.3.6 Considerations for High-Capacity Systems (> 29 Ah) | 18 |
| 2.3.7 Autocalibration | 18 |
| 2.4 Temperature Measurement | 19 |
| 2.4.1 Overtemperature: Charge | 20 |
| 2.4.2 Overtemperature: Discharge | 21 |
| 2.4.3 Undertemperature: Charge | 21 |
| 2.4.4 Undertemperature: Discharge | 22 |
| 2.5 SCALED Mode | 22 |
| 2.6 Accumulated Charge Measurement | 23 |
| 2.6.1 Accumulated Charge Positive Threshold | 24 |
| 2.6.2 Accumulated Charge Negative Threshold | 24 |
| 2.7 Gas Gauging | 24 |
| 2.7.1 CEDV Gas Gauging Operational Overview | 25 |
| 2.7.2 Main Gas Gauge Registers | 25 |
| 2.7.3 Capacity Learning (FCC Update) and Qualified Discharge | 27 |
| 2.7.4 End-of-Discharge Thresholds and Capacity Correction | 27 |
| 2.7.5 EDV Discharge Rate and Temperature Compensation | 28 |
| 2.7.6 EDV Age Factor | 29 |
| 2.7.7 Self-Discharge | 29 |
| 2.7.8 Battery Electronic Load Compensation | 30 |
| 2.7.9 CEDV Configuration | 30 |
| 2.7.10 Initial Battery Capacity at Device Reset | 32 |
| 2.7.11 Gas Gauge Operating Modes | 33 |
| 2.7.12 CEDV Smoothing | 34 |
| 2.8 Battery Condition Warnings | 36 |
| 2.8.1 Battery Low Warning | 36 |
| 2.8.2 Battery High Warning | 36 |
| 2.8.3 Battery Low SOC Warning | 36 |
| 2.9 Charging and Charge Termination | 37 |
| 2.9.1 Charge Inhibit | 40 |

| | | |
|----------|--|-----------|
| 2.9.2 | Charge Control | 40 |
| 2.9.3 | WHR Charging..... | 44 |
| 2.10 | Power Modes and Control | 45 |
| 2.10.1 | NORMAL Mode..... | 46 |
| 2.10.2 | SNOOZE Mode..... | 46 |
| 2.10.3 | SLEEP Mode | 46 |
| 2.10.4 | SHUTDOWN Mode | 47 |
| 2.10.5 | Wake-Up Comparator | 47 |
| 2.11 | End-Of-Service Determination..... | 47 |
| 2.11.1 | End-Of-Service Determination—Detailed Description..... | 49 |
| 2.12 | Battery Level Threshold | 61 |
| 2.13 | Lifetime Data Collection | 62 |
| 2.14 | Authentication..... | 63 |
| 2.14.1 | Overview | 63 |
| 2.14.2 | Key Programming | 63 |
| 2.14.3 | Authentication Challenge..... | 63 |
| 2.15 | Communications..... | 64 |
| 3 | Data Commands | 66 |
| 3.1 | Command Summary | 66 |
| 3.2 | Control(): 0x00/0x01 | 67 |
| 3.2.1 | CONTROL_STATUS: 0x0000 | 69 |
| 3.2.2 | DEVICE_TYPE: 0x0001 | 69 |
| 3.2.3 | FW_VERSION: 0x0002..... | 69 |
| 3.2.4 | HW_VERSION: 0x0003 | 69 |
| 3.2.5 | IF_SUM: 0x0004 | 69 |
| 3.2.6 | STATIC_DF_SUM: 0x0005 | 69 |
| 3.2.7 | PREV_MACWRITE: 0x0007 | 70 |
| 3.2.8 | BOARD_OFFSET: 0x0009..... | 70 |
| 3.2.9 | CC_OFFSET: 0x000A | 70 |
| 3.2.10 | CC_OFFSET_SAVE: 0x000B | 70 |
| 3.2.11 | ALL_DF_SUM: 0x0010 | 70 |
| 3.2.12 | SET_SNOOZE: 0x0013 | 70 |
| 3.2.13 | CLEAR_SNOOZE: 0x0014 | 70 |
| 3.2.14 | ACCUM_DSG_EN: 0x001E..... | 70 |
| 3.2.15 | ACCUM_CHG_EN: 0x001F..... | 70 |
| 3.2.16 | IGNORE_SELFDSG_EN: 0x0020 | 70 |
| 3.2.17 | EOS_EN: 0x0021 | 70 |
| 3.2.18 | PIN_CONTROL_EN: 0x0022 | 70 |
| 3.2.19 | LIFETIME_EN: 0x0023..... | 70 |
| 3.2.20 | WHR_EN: 0x0024 | 71 |
| 3.2.21 | CAL_TOGGLE: 0x002D | 71 |
| 3.2.22 | SEAL: 0x0030 | 71 |
| 3.2.23 | ENTER_ROM: 0x0033 | 71 |
| 3.2.24 | SECURITY_KEYS: 0x0035 | 71 |
| 3.2.25 | AUTHENTICATION_KEY: 0x0037 | 71 |
| 3.2.26 | EOS_START_LEARN: 0x0039 | 71 |
| 3.2.27 | EOS_ABORT_LEARN: 0x003A | 71 |
| 3.2.28 | EOS_RCELL_RRATE_LEARN: 0x003B | 71 |
| 3.2.29 | EOS_WARNCLR: 0x003C | 71 |
| 3.2.30 | EOS_INITIAL_RCELL: 0x003E | 72 |
| 3.2.31 | EOS_INITIAL_RRATE: 0x003F | 72 |
| 3.2.32 | RESET: 0x0041 | 72 |
| 3.2.33 | EOS_LOAD_ON: 0x0044 | 72 |

| | | |
|--------|--|----|
| 3.2.34 | EOS_LOAD_OFF: 0x0045 | 72 |
| 3.2.35 | DEVICE_NAME: 0x004A | 72 |
| 3.2.36 | ACCUM_RESET: 0x004B | 72 |
| 3.2.37 | EOS_SAFETY_STATUS: 0x0051 | 72 |
| 3.2.38 | OPERATION_STATUS: 0x0054 | 72 |
| 3.2.39 | GaugingStatus: 0x0056 | 72 |
| 3.2.40 | ManufacturingStatus: 0x0057 | 73 |
| 3.2.41 | ALERT1STATUS: 0x005E | 74 |
| 3.2.42 | ALERT2STATUS: 0x005F | 74 |
| 3.2.43 | LT_DATA: 0x0060 | 74 |
| 3.2.44 | PIN_ALERT1_SET: 0x0068 | 74 |
| 3.2.45 | PIN_ALERT1_RESET: 0x0069 | 75 |
| 3.2.46 | PIN_ALERT2_SET: 0x006A | 75 |
| 3.2.47 | PIN_ALERT2_RESET: 0x006B | 75 |
| 3.2.48 | PIN_VEN_SET: 0x006C | 75 |
| 3.2.49 | PIN_VEN_RESET: 0x006D | 75 |
| 3.2.50 | PIN_LEN_SET: 0x006E | 75 |
| 3.2.51 | PIN_LEN_RESET: 0x006F | 75 |
| 3.2.52 | MANU_DATA: 0x0070 | 75 |
| 3.2.53 | EOSSTATUS1: 0x007A | 75 |
| 3.2.54 | EOSSTATUS2: 0x007B | 76 |
| 3.2.55 | ENTER_ROM: 0x0F00 | 77 |
| 3.2.56 | STORE_REMCAP_A: 0x22C1 | 77 |
| 3.2.57 | STORE_REMCAP_B: 0x28A0 | 77 |
| 3.3 | Temperature(): 0x06/0x07 | 77 |
| 3.4 | Voltage(): 0x08/0x09 | 77 |
| 3.5 | BatteryStatus(): 0x0A/0x0B | 77 |
| 3.6 | Current(): 0x0C/0x0D | 79 |
| 3.7 | RemainingCapacity(): 0x10/0x11 | 79 |
| 3.8 | FullChargeCapacity(): 0x12/0x13 | 79 |
| 3.9 | AverageCurrent(): 0x14/0x15 | 79 |
| 3.10 | TimeToEmpty(): 0x16/0x17 | 80 |
| 3.11 | TimeToFull(): 0x18/0x19 | 80 |
| 3.12 | AveragePower(): 0x24/0x25 | 80 |
| 3.13 | InternalTemperature(): 0x28/0x29 | 80 |
| 3.14 | CycleCount(): 0x2A/0x2B | 80 |
| 3.15 | RelativeStateOfCharge(): 0x2C/0x2D | 80 |
| 3.16 | StateofHealth(): 0x2E/0x2F | 81 |
| 3.17 | ChargingVoltage(): 0x30/0x31 | 81 |
| 3.18 | ChargingCurrent(): 0x32/0x33 | 81 |
| 3.19 | BLTDischargeSet(): 0x34/0x35 | 81 |
| 3.20 | BLTChargeSet(): 0x36/0x37 | 81 |
| 3.21 | OperationStatus(): 0x3A/0x3B | 81 |
| 3.22 | DesignCapacity(): 0x3C/0x3D | 82 |
| 3.23 | ManufacturerAccessControl(): 0x3E/0x3F | 82 |
| 3.24 | MACData(): 0x40 through 0x5F | 83 |
| 3.25 | MACDataSum(): 0x60 | 83 |
| 3.26 | MACDataLen(): 0x61 | 83 |
| 3.27 | EOSLearnStatus(): 0x64/0x65 | 83 |
| 3.28 | EOSSafetyStatus(): 0x66/0x67 | 85 |
| 3.29 | EOSStatus(): 0x68 | 86 |
| 3.30 | AnalogCount(): 0x79 | 87 |
| 3.31 | RawCurrent(): 0x7A/0x7B | 87 |

| | | |
|----------|---|------------|
| 3.32 | RawVoltage(): 0x7C/0x7D | 87 |
| 3.33 | RawIntTemp(): 0x7E/0x7F | 87 |
| 3.34 | RawExtTemp(): 0x80/0x81 | 88 |
| 4 | Data Flash | 89 |
| 4.1 | Accessing Data Flash | 89 |
| 4.1.1 | Write to DF Example | 89 |
| 4.1.2 | Read from DF Example | 89 |
| 4.1.3 | Auto-Increment Reading | 89 |
| 4.2 | Access Modes | 90 |
| 4.3 | Sealing/Unsealing Data Flash Access | 90 |
| 4.4 | SOC Flag Configuration A (SOC Flag Config A) Register | 91 |
| 4.5 | SOC Flag Configuration B (SOC Flag Config B) Register | 92 |
| 4.6 | Manufacturer Information Block | 92 |
| 4.7 | Data Flash Summary | 94 |
| 5 | Factory Calibration | 102 |
| 5.1 | General I ² C Command Information | 102 |
| 5.2 | Calibration Overview | 102 |
| 5.2.1 | Method | 102 |
| 5.2.2 | Sequence | 102 |
| 5.3 | Enter CALIBRATION Mode | 103 |
| 5.4 | Exit CALIBRATION Mode | 103 |
| 5.5 | CC Offset | 104 |
| 5.6 | Board Offset | 105 |
| 5.7 | Obtain Raw Calibration Data | 106 |
| 5.8 | Temperature Calibration | 107 |
| 5.9 | Voltage Calibration | 108 |
| 5.10 | Current Calibration | 110 |
| 5.11 | Floating Point Conversion | 111 |
| | Revision History | 112 |

Read This First

About This Manual

This technical reference manual (TRM) discusses the modules and peripherals of the bq34110 battery gas gauge, and how each is used to build a complete battery fuel gauge and end-of-service monitor. Content in this TRM complements, not supersedes, information in the *bq34110 Multi-Chemistry CEDV Battery Gas Gauge for Rarely Discharged Applications Data Sheet* ([SLUSCI1](#)).

Notational Conventions

This document uses the following conventions:

- Hexadecimal numbers may be shown with the suffix h or the prefix 0x. For example, the following number is 40 hexadecimal (decimal 64): 40h or 0x40.
- Registers in this document are shown in figures and described in tables.
 - Each register figure shows a rectangle divided into fields that represent the fields of the register. Each field is labeled with its bit name, its beginning and ending bit numbers above, and its read/write properties with default reset value below. A legend explains the notation used for the properties.
 - Reserved bits in a register figure can have one of multiple meanings:
 - Not implemented on the device,
 - Reserved for future device expansion,
 - Reserved for TI testing,
 - Reserved configurations of the device that are not supported.
 - Writing non-default values to the Reserved bits could cause unexpected behavior and should be avoided.

Formatting in This Document

The following formatting convention is used in this document:

- SBS Commands: *italic* with parenthesis and no breaking spaces; for example, *RemainingCapacity()*
- Data Flash: *italic*, **bold**, and breaking spaces; for example, **Design Capacity**
- Data Flash Bits: *italic* and **bold**; for example, **[LED1]**
- Register Bits and Flags: *italic* and brackets; for example, *[TDA]*
- Modes and States: ALL CAPITALS; for example, UNSEALED

Glossary

[TI Glossary](#) — This glossary lists and explains terms, acronyms, and definitions.

Related Documentation from Texas Instruments

See the *bq34110 Multi-Chemistry CEDV Battery Gas Gauge for Rarely Discharged Applications Data Sheet* ([SLUSCI1](#)).

For product information, visit the Texas Instruments website at <http://www.ti.com/product/bq34110>.

Trademarks

MathCAD is a trademark of PTC.

All other trademarks are the property of their respective owners.

General Description

The bq34110 device incorporates gas gauging and an End-Of-Service (EOS) Determination function for use in single-cell and multi-cell battery packs, with support for multiple battery chemistries, including Li-Ion, LiFePO₄, lead-acid (PbA), Nickel Metal Hydride (NiMH), and Nickel Cadmium (NiCd). The gas gauging function uses Compensated End-of-Discharge Voltage (CEDV) technology to accurately predict the battery capacity and other operational characteristics of the battery, and can be interrogated by a host processor to provide cell information, such as remaining capacity, full charge capacity, and average current.

The integrated EOS Determination function is specifically intended for applications where the battery is rarely discharged, such as in uninterruptible power supplies (UPS), enterprise server backup systems, and telecommunications backup modules. In such systems, the battery may remain in a fully (or near-fully) charged state for much of its lifetime, with it rarely or never undergoing a significant discharge. If the health of the battery in such a system is not monitored regularly, then it may degrade beyond the level required for a system backup/discharge event, and thus fail precisely at the time when it is needed most.

The EOS Determination function monitors the health of the battery through the use of infrequent learning phases, which involve a controlled discharge of ~1% capacity, and provides an alert to the system when the battery is approaching the end of its usable service. By coordinating battery charging with the learning phases, the battery capacity available to the system can be maintained above a preselected level to avoid compromising the ability for the battery to support a system discharge event.

The bq34110 device can support multi-cell battery configurations with maximum voltage up to 65 V, through the use of external and internal resistive divider networks, to reduce the voltage to an acceptable range for the device's integrated ADC. These resistive dividers are actively controlled to avoid unnecessary power dissipation when not needed. The device integrates an internal temperature sensor as well as support for an external NTC thermistor, such as a Semitec 103AT or Mitsubishi BN35-3H103FB-50.

The battery current is monitored by measuring the voltage across a series resistor, R_{SENSE} , which is placed in series with the battery pack and has a typical value of 5 m Ω to 20 m Ω . The bq34110 device integrates two ADCs, one of which is dedicated to current measurement, and the second is used for measuring several other parameters, including temperature and voltage.

Communication with the device is provided through an I²C interface, supporting rates up to 400 kHz. Dual ALERT pins are provided with programmable configuration, which enables them to be used for such functions as a host interrupt/alert or controlling the battery charger.

To minimize power consumption, the bq34110 device has several power modes: NORMAL, SNOOZE, and SLEEP, which are under register or algorithm control. In addition, a separate chip enable (CE) pin is provided to control the internal LDO that powers the bq34110 internal circuitry, and can put the device into SHUTDOWN mode.

Information is accessed through a series of commands called Data Commands (see [Data Commands](#)), which are indicated by the general format *Command()*. These commands are used to read and write information contained within the bq34110 control and status registers, as well as its data flash locations.

Commands are sent from the host to the bq34110 device via I²C and can be executed during application development, pack manufacture, or end-equipment operation. Cell information is stored in the bq34110 device in non-volatile flash memory. Many of the data flash locations are accessible during application development and pack manufacture. They cannot, generally, be accessed directly during end-equipment operation. Access to these locations is achieved by using the bq34110 companion evaluation software, through individual commands, or through a sequence of data-flash-access commands. To access a specific data flash location, the correct data flash subclass and offset must be known.

The bq34110 device provides 32 bytes of user-programmable data flash memory. This data space is accessed through a data flash interface. For specifics on accessing the data flash, refer to [Accessing Data Flash](#).

A SHA-1/HMAC-based battery pack authentication feature is also implemented on the bq34110 device. When the device is in UNSEALED mode, authentication keys can be (re)assigned. A scratch pad area is used to receive challenge information from a host and to export SHA-1/HMAC encrypted responses. See the [Authentication](#) section for further details.

Functional Description

2.1 Device Configuration

The bq34110 device has many features that can be enabled, disabled, or modified through settings in the **Operation Config A** data flash. These registers are programmed/read via the methods described in [Accessing Data Flash](#).

2.1.1 Operation Config A

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|-----------|--------------------|--------|---------------|-----------|-----------|---------------|------|
| Configuration | Registers | Operation Config A | hex | 2 | — | — | — | — |

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|--------|-----------------|-------|-------|--------|-------|----------------|
| High Byte | TEMPS | RSVD | RSVD | RSVD | RSVD | SCALED | SLEEP | SLPWAKE CHG |
| Low Byte | JEITA | GNDSEL | NiMH_ CHG_EN | Ni_DT | Ni_DV | IWAKE | RSNS1 | RSNS0 |

Legend = **RSVD**: Reserved. Do not use.

TEMPS: Selects external thermistor for *Temperature()* measurements.
True when set. Uses internal temp when clear. The default is 1.

RSVD: Reserved. Do not use.

SCALED: Scaled Capacity and/or Current bit

When set, this bit flags the system that the mA, mAh, and mWh settings and reports will take on a value that is artificially scaled. This setting has no actual effect within the gauge. It is the responsibility of the host to reinterpret the reported values. Scaled current measurement is achieved by calibrating the current measurement to a value lower than actual. The default is 0.

SLEEP: When this bit is set, the bq34110 device can enter sleep if operating conditions allow. The default is 1.

SLPWAKECHG: When this bit is set, the gauge will accumulate estimated charge that has passed during sleep upon wake from sleep when *Current()* > **Sleep Current**, but not enough to trigger wake event. If not set, the estimated charge during sleep is not accumulated. The default is 0.

JEITA: When this bit is set, the device performs charging voltage and current selection based on parameters specified in **Charger Control:JEITA Temperature**. See [Charging and Charge Termination](#). The default is 0.

GNDSEL: The ADC ground select control

The VSS pin is selected as ground reference when the bit is clear. SRN is selected when the bit is set. The default is 0.

- NIMH_CHG_EN:** When set, the device performs primary charge termination using one of the NiXX algorithms, which may be the $\Delta T/\Delta t$ algorithm or the $-\Delta V$ algorithm. See [Charging and Charge Termination](#). If **[NIMH_CHG_EN]** is set and both **[Ni_DT]** and **[Ni_DV]** are cleared, the gauge will use the $-\Delta V$ algorithm. If **[NIMH_CHG_EN]** is cleared, the device will use either JEITA-based charging or WHr Charging, depending on their settings. The default is 0.
- Ni_DT:** When set, the device performs primary charge termination using the $\Delta T/\Delta t$ algorithm. See [Charging and Charge Termination](#). The default is 0.
- Ni_DV:** When set, the device performs primary charge termination using the $-\Delta V$ algorithm. See [Charging and Charge Termination](#). The default is 0.
- IWAKE/RSNS1/RSNS0:** These bits configure the current wake function (see [Wake-Up Comparator](#)). The default is **[IWAKE]=1**, **[RSNS1]=0**, **[RSNS0]=0**.

2.1.2 Manufacturer Testing

To improve the manufacturer testing flow, the bq34110 device allows certain features to be toggled on or off through *Control()* commands: for example, the Lifetime Data Collection status is toggled using the *LIFETIME_EN()* subcommand. Enabling only the feature under test can simplify the test flow in production by avoiding any feature interference. These toggling commands will only set the RAM data, which means the conditions set by these commands will be cleared if a reset or seal is issued to the gauge. The *ManufacturingStatus()* keeps track of the status (enabled or disabled) of each feature.

The data flash **Manufacturing Status Init** provides the option to enable or disable individual features for normal operation. Upon a reset or a seal command, the *ManufacturingStatus()* will be reloaded from data flash **Manufacturing Status Init**. This also means if an update is made to *ManufacturingStatus()* to enable or disable a feature, the gauge will only take the new setting if a reset or seal command is sent.

2.1.3 Manufacturing Status Init

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|---------------|---------------------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | Manufacturing | Manufacturing Status Init | hex | 2 | — | — | — | — |

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----|-------|--------|-------|---------|--------|--------------|----------|----------|
| MSB | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD |
| LSB | RSVD | WHR_EN | LF_EN | PCTL_EN | EOS_EN | IGNORE_SD_EN | ACCHG_EN | ACDSG_EN |

Legend = **RSVD**: Reserved. Do not use.

WHR_EN: **WHR Charge Termination** Enable

- 1 = **WHR Charge Termination** enabled
- 0 = **WHR Charge Termination** disabled (default)

LF_EN: Lifetime Data Collection Enable

- 1 = Enabled
- 0 = Disabled (default)

PCTL_EN: Pin Control Enable

This bit allows the host to manually control the state of the pins ALERT1, ALERT2, VEN, and LEN through the *ManufacturerAccessControl()* subcommands *PIN_ALERT1_SET()*, *PIN_ALERT1_RESET()*, *PIN_ALERT2_SET()*, *PIN_ALERT2_RESET()*, *PIN_VEN_SET()*, *PIN_VEN_RESET()*, *PIN_LEN_SET()*, and *PIN_LEN_RESET()*.

NOTE: If ALERT1 or ALERT2 pins are under manual pin control, they should not also be used for alert/interrupt purposes.

- 1 = Manual pin control is enabled.
- 0 = Manual pin control is disabled (default).

EOS_EN: End-Of-Service Determination Enable

Note that if **[EOS_EN]** is changed directly in data flash, then the device should be reset for the change to take effect.

- 1 = End-Of-Service Determination is enabled.
- 0 = End-Of-Service Determination is disabled (default).

IGNORE_SD_EN: Ignore Self-Discharge Control

- 1 = Accumulated charge integration ignores self-discharge and only integrates real current.
- 0 = Accumulated charge integration includes both real and self-discharge current (default).

ACCHG_EN: Accumulated Charge Enable for Charging Current Integration

- 1 = Positive (charging) values of *Current()* are integrated (default).
- 0 = Positive (charging) values of *Current()* are not integrated.

ACDSG_EN: Accumulated Charge Enable for Discharging Current Integration

- 1 = Negative (discharging) values of *Current()* are integrated (default).
- 0 = Negative (discharging) values of *Current()* are not integrated.

2.2 Pin Controls

The bq34110 device includes multiple pins that can be used for different purposes based on the system configuration, including two ALERT pins (ALERT1 and ALERT2), and can be used as interrupts to a host processor. The device provides a variety of status flags that can be configured to combine together into a single alert signal to generate a single interrupt (for example, using the ALERT1 pin), or flags can be separated to trigger two separate interrupts (using both the ALERT1 and ALERT2 pins). The alert settings are controlled by the **Pin Control Config** data flash value.

2.2.1 Pin Control Config

| Class | Subclass | Name | Format | Size | Min Value | Max Value | Default Value | Unit |
|----------|---------------|--------------------|--------|------|-----------|-----------|---------------|------|
| Settings | Configuration | Pin Control Config | hex | 1 | 0x00 | 0xFF | 0x00 | — |

| | | | | | | | |
|------|------|------|--------|------------|-----------|------------|-----------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | RSVD | RSVD | VEN_EN | ALERT2_POL | ALERT2_EN | ALERT1_POL | ALERT1_EN |

Legend = **RSVD:** Reserved. Do not use.

VEN_EN: VEN pin control for external voltage divider operation

When set, the VEN pin is used to control an external voltage divider, which provides the divided down voltage to the BAT pin. Setting this pin also disables the use of the internal battery voltage divider within the device. When this bit is cleared, the internal battery divider will be activated whenever a battery voltage measurement is activated.

ALERT1_EN and ALERT2_EN: ALERT1 and ALERT2 pin control

These bits are used to control the function of the ALERT1 and ALERT2 pins. When set, the corresponding ALERT pin is used as an interrupt.

ALERT1_POL and ALERT2_POL: ALERT1 and ALERT2 interrupt polarity control

These bits are used to control the polarity of the corresponding ALERT pin when used as an interrupt. When set, the pin will have a high output level when the interrupt is set.

The **Alert1_0 Config** to **Alert1_6 Config** and **Alert2_0 Config** to **Alert2_6 Config** data flash values are used to determine which of many internal flags and condition bits can trigger the ALERT1 and ALERT2 interrupt signals. These configuration flash are identical, allowing any combination of flags to be combined to generate the two alert signals.

For example, when Bit 0 (**[DSG]**) in **Alert1_0 Config** is set AND the corresponding bit in **BatteryAlert()** (that is, **[DSG]**) is set, then the ALERT1 interrupt will be generated.

The **Alert1_0..6 Config** and **Alert2_0..6 Config** signals are cleared upon a read of **ALERT1STATUS()** or **ALERT2STATUS()**, respectively.

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|----------|---------------|-----------------|------|------|-----------|-----------|---------------|------|
| Settings | Configuration | Alert1_0 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_1 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_2 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_3 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_4 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_5 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert1_6 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_0 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_1 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_2 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_3 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_4 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_5 Config | Hex | 1 | — | — | — | — |
| Settings | Configuration | Alert2_6 Config | Hex | 1 | — | — | — | — |

The bits in **ALERT1_0 Config** and **ALERT2_0 Config** match the bits in **BatteryStatus()** lower byte.

| | | | | | | | |
|-------|--------|----|----|-----|-----|-----|-----|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| SLEEP | CHGINH | FD | FC | TCA | TDA | CHG | DSG |

The bits in **Alert1_1 Config** and **Alert2_1 Config** match the bits in **BatteryStatus()** upper byte with an exception in Bit 7.

| | | | | | | | |
|------|--------|-----|-----|-----|-----|---------|--------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | SOCLOW | UTC | UTD | OTC | OTD | BATHIGH | BATLOW |

The bits in **Alert1_2 Config** and **Alert2_2 Config** match the bits in **EOSLearnStatus()** lower byte.

| | | | | | | | |
|------|--------|-------|------|------|------|------|-------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| LCTO | LFAULT | LABRT | LCMD | LPER | LRLX | LCHG | LD SG |

The bits in **Alert1_3 Config** and **Alert2_3 Config** match the bits in **EOSLearnStatus()** upper byte.

| | | | | | | | |
|-------|------|--------|----------|------|-------|-------|-------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| LDONE | LRES | LRSTOR | LCTLEDGE | LUCD | LDPAM | LDPAT | LDPAI |

The bits in **Alert1_4 Config** and **Alert2_4 Config** match the bits in **EOSStatus()**.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|------|------|-----|-------|--------|---------|--------|
| SRRL | SRCL | RSVD | LTl | RSDLI | RCELLR | IRRCOMP | IRCOMP |

The bits in **Alert1_5 Config** and **Alert2_5 Config** match the bits in *EOSSafetyStatus()*, compressed into a single byte.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|----------|---------|---------|------|----------|----------|----------|
| RSVD | RSDLWARN | RSDWARN | DRDWARN | RSVD | RSDALERT | RSDALERT | DRDALERT |

The bits in **Alert1_6 Config** and **Alert2_6 Config** include the following bits.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|------|------|------|------|------|-------|-----|
| RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | ACTHR | BLT |

Legend = **RSVD**: Reserved. Do not use.

BATLOW: Battery voltage low condition

1 = ALERT is triggered when BATLOW becomes set.

0 = ALERT is not triggered when BATHIGH becomes set (default).

BATHIGH: Battery voltage high condition

1 = ALERT is triggered when BATHIGH becomes set.

0 = ALERT is not triggered when BATHIGH becomes set (default).

SOCLOW: Low SOC State is detected.

1 = ALERT is triggered when SOCLOW becomes set.

0 = ALERT is not triggered when SOCLOW becomes set (default).

ACTHR: Accumulated Charge Threshold Flag

1 = The **Accumulated Charge** was detected passing a threshold.

0 = The **Accumulated Charge** has not been detected passing a threshold.

OTC: Overtemperature in Charge condition detected

1 = ALERT is triggered when OTC becomes set.

0 = ALERT is not triggered when OTC becomes set (default).

OTD: Overtemperature in Discharge condition is detected.

1 = ALERT is triggered when OTD becomes set.

0 = ALERT is not triggered when OTD becomes set (default).

UTC: Undertemperature in Charge condition detected

1 = ALERT is triggered when UTC becomes set.

0 = ALERT is not triggered when UTC becomes set (default).

UTD: Undertemperature in Discharge condition is detected.

1 = ALERT is triggered when UTD becomes set.

0 = ALERT is not triggered when UTD becomes set (default).

CHGINH: Charge Inhibit. Unable to begin charging.

Refer to the data flash [**Charge Inhibit Temp Low, Charge Inhibit Temp High**] parameters.

1 = ALERT is triggered when CHGINH becomes set.

0 = ALERT is not triggered when CHGINH becomes set (default).

FC: Full charge is detected.

This bit is controlled by settings in **SOC Flag Config A** and **SOC Flag Config B**.

1 = ALERT is triggered when FC becomes set.

0 = ALERT is not triggered when FC becomes set (default).

FD: Full discharge is detected. This bit is controlled by settings in **SOC Flag Config B**.

1 = ALERT is triggered when FD becomes set.

0 = ALERT is not triggered when FD becomes set (default).

DSG: Discharging is detected.

1 = ALERT is triggered when DSG becomes set.

0 = ALERT is not triggered when DSG becomes set (default).

CHG: Charging is detected.

1 = ALERT is triggered when CHG becomes set.

0 = ALERT is not triggered when CHG becomes set (default).

DRDALERT: EOS Direct Resistance Detection Alert becomes set.

1 = ALERT is triggered when DRDALERT becomes set.

0 = ALERT is not triggered when DRDALERT becomes set (default).

DRDWARN: EOS Direct Resistance Detection Warning becomes set.

1 = ALERT is triggered when DRDWARN becomes set.

0 = ALERT is not triggered when DRDWARN becomes set (default).

RSDALERT: EOS Resistance Slope Detection Alert becomes set.

1 = ALERT is triggered when RSDALERT becomes set.

0 = ALERT is not triggered when RSDALERT becomes set (default).

RSDWARN: EOS Resistance Slope Detection Warning becomes set.

1 = ALERT is triggered when RSDWARN becomes set.

0 = ALERT is not triggered when RSDWARN becomes set (default).

RSDLALERT: EOS Resistance Slope Detection Long-Term Alert becomes set.

1 = ALERT is triggered when RSDLALERT becomes set.

0 = ALERT is not triggered when RSDLALERT becomes set (default).

RSDLWARN: EOS Resistance Slope Detection Long-Term Warning becomes set.

1 = ALERT is triggered when RSDLWARN becomes set.

0 = ALERT is not triggered when RSDLWARN becomes set (default).

LCTLEDGE: Learning Discharge ([LDSG]) changes state

1 = ALERT is triggered when [LDSG] changes state (this is only applicable when LENCTL=0).

0 = ALERT is not triggered when [LDSG] changes state (default).

LCTO: Learn Charge Time Out becomes set.

1 = ALERT is triggered when LCTO becomes set.

0 = ALERT is not triggered when LCTO becomes set (default).

LDPAI: Learning Discharge Phase Abort on Current becomes set.

1 = ALERT is triggered when LDPAI becomes set.

0 = ALERT is not triggered when LDPAI becomes set (default).

LDPAT: Learning Discharge Phase Abort on Temperature becomes set.

1 = ALERT is triggered when LDPAT becomes set.

0 = ALERT is not triggered when LDPAT becomes set (default).

LDPAM: Learning Discharge Phase Abort on Timer becomes set.

1 = ALERT is triggered when LDPAM becomes set.

0 = ALERT is not triggered when LDPAM becomes set (default).

RSDLI: Resistance Slope Decisioning Long-Term Invalid

This bit is set = 1 if the bq34110 EOS Determination function detects that the timer has been interrupted since the **Initial RRate** was calculated. In this case, the RSDL algorithm will no longer trigger an alert or warning.

1 = A timer interruption was detected.

0 = A timer interruption has not been detected.

LTI: Learn Timer Invalid

This bit is set = 1 if the bq34110 EOS Determination function detects the timer has been interrupted since the most recent **Rcell** was calculated. In this case, the RSD algorithm must capture two new **Rcell** values separated in time in order to calculate a new value of **RRate** and evaluate this for corresponding alerts and warnings.

1 = A timer interruption was detected.

0 = A timer interruption has not been detected.

RCELLR: Rcell Reduction Alert

This bit is set = 1 if the bq34110 EOS Determination function detects a value of **Rcell**, which is more than 2% below the previous value of **Rcell**. This signal is cleared when the register is read or if a new learning phase begins.

1 = A reduction in **Rcell** was detected.

0 = A reduction in **Rcell** has not been detected.

IRCOMP: Initial Rcell Calculation Complete

This bit is set = 1 if the bq34110 EOS Determination function has completed the required learning phases to calculate a value of **Initial Rcell**. This bit is reset when a new **Initial Rcell** calculation is triggered, until the new calculation is complete. This bit can be written by the host through loading data flash, if the host wishes to initialize the device with previously calculated **Initial Rcell** data and not trigger a new **Initial Rcell** calculation.

1 = **Initial Rcell** was obtained.

0 = **Initial Rcell** has not been obtained.

IRRCOMP: Initial RRate Calculation Complete

This bit is set = 1 if the bq34110 EOS Determination function has completed the required learning phases to calculate a value of **Initial RRate**. This bit is reset when a new **Initial RRate** calculation is triggered, until the new calculation is complete. This bit can be written by the host through loading data flash if the host wants to initialize the device with previously calculated **Initial RRate** data and not trigger a new **Initial RRate** calculation.

1 = **Initial RRate** was obtained.

0 = **Initial RRate** has not been obtained.

BLT: Battery Level Threshold becomes set.

1 = ALERT is triggered when BLT becomes set.

0 = ALERT is not triggered when BLT becomes set (default).

2.3 Voltage Measurement and Calibration

The bq34110 device is shipped with a factory configuration for the default case of the 1-series Li-Ion cell. This can be changed by setting the **[VEN_EN]** bit and by setting the number of series cells in the data flash configuration section.

Multi-cell applications, with voltages up to 65535 mV, may be gauged by using the appropriate input scaling resistors such that the maximum battery voltage, under all conditions, appears at the BAT input as approximately 900 mV. The actual gain function is determined by a calibration process and the resulting voltage calibration factor is stored in the data flash location **Voltage Divider**.

For single-cell applications, an external divider network is not required. Inside the IC and behind the BAT pin is a nominal 5:1 voltage divider with 88 kΩ in the top leg and 22 kΩ in the bottom leg. This internal divider network is enabled when a battery voltage measurement is activated if the **[VEN_EN]** bit is not set. This ratio is optimum for directly measuring a single Li-Ion cell where charge voltage is limited to 4.5 V.

For higher voltage applications, an external resistor divider network should be implemented as per the reference designs in this document. The quality of the divider resistors is very important to avoid gauging errors over time and temperature. It is recommended to use 0.1% resistors with 25-ppm temperature coefficient. Alternately, a matched network could be used that tracks its dividing ratio with temperature and age due to the similar geometry of each element.

Calculation of the series resistor can be made per the equation below.

NOTE: Exceeding **Vin max mV** results in a measurement with degraded linearity.

The bottom leg of the divider resistor should be in the range of 15 kΩ to 25 kΩ, using 16.5 kΩ:

$$R_{\text{series}} = 16500 \, \Omega (V_{\text{in max mV}} - 900 \, \text{mV}) / 900 \, \text{mV} \quad (1)$$

For all applications, the **Voltage Divider** value in data flash will be used by the firmware to calibrate the total divider ratio. The nominal value for this parameter is the maximum expected value for the stack voltage. The calibration routine adjusts the value to force the reported voltage to equal the actual applied voltage.

Table 2-1. Voltage Divider

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|-----------------|------------------|---------------|-----------|-----------|---------------|------|
| Calibration | Data | Voltage Divider | Unsigned Integer | 2 | 0 | 65535 | 5000 | mV |

2.3.1 1S Example

For stack voltages under 4.5 V max, it is not necessary to provide an external voltage divider network. The internal 5:1 divider should be selected by clearing the **[VEN_EN]** bit. The default value for **Voltage Divider** is 5000 (representing the internal 5000:1000 mV divider) when no external divider resistor is used, and the default number of series cells = 1. In the 1-S case, there is usually no requirement to calibrate the voltage measurement, because the internal divider is calibrated during factory test to within 2 mV.

2.3.2 7S Example

In the multi-cell case, the hardware configuration is different. An external voltage divider network is calculated using the R_{series} formula above. The bottom leg of the divider should be in the range of 15 kΩ to 25 kΩ.

2.3.3 Hardware Considerations for High Voltage Packs

For an application exceeding ~60 V, the external voltage divider should be selected to reduce the maximum pack voltage to a level of approximately 900 mV at the device BAT pin. [Figure 2-1](#) shows the BAT resistor divider. For example, if an 18S Li-Ion pack is used, then the maximum pack voltage should be set to the recommended single-cell maximum voltage (for example, 5 V) times the actual number of series cells (for example 18) which is 90 V.




Figure 2-1. BAT Resistor Divider

Use Equation 2 to setup the voltage divider to support a 90-V pack voltage.

$$R_{\text{SERIES}} = 16\,500\,\Omega \times \frac{(\text{Maximum Pack Voltage mV} - 900\,\text{mV})}{900\,\text{mV}} \quad (2)$$

The second resistor in the resistor divider network should have a value between 15 k Ω and 25 k Ω . For this example, use 16.5 k Ω and Equation 3 to calculate the series resistance.

$$R_{\text{SERIES}} = 16\,500\,\Omega \times \frac{(90\,000\,\text{mV} - 900\,\text{mV})}{900\,\text{mV}} = 1.631\,\text{M}\Omega \quad (3)$$

A standard value 1.62-M Ω resistor will support an 89-V pack voltage and provide adequate cell-voltage measurement margin for a Li-Ion cell.

2.3.4 Parameter Configuration Considerations for High Voltage Applications

The data flash configuration must scale the pack voltage to ensure that the maximum reported voltage does not exceed 65 535 mV.

This additional scaling is created by scaling the value stored in number of series cells, together with the value used for the external voltage divider ratio. Use Equation 4 to calculate the maximum pack voltage with the example values.

$$\frac{\text{Maximum Pack Voltage}}{\text{Maximum Reportable Value}} = \frac{90\,000\,\text{mV}}{65\,535\,\text{mV}} = 1.38 \quad (4)$$

The number of series cells is an integer unit so the scaling factor should be rounded up. For this example, use a 2x scaling factor.

$$\text{Stored Number of Cells} = \frac{\text{Actual Number of Cells}}{\text{Scaling Factor}} \rightarrow \frac{18}{2} = 9 \quad (5)$$

Therefore, the **Number of Series Cells** is set to 9. The voltage must be divided by 2 when calibrating the voltage. For example, if the applied pack voltage is 80 V, then the designer should enter 40 000 mV in the program. This will result in the **Voltage Divider** being calibrated to a value near 44500 mV (representing 1/2 of the 89:1 divider ratio).

In this configuration, the host device that is reading the reported voltage value must also know that the voltage is scaled so that it can rescale the voltage to the true pack voltage.

Due to the maximum **Voltage Divider** setting of 65535 (which represents a resistive divide ratio of 65.536:1), which may need to be slightly higher due to calibration for resistor tolerances, it is recommended to use a maximum divider ratio of 60:1 when scaling is not being used

NOTE: The actual number of series cells that can be scaled is limited. The result of the equation must be an integer. The result cannot be rounded up or down because this would cause the gauge to calculate the wrong cell voltage. As an example, if the actual number of series cells was 17, then the number of series cells must be set to 17 and the voltage will be reported as a single cell. The **[VEN_EN]** bit must be set in the pack configuration register.

2.3.5 Considerations for High-Current Systems (> $\pm 32\,767\,\text{mA}$)

The gauge can support charge and discharge currents up to 32 767 mA. Current scaling is required to support higher currents. High-current packs are typically high-capacity packs as well, so both the current and capacity may need to be considered when scaling the pack. The scale factor is calculated for both parameters and the largest scale factor is used for both parameters.

2.3.5.1 Hardware Considerations

To ensure accurate current measurement, the input voltage generated across the current-sense resistor should not exceed $\pm 125\,\text{mV}$. The value of the sense resistor must be set to ensure that this voltage is not exceeded at the maximum charge and discharge current.

2.3.5.2 Parameter Configuration Considerations

The data flash configuration must scale the current to ensure that the maximum current does not exceed 32 767 mA. As an example, if the maximum discharge current is 64 A, then the scale factor is set to $64\,000\text{ mA} / 32\,767\text{ mA} = 1.95x$ or is rounded up to $2x$. All current and capacity parameters in the data flash should be divided by 2.

2.3.5.3 How to Calibrate for Current Scaling

The current must be scaled during the calibration phase. If $2x$ scaling is used, then the current is divided by 2. If a 4-A discharge current is used to calibrate the pack, then -2000 mA is entered as the actual current. All current and capacity parameters are reported at half the actual value and the host must to multiply these parameters by the scale factor to find the true value.

2.3.6 Considerations for High-Capacity Systems (> 29 Ah)

The gauge can support pack capacities up to 29 Ah. Current scaling is required to support higher capacities. High-capacity packs are typically high current packs as well, so both the current and capacity may need to be considered when scaling the pack. The scale factor is calculated for both parameters and the largest scale factor is used for both parameters.

2.3.6.1 Parameter Configuration Considerations

The data flash configuration must scale the capacity to ensure that the maximum capacity does not exceed 29 000 mAh. As an example, if the maximum pack capacity is 100 Ah, then the scale factor is set to $100\,000\text{ mAh} / 29\,000\text{ mAh} = 3.45x$ or rounded up to $4x$. All current and capacity parameters in the data flash (such as **Sleep Current**, **Quit Current**, **Design Capacity**, **Accumulated Charge Positive Threshold**, and so on) are divided by $4x$, and current calibration must also follow the scaling, as described in [Section 2.3.5.3](#).

2.3.7 Autocalibration

The bq34110 device provides an autocalibration feature that will measure the voltage offset error across SRP and SRN as operating conditions change. It subtracts the resulting offset error from normal sense resistor voltage, V_{SR} , for maximum measurement accuracy.

The device performs a single offset calibration at entry to SLEEP mode, except if *Temperature()* is \leq **Offset Cal Inhibit Temp Low** or *Temperature()* is \geq **Offset Cal Inhibit Temp High**.

The gas gauge also performs a single offset when:

1. Voltage change since last offset calibration $\geq 256\text{ mV}$ for 30 s OR
2. Temperature change since last offset calibration is greater than 8°C for $\geq 30\text{ s}$ OR
3. *AverageCurrent()* $< 100\text{ mA}$ for 30 s.

Capacity and current measurements should continue at the last measured rate during the offset calibration when these measurements cannot be performed. If the battery voltage drops more than 256 mV during the offset calibration, the load current has likely increased; thus, the offset calibration is aborted. The *CONTROL_STATUS()*[CCA] bit is set during coulomb counter autocalibration.

Automatic offset calibration will not be initiated during a learning phase when the EOS Determination function is enabled.

The bq34110 device defines the coulomb counter deadband voltage for the measured voltage between the SRP and SRN pins used for capacity accumulation in units of 294 nV. Any voltages within \pm **CC Deadband** do not contribute to capacity accumulation.

The device also uses the **Deadband** parameter, such that any current within \pm **Deadband** will be reported as 0 mA by the *Current()* function. This parameter does not affect capacity accumulation.

2.3.7.1 Deadband

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|----------|------------------|---------------|-----------|-----------|---------------|------|
| Calibration | Current | Deadband | Unsigned Integer | 1 | 0 | 255 | 5 | mA |

2.3.7.2 CC Deadband

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|-------------|------------------|---------------|-----------|-----------|---------------|--------|
| Calibration | Current | CC Deadband | Unsigned Integer | 1 | 0 | 255 | 17 | 294 nV |

2.3.7.3 Offset Cal Inhibit Temp Low

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|----------|-----------------------------|----------------|---------------|-----------|-----------|---------------|-------|
| Configuration | Power | Offset Cal Inhibit Temp Low | Signed Integer | 2 | –400 | 1200 | 50 | 0.1°C |

2.3.7.4 Offset Cal Inhibit Temp High

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|----------|------------------------------|----------------|---------------|-----------|-----------|---------------|-------|
| Configuration | Power | Offset Cal Inhibit Temp High | Signed Integer | 2 | –400 | 1200 | 450 | 0.1°C |

2.4 Temperature Measurement

The bq34110 device can measure temperature through an integrated temperature sensor or an external NTC thermistor. Only one source can be used, and the selection is made by setting **Operation Config A [TEMPS]** appropriately. Temperature measurements are made by calling the *Temperature()* function (see [Data Commands](#) for specific information).

TEMPS: *Temperature()* source selection

1 = External temperature sensor is used (default).

0 = Internal temperature sensor is used.

When an external thermistor is selected, REG25 (pin 7) is used to bias the thermistor and TS (pin 11) is used to measure the thermistor voltage (a pull-down circuit is implemented inside the device). The device then correlates the voltage to temperature, assuming the thermistor is a Semitec 103AT or similar device.

The bq34110 device includes a temperature model for the internal as well as external temperature measurements. The external temperature model default values model a Semitec 103AT NTC thermistor.

NOTE: Do not modify these values without consulting with TI.

Table 2-2. Internal Temperature Measurement Model

| Subclass Name | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Units |
|---------------|--------------|----------------|---------------|-----------|-----------|---------------|-------|
| Temp Model | Int Coeff 1 | Signed integer | 2 | –32768 | 32767 | 0 | Num |
| Temp Model | Int Coeff 2 | Signed integer | 2 | –32768 | 32767 | 0 | Num |
| Temp Model | Int Coeff 3 | Signed integer | 2 | –32768 | 32767 | –12324 | Num |
| Temp Model | Int Coeff 4 | Signed integer | 2 | –32768 | 32767 | 6131 | 0.1°K |
| Temp Model | Int Min AD | Signed integer | 2 | –32768 | 32767 | 0 | Num |
| Temp Model | Int Max Temp | Signed integer | 2 | –32768 | 32767 | 6131 | 0.1°K |

Table 2-3. External Temperature Measurement Model

| Subclass Name | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Units |
|---------------|-------------|----------------|---------------|-----------|-----------|---------------|-------|
| Temp Model | Ext Coeff 1 | Signed integer | 2 | –32768 | 32767 | 20982 | Num |
| Temp Model | Ext Coeff 2 | Signed integer | 2 | –32768 | 32767 | –13836 | Num |
| Temp Model | Ext Coeff 3 | Signed integer | 2 | –32768 | 32767 | 5202 | Num |
| Temp Model | Ext Coeff 4 | Signed integer | 2 | –32768 | 32767 | 2337 | 0.1°K |
| Temp Model | Ext Min AD | Signed integer | 2 | –32768 | 32767 | 12909 | Num |

The bq34110 device also includes temperature compensation for the internal voltage reference when used for voltage measurement.

Table 2-4. Internal Voltage Reference Temperature Compensation Model

| Subclass Name | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Units |
|---------------|------------------------|------------------|---------------|-----------|-----------|---------------|-------|
| Temp Model | Vcomp Coeff 1 | Signed integer | 2 | –32768 | 32767 | 0 | Num |
| Temp Model | Vcomp Coeff 2 | Signed integer | 2 | –32768 | 32767 | 14902 | Num |
| Temp Model | Vcomp Coeff 3 | Signed integer | 2 | –32768 | 32767 | –623 | Num |
| Temp Model | Vcomp Coeff 4 | Signed integer | 2 | –32768 | 32767 | 37 | Num |
| Temp Model | Vcomp Input Multiplier | Unsigned integer | 1 | 0 | 255 | 48 | Num |
| Temp Model | Vcomp Output Divisor | Signed integer | 2 | –32768 | 32767 | 256 | Num |

2.4.1 Overtemperature: Charge

If during charging, *Temperature()* reaches the threshold of **OT Chg** for a period of **OT Chg Time** and *AverageCurrent()* > **Charge Detection Threshold**, then the [OTC] bit of *BatteryStatus()* is set.

NOTE: If **OT Chg Time** = 0, then the feature is completely disabled.

2.4.1.1 OT Chg

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|--------|------------------|---------------|-----------|-----------|---------------|-------|
| Safety | OTC | OT Chg | Unsigned Integer | 2 | 0 | 1200 | 550 | 0.1°C |

2.4.1.2 Charge Detection Threshold

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|--------------------|-------------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Current Thresholds | Chg Detection Threshold | Unsigned Integer | 2 | 0 | 2000 | 75 | mA |

2.4.1.3 OT Chg Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-------------|------------------|---------------|-----------|-----------|---------------|------|
| Safety | OTC | OT Chg Time | Unsigned Integer | 1 | 0 | 60 | 2 | s |

2.4.1.4 OT Chg Recovery

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-----------------|------------------|---------------|-----------|-----------|---------------|-------|
| Safety | OTC | OT Chg Recovery | Unsigned Integer | 2 | 0 | 1200 | 500 | 0.1°C |

2.4.2 Overtemperature: Discharge

If during discharging or relaxation, *Temperature()* reaches the threshold of **OT Dsg** for a period of **OT Dsg Time**, and *AverageCurrent()* \leq **Discharge Detection Threshold**, then the [OTD] bit of *BatteryStatus()* is set. If **OT Dsg Time** = 0, then the feature is completely disabled.

When *Temperature()* falls to **OT Dsg Recovery**, the [OTD] bit of *BatteryStatus()* is reset.

2.4.2.1 OT Dsg

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|--------|------------------|---------------|-----------|-----------|---------------|-------|
| Safety | OTD | OT Dsg | Unsigned Integer | 2 | 0 | 1200 | 600 | 0.1°C |

2.4.2.2 OT Dsg Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-------------|------------------|---------------|-----------|-----------|---------------|------|
| Safety | OTD | OT Dsg Time | Unsigned Integer | 1 | 0 | 60 | 2 | s |

2.4.2.3 Discharge Detection Threshold

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|--------------------|-------------------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Current Thresholds | Discharge Detection Threshold | Unsigned Integer | 2 | 0 | 2000 | 60 | mA |

2.4.2.4 OT Dsg Recovery

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-----------------|------------------|---------------|-----------|-----------|---------------|-------|
| Safety | OTD | OT Dsg Recovery | Unsigned Integer | 2 | 0 | 1200 | 550 | 0.1°C |

2.4.3 Undertemperature: Charge

If during charging, *Temperature()* reaches the threshold of **UT Chg** for a period of **UT Chg Time** and *AverageCurrent()* $>$ **Charge Detection Threshold**, then the [UTC] bit of *BatteryStatus()* is set.

NOTE: If **UT Chg Time** = 0, then the feature is completely disabled.

When *Temperature()* rises to **UT Chg Recovery**, the [UTC] of *BatteryStatus()* is reset.

2.4.3.1 UT Chg

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|--------|----------------|---------------|-----------|-----------|---------------|-------|
| Safety | UTC | UT Chg | Signed Integer | 2 | –1200 | 1200 | –100 | 0.1°C |

2.4.3.2 UT Chg Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-------------|------------------|---------------|-----------|-----------|---------------|------|
| Safety | UTC | UT Chg Time | Unsigned Integer | 1 | 0 | 60 | 2 | s |

2.4.3.3 UT Chg Recovery

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-----------------|----------------|---------------|-----------|-----------|---------------|-------|
| Safety | UTC | UT Chg Recovery | Signed Integer | 2 | –1200 | 1200 | 0 | 0.1°C |

2.4.4 Undertemperature: Discharge

If during discharging or relaxation, *Temperature()* reaches the threshold of **UT Dsg** for a period of **UT Dsg Time**, and *AverageCurrent()* ≤ **–Discharge Detection Threshold**, then the [UTD] bit of *BatteryStatus()* is set. If **UT Dsg Time** = 0, then the feature is completely disabled.

When *Temperature()* rises to **UT Dsg Recovery**, the [UTD] bit of *BatteryStatus()* is reset.

2.4.4.1 UT Dsg

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|--------|----------------|---------------|-----------|-----------|---------------|-------|
| Safety | UTD | UT Dsg | Signed Integer | 2 | –1200 | 1200 | –150 | 0.1°C |

2.4.4.2 UT Dsg Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-------------|------------------|---------------|-----------|-----------|---------------|------|
| Safety | UTD | UT Dsg Time | Unsigned Integer | 1 | 0 | 60 | 2 | s |

2.4.4.3 UT Dsg Recovery

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|--------|----------|-----------------|----------------|---------------|-----------|-----------|---------------|-------|
| Safety | UTD | UT Dsg Recovery | Signed Integer | 2 | –1200 | 1200 | –50 | 0.1°C |

2.5 SCALED Mode

The bq34110 device supports high-current and high-capacity batteries above 32.76 A and 29 Ah indirectly by scaling the actual sense resistor value compared with the calibrated value stored in the device. The need for this is due to the standardization of a 2-byte data command having a maximum representation of +/–32767. When the **[SCALED]** bit is set, this indicates that the current and capacity data is scaled.

It is important to know that setting the **[SCALED]** flag does not actually change anything in the operation of the device. It serves as a notice to the host that the various reported values should be reinterpreted based on the scale used. Because the flag has no actual effect, it can be used to represent other scaling values.

NOTE: It is recommended to only scale by a value between 1 and 10 to optimize resolution and accuracy while still extending the data range.

2.6 Accumulated Charge Measurement

The bq34110 device integrates an **Accumulated Charge** function that measures the integrated charge passed in or out of the cell since the integration is reset. This function can be used to generate an alert to the host when a programmable threshold of **Accumulated Charge** is achieved.

The device also integrates the elapsed time since the integration began, assuming the timer has not been interrupted by a power cycle or put into SHUTDOWN mode. This time is read using the command *AccumulatedTime()*. If an event has occurred that interrupted the timer, the value of *AccumulatedTime()* will be fixed unchanging at 0 until the integration is reset.

The charge and time integration is reset at full charge termination or upon issue of the *AccumulationReset()* command. While the battery is discharging (that is, the measured *Current()* is negative), then the charge integration counter increases. If the battery starts charging (that is, the measured *Current()* is positive), then the charge integration counter decreases. The integrated charge value in mAh can be read by the host using the command *AccumulatedCharge()*. The elapsed time (which does not decrease in value) is read by issuing the *AccumulatedTime()* command.

The **Accumulated Charge** calculation uses the current measured across the sense resistor and, similar to the coulomb counter integration, ignores currents below a programmed level controlled by **CC Deadband**. In periods when the bq34110 device is in SNOOZE or SLEEP mode, the **Accumulated Charge** integration includes an estimate of the charge integrated based on analysis of the periodic measured current.

If the user prefers to include cell self-discharge in the integration, this capability can be enabled or disabled using the **[IGNORE_SD_EN]** configuration bit.

The charge integration can also be limited to only include positive (charging) currents, only negative (discharging) currents, or both, through setting the **[ACCHG_EN]** and **[ACDSG_EN]** configuration bits. If **both [ACCHG_EN] and [ACDSG_EN]** are reset, then the timer is halted. These bits can be set using the *ACCUM_CHG_EN()* and *ACCUM_DSG_EN()* commands.

When the cell is fully charged and the FC bit is set due to normal charge termination, then the integration counter is again reset. At this point, the values of **Accumulated Charge** and time just before reset are stored and can be read using *LastAccumulatedCharge()* and *LastAccumulatedTime()*. The values stored in *LastAccumulatedCharge()* and *LastAccumulatedTime()* are cleared each time the command is issued and the respective value read. They are also overwritten whenever the integration counter is reset again. The user can set thresholds to alert the host when *AccumulatedCharge()* reaches a particular level in both the charge (positive) and discharge (negative) directions. These thresholds are set by **Accumulated Charge Positive Threshold** and **Accumulated Charge Negative Threshold**.

NOTE: *AccumulatedCharge()* does not reset when a threshold is reached, the reset should be initiated by the host using *AccumulationReset()*. When a threshold is passed, a flag is set in *OperationStatus()[ACTHR]*.

It is possible for the integration counter to be reset at normal charge termination, but the charger to continue charging the battery for additional time until the charger ceases charging. In this case, the integration counter would reset, then proceed to integrate this additional charge. The user should be aware of this possibility and if it is a concern to plan for a workaround, such as programming the integration to only accumulate discharging currents or to detect when the charger stops charging, and then issue an *AccumulationReset()* command to clear any residual charging integration.

Due to the charge integration and timer information being stored in RAM, any power cycle of the device or putting the device into SHUTDOWN will result in the loss of *AccumulatedCharge()*, *AccumulatedTime()*, *LastAccumulatedCharge()*, and *LastAccumulatedTime()* data.

| Command | R/W | Type | Min | Max | Default | Units |
|-----------------------|-----|---------------------------|--------|-------|---------|-------|
| AccumulatedCharge | R | Signed integer, 2-bytes | –32767 | 32767 | 0 | mAh |
| LastAccumulatedCharge | R | Signed integer, 2-bytes | –32767 | 32767 | 0 | mAh |
| AccumulatedTime | R | Unsigned integer, 2-bytes | 0 | 65535 | 0 | 5 min |
| LastAccumulatedTime | R | Unsigned integer, 2-bytes | 0 | 65535 | 0 | 5 min |
| AccumulationReset | W | Boolean | NA | NA | NA | |

2.6.1 Accumulated Charge Positive Threshold

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|--------------------|---------------------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Settings | Accumulated Charge | Accumulated Charge Positive Threshold | Signed Integer | 2 | 0 | 32767 | 1000 | mAh |

2.6.2 Accumulated Charge Negative Threshold

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|--------------------|---------------------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Settings | Accumulated Charge | Accumulated Charge Negative Threshold | Signed Integer | 2 | 0 | 32767 | 1000 | mAh |

2.7 Gas Gauging

The bq34110 device implements a Compensated End of Discharge Voltage (CEDV) gauging algorithm, which accurately predicts the battery capacity and other operational characteristics of a rechargeable cell or pack. It can be interrogated by a system processor through the I²C communication interface to provide cell information, such as time-to-empty (TTE), state-of-charge (SOC), and state-of-health (SOH). Changes in flag values associated with configurable thresholds or settings within the algorithm can also be provided to the host as an interrupt using one of the two ALERT pins on this device. The data from the gas gauge function is provided in units of mAh, and the device is capable of gauging a maximum capacity of 32 Ah. The operational overview in [Figure 2-2](#) illustrates the gas gauge operation of the bq34110 device.




Figure 2-2. bq34110 Gas Gauging Overview

2.7.1 CEDV Gas Gauging Operational Overview

The bq34110 device accumulates the measured quantities of charge and discharge and estimates self-discharge of the battery. The bq34110 device compensates the charge current measurement for temperature and state-of-charge of the battery. The bq34110 device also adjusts the self-discharge estimation based on temperature. The initial battery state-of-charge estimation on first insertion of the battery pack in the system may display a factor of the true value. The system must go through a full charge and then a full discharge cycle before the correct *FullChargeCapacity()* (FCC) is estimated.

The main charge counter, *RemainingCapacity()* (RC), represents the available charge or energy capacity in the battery at any given time. The bq34110 device adjusts RC for charge, self-discharge, and other compensation factors. The information in the RC register is accessible through the I²C interface. The *FullChargeCapacity()* (FCC) register represents the initial or last measured full discharge of the battery. It is used as the battery full-charge reference for relative capacity indication. The bq34110 device updates FCC after the battery undergoes a qualified discharge from nearly full to a low battery level. FCC is accessible through the I²C interface.

The Discharge Count Register (DCR) is an internal register that tracks discharge of the battery. The bq34110 device uses the DCR to update the FCC register if the battery undergoes a qualified discharge from nearly full to a low battery level. In this way, the bq34110 device learns the true discharge capacity of the battery under-system use conditions.

2.7.2 Main Gas Gauge Registers

Remaining Capacity (RC)—Remaining capacity in the battery

RC represents the remaining capacity in the battery. The bq34110 device computes RC in units of mAh.

RC counts up during charge to a maximum value of *FCC* and down during discharge and self-discharge to a minimum of 0. In addition to charge and self-discharge compensation, the bq34110 device calibrates *RC* at three low-battery-voltage thresholds—EDV2, EDV1, and EDV0. This provides a voltage-based calibration to the *RC* counter.

Design Capacity (DC)—User-specified battery full capacity

DC is the user-specified battery full charge capacity in units of mAh and is calculated from **Design Capacity**. *DC* also represents the full-battery reference for the absolute display mode.

Table 2-5. Design Capacity

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|--------------|-----------------|----------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Profile | Design Capacity | Signed Integer | 2 | 0 | 32767 | 2200 | mAh |

Full Charge Capacity (FCC)—Last measured discharge capacity of the battery

FCC is the last measured discharge capacity of the battery. It is represented in units of mAh. On initialization, the bq34110 device sets *FullChargeCapacity()* to the data flash value stored in **Learned Full Charge Capacity** (*FCC*), which should be initialized using the same units. During subsequent discharges, the bq34110 device updates *FullChargeCapacity()* with the last measured discharge capacity of the battery. The last measured discharge of the battery is based on the value in the DCR after a qualified discharge occurs. Once updated, the bq34110 device writes the new *FullChargeCapacity()* value to data flash to **Learned Full Charge Capacity**. *FullChargeCapacity()* represents the full battery reference for the state-of-charge calculations.

Discharge Count Register (DCR)—The DCR counts up during discharge, independent of *RC*. The DCR counts discharge activity, battery load estimation, and self-discharge increment.

The bq34110 device initializes the *DCR* at the beginning of a discharge to $FCC - RC$ when *RC* is within the programmed value in **Near Full**. The DCR initial value of $FCC - RC$ is reduced by $FCC/128$ if *[SC]* = 1 in **CEDV Gauging Configuration** and is not reduced if *[SC]* = 0. The DCR stops counting when the battery voltage reaches the EDV2 threshold on discharge. The *DCR* uses the same units as *FCC* and *RC*.

Cycle Count —The number of cycles the battery has experienced is calculated and tracked by the bq34110 device.

One cycle occurs when the accumulated discharge \geq cycle threshold. The cycle threshold is calculated as **Cycle Count Percentage** times either *FullChargeCapacity()* (when **CEDV Gauging Configuration**[*CCT*] = 1) or *DesignCapacity()* (when **CEDV Gauging Configuration**[*CCT*] = 0). The device saves the cycle count value to **Cycle Count**, which is read using the command *CycleCount()*.

NOTE: A minimum of 10% of a *DesignCapacity()* change of the accumulated discharge is required for a cycle count increment. This prevents an erroneous cycle count increment due to extremely low *FullChargeCapacity()*.

Table 2-6. Cycle Count

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|---------------|-------------|------------------|---------------|-----------|-----------|---------------|-------|
| Gas Gauging | State Profile | Cycle Count | Unsigned Integer | 2 | 0 | 65535 | 0 | count |

Table 2-7. Cycle Count Percentage

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|------------------------|------------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | Cycle | Cycle Count Percentage | Unsigned Integer | 1 | 0 | 100 | 90 | % |

2.7.3 Capacity Learning (FCC Update) and Qualified Discharge

The bq34110 device updates *FCC* with an amount based on the value in *DCR* if a qualified discharge occurs. The new value for *FCC* equals the *DCR* value plus the programmable **Near Full** and low battery levels per the following equation:

$$FCC \text{ (new)} = DCR \text{ (final)} = DCR \text{ (initial)} + \text{Measured Discharge to EDV2} + (FCC \times \text{Battery_Low\%}) \quad (6)$$

Where **Battery_Low%** = (**Battery Low%** value in data flash) ÷ 100

A qualified discharge occurs if the battery discharges from $RC \geq FCC - \text{Near Full}$ to the EDV2 voltage threshold with the following conditions:

- No valid charge activity occurs during the discharge period. A valid charge is defined as a charge of 10 mAh into the battery.
- No more than 256 mAh of self-discharge or battery load estimation occurs during the discharge period.
- The temperature does not drop below the low temperature thresholds programmed in **Low Temp** during the discharge period.
- The battery voltage reaches the EDV2 threshold during the discharge period and the voltage is greater than or equal to the EDV2 threshold – 256 mV when the bq34110 device detected EDV2.
- Current remains $\geq 3C/32$ when EDV2 is reached.
- No overload condition exists when the EDV2 threshold is reached or if RC has dropped to **Battery_Low % × FCC**.

The bq34110 device sets $[VDQ] = 1$ in *OperationStatus()* when a qualified discharge begins. The bq34110 device sets $[VDQ] = 0$ if any disqualifying condition occurs. One complication may arise regarding the state of $[VDQ]$ if **[CSYNC]** is set in **CEDV Gauging Configuration**. When **[CSYNC]** is enabled, *RemainingCapacity()* is written to equal *FullChargeCapacity()* on valid primary charge termination. This capacity synchronization is done even if the condition $RC \geq FCC - \text{Near Full}$ is not satisfied at charge termination.

FCC cannot be reduced by more than **FCC Learn Down** or increased by more than **FCC Learn Up** during any single update cycle. If **[FCC_LIMIT]** is set in **CEDV Gauging Configuration**, then *FCC* cannot learn above the **Design Capacity**. The bq34110 device saves the new *FCC* value to the data flash within 4 s of being updated.

2.7.4 End-of-Discharge Thresholds and Capacity Correction

The bq34110 device monitors the battery for three low-voltage thresholds: EDV0, EDV1, and EDV2.

If the **[EDV_CMP]** bit in **CEDV Gauging Configuration** is clear, fixed EDV thresholds may be programmed in **Fixed EDV0**, **Fixed EDV1**, and **Fixed EDV2** in mV.

If the **[EDV_CMP]** bit in **CEDV Gauging Configuration** is set, automatic EDV compensation is enabled and the bq34110 device computes the EDV0, EDV1, and EDV2 thresholds based on values stored in the selected CEDV profile in data flash and the battery's current discharge rate and temperature. If the **[FIXED_EDV0]** bit in **CEDV Gauging Configuration** is also set, then the EDV0 threshold will be set to the programmed **Fixed EDV0**, and the EDV1 and EDV2 compensated thresholds will not go below the programmed **Fixed EDV0**.

The bq34110 device disables EDV detection if current exceeds the **Overload Current** threshold. The bq34110 device resumes EDV threshold detection after current drops below the **Overload Current** threshold. Any EDV threshold detected is reset after charge is applied, and $[VDQ]$ is cleared after 10 mAh of charge.

| Class | Subclass | Name | Format | Size in Bytes | Min | Max | Default | Unit |
|-------------|----------|------------------|----------------|---------------|-----|-------|---------|------|
| Gas Gauging | CEDV Cfg | Overload Current | Signed Integer | 2 | 0 | 32767 | 5000 | mA |

The bq34110 device uses the EDV thresholds to apply voltage-based corrections to the RC register per to the content in [Table 2-8](#).

Table 2-8. State-of-Charge Based on Low Battery Voltage

| Threshold | Relative State-of-Charge (RSOC) |
|-----------|---------------------------------|
| EDV0 | 0% |
| EDV1 | 3% |
| EDV2 | Battery Low% |

The bq34110 device performs EDV-based RC adjustments with $Current() \geq 3C/32$. No EDVs are set if $Current() < C/32$. The bq34110 device adjusts RC as it detects each threshold. If the voltage threshold is reached before the corresponding capacity on discharge, the bq34110 device reduces RC to the appropriate amount, as shown in [Table 2-8](#).

If an RC % level is reached on discharge before the voltage reaches the corresponding threshold, then RC is held at that % level until the threshold is reached. RC is only held if $[VDQ] = 1$, indicating a valid learning cycle is in progress. If **Battery_Low%** is set to zero, EDV1 and EDV0 corrections are disabled.

2.7.5 EDV Discharge Rate and Temperature Compensation

If EDV compensation is enabled, the bq34110 device calculates battery voltage to determine EDV0, EDV1, and EDV2 thresholds as a function of battery capacity, temperature, and discharge load. The general equation for EDV0, EDV1, and EDV2 calculation is as follows:

$$EDV_{0,1,2} = n (EMF \times FBL - |I_{LOAD}| \times R0 \times FTZ) \quad (7)$$

- EMF is a no-load cell voltage higher than the highest cell EDV threshold computed. EMF is programmed in mV in **EMF**.
- I_{LOAD} is the current discharge load magnitude.
- n = the number of series cells.
- FBL is the factor that adjusts the EDV voltage for battery capacity and temperature to match the no-load characteristics of the battery.

$$FBL = f(C0, C + C1, T) \quad (8)$$

- C (either 0%, 3% or Battery Low% for EDV0, EDV1, and EDV2, respectively) and C0 are the capacity related EDV adjustment factors. C0 is programmed in the CEDV profile **C0**. C1 is the needed residual battery capacity remaining at EDV0 (RC = 0). The C1 factor is stored in the CEDV profile **C1**.
- T is the current temperature in °K.
- $R0 \cdot FTZ$ represents the resistance of a cell as a function of temperature and capacity.

$$FTZ = f(R1, T0, C + C1, TC) \quad (9)$$

- R0 is the first order rate dependency factor stored in the CEDV profile **R0**.
- T is the current temperature. C is the battery capacity relating to EDV0, EDV1, and EDV2.
- R1 adjusts the variation of impedance with battery capacity. R1 is programmed in the CEDV profile **R1**.
- T0 adjusts the variation of impedance with battery temperature. T0 is programmed in the CEDV profile **T0**.
- TC adjusts the variation of impedance for cold temperatures ($T < 23^\circ\text{C}$) TC is programmed in the CEDV profile **TC**.

The graphs below show the calculated EDV0, EDV1, and EDV2 thresholds versus capacity using the typical compensation values for different temperatures and loads for a Li-Ion 18650 cell. The compensation values vary widely for different cell types and manufacturers and must be matched exactly to the unique characteristics for optimal performance.




Figure 2-3. (a) EDV Calculations vs Capacity for Various Temperatures, (b) EDV Calculations vs Capacity for Various Loads

2.7.6 EDV Age Factor

The EDV **Age Factor** allows the bq34110 device to correct the EDV detection algorithm to compensate for cell aging. This parameter scales cell impedances as the cycle count increases. This new factor is used to accommodate for much higher impedances observed in larger capacity and/or aged cells. For most applications, the default value of zero is sufficient. However, for some very specific applications, this new aging factor may be required. In those cases, experimental data must be taken at the 0, 100, 200, and 300 cycle read points using a typical discharge rate while at ambient temperature. Entering this data into a TI provided MathCAD™ program will yield the appropriate EDV **Age Factor** value. Contact TI Applications Support @ <http://www-k.ext.ti.com/sc/technical-support/email-tech-support.asp?AAP> for more detailed information.

2.7.7 Self-Discharge

The bq34110 device estimates the self-discharge of the battery to maintain an accurate measure of the battery capacity during periods of inactivity. The bq34110 device makes self-discharge adjustments to RC every 1/4 second when awake and periodically when in SLEEP mode. The period is determined by **Sleep Current Time**.

The self-discharge estimation rate is a continuous function that doubles for every increase of 10 degrees, and halves for each decrease of 10 degrees. Table 2-9 shows the relation of the self-discharge estimation at a given temperature to the programmed rate.

Table 2-9. Self-Discharge for Rate Programmed

| TEMPERATURE (°C) | SELF-DISCHARGE RATE |
|------------------|---------------------|
| Temp = 0C | 1/4 Y% per day |
| Temp = 10C | ½ Y% per day |
| Temp = 20C | Y% per day |
| Temp = 30C | 2Y% per day |
| Temp = 40C | 4Y% per day |
| Temp = 50C | 8Y% per day |
| Temp = 60C | 16Y% per day |
| Temp = 70C | 32Y% per day |

The nominal self-discharge rate, %PERDAY (% per day), is programmed in an 8-bit value **Self-Discharge Rate** by the following relation:

$$\text{Self-Discharge Rate} = \%PERDAY / 0.01$$

Table 2-10. Self-Discharge Rate

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|---------------------|------------------|---------------|-----------|-----------|----------------------------------|---------------|
| Gas Gauging | CEDV Cfg | Self-Discharge Rate | Unsigned Integer | 1 | 0 | 255 | 20 (corresponds to 0.2% per day) | 0.01% per day |

2.7.8 Battery Electronic Load Compensation

The bq34110 device can be configured to compensate for a constant load (as from battery electronics) present in the battery pack at all times. The bq34110 device applies the compensation continuously when the charge or discharge is below the digital filter. The bq34110 device applies the compensation in addition to self-discharge. The compensation occurs at a rate determined by the value stored in **Electronics Load**. The compensation range is 0 μ A–765 μ A in steps of approximately 3 μ A.

The amount of internal battery electronics load estimate in μ A, BEL, is stored as follows:

$$\text{Electronics Load} = BEL/3$$

2.7.9 CEDV Configuration

Various gas gauging features can be configured by the **CEDV Gauging Configuration** data flash.

Table 2-11. CEDV Gauging Configuration

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|---------------|----------------------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | Configuration | CEDV Gauging Configuration | Hex | 2 | 0x0000 | 0xFFFF | 0x102A | — |

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|-------|----------------|-------|---------|-------------|-------|-----------|
| High Byte | RSVD | RSVD | RESTORE_REMCAP | SME0 | RSVD | FCC_FOR_VDQ | RSVD | FCC_LIMIT |
| Low Byte | RSVD | RSVD | FIXED_EDV0 | SC | EDV_CMP | RSVD | CSYNC | CCT |

Legend = **RSVD**: Reserved. Do not use.

RESTORE_REMCAP: Restore *RemainingCapacity()*

- 1 = Upon reset or power-up, the device restores the previous value of *RemainingCapacity()*, which was stored before going into shutdown.
- 0 = The device does not restore the previous value of *RemainingCapacity()* after reset or power-up, but instead recalculates it.

SME0: Smoothing Configuration (See [CEDV Smoothing](#) for more information.)

- 1 = SOC smooths directly to EDV0.
- 0 = SOC smooths to EDV2, then to EDV1, then and EDV0.

FCC_FOR_VDQ: Capacity Learning during Qualified Discharge

- 1 = The device only updates FCC when full charge termination is detected.
- 0 = The device updates FCC per capacity learning criteria.

FCC_LIMIT: The **FCC_LIMIT** bit selects whether FCC limit can go above **Design Capacity**.

- 1 = FCC is limited to **Design Capacity**.
- 0 = FCC can learn above **Design Capacity**.

FIXED_EDV0: The **FIXED_EDV0** bit selects whether EDV0 is always fixed.

1 = EDV0 will always use **Fixed EDV0**. EDV1 and EDV2 compensation will not go below **Fixed EDV0**.

0 = EDV0 is determined based on the **[EDV_CMP]** bit.

SC: The **SC** bit enables learning cycle optimization for a Smart Charger or independent charge.

1 = Learning cycle is optimized for independent charger.

0 = Learning cycle is optimized for Smart Charger.

EDV_CMP: The **EDV_CMP** bit determines whether the bq34110 device implements automatic EDV compensation to calculate the EDV0, EDV1, and EDV2 thresholds based on rate, temperature, and capacity.

If the bit is cleared, the bq34110 device uses the fixed values programmed in data flash for EDV0, EDV1, and EDV2. If the bit is set, the bq34110 device calculates EDV0, EDV1, and EDV2.

1 = EDV compensation is enabled.

0 = EDV compensation is disabled.

CSYNC: The CSYNC bit selects whether RC is set to FCC at charge termination.

1 = RC will be set to FCC when charge termination is reached.

0 = RC is not changed when charge termination is reached.

CCT: Cycle Count Threshold

1 = The device evaluates a percentage of *FullChargeCapacity()* when determining if a cycle is counted.

0 = The device evaluates a percentage of *DesignCapacity()* when determining if a cycle is counted (default).

The *GaugingStatus()* *ManufacturerAccessControl()* subcommand returns flags associated with the CEDV gas gauging function.

Table 2-12. *GaugingStatus()*

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|-------|-------|-------|-------|-------|-------|-------|
| High Byte | VDQ | EDV2 | EDV1 | RSVD | RSVD | FCCX | RSVD | REST |
| Low Byte | CF | DSG | EDV | RSVD | TC | TD | FC | FD |

Legend = **RSVD:** Reserved. Do not use.

VDQ: Discharge Qualified for Learning

1 = Detected

0 = Not Detected

EDV2: End-of-Discharge Voltage Level 2

1 = EDV2 voltage is reached during discharge.

0 = EDV2 voltage is not reached or not in DISCHARGE mode.

EDV1: Discharge Qualified for Learning

1 = Detected

0 = Not Detected

FCCX: *FullChargeCapacity()* is updated.

This bit changes state each time *FullChargeCapacity()* updates.

REST: This bit indicates whether the device is in RELAX mode.

1 = The device has reached relaxation.

0 = The device has not reached relaxation.

CF: Condition Flag

- 1 = This bit is set if the device determines that the error in gauging has reached a level where a condition cycle is needed (discharging to EDV2 and charging to full).
- 0 = Gauging error has not reached the level where a condition cycle is needed.

DSG: Discharge/Relax

This bit is set whenever the cell is detected in a RELAX state or discharging, but not when charging. Note that this bit differs from the DSG bit in *BatteryStatus()*, which is set only when a discharge current is present, but not during relaxation.

- 1 = Charging is not detected.
- 0 = Charging is detected.

EDV0: End-of-Discharge Voltage Level 0 (Termination)

- 1 = Termination voltage is reached during DISCHARGE.
- 0 = Termination voltage is not reached or not in DISCHARGE mode.

TC: Terminate Charge

- 1 = Detected
- 0 = Not Detected

TD: Terminate Discharge

- 1 = Detected
- 0 = Not Detected

FC: Fully Charged

- 1 = Detected
- 0 = Not Detected

FD: Fully Discharged

- 1 = Detected
- 0 = Not Detected

2.7.10 Initial Battery Capacity at Device Reset

The bq34110 device estimates the initial capacity of a battery pack at device reset, which is the case when battery cells are first attached to the application circuit. The initial *FullChargeCapacity()* (*FCC*) is a direct copy of the data flash parameter **Learned Full Charge Capacity**. The initial RC is estimated using the voltage characteristics of the programmed battery voltage table (see **Voltage 0% DOD** through **Voltage 100% DOD**) and **Learned Full Charge Capacity**. Upon the update of RC based on the battery voltage table data, the *GaugingStatus()* [*CF*] flag will be cleared. This gives a reasonably accurate RC; however, battery capacity learning is required in order to find the accurate FCC and RC.

The determined value of remaining capacity can be further scaled, if needed, through the value of **RemCap Init Percent**. Upon a reset, the final value of *RemainingCapacity()* is initialized from the **RemCap Init Percent** value of the initial value correlated to the battery voltage table.

Table 2-13. Rem Cap Init Percent

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|----------------------|------------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Cfg | Rem Cap Init Percent | Unsigned Integer | 1 | 0 | 110 | 100 | % |

The data flash parameter **Learned Full Charge Capacity** should be programmed to the **Design Capacity** at initial device setup.

Table 2-14. Voltage % DOD

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|--------------|-----------------|----------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Profile | Voltage 0% DOD | Signed Integer | 2 | –32768 | 32767 | 4173 | mV |
| Gas Gauging | CEDV Profile | Voltage 10% DOD | Signed Integer | 2 | –32768 | 32767 | 4043 | mV |

Table 2-14. Voltage % DOD (continued)

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|--------------|------------------|----------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Profile | Voltage 20% DOD | Signed Integer | 2 | –32768 | 32767 | 3925 | mV |
| Gas Gauging | CEDV Profile | Voltage 30% DOD | Signed Integer | 2 | –32768 | 32767 | 3821 | mV |
| Gas Gauging | CEDV Profile | Voltage 40% DOD | Signed Integer | 2 | –32768 | 32767 | 3725 | mV |
| Gas Gauging | CEDV Profile | Voltage 50% DOD | Signed Integer | 2 | –32768 | 32767 | 3656 | mV |
| Gas Gauging | CEDV Profile | Voltage 60% DOD | Signed Integer | 2 | –32768 | 32767 | 3619 | mV |
| Gas Gauging | CEDV Profile | Voltage 70% DOD | Signed Integer | 2 | –32768 | 32767 | 3582 | mV |
| Gas Gauging | CEDV Profile | Voltage 80% DOD | Signed Integer | 2 | –32768 | 32767 | 3515 | mV |
| Gas Gauging | CEDV Profile | Voltage 90% DOD | Signed Integer | 2 | –32768 | 32767 | 3439 | mV |
| Gas Gauging | CEDV Profile | Voltage 100% DOD | Signed Integer | 2 | –32768 | 32767 | 2713 | mV |

2.7.11 Gas Gauge Operating Modes

Entry and exit of each mode is controlled by data flash parameters in the **Current Thresholds** subclass. The *[DSG]* flag referenced below is from the *MAC GaugingStatus()* subcommand and is set in both RELAX and DISCHARGING modes. The *[DSG]* flag in *BatteryStatus()* is slightly different—it sets only in DISCHARGING mode and not in RELAX mode.

CHARGE mode is exited and RELAX mode is entered when *Current()* goes below **Quit Current** for a period of **Charge Relax Time**. DISCHARGE mode is entered when *Current()* goes below **(–)Dsg Current Threshold**. DISCHARGE mode is exited and RELAX mode is entered when *Current()* goes above **(–)Quit Current** threshold for a period of **Discharge Relax Time**. CHARGE mode is entered when *Current()* goes above **Chg Current Threshold**.

Table 2-15. Charge Relax Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|--------------------|-------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Current Thresholds | Charge Relax Time | Unsigned Integer | 1 | 0 | 255 | 60 | s |

Table 2-16. Discharge Relax Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|--------------------|----------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Current Thresholds | Discharge Relax Time | Unsigned Integer | 2 | 0 | 8191 | 60 | s |




Figure 2-4. Fuel Gauge Operating Mode Example

2.7.12 CEDV Smoothing

The bq34110 device has the ability to smooth the *RemainingCapacity()* during discharge in order to avoid a drop in *RelativeStateOfCharge()* when the EDV thresholds are reached. This feature is enabled by setting the **Smoothing Config [SMEN]** = 1 and configuring the **Smoothing Start Voltage** and **Smoothing Delta Voltage**.

The smoothing will activate only when all of the following conditions are true:

- *Current()* < 0
- *Voltage()* < **Smoothing Start Voltage**
- EDV2 was reached (*[EDV2]* = 1) OR (*Voltage()* – present EDV2 threshold) < **Smoothing Delta Voltage**.
- *Maximum Voltage()* during the previous one minute is greater than the maximum *Voltage()* during the current minute (that is, "drop rate" is greater than zero).
- *RemainingCapacity()* is greater than the capacity at the next EDV point.

While smoothing is active, the "drop rate" is used to estimate the time to the EDV point under the assumption that the rate is constant (linear). This information is then used to estimate how much current would need to be applied in order to have *RemainingCapacity()* reach the expected capacity at the EDV point. The actual *Current()* is then scaled by the "smoothing current." This will either speed up or slow down the *RemainingCapacity()* accumulation to reach the EDV threshold at the correct time.

Whenever the *RemainingCapacity()* accumulation is actively scaled, the *OperationStatus()*[*SMTH*] bit will be set.

The smoothing will deactivate whenever an EDV threshold is reached until the rate to the next EDV threshold can be calculated. However, smoothing past the EDV2 point will only occur if the **Smoothing Config [SMEXT]** is set to 1.

To improve smoothing at the end of discharge, the SME0 configuration bit provides additional flexibility. This is particularly useful when **FIXED_EDV0** is set and the calculated EDV2/EDV1 is lower than EDV0. In this scenario, the SOC smooths to EDV2, then to EDV1, and then to EDV0, leading to SOC jumps. If the SME0 bit is set, then the SOC smooths directly to EDV0, leading to a smooth transition to empty.

Table 2-17. Smoothing Configurations

| SMEN | SMEXT | SME0 | Description |
|------|-------|------|--|
| 0 | 0 | 0 | No Smoothing |
| 0 | 0 | 1 | No Smoothing |
| 0 | 1 | 0 | No Smoothing |
| 0 | 1 | 1 | No Smoothing |
| 1 | 0 | 0 | Smoothing to EDV2 |
| 1 | 0 | 1 | Smoothing to EDV0 if calculated EDV2/EDV1 is less than EDV0. |
| 1 | 1 | 0 | Smoothing to EDV2 \geq EDV1 \geq EDV0 |
| 1 | 1 | 1 | Smoothing to EDV0 if calculated EDV2/EDV1 is less than EDV0. |

Table 2-18. Smoothing Start Voltage

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|-----------------------|-------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Smoothing Config | Smoothing Start Voltage | Signed Integer | 2 | 0 | 4300 | 3700 | mV |

Table 2-19. Smoothing Delta Voltage

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|-----------------------|-------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Gas Gauging | CEDV Smoothing Config | Smoothing Delta Voltage | Signed Integer | 2 | 0 | 4200 | 100 | mV |

Table 2-20. Smoothing Config

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------|-----------------------|------------------|--------|---------------|-----------|-----------|---------------|------|
| Gauging | CEDV Smoothing Config | Smoothing Config | Hex | 1 | 0x00 | 0xff | 0x08 | — |

| | | | | | | | |
|------|------|------|------|---------------|-------|------|------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | RSVD | RSVD | RSVD | SMOOTH EOC_EN | SMEXT | VAVG | SMEN |

Legend = **RSVD**: Reserved. Do not use.

SMOOTH EOC_EN: In situations when the FCC is not updated during a discharge cycle or on a subsequent charge cycle, if the valid charge termination is reached, RSOC is synced to 100% regardless of the true RSOC.

When enabled, the RSOC value is gradually increased to 100% instead of a sudden jump in selected situations. The default is 1 (enabled).

SMEXT: When set to 1, smoothing will continue to EDV1 and EDV0 points.

When set to 0, smoothing will stop at EDV2. The default is 0.

VAVG: When set to 1, smoothing uses average voltage.

When set to 0 smoothing will use measured voltage. The default is 0.

SMEN: When set to 1 the smoothing result will be reported on *RemainingCapacity()*.

When set to 0 the normal CEDV remaining capacity will be reported. The default is 0.

2.8 Battery Condition Warnings

2.8.1 Battery Low Warning

The bq34110 device can indicate, and optionally trigger an alert signal, when the battery voltage falls below a programmable threshold. This feature is disabled if **Battery Low Time** is set to 0.

NOTE: If **Battery Low Time** is set to 30 seconds or higher, the device may initiate an automatic offset calibration during the time window, resulting in the BATLOW signal being delayed approximately an additional 15–20 seconds beyond the **Battery Low Time** setting.

| Status | Condition | Action |
|----------|---|-------------------------------|
| Normal | $Voltage() > \text{BATLOW: Battery Low Set Threshold}$ | $BatteryStatus()[BATLOW] = 0$ |
| Trip | $Voltage() \leq \text{BATLOW: Battery Low Set Threshold}$ For BATLOW: Battery Low Time | $BatteryStatus()[BATLOW] = 1$ |
| Recovery | $Voltage() > \text{BATLOW: Battery Low Clear Threshold}$ | $BatteryStatus()[BATLOW] = 0$ |

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|--------|----------|-----------------------------|---------|------|-----------|-----------|---------------|------|
| Safety | BATLOW | Battery Low Set Threshold | Integer | 2 | 0 | 5000 | 3150 | mV |
| Safety | BATLOW | Battery Low Time | Integer | 1 | 0 | 255 | 2 | s |
| Safety | BATLOW | Battery Low Clear Threshold | Integer | 2 | 0 | 5000 | 3400 | mV |

2.8.2 Battery High Warning

The bq34110 device can indicate and optionally trigger an alert signal when the battery voltage falls below a programmable threshold. This feature is disabled if **Battery High Time** is set to 0.

| Status | Condition | Action |
|----------|--|--------------------------------|
| Normal | $Voltage() > \text{BATHIGH: Battery High Set Threshold}$ | $BatteryStatus()[BATHIGH] = 0$ |
| Trip | $Voltage() \leq \text{BATHIGH: Battery High Set Threshold}$ For BATHIGH: Battery High Time duration | $BatteryStatus()[BATHIGH] = 1$ |
| Recovery | $Voltage() > \text{BATHIGH: Battery High Clear Threshold}$ | $BatteryStatus()[BATHIGH] = 0$ |

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|--------|----------|------------------------------|---------|------|-----------|-----------|---------------|------|
| Safety | BATHIGH | Battery High Set Threshold | Integer | 2 | 0 | 5000 | 4200 | mV |
| Safety | BATHIGH | Battery High Time | Integer | 1 | 0 | 255 | 2 | s |
| Safety | BATHIGH | Battery High Clear Threshold | Integer | 2 | 0 | 5000 | 4100 | mV |

2.8.3 Battery Low SOC Warning

The bq34110 device can indicate, and optionally trigger an alert signal, when the battery state-of-charge (SOC) falls below a programmable threshold. This feature is disabled by setting **SOC Low Threshold** and **SOC Low Recovery** to 0.

| Status | Condition | Action |
|----------|---|-------------------------------|
| Normal | $RelativeStateOfCharge() > \text{SOC Low Threshold}$ | $BatteryStatus()[SOCLOW] = 0$ |
| Trip | $RelativeStateOfCharge() \leq \text{SOC Low Threshold}$ | $BatteryStatus()[SOCLOW] = 1$ |
| Recovery | $RelativeStateOfCharge() > \text{SOC Low Recovery}$ | $BatteryStatus()[SOCLOW] = 0$ |

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|--------|----------|-------------------|----------------|------|-----------|-----------|---------------|------|
| Safety | SOCLOW | SOC Low Threshold | Signed Integer | 1 | 0 | 100 | 10 | % |
| Safety | SOCLOW | SOC Low Recovery | Integer | 1 | 0 | 100 | 30 | % |

2.9 Charging and Charge Termination

For proper bq34110 operation, the battery per cell charging voltage should be specified by the user in the 3 **Charge Voltage T#-T#** registers. These parameters should be set to the recommended charging voltage for the entire battery stack divided by the number of series cells.

The bq34110 device includes multiple algorithms for charging and charge termination, including JEITA-based charging, temperature-based charging, negative delta voltage based charging, and WHr charging.

The *ChargingVoltage()* and *ChargingCurrent()* will be selected by the bq34110 device following the *JEITA* method depending on the [JEITA] bit setting. If this bit is set, the voltage and current is selected based on the settings in **Charge Voltage T#-T#**, **Charge Current T#-T#**, and **JEITA T# Temp**. The **JEITA T# Temp** provides temperature boundaries for the temperature category.

If *Temperature()* < **JEITA T1 Temp**, then charging is inhibited,

ChargingVoltage() = 0,

ChargingCurrent() = 0.

If **JEITA T1 Temp** ≤ *Temperature()* ≤ **JEITA T2 Temp**, then

ChargingVoltage() = **Charge Voltage T1 – T2**,

ChargingCurrent() = **Charge Current T1 – T2**.

If **JEITA T2 Temp** < *Temperature()* ≤ **JEITA T3 Temp**, then

ChargingVoltage() = **Charge Voltage T2 – T3**,

ChargingCurrent() = **Charge Current T2 – T3**.

If **JEITA T3 Temp** < *Temperature()* ≤ **JEITA T4 Temp**, then

ChargingVoltage() = **Charge Voltage T3 – T4**,

ChargingCurrent() = **Charge Current T3 – T4**.

If **JEITA T4 Temp** < *Temperature()*, then charging is inhibited,

ChargingVoltage() = 0,

ChargingCurrent() = 0.

If the [JEITA] bit is reset (and WHr Charging is not enabled), then operation is as follows:

If *Temperature()* < **JEITA T1 Temp**, then charging is inhibited,

ChargingVoltage() = 0,

ChargingCurrent() = 0.

If **JEITA T1 Temp** ≤ *Temperature()* ≤ **JEITA T4 Temp**, then

ChargingVoltage() = **Charge Voltage T2 – T3**,

ChargingCurrent() = **Charge Current T2 – T3**.

If **JEITA T4 Temp** < *Temperature()*, then charging is inhibited,

ChargingVoltage() = 0,

ChargingCurrent() = 0.

The device detects valid charge termination in one of three ways:

1. Current Taper method:

- During two consecutive periods of **Current Taper Window**, the *AverageCurrent()* is less than **Taper Current** AND
- During the same periods, the accumulated change in capacity > **Minimum Taper Capacity** AND
- Voltage()* is > *ChargingVoltage()* – **Taper Voltage**. When this occurs, the [CHG] bit of *BatteryStatus()* is cleared. Also, if the [CSYNC] bit of **CEDV_Gauging_Configuration** is set, and *RemainingCapacity()* is set equal to *FullChargeCapacity()*.

Table 2-21. Charger Control Class

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|-----------------|-------------------------|--------------------------|------------------|------|-----------|-----------|---------------|---------|
| Charger Control | Charge Inhibit Cfg | Chg Inhibit Temp Low | Signed integer | 2 | –400 | 1200 | 0 | 0.1°C |
| Charger Control | Charge Inhibit Cfg | Chg Inhibit Temp High | Signed integer | 2 | –400 | 1200 | 450 | 0.1°C |
| Charger Control | Charge Inhibit Cfg | Temp Hys | Signed integer | 2 | 0 | 100 | 50 | 0.1°C |
| Charger Control | JEITA Temperature | T1 Temp | Signed integer | 2 | –400 | 1200 | 0 | 0.1°C |
| Charger Control | JEITA Temperature | T2 Temp | Signed integer | 2 | –400 | 1200 | 100 | 0.1°C |
| Charger Control | JEITA Temperature | T3 Temp | Signed integer | 2 | –400 | 1200 | 450 | 0.1°C |
| Charger Control | JEITA Temperature | T4 Temp | Signed integer | 2 | –400 | 1200 | 550 | 0.1°C |
| Charger Control | JEITA Temperature | Charge Current T1-T2 | Signed integer | 2 | 0 | 32767 | 300 | mA |
| Charger Control | JEITA Temperature | Charge Current T2-T3 | Signed integer | 2 | 0 | 32767 | 660 | mA |
| Charger Control | JEITA Temperature | Charge Current T3-T4 | Signed integer | 2 | 0 | 32767 | 1100 | mA |
| Charger Control | JEITA Temperature | Charge Voltage T1-T2 | Signed integer | 2 | 0 | 32767 | 4100 | mV |
| Charger Control | JEITA Temperature | Charge Voltage T2-T3 | Signed integer | 2 | 0 | 32767 | 4200 | mV |
| Charger Control | JEITA Temperature | Charge Voltage T3-T4 | Signed integer | 2 | 0 | 32767 | 4100 | mA |
| Charger Control | Charge Termination | Maintenance Current | Signed integer | 2 | 0 | 1000 | 200 | mA |
| Charger Control | Charge Termination | Taper Current | Signed integer | 2 | 0 | 1000 | 100 | mA |
| Charger Control | Charge Termination | Minimum Taper Capacity | Signed integer | 2 | 0 | 1000 | 25 | mAh/256 |
| Charger Control | Charge Termination | Taper Voltage | Signed integer | 2 | 0 | 1000 | 100 | mV |
| Charger Control | Charge Termination | Current Taper Window | Unsigned integer | 1 | 0 | 60 | 40 | s |
| Charger Control | WHr Charge Termination | Max Charge Voltage | Signed integer | 2 | 0 | 32767 | 4200 | mV |
| Charger Control | WHr Charge Termination | WHr CV Step | Signed integer | 2 | 0 | 32767 | 50 | mV |
| Charger Control | WHr Charge Termination | WHr Termination Capacity | Signed integer | 2 | 0 | 32767 | 2200 | mAh |
| Charger Control | WHr Charge Termination | FC WHr Clear | Signed integer | 2 | 0 | 32767 | 2090 | mAh |
| Charger Control | NiMH Charge Termination | Delta Temperature | Signed integer | 2 | –400 | 1200 | 30 | 0.1°C |
| Charger Control | NiMH Charge Termination | Delta Temperature Time | Unsigned integer | 2 | 0 | 255 | 100 | s |
| Charger Control | NiMH Charge Termination | Holdoff Time | Unsigned integer | 2 | 0 | 255 | 180 | s |
| Charger Control | NiMH Charge Termination | Holdoff Current | Signed integer | 2 | 0 | 32767 | 240 | mA |

Table 2-21. Charger Control Class (continued)

| Class | Subclass | Name | Type | Size | Min Value | Max Value | Default Value | Unit |
|-----------------|-------------------------|----------------------------------|------------------|------|-----------|-----------|---------------|-------|
| Charger Control | NiMH Charge Termination | Holdoff Temperature | Signed integer | 2 | –400 | 1200 | 250 | 0.1°C |
| Charger Control | NiMH Charge Termination | Cell Negative Delta Voltage | Signed integer | 2 | 0 | 32767 | 17 | mV |
| Charger Control | NiMH Charge Termination | Cell Negative Delta Time | Unsigned integer | 1 | 0 | 255 | 16 | s |
| Charger Control | NiMH Charge Termination | Cell Negative Delta Qual Voltage | Signed integer | 2 | 0 | 32767 | 4200 | mV |

2. **Delta Temperature** ($\Delta T/\Delta t$) method—For $\Delta T/\Delta t$, the bq34110 device detects an increase in temperature over many seconds. The $\Delta T/\Delta t$ setting is programmable in the temperature step, **Delta Temperature** (0°C – 25.5°C), and the time step, **Delta Temperature Time** (0 s–1000 s). Typical settings for 1°C/minute include 2°C/120 s and 3°C/180 s (default). Longer times may be used for increased slope resolution.

In addition to the $\Delta T/\Delta t$ timer, a holdoff timer starts (using **Holdoff Time**) when the battery is charged at more than **Holdoff Current** (default is 240 mA), and the temperature is above **Holdoff Temperature**. Until this timer expires, $\Delta T/\Delta t$ detection is suspended. If *Current()* drops below **Holdoff Current** or *Temperature()* below **Holdoff Temperature**, the holdoff timer resets and restarts only when the current and temperature conditions are met again.

3. Negative Delta Voltage ($-\Delta V$) method—For negative delta voltage, the bq34110 device detects a charge termination when the pack voltage drops during charging by **Cell Negative Delta Voltage** for a period of **Cell Negative Delta Time** during which time *Voltage()* must be greater than **Cell Negative Delta Qual Voltage**. If there is difficulty in the system to detect charge termination using this technique, then an alternative option is provided based only on voltage and time. Charge termination can be achieved by setting **Cell Negative Delta Voltage** to 0. In this case, the gauge monitors when the pack voltage exceeds **Cell Negative Delta Qual Voltage** for **Cell Negative Delta Time**, and if *Current()* > 0 during this time, then charge termination will be detected.

When either condition occurs, the *GaugingStatus()*[FC] bit is set. Also, if the [CSYNC] bit of **CEDV_Gauging_Configuration** is set, and *RemainingCapacity()* is set equal to *FullChargeCapacity()*.




Figure 2-5. NiXX Termination

2.9.1 Charge Inhibit

The gas gauge can indicate when battery temperature has fallen below or risen above predefined thresholds **Charge Inhibit Temp Low** or **Charge Inhibit Temp High**, respectively. In this mode, the `BatteryStatus()[CHGINH]` bit is set to indicate this condition. The `[CHGINH]` bit is cleared once the battery temperature returns to the range `[Charge Inhibit Temp Low + Temp Hys, Charge Inhibit Temp High – Temp Hys]`.

The charging should not start when the temperature is below the **Charge Inhibit Temp Low** or above the **Charge Inhibit Temp High**. The charging can continue if the charging starts inside the window `[Charge Inhibit Temp Low, Charge Inhibit Temp High]`.

2.9.2 Charge Control

The bq34110 device integrates two battery charge control architectures: discrete control and smart control. In a discrete charge control implementation, selected pins (some or all of ALERT1, ALERT2, VEN, and LEN) can be used to enable/disable charging and to adjust the charging voltage of an external supply, if they are not already being used for other another purpose.

In the simplest level of control, a pin can be used to directly control an external charger enable. This is controlled using **Direct Charge Pin Control**.

NOTE: If none of the pins is selected for use, then the function is not enabled.

If **Direct Charge Pin Control** is enabled in normal operation (outside the EOS Determination function's learning phase), it is set while `Voltage()` is below **FC Clear Voltage Threshold**, and it is cleared when charge terminates and `[FC]` is set. It also will be cleared if a fault occurs that would interrupt charging, such as a `[BATHIGH]`, `[OTC]`, or `[UTC]` event.

During the EOS Determination function's learning phase, this pin is only allowed to set whenever LCHG is set, then it is deasserted when LCHG mode ends.

Table 2-22. Direct Charge Pin Control

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|---------------|---------------------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | Configuration | Direct Charge Pin Control | Hex | 1 | 0x00 | 0xff | 0x00 | — |

| | | | | | | | |
|------|------|------|------|---------|------|------|------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | RSVD | RSVD | RSVD | DCHGPOL | DCP2 | DCP1 | DCP0 |

Legend = **RSVD**: Reserved. Do not use.

DCHGPOL (Bit 3): Direct Charge Control Pin Polarity

If set, the pin selected for direct charger control will generate a 1 output when charging is to be enabled, and a 0 output when charging is to be disabled.

Conversely, if not set, the pin selected for direct charger control will generate a 0 output when charging is to be enabled, and a 1 output when charging is to be disabled.

DCP2–DCP0 (Bits 2–0): Direct Charge Pin Control

These bits determine which, if any, of the ALERT1, ALERT2, VEN, or LEN pins is used for direct charge control.

0xx = None of the pins is used for direct charger control.

100 = The ALERT1 pin is used for direct charger control.

101 = The ALERT2 pin is used for direct charger control.

110 = The VEN pin is used for direct charger control.

111 = The LEN pin is used for direct charger control.

Discrete control of the charging voltage can be implemented using up to 3 additional pins, whereby the combination of the pin levels determines the charging voltage. The pins used for this purpose are selected based on the settings in **Charge Level Pin Control**.

NOTE: If ALERT1 or ALERT2 pins are used for direct charger control, they should not also be used for alert/interrupt purposes.

Table 2-23. Charge Level Pin Control

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|---------------|--------------------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | Configuration | Charge Level Pin Control | Hex | 1 | 0x00 | 0x3f | 0x00 | — |

| | | | | | | | |
|------|------|---------|---------|-------------|-------------|----------|----------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | RSVD | VEN_PUP | LEN_PUP | CHGL_ALERT1 | CHGL_ALERT2 | CHGL_VEN | CHGL_LEN |

Legend = **RSVD**: Reserved. Do not use.

VEN_PUP: Pull-Up Control for VEN Pin

This bit controls how the VEN pin drives a high level when in GPIO and in discrete pin control mode. If set, the device will use a strong logic 1 output drive; otherwise, it will use a high impedance state.

LEN_PUP: Pull-Up Control for LEN Pin

This bit controls how the LEN pin drives a high level when in GPIO and in discrete pin control mode. If set, the device will use a strong logic 1 output drive; otherwise, it will use a high impedance state.

CHGL_ALERT1: Charge Level Control for ALERT1 Pin

If set, this bit directs the device to use ALERT1 for discrete charge level control.

Note that since ALERT1 is an open-drain pin, it will require a pull-up resistor to generate a high voltage.

CHGL_ALERT2: Charge Level Control for ALERT2 Pin

If set, this bit directs the device to use ALERT2 for discrete charge level control.

Note that since ALERT2 is an open-drain pin, it will require a pull-up resistor to generate a high voltage.

CHGL_VEN: Charge Level Control for VEN Pin

If set, this bit directs the device to use VEN for discrete charge level control.

CHGL_LEN: Charge Level Control for LEN Pin

If set, this bit directs the device to use LEN for discrete charge level control.

NOTE: A maximum of three pins should be selected for use in charge level control. If all four bits (CHGLA1, CHGLA2, CHGLVEN, CHGLLEN) are set, this will be interpreted as if all bits were not set.

Additionally, the pin selected under **Direct Charge Pin Control** cannot also be used for charge level control.

The pins selected for discrete charge level control are automatically arranged MSB to LSB in the following order:

ALERT1, ALERT2, VEN, LEN

This is based on which pins are or are not selected. For example, if ALERT2 and LEN are selected for discrete charge level control, then ALERT2 will be the MSB, and LEN will be the LSB.

The charge voltage levels that map to the discrete charge control bits are programmed in **Charge Voltage Level A** to **Charge Voltage Level H**.

Table 2-24. Charge Voltage Levels

| Data Flash | Charge Level Control Bits (MSB/Middle Bit/LSB) | Default (mV) |
|------------------------|--|--------------|
| Charge Voltage Level A | 000 | 3900 |
| Charge Voltage Level B | 001 | 3950 |
| Charge Voltage Level C | 010 | 4000 |
| Charge Voltage Level D | 011 | 4050 |
| Charge Voltage Level E | 100 | 4100 |
| Charge Voltage Level F | 101 | 4150 |
| Charge Voltage Level G | 110 | 4200 |
| Charge Voltage Level H | 111 | 4250 |

NOTE: It is important to make all values increase monotonically, with the lowest voltage in **Charge Voltage Level A**, and the highest voltage in **Charge Voltage Level H**. If fewer than 8 levels are used, program all unused levels to the same value as the highest charge voltage setting that is in use.

The number of levels used will always start from **Charge Voltage Level A**, as shown in the table below:

| Number of Levels Used | Data Flash Settings Used |
|-----------------------|----------------------------|
| 1 | Charge Voltage Level A |
| 2 | Charge Voltage Level A ~ B |
| 4 | Charge Voltage Level A ~ D |
| 8 | Charge Voltage Level A ~ H |

For example, if ALERT2 is selected for direct charge control, and VEN and LEN are selected for discrete charge levels, the Charge Voltage Levels would be set as:

| Data Flash | Charge Voltage Level |
|------------------------|----------------------|
| Charge Voltage Level A | 3900 |
| Charge Voltage Level B | 4000 |
| Charge Voltage Level C | 4100 |
| Charge Voltage Level D | 4200 |
| Charge Voltage Level E | 4200 |
| Charge Voltage Level F | 4200 |
| Charge Voltage Level G | 4200 |
| Charge Voltage Level H | 4200 |

Table 2-25. Charge Voltage Level A–H

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------------|----------------------|------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Configuration | Charge Level Control | Charge Voltage Level A | Signed integer | 2 | 0 | 32767 | 3900 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level B | Signed integer | 2 | 0 | 32767 | 3950 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level C | Signed integer | 2 | 0 | 32767 | 4000 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level D | Signed integer | 2 | 0 | 32767 | 4050 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level E | Signed integer | 2 | 0 | 32767 | 4100 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level F | Signed integer | 2 | 0 | 32767 | 4150 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level G | Signed integer | 2 | 0 | 32767 | 4200 | mV |
| Charger Configuration | Charge Level Control | Charge Voltage Level H | Signed integer | 2 | 0 | 32767 | 4250 | mV |

The levels of the ALERT1, ALERT2, VEN, and LEN pins can be manually controlled by the host using the *[PCTL_EN]* and the *ManufacturerAccessControl()* subcommands of *PIN_ALERT1_SET*, *PIN_ALERT1_RESET*, *PIN_ALERT2_SET*, *PIN_ALERT2_RESET*, *PIN_VEN_SET*, *PIN_VEN_RESET*, *PIN_LEN_SET*, and *PIN_LEN_RESET*.

The bq34110 device also supports smart charge control, whereby the device makes the appropriate decisions for maximum charging current and voltage per the integrated charge algorithm. This enables a smart charger to manage the charging of the battery pack through reading these values, using the *ChargingCurrent()* and *ChargingVoltage()* commands. The bq34110 device does not broadcast the charger values; they must be read by the host or charger.

2.9.3 WHr Charging

The bq34110 device incorporates an innovative charge termination procedure specifically for use in systems that strive to extend battery life by charging the battery only as much as required to achieve a target level of capacity. The **WHr Charge Termination** function is excellent for applications where a particular level of battery capacity is required, such as battery backup modules or uninterruptible power supplies. As the battery ages, the charging voltage required to maintain the target level of capacity increases, which in a fixed charge voltage system would require overcharging the battery in the early stages of its lifetime to ensure sufficient capacity in its later stages of life.

The **WHr Charge Termination** function provides an adaptive charge voltage control that dynamically determines the *ChargingVoltage()* required to achieve a programmable target level of battery capacity. To take advantage of this function, the system must have a smart charger or some ability to adjust charging voltage.

NOTE: The **WHr Charge Termination** function is not applicable to NiMH battery chemistries.

2.9.3.1 Detailed Description

When enabled, the **WHr Charge Termination** function initially sets *ChargingVoltage()* to the number of cells \times **Cell Charge Voltage T2 – T3** if [JEITA] is not set, or the appropriate voltage based on *Temperature()* if [JEITA] is set. This value is also loaded into **Last Charge Voltage T2 – T3** if [JEITA] is not set, or the appropriate voltage based on *Temperature()* if [JEITA] is set at this initial step. The battery is charged using this voltage, with termination complete when the following charge-complete criteria are met:

- *Voltage()* > *ChargingVoltage()* – **Charging Taper Voltage** AND
- *Current()* < **Taper Current** for two **Current Taper Window** AND
- *RemainingCapacity()* > **WHr Termination Capacity** OR *ChargingVoltage()* = **Max Charge Voltage**.

If the first two conditions are satisfied, but *RemainingCapacity()* \leq **WHr Termination Capacity**, then:

- *ChargingVoltage()* is set to **Last Charge Voltage T2 – T3 + WHr CV Step**: for example, 3.9 V + 0.05 V \times the number of series cells.
- Charging continues incrementing the CV mode voltage until the charge-complete criteria are met. The ceiling on allowable values of *ChargingVoltage()* is set by **Max Charge Voltage**. If the incrementing procedure attempts to increase *ChargingVoltage()* to a level above **Max Charge Voltage**, then *ChargingVoltage()* will be set to **Max Charge Voltage**.
- When charge completes, the appropriate **Last Charge Voltage Tx - Ty** is updated to the last *ChargingVoltage()* used for charging.

After charging terminates, charging can be restarted when *RemainingCapacity()* < **FC WHr Clear**.

NOTE: If the discrete charge level control is enabled, then the bq34110 device uses the *ChargingVoltage()* data to set the discrete charge level, using the charge level control pins. In this case, the device selects which discrete level to use, based on the **Charge Voltage Level A-H** values, to provide the highest voltage less than or equal to *ChargingVoltage()*.

Table 2-26. WHr Termination Capacity

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------|------------------------|--------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Control | WHr Charge Termination | WHr Termination Capacity | Signed Integer | 2 | 0 | 32767 | 2200 | mAh |

Table 2-27. Last Charge Voltage Tx - Ty

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------|------------------------|-----------------------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Control | Learned Charge Voltage | Last Charge Voltage T1 – T2 | Signed Integer | 2 | 0 | 32767 | 4100 | mV |
| Charger Control | Learned Charge Voltage | Last Charge Voltage T2 – T3 | Signed Integer | 2 | 0 | 32767 | 4200 | mV |
| Charger Control | Learned Charge Voltage | Last Charge Voltage T3 – T4 | Signed Integer | 2 | 0 | 32767 | 4100 | mV |

Last Charge Voltage Tx - Ty is updated to the most recent value of *ChargingVoltage()* used during normal and **WHr Charge Termination** charging.

NOTE: During EOS Determination Learning Charge Phases, **Last Charge Voltage Tx - Ty** is not incremented due to the charging voltage being increased by **Learn Charge Voltage Delta**.

Table 2-28. Max Charge Voltage

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------|------------------------|--------------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Control | WHr Charge Termination | Max Charge Voltage | Signed Integer | 2 | 0 | 32767 | 4200 | mV |

Table 2-29. WHr CV Step

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------|------------------------|-------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Control | WHr Charge Termination | WHr CV Step | Signed Integer | 2 | 0 | 32767 | 50 | mV |

Table 2-30. FC WHr Clear

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------------|------------------------|--------------|----------------|---------------|-----------|-----------|---------------|------|
| Charger Control | WHr Charge Termination | FC WHr Clear | Signed Integer | 2 | 0 | 32767 | 2090 | mAh |

2.10 Power Modes and Control

The bq34110 device has four power modes associated with the gas gauging function, as well as with the EOS Determination function. In addition, it provides a hardware-controlled powerdown using the CE pin.

The power consumption of the bq34110 device can change significantly based on host commands it receives and the operation it is conducting at the time. Some operations are initiated based on host commands, such as commands that trigger measurements of temperature, voltage, or current, or to write data flash, and so are under the direct control of the host. However, other operations are dependent on automatic timers or external system events.

An example of this is when no charge or discharge current is flowing, the gas gauge remains in a low power state, monitoring for any current that may begin flowing through the sense resistor. If a current is detected, the device transitions into a higher power operation as it enables the coulomb counter and other gas gauge circuitry, as long as current continues flowing. Similarly, the EOS Determination function will be in a very low power state between learning phases, with only the timer operating. However, when a learning phase begins, the device will draw higher power as it continuously monitors the battery *Voltage()*, *Current()*, and other parameters while the learning phase is in progress.

The four bq34110 power modes are NORMAL, SNOOZE, SLEEP, and SHUTDOWN.

- In NORMAL mode, the device is fully powered and can execute any allowable task.

- In SNOOZE mode, the device periodically wakes to take data measurements and updates the data set. Both the low-frequency and high-frequency oscillators are active in this reduced-power mode.
- In SLEEP mode, the device maintains the low-frequency oscillator but turns off the high-frequency oscillator and exists in a even further reduced-power state, periodically taking measurements and performing calculations.
- In SHUTDOWN mode, the device is fully powered down and can only be awakened using the chip enable (CE) pin.

Because the gas gauging and EOS Determination functions each have decisioning included, which may require them to change states, the bq34110 device generally resides in the state that accommodates both functions operating as required.

2.10.1 NORMAL Mode

The bq34110 device is in NORMAL mode when not in any other power mode. During this mode, *Current()*, *Voltage()*, and *Temperature()* measurements are taken, and the interface data set is updated. Decisions to change states are also made. This mode is exited by activating a different power mode.

Because the device consumes the most power in the NORMAL mode, the gas gauging and EOS Determination algorithms minimize the time the device remains in this mode.

2.10.2 SNOOZE Mode

SNOOZE mode is entered automatically if the feature is enabled (*CONTROL_STATUS()*[*SNOOZE*] bit = 1 and **Operation Config A [*SLEEP*]** bit = 1) and *Current()* is below the programmable level **Sleep Current**. If the [*SNOOZE*] bit is set, this prevents the device from entering SLEEP mode. This mode maintains the high-frequency oscillator active, which then allows the device to respond to communication without the added delay that may be needed in SLEEP mode.

During SNOOZE mode, the gas gauge periodically takes data measurements and updates its data set. However, a majority of its time is spent in an idle condition.

The bq34110 device exits SNOOZE mode if any entry condition is broken, specifically when:

- Any communication activity occurs with the device.
- *Current()* rises above **Sleep Current**.
- A current in excess of I_{WAKE} through R_{SENSE} is detected.
- The EOS Determination function timer counting the **Auto Learn Time**, **Auto Learn Retry Time**, or **Alert-Warn Learn Time** expires, whereupon a new learning phase is initiated.

2.10.3 SLEEP Mode

SLEEP mode is entered automatically if the feature is enabled (**Operation Config A [*SLEEP*]** bit = 1 and *CONTROL_STATUS()*[*SNOOZE*] bit = 0) and *Current()* is below the programmable level **Sleep Current**. Once entry into SLEEP mode is qualified, but prior to entering it, the gas gauge performs a coulomb counter autocalibration to minimize offset.

During SLEEP mode, the gas gauge periodically takes data measurements and updates its data set. However, a majority of its time is spent in an idle condition. The interval at which the device wakes to take measurements is set by the data flash values of **Sleep Current Time** and **Sleep Voltage Time**.

The gas gauge exits the SLEEP mode if any entry condition is broken, specifically when either:

- *Current()* rises above **Sleep Current**.
- A current in excess of I_{WAKE} through R_{SENSE} is detected.
- The EOS Determination function timer counting the **Auto Learn Time**, **Auto Learn Time Retry**, or **Alert-Warn Learn Time** expires, whereupon a new learning phase is initiated.

While in the SLEEP mode, the fuel gauge can suspend serial communications as much as 4 ms by holding the communication line(s) low. This delay is necessary to correctly process host communication since the fuel gauge processor is mostly halted.

Table 2-31. Sleep Current

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|----------|---------------|----------------|---------------|-----------|-----------|---------------|------|
| Configuration | Power | Sleep Current | Signed Integer | 2 | 0 | 100 | 10 | mA |

Table 2-32. Sleep Current Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|----------|--------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Power | Sleep Current Time | Unsigned Integer | 1 | 0 | 255 | 20 | s |

Table 2-33. Sleep Voltage Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|---------------|----------|--------------------|------------------|---------------|-----------|-----------|---------------|------|
| Configuration | Power | Sleep Voltage Time | Unsigned Integer | 1 | 0 | 100 | 20 | s |

2.10.4 SHUTDOWN Mode

The SHUTDOWN mode is controlled by the state of the chip enable (CE) pin, with the bq34110 device powered if the CE pin is driven high, and the device in a full powerdown state while the CE pin is held low. The internal LDO within the bq34110 device is powered down whenever the CE pin is driven low, and all data within the device that has not been written into data flash will be lost. The only manner for the device to exit the SHUTDOWN mode is for the CE pin to be driven high.

2.10.5 Wake-Up Comparator

The wake-up comparator is used to indicate a change in cell current while the device is in SNOOZE or SLEEP mode. The bits [RSNS1–RSNS0] in **Operation Config A** are used to set the sense resistor selection. The *[IWAKE]* bit in the same register is used to select one of two possible voltage threshold ranges for the given sense resistor selection. An internal interrupt is generated when the threshold is breached in either charge or discharge directions. A setting of 0x00 of [RSNS1, RSNS0] disables this feature.

| RSNS1 | RSNS0 | I _{WAKE} | V _{th} (SRP – SNR) |
|-------|-------|-------------------|-----------------------------|
| 0 | 0 | 0 | Disabled |
| 0 | 0 | 1 | Disabled |
| 0 | 1 | 0 | +1.25 mV or –1.25 mV |
| 0 | 1 | 1 | +2.5 mV or –2.5 mV |
| 1 | 0 | 0 | +2.5 mV or –2.5 mV |
| 1 | 0 | 1 | +5 mV or –5 mV |
| 1 | 1 | 0 | +5 mV or –5 mV |
| 1 | 1 | 1 | +10 mV or –10 mV |

2.11 End-Of-Service Determination

The bq34110 device incorporates the End-Of-Service (EOS) Determination function to determine the end of useful service of the battery and provide alerts based on this detection. Learning phases are used to gather information about the present state of the battery through its cell resistance. The EOS Determination function is enabled when *[EOS_EN]* in *ManufacturingStatus()* = 1. This bit can be toggled using the *EOS_EN()* subcommand. If the *[EOS_EN]* bit or other data flash values related to this function are changed directly in data flash, they will not take effect until a device reset is issued.

For best results, it is recommended that JEITA-based charging and **WHr Charge Termination** are not enabled when the EOS Determination feature is used.

There are two ways to initiate a learning phase:

- a. To have it automatically controlled by the device (recommended) based on when the internal **Auto Learn Time** timer has expired since the last successful learning phase OR
- b. To have it triggered by the host by writing a `ManufacturerAccessControl() EOS_START_LEARN()` subcommand to the device.

Automatic learning is disabled if **Auto Learn Time** = 0. There is also a special test mode, which is entered using the `[LTEST]` bit and sets several timers to short time durations.

The learning phase can be implemented in two ways, which are controlled by the `[LSM]` bit:

- a. **CHARGE-BEFORE-DISCHARGE**: The device begins a Learn Charge Phase where it enables charging to a voltage given by the charging voltage determined by the selected algorithm (JEITA, for example) incremented by **Learn Charge Voltage Delta**. This increases charging from the level used when not in a learning phase.

NOTE: The data flash value of **Last Charge Voltage Tx - Ty** is not increased due to this Learn Charge Phase.

After this charging is completed through normal charge termination, the device waits for the cell to relax. It then initiates a **Learn Discharge Phase**, whereby an intended **Learn Discharge Current** is enabled for a length of time given by **Learn Discharge Time**. When this time has expired, the device disables the **Learn Discharge Current**. The bq34110 device analyzes the response of the battery to this discharge current to estimate the status of the battery regarding its end of usable service.

If needed, the device can then be configured to continue discharging the battery until `Voltage()` reaches the appropriate voltage as determined by the charging algorithm selected, OR

- b. **DISCHARGE-BEFORE-CHARGE**: The device begins by ensuring it is in a RELAXED state (typically fully or near-fully charged).

The device begins a **Learn Discharge Phase** by enabling **Learn Discharge Current** for a length of time given by **Learn Discharge Time**. When this time has expired, the device disables the **Learn Discharge Current**.

The device can now be recharged to the appropriate voltage as determined by the charging algorithm selected, if needed.

NOTE: The learning discharge current value is set by external components and is not directly controlled by the bq34110 device. However, this current is monitored throughout the **Learn Discharge Phase** and evaluated to ensure it is close to the intended value.

The **CHARGE-BEFORE-DISCHARGE** approach described above in (a) is appealing in that the battery voltage is not discharged below the appropriate charging voltage level by the learning phase. However, it requires the use of a charger with programmable charging voltage, which may be a limitation in some systems. For those cases, the **DISCHARGE-BEFORE-CHARGE** approach in (b) is provided, whereby a charger with a fixed output voltage can be used with the tradeoff that the battery voltage will be discharged below this level during the **Learn Discharge Phase**. However, the amount of this reduction in battery voltage, and thus capacity, can be controlled and limited to acceptable levels through appropriate device settings.

The response of the battery to the learning discharge current is analyzed and used to estimate the cell resistance, **Rcell**, and this resistance estimate is used in two different methods to evaluate the cell EOS status:

- a. **Direct Resistance Decisioning**: This method uses the newly measured value of **Rcell** and computes the ratio of **Rcell** with that of an **Initial Rcell** captured when the battery was first put into service. The ratios are compared to thresholds to generate an alert and a warning.

Alert if $\frac{R_{cell}}{Initial\ R_{cell}} > AlertThreshold,$

Warning if $\frac{R_{cell}}{Initial\ R_{cell}} > WarningThreshold$

- b. **Resistance Slope Decisioning**: This method uses the changes with respect to time of **Rcell**,

comparing this to programmable thresholds to generate an alert and a warning.

Use of **Resistance Slope Decisioning** requires an accurate measurement of the time between consecutive learning phases for calculation of the slope of **Rcell** change with respect to time. This will not be possible if the device is powered off between learning phases, in which case, **Direct Resistance Decisioning** can still be used. If the device is programmed to use **Resistance Slope Decisioning** and a power cycle is detected (or anything which could impact the validity of the time measurement between learning phases), then the device defaults to only using **Direct Resistance Decisioning** until the device is continuously powered long enough to complete multiple learning phases and accurately evaluate the **Rcell** change over time.

2.11.1 End-Of-Service Determination—Detailed Description

The **EOS Configuration** data flash is used to configure certain settings associated with the EOS Determination function.

Table 2-34. EOS Configuration

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|------|------|------|-------|-----|-----|--------|
| RSVD | RSVD | RSVD | RSVD | LTEST | LVR | LSM | LENCTL |

Legend = **RSVD**: Reserved. Do not use.

LTEST: Learn Test Mode Control

This bit is used to put the device into a test mode for reduced timing testing of the EOS Determination function.

1 = When this bit is set = 1, the following values are set:

Auto Learn Time = 10 min

Auto Learn Retry Time = 5 min

Alert-Warn Learn Time = 10 min

Minimum Learn Time = 10 min

0 = The device uses the values programmed in data flash for the above parameters (default).

LVR: Learn Voltage Restore Control

This bit determines whether the device continues discharging during **Learn Discharge Phase** until **Voltage()** reaches the appropriate **Last Charge Voltage Tx - Ty** (when set = 1), or to simply stop discharge when the timer reaches **Learn Discharge Time** (when set = 0).

1 = The device continues **Learn Discharge Phase** until **Voltage()** reaches the appropriate **Last Charge Voltage Tx - Ty**.

0 = The device stops **Learn Discharge Phase** when the timer reaches **Learn Discharge Time** (default).

LSM: Learn Sequence Mode Control

This bit determines whether the EOS algorithm uses CHARGE-BEFORE-DISCHARGE or DISCHARGE-BEFORE-CHARGE mode.

1 = DISCHARGE-BEFORE-CHARGE mode is used.

0 = CHARGE-BEFORE-DISCHARGE mode is used (default).

LENCTL: Learning Pin (LEN) Control Enable

This bit determines whether the LEN pin on the bq34110 device is used to directly control the external FET implementing the **Learn Discharge Phase**, or whether the host will control the external FET. In the case when the host controls the FET, it is expected that the **[LCTLEDGE]** bit in **EOSLearnStatus()** will be set to trigger an ALERT interrupt to the host whenever **[LDSEG]** changes state (that is, transitions from 0 to 1, or from 1 to 0).

1 = The LEN pin is used to control **Learn Discharge Current**.

0 = The LEN pin is not used to control **Learn Discharge Current** (default).

The device includes a variety of flags to provide visibility into the operation of the EOS Determination Learning process. These are found in *EOSLearnStatus()*:

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----|-------|--------|--------|----------|-------|-------|-------|-------|
| LSB | LCTO | LFAULT | LABRT | LCMD | LPER | LRLX | LCHG | LDSG |
| MSB | LDONE | LRES | LRSTOR | LCTLEDGE | LUCD | LDPAM | LDPAT | LDPAI |

The sequence of steps involved in a learning phase differs depending on the setting of *[LSM]*. These are depicted in the following figures.




Figure 2-6. State Diagram for LSM=0




Figure 2-7. State Diagram for LSM=1

2.11.1.1 Periodic and Manual Learn Command

For manual control of learning phases, the *ManufacturerAccessControl()* subcommand *EOS_START_LEARN()* is used. When the device receives this command, it sets the *[LCMD]* flag and initiates the learning phase if conditions permit: for example, charger present, no charging or safety faults, and the temperature is within acceptable limits. The *[LDPAT]* and *[LFAULT]* flags will be set if the Learning Discharge Phase is attempted but temperature conditions do not permit it.

If the device is in periodic (automatic) learning mode, then the *[LPER]* bit will be set while the device is in a learning phase.

EOS_ABORT_LEARN(): This *ManufacturerAccessControl()* subcommand is used to abort a learning phase that is in progress. Use of this command during a learning phase results in a failed learning phase and setting the *[LABRT]* flag, whereupon the device will retry another learning phase after a time period of **Auto Learn Retry Time**.

When the device attempts to initiate a learning phase, but conditions do not permit this, then the device will wait for **Auto Learn Retry Time** to again attempt a learning phase. Note that this will occur whether the device is configured in periodic learning or learning is initiated through a host command.

If the case occurs where an alert or warning is detected, either through **Direct Resistance Decisioning** or **Resistance Slope Decisioning**, the **Alert-Warn Learn Time** is used to schedule a new learning phase. If multiple fault events must be detected before the alert or warning flags are set, and an aborted learning phase occurs after the first alert or warning is detected, then **Alert-Warn Learn Time** is used to schedule future **Rcell** measurements rather than **Auto Learn Retry Time**.

NOTE: If *[LTEST]* is set, special values override the selected timer values to facilitate device operation testing in a shorter time scale.

To avoid interruption to the EOS Determination measurements and calculations, automatic offset calibration is not initiated during a learning phase. While it is possible for the host to manually initiate a calibration event during a learning phase, it is recommended that the host avoid this.

Table 2-35. Auto Learn Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------|------------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Auto Learn Time | Unsigned Integer | 2 | 0 | 65535 | 1500 | Hours |

Table 2-36. Auto Learn Retry Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------|------------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Auto Learn Retry Time | Unsigned Integer | 1 | 0 | 255 | 1 | Hours |

Table 2-37. Alert-Warn Learn Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------|------------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Alert-Warn Learn Time | Unsigned Integer | 2 | 0 | 65535 | 1 | Hours |

NOTE: **Alert-Warn Learn Time** has priority over **Auto Learn Retry Time**, so if multiple occurrences must be detected before an alert or warning is triggered, and after the first occurrence is detected that a fault occurred that invalidated a following attempted learning phase, the **Alert-Warn Learn Time** will be used to determine the time to the next learning phase attempt. It should also be noted that if **Alert-Warn Learn Time** is set to be lower than **Minimum Learn Time**, then **Minimum Learn Time** will be used to determine the time to the next learning phase attempt.

2.11.1.2 Learn Charge Phase

The operation of the device is first described for the case of *[LSM]* = 0, in which the device uses CHARGE-BEFORE-DISCHARGE mode. In this mode, the device first enters Learn Charge Phase by setting *ChargingVoltage()* to the appropriate charging voltage determined by the selected charging algorithm (JEITA, for example) incremented by **Learn Charge Voltage Delta**. The *[LCHG]* flag is set and charge terminates using standard charge termination criteria. Upon termination of charge, then *[LCHG]* is cleared. Note that the data flash value of **Last Charge Voltage Tx - Ty** is not incremented due to this Learn Charge Phase.

The time while *[LCHG]* is set is measured and compared against a threshold given by **Learn Charge Time Limit** to identify an excessive charging time, which may indicate an issue in the system. When the learn charging time exceeds this limit, the *[LCTO]* flag is set, learning is terminated, and the *[LFAULT]* flag is set to indicate a fault has occurred. The *[LCHG]* flag is reset whenever the device exits from CHARGING mode. If a learning fault occurs, the status flag (*[LCHG]* in this case) remains set to enable the host to understand what mode the system was in when the fault occurred.

Table 2-38. Learn Charge Time Limit

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-------------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Learning | Learn Charge Time Limit | Unsigned Integer | 2 | 0 | 65535 | 3600 | s |

NOTE: The standard charge termination criteria voltage condition is relative to *ChargingVoltage()*, so the same settings are used for *Normal* and *Learn* charging phases.

Table 2-39. Learn Charge Voltage Delta

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|----------------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Learning | Learn Charge Voltage Delta | Unsigned Integer | 2 | 0 | 32767 | 100 | mV |

2.11.1.3 Learn Pre-Relax Phase

If *[LSM]* = 0, then the device next waits for relaxation of the cell, during which *Voltage()* is monitored for 100-s time windows. While in this phase, the device sets the *[LRLX]* flag. If the change in the consecutive 100-s averages of *Voltage()* is less than 4 μ V, then relaxation is deemed achieved. If not, the device continues monitoring for another 100-s time window. It is important that the cell be fully relaxed before the algorithm can continue onto the **Learn Discharge Phase**. The status of relaxation can be seen by the *[REST]* bit in the *Gauging Status* register, after which the algorithm can move onto the **Learn Discharge Phase**. If a learning fault occurs while in the **Learn Pre-Relax Phase** or the **Learn Post-Relax Phase**, the status flag (*[LRLX]* in this case) will remain set to allow the host to understand what mode the system was in when the fault occurred.

When the device is in learning mode (but not in the **Learn Discharge Phase**), and a current is detected differently than what is expected, the *[LUCD]* bit will be set. It is set if the device is attempting to charge or relax, and a discharge current in excess of **Discharge Detection Threshold** is detected. It is also set if the device is in a RELAX mode and a charging current in excess of **Charge Detection Threshold** is detected. This detection also terminates the learning phase, and this flag will remain set so the host can recognize why the learning phase was aborted. This bit will be reset to 0 when charging is terminated or the register is read.

2.11.1.4 Learn Discharge Phase

After achieving relaxation, the bq34110 device next enters the **Learn Discharge Phase**, whereby the device enables the **Learn Discharge Current** (depending on the *[LENCTL]* setting), sets the *[LD SG]* flag, and begins the timer.

External circuitry is required to actively discharge the battery at a constant current rate where the discharge current flows through the sense resistor connected across SRP – SRN. This will be implemented by the device controlling the LEN pin on the device, or the host directly controlling the current (depending on the *[LENCTL]* setting). To provide sufficient resolution in the associated calculations, it is important that the level of this **Learn Discharge Current** be large enough so that it generates a cell voltage change of approximately 5 mV or greater. A current level of C/20 or higher is generally recommended.

[LD SG] remains enabled until the timer reaches **Learn Discharge Time**, at which point (if *[LVR]* = 0), the *[LD SG]* flag is reset and **Learn Discharge Current** is disabled. The device then transitions into the **Learn Post-Relax Phase**.

The **[LVR]** (Learn Voltage Restore) bit is used to tell the device to resume discharging using the learning load after completion of the voltage determined by the charging algorithm selected until **Voltage()** reaches the appropriate voltage determined by the charging algorithm selected (when **[LVR]** is set = 1). When this is finished (or when the **Learn Post-Relax Phase** is complete, if **[LVR]** is set = 0), the entire learning phase is complete, at which point the device sets the **[LDONE]** flag.

During the time period while the timer is active for the **Learn Discharge Time** period, the average current and average temperature over this time period will be calculated by the device and saved, at the conclusion of the **Learn Discharge Phase**. These values are used in later calculations to provide better accuracy.

While the device is in **Learn Discharge Phase**, it is also monitoring **Current()** and ensuring it is within an acceptable range around the intended discharge current. The algorithm knows the intended current based on the **Learn Discharge Current**, which is the intended **Learn Discharge Current** implemented using the external circuitry. This current should generally be designed greater than C/20. The boundary the algorithm uses for the acceptable range is determined using the **Learn Discharge Current Boundary**. If the current exceeds the **Learn Discharge Current Boundary**, the **[LDPAI]** and **[LFAULT]** flags are set, and the learning phase is aborted. If a learning fault does occur, the status flag (**[LDSEG]** in this case) will remain set to allow the host to understand what mode the system was in when the fault occurred.

The value of **Learn Discharge Current** should be selected large enough to accept variations in the current with temperature and system noise, but low enough to ensure identification of other events, such as an unintended charging session starting or a system load discharge event beginning. The **Learn Discharge Current** should also be chosen well above the **Discharge Detection Threshold** and **Quit Current** to ensure proper operation.

Table 2-40. Learn Discharge Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|----------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Learning | Learn Discharge Time | Unsigned Integer | 2 | 0 | 65535 | 500 | s |

Table 2-41. Learn Discharge Current

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-------------------------|----------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Learning | Learn Discharge Current | Signed Integer | 2 | 1 | 32767 | 100 | mA |

Table 2-42. Learn Discharge Current Boundary

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|----------------------------------|------------------|---------------|-----------|-----------|---------------|------------------------------|
| End Of Service | Resistance Learning | Learn Discharge Current Boundary | Unsigned Integer | 2 | 0 | 100 | 25 | % of Learn Discharge Current |

NOTE: If **[LENCTL]** is set such that the bq34110 device does not directly control the **Learn Discharge Current** using the LEN pin. Then after setting **[LDSEG]**, the device will monitor **Current()** for up to **Learn Request Timeout** seconds and start the timer only when the current has entered the acceptable range around **Learn Discharge Current**. This will accommodate delay in the host responding to the ALERT interrupt to see the **[LCTLEDGE]** signal and enable the **Learn Discharge Current**.

If the bq34110 device does not detect a valid current within a time period of **Learn Request Timeout** after setting **[LDSEG]**, then the device will set **[LFAULT]**, delay a time given by **Auto Learn Retry Time**, and then initiate a new learning phase. The **[LDSEG]** flag will remain set so the host can read and determine the phase in which the fault occurred. The **Learn Request Timeout** timer is similarly used after the **[LCTLEDGE]** signal asserts when the host should disable the learning load.

Table 2-43. Learn Request Timeout

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Learning | Learn Request Timeout | Unsigned Integer | 1 | 0 | 255 | 4 | s |

The **Learn Discharge Phase** can be terminated for other criteria (beyond its intended, valid termination by persisting for the **Learn Discharge Time** period), including *Current()* exiting the acceptable range, safety fault detected, or temperature exceeding allowed learning temperature limits. If the **Learn Discharge Phase** is terminated for any reason other than valid termination, then *[LFAULT]* is set, indicating that the learning phase was not completed. *[LFAULT]* is cleared when the learning process is initiated again.

The **Learn Discharge Phase** is only allowed when the temperature is within an allowed range, which is given by the **Learn Min Temperature** and **Learn Max Temperature**. If a **Learn Discharge Phase** is attempted when the temperature is outside this allowed range, the *[LDPAT]* and *[LFAULT]* flags are set.

Table 2-44. Learn Min Temperature

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------|----------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Learn Min Temperature | Signed Integer | 2 | –400 | 1500 | 50 | 0.1°C |

Table 2-45. Learn Max Temperature

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------|----------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Learn Max Temperature | Signed Integer | 2 | –400 | 1500 | 400 | 0.1°C |

If the *[LSM]* is set = 1, then DISCHARGE-BEFORE-CHARGE mode is used, in which the operation sequence is described below:

1. Check for relaxation by monitoring *Voltage()* as described above, delay until relaxation is achieved.
2. Enable *[LD SG]*, enable the **Learn Discharge Current**, and reset the timer to begin **Learn Discharge Phase**.
3. When the timer reaches **Learn Discharge Time**, then disable *[LD SG]* and **Learn Discharge Current**.

2.11.1.5 Learn Post-Relax Phase

After the **Learn Discharge Phase** completes, the bq34110 device will disable the learning current and enter the **Learn Post-Relax Phase**, whereby the device again waits for relaxation of the cell, during which *Voltage()* is monitored for 100-s time windows. While in this phase, the device sets the *[LRLX]* flag. If the change in the consecutive 100-s averages of *Voltage()* is less than 4 μ V, then relaxation is deemed achieved. If not, the device continues monitoring for another 100-s time window. It is important that the cell be fully relaxed before the algorithm can continue. The status of relaxation can be seen by the *[REST]* bit in the Gauging Status register. If a learning fault occurs while in the **Learn Post-Relax Phase**, the status flag (*[LRLX]* in this case) will remain set to allow the host to understand what mode the system was in when the fault occurred.

As in the **Learn Pre-Relax Phase**, if a discharge current in excess of **Discharge Detection Threshold** or a charging current in excess of **Charge Detection Threshold** is detected, then the *[LUCD]* flag is set. This detection also terminates the learning phase, and this flag will remain set so the host can recognize why the learning phase was aborted. This bit will be reset to 0 when charging is terminated or the register is read.

At the completion of the **Learn Post-Relax Phase**, if in CHARGE-BEFORE-DISCHARGE mode and *Voltage()* > the charging voltage determined by the selected charging algorithm and *[LVR]* = 1, then the device will set *[LD SG]* and enable the **Learn Discharge Current** until *Voltage()* \leq the calculated charging voltage. At which point, *[LD SG]* is reset and the **Learn Discharge Current** is disabled. The *[LRSTOR]* bit will be set while the device is continuing discharge to reach the calculated charging voltage.

If in DISCHARGE-BEFORE-CHARGE mode and $[LVR] = 0$, then the device will set $[LDONE]$ and complete learning. If $[LVR] = 1$, then the device will initiate a new charging session to charge the battery back to the appropriate charging voltage determined by the selected charging algorithm using a similar sequence as described above. In this case, the device sets the $[LCHG]$ and $[LRSTOR]$ flags to indicate to the host that charging can begin. If charging does not terminate within **Learn Charge Time Limit**, then $[LCTO]$ and $[LFAULT]$ is set. If a learning fault does occur, the status flag ($[LCHG]$ in this case) will remain set to allow the host to understand what mode the system was in when the fault occurred.

NOTE: It is possible that a **Learn Discharge Phase** has completed, and a new **Rcell** value has been calculated and stored, but during a Voltage Restore phase, a fault could occur. This would cause $[LFAULT]$ to be set, and the device would retry a new learning phase after **Auto Learn Retry Time**.

2.11.1.6 Cell Resistance Calculation

The device uses the values obtained during each learning phase to estimate a value of **Rcell** for the battery. Note the actual value of this **Rcell** estimate is not critical here, rather its change as the battery ages is what is important. The $[LRES]$ bit indicates when a new **Rcell** value has been acquired and stored by the device.

The change in value of **Rcell** must be normalized relative to differences in temperature when they are captured. Therefore, the bq34110 device uses resistance temperature parameters in **Rcell High & Low Temperature Coefficients** to calculate an expected value of resistance at the **Learn Target Temperature**.

The **Rcell High & Low Temperature Coefficients** are obtained during a pre-production test whereby the customer initiates **Initial Rcell** calculations at temperatures of 5°C, 25°C, and 40°C. These **Initial Rcell** values are put into a spreadsheet provided by TI, which then calculates the values of **Rcell High Temperature Coefficient** and **Rcell Low Temperature Coefficient**. These values are then loaded into data flash and used by the device to normalize effective **Rcell** measurements back to an equivalent value at the **Learn Target Temperature**.

NOTE: The **Rcell** and **Initial Rcell** values read by the device are normalized to **Learn Target Temperature**. During the pre-production testing to capture the **Initial Rcell** values as described above, it is important to keep the **Rcell High & Low Temperature Coefficients** set = 0, so the **Initial Rcell** values captured there are not further normalized.

It is important that the temperature remain stable during the learning phase. If the temperature is detected to vary more than 10°C during certain portions of the learning phase, the learning phase will be aborted, and the $[LDPAT]$ and $[LFAULT]$ flags will be set.

Table 2-46. Rcell High Temperature Coefficient

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|------------------------------------|----------------|---------------|-----------|-----------|---------------|-------------------------------|
| End Of Service | Resistance Learning | Rcell High Temperature Coefficient | Signed Integer | 2 | -32767 | 32768 | 0 | $2^{-16}/0.1^{\circ}\text{C}$ |

Table 2-47. Rcell Low Temperature Coefficient

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|-----------------------------------|----------------|---------------|-----------|-----------|---------------|-------------------------------|
| End Of Service | Resistance Learning | Rcell Low Temperature Coefficient | Signed Integer | 2 | -32767 | 32767 | 0 | $2^{-16}/0.1^{\circ}\text{C}$ |

Table 2-48. Learn Target Temperature

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|--------------------------|----------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Learn Target Temperature | Signed Integer | 2 | –400 | 1500 | 250 | 0.1°C |

Learn Target Temperature should be the typical or nominal temperature for intended cell operation.

2.11.1.7 End-Of-Service Evaluation

2.11.1.7.1 Direct Resistance Decisioning

The device uses the change in **Rcell** relative to the value of **Initial Rcell** as one method to estimate EOS. The ratio of **Rcell** / **Initial Rcell** is compared to two thresholds to generate **[DRDALERT]** and **[DRDWARN]** flags by:

$$[DRDALERT] \text{ is set if } \frac{R_{cell}}{Initial\ R_{cell}} > \left(1 + \frac{DRD\ Alert\ Level}{100}\right)$$

$$[DRDWARN] \text{ is set if } \frac{R_{cell}}{Initial\ R_{cell}} > \left(1 + \frac{DRD\ Warning\ Level}{100}\right)$$

The EOS alerts and warnings are read using the command **EOSSafetyStatus()**, which will clear the alert bits in this register. There is also a **ManufacturerAccessControl()** subcommand **EOS_SAFETY_STATUS()**, which can be read and does not clear the alert bits.

The following data flash values are set to provide levels at which the bq34110 device will generate an alert or a warning, based on the DRD algorithm.

Table 2-49. DRD Alert Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|-----------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Direct Resistance Decision | DRD Alert Level | Unsigned Integer | 2 | 0 | 65535 | 15 | % |

Table 2-50. DRD Warning Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|-------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Direct Resistance Decision | DRD Warning Level | Unsigned Integer | 2 | 0 | 65535 | 30 | % |

In normal situations, the value of **Rcell** is expected to increase over time. If the value of **Rcell** is detected to decrease from the previous measurement, this is unexpected and may indicate an abnormal situation, such as a cell having been replaced. The bq34110 device will set the **[RCELLR]** flag if a reduction in the value of **Rcell** of more than 2% is detected.

To offer improved robustness, there is the option to enable a filter to help ensure that the condition has been detected for a number of consecutive learning phases through programming **DRD Alert Counts** and **DRD Warning Counts**.

If the DRD Alert calculation is positive for **DRD Alert Counts**, then **[DRDALERT]** is set. If **DRD Alert Counts** is set = 0, then this test is disabled.

If the DRD Warning calculation is positive for **DRD Warning Counts**, then **[DRDWARN]** is set. If **DRD Warning Counts** is set = 0, then this test is disabled.

Additionally, once the first instance of the either a DRD Alert or DRD Warning condition is detected then the time between automatic learns can be adjusted and is based on **Alert-Warn Learn Time**. If **Alert-Warn Learn Time** = 0, then the value in **Auto Learn Time** continues to be used.

After **DRD Alert Counts** number of alert conditions have occurred and a *[DRDALERT]* has been triggered, then the timing to the next learning phase returns to **Auto Learn Time**.

Table 2-51. DRD Alert Counts

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|------------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Direct Resistance Decision | DRD Alert Counts | Unsigned Integer | 1 | 0 | 255 | 3 | Counts |

Table 2-52. DRD Warning Counts

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|--------------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Direct Resistance Decision | DRD Warning Counts | Unsigned Integer | 1 | 0 | 255 | 3 | Counts |

When the *[DRDALERT]* flag is set, it will be cleared after being read by the host. However, if the *[DRDWARN]* flag is set, it is NOT cleared after being read by the host, but can only be cleared by the host using the *ManufacturerAccessControl()* subcommand *EOS_WARNCLR()*.

2.11.1.7.2 Resistance Slope Decisioning

This second method used by the device for evaluating EOS is based on the slope of the change in **Rcell** versus time. The preferred approach is to use both **Direct Resistance Decisioning** with **Resistance Slope Decisioning**, whereby an even more robust solution is obtained.

Resistance Slope Decisioning requires an accurate measurement of the time between consecutive learning phases, which it uses to calculate the slope of the **Rcell** change with respect to time. For best results, this mode should be used with automatic learning mode enabled and the device experiences no (or few) power cycles during its lifetime.

Here, the device collects **Rcell** information using periodic learning phases, which may be in either CHARGE-BEFORE-DISCHARGE or DISCHARGE-BEFORE-CHARGE mode. The device measures accurately the time between learning phases, and this is then used to calculate the rate of change in **Rcell** with respect to time, which is termed **RRate**. The value of **RRate** is stored in units of $\mu\Omega/\text{day}$ as a two-byte signed value, which can store values up to a maximum of 32767 $\mu\Omega/\text{day}$. If a value of **RRate** is calculated exceeding this level, the value stored will be limited at 32767. If this value is read back by the host, it should serve as an indication that the **RRate** value has saturated the range allotted for storing it.

During operation, the algorithm uses the newly measured value of **RRate** and computes the ratio of **RRate** with that of an **Initial RRate** captured when the battery was first put into service. The ratios are compared to thresholds to generate an alert and a warning:

$$[RSDAlert] \text{ is set if } \frac{RRate}{Initial\ RRate} > 1 + \left(\frac{RRate\ Alert\ Level}{100} \right)$$

$$[RSDWarn] \text{ is set if } \frac{RRate}{Initial\ RRate} > 1 + \left(\frac{RRate\ Warning\ Level}{100} \right)$$

Table 2-53. RSD Alert Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|-----------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Slope Decision | RSD Alert Level | Unsigned Integer | 2 | 0 | 65535 | 15 | % |

Table 2-54. RSD Warning Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|-------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Slope Decision | RSD Warning Level | Unsigned Integer | 2 | 0 | 65535 | 30 | % |

The device also maintains a long-term timer value, which counts the time from the completion of the **Initial RRate** learning phases to the present time. This value will only be valid if no power cycles or interruptions to device operation have been encountered since the **Initial RRate** learning phases were completed. If there is a power cycle such that the timer has been interrupted, then the **[RDSL]** flag will be set, which indicates that no alerts or warnings based on the long-term RSD value (described below) will ever be triggered.

A long-term value for the resistance slope (given by $RRate_{longterm}$) is calculated as the change in **RRate** from the **Initial RRate** value to the most recent **RRate** measurement.

The ratio of **RRate** to $RRate_{longterm}$ is compared against thresholds to provide further information as:

$$[RSDLAert] \text{ is set if } \frac{RRate}{RRate_{longterm}} > \left(1 + \frac{RSDL \text{ Alert Level}}{100}\right)$$

$$[RSDLWarn] \text{ is set if } \frac{RRate}{RRate_{longterm}} > \left(1 + \frac{RSDL \text{ Warning Level}}{100}\right)$$

NOTE: It is important that the delay between successive **Rcell** calculations be long enough such that the slope of resistance change can be accurately calculated. If the triggering of learning phases is being performed manually (rather than automatically using the **Auto Learn Time**), then it is possible for the host to request successive learning phases with too short of a time delay between them. The minimum time required for successive learning phases is set by **Minimum Learn Time**. If the host manually requests a new learning phase without waiting for **Minimum Learn Time**, then the **[LDPAM]** flag will be set and the request for a new learning phase will be declined. The **[LFAULT]** flag is not set here because the learning phase was never started.

It is important that **Auto Learn Time** be set larger than **Minimum Learn Time**; otherwise, **Minimum Learn Time** will be used in place of **Auto Learn Time**. It is also recommended that, if Resistance Slope Decisioning is used, the value of **RRate** be ~ 10 in practice, to enable appropriate resolution during mathematical computation within the device.

NOTE: Note that **Minimum Learn Time** will also limit the time between successive **Rcell** measurements even when DRD Decisioning is used and RSD/RSDL Decisioning is not used. In the case where RSD/RSDL Decisioning is not being used, the user can set the **Minimum Learn Time** to zero if frequent **Rcell** measurements are needed.

Table 2-55. RSDL Alert Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Slope Decision | RSDL Alert Level | Unsigned Integer | 1 | 0 | 255 | 15 | % |

Table 2-56. RSDL Warning Level

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|--------------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Resistance Slope Decision | RSDL Warning Level | Unsigned Integer | 1 | 0 | 255 | 30 | % |

Table 2-57. Minimum Learn Time

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|--------------------|------------------|---------------|-----------|-----------|---------------|-------|
| End Of Service | Resistance Learning | Minimum Learn Time | Unsigned Integer | 2 | 0 | 65535 | 1 | hours |

Table 2-58. Warning Status

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------|----------------|--------|---------------|-----------|-----------|---------------|------|
| End Of Service | Safety Status | Warning Status | Hex | 1 | 0x00 | 0xff | 0x00 | — |

| | | | | | | | |
|------|------|------|------|------|----------|---------|---------|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| RSVD | RSVD | RSVD | RSVD | RSVD | RSDLWARN | RSDWARN | DRDWARN |

To offer improved robustness, there is the option to enable a filter to help ensure that the condition has been detected for a number of consecutive learning phases through programming **RSD Alert Counts** and **RSD Warning Counts**.

If the RSD Alert calculation is positive for **RSD Alert Counts** then **[RSDALERT]** is set. Similarly, if the RSDL Alert calculation is positive for **RSD Alert Counts**, then **[RSDLALERT]** is set. If **RSD Alert Counts** is set = 0, then these tests will not be enabled.

If the RSD Warning calculation is positive for **RSD Warning Counts**, then **[RSDWARN]** is set. Similarly, if the RSDL Warning calculation is positive for **RSD Warning Counts** then **[RSDLWARN]** is set. If **RSD Warning Counts** is set = 0, then these tests will not be enabled.

Additionally, once the first instance of the either a RSD Alert, RSDL Alert, RSD Warning, or RSDL Warning condition is detected then the time between automatic learns can be adjusted and is based on **Alert-Warn Learn Time**. If **Alert-Warn Learn Time** = 0 then the value in **Auto Learn Time** continues to be used.

Table 2-59. RSD Alert Counts

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|------------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Resistance Slope Decision | RSD Alert Counts | Unsigned Integer | 1 | 0 | 255 | 3 | Counts |

Table 2-60. RSD Warning Counts

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|--------------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Resistance Slope Decision | RSD Warning Counts | Unsigned Integer | 1 | 0 | 255 | 3 | Counts |

Table 2-61. Initial RRate

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------------|---------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Resistance Slope Decision | Initial RRate | Unsigned Integer | 2 | 0 | 65535 | 0 | μΩ/day |

When the bq34110 device is operating in Resistance Slope Decisioning mode and a power cycle is detected, such that the timer is stopped and restarted, then newly calculated values of **RRate** will no longer be compared against the long-term value of the resistance slope. Thus, the **[RSDLAlert]** and **[RSDLWarn]** flags will never be set. The **[RSDLI]** flag is set to indicate an interruption has occurred.

In addition, a new value of **RRate** cannot be calculated until two learning phases are completed with the device maintaining power between them, so a valid time is available for the calculation.

If the system designer is concerned about the power drawn by the bq34110 timer, another option is for the system to power up the bq34110 device, maintain power long enough for the device to complete two learning phases and calculate a valid **RRate** value for evaluation. The device can then be powered down until another evaluation is needed, in which case the sequence can be repeated.

2.11.1.8 Initial Rcell and RRate Learning Process

When the cell is first put into service, **Initial Learn Pulse Number** learning phases will be initiated, each resulting in a calculated **Rcell** value. These **Rcell** values will be averaged and stored as **Initial Rcell**.

The **EOS_RCELL_RRATE_LEARN()** command is available for the host to initiate the measurement of an **Initial Rcell** value. This command will also reset the timer measuring the time since completion of the **Initial Rcell** measurement.

NOTE: The **Initial Rcell** measurement can be done while in test mode, but the **Initial RRate** measurement cannot practically be done in test mode with an actual cell, due to the minimal change expected in the values of **Rcell** when using the short time durations of the test mode.

If any fault is detected during the **Initial Rcell** or **Initial RRate** measurement process, all learned data associated with the Rcell measurement in progress is discarded, and the device will initiate a new learning phase after **Auto Learn Retry Time**. If the **Initial RRate** value measured by the device is zero or negative, this result is ignored, and the device will still consider **Initial RRate** not yet learned. In this case, the host should initiate a new **Initial RRate** using **EOS_RCELL_RRATE_LEARN()**.

Table 2-62. Initial Learn Pulse Number

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|---------------------|----------------------------|------------------|---------------|-----------|-----------|---------------|--------|
| End Of Service | Resistance Learning | Initial Learn Pulse Number | Unsigned Integer | 1 | 0 | 255 | 1 | counts |

Table 2-63. Initial Rcell

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|---------------|------------------|---------------|-----------|-----------|---------------|------|
| End Of Service | Direct Resistance Decision | Initial Rcell | Unsigned Integer | 2 | 0 | 65535 | 0 | mΩ |

Table 2-64. Initial Rcell Learned

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------------|----------------------------|-----------------------|---------|---------------|-----------|-----------|---------------|------|
| End Of Service | Direct Resistance Decision | Initial Rcell Learned | Boolean | 1 | 0 | 1 | 0 | — |

The time since the last successful calculation of **Rcell** is provided via the **EOSSTATUS2()** command. If timing were disrupted since the last **Rcell** calculation, such as caused by a power cycle on the device, then this register will read zero until a new **Rcell** is calculated.

Similarly, the time since the successful calculation of **Initial Rcell** is also provided via the **EOSSTATUS2()** command. If timing was disrupted since the **Initial Rcell** calculation, this register will read zero, and the **[RSDLI]** flag will be set.

When the cell is first put into service, the first learning phases that are initiated are used to calculate multiple values for **RRate**. These multiple values are averaged and stored as **Initial RRate**. For the **Initial RRate** procedure to operate, the **Auto Learn Time** cannot be set = 0.

NOTE: For the EOS Determination function to provide best results, it is important that the values of **Rcell** be measured at a consistent level of charge. This means it cannot directly be used together with JEITA charging or **WHr Charge Termination** without additional steps.

If the **Initial Learn Pulse Number** is set greater than 1, **Learn Voltage Restore** is set = 1, and **Learn Sequence Mode** is set = 1 (DISCHARGE-BEFORE-CHARGE mode), the bq34110 device will wait for the cell to be charged after each **Learn Post-Relax Phase** is complete before it completes the learning cycle for a single initial learn pulse. It then initiates the next learning cycle for the next initial learn pulse.

However, if the **Learn Voltage Restore** is set = 0, then the bq34110 device will wait for the cell to be charged back after the **Learn Post-Relax Phase** is complete, but will immediately complete the learning cycle and initiate a new learning cycle for the next initial learn pulse. This will result in each of the multiple initial learn pulses being captured at slightly different depth-of-discharge, which can introduce an additional error into the measurement, depending on the battery chemistry used. To avoid this error, it is recommended that either the **Learn Voltage Restore** be set = 1 or the **Initial Learn Pulse Number** be set = 1.

Because the Learn Discharge Pulses only discharge the battery a small amount, recharging to compensate for this small discharge may create difficulty in achieving proper charge termination, depending on the battery chemistry used. This case should be evaluated during development, and if necessary, the pertinent charge termination settings can be adjusted to address this issue. For example, the **Current Taper Window** and **Minimum Taper Capacity** may need to be reduced to facilitate proper charge termination.

A possible issue can arise if the bq34110 gauge is configured for CHARGE-BEFORE-DISCHARGE mode, and a fault occurs after charging, but before the **Learn Discharge Phase** has completed. Then when the device attempts a new learning phase, it may have difficulty achieving proper charge termination, since the battery was already charged to the required level. In this case, a possible workaround is to enable the learning load and discharge the battery back to the original level before the next learning phase occurs.

2.12 Battery Level Threshold

The battery level threshold (BLT) feature indicates when the SOC of a battery pack has depleted to a certain value set in a DF register. This feature allows a host to program two capacity-based thresholds that govern the triggering of the BLT flag and the setting or clearing of the *OperationStatus()[BLT]* on the basis of *RemainingCapacity()*. The interrupt on pins ALERT1 and/or ALERT2 is enabled or disabled via *Alert1_6[BLT]* and *Alert2_6[BLT]*, respectively.

- *OperationStatus()[BLT]* is set when:
 - Current > 0 and *RemainingCapacity()* > *BLTChargeSet()*. This threshold is initialized at reset from **Init Charge Set**.
 - Current ≤ 0 and *RemainingCapacity()* < *BLTDischargeSet()*. This threshold is initialized at reset from **Init Discharge Set**.
- When either *BLTDischargeSet()* or *BLTChargeSet()* commands are received, *OperationStatus()[BLT]* will clear and the flag will be deasserted. The new threshold is written to either *BLTDischargeSet()* or *BLTChargeSet()*.
- At reset, the flag is set to the deasserted state.

Table 2-65. BLTDischargeSet()

| Name | Access | | | Protocol | Type | Min | Max | Default | Unit |
|-------------------|--------|-----|-----|----------|------|-----|-------|---------|------|
| | SE | US | FA | | | | | | |
| BLT Discharge Set | R/W | R/W | R/W | Word | S2 | — | 65535 | 150 | mAh |

This read/write word command updates the BLT set threshold for DISCHARGE mode for the next BLT flag assertion, deasserts the present BLT flag, and clears the *OperationStatus()[BLT]* bit.

Table 2-66. BLTChargeSet()

| Name | Access | | | Protocol | Type | Min | Max | Default | Unit |
|----------------|--------|-----|-----|----------|------|-----|-------|---------|------|
| | SE | US | FA | | | | | | |
| BLT Charge Set | R/W | R/W | R/W | Word | S2 | — | 65535 | 175 | mAh |

The read/write word command updates the BLT set threshold for CHARGE mode for the next BLT flag assertion, deasserts the present BLT flag, and clears the *OperationStatus()*[BLT] bit.

Table 2-67. Init Discharge Set

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|----------|--------------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | BLT | Init Discharge Set | I2 | 2 | 0 | 32767 | 150 | mAh |

Description: Initial value for *BLTDischargeSet()*

Table 2-68. Init Charge Set

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|----------|----------|-----------------|--------|---------------|-----------|-----------|---------------|------|
| Settings | BLT | Init Charge Set | I2 | 2 | 0 | 32767 | 175 | mAh |

Description: Initial value for *BLTChargeSet()*

2.13 Lifetime Data Collection

The bq34110 Lifetime Data Collection function can be enabled by setting *ManufacturingStatus()*[LF_EN] to gather data regarding the battery and store it to data flash.

The device logs the lifetime data for temperature, voltage, and current with programmable frequency and resolution. The data log recordings are controlled by settings in the **Lifetime Resolution** data flash subclass. The Lifetime Data Collection can be started by setting the [LF_EN] bit. Data available for collection include maximum charge and discharge currents, maximum pack voltage, number of data flash updates, and minimum and maximum temperature.

Once the Lifetime Data Collection function is enabled, the measured values are compared to what is already stored in the data flash. If the measured value is higher than the maximum or lower than the minimum value stored in the data flash by more than the "Resolution" set for at least one parameter, the entire Data Flash Lifetime Registers are updated after at least 60 seconds.

There is a 60-s minimum update time between DF writes. When a new maximum or minimum is detected, a 60-s timer is enabled, and the DF writes occur at the end of this window. Any additional max/min value detected within this window will also be updated. The first new max/min value detected after this window will trigger the next 60-s timer window.

Internal to the bq34110 device, there exists a RAM maximum/minimum table in addition to the DF maximum/minimum table. The RAM table is updated independent of the resolution parameters. The DF table is updated only if at least one of the RAM parameters exceeds the DF value by more than the resolution associated with it. When DF is updated, the entire RAM table is written to DF. Consequently, it is possible to see a new maximum or minimum value for a certain parameter even if the value of this parameter never exceeds the maximum or minimum value stored in the data flash for this parameter value by the resolution amount.

The Lifetime Data Collection of one or more parameters can be reset or restarted by writing new default (or starting) values to the corresponding data flash registers through sealed or unsealed access as described below. However, when using unsealed access, new values will only take effect after device reset.

The logged data can be accessed as RW in UNSEALED mode from the **Lifetime** class of data flash. Lifetime data may be accessed read-only when sealed using the *LT_DATA()* subcommand, which returns data on *MACData()*.

The logging settings such as **Temperature Resolution**, **Voltage Resolution**, and **Current Resolution** can be configured only in UNSEALED mode by writing to the **Lifetime Resolution** subclass of the data flash.

The **Lifetime Resolution** data flash contains the parameters that set the limits related to how much a data parameter must exceed the previously logged maximum/minimum value to be updated in the lifetime log. For example, voltage must exceed **Max Pack Voltage** by more than **Voltage Resolution** to update **Max Pack Voltage** in the data flash.

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-----------|---------------------|------------------------|------------------|---------------|-----------|-----------|---------------|-------|
| Lifetimes | Temperature | Max Temperature | Unsigned Integer | 2 | –400 | 1200 | 300 | 0.1°C |
| Lifetimes | Temperature | Min Temperature | Signed Integer | 2 | –400 | 1200 | 200 | 0.1°C |
| Lifetimes | Current | Max Charge Current | Signed Integer | 2 | 0 | 32767 | 0 | mA |
| Lifetimes | Current | Max Discharge Current | Signed Integer | 2 | 0 | 32767 | 0 | mA |
| Lifetimes | Voltage | Max Pack Voltage | Signed Integer | 2 | 0 | 32767 | 160 | 20 mV |
| Lifetimes | Voltage | Min Pack Voltage | Signed Integer | 2 | 0 | 32767 | 175 | 20 mV |
| Lifetimes | Lifetime Resolution | Temperature Resolution | Unsigned Integer | 1 | 0 | 255 | 10 | 0.1°C |
| Lifetimes | Lifetime Resolution | Current Resolution | Unsigned Integer | 1 | 0 | 255 | 100 | mA |
| Lifetimes | Lifetime Resolution | Voltage Resolution | Unsigned Integer | 1 | 0 | 255 | 1 | 20 mV |

2.14 Authentication

2.14.1 Overview

The bq34110 device can act as a SHA-1/HMAC authentication slave by using its internal engine. Sending a 160-bit SHA-1 challenge message to the device causes the device to return a 160-bit digest, based on the challenge message and hidden plain-text authentication keys. When this digest matches an identical one generated by a host or dedicated authentication master (operating on the same challenge message and using the same plain text keys), the authentication process is successful.

The device contains a default plain-text authentication key of 0x0123456789ABCDEFFEDCBA987654321. If using the device's internal authentication engine, the default key can be used for development purposes, but should be changed to a secret key and the part immediately sealed before putting a pack into operation.

2.14.2 Key Programming

When the device's SHA-1/HMAC internal engine is used, authentication keys are stored as plain text in memory. The *Authentication_Key()* command is the *ManufacturerAccessControl()* 0x0037 command and enables the update of the authentication key into the device. The device must be in FULL ACCESS mode for the authentication key to update.

To update a new authentication key, send the *Authentication_Key()* + the new 128-bit authentication key to *MACData()*.

There is no direct read access to the authentication key. After writing the new authentication to the gauge, the gauge will generate an all-zero challenge and provide the corresponding response for verification.

2.14.3 Authentication Challenge

To initiate an authentication challenge while in SEALED mode:

- Write 0x00 to *ManufacturerAccessControl()* at 0x3F.
- Write the 20-byte challenge to *MACData()* at addresses 0x40 through 0x53.
- Write the checksum to *MACDataSum()* at address 0x60.

At the last write to *MACDataSum()*, the bq34110 device will check the checksum and, if correct, begin an authentication computation. This procedure takes approximately 200 ms, after which the resulting digest will be written to *MACData()*, overwriting the pre-existing challenge.

To initiate an authentication challenge while in UNSEALED mode:

- Write 0x01 to *MACDataLen()* at 0x61.
- Write the 20-byte challenge to *MACData()* at addresses 0x40 through 0x53.
- Write the checksum to *MACDataSum()* at address 0x60.

At the last write to *MACDataSum()*, the bq34110 device will check the checksum and, if correct, begin an authentication computation. This procedure takes approximately 200 ms, after which the resulting digest will be written to *MACData()*, overwriting the pre-existing challenge.

NOTE: If there is an error detected in the checksum or the *MACData()* was read before the authentication computation was completed, then *MACData()* will still hold the original challenge data.

2.15 Communications

Communication with the bq34110 device is primarily via its I²C bus. The device supports the standard I²C read, incremental read, one-byte write quick read, and functions. The 7-bit device address (ADDR) is the most significant 7 bits of the hex address and is fixed as 1010101. The 8-bit device address is therefore 0xAA or 0xAB for write or read, respectively.




Figure 2-8. Supported I²C formats: (a) 1-byte write, (b) quick read, (c) 1 byte-read, and (d) incremental read (S = Start, Sr = Repeated Start, A = Acknowledge, N = No Acknowledge, and P = Stop).

The “quick read” returns data at the address indicated by the address pointer. The address pointer, a register internal to the I²C communication engine, increments whenever data is acknowledged by the device or the I²C master. “Quick writes” function in the same manner and are a convenient means of sending multiple bytes to consecutive command locations (such as 2-byte commands that require two bytes of data).




Figure 2-9. Attempt to Write a Read-Only Address (Nack After Data Sent By Master)



Figure 2-10. Attempt to Read an Address Above 0x7F (NACK Command)



Figure 2-11. Attempt at Incremental Writes (Nack All Extra Data Bytes Sent)




Figure 2-12. Incremental Read at the Maximum Allowed Read Address

The I²C engine releases both SDA and SCL if the I²C bus is held low for **Bus Low Time**. If the device were holding the lines, releasing them frees the master to drive the lines. If an external condition is holding either of the lines low, the I²C engine enters the low-power SLEEP mode.

Detailed examples of I²C transactions accessing gauge data can be found in the *Using I²C Communication with the bq275xx Series of Fuel Gauges Application Report* ([SLUA467](#)).

Data Commands

The bq34110 device uses a series of 2-byte standard commands to enable system reading and writing of battery information. Each command has an associated command-code pair, as indicated in [Table 3-1](#). Because each command consists of two bytes of data, two consecutive I²C transmissions must be executed to initiate the command function and to read or write the corresponding two bytes of data. Additional options for transferring data are described under the *Control()* command section below. Read and write permissions depend on the active access mode, SEALED or UNSEALED. See [Communications](#) for I²C details.

3.1 Command Summary

Table 3-1. Command Summary

| Name | Acronym | COMMAND CODE | UNIT | SEALED ACCESS |
|-----------------------------|-----------------|-------------------|---------|---------------|
| Control()/CONTROL_STATUS() | CNTL | 0x00 and 0x01 | NA | R/W |
| Temperature() | TEMP | 0x06 and 0x07 | 0.1°K | R |
| Voltage() | VOLT | 0x08 and 0x09 | mV | R |
| BatteryStatus() | BSTAT | 0x0A and 0x0B | NA | R |
| Current() | Current() | 0x0C and 0x0D | mA | R |
| RemainingCapacity() | RC | 0x10 and 0x11 | mAh | R |
| FullChargeCapacity() | FCC | 0x12 and 0x13 | mAh | R |
| AverageCurrent() | AI | 0x14 and 0x15 | mA | R |
| TimeToEmpty() | TTE | 0x16 and 0x17 | Minutes | R |
| TimeToFull() | TTF | 0x18 and 0x19 | Minutes | R |
| AccumulatedCharge | | 0x1A and 0x1B | mAh | R |
| AccumulatedTime | | 0x1C and 0x1D | 5 min | R |
| LastAccumulatedCharge | | 0x1E and 0x1F | mAh | R |
| LastAccumulatedTime | | 0x20 and 0x21 | 5 min | R |
| AveragePower() | AP | 0x24 and 0x25 | mW | R |
| InternalTemperature() | INTTEMP | 0x28 and 0x29 | 0.1°K | R |
| CycleCount() | CC | 0x2A and 0x2B | Number | R |
| RelativeStateOfCharge() | RSOC | 0x2C and 0x2D | % | R |
| StateOfHealth() | SOH | 0x2E and 0x2F | % | R |
| ChargingVoltage() | CV | 0x30 and 0x31 | mV | R |
| ChargingCurrent() | CC | 0x32 and 0x33 | mA | R |
| BLTDischargeSet | | 0x34 and 0x35 | mAh | RW |
| BLTChargeSet | | 0x36 and 0x37 | mAh | RW |
| OperationStatus() | | 0x3A and 0x3B | NA | R |
| DesignCapacity() | Design Capacity | 0x3C and 0x3D | mAh | R |
| ManufacturerAccessControl() | MAC | 0x3E and 0x3F | | RW |
| MACData() | | 0x40 through 0x5F | | RW |
| MACDataSum() | | 0x60 | | RW |
| MACDataLen() | | 0x61 | | RW |
| EOSLearnStatus | | 0x64 and 0x65 | | R |

Table 3-1. Command Summary (continued)

| Name | Acronym | COMMAND CODE | UNIT | SEALED ACCESS |
|-----------------|---------|---------------|-------|---------------|
| EOSSafetyStatus | | 0x66 and 0x67 | | R |
| EOSStatus | | 0x68 | | R |
| AnalogCount() | | 0x79 | | R |
| RawCurrent() | | 0x7A and 0x7B | | R |
| RawVoltage() | | 0x7C and 0x7D | mV | R |
| RawIntTemp() | | 0x7E and 0x7F | 0.1°K | R |
| RawExtTemp() | | 0x80 and 0x81 | 0.1°K | R |

3.2 Control(): 0x00/0x01

Issuing a *Control()* (or Manufacturer Access Control or MAC) command requires a 2-byte subcommand. The subcommand specifies the particular MAC function needed. The *Control()* command allows the system to control specific features of the gas gauge during normal operation and additional features when the device is in different access modes, as described below. On this device, *Control()* commands may also be sent to *ManufacturerAccessControl()*. Any subcommand that has a data response will be read back on *MACData()*. The readback of *CONTROL_STATUS()* is an exception in that this data is not read back on *MACData()*, but is read back directly.

Reading the *Control()* registers will always report the *CONTROL_STATUS()* data field except after the *DEVICE_TYPE()* and *FW_VERSION()* subcommands. After these subcommands, *CONTROL_STATUS()* will report the value 0xFFA5 one time before reverting to the normal data response. This is a flag to indicate that the data response has been moved to *MACData()*. Writing a 0x0000 to *Control()* is no longer necessary to read the *CONTROL_STATUS()*; however, doing so is acceptable.

When executing commands that require data (such as data flash writes), the subcommand can be written to either *Control()* or *ManufacturerAccessControl()* registers; however, it is recommended to write using the *ManufacturerAccessControl()* registers as this allows performing the full command in a single I²C transaction.

Table 3-2. Control() MAC Subcommands

| CNTL FUNCTION | CNTL DATA | SEALED ACCESS | DESCRIPTION |
|----------------|-----------|---------------|---|
| CONTROL_STATUS | 0x0000 | Yes | Reports the status of key features. This command should be read back on 0x00; it will not read back on <i>MACData()</i> . |
| DEVICE_TYPE | 0x0001 | Yes | Reports the device type of 0x0110 (indicating the bq34110 device) |
| FW_VERSION | 0x0002 | Yes | Reports the firmware version on the device type |
| HW_VERSION | 0x0003 | Yes | Reports the hardware version of the device type |
| IF_SUM | 0x0004 | Yes | Reports Instruction flash checksum |
| STATIC_DF_SUM | 0x0005 | Yes | Reports the static data flash checksum |
| PREV_MACWRITE | 0x0007 | Yes | This MAC subcommand returns previous <i>Control()</i> subcommand code. |
| BOARD_OFFSET | 0x0009 | Yes | Invokes the board offset correction |
| CC_OFFSET | 0x000A | Yes | Invokes the CC offset correction |
| CC_OFFSET_SAVE | 0x000B | Yes | Saves the results of the offset calibration process |
| ALL_DF_SUM | 0x0010 | Yes | This MAC subcommand returns the checksum of the entire data flash except for calibration data. |
| SET_SNOOZE | 0x0013 | Yes | This MAC subcommand forces the <i>CONTROL_STATUS()[SNOOZE]</i> bit to 1. |
| CLEAR_SNOOZE | 0x0014 | Yes | This MAC subcommand forces the <i>CONTROL_STATUS()[SNOOZE]</i> bit to 0. |
| ACCUM_DSG_EN | 0x001E | No | This MAC subcommand toggles the value of <i>ManufacturingStatus()[ACDSG_EN]</i> . |

Table 3-2. Control() MAC Subcommands (continued)

| CNTL FUNCTION | CNTL DATA | SEALED ACCESS | DESCRIPTION |
|-----------------------|-----------|---------------|---|
| ACCUM_CHG_EN | 0x001F | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [ACCHG_EN]</i> . |
| IGNORE_SELFDSG_EN | 0x0020 | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [IGNORE_SD_EN]</i> . |
| EOS_EN | 0x0021 | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [EOS_EN]</i> . |
| PIN_CONTROL_EN | 0x0022 | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [PCTL_EN]</i> . |
| LIFETIME_EN | 0x0023 | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [LF_EN]</i> . |
| WHR_EN | 0x0024 | No | This MAC subcommand toggles the value of <i>ManufacturingStatus() [WHR_EN]</i> . |
| CAL_TOGGLE | 0x002D | No | This MAC subcommand toggles the value of <i>OperationStatus() [CALMD]</i> . |
| SEAL | 0x0030 | No | Places the device in SEALED access mode |
| ENTER_ROM | 0x0033 | No | Places the device into ROM mode (same function as 0x0F00). |
| SECURITY_KEYS | 0x0035 | No | Reads and writes Security Keys |
| AUTHENTICATION_KEY | 0x0037 | No | Writes the authentication key into data flash |
| EOS_START_LEARN | 0x0039 | Yes | Initiates an EOS learning phase |
| EOS_ABORT_LEARN | 0x003A | Yes | Aborts an EOS learning phase |
| EOS_RCELL_RRATE_LEARN | 0x003B | No | Initiates the Initial Rcell and Initial RRate learning procedures |
| EOS_WARNCLR | 0x003C | Yes | Clears the EOS Warning flags |
| EOS_INITIAL_RCELL | 0x003E | Yes | Used to read and write the EOS Initial Rcell value |
| EOS_INITIAL_RRATE | 0x003F | Yes | Used to read and write the EOS Initial RRate value |
| RESET | 0x0041 | No | Resets device |
| EOS_LOAD_ON | 0x0044 | No | Turns on the learning load |
| EOS_LOAD_OFF | 0x0045 | No | Turns off the learning load |
| DEVICE_NAME | 0x004A | Yes | This MAC subcommand returns the device name. |
| ACCUM_RESET | 0x004B | Yes | Resets the Accumulated Charge integration counter |
| EOS_SAFETY_STATUS | 0x0051 | Yes | This returns the same value as the <i>EOSSafetyStatus()</i> command, but does not clear the bits after reading. |
| OPERATION_STATUS | 0x0054 | Yes | This returns the same value as the <i>OperationStatus()</i> command. |
| GaugingStatus | 0x0056 | Yes | This MAC subcommand returns the information in the CEDV gauging status register. |
| ManufacturingStatus | 0x0057 | Yes | This MAC subcommand returns the values of various functional modes of the device. |
| ALERT1STATUS | 0x005E | Yes | This MAC subcommand returns the value of flags as given by Alert1_0..6 Config . |
| ALERT2STATUS | 0x005F | Yes | This MAC subcommand returns the value of flags as given by Alert2_0..6 Config . |
| LT_DATA_1 | 0x0060 | Yes | This MAC subcommand returns lifetime data. |
| PIN_ALERT1_SET | 0x0068 | Yes | Sets the ALERT1 pin to high |
| PIN_ALERT1_RESET | 0x0069 | Yes | Resets the ALERT1 pin to low |
| PIN_ALERT2_SET | 0x006A | Yes | Sets the ALERT2 pin to high |
| PIN_ALERT2_RESET | 0x006B | Yes | Resets the ALERT2 pin to low |
| PIN_VEN_SET | 0x006C | Yes | Sets the VEN pin to high |
| PIN_VEN_RESET | 0x006D | Yes | Resets the VEN pin to low |
| PIN_LEN_SET | 0x006E | Yes | Sets the LEN pin to high |
| PIN_LEN_RESET | 0x006F | Yes | Resets the LEN pin to low |

Table 3-2. Control() MAC Subcommands (continued)

| CNTL FUNCTION | CNTL DATA | SEALED ACCESS | DESCRIPTION |
|----------------|-----------|---------------|---|
| MANU_DATA | 0x0070 | Yes | This MAC subcommand returns the Manufacturer Information Block. This can be written directly when unsealed. |
| EOSSTATUS1 | 0x007A | Yes | This MAC subcommand returns status information associated with the EOS Determination function. |
| EOSSTATUS2 | 0x007B | Yes | This MAC subcommand returns status information associated with the EOS Determination function. |
| ENTER_ROM | 0x0F00 | No | Places the device into ROM mode (same function as 0x0033) |
| STORE_REMCAP_A | 0x22C1 | Yes | Used to initiate storing the present value of <i>RemainingCapacity</i> for post-reset restore |
| STORE_REMCAP_B | 0x28A0 | Yes | Used to initiate storing the present value of <i>RemainingCapacity</i> for post-reset restore |

3.2.1 CONTROL_STATUS: 0x0000

A read of this command should be done by reading 0x00, which directly returns the data below. This command is an exception in that it does not read back on *MACData()*. The status word includes the following information:

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|-------|-------|-------|--------|-------|-------|-------|
| High Byte | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD |
| Low Byte | RSVD | RSVD | CCA | BCA | SNOOZE | RSVD | RSVD | RSVD |

RSVD: Reserved. Do not use.

CCA (Bit 5): Indicates the device Coulomb Counter Calibration routine is active. Active when set.

BCA (Bit 4): Indicates the device Board Calibration routine is active. Active when set.

SNOOZE (Bit 3): Status bit indicating a request for entry into SNOOZE mode. True when set. Default is 0.

3.2.2 DEVICE_TYPE: 0x0001

This MAC subcommand instructs the bq34110 device to return the device type to addresses 0x40/0x41.

3.2.3 FW_VERSION: 0x0002

This MAC subcommand instructs the bq34110 device to return the device number (0110 for the bq34110 device), followed by the firmware version (single byte), and the firmware build number (single byte) in big-endian format.

3.2.4 HW_VERSION: 0x0003

This MAC subcommand instructs the bq34110 device to return the hardware version to addresses 0x40/0x41.

3.2.5 IF_SUM: 0x0004

This MAC subcommand instructs the bq34110 device to report the instruction flash checksum.

3.2.6 STATIC_DF_SUM: 0x0005

This MAC subcommand instructs the bq34110 device to report the static data flash checksum.

3.2.7 PREV_MACWRITE: 0x0007

This MAC subcommand instructs the bq34110 device to return the previous command written to addresses 0x40/0x41. The value returned is limited to less than 0x0020. The data returned by this command is provided in little-endian format.

3.2.8 BOARD_OFFSET: 0x0009

This MAC subcommand instructs the bq34110 device to calibrate board offset. During board offset calibration, the [BCA] bit is set.

3.2.9 CC_OFFSET: 0x000A

This MAC subcommand instructs the bq34110 device to calibrate the coulomb counter offset. During calibration, the [CCA] bit is set.

3.2.10 CC_OFFSET_SAVE: 0x000B

This MAC subcommand instructs the bq34110 device to save the coulomb counter offset after calibration.

3.2.11 ALL_DF_SUM: 0x0010

This MAC subcommand instructs the bq34110 device to report the checksum of the entire data flash except for calibration data.

3.2.12 SET_SNOOZE: 0x0013

This MAC subcommand forces the *CONTROL_STATUS()*[SNOOZE] bit to 1.

3.2.13 CLEAR_SNOOZE: 0x0014

This MAC subcommand forces the *CONTROL_STATUS()*[SNOOZE] bit to 0.

3.2.14 ACCUM_DSG_EN: 0x001E

This MAC subcommand toggles the value of *ManufacturingStatus()*[ACDSG_EN].

3.2.15 ACCUM_CHG_EN: 0x001F

This MAC subcommand toggles the value of *ManufacturingStatus()*[ACCHG_EN].

3.2.16 IGNORE_SELFDSG_EN: 0x0020

This MAC subcommand toggles the value of *ManufacturingStatus()*[IGNORE_SD_EN].

3.2.17 EOS_EN: 0x0021

This MAC subcommand toggles the value of *ManufacturingStatus()*[EOS_EN].

NOTE: If [EOS_EN] is changed directly in data flash, then the device should be reset for the change to take effect.

3.2.18 PIN_CONTROL_EN: 0x0022

This MAC subcommand toggles the value of *ManufacturingStatus()*[PCTL_EN].

3.2.19 LIFETIME_EN: 0x0023

This MAC subcommand toggles the value of *ManufacturingStatus()*[LT_EN].

3.2.20 WHR_EN: 0x0024

This MAC subcommand toggles the value of *ManufacturingStatus()*[WHR_EN].

3.2.21 CAL_TOGGLE: 0x002D

This MAC subcommand toggles the value of *OperationStatus()*[CALMD].

3.2.22 SEAL: 0x0030

This MAC subcommand instructs the bq34110 device to transition from UNSEALED state to SEALED state. The fuel gauge should always be set to SEALED state for use in customers' end equipment.

3.2.23 ENTER_ROM: 0x0033

This MAC subcommand instructs the bq34110 device to enter ROM mode. This has the same function as the subcommand 0x0F00.

3.2.24 SECURITY_KEYS: 0x0035

This is a read/write command that changes the Unseal and Full Access Keys.

To read the keys, do the following:

1. Send the *Securitykeys()* subcommand to the *Control()* or *ManufacturerAccessControl()*.
2. Write 0x35 0x00 to either *Control(0x00, 0x01)* or *ManufacturerAccessControl(0x3E, 0x3F)*.
3. Read back 8 bytes at *MACData(0x40–0x47)*.

To write the keys, do the following:

1. Write 0x35 0x00 to either *Control(0x00, 0x01)* or *ManufacturerAccessControl(0x3E, 0x3F)*.
2. Write the data in big endian format to *MACData(0x40–0x47)*.
3. Write the checksum to *MACDataSum(0x60)*. The checksum is the complement of the sum of the data and command bytes.
4. Write the length of 0x08 to *MACDataLen(0x61)*. The length includes the command, data, checksum, and length bytes.

3.2.25 AUTHENTICATION_KEY: 0x0037

This MAC subcommand writes the authentication key into the device. See [Authentication](#) for more details.

3.2.26 EOS_START_LEARN: 0x0039

This MAC subcommand instructs the bq34110 device to begin a learning phase.

3.2.27 EOS_ABORT_LEARN: 0x003A

This MAC subcommand instructs the bq34110 device to stop a learning phase.

3.2.28 EOS_RCELL_RRATE_LEARN: 0x003B

This MAC subcommand instructs the bq34110 device to initiate an **Initial Rcell** and **Initial RRate** measurement.

3.2.29 EOS_WARNCLR: 0x003C

This MAC subcommand instructs the bq34110 device to clear the EOS warning bits (this includes [DRDWARN], [RSDWARN], and [RSDLWARN]).

3.2.30 EOS_INITIAL_RCELL: 0x003E

This MAC subcommand is used to read the stored **Initial_Rcell** measurement or to overwrite the value with a previously measured value.

3.2.31 EOS_INITIAL_RRATE: 0x003F

This MAC subcommand is used to read the **Initial_RRate** measurement or to overwrite the value with a previously measured value.

3.2.32 RESET: 0x0041

This MAC subcommand instructs the bq34110 device to perform a full reset. This command is only available when the device is UNSEALED.

3.2.33 EOS_LOAD_ON: 0x0044

This MAC subcommand instructs the bq34110 device to enable the EOS learning load.

3.2.34 EOS_LOAD_OFF: 0x0045

This MAC subcommand instructs the bq34110 device to disable the EOS learning load.

3.2.35 DEVICE_NAME: 0x004A

This MAC subcommand returns the device name on *MACData()* in ASCII characters (0x62 0x71 0x33 0x34 0x31 0x31 0c30 for the bq34110 device).

3.2.36 ACCUM_RESET: 0x004B

This MAC subcommand resets the **Accumulated Charge** integration counter.

3.2.37 EOS_SAFETY_STATUS: 0x0051

This MAC subcommand returns the same values as the *EOSSafetyStatus()* command, but does not clear the bits after reading.

3.2.38 OPERATION_STATUS: 0x0054

This MAC subcommand returns the same values as the *OperationStatus()* command.

3.2.39 GaugingStatus: 0x0056

This MAC subcommand returns various flags associated with the CEDV gas gauging function.

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|-------|-------|-------|-------|-------|-------|-------|
| High byte | VDQ | EDV2 | EDV1 | RSVD | RSVD | FCCX | RSVD | REST |
| Low byte | CF | DSG | EDV | RSVD | TC | TD | FC | FD |

Legend = **RSVD**: Reserved. Do not use.

VDQ: Discharge Qualified for Learning

1 = Detected

0 = Not Detected

EDV2: End-of-Discharge Voltage Level 2

1 = EDV2 voltage is reached during discharge.

0 = EDV2 voltage is not reached, or is not in DISCHARGE mode.

EDV1: Discharge Qualified for Learning

- 1 = Detected
- 0 = Not Detected

FCCX: *FullChargeCapacity()* has been updated.

This bit changes state each time *FullChargeCapacity()* updates.

REST: This bit indicates whether the device is in RELAX mode.

- 1 = The device has reached relaxation.
- 0 = The device has not reached relaxation.

CF: Condition Flag

- 1 = This bit is set if the device determines that the error in gauging has reached a level where a condition cycle is needed (discharging to EDV2 and charging to full).
- 0 = The gauging error has not reached the level where a condition cycle is needed.

DSG: Discharge/Relax

This bit is set when the cell is detected in a RELAX state or discharging, just not charging.

Note that this bit differs from the DSG bit in *BatteryStatus()*, which is set only when a discharge current is present, not during RELAX.

- 1 = Charging Not Detected
- 0 = Charging Detected

EDV0: End-of-Discharge Voltage Level 0 (Termination)

- 1 = Termination voltage is reached during discharge.
- 0 = Termination voltage is not reached or is not in DISCHARGE mode.

TC: Terminate Charge

- 1 = Detected
- 0 = Not Detected

TD: Terminate Discharge

- 1 = Detected
- 0 = Not Detected

FC: Fully Charged

- 1 = Detected
- 0 = Not Detected

FD: Fully Discharged

- 1 = Detected
- 0 = Not Detected

3.2.40 ManufacturingStatus: 0x0057

This MAC subcommand instructs the bq34110 device to provide the status of various functional modes, reflecting their state in the **Manufacturing Status Init** data flash. These bits are described in detail in [Section 2.1.2](#).

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|--------|--------|-------|---------|--------|--------------|----------|----------|
| High byte | CAL_EN | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD |
| Low byte | RSVD | WHR_EN | LF_EN | PCTL_EN | EOS_EN | IGNORE_SD_EN | ACCHG_EN | ACDSG_EN |

Legend = **RSVD**: Reserved. Do not use.

CAL_EN: Calibration Enabled

- 1 = Indicates the device is in CALIBRATION mode.
- 0 = Indicates the device is not in CALIBRATION mode.

WHR_EN: **WHr Charge Termination** Enable

- 1 = **WHr Charge Termination** is enabled.
- 0 = **WHr Charge Termination** is disabled (default).

LF_EN: Lifetime Data Collection Enable

- 1 = Enabled
- 0 = Disabled (default)

PCTL_EN: Pin Control Enable

This bit allows the host to manually control the state of the pins ALERT1, ALERT2, VEN, and LEN through the *ManufacturerAccessControl()* subcommands *PIN_ALERT1_SET()*, *PIN_ALERT1_RESET()*, *PIN_ALERT2_SET()*, *PIN_ALERT2_RESET()*, *PIN_VEN_SET()*, *PIN_VEN_RESET()*, *PIN_LEN_SET()*, and *PIN_LEN_RESET()*.

- 1 = Manual pin control is enabled.
- 0 = Manual pin control is disabled (default).

EOS_EN: End-Of-Service Determination Enable

Note that if **[EOS_EN]** is changed directly in data flash, then the device should be reset for the change to take effect.

- 1 = End-Of-Service Determination is enabled.
- 0 = End-Of-Service Determination is disabled (default).

IGNORE_SD_EN: Ignore Self-Discharge Control

- 1 = Accumulated charge integration ignores self-discharge, only integrates real current.
- 0 = Accumulated charge integration includes both real and self-discharge current (default).

ACCHG_EN: Accumulated Charge Enable for Charging Current Integration

- 1 = Positive (charging) values of *Current()* are integrated (default).
- 0 = Positive (charging) values of *Current()* are not integrated.

ACDSG_EN: Accumulated Charge Enable for Discharging Current Integration

- 1 = Negative (discharging) values of *Current()* are integrated (default).
- 0 = Negative (discharging) values of *Current()* are not integrated.

3.2.41 ALERT1STATUS: 0x005E

This MAC subcommand returns the value of flags as given by **Alert1_0 Config** to **Alert1_6 Config**.

3.2.42 ALERT2STATUS: 0x005F

This MAC subcommand returns the value of flags as given by **Alert2_0 Config** to **Alert2_6 Config**.

3.2.43 LT_DATA: 0x0060

This MAC subcommand returns the lifetime operation data. For more information, see [Lifetime Data Collection](#).

3.2.44 PIN_ALERT1_SET: 0x0068

This MAC subcommand directs the bq34110 device to assert the ALERT1 pin.

3.2.45 PIN_ALERT1_RESET: 0x0069

This MAC subcommand directs the bq34110 device to deassert the ALERT1 pin.

3.2.46 PIN_ALERT2_SET: 0x006A

This MAC subcommand directs the bq34110 device to assert the ALERT2 pin.

3.2.47 PIN_ALERT2_RESET: 0x006B

This MAC subcommand directs the bq34110 device to deassert the ALERT2 pin.

3.2.48 PIN_VEN_SET: 0x006C

This MAC subcommand directs the bq34110 device to assert the VEN pin.

3.2.49 PIN_VEN_RESET: 0x006D

This MAC subcommand directs the bq34110 device to deassert the VEN pin.

3.2.50 PIN_LEN_SET: 0x006E

This MAC subcommand directs the bq34110 device to assert the LEN pin.

3.2.51 PIN_LEN_RESET: 0x006F

This MAC subcommand directs the bq34110 device to deassert the LEN pin.

3.2.52 MANU_DATA: 0x0070

This MAC subcommand is used to read/write the 32-byte Manufacturer Information Block. See [Manufacturer Information Block](#) for more details.

3.2.53 EOSSTATUS1: 0x007A

This MAC subcommand returns 22-bytes of read-only information on *MACData()*. All numerical information that spans multiple bytes is represented in little-endian format.

| Byte | Name | Description |
|-------|--------------------------|--|
| 0–3 | EOS Auto Learn Time | This 4-byte number is a countdown timer in seconds, which counts down from the programmed value of Auto Learn Time to zero for a new learning phase to occur. |
| 4 | Learn Request Timeout | This is a single-byte countdown timer in seconds, which counts down from the programmed value of Learn Request Timeout to zero for the host to control the learning load. |
| 5 | Learning State | This is a single-byte number that shows in which state is the learning phase . See below for further details. |
| 6–7 | Learning Start Voltage | This two-byte number contains the voltage in mV that the EOS algorithm measured just before the Learn Discharge Phase begins. |
| 8–9 | Learning End Voltage | This two-byte number contains the voltage in mV that the EOS algorithm measured just before the Learn Discharge Phase ended. |
| 10–11 | Learning Charge Timer | This two-byte number is a countdown timer in seconds, which counts down from the programmed value of Learn Charge Timeout to zero. |
| 12–13 | Learning Discharge Timer | This two-byte number is a countdown timer in seconds, which counts down the duration of the learning discharge pulse. |
| 14–17 | Minimum Learn Time | This 3-byte number is a countdown timer in seconds, which counts down from the programmed value of Minimum Learn Time to zero. |
| 18–19 | EOS Avg Dsg Current | This is the calculated 100-s average discharge current measured over the last Learn Discharge Phase in mA. |
| 20–21 | EOS Avg Dsg Temp | This is the calculated average temperature measured over the last Learn Discharge Phase in 0.1°C. |

Table 3-3. Byte 5: Learning State

| Integer Value | State |
|---|--|
| Note that these bits reflect the present status at the time and are not sticky. | |
| 0 | IDLE |
| 1 | START |
| 2 | CHARGE |
| 3 | PRE-RELAX |
| 4 | DISCHARGE |
| 5 | POST-RELAX |
| 6 | CALC_RES |
| 7 | RESTORE VOLTAGE (CHG before DSG cycle) |
| 8 | RESTORE VOLTAGE (DSG before CHG cycle) |
| 8 | FAULT |

3.2.54 EOSSTATUS2: 0x007B

This MAC subcommand returns 25-bytes of read-only information on *MACData()*. All numerical information that spans multiple bytes is represented in little-endian format.

| Byte | Name | Description |
|-------|-----------------------------------|--|
| 0–1 | EOS Learned Resistance | This two-byte number provides the most recently calculated value of Rcell . |
| 2–3 | EOS Learned Res Time Hours | This two-byte number provides the hour value of the EOS timer since the most recent Rcell value was captured. |
| 4–5 | EOS Learned Res Time Seconds | This two-byte number provides the seconds value of the EOS timer since the most recent Rcell value was captured. |
| 6–7 | EOS Last Learned Resistance | This two-byte number provides the previous calculated value of Rcell . Note that this does not include Initial Rcell calculations. |
| 8–9 | EOS Last Learned Res Time Hours | This two-byte number provides the hour value of the EOS timer since the last Rcell value was captured. |
| 10–11 | EOS Last Learned Res Time Seconds | This two-byte number provides the seconds value of the EOS timer since the last Rcell value was captured. |
| 12–13 | EOS Initial RRate Age Hours | This two-byte number provides the hour value of the EOS timer since the Initial RRate value was captured. |
| 14–15 | EOS Initial RRate Age Seconds | This two-byte number provides the seconds value of the EOS timer since the Initial RRate value was captured. |
| 16–17 | EOS RRate | This two-byte number provides the most recently calculated value of RRate . |
| 18–19 | EOS RRate Long | This two-byte number provides the most recently calculated value of RRate_{longterm} . |
| 20–23 | InitialRcell/RRate Learn Res | This 4-byte value is a sum of the individual Rcell or RRate measurements captured thus far for averaging multiple values during the Initial Rcell and Initial RRate computation procedure. The number of measurements averaged is dictated by the value of Initial Learn Pulse Number . |
| 24 | InitialRcell/RRate Learn Count | This single-byte number provides the number of Learning Discharge Pulses used thus far during computation of the Initial Rcell and Initial RRate values. The final number of measurements averaged is dictated by the value of Initial Learn Pulse Number . |

3.2.55 ENTER_ROM: 0x0F00

This MAC subcommand instructs the bq34110 device to enter ROM mode. This has the same function as the subcommand 0x0033.

3.2.56 STORE_REMCAP_A: 0x22C1

When this MAC subcommand is written within 4 seconds of when the *STORE_REMCAP_B()* MAC subcommand is written, the present value of *RemainingCapacity()* is stored to data flash. When the bq34110 device is reset, the value of *RemainingCapacity()* is initialized to the stored value.

3.2.57 STORE_REMCAP_B: 0x28A0

When this MAC subcommand is written within 4 seconds of when the *STORE_REMCAP_A()* MAC subcommand is written, the present value of *RemainingCapacity()* is stored to data flash. When the bq34110 device is reset, the value of *RemainingCapacity()* is initialized to the stored value.

3.3 Temperature(): 0x06/0x07

This read-only command pair returns an unsigned integer value of the temperature, in units of 0.1°K, measured by the device and has a range of 0 to 6553.5°K. The source of the measured temperature is configured by the **[TEMPS]** bit in the **Operation Config A** register.

TEMPS: *Temperature()* source selection

1 = External temperature sensor is used (default).

0 = Internal temperature sensor is used.

Table 3-4. Temperature()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|-------------|--------|----|----|----------|------|-----|-------|-------|
| | SE | US | FA | | | | | |
| Temperature | R | R | R | Word | U2 | 0 | 65535 | 0.1°K |

3.4 Voltage(): 0x08/0x09

This read-word command pair returns an unsigned integer value of the measured battery voltage in mV with a range of 0 V to 65535 mV.

Table 3-5. Voltage()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|---------|--------|----|----|----------|------|-----|-------|------|
| | SE | US | FA | | | | | |
| Voltage | R | R | R | Word | U2 | 0 | 65535 | mV |

3.5 BatteryStatus(): 0x0A/0x0B

This read only register provides indications on the status of the battery.

Table 3-6. BatteryStatus()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|---------------|--------|----|----|----------|------|------|------|------|
| | SE | US | FA | | | | | |
| BatteryStatus | R | R | R | Word | Hex | 0x00 | 0xff | — |

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----|-------|--------|-------|-------|-------|-------|---------|--------|
| MSB | RSVD | SOCLOW | UTC | UTD | OTC | OTD | BATHIGH | BATLOW |
| LSB | SLEEP | CHGINH | FD | FC | TCA | TDA | CHG | DSG |

Legend = **RSVD**: Reserved. Do not use.

SOCLOW: State-Of-Charge low detection

1 = Low SOC state is detected.

0 = Low SOC state is not detected.

UTC: Undertemperature in Charge condition is detected.

1 = Undertemperature in Charge is detected.

0 = Undertemperature in Charge is not detected.

UTD: Undertemperature in Discharge condition is detected.

1 = Undertemperature in Discharge is detected.

0 = Undertemperature in Discharge is not detected.

OTC: Overtemperature in Charge condition is detected.

1 = Overtemperature in Charge is detected.

0 = Overtemperature in Charge is not detected.

OTD: Overtemperature in Discharge condition is detected.

1 = Overtemperature in Discharge is detected.

0 = Overtemperature in Discharge is not detected.

BATHIGH: Battery High Voltage Alarm.

This flag is set and cleared based on the selected thresholds in **Safety.BATHIGH** data flash settings.

BATLOW: Battery Low Voltage Alarm

This flag is set and cleared based on the selected thresholds in **Safety.BATLOW** data flash settings.

SLEEP: The device is in SLEEP mode when set.

1 = The device is in SLEEP mode.

0 = The device is not in SLEEP mode.

CHGINH: Charge inhibit.

If set, this indicates charging should not begin because *Temperature()* is outside the acceptable range.

1 = Charging is inhibited, indicating charging should not begin.

0 = Charging is not inhibited.

FD: Full discharge is detected.

This flag is set and cleared based on the selected **SOC Flag Config B** options.

FC: Full charge is detected.

This bit is controlled by settings in **SOC Flag Config A** and **SOC Flag Config B**.

TCA: Terminate Charge Alarm.

This flag is set and cleared based on the selected **SOC Flag Config A** options.

TDA: Terminate Discharge Alarm.

This flag is set and cleared based on the selected **SOC Flag Config A** options.

CHG: Charge current detection

1 = Charge current is detected.

0 = No charge is detected.

DSG: Discharge current detection

1 = Discharge is current detected.

0 = No discharge is detected.

3.6 Current(): 0x0C/0x0D

This read-only command pair returns a signed integer value that is the average current flowing through the sense resistor. It is updated every 1 second with units of 1 mA per LSB.

Table 3-7. Current()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|---------|--------|----|----|----------|------|--------|-------|------|
| | SE | US | FA | | | | | |
| Current | R | R | R | Word | I2 | –32768 | 32767 | mA |

3.7 RemainingCapacity(): 0x10/0x11

This read-only command pair returns the compensated battery capacity remaining. Unit is 1 mAh per LSB.

Table 3-8. RemainingCapacity()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|-------------------|--------|----|----|----------|------|-----|-------|------|
| | SE | US | FA | | | | | |
| RemainingCapacity | R | R | R | Word | U2 | 0 | 65535 | mAh |

3.8 FullChargeCapacity(): 0x12/0x13

This read-only command pair returns the learned full battery capacity. Unit is 1 mAh per LSB.

Table 3-9. FullChargeCapacity()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|--------------------|--------|----|----|----------|------|-----|-------|------|
| | SE | US | FA | | | | | |
| FullChargeCapacity | R | R | R | Word | U2 | 0 | 65535 | mAh |

3.9 AverageCurrent(): 0x14/0x15

This read-word function returns a signed integer value that approximates a one-minute rolling average of the current being supplied (or accepted) through the battery terminals in mA with a range of –32,768 to 32,767.

AverageCurrent() is calculated by a rolling IIR filtered average of *Current()* function data with a period of 14.5 s. During the time after a reset or when switching between charge and discharge currents and before 14.5 s has elapsed, the reported *AverageCurrent()* = *Current()* function value.

Table 3-10. AverageCurrent()

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|----------------|--------|----|----|----------|------|--------|-------|------|
| | SE | US | FA | | | | | |
| AverageCurrent | R | R | R | Word | I2 | –32767 | 32767 | mA |

The data flash value **Filter** determines the time constant of the filter operation used in the calculation of *AverageCurrent()* as follows:

$AverageCurrent() = a \times AverageCurrent() \text{ old} + (1-a) \times Current()$ with:

$a = \text{Filter}/256$; time constant = (1 s) / $\ln(1/a)$ (default = 14.5 s)

TimeToEmpty(): 0x16/0x17

www.ti.com

| Class | Subclass | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|----------|--------|------------------|---------------|-----------|-----------|---------------|------|
| Calibration | Current | Filter | Unsigned integer | 1 | 0 | 255 | 239 | — |

3.10 TimeToEmpty(): 0x16/0x17

This read-word function returns the predicted remaining battery capacity based on the present rate of discharge.

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|-------------|--------|----|----|----------|------|-----|-------|------|
| | SE | US | FA | | | | | |
| TimeToEmpty | R | R | R | Word | U2 | 0 | 65535 | min |

3.11 TimeToFull(): 0x18/0x19

This read-word function returns the predicted time to full charge based on *Current()*.

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|------------|--------|----|----|----------|------|-----|-------|------|
| | SE | US | FA | | | | | |
| TimeToFull | R | R | R | Word | U2 | 0 | 65535 | min |

3.12 AveragePower(): 0x24/0x25

This read-word function returns a signed integer value that approximates a one-minute rolling average of the power being supplied (or accepted) through the battery terminals in units of 10 mW with a range of –32,768 to 32,767.

AveragePower() is calculated by a rolling IIR filtered average of *Current()* and *Voltage()* function data with a period of 14.5 s. During the time after a reset or when switching between charge and discharge currents and before 14.5 s has elapsed, the reported *AveragePower()* = *Current()* × *Voltage()*.

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|--------------|--------|----|----|----------|------|--------|-------|-------|
| | SE | US | FA | | | | | |
| AveragePower | R | R | R | Word | I2 | –32767 | 32767 | 10 mW |

3.13 InternalTemperature(): 0x28/0x29

This read-only function returns an unsigned integer value of the internal temperature sensor in units of 0.1°K measured by the gas gauge. This function can be useful as an additional system-level temperature monitor if the main *Temperature()* function is configured for external or host-reported temperature.

3.14 CycleCount(): 0x2A/0x2B

This read-only function returns an unsigned integer value of the number of cycles that the active cell has experienced with a range of 0 to 65535. One cycle occurs when accumulated discharge ≥ cycle threshold. The cycle threshold is calculated as **Cycle Count Percentage** times either *FullChargeCapacity()* (when **CEDV Gauging Configuration [CCT]** = 1) or *DesignCapacity()* (when **[CCT]** = 0).

3.15 RelativeStateOfCharge(): 0x2C/0x2D

This read-only command returns an unsigned integer value of the predicted remaining battery capacity expressed as a percentage of *FullChargeCapacity()* with a range of 0 to 100%.

3.16 StateofHealth(): 0x2E/0x2F

This command returns the state-of-health (SOH) information of the battery. *StateOfHealth()* is calculated as a percentage of *FullChargeCapacity()* relative to **Design Capacity**. It is a read-only command.

Byte 0: LSB of SOH in capacity

Byte 1: MSB of SOH in capacity

Byte 2: LSB of SOH in energy

Byte 3: MSB of SOH in energy

3.17 ChargingVoltage(): 0x30/0x31

This read-only function returns an unsigned integer value of the needed charging voltage of the battery. A value of 65,535 indicates that the battery is requesting the maximum voltage from the battery charger.

3.18 ChargingCurrent(): 0x32/0x33

This function returns the needed charging current determined by the device.

| Name | Access | | | Protocol | Type | Min | Max | Unit |
|-------------------|--------|----|----|----------|------|-----|-------|-------|
| | SE | US | FA | | | | | |
| ChargingCurrent() | R | R | R | Word | U2 | 0 | 65535 | 10 mA |

3.19 BLTDischargeSet(): 0x34/0x35

This read/write word command updates the BLT set threshold for DISCHARGE mode for the next BLT flag assertion, deasserts the present BLT flag, and clears the *OperationStatus()[BLT]* bit.

| Name | Access | | | Protocol | Type | Min | Max | Default | Unit |
|-------------------|--------|-----|-----|----------|------|-----|-------|---------|------|
| | SE | US | FA | | | | | | |
| BLT Discharge Set | R/W | R/W | R/W | Word | S2 | — | 65535 | 150 | mAh |

3.20 BLTChargeSet(): 0x36/0x37

This read/write word command updates the BLT set threshold for CHARGE mode for the next BLT flag assertion, deasserts the present BLT flag, and clears the *OperationStatus()[BLT]* bit.

| Name | Access | | | Protocol | Type | Min | Max | Default | Unit |
|----------------|--------|-----|-----|----------|------|-----|-------|---------|------|
| | SE | US | FA | | | | | | |
| BLT Charge Set | R/W | R/W | R/W | Word | S2 | — | 65535 | 175 | mAh |

3.21 OperationStatus(): 0x3A/0x3B

This read-only command returns the value of various flags. When read, this data is returned in little-endian format.

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------|-------|-------|-------|-------|-------|-------|----------|-------|
| High Byte | RSVD | RSVD | RSVD | RSVD | RSVD | RSVD | INITCOMP | AUTH |
| Low Byte | BLT | SMTH | ACTHR | VDQ | EDV2 | SEC1 | SEC0 | CALMD |

Legend = **RSVD**: Reserved. Do not use.

AUTH: Authentication status

1 = Authentication is in progress.

0 = Authentication is not in progress.

INITCOMP: Initialization Complete

- 1 = Device initialization (after reset or initial power up) is complete.
- 0 = Device initialization is not complete.

BLT: Battery Level Threshold Flag.

Setting and clearing this flag depends upon various conditions. See [Battery Level Threshold](#) for details.

SMTH: Smoothing Flag

This flag indicates whether the *RemainingCapacity()* accumulation is currently scaled by the smoothing engine.

- 1 = Smoothing engine is enabled.
- 0 = Smoothing engine is not enabled.

ACTHR: Accumulated Charge Threshold Flag

- 1 = The accumulated charge has been detected passing a threshold.
- 0 = The accumulated charge has not been detected passing a threshold.

VDQ: Discharge Qualified flag

This flag indicates whether the present discharge cycle is qualified for an FCC update.

- 1 = Discharge cycle is qualified.
- 0 = Discharge cycle is not qualified.

EDV2: EDV2 flag

This flag indicates whether the measured cell voltage is below the EDV2 threshold.

- 1 = Cell voltage is below the EDV2 threshold.
- 0 = Cell voltage is not below the EDV2 threshold.

SEC1, SEC0: Security Status bits

- 1, 1 = Sealed status
- 1, 0 = Unsealed status
- 0, 1 = Full access status
- 0, 0 = Invalid. This indicates the state has not yet been loaded.

CALMD: CALIBRATION mode

This flag indicates whether the device is in CALIBRATION mode or not. It is controlled by the *CAL_TOGGLE()* subcommand, which toggles its state.

- 1 = Calibration is enabled; *ManufacturingData()* is enabled to output ADC and coulomb counter raw data.
- 0 = Calibration is disabled.

3.22 **DesignCapacity(): 0x3C/0x3D**

This read-only function returns the value stored in **Design Capacity**. This is intended to be the theoretical or nominal capacity of a new pack in units of 1 mAh per LSB, and is used for the calculation of *StateOfHealth()*.

3.23 **ManufacturerAccessControl(): 0x3E/0x3F**

This read-write word function returns the subcommand that is currently active for reads on *MACData()*.

Word writes to this function will set a subcommand. Commands that do not require data will execute immediately (identical to writes to *Control()*).

3.24 MACData(): 0x40 through 0x5F

This read-write block returns the result data for the currently active subcommand. It is recommended to start the read at *ManufacturerAccessControl()* to verify the active subcommand.

Writes to this block are used to provide data to a subcommand when required.

3.25 MACDataSum(): 0x60

This read-write function returns the checksum of the current subcommand and data block.

Writes to this register provide the checksum necessary in order to execute subcommands that require data. The checksum is calculated as the complement of the sum of the *ManufacturerAccessControl()* and the *MACData()* bytes. *MACDataLen()* determines the number of bytes of *MACData()* that are included in the checksum.

3.26 MACDataLen(): 0x61

This read-write function returns the number of bytes of *MACData()* that are part of the response and included in *MACDataSum()*.

Writes to this register provide the number of bytes in *MACData()* that should be processed as part of the subcommand. Subcommands that require block data are not executed until *MACDataSum()* and *MACDataLen()* are written together as a word.

3.27 EOSLearnStatus(): 0x64/0x65

This command returns various flags providing information on the EOS Determination function.

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----|-------|--------|--------|----------|-------|-------|-------|-------|
| LSB | LCTO | LFAULT | LABRT | LCMD | LPER | LRLX | LCHG | LDSG |
| MSB | LDONE | LRES | LRSTOR | LCTLEDGE | LUCD | LDPAM | LDPAT | LDPAT |

RSVD: Reserved. Do not use.

LCTO: Learn Charge Time Out

This bit is set = 1 if the bq34110 device is in LEARN CHARGE mode and detects the charging time has exceeded **Learn Charge Time Limit**. This bit is reset to 0 when a new learning phase begins.

1 = A Learn Excessive Charge Time has been detected.

0 = A Learn Excessive Charge Time has not been detected.

LFAULT: Learn Fault Flag

This bit is set = 1 whenever a learning phase is terminated for any reason other than a valid termination, and also if any other fault (such as in *GaugingStatus()* or *BatteryStatus()*) occurred during the learning phase. The bit will be reset to 0 when a new learning phase begins.

1 = A learning phase has been aborted.

0 = A learning phase has not been aborted.

LABRT: Learn Abort on Command

This bit is set = 1 whenever a learning phase was aborted by the host. A bit that has been set = 1 will be reset to 0 when a new learning phase begins.

1 = A requested learning phase has been aborted.

0 = A requested learning phase has not been aborted.

LCMD: Learn Command

This bit is set = 1 if learning is activated and a learning phase has been started by a command. The bit will remain high until the learning phase is complete (including charging, learning, discharging, and related calculations).

- 1 = The device is in a command-initiated learning phase.
- 0 = The device is not in a command-initiated learning phase.

LPER: Learn Periodic Mode

This bit is set = 1 if learning is activated and the bq34110 device is in PERIODIC LEARN mode. This bit is only set while the device is in a learning phase.

- 1 = The device is in periodic learn mode.
- 0 = The device is not in periodic learn mode.

LRLX: Learn RELAX mode

This bit is set = 1 if learning is activated and the bq34110 device is in a RELAX mode during learning. This means the cell is waiting to detect a relaxed condition; it may not have achieved relaxation yet.

- 1 = The device is in RELAX mode during learning.
- 0 = The device is not in RELAX mode during learning.

LCHG: Learn CHARGE mode

This bit is set = 1 if the bq34110 device is in learn CHARGE mode. If the device is controlling a charger directly through a device pin, then the value of this signal will be reflected on the selected pin. If instead the host is controlling the charger, then this bit can be used to signal the host to initiate charging.

- 1 = A LEARN CHARGE mode is in progress.
- 0 = A LEARN CHARGE mode is not in progress.

LDSG: Learn DISCHARGE Mode

This bit is set = 1 if the bq34110 device is in automatic END-OF-SERVICE DETERMINATION mode and the device intends to begin a **Learn Discharge Phase**. It is set = 0 when the device intends the **Learn Discharge Phase** to end. If the device is controlling the discharge directly using the LEN pin, then the LEN pin will reflect the value of LDSG. If instead the host is controlling the **Learn Discharge Current**, this bit will signal the host to enable the **Learn Discharge Current**.

- 1 = A **Learn Discharge Phase** has been requested or is in progress.
- 0 = A **Learn Discharge Phase** is requested to stop or has been stopped.

LDONE: Learn Done

This bit is set = 1 when a valid learning phase has completed.

- 1 = A valid learning phase was completed.
- 0 = A valid learning phase was not completed.

LRES: Learned **Rcell**

This bit is set = 1 when the bq34110 device has completed the computation of a new **Rcell** value during the present learning phase. This bit is cleared when the learning phase is complete.

- 1 = A new value of **Rcell** was acquired.
- 0 = A new value of **Rcell** has not yet been acquired.

LRSTOR: Learn Voltage Restore

This bit is set = 1 if whenever the **Learn Discharge Phase** is complete and the voltage can be restored back to its original level. This bit is cleared when the learning phase is complete.

- 1 = A Learning Discharge Phase has completed, and the voltage can be restored.
- 0 = The device has completed the learning phase.

LCTLEDGE: Learn Discharge Flag Edge Detected

This bit is set = 1 if whenever LDSG changes state. This can be used by the host as an interrupt to recognize when a learning load should be activated and when it should be disabled. This bit clears when the register is read.

- 1 = A change in LDSG was detected (this is only applicable when LENCTL=0).
- 0 = A change in LDSG was not detected.

LUCD: Learn Unexpected Current Detected

This bit is set when the device is in **LEARNING** mode (but not in the **Learn Discharge Phase**), and a current is detected differently than what is expected. It is set if the device is attempting to charge or relax, and a discharge current in excess of **Discharge Detection Threshold** is detected. It is also set if the device is in a **RELAX** mode and a charging current in excess of **Charge Detection Threshold** is detected. This detection also terminates the learning phase, and this bit will remain set as a flag to the host as to why the learning phase was aborted. This bit will be reset to 0 when a new learning phase begins.

1 = An unexpected system-related current was detected during a learning charge or learning relax period.

0 = An unexpected system-related current was not detected.

LDPAM: Learn Discharge Phase Abort on Timer

This bit is set = 1 when a **Learn Discharge Phase** was requested by the host but was declined due to the time since the last **Learn Discharge Phase** was less than the interval specified in **Minimum Learn Time**. A bit that was set = 1 will be reset to 0 when **Minimum Learn Time** has passed.

1 = A requested **Learn Discharge Phase** was declined.

0 = A requested **Learn Discharge Phase** has not been declined.

LDPAT: Learn Discharge Phase Abort on Temperature

This bit is set = 1 when a **Learn Discharge Phase** was initiated but was aborted due to **Temperature()** measured outside the range allowed by **Learn Min Temperature** and **Learn Max Temperature**. A bit that was set = 1 will be reset to 0 when a new **Learn Discharge Phase** begins.

1 = A **Learn Discharge Phase** was aborted.

0 = A **Learn Discharge Phase** has not been aborted.

LDPAI: Learn Discharge Phase Abort on Current

This bit is set = 1 when a **Learn Discharge Phase** was initiated but was aborted due to **Current()** measured outside the range allowed by **Learn Discharge Current** and **Learn Discharge Current Boundary**. A bit that was set = 1 will be reset to 0 when a new **Learn Discharge Phase** begins.

1 = A **Learn Discharge Phase** was aborted.

0 = A **Learn Discharge Phase** has not been aborted.

3.28 EOSSafetyStatus(): 0x66/0x67

This command returns flags generated by the EOS Determination function.

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----|-------|-------|-------|-------|-------|------------|----------|----------|
| LSB | RSVD | RSVD | RSVD | RSVD | RSVD | RSDL ALERT | RSDALERT | DRDALERT |
| MSB | RSVD | RSVD | RSVD | RSVD | RSVD | RSDLWARN | RSDWARN | DRDWARN |

Legend = **RSVD**: Reserved. Do not use.

RSDLALERT: Resistance Slope Decisioning Long-Term Alert

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the **[RSDLALERT]** signal. This signal is cleared when the register is read or if a new learning phase begins.

1 = An RSDLALERT was detected.

0 = An RSDLALERT has not been detected.

RSDALERT: Resistance Slope Decisioning Alert

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the [RSDALERT] signal. This signal is cleared when the register is read or if a new learning phase begins.

- 1 = An RSDALERT was detected.
- 0 = An RSDALERT has not been detected.

DRDALERT: Direct Resistance Decisioning Alert

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the [DRDALERT] signal. This signal is cleared when the register is read or if a new learning phase begins.

- 1 = A DRDALERT was detected.
- 0 = A DRDALERT has not been detected.

RSDLWARN: Resistance Slope Decisioning Long-Term Warning

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the [RSDLWARN] signal. This signal is NOT cleared when the register is read. It can only be cleared using the command *EOS_WARNCLR()*.

- 1 = An RSDLWARN was detected.
- 0 = An RSDLWARN has not been detected.

RSDWARN: Resistance Slope Decisioning Warning

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the [RSDWARN] signal. This signal is NOT cleared when the register is read. It can only be cleared using the command *EOS_WARNCLR()*.

- 1 = An RSDWARN was detected.
- 0 = An RSDWARN has not been detected.

DRDWARN: Direct Resistance Decisioning Warning

This bit is set = 1 if the bq34110 EOS Determination function detects the condition described above to trigger the [DRDWARN] signal. This signal is NOT cleared when the register is read. It can only be cleared using the command *EOS_WARNCLR()*.

- 1 = A DRDWARN was detected.
- 0 = A DRDWARN has not been detected.

3.29 EOSStatus(): 0x68

This command returns additional flags that provide information related to the EOS Determination function.

| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|------|------|------|-----|-------|--------|---------|--------|
| SRRL | SRCL | RSVD | LTI | RSDLI | RCELLR | IRRCOMP | IRCOMP |

Legend = **RSVD:** Reserved. Do not use.

SRRL: *Initial RRate* Learning in Progress

This bit is set = 1 if the bq34110 EOS Determination function begins the required learning phases to calculate a value of *Initial RRate*, generally after an *EOS_RCELL_RRATE_LEARN()* command has been issued. The bit will clear when the *Initial RRate* learning and computation is complete.

SRCL: *Initial Rcell* Learning in Progress

This bit is set = 1 if the bq34110 EOS Determination function begins the required learning phases to calculate a value of *Initial Rcell*, generally after an *EOS_RCELL_RRATE_LEARN()* command has been issued. The bit will clear when the Initial Rcell learning and computation is complete.

LTI: Learn Timer Invalid

This bit is set = 1 if the bq34110 EOS Determination function detects that the timer has been interrupted since the most recent **Rcell** was calculated. In this case, the RSD algorithm must capture two new **Rcell** values separated in time to calculate a new value of **RRate** and evaluate this for corresponding alerts and warnings.

1 = A timer interruption was detected.

0 = A timer interruption has not been detected.

RSDLI: Resistance Slope Decisioning Long-Term Invalid

This bit is set = 1 if the bq34110 EOS Determination function detects that the timer has been interrupted since the **Initial RRate** was calculated. In this case, the RSDL algorithm will no longer trigger an alert or warning.

1 = A timer interruption was detected.

0 = A timer interruption has not been detected.

RCELLR: Rcell Reduction Alert

This bit is set = 1 if the bq34110 EOS Determination function detects a value of Rcell that is more than 2% below the previous value of **Rcell**. This signal is cleared when the register is read or if a new learning phase begins.

1 = A reduction in **Rcell** was detected.

0 = A reduction in **Rcell** has not been detected.

IRRCOMP: Initial RRate Calculation Complete

This bit is set = 1 if the bq34110 EOS Determination function has completed the required learning phases to calculate a value of **Initial RRate**. This bit is reset when a new **Initial RRate** calculation is triggered until the new calculation is complete. This bit can be written by the host through loading data flash if the host wishes to initialize the device with previously calculated **Initial RRate** data and not trigger a new **Initial RRate** calculation.

1 = **Initial RRate** was obtained.

0 = **Initial RRate** has not been obtained.

IRCOMP: Initial Rcell Calculation Complete

This bit is set = 1 if the bq34110 EOS Determination function has completed the required learning phases to calculate a value of Initial Rcell. This bit is reset when a new **Initial Rcell** calculation is triggered until the new calculation is complete. This bit can be written by the host through loading data flash if the host wishes to initialize the device with previously calculated **Initial Rcell** data and not trigger a new **Initial Rcell** calculation.

1 = **Initial Rcell** was obtained.

0 = **Initial Rcell** has not been obtained.

3.30 AnalogCount(): 0x79

This read-only function returns the analog calibration counter. The value is incremented every time the analog calibration data is updated.

3.31 RawCurrent(): 0x7A/0x7B

This read-only function returns the raw data from the coulomb counter, which is indirectly related to the current being measured.

3.32 RawVoltage(): 0x7C/0x7D

This read-only function returns the raw data from the cell voltage reading.

3.33 RawIntTemp(): 0x7E/0x7F

This read-only function returns the raw data from the internal temperature measurement.

3.34 RawExtTemp(): 0x80/0x81

This read-only function returns the raw data from the external temperature measurement.

Data Flash

Data flash (DF) can only be updated if *Voltage()* \geq **Flash Update OK Voltage**, except while the device is in CALIBRATION mode. Flash programming current can cause an increase in LDO dropout. The value of **Flash Update OK Voltage** should be selected such that the device V_{CC} voltage does not fall below its minimum of 2.4 V during flash write operations.

4.1 Accessing Data Flash

Accessing data flash is supported by accessing the actual physical memory in the address range 0x4000–0x43FF. This provides up to 1k of directly addressable DF. In this mode, the subcommand represents the actual base address in DF to access. Reads provide a 32-byte block (except if it runs off the end of DF). The length will identify if it is at the end (less than 32 bytes). Writes can have anywhere from 1 to 32 bytes, which provide the ability to write a single DF parameter without having to read a row first.

4.1.1 Write to DF Example

Assume data1 is located at address 0x4000 and data2 is located at address 0x4002 and both data1 and data2 are U2 type. To update data1 and data2 to 0x1234 and 0x5678, respectively, do the following:

- Write 0x00 0x40 (DF address in little endian format) to *ManufacturerAccessControl(0x3E, 0x3F)*.
- Write 0x12 0x34 0x56 0x78 (data in big endian format) to *MACData(0x40–0x43)*. The writes to *ManufacturerAccessControl()* and *MACData()* can be performed in a single transaction.
- Write 0xAB (complement of the sum of the *ManufacturerAccessControl()* and *MACData()* bytes) to *MACDataSum(0x60)*.
- Write 0x08 (4 + length of *MACData()* bytes) to *MACDataLen(0x61)*.
- The data flash write will execute when the *MACDataSum()* and *MACDataLen()* are written in order (word write) and are verified to be correct.

4.1.2 Read from DF Example

- Write 0x00 0x40 (DF address in little endian format) to *ManufacturerAccessControl(0x3E, 0x3F)*.
- Read *ManufacturerAccessControl(0x3E, 0x3F)* to verify.
- Read data from *MACData(0x40–0x5F)*.
- Read checksum and length from *MACDataSum(0x60)*, *MACDataLen()*.
- Verify checksum. All data above can be read in a single transaction by reading 36 bytes starting at *ManufacturerAccessControl()*.

4.1.3 Auto-Increment Reading

To support faster data flash dumps, the 0x4000–0x43FF commands will auto-increment after a successful read. This enables the host to skip the write word step, which increases throughput by at least 2x. After a word read is detected of the *MACDataSum()* and *MACDataLen()* registers, the gauge will add the current block size to the command (32 bytes). There is no auto-increment for the last block of DF.

4.2 Access Modes

The bq34110 device provides three security modes that control data flash access permissions (see [Table 4-1](#)). Public Access refers to data flash locations specified in [Data Flash Summary](#) that are accessible to the user. Private Access refers to reserved data flash locations used by the device system. Following the procedure outlined in [Accessing Data Flash](#), care should be taken to avoid writing to Private data flash locations when performing block writes in FULL ACCESS mode.

Table 4-1. Data Flash Access

| SECURITY MODE | DF—PUBLIC ACCESS | DF—PRIVATE ACCESS |
|---------------|------------------|-------------------|
| BOOTROM | N/A | N/A |
| FULL ACCESS | R/W | R/W |
| UNSEALED | R/W | R/W |
| SEALED | R | N/A |

Although FULL ACCESS and UNSEALED modes appear identical, FULL ACCESS mode allows the device to directly transition to BOOTROM mode and also write access keys. UNSEALED mode does not have these abilities.

4.3 Sealing/Unsealing Data Flash Access

The bq34110 device implements a key-access scheme to transition between SEALED, UNSEALED, and FULL ACCESS modes. Each transition requires that a unique set of two keys are sent to the device via the *Control()* command (these keys are unrelated to the keys used for SHA-1/HMAC authentication). The keys must be sent consecutively, with no other data written to the *Control()* register in between. Do not set the two keys to identical values.

When in the SEALED mode, the *OperationStatus()*[*SEC1*, *SEC0*] bits are set to [1, 1]. When the UNSEAL keys are correctly received by the gas gauge, the bits will be set to [1, 0]. When the FULL ACCESS keys are correctly received, then the bits will change to [0, 1]. The state [0, 0] is not valid, and only indicates that the state has not yet been loaded.

The access keys are changed using the *SECURITY_KEYS()* subcommand. This command enables a read/write of the 4 key words (8 bytes). Each word is in big endian order, with the first two words being the unseal code and the remaining two words being the full access codes.

When writing the codes to *Control()* or *ManufacturerAccessControl()*, they must be sent in little endian order; therefore, if 0x1234 and 0x5678 are written as the unseal codes to *SECURITY_KEYS()*, then to unseal requires writing 0x34 0x12 followed by writing 0x78 0x56. The two codes must be written within 4 s of each other to succeed.

The read/write subcommand *SECURITY_KEYS()* can be sent to *Control()* or *ManufacturerAccessControl()* to read/write the keys.

To read the keys:

- Write 0x35 0x00 to either *Control(0x00, 0x01)* or *ManufacturerAccessControl(0x3E, 0x3F)*.
- Read back 8 bytes at *MACData(0x40–0x47)*.

To write the keys:

- Write 0x35 0x00 to either *Control(0x00, 0x01)* or *ManufacturerAccessControl(0x3E, 0x3F)*.
- Write the data in big endian format to *MACData(0x40–0x47)*.
- Write the checksum to *MACDataSum(0x60)*. The checksum is the complement of the sum of the data and command bytes.
- Write the length of 0x08 to *MACDataLen(0x61)*. The length includes the command, data, checksum, and length bytes.

4.4 SOC Flag Configuration A (SOC Flag Config A) Register

The settings in **SOC Flag Config A** configure how the *[TC]*, *[FC]*, and *[TD]* flags in *GaugingStatus()* set and clear. These flags are also used to set the *[TCA]*, *[TDA]*, and *[FC]* flags in *BatteryStatus()*.

Table 4-2. SOC Configuration Flag A Register Bit Definitions

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|------------------|--------------|------------|----------|--------|--------------|------------|----------|--------|
| High Byte | RSVD | RSVD | RSVD | RSVD | TCSETVCT | FCSETVCT | RSVD | RSVD |
| Default | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| | 0x0C | | | | | | | |
| Low Byte | TCCLEAR RSOC | TCSET RSOC | TCCLEARV | TCSETV | TDCLEAR RSOC | TDSET RSOC | TDCLEARV | TDSETV |
| Default | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| | 0x8C | | | | | | | |

RSVD = Reserved

TCSETVCT= Enables *BatteryStatus()*[TCA] flag set on primary charge termination

0 = Disabled

1 = Enabled (default)

FCSETVCT= Enables *BatteryStatus()*[FC] flag set on primary charge termination

0 = Disabled

1 = Enabled (default)

TCCLEARRSOC = Enables *BatteryStatus()*[TCA] flag clear when *RelativeStateOfCharge()* ≤ **TC:Clear % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

TCSETRSOC = Enables *BatteryStatus()*[TCA] flag set when *RelativeStateOfCharge()* ≥ **TC:Set % RSOC Threshold**

0 = Disabled (default)

1 = Enabled

TCCLEARV = Enables *BatteryStatus()*[TCA] flag clear when *Voltage()* ≤ **TC:Clear Voltage Threshold**

0 = Disabled (default)

1 = Enabled

TCSETV = Enables *BatteryStatus()*[TCA] flag set when *Voltage()* ≥ **TC:Set Voltage Threshold**

0 = Disabled (default)

1 = Enabled

TDCLEARRSOC = Enables *BatteryStatus()*[TDA] flag clear when *RelativeStateOfCharge()* ≥ **TD:Clear % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

TDSETRSOC = Enables *BatteryStatus()*[TDA] flag set when *RelativeStateOfCharge()* ≤ **TD:Set % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

TDCLEARV = Enables *BatteryStatus()*[TDA] flag clear when *Voltage()* ≥ **TD:Clear Voltage Threshold**

0 = Disabled (default)

1 = Enabled

TDSETV = Enables *BatteryStatus()*[TDA] flag set when *Voltage()* ≤ **TD:Set Voltage Threshold**

0 = Disabled (default)

1 = Enabled

4.5 SOC Flag Configuration B (SOC Flag Config B) Register

Table 4-3. SOC Configuration Flag B Register Bit Definitions

| | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|----------------|-----------------|---------------|----------|--------|-----------------|---------------|----------|--------|
| | FCCLEAR RSOC | FCSET RSOC | FCCLEARV | FCSETV | FDCLEAR RSOC | FDSET RSOC | FDCLEARV | FDSETV |
| Default | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| | 0x8C | | | | | | | |

FCCLEARRSOC = Enables *BatteryStatus()*[FC] flag clear when *RelativeStateOfCharge()* ≤ **FC:Clear % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

FCSETRSOC = Enables *BatteryStatus()*[FC] flag set when *RelativeStateOfCharge()* ≥ **FC:Set % RSOC Threshold**

0 = Disabled (default)

1 = Enabled

FCCLEARV = Enables *BatteryStatus()*[FC] flag clear when *Voltage()* ≤ **FC:Clear Voltage Threshold**

0 = Disabled (default)

1 = Enabled

FCSETV = Enables *BatteryStatus()*[FC] flag set when *Voltage()* ≥ **FC:Set Voltage Threshold**

0 = Disabled (default)

1 = Enabled

FDCLEARRSOC = Enables *BatteryStatus()*[FD] flag clear when *RelativeStateOfCharge()* ≥ **FD:Clear % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

FDSETRSOC = Enables *BatteryStatus()*[FD] flag set when *RelativeStateOfCharge()* ≤ **FD:Set % RSOC Threshold**

0 = Disabled

1 = Enabled (default)

FDCLEARV = Enables *BatteryStatus()*[FD] flag clear when *Voltage()* ≥ **FD:Clear Voltage Threshold**

0 = Disabled (default)

1 = Enabled

FDSETV = Enables *BatteryStatus()*[FD] flag set when *Voltage()* ≤ **FD:Set Voltage Threshold**

0 = Disabled (default)

1 = Enabled

4.6 Manufacturer Information Block

The gas gauge contains 32 bytes of user-programmable data flash storage called the **Manufacturer Info Block**. This block is accessible using the *MANU_DATA()* subcommand. The *MANU_DATA()* command is read/write when UNSEALED and read-only when SEALED.

To read the block in any mode, write 70 00 (*MANU_DATA()*) to *ManufacturerAccessControl()* or *Control()*, then read the *MACData()* block.

To write the block, send 70 00 to *ManufacturerAccessControl()*, write the 32 byte data block to *MACData()*, and then write the checksum and length to *MACDataSum()* and *MACDataLen()*. The write will not proceed until the checksum and length are verified.

It is also possible to write the **Manufacturer Info Block** using the data flash interface by writing to the DF address where the block is stored.

NOTE: The **Manufacturer Info Block** is read-only when in SEALED mode.

Table 4-4. Manufacturer Info Block

| Class | Subclass | Address | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|-------------------|---------|-----------------------------|--------|---------------|-----------|-----------|---------------|------|
| System Data | Manufacturer Data | 0x4042 | Manufacturer Info Block A01 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4043 | Manufacturer Info Block A02 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4044 | Manufacturer Info Block A03 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4045 | Manufacturer Info Block A04 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4046 | Manufacturer Info Block A05 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4047 | Manufacturer Info Block A06 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4048 | Manufacturer Info Block A07 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4049 | Manufacturer Info Block A08 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404A | Manufacturer Info Block A09 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404B | Manufacturer Info Block A10 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404C | Manufacturer Info Block A11 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404D | Manufacturer Info Block A12 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404E | Manufacturer Info Block A13 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x404F | Manufacturer Info Block A14 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4050 | Manufacturer Info Block A15 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4051 | Manufacturer Info Block A16 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4052 | Manufacturer Info Block A17 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4053 | Manufacturer Info Block A18 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4054 | Manufacturer Info Block A19 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4055 | Manufacturer Info Block A20 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4056 | Manufacturer Info Block A21 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4057 | Manufacturer Info Block A22 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4058 | Manufacturer Info Block A23 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4059 | Manufacturer Info Block A24 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405A | Manufacturer Info Block A25 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405B | Manufacturer Info Block A26 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405C | Manufacturer Info Block A27 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405D | Manufacturer Info Block A28 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405E | Manufacturer Info Block A29 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x405F | Manufacturer Info Block A30 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |
| System Data | Manufacturer Data | 0x4060 | Manufacturer Info Block A31 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |

Table 4-4. Manufacturer Info Block (continued)

| Class | Subclass | Address | Name | Format | Size in Bytes | Min Value | Max Value | Default Value | Unit |
|-------------|-------------------|---------|-----------------------------|--------|---------------|-----------|-----------|---------------|------|
| System Data | Manufacturer Data | 0x4061 | Manufacturer Info Block A32 | Hex | 1 | 0x00 | 0xFF | 0x00 | — |

4.7 Data Flash Summary

The data types used in this section are described below.

| Type | Min Value | Max Value |
|------|------------------------------|-------------------------------|
| F4 | $\pm 9.8603 \times 10^{-39}$ | $\pm 5.707267 \times 10^{37}$ |
| H1 | 0x00 | 0xFF |
| H2 | 0x00 | 0xFFFF |
| H4 | 0x00 | 0xFFFF FFFF |
| I1 | –128 | 127 |
| I2 | –32768 | 32767 |
| I4 | –2,147,483,648 | 2,147,483,647 |
| Sx | 1-byte string | x-byte string |
| U1 | 0 | 255 |
| U2 | 0 | 65535 |
| U4 | 0 | 4,294,967,295 |

Table 4-5. Data Flash Table

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|-------------|------------|---------|------------------------|------|-------------|--------------|------------|-------|
| Calibration | Data | 0x4000 | CC Gain | F4 | 1.00E–01 | 4.00E+00 | .47095 | — |
| Calibration | Data | 0x4004 | CC Delta | F4 | 2.98262E+04 | 1.193046E+06 | 5.677446e5 | — |
| Calibration | Data | 0x4008 | CC Offset | I2 | –32767 | 32767 | –1432 | mA |
| Calibration | Data | 0x400C | Board Offset | I1 | –128 | 127 | 0 | μA |
| Calibration | Data | 0x400D | Int Temp Offset | I1 | –128 | 127 | 0 | 0.1°C |
| Calibration | Data | 0x400E | Ext Temp Offset | I1 | –128 | 127 | 0 | 0.1°C |
| Calibration | Data | 0x400F | Pack V Offset | I1 | –128 | 127 | 0 | mV |
| Calibration | Data | 0x4010 | Voltage Divider | U2 | 0 | 65535 | 5000 | mV |
| Calibration | Temp Model | 0x41C1 | Int Coeff 1 | I2 | –32768 | 32767 | 0 | Num |
| Calibration | Temp Model | 0x41C3 | Int Coeff 2 | I2 | –32768 | 32767 | 0 | Num |
| Calibration | Temp Model | 0x41C5 | Int Coeff 3 | I2 | –32768 | 32767 | –12324 | Num |
| Calibration | Temp Model | 0x41C7 | Int Coeff 4 | I2 | –32768 | 32767 | 6131 | 0.1°K |
| Calibration | Temp Model | 0x41C9 | Int Min AD | I2 | –32768 | 32767 | 0 | — |
| Calibration | Temp Model | 0x41CB | Int Max Temp | I2 | –32768 | 32767 | 6131 | 0.1°K |
| Calibration | Temp Model | 0x41CD | Ext Coeff 1 | I2 | –32768 | 32767 | 20982 | Num |
| Calibration | Temp Model | 0x41CF | Ext Coeff 2 | I2 | –32768 | 32767 | –13836 | Num |
| Calibration | Temp Model | 0x41D1 | Ext Coeff 3 | I2 | –32768 | 32767 | 5202 | Num |
| Calibration | Temp Model | 0x41D3 | Ext Coeff 4 | I2 | –32768 | 32767 | 2337 | 0.1°K |
| Calibration | Temp Model | 0x41D5 | Ext Min AD | I2 | –32768 | 32767 | 12909 | — |
| Calibration | Temp Model | 0x41D7 | Vcomp Coeff 1 | I2 | –32768 | 32767 | 0 | Num |
| Calibration | Temp Model | 0x41D9 | Vcomp Coeff 2 | I2 | –32768 | 32767 | 14902 | Num |
| Calibration | Temp Model | 0x41DB | Vcomp Coeff 3 | I2 | –32768 | 32767 | –623 | Num |
| Calibration | Temp Model | 0x41DD | Vcomp Coeff 4 | I2 | –32768 | 32767 | 37 | Num |
| Calibration | Temp Model | 0x41DF | Vcomp Input Multiplier | U1 | 0 | 255 | 48 | Num |
| Calibration | Temp Model | 0x41E0 | Vcomp Output Divisor | I2 | –32768 | 32767 | 256 | Num |
| Calibration | Current | 0x41E2 | Filter | U1 | 0 | 255 | 239 | Num |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|-----------------|-------------------------|---------|----------------------------------|------|-----------|-----------|---------|----------|
| Calibration | Current | 0x41E3 | Deadband | U1 | 0 | 255 | 5 | mA |
| Calibration | Current | 0x41E4 | CC Deadband | U1 | 0 | 255 | 34 | 149 nV |
| Charger Control | Charge Inhibit Cfg | 0x4100 | Chg Inhibit Temp Low | I2 | –400 | 1200 | 0 | 0.1°C |
| Charger Control | Charge Inhibit Cfg | 0x4102 | Chg Inhibit Temp High | I2 | –400 | 1200 | 450 | 0.1°C |
| Charger Control | Charge Inhibit Cfg | 0x4104 | Temp Hys | I2 | 0 | 100 | 50 | 0.1°C |
| Charger Control | JEITA Temperature | 0x4106 | T1 Temp | I2 | –400 | 1200 | 0 | 0.1°C |
| Charger Control | JEITA Temperature | 0x4108 | T2 Temp | I2 | –400 | 1200 | 100 | 0.1°C |
| Charger Control | JEITA Temperature | 0x410A | T3 Temp | I2 | –400 | 1200 | 450 | 0.1°C |
| Charger Control | JEITA Temperature | 0x410C | T4 Temp | I2 | –400 | 1200 | 550 | 0.1°C |
| Charger Control | JEITA Temperature | 0x410E | Charge Current T1-T2 | I2 | 0 | 32767 | 300 | mA |
| Charger Control | JEITA Temperature | 0x4110 | Charge Current T2-T3 | I2 | 0 | 32767 | 1100 | mA |
| Charger Control | JEITA Temperature | 0x4112 | Charge Current T3-T4 | I2 | 0 | 32767 | 660 | mA |
| Charger Control | JEITA Temperature | 0x4114 | Charge Voltage T1-T2 | I2 | 0 | 32767 | 4100 | mV |
| Charger Control | JEITA Temperature | 0x4116 | Charge Voltage T2-T3 | I2 | 0 | 32767 | 4200 | mV |
| Charger Control | JEITA Temperature | 0x4118 | Charge Voltage T3-T4 | I2 | 0 | 32767 | 4100 | mA |
| Charger Control | Charge Termination | 0x411A | Maintenance Current | I2 | 0 | 1000 | 0 | mV |
| Charger Control | Charge Termination | 0x411C | Taper Current | I2 | 0 | 1000 | 100 | mA |
| Charger Control | Charge Termination | 0x411E | Minimum Taper Capacity | I2 | 0 | 1000 | 25 | 0.01 mAh |
| Charger Control | Charge Termination | 0x4120 | Taper Voltage | I2 | 0 | 1000 | 100 | mV |
| Charger Control | Charge Termination | 0x4122 | Current Taper Window | U1 | 0 | 60 | 40 | s |
| Charger Control | WHr Charge Termination | 0x4123 | Max Charge Voltage | I2 | 0 | 32767 | 4200 | mV |
| Charger Control | WHr Charge Termination | 0x4125 | WHr CV Step | I2 | 0 | 32767 | 50 | mV |
| Charger Control | WHr Charge Termination | 0x4127 | WHr Termination Capacity | I2 | 0 | 32767 | 1100 | mAh |
| Charger Control | WHr Charge Termination | 0x4129 | FC WHr Clear | I2 | 0 | 32767 | 1000 | mAh |
| Charger Control | NiMH Charge Termination | 0x412B | Delta Temperature | I2 | –400 | 1200 | 30 | 0.1°C |
| Charger Control | NiMH Charge Termination | 0x412D | Delta Temperature Time | U2 | 0 | 255 | 100 | s |
| Charger Control | NiMH Charge Termination | 0x412F | Holdoff Time | U2 | 0 | 255 | 180 | s |
| Charger Control | NiMH Charge Termination | 0x4131 | Holdoff Current | I2 | 0 | 32767 | 240 | mA |
| Charger Control | NiMH Charge Termination | 0x4133 | Holdoff Temperature | I2 | –400 | 1200 | 250 | 0.1°C |
| Charger Control | NiMH Charge Termination | 0x4135 | Cell Negative Delta Voltage | I2 | 0 | 32767 | 17 | mV |
| Charger Control | NiMH Charge Termination | 0x4137 | Cell Negative Delta Time | U1 | 0 | 255 | 16 | s |
| Charger Control | NiMH Charge Termination | 0x4138 | Cell Negative Delta Qual Voltage | I2 | 0 | 32767 | 3600 | mV |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|-----------------|------------------------|---------|---------------------------------|------|-----------|-----------|---------|-------|
| Charger Control | Learned Charge Voltage | 0x40C7 | Last Charge Voltage T1-T2 | I2 | 0 | 32767 | 4100 | mV |
| Charger Control | Learned Charge Voltage | 0x40C9 | Last Charge Voltage T2-T3 | I2 | 0 | 32767 | 4200 | mV |
| Charger Control | Learned Charge Voltage | 0x40CB | Last Charge Voltage T3-T4 | I2 | 0 | 32767 | 4100 | mV |
| Charger Control | Charge Level Control | 0x4197 | Charge Voltage Level A | I2 | 0 | 32767 | 3900 | mV |
| Charger Control | Charge Level Control | 0x4199 | Charge Voltage Level B | I2 | 0 | 32767 | 3950 | mV |
| Charger Control | Charge Level Control | 0x419B | Charge Voltage Level C | I2 | 0 | 32767 | 4000 | mV |
| Charger Control | Charge Level Control | 0x419D | Charge Voltage Level D | I2 | 0 | 32767 | 4050 | mV |
| Charger Control | Charge Level Control | 0x419F | Charge Voltage Level E | I2 | 0 | 32767 | 4100 | mV |
| Charger Control | Charge Level Control | 0x41A1 | Charge Voltage Level F | I2 | 0 | 32767 | 4150 | mV |
| Charger Control | Charge Level Control | 0x41A3 | Charge Voltage Level G | I2 | 0 | 32767 | 4200 | mV |
| Charger Control | Charge Level Control | 0x41A5 | Charge Voltage Level H | I2 | 0 | 32767 | 4250 | mV |
| Settings | Configuration | 0x413D | Pin Control Config | H1 | 0x0 | 0x1F | 0x00 | Hex |
| Settings | Configuration | 0x413E | Alert1_0 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x413F | Alert1_1 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4140 | Alert1_2 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4141 | Alert1_3 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4142 | Alert1_4 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4143 | Alert1_5 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4144 | Alert1_6 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4145 | Alert2_0 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4146 | Alert2_1 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4147 | Alert2_2 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4148 | Alert2_3 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4149 | Alert2_4 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x414A | Alert2_5 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x414B | Alert2_6 Config | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Settings | Configuration | 0x4195 | Direct Charge Pin Control | H1 | 0x0 | 0x0F | 0x00 | Hex |
| Settings | Configuration | 0x4196 | Charge Level Pin Control | H1 | 0x0 | 0x3F | 0x00 | Hex |
| Settings | Configuration | 0x41FD | SOC Flag Config A | H2 | 0x0 | 0x0FFF | 0x0C8C | Hex |
| Settings | Configuration | 0x41FF | SOC Flag Config B | H1 | 0x0 | 0xFF | 0x8C | Hex |
| Settings | Configuration | 0x4218 | EOS Configuration | H1 | 0x0 | 0x0F | 0x01 | Hex |
| Settings | Configuration | 0x424B | CEDV Gauging Configuration | H2 | 0x0 | 0x3FFF | 0x102A | Hex |
| Settings | BLT | 0x414D | Init Discharge Set | I2 | 0 | 32767 | 150 | mAh |
| Settings | BLT | 0x414F | Init Charge Set | I2 | 0 | 32767 | 175 | mAh |
| Settings | Accumulated Charge | 0x416C | Accum Charge Positive Threshold | I2 | 0 | 32767 | 1000 | mAh |
| Settings | Accumulated Charge | 0x416E | Accum Charge Negative Threshold | I2 | 0 | 32767 | 1000 | mAh |
| Settings | Manufacturing | 0x40D7 | Mfg Status Init | H2 | 0x0 | 0xFFFF | 0x0000 | Hex |
| Safety | OTC | 0x4170 | OT Chg | I2 | 0 | 1200 | 550 | 0.1°C |
| Safety | OTC | 0x4172 | OT Chg Time | U1 | 0 | 60 | 2 | s |
| Safety | OTC | 0x4173 | OT Chg Recovery | I2 | 0 | 1200 | 500 | 0.1°C |
| Safety | OTD | 0x4175 | OT Dsg | I2 | 0 | 1200 | 600 | 0.1°C |
| Safety | OTD | 0x4177 | OT Dsg Time | U1 | 0 | 60 | 2 | s |
| Safety | OTD | 0x4178 | OT Dsg Recovery | I2 | 0 | 1200 | 550 | 0.1°C |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|---------------|--------------------|---------|-------------------------------|------|------------|------------|------------|---|
| Safety | UTC | 0x417A | UT Chg | I2 | −400 | 1200 | 0 | 0.1°C |
| Safety | UTC | 0x417C | UT Chg Time | U1 | 0 | 60 | 2 | s |
| Safety | UTC | 0x417D | UT Chg Recovery | I2 | −400 | 1200 | 50 | 0.1°C |
| Safety | UTD | 0x417F | UT Dsg | I2 | −400 | 1200 | 0 | 0.1°C |
| Safety | UTD | 0x4181 | UT Dsg Time | U1 | 0 | 60 | 2 | s |
| Safety | UTD | 0x4182 | UT Dsg Recovery | I2 | −400 | 1200 | 50 | 0.1°C |
| Safety | BATLOW | 0x4184 | Battery Low Set Threshold | I2 | 0 | 5000 | 3150 | mV |
| Safety | BATLOW | 0x4186 | Battery Low Time | U1 | 0 | 60 | 2 | s |
| Safety | BATLOW | 0x4187 | Battery Low Clear Threshold | I2 | 0 | 5000 | 3400 | mV |
| Safety | BATHIGH | 0x4189 | Battery High Set Threshold | I2 | 0 | 5000 | 4300 | mV |
| Safety | BATHIGH | 0x418B | Battery High Time | U1 | 0 | 60 | 2 | s |
| Safety | BATHIGH | 0x418C | Battery High Clear Threshold | I2 | 0 | 5000 | 4200 | mV |
| Safety | SOCLOW | 0x418E | SOC Low Threshold | U1 | 0 | 100 | 10 | % |
| Safety | SOCLOW | 0x418F | SOC Low Recovery | U1 | 0 | 100 | 30 | % |
| Configuration | Registers | 0x413A | Operation Config A | H2 | 0x0000 | 0xFFFF | 0x8204 | Hex |
| Configuration | Registers | 0x4151 | Device Type | H2 | 0x0000 | 0xFFFF | 0x0110 | Hex |
| Configuration | Registers | 0x4155 | Number of Series Cells | U1 | 1 | 100 | 1 | Num |
| Configuration | Power | 0x4157 | Flash Update OK Voltage | I2 | 0 | 5000 | 2800 | mV |
| Configuration | Power | 0x4159 | Sleep Current | I2 | 0 | 100 | 10 | mA |
| Configuration | Power | 0x415B | Bus Low Time | U1 | 0 | 255 | 5 | s |
| Configuration | Power | 0x415C | Offset Cal Inhibit Temp Low | I2 | −400 | 1200 | 50 | 0.1°C |
| Configuration | Power | 0x415E | Offset Cal Inhibit Temp High | I2 | −400 | 1200 | 450 | 0.1°C |
| Configuration | Power | 0x4160 | Sleep Voltage Time | U1 | 0 | 100 | 20 | s |
| Configuration | Power | 0x4161 | Sleep Current Time | U1 | 0 | 255 | 20 | s |
| Configuration | Current Thresholds | 0x4162 | Discharge Detection Threshold | I2 | 0 | 2000 | 60 | mA |
| Configuration | Current Thresholds | 0x4164 | Charge Detection Threshold | I2 | 0 | 2000 | 75 | mA |
| Configuration | Current Thresholds | 0x4166 | Quit Current | I2 | 0 | 1000 | 40 | mA |
| Configuration | Current Thresholds | 0x4168 | Discharge Relax Time | U2 | 0 | 8191 | 60 | s |
| Configuration | Current Thresholds | 0x416A | Charge Relax Time | U1 | 0 | 255 | 60 | s |
| Configuration | Current Thresholds | 0x416B | Quit Relax Time | U1 | 0 | 63 | 1 | s |
| Configuration | Data | 0x406A | Device Name | S9 | x | x | bq34110 | — |
| Configuration | Data | 0x4073 | Data Flash Version | H2 | 0x0000 | 0xFFFF | 0xFFFF | — |
| Configuration | Data | 0x4075 | Serial Number | H2 | 0x0000 | 0xFFFF | 0x0001 | Hex |
| Configuration | Data | 0x4077 | Manufacture Date | U2 | 0 | 65535 | 0 | Day + Mo*32 + (Yr −1980) *512 |
| Configuration | Data | 0x41A7 | Default Temperature | I2 | 2732 | 3732 | 2982 | 0.1°K |
| Configuration | Integrity Data | 0x4062 | DF Static Checksum | H2 | 0x0000 | 0x7FFF | 0x0000 | Hex |
| Configuration | Integrity Data | 0x4064 | All DF Checksum | H2 | 0x0000 | 0x7FFF | 0x0000 | Hex |
| Configuration | Integrity Data | 0x4066 | IF Checksum | H4 | 0x00000000 | 0xFFFFFFFF | 0xFBD3E090 | Hex |
| Configuration | Integrity Data | 0x40D4 | Full Reset Counter | U1 | 0 | 255 | 0 | Num |
| Configuration | Integrity Data | 0x40D5 | Reset Counter WD | U1 | 0 | 255 | 0 | Num |
| System Data | Manufacturer Data | 0x4042 | Manufacturer Info Block A01 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4043 | Manufacturer Info Block A02 | H1 | 0x00 | 0xFF | 0x00 | Hex |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|-------------|---------------------|---------|-----------------------------|------|-----------|-----------|---------|-------|
| System Data | Manufacturer Data | 0x4044 | Manufacturer Info Block A03 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4045 | Manufacturer Info Block A04 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4046 | Manufacturer Info Block A05 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4047 | Manufacturer Info Block A06 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4048 | Manufacturer Info Block A07 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4049 | Manufacturer Info Block A08 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404A | Manufacturer Info Block A09 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404B | Manufacturer Info Block A10 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404C | Manufacturer Info Block A11 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404D | Manufacturer Info Block A12 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404E | Manufacturer Info Block A13 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x404F | Manufacturer Info Block A14 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4050 | Manufacturer Info Block A15 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4051 | Manufacturer Info Block A16 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4052 | Manufacturer Info Block A17 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4053 | Manufacturer Info Block A18 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4054 | Manufacturer Info Block A19 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4055 | Manufacturer Info Block A20 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4056 | Manufacturer Info Block A21 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4057 | Manufacturer Info Block A22 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4058 | Manufacturer Info Block A23 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4059 | Manufacturer Info Block A24 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405A | Manufacturer Info Block A25 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405B | Manufacturer Info Block A26 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405C | Manufacturer Info Block A27 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405D | Manufacturer Info Block A28 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405E | Manufacturer Info Block A29 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x405F | Manufacturer Info Block A30 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4060 | Manufacturer Info Block A31 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| System Data | Manufacturer Data | 0x4061 | Manufacturer Info Block A32 | H1 | 0x00 | 0xFF | 0x00 | Hex |
| Lifetimes | Lifetime Resolution | 0x4190 | Temperature Resolution | U1 | 0 | 255 | 10 | 0.1°C |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|-------------|---------------------|---------|-------------------------|------|-----------|-----------|---------|-------|
| Lifetimes | Lifetime Resolution | 0x4191 | Current Resolution | U1 | 0 | 255 | 100 | mA |
| Lifetimes | Lifetime Resolution | 0x4192 | Voltage Resolution | U1 | 0 | 255 | 1 | 20 mV |
| Lifetimes | Temperature | 0x4080 | Max Temperature | I2 | –400 | 1200 | 300 | 0.1°C |
| Lifetimes | Temperature | 0x4082 | Min Temperature | I2 | –400 | 1200 | 200 | 0.1°C |
| Lifetimes | Current | 0x4084 | Max Charge Current | I2 | 0 | 32767 | 0 | mA |
| Lifetimes | Current | 0x4086 | Max Discharge Current | I2 | –32768 | 32767 | 0 | mA |
| Lifetimes | Voltage | 0x4088 | Max Pack Voltage | I2 | 0 | 32767 | 160 | 20 mV |
| Lifetimes | Voltage | 0x408A | Min Pack Voltage | I2 | 0 | 32767 | 175 | 20 mV |
| Gas Gauging | CEDV Profile | 0x41F5 | Design Capacity mAh | I2 | 0 | 32767 | 2200 | mAh |
| Gas Gauging | CEDV Profile | 0x424D | EMF | U2 | 0 | 65535 | 3743 | — |
| Gas Gauging | CEDV Profile | 0x424F | C0 | U2 | 0 | 65535 | 149 | — |
| Gas Gauging | CEDV Profile | 0x4251 | R0 | U2 | 0 | 65535 | 867 | — |
| Gas Gauging | CEDV Profile | 0x4253 | T0 | U2 | 0 | 65535 | 4030 | — |
| Gas Gauging | CEDV Profile | 0x4255 | R1 | U2 | 0 | 65535 | 316 | — |
| Gas Gauging | CEDV Profile | 0x4257 | TC | U1 | 0 | 255 | 9 | — |
| Gas Gauging | CEDV Profile | 0x4258 | C1 | U1 | 0 | 255 | 0 | — |
| Gas Gauging | CEDV Profile | 0x4259 | Age Factor | U1 | 0 | 255 | 0 | — |
| Gas Gauging | CEDV Profile | 0x425A | Fixed EDV 0 | I2 | 0 | 32767 | 3031 | — |
| Gas Gauging | CEDV Profile | 0x425C | EDV 0 Hold Time | U1 | 1 | 255 | 1 | s |
| Gas Gauging | CEDV Profile | 0x425D | Fixed EDV 1 | I2 | 0 | 32767 | 3385 | — |
| Gas Gauging | CEDV Profile | 0x425F | EDV 1 Hold Time | U1 | 1 | 255 | 1 | s |
| Gas Gauging | CEDV Profile | 0x4260 | Fixed EDV 2 | I2 | 0 | 32767 | 3501 | — |
| Gas Gauging | CEDV Profile | 0x4262 | EDV 2 Hold Time | U1 | 1 | 255 | 1 | s |
| Gas Gauging | CEDV Profile | 0x4263 | Voltage 0% DOD | I2 | –32768 | 32767 | 4173 | mV |
| Gas Gauging | CEDV Profile | 0x4265 | Voltage 10% DOD | I2 | –32768 | 32767 | 4043 | mV |
| Gas Gauging | CEDV Profile | 0x4267 | Voltage 20% DOD | I2 | –32768 | 32767 | 3925 | mV |
| Gas Gauging | CEDV Profile | 0x4269 | Voltage 30% DOD | I2 | –32768 | 32767 | 3821 | mV |
| Gas Gauging | CEDV Profile | 0x426B | Voltage 40% DOD | I2 | –32768 | 32767 | 3725 | mV |
| Gas Gauging | CEDV Profile | 0x426D | Voltage 50% DOD | I2 | –32768 | 32767 | 3656 | mV |
| Gas Gauging | CEDV Profile | 0x426F | Voltage 60% DOD | I2 | –32768 | 32767 | 3619 | mV |
| Gas Gauging | CEDV Profile | 0x4271 | Voltage 70% DOD | I2 | –32768 | 32767 | 3582 | mV |
| Gas Gauging | CEDV Profile | 0x4273 | Voltage 80% DOD | I2 | –32768 | 32767 | 3515 | mV |
| Gas Gauging | CEDV Profile | 0x4275 | Voltage 90% DOD | I2 | –32768 | 32767 | 3439 | mV |
| Gas Gauging | CEDV Profile | 0x4277 | Voltage 100% DOD | I2 | –32768 | 32767 | 2713 | mV |
| Gas Gauging | Design | 0x41F9 | Design Voltage | I2 | 0 | 32767 | 3700 | mV |
| Gas Gauging | Cycle | 0x41FB | Cycle Count Percentage | U1 | 0 | 100 | 90 | % |
| Gas Gauging | FD | 0x4200 | Set Voltage Threshold | I2 | 0 | 5000 | 3000 | mV |
| Gas Gauging | FD | 0x4202 | Clear Voltage Threshold | I2 | 0 | 5000 | 3100 | mV |
| Gas Gauging | FD | 0x4204 | Set % RSOC Threshold | U1 | 0 | 100 | 0 | % |
| Gas Gauging | FD | 0x4205 | Clear % RSOC Threshold | U1 | 0 | 100 | 5 | % |
| Gas Gauging | FC | 0x4206 | Set Voltage Threshold | I2 | 0 | 5000 | 4200 | mV |
| Gas Gauging | FC | 0x4208 | Clear Voltage Threshold | I2 | 0 | 5000 | 4100 | mV |
| Gas Gauging | FC | 0x420A | Set % RSOC Threshold | U1 | 0 | 100 | 100 | % |
| Gas Gauging | FC | 0x420B | Clear % RSOC Threshold | U1 | 0 | 100 | 95 | % |
| Gas Gauging | TD | 0x420C | Set Voltage Threshold | I2 | 0 | 5000 | 3200 | mV |
| Gas Gauging | TD | 0x420E | Clear Voltage Threshold | I2 | 0 | 5000 | 3300 | mV |
| Gas Gauging | TD | 0x4210 | Set % RSOC Threshold | U1 | 0 | 100 | 6 | % |
| Gas Gauging | TD | 0x4211 | Clear % RSOC Threshold | U1 | 0 | 100 | 8 | % |
| Gas Gauging | TC | 0x4212 | Set Voltage Threshold | I2 | 0 | 5000 | 4200 | mV |
| Gas Gauging | TC | 0x4214 | Clear Voltage Threshold | I2 | 0 | 5000 | 4100 | mV |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|----------------|-----------------------|---------|----------------------------------|------|-----------|-----------|---------|----------------------|
| Gas Gauging | TC | 0x4216 | Set % RSOC Threshold | U1 | 0 | 100 | 100 | % |
| Gas Gauging | TC | 0x4217 | Clear % RSOC Threshold | U1 | 0 | 100 | 95 | % |
| Gas Gauging | State Profile | 0x40C0 | Learned Full Charge Capacity | I2 | 0 | 32767 | 2200 | mAh |
| Gas Gauging | State Profile | 0x40C2 | Stored Remaining Capacity | I2 | 0 | 32767 | 0 | mAh |
| Gas Gauging | State Profile | 0x40C5 | Cycle Count | U2 | 0 | 65535 | 0 | — |
| Gas Gauging | CEDV Cfg | 0x427D | Battery Low % | U2 | 0 | 65535 | 700 | .01% |
| Gas Gauging | CEDV Cfg | 0x4288 | Learning Low Temp | U1 | 0 | 255 | 119 | 0.1°C |
| Gas Gauging | CEDV Cfg | 0x4291 | OverLoad Current | I2 | 0 | 32767 | 3400 | mA |
| Gas Gauging | CEDV Cfg | 0x4295 | Self Discharge Rate | U1 | 0 | 255 | 20 | 0.01%/day |
| Gas Gauging | CEDV Cfg | 0x4296 | Electronics Load | I2 | 0 | 255 | 0 | 3 μ A |
| Gas Gauging | CEDV Cfg | 0x4298 | Near Full | I2 | 0 | 32767 | 200 | mAh |
| Gas Gauging | CEDV Cfg | 0x429A | Reserve Capacity | I2 | 0 | 32767 | 0 | mAh |
| Gas Gauging | CEDV Cfg | 0x429C | Chg Eff | U1 | 0 | 100 | 100 | % |
| Gas Gauging | CEDV Cfg | 0x429D | Dsg Eff | U1 | 0 | 100 | 100 | % |
| Gas Gauging | CEDV Cfg | 0x429E | RemCap Init Percent | U1 | 0 | 110 | 100 | % |
| Gas Gauging | CEDV Smoothing Config | 0x429F | Smoothing Config | H1 | 0x00 | 0xFF | 0x08 | Hex |
| Gas Gauging | CEDV Smoothing Config | 0x42A0 | Smoothing Start Voltage | I2 | 0 | 5000 | 3700 | mV |
| Gas Gauging | CEDV Smoothing Config | 0x42A2 | Smoothing Delta Voltage | I2 | 0 | 5000 | 100 | mV |
| Gas Gauging | CEDV Smoothing Config | 0x42A4 | Max Smoothing Current | U2 | 0 | 65535 | 8000 | mA |
| Gas Gauging | CEDV Smoothing Config | 0x42A9 | EOC Smooth Current | U1 | 0 | 10 | 2 | 0.1% |
| Gas Gauging | CEDV Smoothing Config | 0x42AA | EOC Smooth Current Time | U1 | 0 | 255 | 60 | s |
| End Of Service | Resistance Learning | 0x4219 | Auto Learn Time | U2 | 0 | 65535 | 1500 | Hours |
| End Of Service | Resistance Learning | 0x421B | Auto Learn Retry Time | U1 | 0 | 255 | 1 | Hours |
| End Of Service | Resistance Learning | 0x421C | Minimum Learn Time | U2 | 0 | 65535 | 750 | Hours |
| End Of Service | Resistance Learning | 0x421E | Alert-Warn Learn Time | U2 | 0 | 65535 | 750 | Hours |
| End Of Service | Resistance Learning | 0x4220 | Initial Learn Pulse Number | U1 | 0 | 255 | 1 | Counts |
| End Of Service | Resistance Learning | 0x4221 | Learn Charge Voltage Delta | I2 | 0 | 32767 | 100 | mV |
| End Of Service | Resistance Learning | 0x4223 | Learn Charge Time Limit | U2 | 0 | 65535 | 3600 | s |
| End Of Service | Resistance Learning | 0x4225 | Learn Discharge Current | I2 | 0 | 32767 | 220 | mA |
| End Of Service | Resistance Learning | 0x4227 | Learn Discharge Current Boundary | I2 | 0 | 100 | 25 | % |
| End Of Service | Resistance Learning | 0x4229 | Learn Discharge Time | U2 | 0 | 65535 | 500 | s |
| End Of Service | Resistance Learning | 0x422B | Learn Request Timeout | U1 | 0 | 255 | 4 | s |
| End Of Service | Resistance Learning | 0x422C | Learn Min Temperature | I2 | –400 | 1500 | 100 | 0.1°C |
| End Of Service | Resistance Learning | 0x422E | Learn Max Temperature | I2 | –400 | 1500 | 400 | 0.1°C |
| End Of Service | Resistance Learning | 0x4230 | Learn Target Temperature | I2 | –400 | 1500 | 250 | 0.1°C |
| End Of Service | Resistance Learning | 0x4232 | Rcell High Temp Coefficient | I2 | –32768 | 32767 | 0 | 2^{-16} / 0.1°C |

Table 4-5. Data Flash Table (continued)

| Class | Subclass | Address | Name | Type | Min Value | Max Value | Default | Units |
|----------------|----------------------------|---------|----------------------------|------|-----------|-----------|---------|---------------------|
| End Of Service | Resistance Learning | 0x4234 | Rcell Low Temp Coefficient | I2 | –32768 | 32767 | 0 | 2^{-16} /0.1°C |
| End Of Service | Direct Resistance Decision | 0x40CD | Initial Rcell | I2 | 0 | 32767 | 0 | mΩ |
| End Of Service | Direct Resistance Decision | 0x40CF | Initial Rcell Learned | U1 | 0 | 1 | 0 | — |
| End Of Service | Direct Resistance Decision | 0x4239 | DRD Alert Level | U2 | 0 | 65535 | 45 | % |
| End Of Service | Direct Resistance Decision | 0x423B | DRD Alert Counts | U1 | 0 | 255 | 3 | Counts |
| End Of Service | Direct Resistance Decision | 0x423C | DRD Warning Level | U2 | 0 | 65535 | 60 | % |
| End Of Service | Direct Resistance Decision | 0x423E | DRD Warning Counts | U1 | 0 | 255 | 3 | Counts |
| End Of Service | Resistance Slope Decision | 0x40D0 | Initial RRate | I2 | 0 | 32767 | 0 | — |
| End Of Service | Resistance Slope Decision | 0x40D2 | Initial RRate Learned | U1 | 0 | 1 | 0 | — |
| End Of Service | Resistance Slope Decision | 0x423F | RSD Alert Level | U2 | 0 | 65535 | 15 | % |
| End Of Service | Resistance Slope Decision | 0x4241 | RSD Alert Counts | U1 | 0 | 255 | 3 | Counts |
| End Of Service | Resistance Slope Decision | 0x4242 | RSD Warning Level | U2 | 0 | 65535 | 30 | % |
| End Of Service | Resistance Slope Decision | 0x4244 | RSD Warning Counts | U1 | 0 | 255 | 3 | Counts |
| End Of Service | Resistance Slope Decision | 0x4245 | RSDL Alert Level | U2 | 0 | 65535 | 15 | % |
| End Of Service | Resistance Slope Decision | 0x4247 | RSDL Warning Level | U2 | 0 | 65535 | 30 | % |
| End Of Service | Safety Status | 0x40D3 | Warning Status | H1 | 0x0 | 0xFF | 0x0 | Hex |

Factory Calibration

The bq34110 device requires factory calibration. The device performs only a limited number of calibration functions, and the rest of the functions must be performed by a host system using commands provided by the gauge for this purpose. The following sections give a detailed description of the various calibration sequences with the help of flowcharts.

5.1 General I²C Command Information

In the following flowcharts, all I²C functions take three arguments.

Write command arguments:

- Address
- Data
- Wait time in ms

Read command arguments:

- Address
- Number of bytes read
- Wait time in ms

5.2 Calibration Overview

5.2.1 Method

The calibration method is broken up into the following sections. The first four sequences are subroutines to be used in the main calibration sequences.

- [Section 5.3](#), *Enter CALIBRATION Mode*
- [Section 5.4](#), *Exit CALIBRATION Mode*
- [Section 5.5](#), *CC Offset*
- [Section 5.6](#), *Board Offset*
- [Section 5.7](#), *Obtain Raw Calibration Data*
- [Section 5.8](#), *Temperature Calibration*
- [Section 5.9](#), *Voltage Calibration*
- [Section 5.10](#), *Current Calibration*
- [Section 5.11](#), *Floating Point Conversion*

5.2.2 Sequence

Perform the following calibration sequence during battery pack manufacturing process:

1. Perform CC Offset.
2. Perform Board Offset.
3. Perform Temperature Calibration.
4. Perform Voltage Calibration.
5. Perform Current Calibration.
6. Write calibration results to data flash.

5.3 Enter CALIBRATION Mode

The bq34110 device must be enabled (CE pin pulled high), then the following sequence puts the device in CALIBRATION mode. These steps must be performed when the gauge is in UNSEALED mode.




Figure 5-1. Entering Calibration Mode

5.4 Exit CALIBRATION Mode

This sequence takes the gauge out of CALIBRATION mode. These steps must be performed when the gauge is in UNSEALED mode.




Figure 5-2. Exiting Calibration Mode

5.5 CC Offset

Use MAC commands for **CC Offset** calibration. The host system does not need to write information to the data flash (DF). See [CONTROL_STATUS: 0x0000](#) for the description of the *CONTROL_STATUS[CCA]* bit. The host system needs to ensure the fuel gauge is UNSEALED.

NOTE: While the device is calibrating **CC Offset**, the host system must not read the *CONTROL_STATUS* register at a rate greater than once every 0.5 seconds.

The step labeled **Enter CALIBRATION Mode** refers to [Section 5.3, Enter CALIBRATION Mode](#).

The step labeled **Exit CALIBRATION Mode** refers to [Section 5.4, Exit CALIBRATION Mode](#).




Figure 5-3. CC Offset Flow

5.6 Board Offset

Use MAC commands for **Board Offset** calibration. The host system does not need to write information to the DF. The host system needs to ensure the fuel gauge is UNSEALED. See [CONTROL_STATUS: 0x0000](#) for the description of the **CONTROL_STATUS[CCA]** and **[BCA]** bits.

Calculating the **Board Offset** also calculates the **CC Offset**, therefore, it is not necessary to go through the **CC Offset** calibration process if the **Board Offset** calibration process is implemented.

NOTE: While the device is calibrating **CC Offset**, the host system should not read the **CONTROL_STATUS()** register at a rate greater than once every 0.5 seconds.

The step labeled **Enter CALIBRATION Mode** refers to [Section 5.3, Enter CALIBRATION Mode](#).

The step labeled **Exit CALIBRATION Mode** refers to [Section 5.4, Exit CALIBRATION Mode](#).




Figure 5-4. Board Offset Flow

5.7 Obtain Raw Calibration Data

The following flowchart demonstrates how the host system obtains the raw data to calibrate current, voltage, and temperature. The host system uses this flow in conjunction with the current, voltage, and temperature flows described in this chapter. It is recommended that the host system samples the raw data multiple times at a rate of once per second to obtain an average of the raw current, voltage, and temperature. The host system needs to ensure the fuel gauge is UNSEALED.

NOTE: The data provided in *RawCurrent()* at 0x7A/0x7B is indirectly related to the current being measured.

NOTE: The step labeled **Enter CALIBRATION Mode** refers to [Section 5.3, Enter CALIBRATION Mode](#).

The step labeled **Exit CALIBRATION Mode** refers to [Section 5.4, Exit CALIBRATION Mode](#).




Figure 5-5. Calibration Flow

5.8 Temperature Calibration

This feature calibrates the temperature source set by **Operation Config A [TEMPS]**. A known temperature must be applied to the device for temperature calibration. The calculated temperature offset is written to the corresponding location in DF. The temperature offset is represented by an integer that is a single byte in size and can be written to the appropriate location in DF without any intermediate steps. The host system needs to ensure the fuel gauge is UNSEALED.

NOTE: a) The step labeled **Obtain avgRawTemp** refers to [Obtain Raw Calibration Data](#).
b) When using [bqStudio](#), ensure that the selected calibration of Internal or External temperature matches the setting on the **[TEMPS]** selection.




Figure 5-6. Temperature Calibration

5.9 Voltage Calibration

The bq34110 device has the option to use an external voltage divider circuit to scale the voltage down before it is measured at the BAT pin (see [Voltage Measurement and Calibration](#) for more details). The gain of this divider network should be calibrated and stored in the **Voltage Divider** parameter, as shown in the diagram below. The **Voltage Divider** parameter in data flash is represented as an unsigned word with the maximum value 65535, which would represent a divider ratio of 65.536.

Before attempting to write the updated value of **Voltage Divider**, the bq34110 should be placed into CALIBRATION mode, which disables the restriction of writing to DF when measured *Voltage()* < **Flash Update OK Voltage**. Otherwise, the device may prevent the update of the new value of **Voltage Divider**.

NOTE: The step labeled **Obtain avgRawVoltage** refers to [Obtain Raw Calibration Data](#).




Figure 5-7. Voltage Divider Calibration

The bq34110 device is default-configured to use the BAT input for voltage measurement, and the data used for calibration is made available through the calibration commands. In this setup, the calculated voltage offset must be written to the corresponding location in DF. The voltage offset is represented by an integer that is a single byte in size and can be written to the DF parameter **Pack V Offset**. The diagram below shows the steps to calibrate the voltage offset in this case. The host system needs to ensure the fuel gauge is UNSEALED.

NOTE: The step labeled **Obtain avgRawVoltage** refers to [Obtain Raw Calibration Data](#).




Figure 5-8. Pack Voltage Calibration

5.10 Current Calibration

CC Gain and **CC Delta** are two calibration parameters for current calibration. A known load, typically 1000 mA, is applied to the device during this process. Details on converting the **CC Gain** and **CC Delta** to floating point format are in [Floating Point Conversion](#). The host system needs to ensure the fuel gauge is UNSEALED.

NOTE: The step labeled **Obtain avgRawCurrent** refers to [Obtain Raw Calibration Data](#).

The step labeled **Convert ccGain and ccDelta to Gauge's floating point representation and write to DF** refers to [Floating Point Conversion](#).





Figure 5-9. Current Calibration

5.11 Floating Point Conversion

Figure 5-10 details how to convert the floating point **CC Gain** and **CC Delta** values to the format recognized by the gauge.



* LHS is an abbreviation for left-hand side. This refers to truncating the floating point value by removing anything to the right of the decimal point.

Figure 5-10. Floating Point Conversion

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

| Changes from Original (November 2016) to A Revision | Page |
|---|------|
| • Added additional detail on selected bits in Operation Config A | 9 |
| • Added more descriptions regarding voltage divider design and scaling..... | 16 |
| • Changed Sleep Time to Sleep Current Time | 29 |
| • Changed Bit 5 in high byte from RSVD to RESTORE_REMCAP and added a description | 30 |
| • Changed "negative temperature based charging" to "temperature-based charging" | 37 |
| • Added description of functionality when Cell Negative Delta Voltage is set to zero | 39 |
| • Changed "pin" to "bit" in some descriptions | 42 |
| • Changed Bit 1 in BLTChargSet() high byte from RSVD to INITCOMP and added a description | 81 |
| • Added SOC Flag Config A section, describing additional data flash settings | 91 |
| • Added SOC Flag Config B section, describing additional data flash settings | 92 |
| • Added captions to figures in Chapter 5 | 102 |

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ("TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products (<http://www.ti.com/sc/docs/stdterms.htm>), [evaluation modules](#), and [samples](http://www.ti.com/sc/docs/sampterm.htm) (<http://www.ti.com/sc/docs/sampterm.htm>).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2018, Texas Instruments Incorporated