



# Configuration instructions for each version

There are Standard Kit, Superior kit, Ultimate kit. Different kits may contain different accessories.





## Configuration Differences

Version	Main controller	Depth camera	Lidar	Voice interaction module
Standard	 Raspberry Pi 4B  JETSON NANO	With: Astro Pro Plus depth camera	SLAM A1	Without
Superior kit A			SLAM A1	With
Ultimate kit B			YDLIDAR 4ROS	With







## Packing List

 Chassis		USB HUB board	
		OLED board	
		OLED board accessory pack⑥	
	OLED fixed plate		OLED board acrylic board
	USB HUB board accessory pack③		Charger
	Battery pack		PS2 handle+ AAA battery
	Astra Pro depth camera		Depth camera mounting bracket
	⑤ screw pack		XH2.54 cable
	USB3.0 male-male		Micro USB cable (right-bend)
	OLED connection cable		Manual
	Screwdriver		Velcro



## Voice interaction package (optional)

	Voice interaction module (EN)		Type-c data cable
	Voice Screw Pack		Speaker

## Raspberry Pi Accessories(optional)

	Raspberry Pi 5 (optional)		TF card
	Cool cooler Pi 50		Card reader
	Muto Raspberry Pi accessory pack②		RPI 5 power supply expansion board pack

## Jetson NANO 4GB Accessories(optional)

	Jetson NANO 4GB (optional)		U disk
	Muto NANO 4GB accessory pack①		4010 fan
	M.2 antennas		DC power cable

## SLAM A1 Lidar (optional)

	SLAM A1 Lidar		Micro USB data cable (right bend)
	④ screw pack		

## YDLIDAR 4ROS Lidar (Optional)

	4ROS Lidar		Lidar adapter board
	Type-c data cable		④ screw pack