

Timer capture encoder data

Timer capture encoder data

1. Experiment purpose
2. Configuration pin information
3. Analysis of experimental flow chart
4. Explanation of the core code
5. Hardware connection
6. Experimental effect


1. Experiment purpose

Use the timer encoder mode function of STM32 to capture the encoder data.


2. Configuration pin information

1. Import the ioc file from the Motor project, name it Encoder, and then the related driver of serial port 1.


According to the schematic diagram, the two encoders of the four motors are respectively connected to channel 1 and channel 2 of timer 2 3 4 5. The motor M1 corresponds to the timer TIM2, M2 corresponds to TIM4, M3 corresponds to TIM5, and M4 corresponds to TIM3.




2. Taking the timer TIM2 as an example, the setting methods for TIM3, TIM4, and TIM5 are the same. Select Combined Channels mode as Encoder Mode.




3. In the settings, change the Encoder Mode to Encoder Mode TI1 and TI2, set it to quadruple frequency, and other parameters are shown below.



The final chip configuration pins are as shown below:



3. Analysis of experimental flow chart



4. Explanation of the core code

1. Create new bsp_encoder.h and bsp_encoder.c, and add the following to bsp_encoder.h:

```
// 轮子转一整圈，编码器获得的脉冲数:30*11*2*2
// One full turn of the wheel, the number of pulses
#define ENCODER_CIRCLE          (1320)

void Encoder_Init(void);
void Encoder_Update_Count(void);
int Encoder_Get_Count_Now(uint8_t Motor_id);
void Encoder_Get_ALL(int* Encoder_all);
```

2. Create the following content in the bsp_encoder.c file:

Encoder timer initialization.

```
// Initializing timer 初始化定时器
void Encoder_Init(void)
{
    HAL_TIM_Encoder_Start(&htim2, TIM_CHANNEL_1 | TIM_CHANNEL_2);
    HAL_TIM_Encoder_Start(&htim3, TIM_CHANNEL_1 | TIM_CHANNEL_2);
    HAL_TIM_Encoder_Start(&htim4, TIM_CHANNEL_1 | TIM_CHANNEL_2);
    HAL_TIM_Encoder_Start(&htim5, TIM_CHANNEL_1 | TIM_CHANNEL_2);
}
```

3. Read the encoder data.

```
/**
 * @Brief: To read the encoder count, call every 10 milliseconds 读取编码器计数，需每10毫秒调用一次
 * @Note:
 * @Parm: Motor id: 电机的ID号:MOTOR_ID_M1, MOTOR_ID_M2, MOTOR_ID_M3, MOTOR_ID_M4
 * @Retval: Returns encoder count data 返回编码器计数数据
 */
static int16_t Encoder_Read_CNT(uint8_t Motor_id)
{
    int16_t Encoder_TIM = 0;
    switch(Motor_id)
    {
        case MOTOR_ID_M1: Encoder_TIM = (short)TIM2 -> CNT; TIM2 -> CNT = 0; break;
        case MOTOR_ID_M2: Encoder_TIM = (short)TIM4 -> CNT; TIM4 -> CNT = 0; break;
        case MOTOR_ID_M3: Encoder_TIM = (short)TIM5 -> CNT; TIM5 -> CNT = 0; break;
        case MOTOR_ID_M4: Encoder_TIM = (short)TIM3 -> CNT; TIM3 -> CNT = 0; break;
        default: break;
    }
    return Encoder_TIM;
}
```

4. Update the count value of the encoder. It needs to be called every 10 milliseconds.

```

// 更新编码器的计数总值。需每10毫秒调用一次
// Update the count value of the encoder. call every 10 milliseconds
void Encoder_Update_Count(void)
{
    // g_Encoder_M1_Now += Encoder_Read_CNT(MOTOR_ID_M1);
    g_Encoder_M1_Now -= Encoder_Read_CNT(MOTOR_ID_M1);

    g_Encoder_M2_Now += Encoder_Read_CNT(MOTOR_ID_M2);
    // g_Encoder_M2_Now -= Encoder_Read_CNT(MOTOR_ID_M2);

    g_Encoder_M3_Now += Encoder_Read_CNT(MOTOR_ID_M3);
    // g_Encoder_M3_Now -= Encoder_Read_CNT(MOTOR_ID_M3);

    // g_Encoder_M4_Now += Encoder_Read_CNT(MOTOR_ID_M4);
    g_Encoder_M4_Now -= Encoder_Read_CNT(MOTOR_ID_M4);
}

```

5.Return to boot up to now the total count of the encoders counted,Encoder_Get_Count_Now returns one-channel, Encoder_Get_ALL returns four-channel.

```

// 返回开机到现在总共统计的编码器的计数（单路）。
// Returns the total count of encoders from boot up to now (single channel)
int Encoder_Get_Count_Now(uint8_t Motor_id)
{
    if (Motor_id == MOTOR_ID_M1) return g_Encoder_M1_Now;
    if (Motor_id == MOTOR_ID_M2) return g_Encoder_M2_Now;
    if (Motor_id == MOTOR_ID_M3) return g_Encoder_M3_Now;
    if (Motor_id == MOTOR_ID_M4) return g_Encoder_M4_Now;
    return 0;
}

// 获取开机到现在总共的四路编码器计数。
// Get the total four - way encoder count up to now
void Encoder_Get_ALL(int* Encoder_all)
{
    Encoder_all[0] = g_Encoder_M1_Now;
    Encoder_all[1] = g_Encoder_M2_Now;
    Encoder_all[2] = g_Encoder_M3_Now;
    Encoder_all[3] = g_Encoder_M4_Now;
}

```

6.Add the content of encoder initialization in the Bsp_Init() function.

```

// The peripheral device is initialized 外设设备初始化
void Bsp_Init(void)
{
    Beep_On_Time(50);
    Motor_Init();
    Encoder_Init();
}

```

7.The new encoder array is used to save the encoder data, and show_encoder is used to print the encoder count.

```

int encoder[4] = {0};
int show_encoder = 0;

```

8. On the basis of the original control motor, add the function of printing encoder data every 100 milliseconds.

```
// main.c中循环调用此函数，避免多次修改main.c文件。
// This function is called in a loop in main.c to avoid multiple modifications to the main.c file
void Bsp_Loop(void)
{
    // Detect button down events    检测按键按下事件
    if (Key1_State(KEY_MODE_ONE_TIME))
    {
        Beep_On_Time(50);
        static int state = 0;
        state++;
        int speed = 0;
        if (state == 1)
        {
            speed = 2000;
            Motor_Set_Pwm(MOTOR_ID_M1, speed);
            Motor_Set_Pwm(MOTOR_ID_M2, speed);
            Motor_Set_Pwm(MOTOR_ID_M3, speed);
            Motor_Set_Pwm(MOTOR_ID_M4, speed);
        }
        if (state == 2)
        {
            Motor_Stop(0);
        }
        if (state == 3)
        {
            speed = -2000;
            Motor_Set_Pwm(MOTOR_ID_M1, speed);
            Motor_Set_Pwm(MOTOR_ID_M2, speed);
            Motor_Set_Pwm(MOTOR_ID_M3, speed);
            Motor_Set_Pwm(MOTOR_ID_M4, speed);
        }
        if (state == 4)
        {
            state = 0;
            Motor_Stop(1);
        }
    }

    show_encoder++;
    if (show_encoder > 10)
    {
        show_encoder = 0;
        Encoder_Get_ALL(encoder);
        printf("Encoder:%d, %d, %d, %d\n", encoder[0], encoder[1], encoder[2], encoder[3]);
    }

    Encoder_Update_Count();
    Bsp_Led_Show_State_Handle();
    Beep_Timeout_Close_Handle();
    HAL_Delay(10);
}
```

5. Hardware connection

The motor connecting line needs to be connected to the corresponding motor as shown below, otherwise it may cause the problem that the program does not match the phenomenon. Motor 1 corresponds to the motor in the upper left corner of the body, Motor 2 corresponds to the motor in the lower left corner, Motor 3 corresponds to the motor in the upper right corner, and Motor 4 corresponds to the motor in the lower right corner.



Due to the relatively large power of the motor, the expansion board should not be powered by USB 5V directly, and must be powered by DC 12V.

Then connect the micro-USB cable to the expansion board and computer.

6. Experimental effect

Since the motor will turn when started, please stand up the car before the experiment, and the motor wheels are suspended to avoid rampage.

After programming the program, the LED light flashes every 200ms. Open the serial port assistant, you can see the encoder data. Press the first time to go forward, the second time to free stop, the third time to reverse, and the fourth time to brake to stop.

