

## Temperature and humidity broadcaster

### 1. Learning target


In this course, we will learn how to use Micro:bit, voice broadcast module, temperature and humidity sensor and key module realize voice broadcast temperature and humidity.

### 2. Preparation

Connect the module to Micro:bit board by expansion board, as shown below.

**Note: The voice broadcast module used in this course needs to be purchased additionally.**

**Link:**<https://category.yahboom.net/products/world-of-module>



### 3. Programming method

**Mode 1 online programming:** First, we need to connect the micro:bit to the computer by USB cable. The computer will pop up a USB flash drive and click on the URL in the USB flash drive:

<http://microbit.org/> to enter the programming interface. Add the Yahboom package

<https://github.com/YahboomTechnology/SuperBitLibV2> and

<https://github.com/YahboomTechnology/Speech> to program.


**Mode 2 offline programming:** We need to open the offline programming software. After the installation is complete, enter the programming interface, click **【New Project】**, add Yahboom package:


<https://github.com/YahboomTechnology/SuperBitLibV2> and

<https://github.com/YahboomTechnology/Speech>, you can start programming.

#### 4.Looking for blocks


The following is the location of the building blocks required for this programming.





### 5.Combine block

The summary program is shown below.



### 5. Phenomenon

After the program is downloaded successfully. When we press the key module, the voice broadcast module will broadcast the current detected temperature and air humidity percentage.