

# IBM Long Range Signaling and Control

**IBM LoRaWAN Modem**  
**(IMST WiMOD Edition)**

Version 1.2  
8 - May - 2015

## **IBM LoRaWAN Modem Product Information**

LoRaWAN Modem is developed and marketed by the IBM Zurich Research Laboratory (IBM Research GmbH), 8803 Rüschlikon, Switzerland. For additional information please contact: [lrsc@zurich.ibm.com](mailto:lrsc@zurich.ibm.com).

### **© 2015 IBM Corporation**

Copyright International Business Machines Corporation, 2015. All Rights Reserved.

The following are trademarks or registered trademarks of International Business Machines Corporation in the United States, or other countries, or both: IBM, the IBM Logo, Ready for IBM Technology.

Other company, product and service names may be trademarks or service marks of others.

All information contained in this document is subject to change without notice. The information contained in this document does not affect or change IBM product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of IBM or third parties. All information contained in this document was obtained in specific environments, and is presented as an illustration. The results obtained in other operating environments may vary. THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROVIDED ON AN "AS IS" BASIS. In no event will IBM be liable for damages arising directly or indirectly from any use of the information contained in this document.

## Table of Contents

<b>1.</b>	<b>Introduction.....</b>	<b>4</b>
<b>2.</b>	<b>Modem Interface .....</b>	<b>6</b>
2.1	Connection .....	6
2.2	LED Indicators.....	6
2.3	Messages .....	6
<b>3.</b>	<b>Modem State .....</b>	<b>8</b>
3.1	Activation.....	8
3.2	Firmware Personalization.....	9
<b>4.</b>	<b>AT Command Set.....</b>	<b>10</b>
4.1	NOP Command.....	10
4.2	Version Command .....	10
4.3	Reset Command .....	10
4.4	Factory Reset Command .....	11
4.5	Session Parameter Commands .....	11
4.6	Join Parameter Commands .....	12
4.7	Join Command .....	12
4.8	Transmit Command.....	13
4.9	Ping Mode Command .....	13
4.10	Alarm Timer Command .....	14
4.11	Event Mask Commands .....	14
4.12	Events.....	16
<b>5.</b>	<b>Release History.....</b>	<b>18</b>


## 1. Introduction

The IBM LoRaWAN Modem provides access to LoRaWAN networks via high-level commands exchanged over a serial interface. All kinds of devices can be easily enabled to participate in LoRaWAN networks just by connecting the modem via a serial link and sending a few commands. The modem offers full functionality over a simple interface and handles all details of the LoRaWAN protocol internally. It can be personalized and configured with the specific network parameters.

The modem firmware is based on the IBM LoRaWAN C-library (LMiC). This edition is running on the IMST WiMOD module, featuring a STM32 Cortex-M3 MCU and the Semtech SX1272 LoRa™ radio. The firmware is shipped as Intel HEX file and can be run directly on the IMST WiMOD SK-iM880A (Figure 1) and on the IBM LRSC Modem boards (Figure 2).

**Figure 1.** *IMST / WiMOD LoRa™ Radio Starter Kit*

---



*Directly supported by the IBM LoRaWAN Modem firmware (IMST WiMOD Edition).*

---

**Figure 2.** IBM LRSC Modem v1.0



*Directly supported by the IBM LoRaWAN Modem firmware (IMST WiMOD Edition).*

## 2. Modem Interface

### 2.1 Connection

The modem is connected to the end device via a standard serial USART interface with the communication settings 115200bps, 8/N/1, using half-duplex mode. Only four digital lines are needed to connect the modem to the end device:

- 3.3V
- GND
- RX
- TX

### 2.2 LED Indicators

Two LEDs are used to indicate internal modem states:

State	IMST WiMOD SK-iM880A	IBM LRSC Modem
Power:	LED D3 (green)	LED D4 (red)
Session:	LED D2 (yellow)	LED D3 (green)

The power LED is lit at startup of the modem firmware and is kept continuously on. It is switched off and on again for a very short moment whenever an event is generated to indicate activity. The session LED is driven depending on the activation state of the modem.

Activation State	Session LED
Not activated	Off
Activated	On
Joining	Blinking

### 2.3 Messages

The modem processes all radio messages and LoRaWAN protocol states internally and can be driven by the end device over the serial link. It recognizes a set of commands to configure and query parameters and to initiate and report data exchanges with the network.


All commands are answered by the modem with a corresponding response message. The end device must not issue a new command before it has received the response to the previous command.

In addition to the response messages the modem can generate event messages. These event messages can inform the end device about certain state changes inside the modem triggered by the protocol. Given the nature of the LoRaWAN protocol these state changes and corresponding events can occur at any time. I.e. the end device application must be always prepared to accept event messages. This is even the case when a command/response exchange is in progress. If the generation of the event overlaps with the sending of a command, the event message could be received by the end device **before** the expected response message!

The types of event messages to be reported by the modem can be configured via an event mask (see section 4.11). Possible message flows are shown in Figure 3.

Currently the modem supports an ASCII AT command set (see section 4), inspired by the command set of Hayes data modems. A binary command set is planned.

**Figure 3. Modem Message Flow**



*Exchange of command, response, and event messages.*

## 3. Modem State

The modem has a persistent memory to store its internal state. The stored state is continuously updated, so the modem can continue operation after a power cycle without reconfiguration. Most importantly the activation state (session state) is stored and updated. This includes session keys and frame sequence counters.

### 3.1 Activation

To be able to exchange data with the network server the modem needs to be activated. A valid activation state requires session parameters.

#### 3.1.1 Session Parameters

The session parameters consist of:

- Network ID (32 bit)
- Short device address (32 bit)
- Network session key (128 bit)
- Application session key (128 bit)

These parameters can be obtained by three ways:

1. embedded in the modem firmware (personalized activation, see section 3.2.1)
2. configured by a modem command (personalized activation, see section 4.5.1)
3. established via the JOIN command (over-the-air activation, see sections 3.1.2 and 4.7)

Once obtained the session parameters are stored and updated in the persistent storage. Whenever new session parameters are set, the upstream and downstream sequence counters are reset to zero.

#### 3.1.2 Join Parameters

If the modem is to be activated via over-the-activation (JOIN), the following join parameters are required:

- Device EUI (64 bit)
- Application EUI (64 bit)
- Device Key (128 bit)

The join parameters can be obtained by two ways:

1. embedded in the modem firmware (see section 3.2.2)
2. configured by a modem command (see section 4.6.1)

Using the join command (see section 4.7) a new session is established over-the-air and the obtained session parameters are stored and updated in the persistent storage.



## 3.2 Firmware Personalization

In some cases it is desirable to have the modem firmware preconfigured with the specific network parameters, so the modem is operational without any configuration commands. Therefore the parameters can be patched into the HEX file containing the firmware. Special patterns have been embedded in the firmware to identify the locations of the parameter blocks to be patched.

### 3.2.1 Session Parameters

The block of session parameters can be patched into the firmware file where the following 40-byte HEX-pattern is found:

```
426d6633717561434a77564b55525757524565474b746d3070714c4430596872356370506b503673
```

The layout of the patched session parameters is as follows:

Parameter	Size in bytes	Remark
Network ID	4	least-significant-byte-first
Short device address	4	least-significant-byte-first
Network session key	16	
Application session key	16	

### 3.2.2 Join Parameters

The block of join parameters can be patched into the firmware file where the following 32-byte HEX-pattern is found:

```
6730434d7734397252626176364877514e303131356734324f706d76546e3771
```

The layout of the patched join parameters is as follows:

Parameter	Size in bytes	Remark
Device EUI	8	least-significant-byte-first
Application EUI	8	least-significant-byte-first
Device Key	16	

## 4. AT Command Set

Modem commands, responses and events are encoded as ASCII strings terminated by a carriage-return character <CR>. This way the modem can be directly accessed with the terminal application of your choice and the commands can be typed and read in a human-readable form.

All commands are prefixed with the characters “AT”, followed by comma-separated parameters, and terminated by <CR>. The interpretation of the commands is case-insensitive. All commands will be answered by the modem with “OK” and optional parameters and <CR>, or “ERROR<CR>”. As mentioned in section 2.3, intermittent events can be generated by the modem before the response is sent. Event names are prefixed with “EV\_” and are followed by optional comma-separated parameters and a trailing <CR>.

All available commands with their responses and possible events are described in detail in the following sub sections.

### 4.1 NOP Command

An empty command can be used to test the communication between the modem and the end device. It performs no operation.

<b>Command</b>	AT
<b>Response</b>	OK

Example:

```
→ AT
← OK
```

### 4.2 Version Command

This command can be used to query the firmware version of the modem. It will return a fixed-length string containing the major and minor version number and the compile time of the modem firmware.

<b>Command</b>	ATV?
<b>Response</b>	OK, <version string>

Example:

```
→ ATV?
← OK,VERSION 1.2 (May 8 2015 16:32:38)
```

### 4.3 Reset Command

This command resets the internal state engine and reloads session state from persistent memory.

<b>Command</b>	ATZ
<b>Response</b>	OK

Example:

```
→ ATZ
← OK
```

## 4.4 Factory Reset Command

This command resets the persistent memory to factory state. All parameters will be reverted to the values built into the firmware or cleared. Manually configured parameters and progressed session state will be discarded.

<b>Command</b>	AT&F
<b>Response</b>	OK

Example:

```
→ AT&F
← OK
```

## 4.5 Session Parameter Commands

The following two commands allow to set and query the session parameters.

### 4.5.1 Set Session Parameter Command

This command allows to directly set the session parameters. The new session parameters will be written to persistent memory and sequence counters will be reset to zero.

<b>Command</b>	ATS=<network id>,<device address>,<network session key>,<application session key>
<b>Response</b>	OK

Example:

```
→ ATS=00000002,05A49FEC,00112233445566778899AABBCCDDEEFF,00112233445566778899AABBCCDDEEFF
← OK
```

### 4.5.2 Query Session Parameter Command

This command returns the current session parameters. If the modem is not activated, i.e. no session exists, ERROR will be returned. **Note:** The session keys are not returned by the modem!

<b>Command</b>	ATS?
<b>Response</b>	OK, <network id>,<device address>,<up sequence counter>,<down sequence counter>

Example:

```
→ ATS?
← OK, 00000002, 05A49FEC, 00000004, 00000003
```

## 4.6 Join Parameter Commands

The following commands allow to set and query the join parameters which will be used by the JOIN command (section 4.7) for over-the-air activation.

### 4.6.1 Set Join Parameter Command

This command allows to directly set the join parameters.

<b>Command</b>	ATJ=<device EUI>,<application EUI>,<device key>
<b>Response</b>	OK

Example:

```
→ ATJ=FFFFFFFFFFFFFFF00,DEDEAAAA0000001A,AA55555555555555AAAAAAAAAAAA
← OK
```

### 4.6.2 Query Join Parameter Command

This command returns the join parameters. If no join parameters are set, ERROR will be returned.

**Note:** The device key is not returned by the modem!

<b>Command</b>	ATJ?
<b>Response</b>	OK, <device EUI>,<application EUI>

Example:

```
→ ATJ?
← OK, FFFFFFFFFFFFFFFF00,DEDEAAAA0000001A
```

## 4.7 Join Command

This command triggers the over-the-air activation using the configured join parameters to establish a new session. If no join parameters are configured the command will return ERROR.

<b>Command</b>	ATJ
<b>Response</b>	OK
<b>Events</b>	EV_JOINING EV_JOINED

The command immediately triggers the JOINING event and the session LED starts blinking. When the join procedure succeeded a JOINED event is generated and the session LED is turned on. The newly

established session parameters will be stored persistently and the sequence counters will be reset to zero.

Example:

```
→ ATJ
← OK
← EV_JOINING
← EV_JOINED
```

## 4.8 Transmit Command

This command is used to send upstream data to the network server. If the modem is not activated and join parameters are set, the modem will implicitly join and establish a new session. If the modem is not activated and no join parameters are set, ERROR will be returned.

<b>Command</b>	ATT<confirmed>,<port>[,<data>]
<b>Response</b>	OK
<b>Events</b>	EV_TXCOMPLETE,<flags>[,<port>[,<data>]]

The data is addressed to a specific port (01-FF) and can be requested to be confirmed (0 or 1). After the data is sent by the modem it will check for downstream frames sent by the server. These frames could contain protocol information (like ACK or NACK), or application data. In any case an EV\_TXCOMPLETE event will be generated to signal transmission and optional reception (see section 4.12 for description of event messages). **Note:** The data will only be sent at the point in time allowed by the modem's duty cycle.

Example:

```
→ ATT0,FF,1122334455      (send data unconfirmed to port 255)
← OK
← EV_TXCOMPLETE,00        (data sent, nothing received)

→ ATT1,03,112233          (send data confirmed to port 3)
← OK
← EV_TXCOMPLETE,A2        (data sent, ACK received in second window)

→ ATT0,04,112233          (send data unconfirmed to port 4)
← OK
← EV_TXCOMPLETE,02,0A,C0FFEE (data sent, data received in second window on port 10)
```

## 4.9 Ping Mode Command

This command enables ping mode and prepares the modem for slotted reception of unsolicited downstream data (class B network). The modem will immediately start scanning for a beacon, and if found, it will deliver an EV\_BEACON\_FOUND event. This command requires a valid session. If no session exists, ERROR will be returned.

<b>Command</b>	ATP<interval exp>
<b>Response</b>	OK
<b>Events</b>	EV_BEACON_FOUND EV_RXCOMPLETE, <flags>[, <port>[, <data>]]

The ping interval is specified as an exponent (0-7) and is defined as  $2^{\text{interval exp}}$  seconds. Whenever data is received in a ping slot window, an EV\_RXCOMPLETE event is generated. See section 4.12 for a detailed description of event messages. **Note:** The network server is only notified of the ping mode and the interval with the next upstream frame sent by the modem!

Example:

```

→ ATP2                                (set 4sec ping interval and scan for beacon)
← OK
← EV_BEACON_FOUND

→ ATT0,01,AABBCC                      (send data, notify server of ping interval)
← OK
← EV_TXCOMPLETE,00

← EV_RXCOMPLETE,0P,01,112233          (data received in ping window on port 1)
← EV_RXCOMPLETE,0P,01,4455667788     (data received in ping window on port 1)

```

## 4.10 Alarm Timer Command

This command sets an alarm timer to the specified number of seconds (variable-length HEX). When the timer expires an EV\_ALARM event is generated. It can be used by the end device to periodically wake up or schedule actions at a specified time.

<b>Command</b>	ATA<seconds>
<b>Response</b>	OK
<b>Events</b>	EV_ALARM

Example:

```

→ ATA1E                              (request ALARM event in 30 seconds)
← OK
← EV_ALARM

```

## 4.11 Event Mask Commands

The following commands allow to modify and query the event types which will be reported by the modem. Events not enabled in the event mask will be silently dropped and not reported by the modem.

### 4.11.1 Query Event Mask Command

This command returns the current event mask. By default all events are enabled.

<b>Command</b>	ATE?
<b>Response</b>	OK, <event mask>

Event mask can be ALL, or NONE, or a list of event names separated by the “|” character.

Example:

```

→ ATE?
← OK, ALL

→ ATE?
← OK, JOINED | TXCOMPLETE | RXCOMPLETE

```

#### 4.11.2 Set Event Mask Command

This command directly sets the event mask to the specified event types. Event names can be abbreviated and all events matching the prefix will be included. Special masks ALL and NONE are recognized by this command.

<b>Command</b>	ATE=<event mask>
<b>Response</b>	OK

Example:

```

→ ATE=ALL                                     (select all events)
← OK

→ ATE=JOIN | TX | RX                         (select events beginning with JOIN* TX* RX*)
← OK
→ ATE?
← OK, JOINING | JOINED | JOIN_FAILED | TXCOMPLETE | RXCOMPLETE

```

#### 4.11.3 Add Event Mask Command

This command adds events to the current event mask.

<b>Command</b>	ATE+<event mask>
<b>Response</b>	OK

Example:

```

→ ATE+JOIN                                     (add JOINING, JOINED, JOIN_FAILED to the current event mask)
← OK

```

#### 4.11.4 Remove Event Mask Command

This command removes events from the current event mask.

<b>Command</b>	ATE-<event mask>
<b>Response</b>	OK

Example:

```
→ ATE-RX|TX          (remove RXCOMPLETE, TXCOMPLETE from the current event mask)
← OK
```

## 4.12 Events

The following events can be generated by the modem if they are enabled in the event mask.

- **EV\_JOINING**  
The modem has started joining the network.
- **EV\_JOINED**  
The modem has successfully joined the network and is now ready for data exchanges.
- **EV\_JOIN\_FAILED**  
The modem could not join the network (after retrying).
- **EV\_REJOIN\_FAILED**  
The modem did not join a new network but is still connected to the old network.
- **EV\_TXCOMPLETE**  
The data has been sent, and eventually downstream data has been received in return. If confirmation was requested, the acknowledgement has been received.
- **EV\_RXCOMPLETE**  
Downstream data has been received.
- **EV\_SCAN\_TIMEOUT**  
No beacon was received within the beacon interval.
- **EV\_BEACON\_FOUND**  
The first beacon has been received.
- **EV\_BEACON\_TRACKED**  
The next beacon has been received at the expected time.
- **EV\_BEACON\_MISSED**  
No beacon was received at the expected time.
- **EV\_LOST\_TSYNC**  
Beacon was missed repeatedly and time synchronization has been lost.
- **EV\_RESET**  
Session reset due to rollover of sequence counters. If configured, the join parameters will be used to automatically rejoin the network.
- **EV\_LINK\_DEAD**  
No confirmation has been received from the network server for an extended period of time. Transmissions are still possible but their reception is uncertain.

Most events don't have return parameters and will be reported only with the event name. Only the two events EV\_TXCOMPLETE and EV\_RXCOMPLETE do have return parameters:

- EV\_TXCOMPLETE,<recv flags>[,<port>[,<data>]]
- EV\_RXCOMPLETE,<recv flags>[,<port>[,<data>]]

Both event messages are always followed by flags to indicate the reception state. Optionally these events are appended with port information and the received application data.



The reception flags are coded as two ASCII digits <X><Y> with the following meaning:

Digit Value	Description
<X> = 0	No information
<X> = A	Frame acknowledged, ACK
<X> = N	Frame not acknowledged, NACK
<Y> = 0	No frame received
<Y> = 1	Frame received in down window 1
<Y> = 2	Frame received in down window 2
<Y> = P	Frame received in ping slot

## 5. Release History

Version and date	Description
V 1.0 February 2015	Initial version.
V 1.1 March 2015	Minor internal fixes. Document reformatting.
V 1.2 May 2015	Rebuilt using LMiC v1.5.

# IBM Long Range Signaling and Control

**IBM LoRaWAN in C (LMiC)**

## **LMiC Product Information**

LMiC is developed and marketed by the IBM Zurich Research Laboratory (IBM Research GmbH), 8803 Rüschlikon, Switzerland. For additional information please contact: [lrsc@zurich.ibm.com](mailto:lrsc@zurich.ibm.com).

### **© 2014-2016 IBM Corporation**

Copyright International Business Machines Corporation, 2014-2016. All Rights Reserved.

The following are trademarks or registered trademarks of International Business Machines Corporation in the United States, or other countries, or both: IBM, the IBM Logo, Ready for IBM Technology.

Other company, product and service names may be trademarks or service marks of others.

All information contained in this document is subject to change without notice. The information contained in this document does not affect or change IBM product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of IBM or third parties. All information contained in this document was obtained in specific environments, and is presented as an illustration. The results obtained in other operating environments may vary. THE INFORMATION CONTAINED IN THIS DOCUMENT IS PROVIDED ON AN "AS IS" BASIS. In no event will IBM be liable for damages arising directly or indirectly from any use of the information contained in this document.



## Table of Contents


<b>1.</b>	<b>Introduction.....</b>	<b>5</b>
<b>2.</b>	<b>Programming Model and API .....</b>	<b>6</b>
2.1	Programming Model .....	6
2.2	Run-time Functions .....	7
2.3	Application callbacks .....	7
2.4	The LMIC Struct .....	9
2.5	API Functions .....	10
<b>3.</b>	<b>Hardware Abstraction Layer .....</b>	<b>13</b>
3.1	HAL Interface .....	13
3.2	HAL Reference Implementation for STM32/Cortex-M3 .....	14
<b>4.</b>	<b>Examples.....</b>	<b>16</b>
4.1	Example 1: hello.....	17
4.2	Example 2: join.....	17
4.3	Example 3: transmit .....	18
4.4	Example 4: periodic.....	19
4.5	Example 5: interrupt .....	20
4.6	Example 6: beacon .....	20
4.7	Example 7: ping .....	21
4.8	Example 8: modem .....	22
4.9	Debug library.....	22
<b>5.</b>	<b>Release History .....</b>	<b>24</b>

## 1. Introduction

The IBM LoRaWAN C-library (LMiC) is a portable implementation of the LoRa™ MAC specification for the C programming language. It supports both the EU-868 and the US-915 variants of the specification and it can handle class A and class B devices. The library takes care of all logical MAC states and timing constraints and drives the SEMTECH SX1272 radio. This way, applications are free to perform other tasks and the protocol compliance is guaranteed by the library. In order to ensure compliance with the specification and associated regulations, the state engine has been tested and verified using a logic simulation environment. The library has been carefully engineered to precisely satisfy the timing constraints of the MAC protocol and to even consider possible clock drifts in the timing computations. Applications can access and configure all functionality via a simple event-based programming model and do not have to deal with platform-specific details like interrupt handlers. By using a thin hardware abstraction layer (HAL), the library can be easily ported to new hardware platforms. For the STM32/Cortex-M3 platform, a reference implementation of the HAL is supplied and the overall code footprint of all components on this platform is less than 20K.

In addition to the provided LMiC library a real-world application also needs drivers for the sensors or other hardware it desires to control. These application drivers are outside the scope of this document and their code will not be provided by IBM.

**Figure 1.** Application device components



*High-level view of all application device components. On top of the STM32 MCU with the connected SX1272 radio and other sensor hardware runs the LMiC library and the application code.*

## 2. Programming Model and API

The LMiC library can be accessed via a set of API functions, run-time functions, callback functions, and a global LMIC data structure. The interface is defined in a single header file “lmic.h” which all applications should include.

```
#include "lmic.h"
```

To identify the version of the LMiC library two constants are defined in this header file.

```
#define LMIC_VERSION_MAJOR 1  
#define LMIC_VERSION_MINOR 6
```

### 2.1 Programming Model

The LMiC library offers a simple event-based programming model where all protocol events are dispatched to the application’s `onEvent()` callback function (see 2.3.4). In order to free the application of details like timings or interrupts, the library has a built-in run-time environment to take care of timer queues and job management.

#### 2.1.1 Application jobs

In this model all application code is run in so-called jobs which are executed on the main thread by the run-time scheduler function `os_runloop()` (see 2.2.4). These application jobs are coded as normal C functions and can be managed using the run-time functions described in section 2.2. For the job management an additional per job control struct `osjob_t` is required which identifies the job and stores context information. **Jobs must not be long-running** in order to ensure seamless operation! They should only update state and schedule actions, which will trigger new job or event callbacks.

#### 2.1.2 Main event loop

All an application has to do is to initialize the run-time environment using the `os_init()` function and to run the job scheduler function `os_runloop()`, which does not return. In order to bootstrap protocol actions and generate events, an initial job needs to be set up. Therefore, a startup job is scheduled using the `os_setCallback()` function.

```
void main () {  
    osjob_t initjob;  
  
    // initialize run-time env  
    os_init();  
    // setup initial job  
    os_setCallback(&initjob, initfunc);  
    // execute scheduled jobs and events  
    os_runloop();  
    // (not reached)  
}
```

The startup code shown in the `initfunc()` function below initializes the MAC and starts joining the network.



```
// initial job
static void initfunc (osjob_t* j) {
    // reset MAC state
    LMIC_reset();
    // start joining
    LMIC_startJoining();
    // init done - onEvent() callback will be invoked...
}
```

The `initfunc()` function will return immediately, and the `onEvent()` callback function will be invoked by the scheduler later on for the events `EV_JOINING`, `EV_JOINED` or `EV_JOIN_FAILED`.

## 2.2 Run-time Functions

The run-time functions mentioned before are used to control the run-time environment. This includes initialization, scheduling and execution of the run-time jobs.

### 2.2.1 void `os_setCallback` (osjob\_t\* job, osjobcb\_t cb)

Prepare an immediately runnable job. This function can be called at any time, including from interrupt handler contexts (e.g. if a new sensor value has become available).

### 2.2.2 void `os_setTimedCallback` (osjob\_t\* job, ostime\_t time, osjobcb\_t cb)

Schedule a timed job to run at the given timestamp (absolute system time). This function can be called at any time, including from interrupt handler contexts.

### 2.2.3 void `os_clearCallback` (osjob\_t\* job)

Cancel a run-time job. A previously scheduled run-time job is removed from timer and run queues. The job is identified by the address of the job struct. The function has no effect if the specified job is not yet scheduled.

### 2.2.4 void `os_runloop` ()

Execute run-time jobs from the timer and from the run queues. This function is the main action dispatcher. It does not return and must be run on the main thread.

### 2.2.5 ostime\_t `os_getTime` ()

Query absolute system time (in ticks).

## 2.3 Application callbacks

The LMIC library requires the application to implement a few callback functions. These functions will be called by the state engine to query application-specific information and to deliver state events to the application.

### 2.3.1 void **os\_getDevEui** (u1\_t\* buf)

The implementation of this callback function has to provide the device EUI and copy it to the given buffer. The device EUI is 8 bytes in length and is stored in little-endian format, that is, least-significant-byte-first (LSBF).

### 2.3.2 void **os\_getDevKey** (u1\_t\* buf)

The implementation of this callback function has to provide the device-specific cryptographic application key and copy it to the given buffer. The device-specific application key is a 128-bit AES key (16 bytes in length).

### 2.3.3 void **os\_getArtEui** (u1\_t\* buf)

The implementation of this callback function has to provide the application EUI and copy it to the given buffer. The application EUI is 8 bytes in length and is stored in little-endian format, that is, least-significant-byte-first (LSBF).

### 2.3.4 void **onEvent** (ev\_t ev)

The implementation of this callback function may react on certain events and trigger new actions based on the event and the LMIC state. Typically, an implementation processes the events it is interested in and schedules further protocol actions using the LMIC API. The following events will be reported:

- **EV\_JOINING**  
The node has started joining the network.
- **EV\_JOINED**  
The node has successfully joined the network and is now ready for data exchanges.
- **EV\_JOIN\_FAILED**  
The node could not join the network (after retrying).
- **EV\_REJOIN\_FAILED**  
The node did not join a new network but is still connected to the old network.
- **EV\_TXCOMPLETE**  
The data prepared via `LMIC_setTxData()` has been sent, and eventually downstream data has been received in return. If confirmation was requested, the acknowledgement has been received.
- **EV\_RXCOMPLETE**  
Downstream data has been received.
- **EV\_SCAN\_TIMEOUT**  
After a call to `LMIC_enableTracking()` no beacon was received within the beacon interval. Tracking needs to be restarted.
- **EV\_BEACON\_FOUND**  
After a call to `LMIC_enableTracking()` the first beacon has been received within the beacon interval.
- **EV\_BEACON\_TRACKED**  
The next beacon has been received at the expected time.
- **EV\_BEACON\_MISSED**  
No beacon was received at the expected time.

- **EV\_LOST\_TSYNC**  
Beacon was missed repeatedly and time synchronization has been lost. Tracking or pinging needs to be restarted.
- **EV\_RESET**  
Session reset due to rollover of sequence counters. Network will be rejoined automatically to acquire new session.
- **EV\_LINK\_DEAD**  
No confirmation has been received from the network server for an extended period of time. Transmissions are still possible but their reception is uncertain.

Details for specific events can be obtained from the global LMIC structure described in the next section.

## 2.4 The LMIC Struct

Instead of passing numerous parameters back and forth between API and callback functions, information about the protocol state can be accessed via a global LMIC structure as shown below. All fields besides the ones explicitly mentioned below are read-only and should not be modified.

```
struct lmic_t {
    u1_t      frame[MAX_LEN_FRAME];
    u1_t      dataLen;    // 0 no data or zero length data, >0 byte count of data
    u1_t      dataBeg;    // 0 or start of data (dataBeg-1 is port)

    u1_t      txCnt;
    u1_t      txrxFlags; // transaction flags (TX-RX combo)

    u1_t      pendTxPort;
    u1_t      pendTxConf; // confirmed data
    u1_t      pendTxLen;
    u1_t      pendTxData[MAX_LEN_PAYLOAD];

    u1_t      bcnChnl;
    u1_t      bcnRxsyms;
    ostime_t  bcnRxtime;
    bcninfo_t bcninfo;   // Last received beacon info

    ...
    ...
};
```

This document does not describe the full struct in detail since most of the fields of the LMIC struct are used internally only. The most important fields to examine on reception (event EV\_RXCOMPLETE or EV\_TXCOMPLETE) are the txrxFlags for status information and frame[] and dataLen / dataBeg for the received application payload data. For data transmission the most important fields are pendTxData[], pendTxLen, pendTxPort and pendTxConf, which are used as input to the LMIC\_setTxData() API function (see 2.5.11).

For the EV\_RXCOMPLETE and EV\_TXCOMPLETE events, the txrxFlags field should be evaluated and the following flags are defined:

- TXRX\_ACK: confirmed UP frame was acked (mutually exclusive with TXRX\_NACK)
- TXRX\_NACK: confirmed UP frame was not acked (mutually exclusive with TXRX\_ACK)
- TXRX\_PORT: a port field is contained in the received frame

- TXRX\_DNW1: received in first DOWN slot (mutually exclusive with TXRX\_DNW2)
- TXRX\_DNW2: received in second DOWN slot (mutually exclusive with TXRX\_DNW1)
- TXRX\_PING: received in a scheduled RX slot

For the EV\_TXCOMPLETE event the fields have the following values:

Received frame	LMIC.txrxFlags						LMIC.dataLen	LMIC.dataBeg
	ACK	NACK	PORT	DNW1	DNW2	PING		
nothing	0	0	0	0	0	0	0	0
empty frame	x	x	0	x	x	0	0	x
port only	x	x	1	x	x	0	0	x
port+payload	x	x	1	x	x	0	x	x

For the EV\_RXCOMPLETE event the fields have the following values:

Received frame	LMIC.txrxFlags						LMIC.dataLen	LMIC.dataBeg
	ACK	NACK	PORT	DNW1	DNW2	PING		
empty frame	0	0	0	0	0	1	0	x
port only	0	0	1	0	0	1	0	x
port+payload	0	0	1	0	0	1	x	x

## 2.5 API Functions

The LMiC library offers a set of API functions to control the MAC state and to trigger protocol actions.

### 2.5.1 void LMIC\_reset ()

Reset the MAC state. Session and pending data transfers will be discarded.

### 2.5.2 bit\_t LMIC\_startJoining ()

Immediately start joining the network. Will be called implicitly by other API functions if no session has been established yet. The events EV\_JOINING and EV\_JOINED or EV\_JOIN\_FAILED will be generated.

### 2.5.3 void LMIC\_tryRejoin ()

Check if other networks are around which can be joined. The session to the current network is kept if no new network is found. The events EV\_JOINED or EV\_REJOIN\_FAILED will be generated.

### 2.5.4 void LMIC\_setSession (u4\_t netid, devaddr\_t devaddr, u1\_t\* nwkKey, u1\_t\* artKey)

Set static session parameters. Instead of dynamically establishing a session by joining the network, precomputed session parameters can be provided. To resume a session with precomputed parameters, the frame sequence counters (LMIC.seqnoUp and LMIC.seqnoDn) must be restored to their latest values.

### 2.5.5 bit\_t LMIC\_setupBand (u1\_t bandidx, s1\_t txpow, u2\_t txcap)

Create new band with the specified transmit power and duty cycle (1/txcap) properties.

**2.5.6** `bit_t LMIC_setupChannel (u1_t channel, u4_t freq, u2_t drmap, s1_t band)`

Create new channel in the given band using the specified frequency and allowing the data rates defined in the data rate bitmask ( $1 \ll \text{DRx}$ ).

**2.5.7** `void LMIC_disableChannel (u1_t channel)`

Disable specified channel.

**2.5.8** `void LMIC_setAdrMode (bit_t enabled)`

Enable or disable data rate adaptation. Should be turned off if the device is mobile.

**2.5.9** `void LMIC_setLinkCheckMode (bit_t enabled)`

Enable/disable link check validation. Link check mode is enabled by default and is used to periodically verify network connectivity. Must be called only if a session is established.

**2.5.10** `void LMIC_setDrTxpow (dr_t dr, s1_t txpow)`

Set data rate and transmit power. Should only be used if data rate adaptation is disabled.

**2.5.11** `void LMIC_setTxData ()`

Prepare upstream data transmission at the next possible time. It is assumed, that `pendTxData`, `pendTxLen`, `pendTxPort` and `pendTxConf` have already been set. Data of length `LMIC.pendTxLen` from the array `LMIC.pendTxData[]` will be sent to port `LMIC.pendTxPort`. If `LMIC.pendTxConf` is true, confirmation by the server will be requested. The event `EV_TXCOMPLETE` will be generated when the transaction is complete, i.e. after the data has been sent and eventual down data or a requested acknowledgement has been received.

**2.5.12** `int LMIC_setTxData2 (u1_t port, xref2u1_t data, u1_t dlen, u1_t confirmed)`

Prepare upstream data transmission at the next possible time. Convenience function for `LMIC_setTxData()`. If `data` is NULL, the data in `LMIC.pendTxData[]` will be used.

**2.5.13** `void LMIC_clrTxData ()`

Remove data previously prepared for upstream transmission.

**2.5.14** `bit_t LMIC_enableTracking (u1_t tryBcnInfo)`

Enable beacon tracking. A value of 0 for `tryBcnInfo` indicates to start scanning for the beacon immediately. A non-zero value specifies the number of attempts to query the server for the exact beacon arrival time. The query requests will be sent within the next upstream frames (no frame will be generated). If no answer is received scanning will be started. The events `EV_BEACON_FOUND` or `EV_SCAN_TIMEOUT` will be generated for the first beacon, and the events `EV_BEACON_TRACKED`, `EV_BEACON_MISSED` or `EV_LOST_TSYNC` will be generated for subsequent beacons.

**2.5.15** `void LMIC_disableTracking ()`

Disable beacon tracking. The beacon will be no longer tracked and, therefore, also pinging will be disabled.

**2.5.16 void LMIC\_setPingable (u1\_t intvExp)**

Enable pinging and set the downstream listen interval. Pinging will be enabled with the next upstream frame (no frame will be generated). The listen interval is  $2^{\text{intvExp}}$  seconds, valid values for `intvExp` are 0-7. This API function requires a valid session established with the network server either via `LMIC_startJoining()` or `LMIC_setSession()` functions (see sections 2.5.2 and 2.5.4). If beacon tracking is not yet enabled, scanning will be started immediately. In order to avoid scanning, the beacon can be located more efficiently by a preceding call to `LMIC_enableTracking()` with a non-zero parameter. Additionally to the events mentioned for `LMIC_enableTracking()`, the event `EV_RXCOMPLETE` will be generated whenever downstream data has been received in a ping slot.

**2.5.17 void LMIC\_stopPingable ()**

Stop listening for downstream data. Periodical reception is disabled, but beacons will still be tracked. In order to stop tracking, the beacon a call to `LMIC_disableTracking()` is required.

**2.5.18 void LMIC\_sendAlive ()**

Send one empty upstream MAC frame as soon as possible. Might be used to signal liveness or to transport pending MAC options, and to open a receive window.

**2.5.19 void LMIC\_shutdown ()**

Stop all MAC activity. Subsequently, the MAC needs to be reset via a call to `LMIC_reset()` and new protocol actions need to be initiated.

## 3. Hardware Abstraction Layer

The LMiC library is separated into a large portion of portable code and a small platform-specific part. By implementing the functions of this hardware abstraction layer with the specified semantics, the library can be easily ported to new hardware platforms.

### 3.1 HAL Interface

The following groups of hardware components must be supported:

- Four digital I/O lines are needed in output mode to drive the radio's antenna switch (RX and TX), the SPI chip select (NSS), and the reset line (RST).
- Three digital I/O lines are needed in input mode to sense the radio's transmitter and receiver states (DIO0, DIO1 and DIO2).
- A SPI unit is needed to read and write the radio's registers.
- A timer unit is needed to precisely record events and to schedule new protocol actions.
- An interrupt controller is needed to forward interrupts generated by the digital input lines.

This section describes the function interface required to access these hardware components:

#### 3.1.1 `void hal_init ()`

Initialize the hardware abstraction layer. Configure all components (IO, SPI, TIMER, IRQ) for further use with the `hal_xxx()` functions.

#### 3.1.2 `void hal_failed ()`

Perform "fatal failure" action. This function will be called by code assertions on fatal conditions. Possible actions could be HALT or reboot.

#### 3.1.3 `void hal_pin_rxtx (u1_t val)`

Drive the digital output pins RX and TX (0=receive, 1=transmit).

#### 3.1.4 `void hal_pin_nss (u1_t val)`

Drive the digital output pin NSS (0=low/selected, 1=high/deselected).

#### 3.1.5 `void hal_pin_rst (u1_t val)`

Control the radio RST pin (0=low, 1=high, 2=floating)

#### 3.1.6 `void radio_irq_handler (u1_t dio)`

The three input lines DIO0, DIO1 and DIO2 must be configured to trigger an interrupt on the rising edge and the corresponding interrupt handlers must invoke the function `radio_irq_handler()` and pass the line which generated the interrupt as argument (0, 1, 2).

### 3.1.7 `u1_t hal_spi (u1_t outval)`

Perform 8-bit SPI transaction. Write given byte *outval* to radio, read byte from radio and return value.

### 3.1.8 `u4_t hal_ticks ()`

Return 32-bit system time in ticks.

### 3.1.9 `void hal_waitUntil (u4_t time)`

Busy-wait until specified timestamp (in ticks) is reached.

### 3.1.10 `u1_t hal_checkTimer (u4_t targettime)`

Check and rewind timer for given *targettime*. Return 1 if *targettime* is close (not worthwhile programming the timer). Otherwise rewind timer for exact *targettime* or for full timer period and return 0. The only action required when *targettime* is reached is that the CPU wakes up from possible sleep states.

### 3.1.11 `void hal_disableIRQs ()`

Disable all CPU interrupts. Might be invoked nested. But will always be followed by matching call to `hal_enableIRQs()`.

### 3.1.12 `void hal_enableIRQs ()`

Enable CPU interrupts. When invoked nested, only the outmost invocation actually must enable the interrupts.

### 3.1.13 `void hal_sleep ()`

Sleep until interrupt occurs. Preferably system components can be put in low-power mode before sleep, and be re-initialized after sleep.

## 3.2 HAL Reference Implementation for STM32/Cortex-M3

The source code of the LMiC library includes a reference implementation of the HAL for the STM32/Cortex-M3 platform. This implementation demonstrates the required semantics of the HAL function interface. For brevity's sake it is kept as simple as possible and it is not optimized (e.g. for power consumption). We will describe here the hardware resources used by this implementation. Applications using the library must be aware of the use of these resources and must not interfere with them! Either applications have to use different resources available on the platform, or they have to modify the HAL implementation and multiplex access to the required resources!

### 3.2.1 Output I/O Lines

The following generic output lines are used to control the radio.



Function	GPIO
NSS	PB 0
TX	PA 4
RX	PC 13
RST	PA 2

### 3.2.2 Input I/O Lines

The following generic input lines are used to track the transmitter and receiver state. These lines are programmed to generate interrupts on the rising edge (see section 3.1.6 and 3.2.5).

Function	GPIO
DIO 0	PB 1
DIO 1	PB 10
DIO 2	PB 11

### 3.2.3 SPI

The SPI1 peripheral is connected to the radio as shown in the table below.

Function	GPIO
SCK	PA 5
MISO	PA 6
MOSI	PA 7

### 3.2.4 Timer

The TIMER 9 peripheral is used to provide 32kHz clock ticks and to generate comparator interrupts for scheduled protocol actions.

### 3.2.5 Interrupts

One EXTI interrupt handler is used to handle all external I/O line interrupt groups (0, 1, 2, 3, 4, 5-9, 10-15). The EXTI handler checks the source of the interrupt and eventually invokes the `radio_irq_handler()`.

The handler for TIMER 9 interrupts updates the system clock ticks on roll-over of the counter. No specific action has to be performed by the handler when the interrupt is triggered by the comparator. It is sufficient that the CPU wakes from sleep and the run-time environment of LMiC can check for pending actions.

## 4. Examples


A set of examples is provided to demonstrate how typical node applications can be implemented with only a few lines of code using the LMiC library. The shipped examples are ready to run on the demo board of the *IMST / WiMOD LoRa™ Radio Starter Kit*.

The examples can be built using different compiler toolchains and makefiles are provided for *IAR*, *Keil* and *GCC*. Additionally project files for the integrated development environments *IAR Workbench* and *Keil µVision* are provided in the `examples` directory of the ZIP file.

**Note:** all projects should have the following preprocessor defines set in the project options:  
`CFG_eu868`, `CFG_wimod_board`, `CFG_sx1272_radio`

In addition to driving the radio using the LMiC APIs, the examples are written to give local feedback via a LED and a serial console using the debug library described in section 4.8. The demo board will make the serial console available as “USB Serial Port” on the connected PC and the output of the debug functions can be easily viewed with the terminal application of your choice. Communication parameters are 115200bps 8/N/1.

**Figure 2.** *IMST / WiMOD LoRa™ Radio Starter Kit*



*The examples have been tested on IMST WiMOD SK-iM880A.*

For brevity's sake only the relevant portions of the code are included in the snippets shown for each example in this section. In most cases, this is the application's `onEvent()` callback function plus some utility glue contained in the example's `main.c` file.

## 4.1 Example 1: hello

The first example (*hello*) can be used to verify that your development environment is up and running and all components are well connected. The example doesn't use the radio, it only uses the run-time functions and the debug library to periodically log a counter value to the serial console and to blink the LED.

```
// counter
static int cnt = 0;

// log text to USART and toggle LED
static void initfunc (osjob_t* job) {
    // say hello
    debug_str("Hello World!\r\n");
    // log counter
    debug_val("cnt = ", cnt);
    // toggle LED
    debug_led(++cnt & 1);
    // reschedule job every second
    os_setTimedCallback(job, os_getTime()+sec2osticks(1), initfunc);
}
```

If everything is set up correctly and the program is executed you should see the LED blink in a one second interval and see the following output on the terminal:

```
===== DEBUG STARTED =====
Hello World!
cnt = 00000000
Hello World!
cnt = 00000001
Hello World!
cnt = 00000002
.....
```

## 4.2 Example 2: join

The next example (*join*) can be used to verify that the radio is working and that the node settings are correct and match your network infrastructure. For the example to work, the application callbacks `os_getArtEui()`, `os_getDevEui()` and `os_getDevKey()` have to return correct values for the application router id, the device id, and the device key!

```
static osjob_t blinkjob;
static u1_t ledstate = 0;

static void blinkfunc (osjob_t* j) {
    // toggle LED
    ledstate = !ledstate;
    debug_led(ledstate);
    // reschedule blink job
    os_setTimedCallback(j, os_getTime()+ms2osticks(100), blinkfunc);
}

void onEvent (ev_t ev) {
```

```

debug_event(ev);

switch(ev) {

    // starting to join network
    case EV_JOINING:
        // start blinking
        blinkfunc(&blinkjob);
        break;

    // network joined, session established
    case EV_JOINED:
        // cancel blink job
        os_clearCallback(&blinkjob);
        // switch on LED
        debug_led(1);
        // (don't schedule any new actions)
        break;
}
}

```

On execution the LED should start blinking fast, and after about five seconds (if the network can be successfully joined), it should become ON permanently. The output on the terminal should be JOINING at the beginning, and after about five seconds JOINED.

```

===== DEBUG STARTED =====
JOINING
JOINED

```

### 4.3 Example 3: transmit

After joining the network, the *transmit* example will start sending upstream frames containing one byte with the last known signal-to-noise ratio. Once a transmission is complete, a new transmission will be scheduled immediately, and hence the frames will be sent with the maximum rate permitted by the duty cycle. If downstream data has been received in the receive slot after the transmission, it will be logged to the console.

```

void onEvent (ev_t ev) {
    debug_event(ev);

    switch(ev) {

        // network joined, session established
        case EV_JOINED:
            debug_val("netid = ", LMIC.netid);
            goto tx;

        // scheduled data sent (optionally data received)
        case EV_TXCOMPLETE:
            if(LMIC.dataLen) { // data received in rx slot after tx
                debug_buf(LMIC.frame+LMIC.dataBeg, LMIC.dataLen);
            }
            tx:
            // immediately prepare next transmission
            LMIC.frame[0] = LMIC.snr;

```

```

        // schedule transmission (port 1, datalen 1, no ack requested)
        LMIC_setTxData2(1, LMIC.frame, 1, 0);
        // (will be sent as soon as duty cycle permits)
        break;
    }
}

```

The upstream frames should be delivered to the application router and the following output should be seen on the node's console:

```

===== DEBUG STARTED =====
JOINING
JOINED
netid = 00000001
TXCOMPLETE
TXCOMPLETE
TXCOMPLETE

```

#### 4.4 Example 4: periodic

The next example (*periodic*) will periodically report a sensor value to the network. After joining, a job is run which reads the sensor, prepares an upstream transmission with the sensor's value, and reschedules the job for repeated execution in 60 seconds. To implement the sensor, this example uses platform-specific functions `initsensor()` and `readsensor()` contained in the file `sensor.c`. The sample sensor simply reads the position of the “DIP switch 1” on the demo board (PB 12) as 1-bit value.

```

static osjob_t reportjob;

// report sensor value every minute
static void reportfunc (osjob_t* j) {
    // read sensor
    u2_t val = readsensor();
    debug_val("val = ", val);
    // prepare and schedule data for transmission
    LMIC.frame[0] = val << 8;
    LMIC.frame[1] = val;
    LMIC_setTxData2(1, LMIC.frame, 2, 0); // (port 1, 2 bytes, unconfirmed)
    // reschedule job in 60 seconds
    os_setTimedCallback(j, os_getTime()+sec2osticks(60), reportfunc);
}

void onEvent (ev_t ev) {
    debug_event(ev);

    switch(ev) {

        // network joined, session established
        case EV_JOINED:
            // switch on LED
            debug_led(1);
            // kick-off periodic sensor job
            reportfunc(&reportjob);
            break;
    }
}

```

```
}  
}
```

Depending on the position of DIP switch 1, this example should generate output similar to this:

```
===== DEBUG STARTED =====  
JOINING  
JOINED  
val = 00000001  
TXCOMPLETE  
val = 00000001  
TXCOMPLETE  
val = 00000000  
TXCOMPLETE
```

## 4.5 Example 5: interrupt

This example (*interrupt*) uses the same sensor as in the previous example but it doesn't read the sensor periodically. Instead, it is interrupt-driven and only sends the sensor value when the sensor has changed. An application-defined interrupt handler has been added in the `sensor.c` file to run a registered job callback when the interrupt is triggered:

```
// called by EXTI_IRQHandler  
// (set preprocessor option CFG_EXTI_IRQ_HANDLER=sensorirq)  
void sensorirq () {  
    if((EXTI->PR & (1<<INP_PIN)) != 0) { // pending  
        EXTI->PR = (1<<INP_PIN); // clear irq  
        // run application callback function in 50ms (debounce)  
        os_setTimedCallback(&irqjob, os_getTime()+ms2osticks(50), irqjob.func);  
    }  
}
```

## 4.6 Example 6: beacon

The following example (*beacon*) enables beacon tracking after joining the network. It drives the LED depending on the TRACKED/MISSED events in each period. If the beacon is successfully tracked, the GPS time contained in the beacon is logged to the console.

```
void onEvent (ev_t ev) {  
    debug_event(ev);  
  
    switch(ev) {  
  
        // network joined, session established  
        case EV_JOINED:  
            // enable tracking mode, start scanning...  
            LMIC_enableTracking(0);  
            debug_str("SCANNING...\r\n");  
            break;  
  
        // beacon found by scanning  
        case EV_BEACON_FOUND:
```

```

        // switch LEN on
        debug_led(1);
        break;

    // beacon tracked at expected time
    case EV_BEACON_TRACKED:
        debug_val("GPS time = ", LMIC.bcninfo.time);
        // switch LEN on
        debug_led(1);
        break;

    // beacon missed at expected time
    case EV_BEACON_MISSED:
        // switch LEN off
        debug_led(0);
        break;
    }
}

```

Depending on the reception quality the console output should look similar to this:

```

===== DEBUG STARTED =====
JOINING
JOINED
SCANNING...
BEACON_FOUND
BEACON_TRACKED
GPS time = 545CE201
BEACON_TRACKED
GPS time = 545CE281
BEACON_TRACKED
GPS time = 545CE301

```

## 4.7 Example 7: ping

The next example (*ping*) joins the network and repeatedly listens for downstream data. This is achieved by enabling the beacon-based ping mode with an interval of two seconds. The call to `LMIC_setPingable()` sets the ping mode locally and starts scanning for the beacon. Once the first beacon has been found, an upstream frame needs to be sent (in this case an empty frame via `LMIC_sendAlive()`) to transport the MAC options and to notify the server of the ping mode and interval. Whenever the server has sent downstream data in one of the receive slots, the `EV_RXCOMPLETE` event is triggered and the received data can be evaluated in the `frame` field of the `LMIC` struct. The sample code logs the received data to the console and, in the special case when exactly one byte is received, it drives the LED depending on the received value.

```

void onEvent (ev_t ev) {
    debug_event(ev);

    switch(ev) {

        // network joined, session established
        case EV_JOINED:
            // enable ping mode, start scanning...
            // (set local ping interval configuration to 2^1 == 2 sec)

```

```

        LMIC_setPingable(1);
        debug_str("SCANNING...\r\n");
        break;

    // beacon found by scanning
    case EV_BEACON_FOUND:
        // send empty frame up to notify server of ping mode and interval!
        LMIC_sendAlive();
        break;

    // data frame received in ping slot
    case EV_RXCOMPLETE:
        // log frame data
        debug_buf(LMIC.frame+LMIC.dataBeg, LMIC.dataLen);
        if(LMIC.dataLen == 1) {
            // set LED state if exactly one byte is received
            debug_led(LMIC.frame[LMIC.dataBeg] & 0x01);
        }
        break;
    }
}

```

## 4.8 Example 8: modem

The next example (*modem*) is a full modem application and provides easy access to LoRaWAN networks via high-level ASCII commands exchanged over a serial interface. For complexity reasons the documentation of the modem has been moved to a separate file `LMiC-Modem.pdf`.

## 4.9 Debug library

A small debug library is provided to enable local text output for the examples shown in this chapter. This library is not required by LMiC but is useful for development and debugging. The library functions offer simple serial console logging and access to a LED for diagnostic output. The debug library is platform-specific and is implemented for STM32/Cortex-M3.

### 4.9.1 void debug\_init ()

Initialize the peripherals required for the debug functions. USART1 and LED4 are used in the reference implementation for STM32/Cortex-M3. Serial communication settings are 115200 8/N/1.

Function	GPIO
USART 1 TX	PA 9
LED 4	PA 8

### 4.9.2 void debug\_led (u1\_t val)

Drive LED (0=off, 1=on).

### 4.9.3 void debug\_char (u1\_t c)

Log single character to serial console.



**4.9.4** `void debug_hex (u1_t b)`

Log byte value as two hexadecimal characters to serial console.

**4.9.5** `void debug_buf (const u1_t* buf, u2_t len)`

Log multiple bytes as space-separated hex characters to serial console.

**4.9.6** `void debug_uint (u4_t v)`

Log 32-bit unsigned int value as eight hexadecimal digits to serial console.

**4.9.7** `void debug_str (const u1_t* str)`

Log arbitrary nul-terminated string to serial console.

**4.9.8** `void debug_event (int ev)`

Log name of event followed by “\r\n” to serial console.

**4.9.9** `void debug_val (const u1_t* label, u4_t val)`

Log label string plus hexadecimal integer value followed by “\r\n” to serial console.

## 5. Release History

Version and date	Description
V 1.0 November 2014	Initial version.
V 1.1 January 2015	Added API <code>LMiC_setSession()</code> . Minor internal fixes.
V 1.2 February 2015	Added APIs <code>LMiC_setupBand()</code> , <code>LMiC_setupChannel()</code> , <code>LMiC_disableChannel()</code> , <code>LMiC_setLinkCheckMode()</code> . Minor internal fixes.
V 1.4 March 2015	Changed API: port indicator flag in <code>LMiC.txrxFlags</code> has been inverted (now <code>TXRX_PORT</code> , previously <code>TXRX_NOPORT</code> ). Internal bug fixes. Document formatting.
V 1.5 May 2015	Bug fixes and documentation update.
V 1.6 Jul 2016	Changed license to BSD. Included modem application (see <code>examples/modem</code> and <code>LMiC-Modem.pdf</code> ). Added STM32 hardware drivers and Blipper board-specific peripheral code.