

# PrusaSlicer slicing guide for ZONESTAR 3D Printer

---





## Contents

1. [Download PrusaSlicer](#)
2. [Run PrusaSlicer and choose the printer](#)
3. [Choose system presets](#)
4. [Slicing one color](#)
5. [Slicing multi-color for E4 hotend](#)
6. [Slicing multi-color for M4 hotend](#)
7. [Gradient and random mixed color printing](#)

## 1. Download PrusaSlicer

### For windows system (win 7/8/10/11)

-  [Download and install slicing software](#)
-  [Download PrusaSlicer 2.4.2 with ZONESTAR 3D Printer Profiles](#)


Download it and unzip it to your PC or laptop, and then find and run the "PrusaSlicer.exe".






### For MacOS or linux

- [Download PrusaSlicer software](#)
- [Download profiles](#)
- Copy Profiles to "resource/profiles" directory of the installation directory of the PrusaSlicer software.


## 2. Run PrusaSlicer and choose the printer

### 2.1 Find the PrusaSlicer.exe and click it to run



 msvcp140.dll	2
 prusa-gcodeviewer.exe	2
 PrusaSlicer.dll	2
 prusa-slicer.exe	2
 prusa-slicer-console.exe	2

### 2.2 Choose your printer, "Other Vendors>>Zonestar FFF>>your printer model>>finish"




### 3. Choose system presets

Choose system presets according to your printer, hotend and the colors you want to print.

⚠ Note: Default Z9V5Pro-MK4 equipped with a E4 hotend.

- If you print one color, choose "Z9 + One Color"
- If your printer has a E4 (4-IN-1-OUT Non-mixing color) hotend and print multi-color, choose "Z9 + E4 HOTEND"
- If your printer has a M4 (4-IN-1-OUT mixing color) hotend and print multi-color, choose "Z9 + M4 HOTEND"


- If your printer has a Direct Drive Extruder, choose "Z9 + DDE"




## 4. Slicing one color

-  [Slicing guide - for one color printing](#)


### 4.1 choose printer presets "Z9 + One Color"




## 4.2 load 3d model file (stl/obj/AMF file etc.)




## 4.3 Choose print filament type



## 4.4 If need, you can resize, cut, rotate the 3d model




## 4.5 Set the print settings: layer height, print speed, support, infill, etc.




You may need to set these parameters according to the shape of the model and your requirements for print quality. For some models, the object even cannot be printed successfully if the settings is incorrect. For details please refer to:

- [PrusaSlicer introduction](#)

## 4.6 Slicing



**4.7 Preview the sliced result (gcode file) and then save to gcode file to your PC and then copy to SD card**



⚠ **NOTE:** While you print one color by E4 (4-IN-1-OUT Non-Mixing) Hotend, only load one filament to which used extrusion feeder and feed it into any one channel of hotend.

⚠ **NOTE:** While you print one color by M4 (4-IN-1-OUT Mixing) Hotend, you can:

- **(RECOMMENDED)** Load filament to that extrusion feeders used, feed it into the center channel of the hotend. And close unused channels of the hotend by "hotend clean tools".
- Or load all filaments to extrusion feeders and feed all filaments into all channels of the hotend.


## 5. Slicing multi-color for E4 hotend

- 🎥 [Slicing guide - for multi colors printing](#)

### 5.1 choose printer presets "Z9 + E4 hotend"



### 5.2 load 3d model files (stl/obj/AMF file etc.)




Usually, "split model" is needed to print multi-color, that is, a 3d model has been split into multiple STL files according to colors, and these files use the same origin coordinate position so that they can be merged correctly.


PrusaSlicer has a very powerful new feature. It can painting any 3d model into multi colors. For details, please refer to

**Slicing guide - Convert one color 3d file to multi colors**


### 5.3 Choose print filament type - PLA and set filament color



5.4 Assign extruders to different parts




5.5 If need, you can resize, cut, rotate the 3d model



5.6 Set the print settings: layer height, print speed, support, infill, etc.






You need to set these parameters according to the shape of the model and your requirements for print quality. Even for some models, printing cannot be completed normally without support. For details please refer to:

- [PrusaSlicer introduction](#)
- [Slic3r User Manual](#)


5.7 Set parameters for "wipe tower"

You may notice that a square square will appear in the sliced figure, which is called "Wipe tower" in PrusaSlicer. Because for the multi-color printer, while switching extruders, there are still the previous color filaments inside the hotend, it need to be clean before printing another color.



In order to obtain better cleaning effect and minimize to waste filament, we can set the amount of purge volume according to different colors. Please pay attention to the following table, the columns shows the filament color of the last extruder printed, and the rows shows the filament color of the next extruder to be printed. When we change from the extruder with lighter color filament to the extruder with darker color filament, we can set a smaller purge volume. On the contrary, when we change from the darker color filament


to the lighter color filament, we need to set a bigger purge volume.




5.8 Slicing



5.9 Preview the sliced result (gcode file) and then save to gcode file to your PC and then copy to SD card



★ When previewing the gcode file, you can see that some additional print lines will appear on the side of bed, which are for preloading filament. For detail how to pre-load filament, please refer to "E4 Hotend user



guide".



## ! ATTENTION PLEASE


Default Z9V5-MK4 used a E4 (4-IN-1-OUT Non Color Mixing Hotend) hotend, if you have upgrade a M4 (4-IN-1-OUT Mixing Color Hotend), please refer to the below steps to slicing

## 6. Slicing multi-color for M4 hotend



### 6.1 choose printer presets "Z9 + M4 hotend"


Print settings :



 0.20mm






Filament :


 Generic PLA






 Generic PLA





 Generic PLA




 Generic PLA



Printer :

 Zonestar Z9+M4 HOTEND



Supports: None

Infill: 20%

Brim: ☒

Purging volumes...

Name	Extruder	Editing
------	----------	---------

6.2 the other steps for E4 hotend and M4 hotend is the same, please refer to

★ For M4 hotend, there is a bigger store room in the hot end, so we have to use bigger purging volume on wipe tower.

Wipe tower - Purging volume adjustment

Here you can adjust required purging volume (mm³) for any given pair of tools.

3

Extruder changed to

1

2

3

4

1

2

3

4

150

150

150

400

200

150

150

200

150

400

150

200

2

Show simplified settings

OK

Cancel

Supports: None

Infill: 20%

Brim: ☒

Purging volumes...

Name	Extruder	Editing
4C_Niko_Dog_1	de...ult	
4C_Niko_Dog_1.stl	1	
4C_Niko_Dog_2.stl	2	
4C_Niko_Dog_3.stl	3	
4C_Niko_Dog_4.stl	4	

7. Gradient and random mixed color printing

⚠ This feature is for M4 hotend only

The slicing process of realizing gradient mixed color printing is exactly the same as that of monochrome, but you need to enable the gradient printing function in the LCD menu. For details, please refer to the user manual from the M4 hot end sell page.