


## Q1. How to control music on the watch?

1. Turn on your app, click 'Device - More Settings - Music Control', please turn on it.
2. Turn on the phone music player firstly and turn on the watch.
3. Swipe left and find music control. You can control the phone music from your watch, such as switch the phone music, pause and play.

Note: The music control function requires audio to always be output through the phone or headphones/ speakers connected to the phone. The watch acts solely as a controller and cannot play music independently. Two prerequisites must be met:

1. The phone and watch must maintain a connection.
2. The music player app must be launched and kept running in the background on the phone.



## Q2. How to charge the watch correctly?

1. Use the original charging cable included in the packaging.
2. Use a dry, soft cloth to gently wipe the metal contact points on the back of the watch and the charger's surface to avoid dust or sweat residue affecting conductivity.
3. Bring the magnetic charging interface close to the watch's back. The magnets will automatically align and attach.
4. Plug the charging cable into a USB port not exceeding 5V/1A (e.g., a standard adapter or computer USB ports).

The watch screen will typically display a charging icon. It will take about 2 hours to fully charge the device.



### **Q3. How long does the watch battery last? How to extend it?**

The smart watch can be used 3~5 days with full 300mAh battery. In order to extend the battery lifespan, please follow the tips below:

1. Turn off continuous heart rate measurement and automatic measurements (e.g., stress, SpO2).
2. Disable Bluetooth when the watch is not used.
3. Limit notifications to essential apps.
4. Enable power-saving mode and disable background app refresh.
5. Update software regularly for optimized efficiency.
6. Avoid extreme temperatures during charging/usage.
7. Reduce screen brightness & shorten screen timeout.