

## SAUCER SQUASHER

by  
Mark Bitting

Saucer Squasher is a graphics target game for a Super Elf with at least 1K of memory. You have sixteen shots, displayed in the lower left of the screen, to shoot down a flying saucer five times. Each time a shot is fired, one of the sixteen dots is erased. If the flying saucer is hit, it explodes, and a score dot is placed in the lower right.

To keep the game interesting, each time the flying saucer is hit the position the shot comes from is moved (and not displayed- good luck!). However, if you are having trouble hitting the saucer from a particular position, the shots keep coming from there until you get it right.

If the flying saucer crosses the screen three times without being hit, it shoots down at your score dots, and erases the top one. If there are no score dots, it places a dot in a minus column. The dots in the minus column must be erased with hits before any dots will be put in the score column.

If there are three dots in the minus column, beware. Another miss and you will lose. If you use up all your shots you will lose. But, if you have four dots in the score column and hit the flying saucer again, you win.

To start the game, press the Input key. The flying saucer will appear at the top left of the screen and travel to the right. Pressing the Input key now fires the shots, which go up from the bar across the bottom of the screen. When the game is over, the program loops back to the beginning and waits for the Input switch to start again.

Here are a few changes which can be made to the program. By changing the code at 0108 through 010E to 89 F6 F6 F6 3A 0F D7 you can continue firing after the sixteen shots are used up, as long as you don't miss. If the game gets too easy for you, change the bytes at 0111 to 2F and 0166 to 4F. Then the flying saucer will only go across twice before shooting at your score. Or to have it go across only once (expert version) change 0111 to 27 and 0166 to 47.

Contrary to the beliefs of my friends and family, the game is honest. If the shot and the flying saucer occupy the same space at the same time, a hit is scored. If they occupy adjacent spaces, though, that's a near miss and doesn't count. So good luck loading the program, and happy saucer-squashing.

## Register Usage:

R0 Display area 0300-03FF  
 R1 Display routine 0011-002E  
 R2 Display stack 02FC-02FF  
 R3 Initialize and  
   move saucer 002F-00C9  
 R4 Main delay 0100-01B4  
 R5 Hit 0209-029D  
 R6 Win 01B5-0208  
 R7 Lose 00CA-00F6  
 R8 Initial shot  
   position 007E  
 R9 Shot  
 RA, RB, RC, RD Flying saucer  
 RE, RF General utility

ADDR	CODE	COMMENT
0000	F8 00 B1 B3	
0004	F8 2F A3	
0007	F8 02 B2	Initialization
000A	F8 FF A2	
000D	F8 13 A1 D3	
0011	72 70	
0013	22 78 22 52	
0017	C4 C4 C4	
001A	F8 03 B0	
001D	F8 00 A0	
0020	80 E2	Video Interrupt Routine
0022	E2 20 A0	
0025	E2 20 A0	
0028	E2 20 A0	
002B	3C 20 30 11	
002F	E2 69	Turn on TV
0031	F8 03 B9	
0034	F8 EF A9	
0037	93 59	Screen Blank
0039	89 32 3F	
003C	29 30 37	
003F	F8 F0 A9	
0042	F8 FF 59	
0045	89 FD FF	Put line across bottom of screen
0048	32 4D	
004A	19 30 42	
004D	99 BA BB BC BD	
0052	93 B7 A4 B8	
0056	F8 01 B4 B6	
005A	F8 02 B5	More Initialization
005D	F8 CA A7	
0060	F8 B5 A6	
0063	F8 09 A5	
0066	F8 7E A8	
0069	F8 D0 A9	
006C	F8 55 59 19 59	Put Shots on Screen
0071	F8 E0 A9	
0074	F8 55 59 19 59	
0079	3F 79 37 7B	Wait for "I" to start game
007D	F8 EE A9	
0080	F8 20 AA 5A	
0084	F8 28 AB	
0087	F8 30 AC	Load shot position, put flying saucer on screen
008A	F8 38 AD	
008D	F8 70 5B 5D	
0091	F8 F8 5C	
0094	D4	Go to delay in R4

ADDR	CODE	COMMENT
0095	0A F6 5A 3B 9D	
009A	1A 76 5A	
009D	0B 3A A3	
00A0	1B 1D 0B	
00A3	F6 5B 5D	
00A6	3B B0	
00A8	1B 1D 0B 76	Move flying saucer
00AC	5B 5D 2B 2D	
00B0	0C 3A B5	
00B3	1C 0C	
00B5	F6 5C	
00B7	3B BE	
00B9	1C 0C 76 5C 2C	
00BE	D4	Go to delay in R4
00BF	30 94	Loop back through R4 again before moving saucer
00C1	1D 93 5D	Blank Screen
00C4	2D BD 3A C2	
00C8	30 7D	Go back to load shot & saucer
00CA	97 BE	R7-Lose routine
00CC	F8 F1 AE	Set location of dot table
00CF	F8 5C A9	
00D2	4E 59 09 32 DC	
00D7	B9 FC 0B	
00DA	30 D1	
00DC	F8 40 AF	
00DF	7B 2E 8E 3A E0	
00E4	7A 2E 8E 3A E5	Razz loser via Q-line
00EA	2F 8F 3A DF	
00ED	F8 31 A3 D3	Return to beginning & try again
00F1	A6 A9 EF	Dot table
00F4	A9 A9 00	
00F7	00 00 00 00 00	(extra space)
00FC	00 00 00 00	
0100	99 BF	R4-Delays & scoring
0102	F8 E0 AF	
0105	0F 3A 0F	See if player used up all the shots
0108	31 0F D7	If all shots are gone, go to Lose (R7)
010B	00 00 00 00	(extra space for alternate code from text)
010F	8A FD 37 32 64	If saucer is at end, go to "Shoot at score"
0114	31 3A	If shot has been fired skip this delay
0116	F8 02 BF	
0119	2F 37 22	Delay with Input check
011C	9F 3A 19	
011F	D3 30 00	Return
0122	7B 99 BF	
0125	F8 D1 AF	If shot is fired, turn on Q & erase one shot dot
0128	0F 3A 37	
012B	2F 0F 3A 37	
012F	F8 E1 AF	
0132	0F 3A 37	
0135	2F 0F	
0137	FE FE 5F	
013A	89 F6 F6 F6	If shot is at top of screen, turn off Q,
013E	3A 45	reload shot position, go to delay at 0116
0140	08 A9 7A 30 16	
0145	09 32 4E	
0148	FE 3B 4E D5	Check for hit if it hit, go to "Explosion" (R5)
014C	30 00	If miss, continue at 4E

ADDR CODE	COMMENT	ADDR CODE	COMMENT
014E 09 FC 80 59	Add shot	021D 4E 32 27 5C	Load explosion
0152 F8 03 BF		0221 8C FC 08 AC	
0155 2F 9F 3A 55	Delay	0225 30 1D	
0159 09 FF 80 59	Subtract shot	0277 F8 04 AB 7B	
015D 89 FF 08 A9	Move shot up	022B 2F 8F 3A 2B	Sound
0161 D3 30 00	Return to R3	022F 7A 2F 8F 3A 30	
0164 7A	Saucer shoots at score dots	0234 2B 8B 3A 2A	
0165 F8 57 A9	Turn off Q, set up location of saucer's shot	0238 2A 8A 32 42	
		023C 8D FF 08 AC	If last frame of explosion, blank screen & continue
0168 F8 80 59			If not, go back to Load at 021D
016B F8 04 BF		0240 30 1D	
016E 2F 9F 3A 6E	Load shot display, delay, erase shot	0242 93 5C	
0172 93 59		0244 2C 8C 3A 42	
0174 89 FF EF	If shot at bottom go to "Add Minus Dot"	0248 F8 C6 A9	
		024B 09 3A 65	Check for minus dots. If there are any, go to blank.
0177 32 9D			
0179 89 FC 08 A9	Move shot down	024E 89 FC 10 A9	
017D 09 32 68	If no score dot, go back to Load shot (0168)	0252 89 FF F6	
		0255 3A 4B 19	
0180 F8 30 AF		0258 09 32 69	
0183 8F AE 7B		025B 89 FF 10 A9	Find location where next dot belongs and go to Add dot
0186 2E 8E 3A 86	Beep		If this is the fifth hit, go to "Win" (R6)
018A 8F AE 7A		025F 89 FF A7	
018D 2E 8E 3A 8D			
0191 2F 8F 3A 83		0262 3A 5B D6	
0195 93 59	Erase score dot	0265 93 59 30 6C	Blank minus dot & go to Move shot location
0197 F8 C1 A3 D3	Go to screen blank at end of R3		Add score dot
019B 30 00	Return	0269 F8 80 59	
019D 9A AF	Add minus dot	026C 08 FF 01 58	
019F 89 FF 09 A9		0270 08 FF EA 3A 78	
01A3 09 32 B0		0275 F8 EE 58	Move shot location
01A6 2F 8F 3A AB D7	If there are 3 minus dots, go to "Lose" (R7)	0278 F8 7D A3	
		027B D3 30 09	Return
01AB 89 FF 10 30 A2		027E 0A 28 1C 0A	Dot table
01B0 F8 08 59 30 97	Add dot & return	0282 28 00 09 9C	
01B5 F8 EF A9	R6-win	0286 3E FF 7C 39	
01B8 93 59 29	Screen blank	028A 90 00 09 9C	
01BB 89 3A B8		028E 3E FF 7C 39	
01BE F8 F9 AE	Set dot table location	0292 90 00 10 44	
01C1 96 BE		0296 11 84 22 08	
01C3 F8 5B A9		029A 22 08 00 00	The End!
01C6 4E 59 09 32 D4			
01CB 19 4E 59 89			
01CF FC 07 A9 30 C6	Put notice of success on screen		
01D4 89 FF A3 32 DE			
01D9 F8 83 A9 30 C6			
01DE F8 04 BF			
01E1 F8 28 A9			
01E4 7B 29 89 3A E5			
01E9 F8 28 A9	Delay with tone		
01EC 7A 29 89 3A ED			
01F1 2F 9F 3A E1			
01F5 F8 31 A3 D3	Return to screen blank etc. at 0031		
01F9 2B A8 12 A8			
01FD 13 B8 00 8B	Dot table		
0201 A5 8A B5 AA			
0205 AC 53 A5 00			
0209 95 BE	R5-Explosion & Scoring		
020B F8 7E AE	Set dot table address		
020E 1D 93 5D			
0211 2D 8D 3A 0F	Blank Saucer		
0215 8C FF 18 AC AD			
021A F8 04 AA			

## QUESTDATA

P.O. Box 4430  
Santa Clara, CA 95054

Publisher .....Quest Electronics  
Editor .....Paul Messinger  
Proof Reading .....Judy Pitkin  
Production .....John Larimer

The contents of this publication are copyright and shall not be reproduced without permission of QUESTDATA. Permission is granted to quote short sections of articles when used in reviews of this publication. QUESTDATA welcomes contributions from its readers. Manuscripts will be returned only when accompanied by a self addressed stamped envelope. Articles or programs submitted will appear with the authors name unless the contributor wishes otherwise. Payment is at the rate of \$15 per published page. QUESTDATA exists for the purpose of exchanging information about the RCA 1802 microcomputer.

# E~BUG

by  
Phillip Liescheski

This monitor, which I call EBUG, allows you to load a program and inspect code via an ASCII keyboard and a video board or printer. The following is a brief description of the routines used.

## EBUG: Elf Bug Monitor.

This is the main driver routine. It initializes the stack pointer R2, standard subroutine call pointer R4, standard subroutine return pointer R5, break-point interrupt register RE and break-point stack pointer RD. It outputs a carriage return, linefeed and a prompt which is a greater-than sign (>). This prompt signifies an operation code request. The five legal input code are L-load, I-inspect, E-execute, D-dump and B-break-point. If an illegal character is entered, it will not be accepted and a new prompt will be issued.

## LOAD: Load

This operation allows the operator to sequentially modify the contents of memory. After entering L, the starting address for loading is entered followed by a carriage return. A 4-digit hexadecimal number must be entered with a CR following. Without a CR, this operation will be aborted. After the CR, the memory address is displayed with a colon following. After the colon, a 2-digit hexadecimal number is entered and followed with a CR. This will allow the operator to modify the next location. Blanks can be used without discretion. To abort or terminate this operation, one merely enters another character other than the CR when the CR is expected.

## INSP: Inspection

This operation allows the operator to inspect a single memory location at one time. After the I, the 4-digit memory address is entered and followed by the CR. With this, the address is displayed followed by a colon and then the contents of that memory location. If a CR is entered, the next memory location is displayed. If another character is entered, this operation is aborted.

## EXEC: Execute

This operation allows the operator to exit the monitor and enter some other program. After the E, the 4-digit starting address is entered followed by a CR. The program starting at the entered address is executed using R3 as the program counter.

## DUMP: Dump

This operation allows the operator to inspect 8-bytes of memory at one time. After the D, the 4-digit starting memory address is entered followed by the CR. With this, the address is displayed with its colon and eight bytes of memory are displayed on that line. Entering a CR allows the operator to inspect the next 8 bytes of memory. Entering another code aborts this operation.

## BRKP: Break-Point

This operation allows for simple one-level nested break-point executions of a program. After the B, the 4-digit starting address is entered and then the 4-digit break-point address is entered followed with a CR. A blank can be used to separate these two addresses. After entering the CR, the code is executed until the break-point is reached. With this the contents of the accumulator D is displayed and EBUG is re-entered. It should be noted that during BP execution, RD and RE must not be tampered with by the program. Basically, the break-point operation requests the starting address and pushes it on main stack. Then the break-point address is requested. With this the contents of the break-point location is saved on the break-point stack followed by the break-point address. After this, the SEP RE instruction is stored at the b - p location and the program is executed. Control is returned back to the monitor via the SEP RE. After return, R3 is made the PC; the contents of D is displayed and the original contents of b - p location is restored with help from the b - p stack. The monitor is then re-entered and ready for the next operation. A program entered via this monitor can use the stack pointer R2 without need for initializing and can use the SCRT. Finally the program is able to call and use the subroutines contained in the monitor via the SCRT, but they must use R3 as PC and R2 as stack pointer.

## Brief Description of Subroutines:

## OTT- Out Teletype

This routine is supplied by the user. It is not part of the monitor package. This allows for output device flexibility. OTT is required to print or display the ASCII character contained in the accumulator D. It returns control back to the calling routine with a SEP R5 instruction. Four bytes starting at location OE00 have been allotted for a patch into OTT.

## IKB- In Keyboard

This routine is similar to OTT. It is required to accept an ASCII character for some input device and loads its code into accumulator D. It returns by a SEP R5 instruction and three bytes starting a OE04 are reserved for a long branch into IKB. Finally, IKB must echo its characters.

## IADR- Input Address

This routine accepts a 4-digit ASCII coded hexadecimal number and converts it into a 16-bit binary number which is stored in R0. It calls IHEX.

## OADR- Output Address

This routine takes the 16-bit binary number contained in R0 and converts it into a 4-digit ASCII coded hexadecimal number which is displayed. It also pushes a colon after the displayed number in order to signify that it is a memory address. It calls OHEX and OTT.

## INCR- Input a Carriage Return

This routine checks for a carriage return. If no CR is received, the current operation is aborted and the monitor is initialized and re-entered. If a CR is received, a linefeed (LF) is echoed and the current operation is continued. It calls IKB and OTT.

## IHEX- Input a Hexadecimal Number.

This routine accepts a 2-digit ASCII coded number and converts it into an 8-bit binary number which is loaded into the accumulator D. It calls IHXD.

## OHEX- Output a Hexadecimal Number

This routine accepts an 8-bit binary number contained in the accumulator D and converts it into a 2-digit ASCII coded number which is displayed on the output device. It calls OTT.

## IHxD- Input a Hexadecimal Digit

This routine accepts an ASCII coded Hexadecimal digit from the input device and converts it into a 4-bit binary number which is loaded into the least significant nibble (LSN) of D. The most significant nibble (MSN) contains zero. The routine accepts blanks but does nothing with them. This allows for number spacing. It checks to see if the entered character is a legal hexadecimal digit (ie. 0-9, A-F). If the

code is illegal, an underline character is presented and that character is not accepted. This routine has no provisions for corrections. It calls IKB.

## Summary of EBUG use:

## Execute:

>E starting address (CR)

## Inspect:

>I starting address (CR)

XXXX: XX (CR)

## Load:

>L starting address (CR)

XXXX: XX (CR)


## Dump:




>D starting address (CR)

XXXX: XX XX XX ... XX (CR)


## Break-Point:




>B starting address ending address (CR)





## SCRT Routines





## Register Used:

R0 = Address Pointer  
 R2 = Stack Pointer  
 R3 = Main PC  
 R4 = Call Routine Pointer  
 R5 = Return Routine Pointer  
 R6.0 = SCRT Scratch Pad  
 RB = Scratch Pad  
 RD = Break point Stack Pointer  
 RE = Break point Interrupt Pointer

ADDR	CODE	COMMENT
0E00	BF	
0E01	C0 83 03	OTT Patch
0E04	C0 83 00	IKB Patch
0E07	C0 XX XX	Break-Point Re-entry(Future)
0E0A	E2	EBUG Entry
0E0B	F8 FF	Initialize Registers
0E0D	A2 AD	
0E0F	F8 0E	

ADDR	CODE	COMMENT	ADDR	CODE	COMMENT
0E11	B4 B5 BE			* EXEC	
0E14	F8 98		0E87	D4 0E EF	Call IADR
0E16	B2		0E8A	D4 0E 92	Call INCR
0E17	F8 0F		0E8D	80	Push Starting Address
0E19	8D		0E8E	73	on stack
0E1A	F8 4B		0E8F	90	
0E1C	A4		0E90	73	
0E1D	F8 5D		0E91	D5	Go to It
0E1F	A5			* INCR	
0E20	F8 07		0E92	D4 0E 04	Call IKB
0E22	AE		0E95	FF 0D	Check for CR
0E23	F8 0D	Give a Prompt	0E97	3A 0A	If not, re-enter EBUG
0E25	D4 0E 00		0E9A	F8 0A	If so, echo a LF
0E28	F8 0A		0E9C	D4 0E 00	
0E2A	D4 0E 00		0E9F	D5	Return
0E2D	F8 3E			* IHXD	
0E2F	D4 0E 00		0E9F	D4 0E 04	Call IKB
0E32	D4 0E 04	Get Op Code	0EA2	FF 20	Check if a blank
0E35	FF 42	Test if "B" (illegal)	0EA4	32 9F	If so, ok
0E37	32 23		0EA6	FF 10	Check if legal
0E39	FF 02	Test if "D" (illegal)	0EA8	3B BC	If not, yell
0E3B	32 23		0EAA	FF 0A	Check if 0-9
0E3D	FF 01	Test if "E"	0EAC	33 B1	If so, then add #0A
0E3F	32 87		0EAE	FC 0A	and return
0E41	FF 04	Test if "I"	0EB0	D5	
0E43	32 78		0EB1	FF 07	Check if legal
0E45	FF 03	Test if "L"	0EB3	3B BC	If not, yell
0E47	32 68		0EB5	FF 06	Check if legal
0E49	30 23	Illegal Code	0EB7	33 BC	If not, yell
	* SCRT Call		0EB9	FC 10	Must be A-F, so add #10
0E4B	E2	Set R2 as Stack Pointer	0EBB	D5	and return
0E4C	A6	Save D	0EBC	F8 3F	Since it is illegal, display
0E4D	13 13	Push Returning Address	0EBE	D4 0E 00	a "?" and try again.
0E4F	83	on stack	0EC1	30 9F	
0E50	73			* IHEX	
0E51	93		0EC3	D4 0E 9F	Get MSN and shift
0E52	73		0EC6	FE FE FE FE	It up in D
0E53	23		0ECA	73	Push on Stack
0E54	03	Push Calling address	0ECB	D4 0E 9F	Get LSN
0E55	73	on stack	0ECE	60	Add with MSN on Stack
0E56	23		0ECF	F4	
0E57	03		0ED0	D5	Return
0E58	73			* OHEX	
0E59	86	Restore D	0ED1	73	Save D on Stack
0E5A	D5	Jump to Return	0ED2	F6 F6 F6 F6	Position MSN in D
0E5B	30 4B		0ED6	FF 0A	Convert to ASCII code
	* SCRT Return		0ED8	C7	
0E5D	E2	Set R2 as Stack Pointer	0ED9	FC 07	
0E5E	A6	Save D	0EDB	FC 3A	
0E5F	60	Pop address on stack	0EDD	D4 0E 00	Call OTT
0E60	72	and load into R3	0EE0	60	Restore D from Stack
0E61	B3		0EE1	F0	
0E62	F0		0EE2	FA 0F	Mask LSN in D
0E63	A3		0EE4	FF 0A	Convert to ASCII code
0E64	86	Restore D	0EE6	C7	
0E65	D3	Set R3 as PC	0EE7	FC 07	
0E66	30 5D		0EE9	FC 3A	
	* LOAD		0EEB	D4 0E 00	Call OTT
0E68	D4 0E EF	Call IADR	0EEE	D5	Return
0E6B	D4 0E 92	Call INCR		* IADR	
0E6E	D4 0E F8	Call OADR	0EEF	D4 0E C3	Call IHEX
0E71	D4 0E C3	Call IHEX	0EF2	B0	D --> R(0).1
0E74	50	Store the Number	0EF3	D4 0E C3	Call IHEX
0E75	10	Bump Memory Pointer	0EF6	A0	D --> R(0).0
0E76	30 6B	Do it again	0EF7	D5	Return
	* INSP			* OADR	
0E78	D4 0E EF	Call IADR	0EF8	90	R(0).1 --> D
0E7B	D4 0E 92	Call INCR	0EF9	D4 0E D1	Call OHEX
0E7E	D4 0E F8	Call OADR	0EFC	80	R(0).0 --> D
0E81	40	Inspect Memory Location	0EFD	D4 0E D1	Call OHEX
0E82	D4 0E D1	Call OHEX	0F00	F8 3A	Display a ":"
0E85	30 7B	Do it again	0F02	D4 0E 00	
			0F05	F8 20	and then a "blank"
			0F07	D4 0E 00	
			0F1A	D5	Return



# MEMBERSHIP

by  
E.H. Sandelin

This program provides the data needed by a club's officer's to maintain the membership rolls. It will also provide mailing labels. The program is written in Quest Super Basic V3.0. It includes a Sort Routine that can sort the membership file five different ways. I wrote the program for a radio control aircraft club, but it can be modified to fit the requirements of any type of club or group. Record fields can be added or removed to tailor the program to your needs. The program is in modular form with most or all of a function within a module. The program logic should be easy to follow from the listing. The sort is a "Schell-Metzner" sort. It's not one of the fastest sorts, but works well. A quick look at the listing for the sort will show how small a routine it is. To prevent an error 54 a sort should always be performed before any list function. The functions provided are add, edit, list (member list or mailing labels), initialize, save, load, sort and delete. The use of arrays allows ease of handling of numeric data and simplifies the sorts. Dates are entered 'YYMM' so they can be sorted. The day of the month is not used, but may be added if needed. Renumbering of the basic statements is not recommended as the GOSUB statement numbers are calculated by the program. See line number 200.

## FUNCTION DESCRIPTIONS ;

INITIALIZE - Clears arrays and sets up for initial data entry  
ADD - Adds new records  
DELETE - Removes entries from file  
EDIT - Edits records in file  
SORT - Sorts records in file  
LOAD - Loads data from tape  
SAVE - Saves program and data on tape  
LIST - Prints member list or mailing labels  
END - Ends program. Save must be done before end

To change the record field descriptions change the following statements ; 1070, 1080, 1090, 1100, 1120, 1126, 1130, 1136, 1140, 1150 and 1156. To change the list heading, statements 3030 thru 3038 must be changed.

```

10 REM MEMBERSHIP PROGRAM
20 REM BY E.H. SANDELIN AUG. 1980
25 REM WRITTEN IN QUEST SUPER BASIC V3.0
30 V=0
40 DIM V(5): FOR N=1 TO 5:V(N)=0: NEXT N
70 IF V<>1234 GOTO 100
80 PRINT
90 PRINT "FILE SIZE " ;V(3);" RECORDS AVAILABLE "
  V(3)=V(2)
100 PRINT : PRINT "SELECT AN OPTION ;"
110 PRINT "1 - ADD, 2 - EDIT, 3 - LIST, 4 - DELETE,
  5 - SAVE"
120 INPUT "6 - LOAD, 7 - SORT, 8 - INITIALIZE,
  9 - END " O
170 IF O<1 GOTO 190
175 IF O>9 GOTO 190
180 GOTO 200
190 PRINT : PRINT "INVALID SELECTION" : GOTO 70
200 GOSUB O*1000+10
300 PRINT : GOTO 70
400 PRINT : PRINT "***** REQUEST EXCEEDS FILE SIZE
  OF " ;V(3): PRINT
405 RETURN
1010 V(1)=1000: PRINT "ADD RECORDS"
1014 PRINT : PRINT "ENTER A RECORD # OF 0 TO END
  ADD" : PRINT
1020 INPUT "RECORD # " N
1030 IF N>V(3) GOSUB 400: GOTO 1020
1040 IF N<=0 RETURN
1050 IF N(N)=N PRINT "THAT NUMBER ASSIGNED TO "
  ;N$(N): GOTO 1020
1060 N(N)=N
1070 INPUT "MEMBERS NAME " T$
1075 IF MID$(T$,1,1)=". " GOTO 1080
1076 N$(N)=T$
1080 INPUT "STREET ADDRESS " T$
1082 IF MID$(T$,1,1)=". " GOTO 1090
1084 A$(N)=T$
1090 INPUT "CITY " T$
1092 IF MID$(T$,1,1)=". " GOTO 1100
1094 C$(N)=T$
1100 INPUT "STATE ZIP " T$
1102 IF MID$(T$,1,1)=". " GOTO 1120
1104 S$(N)=T$
1120 INPUT "TELEPHONE ACD XXX XXXX" T$
1122 IF MID$(T$,1,1)=". " GOTO 1126
1124 T$(N)=T$
1126 INPUT "AMA NUMBER " A
1127 IF A=0 GOTO 1130
1128 A(N)=A
1130 INPUT "DATE JOINED CLUB YYMM" J
1132 IF J=0 GOTO 1136
1134 J(N)=J
1136 INPUT "DATE STARTED MODELING YYMM" M
1137 IF M=0 GOTO 1140
1138 M(N)=M
1140 INPUT "DATE OF BIRTH YYMM" B
1142 IF B=0 GOTO 1150
1144 B(N)=B
1150 INPUT "RATING " T$
1152 IF MID$(T$,1,1)=". " GOTO 1156
1154 R$(N)=T$
1156 INPUT "OFFICE " T$
1157 IF MID$(T$,1,1)=". " GOTO 1160
1158 O$(N)=T$
1160 IF V(1)<>1000 RETURN
1190 V(2)=V(2)+1: PRINT : GOTO 1020

```

```

2010 PRINT : PRINT "EDIT RECORDS" : PRINT
2015 V(1)=2000
2017 PRINT : PRINT "ENTER A '.' TO DUP AN ENTRY."
      : PRINT
2020 INPUT "RECORD # " N
2030 IF N>V(3) GOSUB 400: GOTO 2020
2032 IF N=0 RETURN
2035 IF N(N)<>N PRINT N;" HAS NOT BEEN ASSIGNED YET"
      : PRINT : GOTO 2020
2050 PRINT N$(N);
2052 PRINT TAB(21);"TEL " ;T$(N);
2054 PRINT TAB(40);"AMA " ;INUM(A(N));
2056 PRINT TAB(54);R$(N);
2058 PRINT TAB(77);INUM(N(N))
2060 PRINT A$(N);
2062 PRINT TAB(36);"DOB " ;INUM(B(N));
2064 PRINT TAB(50);"JOINED " ;INUM(J(N));
2066 PRINT TAB(65);"ST.MDL. " ;INUM(B(N))
2068 PRINT C$(N);" " ;S$(N);
2070 PRINT TAB(40);"OFFICE " ;O$(N)
2075 IF V(1)=3000 RETURN
2078 PRINT : GOSUB 1070
2080 PRINT : GOTO 2020
3010 PRINT : INPUT "1 - LIST, 2 - LABELS " B
3012 PRINT : INPUT "# OF COPIES " C
3014 IF B=2 GOTO 3300
3015 V(1)=3000: PRINT : INPUT "TODAYS DATE
      MM/DD/YY" D$
3020 INPUT "MAKE PRINTER READY " Z$
3030 DATA "REPLACE WITH CLUB NAME"
3032 DATA "STREET ADDRESS"
3034 DATA "CITY, STATE AND ZIP CODE"
3036 DATA "MEMBERSHIP LIST - ACTIVE MEMBERS ONLY"
3038 DATA "ADDITIONAL HEADING DATA" ,"MORE
      HEADING DATA"
3040 FOR A=1 TO 6: READ H$(A): NEXT A
3045 RESTORE
3050 PRINT TAB(25);H$(1);TAB(70);D$
3051 PRINT TAB(25);H$(2)
3052 PRINT H$(5);TAB(25);H$(3);TAB(62);H$(6)
3060 PRINT
3070 PRINT "-----" ;H$(4);
      "-----" : PRINT
3080 P=14
3100 FOR I=1 TO V(3)
3110 IF S(I,1)=0 GOTO 3150
3115 N=S(I,1)
3120 GOSUB 2050
3130 PRINT
3135 P=P-1: IF P=0 CLS:P=15; PRINT : PRINT
3150 NEXT I
3200 C=C-1: IF C=0 CLS: RETURN
3210 CLS
3220 GOTO 3050
3300 PRINT : INPUT "READY PRINTER " Z$
3310 FOR I=1 TO V(3)
3320 IF S(I,1)=0 GOTO 3340
3325 N=S(I,1)
3330 PRINT N$(N);TAB(30);INUM(A(N))
3332 PRINT A$(N)
3334 PRINT C$(N)
3336 PRINT S$(N)
3338 PRINT : PRINT
3340 NEXT I
3350 C=C-1: IF C=0 CLS: RETURN
3360 GOTO 3310
4010 PRINT : PRINT "DELETE RECORDS" : PRINT
4015 V(1)=4000
4020 INPUT "RECORD # " N
4030 IF N>V(3) GOSUB 400: GOTO 4020
4040 IF N=0 RETURN
4050 IF N(N)=0 PRINT N;" HAS NOT BEEN ASSIGNED"
      : GOTO 4020
4052 PRINT : PRINT "RECORD # " ;INUM(N);" IS "
      ;N$(N)
4054 INPUT "VERIFY DELETE Y/N " Z$
4056 IF MID$(Z$,1,1)="Y" GOTO 4059
4058 GOTO 4020
4059 B(N)=0:J(N)=0:M(N)=0:A(N)=0
4060 N(N)=0: PRINT N$(N);" HAS BEEN DELETED"
4062 V(2)=V(2)-1
4070 PRINT : GOTO 4020
5010 PRINT : PRINT
5015 V(1)=5000
5020 INPUT "MAKE TAPE UNIT 2 READY TO RECORD " Z$
5040 PSAVE : DSAVE
5050 PSAVE : DSAVE
5060 PRINT "DATA HAS BEEN SAVED "
5070 RETURN
6010 PRINT : INPUT "MAKE TAPE READY " Z$
6015 V=1234
6030 DLOAD
6050 RETURN
7010 PRINT "SORT ROUTINE"
7012 V(1)=7000
7014 GOSUB 7300
7016 IF S=5 GOTO 7230
7020 P=0:M=V(3)
7030 M=INT(M/2)
7040 IF M=0 GOTO 7230
7050 P=P+1: PRINT "PASS " ;P;" STARTED"
7070 FOR L=1 TO M
7080 I=L:J=L+M:W=0
7110 IF Z=1 GOTO 7118
7114 IF S(I,2)>=S(J,2) GOTO 7160
7116 GOTO 7120
7118 IF S(I,2)<=S(J,2) GOTO 7160
7120 W=1
7130 X=S(I,2):Y=S(J,2)
7140 S(I,2)=S(J,2):S(J,2)=X
7150 S(J,2)=X:S(J,1)=Y
7160 I=J:J=J+M
7180 IF J<V(3) GOTO 7110
7190 IF W=0 GOTO 7210
7200 GOTO 7080
7210 NEXT L
7220 GOTO 7030
7230 PRINT : PRINT "SORT DONE"
7240 RETURN
7300 PRINT : PRINT "SELECT SORT FIELD ;"
7310 PRINT "1 - JOINED, 2 - DOB, 3 - ST.MDL,
      4 - AMA #, 5 - RECORD # " ;
7320 INPUT S
7332 IF S<1 GOTO 7300
7334 IF S>5 GOTO 7300
7340 PRINT : INPUT "1 TO SORT ASCENDING, 2 FOR
      DESCENDING " Z
7342 PRINT
7344 IF Z>2 GOTO 7340
7345 IF S=1 FOR I=1 TO V(3):S(I,1)=N(I):S(I,2)=J(I):
      NEXT I
7350 IF S=2 FOR I=1 TO V(3):S(I,1)=N(I):S(I,2)=B(I):
      NEXT I
7355 IF S=3 FOR I=1 TO V(3):S(I,1)=N(I):S(I,2)=M(I):
      NEXT I
7360 IF S=4 FOR I=1 TO V(3):S(I,1)=N(I):S(I,2)=A(I):
      NEXT I
7365 IF S=5 FOR I=1 TO V(3):S(I,1)=N(I):S(I,2)=N(I):
      NEXT I
7370 RETURN
8010 PRINT : PRINT "INITIALIZING"
8015 CLD: DIM V(5)
8020 FOR N=1 TO 5:V(N)=0: NEXT N
8022 PRINT : INPUT "ENTER MAX FILE SIZE, # OF
      RECORDS. " V(3)
8024 DIM A(V(3)),B(V(3)),J(V(3)),M(V(3)),N(V(3)),
      S(V(3),2)
8026 FOR N=1 TO V(3)
8030 A(N)=0:B(N)=0:J(N)=0:M(N)=0:N(N)=0
8080 S(N,1)=0:S(N,2)=0
8090 NEXT N
8120 V=1234: RETURN
9010 PRINT "PROGRAM ENDED" : END

```

# ROTATING CHRISTMAS DISPLAY

## ROTATING CHRISTMAS DISPLAY

Written by Fred Hannan

This is a jolly little display program that you can load up on your ELF, start it running, and just let it run continuously on your CRT.

100 REM it will make several different Christmas type pictures with 110 REM a pause between each.

130 REM I usually set it up ready to run on Christmas morning and 140 REM and find it delights the visiting small fry.

160 REM To stop the program, hit your BREAK key.

```

10 REM
20 REM
30 REM
40 REM
50 REM
60 REM
70 REM
80 REM
90 REM
100 REM
110 REM
120 REM
130 REM
140 REM
150 REM
160 REM
170 REM
180 REM
190 A=24:B=20:C=6
200 CLS: PRINT TAB(A); "M"
210 PRINT TAB(A-1); "ERR"
220 PRINT TAB(A-2); "Y CHR"
230 PRINT TAB(A-3); "ISTMAS"
240 PRINT TAB(A-4); "HAPPY NEW"
250 PRINT TAB(A-5); "YEAR MERRY"
260 PRINT TAB(A-6); "CHRISTMAS HAP"
270 PRINT TAB(A-7); "PY NEW YEAR MER"
280 PRINT TAB(A-8); "RY CHRISTMAS HAPP"
290 PRINT TAB(A-9); "Y NEW YEAR MERRY CH"
300 PRINT TAB(A-10); "RISTMAS HAPPY NEW YEAR"
310 PRINT TAB(A-11); "MERRY CHRISTMAS HAPPY NE"
320 PRINT TAB(A); "M"
330 PRINT TAB(A); "Y"
340 PRINT TAB(A-1); "EAR"
350 GOSUB 1040
360 PRINT TAB(B); "00000000"
370 PRINT TAB(B-5); "00000000000000000000"
380 PRINT TAB(B-8); "00000000"
390 PRINT TAB(B-10); "000000"
400 PRINT TAB(B-11); "000000"
410 PRINT TAB(B-11); "000000"
420 PRINT TAB(B-10); "000000"
430 PRINT TAB(B-8); "00000000"
440 PRINT TAB(B-9); "00000000000000000000"
450 PRINT TAB(B-10); "000000"
460 PRINT TAB(B-11); "000000"
470 PRINT TAB(B-10); "000"
480 PRINT TAB(B-9); "0"
490 GOSUB 1040
500 PRINT TAB(C); "M"
510 PRINT TAB(C); "M"
520 PRINT TAB(C); "M"
530 PRINT TAB(C); "M"
540 PRINT TAB(C); "M"

```

### QUESTDATA

P.O. Box 4430

Santa Clara, CA 95054

A 12 issue subscription to QUESTDATA, the publication devoted entirely to the COSMAC 1802 is \$12.  
(Add \$6.00 for airmail postage to all foreign countries except Canada and Mexico.)

Your comments are always welcome and appreciated. We want to be your 1802's best friend.

#### Payment:

- ☐ Check or Money Order Enclosed  
Made payable to Quest Electronics
- ☐ Master Charge No. \_\_\_\_\_
- ☐ Bank Americard No. \_\_\_\_\_
- ☐ Visa Card No. \_\_\_\_\_

Expiration Date: \_\_\_\_\_

Signature \_\_\_\_\_

☐ Renewal ☐ New Subscription

NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY \_\_\_\_\_

STATE \_\_\_\_\_

ZIP \_\_\_\_\_

```

550 PRINT : PRINT : PRINT : PRINT
560 PRINT TAB(C+2);"X" X M M AA SSSSSS"
570 PRINT TAB(C+3);"X" X MM MM A A S"
580 PRINT TAB(C+4);"XXX" M MM M AAAAAA SSSSSS"
590 PRINT TAB(C+3);"X" X M M A A S"
600 PRINT TAB(C+2);"X" X X X A A SSSSSS"
610 GOSUB 1040
620 PRINT : PRINT : PRINT
630 PRINT TAB(C);"H" H 00000"
640 PRINT TAB(C);"H" H 0 0"
650 PRINT TAB(C);"HHHHH" 0 0 H H 00000"
660 PRINT TAB(C);"H" H 0 0 H H 0 0"
670 PRINT TAB(C);"H" H 00000 HHHHH 0 0 H H 00000"
680 D=C+18
690 PRINT TAB(D);"H" H 0 0 H H 0 0"
700 PRINT TAB(D);"H" H 00000 HHHHH 0 0"
710 E=D+18
720 PRINT TAB(E);"H" H 0 0"
730 PRINT TAB(E);"H" H 00000"
740 GOSUB 1040
750 G=C+4
760 PRINT TAB(G);"H" H AAAAAA PPPPPP PPPPPP Y Y"
770 PRINT TAB(G);"H" H A A P P P P Y Y"
780 PRINT TAB(G);"HHHHHH AAAAAA PPPPPP PPPPPP YY"
790 PRINT TAB(G);"H" H A A P P YY"
800 PRINT TAB(G);"H" H A A P P YY"
810 PRINT : PRINT : PRINT :C=C-4
820 PRINT TAB(C);"N" N EEEEE W W Y Y EEEEE AAAAAA RRRRR"
830 PRINT TAB(C);"NN" N E W W Y Y E A A R R"
840 PRINT TAB(C);"N N N EEEEE W WW W YY EEEEE AAAAAA RRRRR"
850 PRINT TAB(C);"N N N E WW WW YY E A A R R"
860 PRINT TAB(C);"N NN EEEEE W W YY EEEEE A A R R"
870 GOSUB 1040
880 PRINT TAB(A);"!"
890 PRINT TAB(A-1);"( )"
900 PRINT TAB(A-2);"( )"
910 PRINT TAB(A-1);"( )"
920 PRINT TAB(A);"!"
930 H=A-3
940 PRINT TAB(H);"00000000"
950 A$="0 0"
960 FOR N=1 TO 5
970 PRINT TAB(H);A$
980 NEXT N
990 PRINT TAB(H);A$;" /"
1000 PRINT TAB(H);A$;" /"
1010 PRINT TAB(H-11);" 0 0 /"
1020 WAIT(700): GOTO 190
1030 END
1040 WAIT(700): CLS
1050 RETURN

```

**COSMAC CLUB COSMAC CLUB COSMAC CLUB COSMAC CLUB COSMAC CLUB COSMAC**

**23**

QUESTDATA

P.O. Box 4430

Santa Clara, CA 95054

**ADDRESS CORRECTION REQUESTED**

**BULK RATE**

U.S. Postage Paid

QUEST

Electronics

Permit No. 549  
Santa Clara, CA

#72194

**RECEIVED**  
24 SEP 1974  
ROCKWELL, INC.