

**NEL-SYSTEM**

**Wafer protection  
tape remover**



**HR8500III**

**TW-UV**

**INSTALLATION  
MANUAL**

**NITTO DENKO  
NITTO SEIKI**

# Overview

	 <b>WARNING</b>
	<p>Read this instruction manual carefully and have a complete understanding of the contents before use.</p> <p>Observe all warnings and cautions in this manual.</p> <p>Failures to observe warnings and cautions could cause of serious injuries to human body and damage/performance decrement of the equipment.</p> <p>Keep this instruction manual so that you can use it at anytime.</p>

This manual consists of below:

- Vol. 1 Installation manual
- Vol. 2 Operation manual
- Vol. 3 Maintenance manual

This manual is Vol. 1 Installation manual to install the equipment correctly and safely by the maintenance engineers.

The maintenance engineers have the operators keep the following rules.

- The operators are allowed to do the works only shown in “Vol. 2 Operation manual”.
- Only authorized persons are allowed to do the works shown in “Vol. 1 Installation manual” and “Vol. 3 Maintenance manual”.
- The operators are not allowed to do the works having use of any tools, such as screwdrivers and wrenches.
- The operators are not allowed to have keys for lockout and override the safety interlock.

## Copyright

Nitto Denko Corporation and Nitto Seiki Co., Ltd. have the copyright of the instruction manual. Use of any part of this document is allowed only after preliminary permission of Nitto Seiki Co., Ltd.

No part of this document may be reproduced or transmitted in any form or by any means for any purpose without permission of Nitto Seiki Co., Ltd.

## - CONTENTS -

1. Installation	
1.1 Sizes and Weight.....	1-1-1
1.2 Transport and Unpacking .....	1-2-1
1.3 Contents confirmation of accessory .....	1-3-1
1.4 Floor conditions and Positioning .....	1-4-1
1.5 Removal of strings and cushioning materials.....	1-5-1
1.6 Leveling .....	1-6-1
2. Utility connection	
2.1 Electrical power.....	2-1-1
2.2 Dry air line and N2 .....	2-2-1
2.3 Power on .....	2-3-1
2.4 Attachment of robot arm .....	2-4-1
3. Preparation for auto operation	
3.1 Peeling tape preparation .....	3-1-1
3.2 Auto operation start .....	3-2-1
3.3 Auto operation stop/restart .....	3-3-1
3.4 Auto operation end procedure .....	3-4-1