

OpenOCD Quick Reference Card

OpenOCD Homepage:
http://openocd.berlios.de
OpenOCD revision: 211

Configuration

Daemon

telnet_port <port> Listen for telnet connections on *port*.

gdb_port <port> Listen for GDB connections on *port*, *port+1*, ... (target 1, target 2, ...)

daemon_startup <'reset'|'attach'> Describes what to do with target on daemon startup.

Target

target <type> <endianness> <reset_mode>
Target *type* is arm7tdmi, arm720t, arm9tdmi, arm920t, arm922t, arm926ejs, arm966e, cortex_m3, xscale; *endianness* is either big or little; *reset_mode* is one of reset_halt, reset_init, reset_run, run_and_halt, run_and_init. **Do not use reset_halt or reset_init on LPC2 or STR7.**

target arm7tdmi <endianness> <reset_mode>
<jtag#> [variant] *variant* is one of arm7tdmi_r4, arm7tdmi-s_r4, and lpc2000.

target arm9tdmi <endianness> <reset_mode>
<jtag#> [variant] *variant* is one of arm920t, arm922t and arm940t.

target arm920t <endianness> <reset_mode>
<jtag#> [variant] *variant* is arm920t.

target arm926ejs <endianness> <reset_mode>
<jtag#> [variant] *variant* is arm926ejs.

flash_bank cfi <base> <size> <chip_width>
<bus_width> <target#>

flash_bank lpc2000 <base> <size> 0 0
<target#> <variant> <clock> ['calc.checksum']
The internal flash of LPC2000 devices doesn't require chip- and buswidth to be defined. The *lpc_variant* specifies the supported IAP commands of the device (lpc2000_v1:2104—5—6, 2114—9, 2124—9, 2194, 2212—4, 2292—4; lpc2000_v2: 213x, 214x, 2101—2—3, 23xx, 24xx). The flash bank is part of *target#* which runs at *clock* kHz. *Calc.checksum* inserts a valid checksum into the exception vector when this area is flashed.

For LPC2138 and LPC2148 devices, the *size* argument has to reflect the user-accessible size, i.e. 0x7d000 (500kB), not 0x80000 (512kB).

flash_bank stellaris <base> <size> 0 0
<target#>

flash_bank stm32x <base> <size> 0 0
<target#>

flash_bank str7x <base> <size> 0 0
<target#> <variant> - *variant* is one of STR71x, STR73x or STR75x.

flash_bank str9x <base> <size> 0 0
<target#>
The str9 needs the flash controller to be configured prior to Flash programming:
str9x flash_config b0size b1size b0start b1start
Example: str9x flash_config 4 2 0 0x80000
This will setup the BBSR, NBBSR, BBADR and NBBADR registers respectively.

flash_bank str9xpec <base> <size> 0 0
<target#> - Before using the flash commands the turbo mode will need enabling using str9xpec enable_turbo <num>

Commands

Daemon

target arm966e <endianness> <reset_mode>
<jtag#> [variant] *variant* is arm966e.

target xscale <endianness> <reset_mode>
<jtag#> [variant] *variant* is one of pxa250, pxa255, pxa26x, pxa27x, ixp42x, ixp45x, ixp46x.

target_script <target#> <event> <scriptfile>
event is either reset, post_halt or pre_resume.

run_and_halt_time <target#> <time> Delay in msec between reset and debug request.

working_area <target#> <addr> <size>
[backup|nobackup]

JTAG

interface <name> - *name* is one of parport, amt_jtagaccel, ft2232, ep93xx, at91rm9200, gw16012, presto, usbprog.

jtag_device <IR length> <IR capture> <IR mask> <IDCODE instruction> - Describes the devices that form the JTAG daisy chain, with the first device being the one closest to TDO.

jtag_nsrst_delay <ms> - *ms* milliseconds delay between going nSRST inactive and following JTAG operations.

jtag_ntrst_delay <ms> - *ms* milliseconds delay between going nTRST inactive and following JTAG operations.

reset_config <signals> [combination]
[trst-type] [srst-type] - *signals* is one of none, trst_only, srst_only or trst_and_srst. *combination* is one of srst_pulls_trst, trst_pulls_srst, combined, separate. *trst-type* is one of trst_open_drain, trst_push_pull. *srst-type* is one of srst_push_pull, srst_open_drain.

sleep <msec>

shutdown Shut server down.

debug_level <n>

log_output <file>

script <file> Execute commands from file.

gdb_detach [resume|reset|halt|nothing] NEW

exit Exit telnet. Leaves server running.

help Print available commands.

Target

targets [num] Display list of configured targets, or make target *num* the current target.

reg [#|name] [value|'force'] Display or modify registers.

poll ['on'|'off'] Print information about the current target state. If the target is in debug mode, architecture specific information about the current state are printed. Enable or disable continuous polling with optional parameter.

wait_halt Wait for target halt

halt Halt target

resume <address> Resume the target at the current position or at *address*.

step <address> Single-step at the current position or at *address*.

reset ['run'|'halt'|'init'|'run_and_halt'|'run_and_init'] Reset the target in a few variations.

soft_reset_halt Halt the target and do a soft reset.

md[whb] <address> [count] Display *count* words (32 bit), half-words (16 bit) or bytes at *address*. If *count* is omitted, one element is displayed.

jtag_speed <value> Select JTAG speed (this is also a command) **ft2232:** 6 MHz / (*value*+1) **parport:** maximum speed / *value* **amt_jtagaccel:** 8 / 2***value*
Note: Max. JTAG-Clock $\approx \frac{1}{6} \times$ CPU-Clock!

Parport

parport_port <port|num> - Either I/O *port* address (e.g. 0x378) or the *number* of the /dev/parport device.

parport_cable <name> - *name* is one of wiggler, old_amt_wiggler, chameleon, dlcs (Xilinx cable III), triton.

Amt_jtagaccel

parport_port <port|number> see previous description.

Ft2232

ft2232_device_desc <description> USB *device description*. Use usbview or similar tool to get this string.

ft2232_layout <name> Layout *name* is one of usbjtag, jtagkey, jtagkey_prototype_v1, oocdlink, olimex-jtag, signalizer, flyswatter, turtelizer2, comstick, evb_lm3s811.

ft2232_vid_pid <vid> <pid> Vendor-ID *vid* and product-ID *pid* of the FTDI device.

Flash Configuration

flash_bank <driver> <base> <size> <chip_width> <bus_width> <target> [driver.options...]
Configure a flash bank at address *base* of *size* bytes with a bus of *bus_width* bits formed by chips of *chip_width* bits size using *driver* at91sam7, cfi, lpc2000, stellaris, stm32x, str7x, str9x, str9xpec.

flash_bank at91sam7 0 0 0 0 <target#>

mw[whb] <address <value> Write *value* at the word, half-word or byte location *address*.

bp <address> <length> [hw] Set a breakpoint of *length* bytes at *address*.

rbp <address> Remove breakpoint at *address*.

wp <address> <length> <r|w|a> [value] [mask] Set a watchpoint of *length* bytes at *address*.

rwp <address> Remove a watchpoint at *address*.

load_image <file> <address> ['bin'|'ihex'|'elf'] Load image *file* to target memory at *address*.

dump_image <file> <address> <size> Dump *size* bytes of target memory starting at *address* to a (binary) *file*.

load_binary <file> <address> Load binary *file* into target memory (RAM) at *address*. DEPRECATED

dump_binary <file> <address> <size> Dump target memory of *size* bytes at *address* into *file*. DEPRECATED

ARM v4/5

armv4_5_reg Display all banked ARM core registers.

armv4_5_core_mode ['arm'|'thumb'] Display the current core state, or switch between Arm and Thumb state.

armv4_5_disassemble <address> <count> ['thumb'] Disassemble instructions

ARM720T

The commands are cp15, virt2phys, mdw_phys, mdh_phys, mdb_phys, mww_phys, mwh_phys, mwb_phys. See ARM7/9 for a short description.

ARM 7/9

arm7_9 write_xpsr <value> <spsr>

Write the program status register. spsr selects between the current program status register (0) and the saved program status register (1) of the current mode.

arm7_9 write_xpsr_im8 <8bit immediate>
<rotate> <not cpsr|spsr>

Same as write_xpsr, but use the immediate operand opcode.

arm7_9 write_core_reg <num> <mode> <value>
Write core register num of mode with value.

arm7_9 sw_bkpts <'enable'|'disable'>
Enable or disable the use of software breakpoints.

arm7_9 force_hw_bkpts <enable|disable>
Force the use of hardware breakpoints.

arm7_9 dbgrrq <enable|disable>
Use EmbeddedICE dbgrrq instead of breakpoint for target halt requests (safe for all except ARM7TDMI-S).

arm7_9 fast_memory_access <enable|disable>
Use fast but potentially unsafe memory accesses instead of slow accesses. Assumes a sufficiently high clock speed.

arm7_9 dcc_downloads <enable|disable>
use DCC downloads for larger memory writes.

ARM920T

arm920t cp15 <num> [value] Display/modify CP15 register

arm920t cp15i <opcode> [value] [address]
Display/modify cp15 (interpreted access)

arm920t cache_info Display information about target caches.

arm920t virt2phys <va> Translate virtual to physical address.

arm920t md[whb].phys <physical addr>
[count] display memory word, half word, byte

arm920t mw[whb].phys <physical addr>
<value> write memory word, half word, byte

arm920t read_cache <filename> display I/D cache content

arm920t read_mmu <filename> display I/D mmu content

ARM926EJ-S

Commands: cp15, cache_info, virt2phys, mdw_phys, mdh_phys, mdb_phys, mww_phys, mwh_phys, mwb_phys.

ARM966E

arm966e cp15 <num> [value] Display/modify CP15 register

scan_chain Print scan chain configuration.

endstate <tap_state> Finish JTAG operations in tap_state.

jtag_reset <trst> <srst> Toggle reset lines.

runtest <num_cycles> Move to Run-Test/Idle and execute num_cycles.

statemove <tap_state> Move to current endstate or tap_state.

irscan <device> <instr> [devN] [instrN]
Execute IR scan.

drscan <device> <var> [devN] [varN] Execute DR scan.

Flash Commands

flash banks Display list of configured flash banks

flash info <num> Display information and list of blocks of flash bank num.

flash probe <num> Probe flash bank num if it matches the configured bank.

flash erase_check <num> Check erase state of flash sectors in bank num.

flash protect_check <num> Check protect state of flash sectors in bank num.

flash erase <num> <first> <last> Erase sectors at bank num, starting at sector first up to and including last. Sector numbering starts at 0.

flash write <num> <binfile> <offset> Write binfile (in binary format!) to bank num at offset bytes from start of bank. DEPRECATED

flash write_binary <bank> <file> <offset>
Write file in binary format to bank num at offset bytes from start of bank.

flash write_image <file> [offset] [type]
Write image file with optional offset. The optional type is one of bin, ihex, elf and s19.

flash protect <num> <first> <last> <'on'|'off'>
Enable (on) or disable (off) protection of flash sectors first to last of flash bank num.

flash auto_erase <'on'|'off'> Auto erase flash sectors on or off.

See also the AT91SAM7 specific flash erase command.

AT91SAM7 specific commands

flash erase <num> first.plane last.plane

at91sam7 gpnmv <num> <bit> <'set'|'clear'>
set or clear at91sam7 gpnmv bit

LPC2000 specific commands

lpc2000 part_id <num> print part id of lpc2000 flash bank num.

STM32x specific commands

stm32x lock <num> lock stm32 device
stm32x unlock <num> unlock stm32 device
stm32x options_read <num> read stm32 option bytes
stm32x options_write <num> <SWWDG|HWWDG>
<RSTSTNDBY|NORSTSTNDBY> <RSTSTOP|NORSTSTOP>
write stm32 option bytes
stm32x mass_erase <num> mass erase flash memory

STR9 specific commands

str9xpec enable_turbo <num> enable turbo mode, simply this will remove the str9 from the chain and talk directly to the embedded flash controller
str9xpec disable_turbo <num> restore the str9 into jtag chain
str9xpec lock <num> lock str9 device. The str9 will only respond to an unlock command that will erase the device.
str9xpec unlock <num> unlock str9 device
str9xpec options_read <num> read str9 option bytes
str9xpec options_write <num> write str9 option bytes

STR9 option byte config

str9xpec options_cmap <num> <bank0|bank1>
configure str9 boot bank
str9xpec options_lvdthd <num> <2.4v|2.7v>
configure str9 lvd threshold
str9xpec options_lvdsel <num> <vdd|vdd_vddq>
configure str9 lvd source
str9xpec options_lvdwarn <bank> <vdd|vdd_vddq>
configure str9 lvd reset warning source

XSVF

xsvf <devnum> <file> Program Xilinx Coolrunner CPLD

JTAG Adaptors

- JTAGkey-Tiny (Amontec)
<http://www.amontec.com>
- Olimex ARM-USB-JTAG
<http://www.olimex.com>
- USBprog is the first USB-to-JTAG adaptor which does *not* use a National USBN9604 and an Atmel AVR. In addition of being an Openocd JTAG adaptor it can do many other useful jobs.
<http://www.embedded-projects.net>.
- OOCdLink/Small (Jörn Kaipf)
<http://www.joernonline.de>
- USBJTAG (homegrown)
<http://www.fh-augsburg.de/~hhoegl/proj/usbjtag/usbjtag.html>

Commandline Options

```
$ openocd --help
Open On-Chip Debugger
(c) 2005 by Dominic Rath

--help      | -h display this help
--file      | -f use configuration file <name>
--debug     | -d set debug level <0-3>
--log_output | -l redirect log output to file <name>
--interface | -i use jtag interface driver <name>
```

Sample Configuration

[see \$(SRCDIR)/doc/configs/*.cfg]

GDB

Startup (replace arm-gdb with your debugger name)
arm-gdb [-x <file>] Execute GDB commands from file.

cgdb -d arm-gdb -x <file> Run cgdb front end.
ddd --debugger arm-gdb -x <file> Run ddd front end.

At the GDB prompt
(gdb) target remote localhost:3333 contact target at localhost, portnumber 3333.

(gdb) monitor arm7_9 force_hw_bkpts enable
'monitor' sends command to Openocd server (force hardware breakpoints)

(gdb) set remote hardware-watchpoint-limit 2
only two hardware breakpoints available

More information

- Get current version with Subversion
svn co svn://svn.berlios.de/openocd/trunk
- OpenOCD Forum at Spark Fun Electronics
<http://www.sparkfun.com/cgi-bin/phpbb/viewforum.php?f=18>

- OpenFacts
http://openfacts.berlios.de/index-en.phtml?title=Open_On-Chip_Debugger

- Mailing List "openocd-development"
http://developer.berlios.de/mail/?group_id=4148

- Yagarto ARM toolchain (Windows)
<http://www.yagarto.de>

- Amontec JTAGkey[-Tiny], sdk4arm
<http://www.amontec.com>

- Olimex ARM-USB-TINY, ARM-USB-OCD
<http://www.olimex.com>

QuickRef written by Hubert.Hoegl@fh-augsburg.de
Date: 2007-11-14

Download this QuickRef from

<http://www.fh-augsburg.de/~hhoegl/proj/openocd/ocod-quickref.pdf>

<http://www.fh-augsburg.de/~hhoegl/proj/openocd/ocod-quickref-compact.pdf>