

Module Interface Specification for MTOBridge

Team 15, Alpha Software Solutions

Badawy, Adham

Yazdinia, Pedram

Jandric, David

Vakili, Farzad

Vezina, Victor

Chiu, Darren

January 18, 2023

1 Revision History

Date	Developer(s)	Notes
January 15, 2023	David and Darren	Initial Draft
January 17, 2023	Adham, Farzad, Pedram, and Victor	Conversion to LaTeX
January 18, 2023	David and Victor	Formatting

2 Symbols, Abbreviations and Acronyms

See SRS Documentation at <https://github.com/agentvv/MTOBridge/blob/main/docs/SRS/SRS.pdf>.

2.1 Abbreviations and Acronyms

symbol	description
MIS	Module Interface Specification
SRS	Software Requirements Specification

Contents

1	Revision History	i
2	Symbols, Abbreviations and Acronyms	ii
2.1	Abbreviations and Acronyms	ii
3	Introduction	1
4	Notation	1
5	Module Decomposition	1
6	MIS of Save to File System	4
6.1	Module	4
6.2	Uses	4
6.3	Syntax	4
6.3.1	Exported Constants	4
6.4	Exported Types	4
6.4.1	Exported Access Programs	4
6.5	Semantics	4
6.5.1	State Variables	4
6.5.2	Environment Variables	4
6.5.3	Assumptions	4
6.5.4	Access Routine Semantics	5
6.5.5	Local Functions	5
7	MIS of Load From File System	6
7.1	Module	6
7.2	Uses	6
7.3	Syntax	6
7.3.1	Exported Constants	6
7.4	Exported Types	6
7.4.1	Exported Access Programs	6
7.5	Semantics	6
7.5.1	State Variables	6
7.5.2	Environment Variables	6
7.5.3	Assumptions	6
7.5.4	Access Routine Semantics	7
7.5.5	Local Functions	7

8	MIS of Calculation Call	8
8.1	Module	8
8.2	Uses	8
8.3	Syntax	8
8.3.1	Exported Constants	8
8.4	Exported Types	8
8.4.1	Exported Access Programs	8
8.5	Semantics	9
8.5.1	State Variables	9
8.5.2	Environment Variables	9
8.5.3	Assumptions	9
8.5.4	Access Routine Semantics	9
8.5.5	Local Functions	9
9	MIS of Truck Platoon Configuration Data Format	14
9.1	Module	14
9.2	Uses	14
9.3	Syntax	14
9.3.1	Exported Constants	14
9.4	Exported Types	14
9.4.1	Exported Access Programs	14
9.5	Semantics	14
9.5.1	State Variables	14
9.5.2	Environment Variables	15
9.5.3	Assumptions	15
9.5.4	Access Routine Semantics	15
9.5.5	Local Functions	16
10	MIS of Bridge Configuration Data Format	17
10.1	Module	17
10.2	Uses	17
10.3	Syntax	17
10.3.1	Exported Constants	17
10.4	Exported Types	17
10.4.1	Exported Access Programs	17
10.5	Semantics	17
10.5.1	State Variables	17
10.5.2	Environment Variables	18
10.5.3	Assumptions	18
10.5.4	Access Routine Semantics	18
10.5.5	Local Functions	19

11 MIS of Solver Configuration Data Format	20
11.1 Module	20
11.2 Uses	20
11.3 Syntax	20
11.3.1 Exported Constants	20
11.4 Exported Types	20
11.4.1 Exported Access Programs	20
11.5 Semantics	20
11.5.1 State Variables	20
11.5.2 Environment Variables	20
11.5.3 Assumptions	21
11.5.4 Access Routine Semantics	21
11.5.5 Local Functions	21
12 MIS of Report Data Format	22
12.1 Module	22
12.2 Uses	22
12.3 Syntax	22
12.3.1 Exported Constants	22
12.4 Exported Types	22
12.4.1 Exported Access Programs	22
12.5 Semantics	22
12.5.1 State Variables	22
12.5.2 Environment Variables	22
12.5.3 Assumptions	22
12.5.4 Access Routine Semantics	23
12.5.5 Local Functions	23
13 MIS of Truck Platoon Configuration Save To File System Visualization	24
13.1 Module	24
13.2 Uses	24
13.3 Syntax	24
13.3.1 Exported Constants	24
13.4 Exported Types	24
13.4.1 Exported Access Programs	24
13.5 Semantics	24
13.5.1 State Variables	24
13.5.2 Environment Variables	24
13.5.3 Assumptions	24
13.5.4 Access Routine Semantics	25
13.5.5 Local Functions	25

14 MIS of Bridge Configuration Save To File System Visualization	26
14.1 Module	26
14.2 Uses	26
14.3 Syntax	26
14.3.1 Exported Constants	26
14.4 Exported Types	26
14.4.1 Exported Access Programs	26
14.5 Semantics	26
14.5.1 State Variables	26
14.5.2 Environment Variables	26
14.5.3 Assumptions	26
14.5.4 Access Routine Semantics	27
14.5.5 Local Functions	27
15 MIS of Solver Configuration Save To File System Visualization	28
15.1 Module	28
15.2 Uses	28
15.3 Syntax	28
15.3.1 Exported Constants	28
15.4 Exported Types	28
15.4.1 Exported Access Programs	28
15.5 Semantics	28
15.5.1 State Variables	28
15.5.2 Environment Variables	28
15.5.3 Assumptions	28
15.5.4 Access Routine Semantics	29
15.5.5 Local Functions	29
16 MIS of Output Report Save To File System Visualization	30
16.1 Module	30
16.2 Uses	30
16.3 Syntax	30
16.3.1 Exported Constants	30
16.4 Exported Types	30
16.4.1 Exported Access Programs	30
16.5 Semantics	30
16.5.1 State Variables	30
16.5.2 Environment Variables	30
16.5.3 Assumptions	30
16.5.4 Access Routine Semantics	31
16.5.5 Local Functions	31

17 MIS of Truck Platoon Configuration Load From File System Visualization	32
17.1 Module	32
17.2 Uses	32
17.3 Syntax	32
17.3.1 Exported Constants	32
17.4 Exported Types	32
17.4.1 Exported Access Programs	32
17.5 Semantics	32
17.5.1 State Variables	32
17.5.2 Environment Variables	32
17.5.3 Assumptions	32
17.5.4 Access Routine Semantics	33
17.5.5 Local Functions	33
18 MIS of Bridge Configuration Load From File System Visualization	34
18.1 Module	34
18.2 Uses	34
18.3 Syntax	34
18.3.1 Exported Constants	34
18.4 Exported Types	34
18.4.1 Exported Access Programs	34
18.5 Semantics	34
18.5.1 State Variables	34
18.5.2 Environment Variables	34
18.5.3 Assumptions	34
18.5.4 Access Routine Semantics	35
18.5.5 Local Functions	35
19 MIS of Solver Configuration Load From File System Visualization	36
19.1 Module	36
19.2 Uses	36
19.3 Syntax	36
19.3.1 Exported Constants	36
19.4 Exported Types	36
19.4.1 Exported Access Programs	36
19.5 Semantics	36
19.5.1 State Variables	36
19.5.2 Environment Variables	36
19.5.3 Assumptions	36
19.5.4 Access Routine Semantics	37
19.5.5 Local Functions	37

20 MIS of Truck Platoon Configuration Visualization	38
20.1 Module	38
20.2 Uses	38
20.3 Syntax	38
20.3.1 Exported Constants	38
20.4 Exported Types	38
20.4.1 Exported Access Programs	38
20.5 Semantics	38
20.5.1 State Variables	38
20.5.2 Environment Variables	38
20.5.3 Assumptions	39
20.5.4 Access Routine Semantics	39
20.5.5 Local Functions	40
21 MIS of Bridge Configuration Visualization	41
21.1 Module	41
21.2 Uses	41
21.3 Syntax	41
21.3.1 Exported Constants	41
21.4 Exported Types	41
21.4.1 Exported Access Programs	41
21.5 Semantics	41
21.5.1 State Variables	41
21.5.2 Environment Variables	41
21.5.3 Assumptions	42
21.5.4 Access Routine Semantics	42
21.5.5 Local Functions	43
22 MIS of Solver Configuration Visualization	44
22.1 Module	44
22.2 Uses	44
22.3 Syntax	44
22.3.1 Exported Constants	44
22.4 Exported Types	44
22.4.1 Exported Access Programs	44
22.5 Semantics	44
22.5.1 State Variables	44
22.5.2 Environment Variables	44
22.5.3 Assumptions	44
22.5.4 Access Routine Semantics	45
22.5.5 Local Functions	45

23 MIS of Calculation Call Visualization	46
23.1 Module	46
23.2 Uses	46
23.3 Syntax	46
23.3.1 Exported Constants	46
23.4 Exported Types	46
23.4.1 Exported Access Programs	46
23.5 Semantics	46
23.5.1 State Variables	46
23.5.2 Environment Variables	46
23.5.3 Assumptions	46
23.5.4 Access Routine Semantics	47
23.5.5 Local Functions	47
24 MIS of Output Report Visualization	48
24.1 Module	48
24.2 Uses	48
24.3 Syntax	48
24.3.1 Exported Constants	48
24.4 Exported Types	48
24.4.1 Exported Access Programs	48
24.5 Semantics	48
24.5.1 State Variables	48
24.5.2 Environment Variables	48
24.5.3 Assumptions	48
24.5.4 Access Routine Semantics	49
24.5.5 Local Functions	49

3 Introduction

The following document details the Module Interface Specifications for MTOBridge,

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at <https://github.com/agentvv/MTOBridge>.

4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol $:=$ is used for a multiple assignment statement and conditional rules follow the form $(c_1 \Rightarrow r_1 | c_2 \Rightarrow r_2 | \dots | c_n \Rightarrow r_n)$.

The following table summarizes the primitive data types used by MTOBridge.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	\mathbb{Z}	a number without a fractional component in $(-\infty, \infty)$
natural number	\mathbb{N}	a number without a fractional component in $[1, \infty)$
real number	\mathbb{R}	any number in $(-\infty, \infty)$

The specification of MTOBridge uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, MTOBridge uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

5 Module Decomposition

The following is taken directly from the Module Guide document for this project.

- **Hardware Hiding**
 - Data Storage Hiding
 - Input Data Storage Hiding
 - **Truck Platoon Configuration Data Storage Hiding**
 - **Bridge Configuration Data Storage Hiding**

- Calculation Data Storage Hiding
 - Calculation Variable Data Storage Hiding
 - **Solver Choice Data Storage Hiding**
 - **Concerned Section Specification Data Storage Hiding**
 - **Critical Section Specification Data Storage Hiding**
 - **Output Report Data Storage Hiding**
- File System Hiding
 - **Save To File System Hiding**
 - **Load From File System Hiding**
- **Software Decision Hiding**
 - **Calculation Call Hiding**
 - **MATLAB Code Hiding**
 - Data Format Hiding
 - Configuration Data Format Hiding
 - **Truck Platoon Configuration Data Format Hiding**
 - **Bridge Configuration Data Format Hiding**
 - **Solver Configuration Data Format Hiding**
 - **Report Data Format Hiding**
- **Behavior Hiding**
 - Visualization Hiding
 - Configuration Visualization Hiding
 - **Truck Platoon Configuration Visualization Hiding**
 - **Bridge Configuration Visualization Hiding**
 - Calculation Visualization Hiding
 - **Calculation Call Visualization Hiding**
 - **Solver Configuration Visualization Hiding**
 - **Output Report Visualization Hiding**
 - File System Visualization Hiding
 - Save To File System Visualization Hiding
 - **Truck Platoon Configuration Save To File System Visualization Hiding**
 - **Bridge Configuration Save To File System Visualization Hiding**
 - **Solver Configuration Save To File System Visualization Hiding**

- **Output Report Save To File System Visualization Hiding**
- Load From File System Visualization Hiding
- **Truck Platoon Configuration Load From File System Visualization Hiding**
- **Bridge Configuration Load From File System Visualization Hiding**
- **Solver Configuration Load From File System Visualization Hiding**

6 MIS of Save to File System

6.1 Module

Saver

6.2 Uses

[PlatoonConfiguration](#), [BridgeConfiguration](#), [SolverConfiguration](#), [Report](#)

6.3 Syntax

6.3.1 Exported Constants

None

6.4 Exported Types

None

6.4.1 Exported Access Programs

Name	In	Out	Exceptions
savePlatoonConfiguration	PlatoonT, string	-	-
saveBridgeConfiguration	BridgeT, string	-	-
saveSolverConfiguration	SolverT, string	-	-
saveReport	ReportT, string	-	-

6.5 Semantics

6.5.1 State Variables

None

6.5.2 Environment Variables

None

6.5.3 Assumptions

None

6.5.4 Access Routine Semantics

savePlatoonConfiguration(platoon, filepath)

- output: open outputFile at filepath for write and write each field of platoon to outputFile delineated by ", " in the following order: platoon.axleLoad as a string of space separated numbers, platoon.axleSpacing as a string of space separated numbers, number of trucks, headway Close outputFile.
- exception: none

saveBridgeConfiguration(bridge, filepath)

- output: open outputFile at filepath for write and write each field of bridge to outputFile delineated by ", " in the following order: bridge.numberSpans, bridge.spanLength as a string of space separated numbers, bridge.concernedSection, bridge.discretizationLength Close outputFile.
- exception: none

saveSolverConfiguration(solver, filepath)

- output: open outputFile at filepath for write and write each field of platoon to outputFile delineated by ", " in the following order: solver.forceType, solver.solverType Close outputFile.
- exception: none

saveReport(report, filepath)

- output: open outputFile at path for write. Write a header for the truck platoon configuration in the form "[Platoon]", then write all fields of truck platoon in the form of "field.name = field.value". Do the same for bridge and solver configurations, with their respective headers and fields. Then, write a header for the analysis in the form "[Results]". If the solver was configured for critical sections, write "critical section = value". Proceed to write out the pairs of first axle position and force, separated by commas and each pair separated by new lines. Close the output file.
- exception: none

6.5.5 Local Functions

None

7 MIS of Load From File System

7.1 Module

Loader

7.2 Uses

[PlatoonConfiguration](#), [BridgeConfiguration](#), [SolverConfiguration](#)

7.3 Syntax

7.3.1 Exported Constants

None

7.4 Exported Types

None

7.4.1 Exported Access Programs

Name	In	Out	Exceptions
loadPlatoonConfiguration	string	PlatoonT	-
loadBridgeConfiguration	string	BridgeT	-
loadSolverConfiguration	string	SolverT	-

7.5 Semantics

7.5.1 State Variables

None

7.5.2 Environment Variables

None

7.5.3 Assumptions

None

7.5.4 Access Routine Semantics

loadPlatoonConfiguration(platoon, filepath)

- output: open outputFile at filepath for read and read each field: Parse space separated \mathbb{R} until comma as axleLoad, parse next set of space separated \mathbb{R} until the next comma as axleSpacing, parse next \mathbb{N} as numberOfTrucks, parse last \mathbb{R} as headway. Close outputFile.
out := PlatoonT constructed from the parsed values above.
- exception: none

loadBridgeConfiguration(bridge, filepath)

- output: open outputFile at filepath for read and read each field: Parse first number as numberOfSpans, parse space separated \mathbb{R} until comma as spanLength, parse next \mathbb{R} as concernedSection, parse last \mathbb{R} as discretization length. Close outputFile.
out := BridgeT constructed from the parsed values above.
- exception: none

loadSolverConfiguration(solver, filepath)

- output: open outputFile at filepath for read and read each field: Parse first string until comma as solver.forceType, parse string after comma as solver.solverType Close outputFile.
out := SolverT constructed from the parsed values above.
- exception: none

7.5.5 Local Functions

None

8 MIS of Calculation Call

8.1 Module

CalculationCaller

8.2 Uses

[PlatoonConfiguration](#), [BridgeConfiguration](#), [SolverConfiguration](#), [Report](#)

8.3 Syntax

8.3.1 Exported Constants

None

8.4 Exported Types

CalculationInputT = {

truckConfig: TruckT,

bridgeConfig: BridgeT,

solverConfig: SolverT

}

CalculationOutputT = {

allForces: sequence of sequence of \mathbb{R} ,

firstAxlePosition: sequence of \mathbb{R} ,

forceConcernedSection: sequence of \mathbb{R} ,

forceCriticalSection: sequence of \mathbb{R} ,

maxForce: \mathbb{R} ,

firstAxlePositionMaxForce: \mathbb{R} ,

sections: sequence of \mathbb{R} ,

criticalSection: \mathbb{R} ,

forceEnvelope: sequence of \mathbb{R} ,

firstAxlePositionForceEnvelope: sequence of \mathbb{R}

}

8.4.1 Exported Access Programs

Name	In	Out	Exceptions
runCalculation	CalculationInputT	CalculationOutputT	-

8.5 Semantics

8.5.1 State Variables

None

8.5.2 Environment Variables

engine: an instance of the matlab engine which exports functions that run the relevant matlab code.

8.5.3 Assumptions

None

8.5.4 Access Routine Semantics

runCalculation(in):

- output: $out :=$
 $(in.solverConfig.solverType = CONCERNED \Rightarrow$
 $concernedSection(in) \mid$
 $in.solverConfig.solverType = CRITICAL \Rightarrow$
 $criticalSection(in)) \wedge$
 $report.updateReport(ReportT\{in, out\})$
- exception: none

8.5.5 Local Functions

concernedSection: $CalculationInputT \rightarrow CalculationOutputT$:

- output: $out :=$
 $(in.bridgeConfig.numberSpans = 1 \Rightarrow$
 $concernedSectionOneSpan(in) \mid$
 $in.bridgeConfig.numberSpans = 2 \Rightarrow$
 $concernedSectionTwoSpan(in) \mid$
 $in.bridgeConfig.numberSpans = 3 \Rightarrow$
 $concernedSectionThreeSpan(in))$
- exception: none

concernedSectionOneSpan: $CalculationInputT \rightarrow CalculationOutputT$:

- output: $out :=$
 $(in.solverConfig.forceType = POSITIVE_MOMENT \Rightarrow$
 $concernedSectionOneSpanMoment(in) \mid$

*in.solverConfig.forceType = SHEAR \Rightarrow
concernedSectionOneSpanShear(in)*

- exception: none

concernedSectionOneSpanMoment: *CalculationInputT \rightarrow CalculationOutputT:*

- output: *out := engine.Concerned_section_one_span_moment(in)*
- exception: none

concernedSectionOneSpanShear: *CalculationInputT \rightarrow CalculationOutputT*

- output: *out := engine.Concerned_section_one_span_shear(in)*
- exception: none

concernedSectionTwoSpan: *CalculationInputT \rightarrow CalculationOutputT*

- output: *out :=
(in.solverConfig.forceType = POSITIVE_MOMENT \Rightarrow
concernedSectionTwoSpanPositiveMoment(in) |
in.solverConfig.forceType = NEGATIVE_MOMENT \Rightarrow
concernedSectionTwoSpanNegativeMoment(in) |
in.solverConfig.forceType = SHEAR \Rightarrow
concernedSectionTwoSpanShear(in))*
- exception: none

concernedSectionTwoSpanPositiveMoment: *CalculationInputT \rightarrow CalculationOutputT*

- output: *out := engine.Concerned_section_two_span_moment(in)*
- exception: none

concernedSectionTwoSpanNegativeMoment: *CalculationInputT \rightarrow CalculationOutputT*

- output: *out := engine.Concerned_section_two_span_moment(in)*
- exception: none

concernedSectionTwoSpanShear: *CalculationInputT \rightarrow CalculationOutputT*

- output: *out := engine.Concerned_section_two_span_shear(in)*
- exception: none

concernedSectionThreeSpan: *CalculationInputT \rightarrow CalculationOutputT*

- output: $out :=$
 $(in.solverConfig.forceType = POSITIVE_MOMENT \Rightarrow$
 $concernedSectionThreeSpanPositiveMoment(in) \mid$
 $in.solverConfig.forceType = NEGATIVE_MOMENT \Rightarrow$
 $concernedSectionThreeSpanNegativeMoment(in) \mid$
 $in.solverConfig.forceType = SHEAR \Rightarrow$
 $concernedSectionThreeSpanShear(in))$
- exception: none

concernedSectionThreeSpanPositiveMoment: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Concerned_section_three_span_moment(in)$
- exception: none

concernedSectionThreeSpanNegativeMoment: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Concerned_section_three_span_moment(in)$
- exception: none

concernedSectionThreeSpanShear: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Concerned_section_three_span_shear(in)$
- exception: none

criticalSection: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out :=$
 $(in.bridgeConfig.numberSpans = 1 \Rightarrow$
 $criticalSectionOneSpan(in) \mid$
 $in.bridgeConfig.numberSpans = 2 \Rightarrow$
 $criticalSectionTwoSpan(in) \mid$
 $in.bridgeConfig.numberSpans = 3 \Rightarrow$
 $criticalSectionThreeSpan(in))$
- exception: none

criticalSectionOneSpan: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out :=$
 $(in.solverConfig.forceType = POSITIVE_MOMENT \Rightarrow$
 $criticalSectionOneSpanMoment(in) \mid$
 $in.solverConfig.forceType = SHEAR \Rightarrow$
 $criticalSectionOneSpanShear(in))$

- exception: none

criticalSectionOneSpanMoment: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Critical_section_one_span_moment(in)$
- exception: none

criticalSectionOneSpanShear: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := Critical_section_one_span_shear(in)$
- exception: none

criticalSectionTwoSpan: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out :=$
 $(in.solverConfig.forceType = POSITIVE_MOMENT) \Rightarrow$
 $criticalSectionTwoSpanPositiveMoment(in) \mid$
 $in.solverConfig.forceType = NEGATIVE_MOMENT) \Rightarrow$
 $criticalSectionTwoSpanNegativeMoment(in) \mid$
 $in.solverConfig.forceType = SHEAR \Rightarrow$
 $criticalSectionTwoSpanShear(in))$
- exception: none

criticalSectionTwoSpanPositiveMoment: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Critical_section_two_span_positive_moment(in)$
- exception: none

criticalSectionTwoSpanNegativeMoment: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Critical_section_two_span_negative_moment(in)$
- exception: none

criticalSectionTwoSpanShear: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out := engine.Critical_section_two_span_shear(in)$
- exception: none

criticalSectionThreeSpan: $CalculationInputT \rightarrow CalculationOutputT$

- output: $out :=$
 $(in.solverConfig.forceType = POSITIVE_MOMENT \Rightarrow$
 $criticalSectionThreeSpanPositiveMoment(in) \mid$
 $in.solverConfig.forceType = NEGATIVE_MOMENT) \Rightarrow$
 $criticalSectionThreeSpanNegativeMoment(in) \mid$
 $in.solverConfig.forceType = SHEAR \Rightarrow$
 $criticalSectionThreeSpanShear(in))$

- exception: none

criticalSectionThreeSpanPositiveMoment: $\text{CalculationInputT} \rightarrow \text{CalculationOutputT}$

- output: $\text{out} := \text{engine.Critical_section_three_span_positive_moment}(\text{in})$
- exception: none

criticalSectionThreeSpanNegativeMoment: $\text{CalculationInputT} \rightarrow \text{CalculationOutputT}$

- output: $\text{out} := \text{engine.Critical_section_three_span_negative_moment}(\text{in})$
- exception: none

criticalSectionThreeSpanShear: $\text{CalculationInputT} \rightarrow \text{CalculationOutputT}$

- output: $\text{out} := \text{engine.Critical_section_three_span_shear}(\text{in})$
- exception: none

9 MIS of Truck Platoon Configuration Data Format

9.1 Module

PlatoonConfiguration

9.2 Uses

None

9.3 Syntax

9.3.1 Exported Constants

None

9.4 Exported Types

PlatoonT = {
 axleLoad: sequence of \mathbb{R} ,
 axleSpacing: sequence of \mathbb{R} ,
 numberOfTrucks: \mathbb{N} ,
 headway: \mathbb{R}
}

9.4.1 Exported Access Programs

Name	In	Out	Exceptions
new PlatoonConfiguration	-	PlatoonConfiguration	-
getConfiguration	-	PlatoonT	invalidConfiguration
updateAxleLoad	string	-	invalidConfigurationValue
updateAxleSpacing	string	-	invalidConfigurationValue
updateNumberOfTrucks	string	-	invalidConfigurationValue
updateHeadway	string	-	invalidConfigurationValue

9.5 Semantics

9.5.1 State Variables

axleLoad: sequence of \mathbb{R} ,
axleSpacing: sequence of \mathbb{R} ,

numberOfTrucks: \mathbb{N} ,
headway: \mathbb{R}

9.5.2 Environment Variables

None

9.5.3 Assumptions

None

9.5.4 Access Routine Semantics

new PlatoonConfiguration():

- transition:
 axleLoad := empty sequence
 axleSpacing := empty sequence
 numberOfTrucks := 0
 headway := 0.0
- output: out := self
- exception: none

PlatoonT getConfiguration():

- output: out := PlatoonT { axleLoad, axleSpacing, numberOfTrucks, headway }
- exception:
 If axleLoad is empty sequence \Rightarrow invalidConfiguration
 If axleSpacing is empty sequence \Rightarrow invalidConfiguration
 If the size of axleSpacing is not size of axleLoad - 1 \Rightarrow invalidConfiguration
 If number of trucks is 0 \Rightarrow invalidConfiguration
 If headway is 0 \Rightarrow invalidConfiguration

updateAxleLoad(newAxleLoad):

- transition: Parse newAxleLoad as either comma separated or space separated sequence of \mathbb{R} greater than 0 of at least length 2. Set self.axleLoad to the parsed value of newAxleLoad.
- exception:
 If newAxleLoad has commas and spaces, or any of the numbers are parsed as being negative, or if the number of parsed numbers is 1 \Rightarrow invalidConfigurationValue
 If newAxleLoad has any characters other than 0-9, '.', ' ', \Rightarrow invalidConfigurationValue
 If newAxleLoad has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue

updateAxleSpacing(newAxleSpacing):

- transition: Parse newAxleSpacing as either comma separated or space separated sequence of \mathbb{R} greater than 0 of at least length 1. Set self.axleSpacing to the parsed value of newAxleSpacing.
- exception:
 - If newAxleSpacing has commas and spaces, or any of the numbers are parsed as being negative \Rightarrow invalidConfigurationValue
 - If newAxleSpacing has any characters other than 0-9, '.', ' ' \Rightarrow invalidConfigurationValue
 - If newAxleSpacing has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue

updateNumberOfTrucks(newNumberOfTrucks)

- transition: Parse newNumberOfTrucks as \mathbb{N} . Set self.numberOfTrucks to the parsed value of newNumberOfTrucks.
- exception:
 - If newAxleSpacing has any characters other than 0-9 \Rightarrow invalidConfigurationValue
 - If newAxleSpacing has only 0's \Rightarrow invalidConfigurationValue

updateHeadway(newHeadway)

- transition: Parse newHeadway as a \mathbb{R} greater than 0. Set self.headway to the parsed value of newHeadway.
- exception:
 - If newAxleSpacing has any characters other than 0-9 or '.' \Rightarrow invalidConfigurationValue
 - If newAxleSpacing has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue

9.5.5 Local Functions

None

10 MIS of Bridge Configuration Data Format

10.1 Module

BridgeConfiguration

10.2 Uses

None

10.3 Syntax

10.3.1 Exported Constants

None

10.4 Exported Types

BridgeT = {
 numberSpans: {1, 2, 3},
 spanLength: seq of \mathbb{R} ,
 concernedSection: \mathbb{R} ,
 discretizationLength: \mathbb{R} ,
}

10.4.1 Exported Access Programs

Name	In	Out	Exceptions
new BridgeConfiguration	-	BridgeConfiguration	-
getConfiguration	-	BridgeT	invalidConfiguration
updateNumberOfSpans	string	-	invalidConfigurationValue
updateSpanLength	string	-	invalidConfigurationValue
updateConcernedSection	string	-	invalidConfigurationValue
updateDiscretizationLength	string	-	invalidConfigurationValue

10.5 Semantics

10.5.1 State Variables

numberOfSpans: \mathbb{N}
spanLength: seq of \mathbb{R}

concernedSection: \mathbb{R}
discretizationLength: \mathbb{R}

10.5.2 Environment Variables

None

10.5.3 Assumptions

None

10.5.4 Access Routine Semantics

new BridgeConfiguration():

- transition:
 numberOfSpans := 0
 spanLength := empty sequence
 concernedSection := -1.0
 discretizationLength := 0.0
- output: out := self
- exception: none

BridgeT getConfiguration():

- output: out := BridgeT { numberOfSpans, spanLength, concernedSection, discretizationLength }.
- exception:
 numberOfSpans = 0 or spanLength = empty sequence or concernedSection = -1.0
 or discretizationLength = 0 \Rightarrow invalidConfiguration

updateNumberOfSpans(newNumberOfSpans):

- transition: Parse newNumberOfSpans as \mathbb{N} between 1 and 3 (inclusive). Set self.numberOfSpans to the parsed value of newNumberOfSpans.
- exception:
 If newAxleSpacing has any characters other than 1-3 \Rightarrow invalidConfigurationValue
 If newAxleSpacing is not a string with length less than 2 \Rightarrow invalidConfigurationValue

updateSpanLength(newSpanLength):

- transition: Parse newSpanLength as either comma separated or space separated sequence of \mathbb{R} greater than 0. Set self.axleLoad to the parsed value of newAxleLoad.
- exception:
 - If newAxleLoad has commas and spaces, or any of the numbers are parsed as being negative \Rightarrow invalidConfigurationValue
 - If newAxleLoad has any characters other than 0-9, '.', ' ', \Rightarrow invalidConfigurationValue
 - If newAxleLoad has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue
 - If newAxleLoad is parsed as a sequence of greater than 3 numbers \Rightarrow invalidConfigurationValue

updateConcernedSection(newConcernedSection)

- transition: Parse newConcernedSection as a \mathbb{R} greater than 0.
- exception:
 - If newConcernedSection has any characters other than 0-9 or '.' \Rightarrow invalidConfigurationValue
 - If newConcernedSection has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue

updateDiscretizationLength(newDiscretizationLength)

- transition: Parse newDiscretizationLength as a \mathbb{R} greater than 0.
- exception:
 - If newDiscretizationLength has any characters other than 0-9 or '.' \Rightarrow invalidConfigurationValue
 - If newDiscretizationLength has a '.' not followed by a 0-9 \Rightarrow invalidConfigurationValue

10.5.5 Local Functions

None

11 MIS of Solver Configuration Data Format

11.1 Module

SolverConfiguration

11.2 Uses

None

11.3 Syntax

11.3.1 Exported Constants

None

11.4 Exported Types

```
SolverT = {  
  forceType: {POSITIVE_MOMENT, NEGATIVE_MOMENT, SHEAR},  
  solverType: {CONCERNED, CRITICAL}  
}
```

11.4.1 Exported Access Programs

Name	In	Out	Exceptions
new SolverConfiguration	-	SolverConfiguration	-
getConfiguration	-	SolverT	-
updateForceType	string	-	invalidConfigurationValue
updateSolverType	string	-	invalidConfigurationValue

11.5 Semantics

11.5.1 State Variables

forceType: SolverT.forceType
solverType: SolverT.solverType

11.5.2 Environment Variables

None

11.5.3 Assumptions

None

11.5.4 Access Routine Semantics

new SolverConfiguration():

- transition:
forceType := POSITIVE_MOMENT
solverType := CONCERNED
- output: out := self
- exception: none

getConfiguration():

- transition: none
- output: out := SolverT { self.forceType, self.solverType }
- exception: none

updateForceType(newForceType):

- transition:
(newForceType = "Positive Moment" \Rightarrow forceType := POSITIVE_MOMENT |
newForceType = "Negative Moment" \Rightarrow forceType := NEGATIVE_MOMENT |
newForceType = "Shear" \Rightarrow forceType := SHEAR)
- exception: if newForceType is not one of the above strings \Rightarrow invalidConfigurationValue

updateSolverType(newSolverType):

- transition:
(newSolverType = "Concerned Section" \Rightarrow solverType := CONCERNED |
newSolverType = "Negative Moment" \Rightarrow solverType := CRITICAL)
- exception: if newSolverType is not one of the above strings \Rightarrow invalidConfigurationValue

11.5.5 Local Functions

None

12 MIS of Report Data Format

12.1 Module

Report

12.2 Uses

None

12.3 Syntax

12.3.1 Exported Constants

None

12.4 Exported Types

```
ReportT = {  
  input: CalculationInputT  
  results: CalculationOutputT  
}
```

12.4.1 Exported Access Programs

Name	In	Out	Exceptions
new Report	-	Report	-
getReport	-	ReportT	invalidReport
updateReport	ReportT	-	-

12.5 Semantics

12.5.1 State Variables

report: ReportT

12.5.2 Environment Variables

None

12.5.3 Assumptions

None

12.5.4 Access Routine Semantics

new Report():

- transition: report := NULL
- output: out := self
- exception: none

getReport():

- output: out := report
- exception: report = NULL \Rightarrow invalidReport

updateReport(ReportT newReport):

- transition: report := newReport
- exception: none

12.5.5 Local Functions

None

13 MIS of Truck Platoon Configuration Save To File System Visualization

13.1 Module

TruckSaver

13.2 Uses

[Saver](#), [PlatoonConfiguration](#)

13.3 Syntax

13.3.1 Exported Constants

None

13.4 Exported Types

None

13.4.1 Exported Access Programs

Name	In	Out	Exceptions
new TruckSaver	-	TruckSaver	-
buttonPressed	-	-	-

13.5 Semantics

13.5.1 State Variables

None

13.5.2 Environment Variables

None

13.5.3 Assumptions

None

13.5.4 Access Routine Semantics

new TruckSaver()

- output: out := TruckSaver
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select where to save the file. After the user selects a valid location and clicks save, the method shall call `PlatoonConfiguration().getConfiguration()` to get the current truck configuration. Then, the method shall call `savePlatoonConfiguration` with the parsed configuration and the filepath the user specified.
- exception: none

13.5.5 Local Functions

None

14 MIS of Bridge Configuration Save To File System Visualization

14.1 Module

BridgeSaver

14.2 Uses

[Saver](#), [BridgeConfiguration](#)

14.3 Syntax

14.3.1 Exported Constants

None

14.4 Exported Types

None

14.4.1 Exported Access Programs

Name	In	Out	Exceptions
new BridgeSaver	-	BridgeSaver	-
buttonPressed	-	-	-

14.5 Semantics

14.5.1 State Variables

None

14.5.2 Environment Variables

None

14.5.3 Assumptions

None

14.5.4 Access Routine Semantics

new BridgeSaver()

- output: out := BridgeSaver
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select where to save the file. After the user selects a valid location and clicks save, the method shall call BridgeConfiguration().getConfiguration() to get the current bridge configuration. Then, the method shall call saveBridgeConfiguration with the parsed configuration and the filepath the user specified.
- exception: none

14.5.5 Local Functions

None

15 MIS of Solver Configuration Save To File System Visualization

15.1 Module

SolverSaver

15.2 Uses

[Saver](#), [SolverConfiguration](#)

15.3 Syntax

15.3.1 Exported Constants

None

15.4 Exported Types

None

15.4.1 Exported Access Programs

Name	In	Out	Exceptions
new SolverSaver	-	SolverSaver	-
buttonPressed	-	-	-

15.5 Semantics

15.5.1 State Variables

None

15.5.2 Environment Variables

None

15.5.3 Assumptions

None

15.5.4 Access Routine Semantics

new SolverSaver()

- output: out := SolverSaver
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select where to save the file. After the user selects a valid location and clicks save, the method shall call SolverConfiguration().getConfiguration() to get the current solver configuration. Then, the method shall call saveSolverConfiguration with the parsed configuration and the filepath the user specified.
- exception: none

15.5.5 Local Functions

None

16 MIS of Output Report Save To File System Visualization

16.1 Module

ReportSaver

16.2 Uses

[Saver](#), [Report](#)

16.3 Syntax

16.3.1 Exported Constants

None

16.4 Exported Types

None

16.4.1 Exported Access Programs

Name	In	Out	Exceptions
new ReportSaver	-	ReportSaver	-
buttonPressed	-	-	-

16.5 Semantics

16.5.1 State Variables

None

16.5.2 Environment Variables

None

16.5.3 Assumptions

None

16.5.4 Access Routine Semantics

new ReportSaver()

- output: out := ReportSaver
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select where to save the file. After the user selects a valid location and clicks save, the method shall get the most recently generated output report with Report().getReport(). Then, the method shall call saveReport with the parsed report and the filepath the user specified.
- exception: none

16.5.5 Local Functions

None

17 MIS of Truck Platoon Configuration Load From File System Visualization

17.1 Module

TruckLoader

17.2 Uses

[Loader](#), [PlatoonConfiguration](#)

17.3 Syntax

17.3.1 Exported Constants

None

17.4 Exported Types

None

17.4.1 Exported Access Programs

Name	In	Out	Exceptions
new TruckLoader	-	TruckLoader	-
buttonPressed	-	-	-

17.5 Semantics

17.5.1 State Variables

None

17.5.2 Environment Variables

None

17.5.3 Assumptions

None

17.5.4 Access Routine Semantics

new ReportSaver()

- output: out := TruckLoader
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select the file containing the platoon configuration. After the user selects a file and clicks load, the method shall call loadPlatoonConfiguration() with the file specified by the user. Then, the method shall set the values of TruckConfiguration() with the respective values.
- exception: none

17.5.5 Local Functions

None

18 MIS of Bridge Configuration Load From File System Visualization

18.1 Module

BridgeLoader

18.2 Uses

[Loader](#), [BridgeConfiguration](#)

18.3 Syntax

18.3.1 Exported Constants

None

18.4 Exported Types

None

18.4.1 Exported Access Programs

Name	In	Out	Exceptions
new BridgeLoader	-	BridgeLoader	-
buttonPressed	-	-	-

18.5 Semantics

18.5.1 State Variables

None

18.5.2 Environment Variables

None

18.5.3 Assumptions

None

18.5.4 Access Routine Semantics

new BridgeLoader()

- output: `out := BridgeLoader`
- exception: none

buttonPressed()

- output: When the button is clicked, open a windows file dialog to select the file containing the bridge configuration. After the user selects a file and clicks load, the method shall call `loadBridgeConfiguration()` with the file specified by the user. Then, the method shall set the values of `BridgeConfiguration()` with the respective values.
- exception: none

18.5.5 Local Functions

None

19 MIS of Solver Configuration Load From File System Visualization

19.1 Module

SolverLoader

19.2 Uses

[Loader](#), [SolverConfiguration](#)

19.3 Syntax

19.3.1 Exported Constants

None

19.4 Exported Types

None

19.4.1 Exported Access Programs

Name	In	Out	Exceptions
new SolverLoader	-	SolverLoader	-
buttonPressed	-	-	-

19.5 Semantics

19.5.1 State Variables

None

19.5.2 Environment Variables

None

19.5.3 Assumptions

None

19.5.4 Access Routine Semantics

`new SolverLoader()`

- output: `out := SolverLoader`
- exception: none

`buttonPressed()`

- output: When the button is clicked, open a windows file dialog to select the file containing the solver configuration. After the user selects a file and clicks load, the method shall call `loadSolverConfiguration()` with the file specified by the user. Then, the method shall set the values of `SolverConfiguration()` with the respective values.
- exception: none

19.5.5 Local Functions

None

20 MIS of Truck Platoon Configuration Visualization

20.1 Module

PlatoonVisualizer

20.2 Uses

[PlatoonConfiguration](#)

20.3 Syntax

20.3.1 Exported Constants

None

20.4 Exported Types

None

20.4.1 Exported Access Programs

Name	In	Out	Exceptions
new PlatoonVisualizer	-	PlatoonVisualizer	-
setAxleLoad	-	-	invalidConfigurationValue
setAxleSpacing	-	-	invalidConfigurationValue
setNumberOfTrucks	-	-	invalidConfigurationValue
setHeadway	-	-	invalidConfigurationValue
visualize	-	-	invalidConfiguration

20.5 Semantics

20.5.1 State Variables

axleLoad: string

axleSpacing: string

numberOfTrucks: string

headway: string

20.5.2 Environment Variables

None

20.5.3 Assumptions

None

20.5.4 Access Routine Semantics

new PlatoonVisualizer()

- transition:
axleLoad := ""
axleSpacing := ""
numberOfTrucks := ""
headway := ""
- output: out := self
- exception: none

setAxleLoad()

- transition: Whenever the user updates the axleLoad line edit, set the axleLoad string to the value of the line edit. If the user presses enter, then call TruckConfiguration.updateAxleLoad(axleLoad).
- exception: TruckConfiguration.updateAxleLoad(axleLoad) could not parse axleLoad \Rightarrow invalidConfigurationValue

setAxleSpacing()

- transition: Whenever the user updates the axleSpacing line edit, set the axleSpacing string to the value of the line edit. If the user presses enter, then call TruckConfiguration.updateAxleSpacing(axleSpacing).
- exception: TruckConfiguration.updateAxleSpacing(axleSpacing) could not parse axleSpacing \Rightarrow invalidConfigurationValue

setNumberOfTrucks()

- transition: Whenever the user updates the numberOfTrucks line edit, set the numberOfTrucks string to the value of the line edit. If the user presses enter, then call TruckConfiguration.updateNumberOfTrucks(numberOfTrucks).
- exception: TruckConfiguration.updateNumberOfTrucks(numberOfTrucks) could not parse numberOfTrucks \Rightarrow invalidConfigurationValue

setHeadway()

- transition: Whenever the user updates the headway line edit, set the headway string to the value of the line edit. If the user presses enter, then call `TruckConfiguration.updateHeadway(headway)`.
- exception: `TruckConfiguration.updateHeadway(headway)` could not parse headway \Rightarrow `invalidConfigurationValue`

visualize()

- output: Call `TruckConfiguration.getConfig()`, and do the following with the result:
 - Draw truck based on `truck.axleSpacing`.
 - Then add an offset of `truck.headway`.
 - Do this `truck.numberOfTrucks` times.

Draw the fields for `axleLoad`, `axleSpacing`, `numberOfTrucks`, `headway` using the respective state variables as their values.

- exception: Calling `TruckConfiguration.getConfig()` yields `invalidConfiguration` exception \Rightarrow `invalidConfiguration`

20.5.5 Local Functions

None

21 MIS of Bridge Configuration Visualization

21.1 Module

BridgeVisualizer

21.2 Uses

[BridgeConfiguration](#)

21.3 Syntax

21.3.1 Exported Constants

None

21.4 Exported Types

None

21.4.1 Exported Access Programs

Name	In	Out	Exceptions
new BridgeVisualizer	-	BridgeVisualizer	-
setNumberOfSpans	-	-	invalidConfigurationValue
setSpanLength	-	-	invalidConfigurationValue
setConcernedSection	-	-	invalidConfigurationValue
setDiscretizationLength	-	-	invalidConfigurationValue
visualize	-	-	invalidConfiguration

21.5 Semantics

21.5.1 State Variables

numberOfSpans: string
spanLength: string
concernedSection: string
discretizationLength: string

21.5.2 Environment Variables

None

21.5.3 Assumptions

None

21.5.4 Access Routine Semantics

new BridgeVisualizer()

- transition:
 numberOfSpans := ""
 spanLength := ""
 concernedSection := ""
 discretizationLength := ""
- output: out := self
- exception: none

setNumberOfSpans()

- transition: Whenever the user updates the numberOfSpans field, set the numberOfFields string to the value of the field and call BridgeConfiguration.updateNumberOfSpans(numberOfSpans).
- exception: BridgeConfiguration.updateNumberOfSpans(numberOfSpans) could not parse numberOfSpans \Rightarrow invalidConfigurationValue

setSpanLength()

- transition: Whenever the user updates the spanLength line edit, set the spanLength string to the value of the line edit. If the user presses enter, then call BridgeConfiguration.updateSpanLength(spanLength).
- exception: BridgeConfiguration.updateSpanLength(spanLength) could not parse spanLength \Rightarrow invalidConfigurationValue

setConcernedSection()

- transition: Whenever the user updates the concernedSection line edit, set the concernedSection string to the value of the line edit. If the user presses enter, then call BridgeConfiguration.updateConcernedSection(concernedSection).
- exception: BridgeConfiguration.updateConcernedSection(concernedSection) could not parse concernedSection \Rightarrow invalidConfigurationValue

setDiscretizationLength()

- transition: Whenever the user updates the discretizationLength line edit, set the discretizationLength string to the value of the line edit. If the user presses enter, then call BridgeConfiguration.updateDiscretizationLength(discretizationLength).

- exception: `BridgeConfiguration.updateDiscretizationLength(discretizationLength)` could not parse `discretizationLength` \Rightarrow `invalidConfigurationValue`

visualize()

- output: Call `BridgeConfiguration.getConfig()`, and do the following with the result:
 - Draw bridge using `bridge.numberOfSpans` and `bridge.spanLength`.
 - If `bridge.discretizationLength` is defined, then draw the separate bridge sections of size `bridge.discretizationLength`.
 - If `bridge.sectionOfConcern` is defined, then show a vertical line at the position of `bridge.sectionOfConcern`.

Draw the input fields for `numberOfSpans`, `spanLength`, `concernedSection`, `discretizationLength` using the respective state variables as their values.

- exception: Calling `BridgeConfiguration.getConfig()` yields `invalidConfiguration` exception \Rightarrow `invalidConfiguration`

21.5.5 Local Functions

None

22 MIS of Solver Configuration Visualization

22.1 Module

SolverVisualizer

22.2 Uses

[SolverConfiguration](#)

22.3 Syntax

22.3.1 Exported Constants

None

22.4 Exported Types

None

22.4.1 Exported Access Programs

Name	In	Out	Exceptions
new SolverVisualizer	-	SolverVisualizer	-
setForceType	-	-	invalidConfigurationValue
setSolverType	-	-	invalidConfigurationValue
visualize	-	-	-

22.5 Semantics

22.5.1 State Variables

forceType: string
solverType: string

22.5.2 Environment Variables

None

22.5.3 Assumptions

None

22.5.4 Access Routine Semantics

new SolverVisualizer()

- transition:
forceType := ""
solverType := ""
- output: out := self
- exception: none

setForceType()

- transition: Whenever the user updates the forceType field, set the forceType string to the value of the field, and call SolverConfiguration.updateForceType(forceType).
- exception: SolverConfiguration.updateForceType(forceType) could not parse forceType \Rightarrow invalidConfigurationValue

setSolverType()

- transition: Whenever the user updates the solverType field, set the solverType string to the value of the field, and call SolverConfiguration.updateSolverType(solverType).
- exception: SolverConfiguration.updateSolverType(solverType) could not parse solverType \Rightarrow invalidConfigurationValue

visualize()

- output: Draw the input fields for forceType, solverType using the respective state variables as their values.
- exception: none

22.5.5 Local Functions

None

23 MIS of Calculation Call Visualization

23.1 Module

CalculationCallVisualizer

23.2 Uses

CalculationCall

23.3 Syntax

23.3.1 Exported Constants

None

23.4 Exported Types

None

23.4.1 Exported Access Programs

Name	In	Out	Exceptions
new CalculationCallVisualizer	-	CalculationCallVisualizer	-
buttonPressed	-	-	invalidConfiguration

23.5 Semantics

23.5.1 State Variables

None

23.5.2 Environment Variables

None

23.5.3 Assumptions

None

23.5.4 Access Routine Semantics

new CalculationCallVisualizer()

- transition: none
- output: out := self
- exception: none

buttonPressed()

- output: When the button to calculate is pressed, call CalculationCaller().runCalculation(CalculationI
TruckConfiguration.getConfig(), BridgeConfiguration.getConfig(), SolverConfiguration.getConfig()
).
- exception: if TruckConfiguration(), BridgeConfiguration() are invalid configurations
⇒ invalidConfiguration

23.5.5 Local Functions

None

24 MIS of Output Report Visualization

24.1 Module

ReportVisualizer

24.2 Uses

[Report](#)

24.3 Syntax

24.3.1 Exported Constants

None

24.4 Exported Types

None

24.4.1 Exported Access Programs

Name	In	Out	Exceptions
new ReportVisualizer	-	ReportVisualizer	-
visualize	-	-	invalidReport

24.5 Semantics

24.5.1 State Variables

None

24.5.2 Environment Variables

None

24.5.3 Assumptions

None

24.5.4 Access Routine Semantics

new ReportVisualizer()

- output: out := self
- exception: none

visualize()

- output: Call Report.getReport(). To visualize the ReportT, show each field of the input alongside its output. Then, to visualize the results, show a depiction of the truck platoon and bridge above a graph. The graph should have an x-axis of the first axle positions, and the y-axis should be the force at each first axle position. Also, there should be a vertical line where the critical/concerned section is on the bridge.
- exception: There is no report \Rightarrow invalidReport

24.5.5 Local Functions

None

References

- Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. *Fundamentals of Software Engineering*. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.
- Daniel M. Hoffman and Paul A. Strooper. *Software Design, Automated Testing, and Maintenance: A Practical Approach*. International Thomson Computer Press, New York, NY, USA, 1995. URL <http://citeseer.ist.psu.edu/428727.html>.