

1 introduction

The [VAR-SOM-MX6 Yocto Sumo release from Variscite](#) holds has a guide to follow for installation, but in previous and current releases have not been trivial to follow. The aim of here is to clarify the methods and to provide the necessary corrections made.

1.1 setup

The recommended first reading is largely unneeded from personal experience. At time of writing, it is unavailable. In addition, there is no "beginners guide" to the Yocto release for VAR-SOM-MX6 that

Note: When initializing, the variviki does not list the folder "build_x11". This will generally need to be added. This should be mentioned at relevant points, but in case one slips through, it is worth noting. Another frequent issue, is when running programs from current folder, there is a need to insert "./" in front of the path.

2 VAR-SOM-MX6 - Yocto Sumo 2.5 based on FSL Community BSP 2.5 with 4.9.88_2.0.0-ga Linux release

Information found on [variwiki under Yocto Sumo release guide](#). website

2.1 build x11 GUI demo image

The given commands throw an error with setup-environment. Adding a "./" as below works. Next is building the demo image using bitbake, excluding QT content.

```
$ cd ~/var-fslc-yocto
$ MACHINE=var-som-mx6 DISTRO=fslc-x11 . ./setup-environment build_x11
```

```
$ bitbake fsl-image-gui
```

Output in appendix [5.1](#).

2.2 console-only demo image

not built. should not pose new issue beyond the GUI. GUI image is enough.

2.3 local conf customization

2.3.1 change download directory.

It is implied already in directory /home/user/var-fslc-yocto/ at execution make and set permission for a yocto download file:

change download path for the configuration file for yocto's build_x11 setup
→ the given link does not work. You need to add the directory for the build, making the addition ./build_x11/conf/local.conf.

```
$ sudo mkdir /opt/yocto_downloads
$ sudo chmod 777 /opt/yocto_downloads
```

```
$ sed -i 's/DL_DIR ?= "${BSPDIR}\/downloads/DL\_DIR = "\/opt\/yocto\_downloads/g
```

2.3.2 BuildResults

The resulting files should be located in: tmp/deploy/images/var-som-mx6
table layout of files on [web page](#)

2.4 create bootable SD card

2.4.1 SD structure. map of SD card structure after partitioning.

schematics on the [wiki](#).

5.2) Yocto pre-built The standard partition is not sensitive to SD size, nor does it include the install scripts. At time of writing, utilized extended version

Replace "sdX" with the right device name. This can be obtained by "dmesg" or "lsusb" or "ls /dev/sd*" command on your host Linux PC, after the SD card reader is inserted. Also notable, the partition containing the root file system is not named "rootfs" \$ sudo umount /dev/sdX*

```
# For GUI-X11 & Qt5-X11
$ cd /var-fslc-yocto/build_x11
```

```
# For fsl-image-gui image (GUI-X11) $ zcat tmp/deploy/images/var-som-mx6/fsl-image-gui-var-som-mx6.wic.gz — sudo dd of=/dev/sdX bs=1M && sync
```

5.3) Create extended SD card This is a variscite partition shell script "var-create-yocto-sdcard.sh" which partitions the card and installs necessary files for NAND flash.

An issue that popped up, was the bash "rename" command. running a "sudo apt-get install rename" fixed issue.

```
$ cd /var-fslc-yocto $ sudo MACHINE=var-som-mx6 sources/meta-variscite-fslc/scripts/var_mk_yocto_sdcard/var-create-yocto-sdcard.sh ;options; /dev/sdX
(Replace /dev/sdX with your actual device)
options: -h Display help message -s Only show partition sizes to be written,
```

without actually write them -a Automatically set the rootfs partition size to fill the SD card -r Select alternative rootfs for recovery images (default: build_x11/tmp/deploy/images/var-som-mx6/fsl-image-gui-var-som-mx6.*)
output in appendix

2.5 Boot board through SD card

- 6.1) Setting boot mode. 6.1.1 has instructions for MX6 custom board.
- 6.2) Automatic device tree selection in U-boot. Default enabled.

2.6 Flash images to NAND

See section 3.

3 Yocto NAND Flash Burning

3.1 Introduction

VAR-SOM-MX6 boots from on-SOM NAND flash. U-boot, kernel image and device tree blob are also stored in NAND flash.

3.2 NAND flash structure

defined MTD partitions on NAND flash:

```
0x0000000000000000-0x0000000200000 : "spl"  
0x00000002000000-0x0000000400000 : "bootloader"  
0x00000004000000-0x0000000c00000 : "kernel"  
0x0000000c000000-End : "rootfs"
```

3.3 eMMC structure

Not explored.

3.4 Yocto built binaries for NAND flash

Images generated for NAND flash are located in "tmp/deploy/images/var-som-mx6". There is a table showing the expected files on the [variwiki site](#)

3.5 installing Yocto binaries

If followed extended SD card creation, NAND flash scripts are already included on the SD card.

3.5.1 images location

3.5.2 Preparing images for NAND flash

Note: the extended SD card creation makes these steps redundant. The SD card should be mounted on the host computer. Assumed mount directory is `"/media/rootfs/"`. If mounted into another folder, modify accordingly.

setup:

```
$ export YOCTO_IMGS_PATH=~/.var-fslc-yocto/build-x11/tmp/deploy/images/var-som-mx6
$ export P2_MOUNT_DIR=/media/rootfs/
$ sudo mkdir -p ${P2_MOUNT_DIR}/opt/images/Yocto/
```

Linux:

```
$ sudo cp ${YOCTO_IMGS_PATH}/uImage ${P2_MOUNT_DIR}/opt/images/Yocto/
```

Device tree:

```
$ sudo cp ${YOCTO_IMGS_PATH}/uImage-imx*.dtb ${P2_MOUNT_DIR}/opt/images/Yocto/
```

NAND images:

SPL:

```
$ sudo cp ${YOCTO_IMGS_PATH}/SPL-nand ${P2_MOUNT_DIR}/opt/images/Yocto/
```

U-Boot:

```
$ sudo cp ${YOCTO_IMGS_PATH}/u-boot.img-nand ${P2_MOUNT_DIR}/opt/images/Yocto/
```

File System:

```
$ sudo cp ${YOCTO_IMGS_PATH}/fsl-image-gui-var-som-mx6.ubi ${P2_MOUNT_DIR}/opt/images/Yocto/
```

Other images on wiki.

3.6 installing Yocto binaries

When accessing board on linux, minicom needed to disable flow control in order to make any input.

3.6.1 Images locations

directory structure on SD card

```
/opt/images/
  Yocto
    SPL-nand
    SPL-sd
    imx6dl-var-som-cap.dtb
    imx6dl-var-som-res.dtb
    imx6dl-var-som-solo-cap.dtb
    imx6dl-var-som-solo-res.dtb
```

```

imx6dl-var-som-solo-vsc.dtb
imx6dl-var-som-vsc.dtb
imx6q-var-dart.dtb
imx6q-var-som-cap.dtb
imx6q-var-som-res.dtb
imx6q-var-som-vsc.dtb
imx6qp-var-som-cap.dtb
imx6qp-var-som-res.dtb
imx6qp-var-som-vsc.dtb
rootfs.tar.gz
rootfs\_128kbpeb.ubi
rootfs\_256kbpeb.ubi
u-boot.img-nand
u-boot.img-sd
uImage

```

3.6.2 preparing images for NAND flash

with standard SD card setup, need to add necessary files. With the standard setup, filenames are not standard. mounted on /media/rootfs. `ls` guide assumes this is files structure. `pwd` on minicom returns /home/root. Probably same function, but name will differ from guide.

NOTE include minicom options and short intro.

Further on in the recipe, the call of `sudo cp YOCTO_IMGS_PATH/fsl-image-gui-var-som-mx6.ubi` lacks a designator of size in the filename. Appended `_128kbpeb` to filename before `.ubi`.

on the board, run: `export YOCTO_IMGS_PATH = /var - fs - yocto/build_x11/tmp/deploy/images/var-som-mx6`

`export P2_MOUNT_DIR=/media/rootfs/ sudo mkdir -p P2_MOUNT_DIR/opt/images/Yocto/`

On computer: linux: `$ sudo cp YOCTO_IMGS_PATH/uImageP2_MOUNT_DIR/opt/images/Yocto/`

Device tree: `$ sudo cp YOCTO_IMGS_PATH/uImage-imx*.dtbP2_MOUNT_DIR/opt/images/Yocto/`

NAND images: SPL: `$ sudo cp YOCTO_IMGS_PATH/SPL-nandP2_MOUNT_DIR/opt/images/Yocto/`

U-Boot: `$ sudo cp YOCTO_IMGS_PATH/u-boot.img-nandP2_MOUNT_DIR/opt/images/Yocto/`

File System: Here, there is a discrepancy with the name of the image. Need to append what seems like a memory string to name, so: `"$ sudo cp YOCTO_IMGS_PATH/fsl-image-gui-var-som-mx6.ubiP2_MOUNT_DIR/opt/images/Yocto/rootfs.ubi"`

becomes `$ sudo cp YOCTO_IMGS_PATH/fsl-image-gui-var-som-mx6_128kbpeb.ubiP2_MOUNT_DIR/opt/images/Yocto/rootfs.ubi`

3.7 Flashing scripts

Located: `"/usr/bin/install_yocto.sh"`

Further on would be to flash onto the board, but this is not a priority at this moment. The main goal now is to get the toolchain up and running.

4 Yocto toolchain installation for out of Yocto builds

4.1 prerequisites

A full Yocto OpenEmbedded environment to generate the toolchain. This means following steps 1 and 3 from the guide to [building yocto from source code](#).

4.2 Build toolchain

run the following code, where the text from the wiki: setup-environment is replaced by ./setup-environment:

```
$ cd ~/var-fslc-yocto
$ MACHINE=var-som-mx6 DISTRO=fslc-x11 . ./setup-environment build_x11

$ bitbake meta-ide-support
$ bitbake meta-toolchain
```

Output can be found in appendix ?? Then run the Tool chain build, output at [5.2](#)

4.3 Build complete SDK

build development environment with the required libraries in addition to the basic toolchain. runoutput in appendix ?? Output will be located in tmp/deploy/sdk/.

5 appendix

5.1 bitbake of fslc image

```
bitbake fsl-image-gui
WARNING: Host distribution "ubuntu-18.04" has not been validated with this version
Parsing recipes: 100% |#####
Parsing of 2471 .bb files complete (0 cached, 2471 parsed). 3374 targets, 209 skipped
NOTE: Resolving any missing task queue dependencies
```

```
Build Configuration:
BB_VERSION           = "1.38.0"
BUILD_SYS            = "x86_64-linux"
NATIVELSBSTRING      = "universal"
TARGET_SYS           = "arm-fslc-linux-gnueabi"
MACHINE              = "var-som-mx6"
DISTRO               = "fslc-x11"
DISTRO_VERSION       = "2.5"
TUNE_FEATURES        = "arm armv7a vfp thumb neon callconvention-hard"
```

```

TARGET_FPU          = "hard"
meta
meta-poky            = "HEAD:5887f81bb585d0a697b91daf7f7dd6ccb1d444e2"
meta-oe
meta-multimedia      = "HEAD:b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-freescale       = "HEAD:50fbef4593f79949ab6c67b2582d8b5c8b24838a"
meta-freescale-3rdparty = "HEAD:42c913b8fd266f72950a9ce305d316c0ecb64343"
meta-freescale-distro = "HEAD:f7e2216e93aff14ac32728a13637a48df436b7f4"
meta-browser         = "HEAD:d807b901b0b68b478093964bd60a77b9376b3f12"
meta-gnome
meta-networking
meta-python          = "HEAD:b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-qt5             = "HEAD:4b96f70a083eacfc4ff4a45d4efbb2d131f88c82"
meta-swupdate        = "HEAD:dae0d3e906e764e02a8b6357e7698bfde278fa6e"
meta-variscite-fslc  = "HEAD:d1aab80e20b92d3fbef64b8368e050d0aec6587a"

```

```

Initialising tasks: 100% |#####
NOTE: Executing SetScene Tasks
NOTE: Executing RunQueue Tasks
NOTE: Tasks Summary: Attempted 8113 tasks of which 8067 didn't need to be rerun
NOTE: Writing buildhistory

```

Summary: There was 1 WARNING message shown.

5.2 bitbake of toolchain

output from build of IDE support:

```

bitbake meta-ide-support
WARNING: Host distribution "ubuntu-18.04" has not been validated with this version
Parsing recipes: 100% |#####
Parsing of 2471 .bb files complete (0 cached, 2471 parsed). 3374 targets, 209 skipped
NOTE: Resolving any missing task queue dependencies

```

```

Build Configuration:
BB_VERSION          = "1.38.0"
BUILD_SYS           = "x86_64-linux"
NATIVELSBSTRING     = "universal"
TARGET_SYS          = "arm-fslc-linux-gnueabi"
MACHINE             = "var-som-mx6"
DISTRO              = "fslc-x11"
DISTRO_VERSION       = "2.5"
TUNE_FEATURES        = "arm armv7a vfp thumb neon callconvention-hard"
TARGET_FPU          = "hard"
meta
meta-poky            = "HEAD:5887f81bb585d0a697b91daf7f7dd6ccb1d444e2"
meta-oe

```

```

meta-multimedia      = "HEAD: b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-freescale       = "HEAD: 50fbef4593f79949ab6c67b2582d8b5c8b24838a"
meta-freescale-3rdparty = "HEAD: 42c913b8fd266f72950a9ce305d316c0ecb64343"
meta-freescale-distro = "HEAD: f7e2216e93aff14ac32728a13637a48df436b7f4"
meta-browser         = "HEAD: d807b901b0b68b478093964bd60a77b9376b3f12"
meta-gnome
meta-networking
meta-python          = "HEAD: b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-qt5             = "HEAD: 4b96f70a083eacfc4ff4a45d4efbb2d131f88c82"
meta-swupdate        = "HEAD: dae0d3e906e764e02a8b6357e7698bfde278fa6e"
meta-variscite-fslc  = "HEAD: d1aab80e20b92d3fbef64b8368e050d0aec6587a"

```

```

Initialising tasks: 100% |#####
NOTE: Executing SetScene Tasks
NOTE: Executing RunQueue Tasks
NOTE: Tasks Summary: Attempted 1298 tasks of which 1246 didn't need to be rerun
NOTE: Writing buildhistory

```

Summary: There was 1 WARNING message shown.

output from toolchain build:

```

bitbake meta-toolchain
WARNING: Host distribution "ubuntu-18.04" has not been validated with this version
Loading cache: 100% |#####
Loaded 3373 entries from dependency cache.
Parsing recipes: 100% |#####
Parsing of 2471 .bb files complete (2470 cached, 1 parsed). 3374 targets, 209 skipped
NOTE: Resolving any missing task queue dependencies

```

Build Configuration:

```

BB_VERSION           = "1.38.0"
BUILD_SYS            = "x86_64-linux"
NATIVELSBSTRING     = "universal"
TARGET_SYS           = "arm-fslc-linux-gnueabi"
MACHINE              = "var-som-mx6"
DISTRO               = "fslc-x11"
DISTRO_VERSION       = "2.5"
TUNE_FEATURES        = "arm armv7a vfp thumb neon callconvention-hard"
TARGET_FPU           = "hard"
meta
meta-poky            = "HEAD: 5887f81bb585d0a697b91daf7f7dd6ccb1d444e2"
meta-oe
meta-multimedia      = "HEAD: b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-freescale       = "HEAD: 50fbef4593f79949ab6c67b2582d8b5c8b24838a"
meta-freescale-3rdparty = "HEAD: 42c913b8fd266f72950a9ce305d316c0ecb64343"
meta-freescale-distro = "HEAD: f7e2216e93aff14ac32728a13637a48df436b7f4"

```



```

meta-browser          = "HEAD:d807b901b0b68b478093964bd60a77b9376b3f12"
meta-gnome
meta-networking
meta-python           = "HEAD:b0950aef5b630256bb5e25ca15f4d59c115e7c1"
meta-qt5              = "HEAD:4b96f70a083eacfc4ff4a45d4efbb2d131f88c82"
meta-swupdate         = "HEAD:dae0d3e906e764e02a8b6357e7698bfde278fa6e"
meta-variscite-fslc   = "HEAD:d1aab80e20b92d3fbef64b8368e050d0aec6587a"

```

```

Initialising tasks: 100% |#####
NOTE: Executing SetScene Tasks
NOTE: Executing RunQueue Tasks
WARNING: nativesdk-bzip2-1.0.6-r5 do_fetch: Checksum mismatch for local file /op
Cleaning and trying again.
WARNING: nativesdk-bzip2-1.0.6-r5 do_fetch: Renaming /opt/yocto_downloads/bzip2-
WARNING: nativesdk-bzip2-1.0.6-r5 do_fetch: Checksum failure encountered with do
WARNING: nativesdk-shadow-4.2.1-r0 do_fetch: Failed to fetch URL http://pkg-shad
WARNING: meta-toolchain-1.0-r7 do_populate_sdk: The postinstall intercept hook '
NOTE: Tasks Summary: Attempted 3156 tasks of which 1586 didn't need to be rerun
NOTE: Writing buildhistory

```

Summary: There were 6 WARNING messages shown.

5.2.1 bild SDK

```

bitbake -c populate_sdk fsl-image-gui
WARNING: Host distribution "ubuntu-18.04" has not been validated with this versio
Loading cache: 100% |#####
Loaded 3373 entries from dependency cache.
Parsing recipes: 100% |#####
Parsing of 2471 .bb files complete (2470 cached, 1 parsed). 3374 targets, 209 sk
NOTE: Resolving any missing task queue dependencies

```

Build Configuration:

```

BB_VERSION            = "1.38.0"
BUILD_SYS             = "x86_64-linux"
NATIVELSBSTRING       = "universal"
TARGET_SYS            = "arm-fslc-linux-gnueabi"
MACHINE               = "var-som-mx6"
DISTRO                = "fslc-x11"
DISTRO_VERSION        = "2.5"
TUNE_FEATURES         = "arm armv7a vfp thumb neon callconvention-hard"
TARGET_FPU            = "hard"
meta
meta-poky              = "HEAD:5887f81bb585d0a697b91daf7f7dd6ccb1d444e2"
meta-oe

```

```

meta-multimedia      = "HEAD: b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-freescale       = "HEAD: 50fbef4593f79949ab6c67b2582d8b5c8b24838a"
meta-freescale-3rdparty = "HEAD: 42c913b8fd266f72950a9ce305d316c0ecb64343"
meta-freescale-distro = "HEAD: f7e2216e93aff14ac32728a13637a48df436b7f4"
meta-browser         = "HEAD: d807b901b0b68b478093964bd60a77b9376b3f12"
meta-gnome
meta-networking
meta-python          = "HEAD: b0950aeff5b630256bb5e25ca15f4d59c115e7c1"
meta-qt5             = "HEAD: 4b96f70a083eacfc4ff4a45d4efbb2d131f88c82"
meta-swupdate        = "HEAD: dae0d3e906e764e02a8b6357e7698bfde278fa6e"
meta-variscite-fslc  = "HEAD: d1aab80e20b92d3fbef64b8368e050d0aec6587a"

```

```

Initialising tasks: 100% |#####
NOTE: Executing SetScene Tasks
NOTE: Executing RunQueue Tasks
WARNING: fsl-image-gui-1.0-r0 do_populate_sdk: The postinstall intercept hook 'u
NOTE: Tasks Summary: Attempted 7315 tasks of which 7314 didn't need to be rerun
NOTE: Writing buildhistory

```

Summary: There were 2 WARNING messages shown.