



LPS8 LoRaWAN Gateway User Manual

Document Version: 1.2.0

Firmware Version: LG02_LG08--build-v5.4.1590459021-20200526-1012

Version	Description	Date
1.0	Release	2019-Aug-10
1.0.1	Add trouble shooting for wifi AP not access issue	2019-Sep-23
1.0.2	Change the HTTP Port and SSH port for firmware version > v5.3	2019-Oct-26
1.1.0	Add more features such packet filter, remote access	2020-Mar-02
1.1.1	Polish network access description to make it clear	2020-Mar-16
1.2.0	Add TTN server explain, change to use new UI and firmware	2020-May-27

Table of Contents

1	Introduction.....	4
1.1	What is the LPS8.....	4
1.2	Specifications.....	5
1.3	Features.....	5
1.4	Hardware System Structure.....	6
1.5	LPS8 Applications	7
1.6	LED Indicators.....	7
2	Access and Configure LPS8.....	8
2.1	Find IP address of LPS8.....	8
2.1.1	Connect via WiFi	8
2.1.2	Connect via Ethernet with DHCP IP from router	8
2.1.3	Connect via WiFi with DHCP IP from router	9
2.1.4	Connect via Ethernet with fall back ip	9
2.2	Access Configure Web UI.....	10
3	Typical Network Setup	11
3.1	Overview	11
3.2	Use WAN port to access Internet.....	11
3.3	Access the Internet as a WiFi Client.....	12
3.4	Check Internet connection.....	12
4	Example: Configure as a LoRaWAN gateway	13
4.1	Create a gateway in TTN Server	14
4.2	Configure LPS8 to connect to TTN	16
4.3	Configure frequency	18
4.4	Add a LoRaWAN End Device	19
5	More features.....	21
5.1	Packet Filtering.....	21
5.2	Remote Access.....	21

5.3	How to decode ABP LoRaWAN node	21
5.4	How to set data to MQTT broker.....	21
5.5	More instructions	21
6	Linux System	22
6.1	SSH Access for Linux console	22
6.2	Edit and Transfer files.....	23
6.3	File System.....	23
6.4	Package maintenance system	24
7	Upgrade Linux Firmware	25
7.1	Upgrade via Web UI	25
7.2	Upgrade via Linux console.....	26
8	FAQ.....	27
8.1	How can I configure for a customized frequency band?.....	27
8.2	Can I make my own firmware for the gateway, Where can I find the source code?	27
8.3	Can I use 868Mhz version for 915Mhz bands?.....	27
9	Trouble Shooting.....	28
9.1	I get kernel error when install new package, how to fix?	28
9.2	How to recover the LPS8 if the firmware crashes.....	28
9.3	I configured LPS8 for WiFi access and lost its IP. What to do now?.....	29
9.4	I connect to the LPS8's SSID but LPS8 didn't assign DHCP IP to my laptop?	30
10	Order Info	31
11	Packing Info	32
12	Support.....	32
13	FCC Warning	32

1 Introduction


1.1 What is the LPS8

The LPS8 is an **open source** LoRaWAN Gateway. It lets you bridge LoRa wireless network to an IP network via **WiFi, Ethernet**. The LoRa wireless allows users to send data and reach extremely long ranges at low data-rates.

The LPS8 uses **Semtech packet forwarder** and fully compatible with LoRaWAN protocol. It includes a **SX1308 LoRa concentrator**, which provides 10 programmable parallel demodulation paths.

LPS8 has **pre-configured standard LoRaWAN frequency bands** to use for different countries. User can also **customized the frequency bands** to use in their own LoRa network.

LPS8 In a LoRaWAN IoT Network:



1.2 Specifications

Hardware System:

Linux Part:

- 400Mhz ar9331 processor
- 64MB RAM
- 16MB Flash

Interface:

- 10M/100M RJ45 Ports x 1
- WiFi : 802.11 b/g/n
- LoRaWAN Wireless
- Power Input: 5V DC, 2A, Type C
- USB 2.0 host connector x 1

WiFi Spec:

- IEEE 802.11 b/g/n
- Frequency Band: 2.4 ~ 2.462GHz
- Tx power:
 - ✓ 11n tx power : mcs7/15: 11db mcs0 : 17db
 - ✓ 11b tx power: 18db
 - ✓ 11g 54M tx power: 12db
 - ✓ 11g 6M tx power: 18db
- Wifi Sensitivity
 - ✓ 11g 54M : -71dbm
 - ✓ 11n 20M : -67dbm

LoRa Spec:

- Up to -140 dBm sensitivity with SX1257 Tx/Rx front-end
- 70 dB CW interferer rejection at 1 MHz offset
- Able to operate with negative SNR, CCR up to 9dB
- Emulates 49 x LoRa demodulators and 1 x (G)FSK demodulator
- Dual digital TX & RX radio front-end interfaces
- 10 programmable parallel demodulation paths
- Dynamic data-rate (DDR) adaptation
- True antenna diversity or simultaneous dual-band operation


1.3 Features

- ✓ Open Source OpenWrt system
- ✓ Managed by Web GUI, SSH via WAN or WiFi

- ✓ Remote access with Reverse-SSH
- ✓ Emulates 49x LoRa demodulators
- ✓ LoRaWAN Gateway
- ✓ 10 programmable parallel demodulation paths
- ✓ Pre-configure to support different LoRaWAN regional settings.
- ✓ Allow to customize LoRaWAN regional parameters.
- ✓ Support Local decode ABP end node info and transfer to MQTT server
- ✓ Support different level log in.

1.4 Hardware System Structure

LPS8 System Overview:







1.5 LPS8 Applications



1.6 LED Indicators

LPS8 has totally four LEDs, They are:

- **Power LED** : This **RED LED** will be **solid on** if the device is properly powered.
- **LoRa LED** : This **RGB LED** will **blink GREEN** when LoRaWAN module starts or transmit a packet.
- **SYS LED** : This **RGB LED** will shows different colors on different state:
 - ✓ **SOLID BLUE**: Device is alive with LoRaWAN server connection.
 - ✓ **BLINKING BLUE**: a) Device has internet connection but no LoRaWAN Connection. or b) Device is in booting stage, in this stage, it will **BLINKING BLUE** for several seconds and then with **SOLID RED** and **BLINKING BLUE** together
 - ✓ **SOLID RED**: Device doesn't have Internet connection.
- **ETH LED** : This LED shows the ETH interface connection status.

2 Access and Configure LPS8

The LPS8 is configured as a WiFi Access Point by factory default. You can access and configure the LPS8 after connecting to its WiFi network, or via its WAN Ethernet port.

2.1 Find IP address of LPS8

2.1.1 Connect via WiFi




At the first boot of LPS8, it will auto generate a WiFi network called **dragino-xxxxxx** with password:

dragino+dragino

You can use a PC to connect to this WiFi network. The PC will get an IP address 10.130.1.xxx and the LPS8 has the default IP **10.130.1.1**



2.1.2 Connect via Ethernet with DHCP IP from router



Alternatively, connect the LPS8 Ethernet port to your router and LPS8 can obtain an IP address from your router. In the router's management portal, you should be able to find what IP address the router has assigned to the LPS8. You can also use this IP to connect.

2.1.3 Connect via WiFi with DHCP IP from router



If the LPS8 already connect to the router via WiFi, use can use the WiFi IP to connect to LPS8.

2.1.4 Connect via Ethernet with fall back ip

The WAN port also has a [fall back ip address](#) for access if user doesn't connect to uplink router. Click [here to see how to configure.](#)

2.2 Access Configure Web UI

Web Interface

Open a browser on the PC and type in the LPS8 ip address (depends on your connect method)

<http://10.130.1.1/> (Access via WiFi AP network)

or


http://IP_ADDRESS or http://IP_ADDRESS:8000 (The web port has been changed to 8000 in **WAN interface**(WAN port or WiFi Client Mode) since firmware 5.3.xxx firmware)

You will see the login interface of LPS8 as shown below.

The account details for Web Login are:

User Name: root

Password: dragino



3 Typical Network Setup


3.1 Overview

The LPS8 supports flexible network set up for different environments. This section describes the typical network topology can be set in LPS8. The network set up includes:

- ✓ **WAN Port Internet Mode**
- ✓ **WiFi Client Mode**
- ✓ **WiFi AP Mode**

3.2 Use WAN port to access Internet

By default, the LPS8 is set to use the WAN port to connect to an upstream network. When you connect the LPS8's WAN port to an upstream router, LPS8 will get an IP address from the router and have Internet access via the upstream router. The network status can be checked as below:



3.3 Access the Internet as a WiFi Client.

In the WiFi Client Mode, LPS8 acts as a WiFi client and gets DHCP from an upstream router via WiFi.

The settings for WiFi Client is under page [System](#) → [WiFi](#) → [WiFi WAN Client Settings](#)

WiFi

Radio Settings

Channel (1-11)

11

Tx Power (0-18) dBm

17

WiFi Access Point Settings

Enable WiFi Access Point

WiFi Name SSID

dragino-1baf44

Passphrase (8-32 char)

Show

Encryption

WPA2

WiFi WAN Client Settings

Enable WiFi WAN Client

Host WiFi SSID

dragino-RD

Passphrase

Show

WiFi Survey

dragino-RD (Ch: 6 Enc

Encryption

WPA/WPA2

Save&Apply




Cancel


Refresh

In the WiFi Survey Choose the WiFi AP, and input the Passphrase then click Save & Apply to connect.

3.4 Check Internet connection

In the [Home](#) page, we can check the Internet connection.


- GREEN Tick  : This interface has Internet connection.
- Yellow Tick  : This interface has IP address but don't use it for internet connection.
- RED Cross  : This interface doesn't connected.



4 Example: Configure as a LoRaWAN gateway

LPS8 is fully compatible with LoRaWAN protocol. It uses the legacy Semtech Packet forwarder to forward the LoRaWAN packets to server. The structure is as below.

LPS8 In a LoRaWAN IoT Network:




This chapter describes how to use the LPS8 to work with

[TheThingsNetwork \(TTN\) LoRaWAN Server](http://www.thethingsnetwork.org) (www.thethingsnetwork.org)

4.1 Create a gateway in TTN Server

Step 1: Get a Unique gateway ID.

Every LPS8 has a unique gateway id. The ID can be found at LoRaWAN page:



LoRaWAN Configuration

Server Settings

LoRaWAN Service Provider: TTN-router-EU

Gateway ID: a840411b8268ffff

Server Port Upstream: 1700

Server Port Downstream: 1700

Latitude: 22.705177

Longitude: 114.243423

Email: dragino-1baf44@dragino.com


Packet Filter

Eport Filter: 0


Save&Apply Cancel

The example gateway id is: **a840411b8268ffff**


Step 2: Sign up a user account in TTN server



Step 3: Create a Gateway



Click on the Gateways icon to open the page below:



Notice: The TTN router should match the Frequency Plan you choose, otherwise you will have problem for End Node to join the network. If you don't which router you need to select, please check: https://www.thethingsnetwork.org/docs/gateways/packet-forwarder/semtech-udp.html#connect-a-gateway_server-addresses


After creating the gateway, you can see the gateway info, as below.



4.2 Configure LPS8 to connect to TTN

You can now configure the LPS8 to let it connect to TTN network.
Make sure your LPS8 has a working Internet Connection first.

Choose the right server provider and click [Save&Apply](#)




The screenshot shows the 'LoRaWAN Configuration' page. At the top is a navigation bar with tabs: LoRa, LoRaWAN, MQTT, TCP, HTTP, Custom, System, and Log. The 'LoRaWAN' tab is selected. Below the navigation bar is the 'LoRaWAN Configuration' section. Under 'Server Settings', there is a table with the following fields:

LoRaWAN Service Provider	TTN-router-EU		
Gateway ID	a840411b8268ffff	Latitude	22.705177
Server Port Upstream	1700	Longitude	114.243423
Server Port Downstream	1700		

Below the table is an 'Email' field with the value 'dragino-1baf44@dragino.com'. Under the 'Packet Filter' section, there is a 'Port Filter' field with the value '0'. At the bottom of the configuration section are two buttons: 'Save&Apply' and 'Cancel'.

Note: The server address must match the router you choose in TTN.


In the home page, we can see the LoRaWAN connection is ready now.




In TTN portal, we can also see the gateway is connected.

CONSOLE
COMMUNITY EDITION

Applications Gateways Su


Gateways >  eui-a840411b8268fff

Overview Traffic Settings

GATEWAY OVERVIEW  [settings](#)

Gateway ID eui-a840411b8268fff



Description Gateway-1

Owner  **edwin** [Transfer ownership](#)

Status connected

Frequency Plan Europe 868MHz

Router ttn-router-eu

Gateway Key  base64 


Last Seen 23 seconds ago

Received Messages 0


Transmitted Messages 0

4.3 Configure frequency

We also need to set the frequency plan in LPS8 to match the end node we use, so to receive the LoRaWAN packets from the LoRaWAN sensor.



In logread page, user can check the frequency actually used.



4.4 Add a LoRaWAN End Device

This section shows how to add a LoRaWAN End device to a LoRaWAN network and see the data from TTN web site.

We use [LT-22222-L](#) IO Controller as a reference device - the setup for other LoRaWAN devices will be similar.



Step 1: Create a Device definition in TTN with the OTAA keys from the example LT-33222-L IO Controller device.

Three codes are required to define the device in TTN:

- ✓ DEV EUI - Unique ID code for a particular device.
- ✓ APP EUI - ID code for an Application defined in TTN.
- ✓ APP Key - Unique key to secure communications with a particular device.

A set of these codes are stored in each device by the manufacturer as the default codes for that particular device. Each device is shipped with a sticker with the default Device EUI as shown below.




Note: You may be able to change these codes in a device by using a configuration facility on the device e.g. the LT-22222 uses a serial port access and a series of AT commands. Changing the codes may be necessary in the case where you have to use codes assigned by a LoRa WAN server.

For the TTN server, you can use the codes set in the device as in the following example.


Select **Add Application** to open the screen below.

Note that there is an APP EUI already created by TTN, but this is not the one set in the device. To add the APP EUI for the LT-2222-L device, select **Manage EUIs** and **Add EUI**, then enter the required code.



Select **Devices** and **Register Device** to open the screen below.

Enter the **Device EUI** and **APP KEY** codes, then select the App EUI from the list. Check that all three codes match those shown on the device label before saving the configuration.



Step 2: Power on LT-2222-L device and it will automatically join the TTN network. After joining successfully, it will start to upload messages to the TTN. Select the Data tab and you will see the data appearing in the panel.

Note that it may take some time for the device data to appear in the TTN display.

ONSOLE
MINI EDITION

Applications > dragino_test_application1 > Devices > It-33222-I-5362 > Data

Overview Data Settings

APPLICATION DATA || pause clear

Filters: uplink downlink activation ack error

time	counter	port		payload
16:54:53	0	2	retry	00 02 01 36 04 C1 04 C2 38
16:54:47			dev addr: 26 01 2C 6B	app eui: FCDEC9B2D32FA6 61 dev eui: A8 40 41 00
16:54:40			dev addr: 26 01 2C 85	app eui: FCDEC9B2D32FA6 61 dev eui: A8 40 41 00
16:54:33			dev addr: 26 01 2E EC	app eui: FCDEC9B2D32FA6 61 dev eui: A8 40 41 00

5 More features

5.1 Packet Filtering

Drop unwanted packets:

See http://wiki.dragino.com/index.php?title=Main_Page#Filter_unwanted_LoRaWAN_packets

5.2 Remote Access

Remote Access Devices for management:

Instruction

http://wiki.dragino.com/index.php?title=Main_Page#Remote_Access_Gateway_via_Reverse_SSH

5.3 How to decode ABP LoRaWAN node

Decode ABP

http://wiki.dragino.com/index.php?title=Communication_with_ABP_End_Node

5.4 How to set data to MQTT broker

Only support ABP LoRaWAN End Node

Instruction:

http://wiki.dragino.com/index.php?title=Main_Page#MQTT_Forward_Instruction

5.5 More instructions

http://wiki.dragino.com/index.php?title=Main_Page#LoRa.2FLoRaWAN_Gateway_Instruction

6 Linux System

The LPS8 is based on the OpenWrt Linux system. It is open source, and users are free to configure and modify the Linux settings.

6.1 SSH Access for Linux console

User can access the Linux console via the SSH protocol. Make sure your PC and the LPS8 are connected to the same network, then use a SSH tool (such as [putty](#) in Windows) to access it.


IP address: IP address of LPS8

Port: 22 or 2222 (SSH port in WAN interface has been change to 2222 since firmware 5.3.xx, for security reason)

User Name: **root**

Password: **dragino** (default)

After logging in, you will be in the Linux console and can enter commands as shown below.




```

10.130.2.1 - PuTTY
login as: root
root@10.130.2.1's password:

BusyBox v1.22.1 (2016-10-09 21:13:07 CST) built-in shell (ash)
Enter 'help' for a list of built-in commands.

DRAGINO
W i F i , L i n u x , M C U , E m b e d d e d
OpenWRT BARRIER BREAKER 14.07
Version: Dragino-v2 IoT-3.4.0
Build Mon Oct 10 08:53:00 CST 2016
www.dragino.com
-----
root@dragino-1347dc:~#
  
```

The “logread -f” command can be used to debug how system runs.



```

10.130.2.54 - SecureCRT
文件(F) 编辑(E) 查看(V) 选项(O) 传输(T) 脚本(S) 工具(L) 帮助(H)

10.130.2.54
wed May 27 05:14:59 2020 daemon.info lora_pkt_fwd[26351]: STAT~ {"stat":{"time":"2020-05-27 05:14:59 UTC","rxnb":0,"rxok":0,"rxfw":0,"ackr":0.0,
wed May 27 05:14:59 2020 daemon.info lora_pkt_fwd[26351]: INFO~ [up] PUSH_ACK received in 0 ms
wed May 27 05:15:01 2020 user.notice iot_keep_alive: Internet Access OK: via eth1
wed May 27 05:15:01 2020 user.notice iot_keep_alive: use WAN or WiFi for internet access now
wed May 27 05:15:06 2020 daemon.info lora_pkt_fwd[26351]: INFO~ [down] PULL_ACK received in 247 ms
wed May 27 05:15:11 2020 daemon.info lora_pkt_fwd[26351]: DATA_UNCONF_UP:{"DevAddr": "2CB9FB36", "Fctrl": ["ADR": 0, "ADRACKReq": 0, "ACK": 1, "F
: 1], "Fcnt": 60739, "Fport": 97, "MIC": "0E676560"}
wed May 27 05:15:11 2020 daemon.info lora_pkt_fwd[26351]: INFO~ [down] PULL_ACK received in 241 ms
wed May 27 05:15:16 2020 daemon.info lora_pkt_fwd[26351]: INFO~ [down] PULL_ACK received in 241 ms
wed May 27 05:15:16 2020 user.notice iot_keep_alive: Internet Access OK: via eth1
wed May 27 05:15:16 2020 user.notice iot_keep_alive: use WAN or WiFi for internet access now
wed May 27 05:15:21 2020 daemon.info lora_pkt_fwd[26351]: INFO~ [down] PULL_ACK received in 241 ms
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]:
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ ##### Report at: 2020-05-27 05:15:29 UTC #####
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ ### [UPSTREAM] ###
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ # RF packets received by concentrator: 1
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ # CRC_OK: 0.00%, CRC_FAIL: 100.00%, NO_CRC: 0.00%
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ # RF packets forwarded: 0 (0 bytes)
wed May 27 05:15:29 2020 daemon.info lora_pkt_fwd[26351]: REPORT~ # PUSH DATA datagrams sent: 0 (0 bytes)
  
```


6.2 Edit and Transfer files

The LPS8 supports the **SCP protocol** and has a built-in **SFTP server**. There are many ways to edit and transfer files using these protocols.

In Windows, one of the easiest methods is using the [WinSCP](#) utility.

After establishing access via WinSCP to the device, you can use an FTP style window to drag / drop files to the LPS8, or edit the files directly in the windows.

Screenshot is as below:



6.3 File System

The LPS8 has a 16MB flash and a 64MB RAM. The /var and /tmp directories are in the RAM, so contents stored in /tmp and /var will be erased after rebooting the device. Other directories are in the flash and will remain after reboot.

The Linux system uses around 8MB ~10MB flash size which means there is not much room for user to store data in the LPS8 flash.

You can use an external USB flash memory device to extend the size of flash memory for storage.

6.4 Package maintenance system

LPS8 uses the OpenWrt [OPKG package maintenance system](#). There are more than 3000+ packages available in our package server for users to install for their applications. For example, if you want to add the *iperf* tool, you can install the related packages and configure LPS8 to use *iperf*.

Below are some example *opkg* commands. For more information please refer to the [OPKG package maintain system](#) (<https://wiki.openwrt.org/doc/techref/opkg>)

In Linux Console run:

```
root@dragino-169d30:~# opkg update // to get the latest packages list
```

```
root@dragino-169d30:~# opkg list //shows the available packages
```

```
root@dragino-169d30:~# opkg install iperf // install iperf
```

The system will automatically install the required packages as shown below.

```
root@dragino-169d30:/etc/opkg# opkg install iperf
```

```
Installing iperf (2.0.12-1) to root...
```

```
Downloading http://downloads.openwrt.org/snapshots/packages/mips\_24kc/base/iperf\_2.0.12-1\_mips\_24kc.ipk
```

```
Installing uclibcxx (0.2.4-3) to root...
```

```
Downloading http://downloads.openwrt.org/snapshots/packages/mips\_24kc/base/uclibcxx\_0.2.4-3\_mips\_24kc.ipk
```

```
Configuring uclibcxx.
```

```
Configuring iperf.
```


7 Upgrade Linux Firmware

We keep improving the LPS8 Linux side firmware for new features and bug fixes. Below are the links for reference.

- **Latest firmware:** [LoRa Gateway Firmware](http://www.dragino.com/downloads/index.php?dir=LoRa_Gateway/LG02-OLG02/Firmware),
(http://www.dragino.com/downloads/index.php?dir=LoRa_Gateway/LG02-OLG02/Firmware)
- **Change Log:** [Firmware Change Log](http://www.dragino.com/downloads/downloads/LoRa_Gateway/LG02-OLG02/Firmware/ChangeLog).
(http://www.dragino.com/downloads/downloads/LoRa_Gateway/LG02-OLG02/Firmware/ChangeLog)

The file named as **xxxxx-xxxxx-squashfs-sysupgrade.bin** is the upgrade Image. There are different methods to upgrade, as below.


7.1 Upgrade via Web UI

Go to the page: **Web → System → Firmware Upgrade**

Select the required image and click **Flash Image**. The image will be uploaded to the device, and then click **Process Update** to upgrade.

NOTE: You normally need to **uncheck** the **Preserve Settings** checkbox when doing an upgrade to ensure that there is no conflict between the old settings and the new firmware. The new firmware will start up with its default settings.

The system will automatically boot into the new firmware after upgrade.



The screenshot shows the Dragino Web UI interface. At the top is a navigation bar with the Dragino logo and several menu items: LoRa, LoRaWAN, MQTT, TCP, HTTP, Custom, System, and LogRead. Below the navigation bar is the 'Firmware Update' section. It contains two main parts: 'Upload Firmware File' and 'Proceed with Flash'. The 'Upload Firmware File' section has a 'Choose File' button (which shows 'No file chosen') and an 'Upload' button (which shows 'Upload selected file.'). The 'Proceed with Flash' section displays a series of status messages in red and black text: '*** Sysupgrade starting now...', 'Configuration settings will be reset to Factory Default.', '*** Please allow 3 minutes to complete flash operation.', 'Time remaining: 171.', and 'Image metadata not found Commencing upgrade. All shell sessions will be closed now.'

7.2 Upgrade via Linux console

SCP the firmware to the system **/var** directory and then run

```
root@OpenWrt:~# /sbin/sysupgrade -n /var/Your_Image
```

NOTE: it is important to transfer the image in the /var directory, otherwise it may exceed the available flash size.

8 FAQ

8.1 How can I configure for a customized frequency band?

See below link for how to customize frequency band:

http://wiki.dragino.com/index.php?title=Customized_Frequency_Band_for_Gateway

8.2 Can I make my own firmware for the gateway, Where can I find the source code?

Yes, You can make your own firmware for the LPS8 for branding purposes or to add customized applications.

The source code and compile instructions can be found at:

https://github.com/dragino/openwrt_lede-18.06

8.3 Can I use 868Mhz version for 915Mhz bands?

It is possible but the distance will be very short, you can select US915 frequency band in 868Mhz version hardware. It will work but you will see the performance is greatly decreased because the 868Mhz version has an RF filter for band 863~870Mhz, all other frequencies will have high attenuation.

9 Trouble Shooting

9.1 I get kernel error when install new package, how to fix?

In some cases, when installing a package with **opkg**, it will generate a kernel error such as below due to a mismatch I the kernel ID:

```
root@dragino-16c538:~# opkg install kmod-dragino2-si3217x_3.10.49+0.2-1_ar71xx.ipk
Installing kmod-dragino2-si3217x (3.10.49+0.2-1) to root...
Collected errors:
* satisfy_dependencies_for: Cannot satisfy the following dependencies for kmod-dragino2-si3217x:
*   kernel (= 3.10.49-1-4917516478a753314254643facdf360a) *
* opkg_install_cmd: Cannot install package kmod-dragino2-si3217x.
```

In this case, you can use the `--force-depends` option to install such package as long as the actual kernel version is the same.


```
Opkg install kmod-dragino2-si3217x_3.10.49+0.2-1_ar71xx.ipk --force-depends
```

9.2 How to recover the LPS8 if the firmware crashes

Please follow this instruction to recover your gateway:

http://wiki.dragino.com/index.php?title=Recover_Gateway

9.3 I configured LPS8 for WiFi access and lost its IP. What to do now?




The LPS8 has a fall-back IP address on its WAN port. This IP is always enabled so you can use the fall-back IP to access LPS8 no matter what the WiFi IP is. The fall back IP is useful for connecting and debug the unit.

(Note: fallback IP can be disabled in the WAN and DHCP page)

Steps to connect via fall back IP:

1. Connect PC's Ethernet port to LG01's WAN port
2. Configure PC's Ethernet port has
IP: 172.31.255.253 and
Netmask: 255.255.255.252

As below photo:



3. In the PC, use IP address 172.31.255.254 to access the LPS8 via Web or Console. Please note the latest firmware uses port 8000 for http and 2222 for ssh access.

9.4 I connect to the LPS8's SSID but LPS8 didn't assign DHCP IP to my laptop?

This is a known bug for the firmware version before 2019-09-23 for LPS, the issue was fixed since version: LG02_LG08--build-v5.2.1569218466-20190923-1402.

In the old version, user can use the [fall back ip method](#) to access and configure the device.

10 Order Info

PART: LPS8-XXX-YYY:

XXX: Frequency Band

- **868**: valid frequency: 863Mhz ~ 870Mhz. for bands EU868, RU864, IN865 or KZ865.
- **915**: valid frequency: 902Mhz ~ 928Mhz. for bands US915, AU915, AS923 or KR920

11 Packing Info

Package Includes:

- ✓ LPS8 LoRaWAN Gateway x 1
- ✓ Stick Antenna for LoRa RF part. Frequency is one of 470 or 868 or 915Mhz depends the model ordered
- ✓ Packaging with environmental protection paper box

Dimension and weight:

- ✓ Device Size: 12 x 12 x 3 cm
- ✓ Weight: 187g
- ✓ Package Size: 14.5 x 13.5 x 6 cm
- ✓ Weight: 300g

12 Support

- Try to see if your questions already answered in the [wiki](#).
- Support is provided Monday to Friday, from 09:00 to 18:00 GMT+8.
Due to different timezones we cannot offer live support. However, your questions will be answered as soon as possible in the before mentioned schedule.
- Provide as much information as possible regarding your enquiry (product models, accurately describe your problem and steps to replicate it etc) and send a mail to:

support@dragino.com

13 FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation