

Example Response	{ "response_code":0 }
------------------	-----------------------------

4.3. setLinkAudioQuality

For setting Link Audio Quality in each Zone.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
mode	string	yes	Specifies Link Audio Quality setting Values: Values gotten via /system/getFeatures

URI	<BaseURL>[/secure]/v1/<zone>/setLinkAudioQuality?mode=<mode>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setLinkAudioQuality?mode=compressed

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------