

# CabinetSense Wiki

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)
  - [CabinetSense Menu](#)
  - [CNC Menu](#)
  - [Component Menu](#)
  - [Document Menu](#)
    - [Add Inside Dimensions](#)
    - [Add Outside Dimensions](#)
    - [Change Prefix](#)
    - [Clear Dimensions](#)
    - [Clear Part Numbers](#)
    - [Dimension Preferences](#)
    - [Find Part Number](#)
    - [Renumber Parts](#)
    - [Send to Layout](#)
    - [Show Part Numbers](#)
  - [Help Menu](#)
  - [Profiles Menu](#)
  - [Scene Menu](#)
  - [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

## [CabinetSense Wiki](#)


Clear Dimensions

This operation will remove all Plan and Elevation dimension from your current view.


NOTE:

- It will also remove any copied or modified plan and elevation dimension
- It will not remove dimensions that were placed using the Sketchup Dimension Tool

... Requesting to Clear Dimensions ...



... after ...



Page updated  
Report abuse