

[Skip to navigation](#)

- [Home](#)
- [32mm System](#)
- [Build History](#)
- [Closet Systems](#)
- [CNC](#)
- [Common Attributes](#)
- [Component Library](#)
- [Components](#)
- [Construction Templates](#)
- [Cutlist Plus Integration](#)
- [Dynamic User Components](#)
- [Elevation and Plan Dimensions](#)
- [Frequently Asked Questions](#)
- [Known Issues](#)
- [Menus](#)

- [CabinetSense Menu](#)
- [CNC Menu](#)
- [Component Menu](#)
- [Document Menu](#)
- [Help Menu](#)
- [Profiles Menu](#)
- [Scene Menu](#)
- [Toolbars](#)
- [Plugins, Programs, and Links](#)
- [Scene and Layer Management](#)
- [Shop and Submittal Drawings](#)
- [Sketchup Tutorials](#)
- [Tips and Tricks](#)
- [Troubleshooting](#)
- [Tutorials](#)
- [Videos](#)

- Wall Tool
- Dashboard


- Online Help: Opens the Help Website
- CNC Preferences

- Preview Machining
- Clear Machining
- Open Machining Database
- Send to Layout
- Dimension Preferences
- Add Outside Dimensions
- Add Inside Dimensions
- Clear Dimensions
- Show Part Numbering
- Clear Part Preview
- Toggle Alignment
- Toggle Public/Private Layer
- Toggle 3D View/Parallel Projection
- Face Me
- Delete Construction Lines
- Toggle Door Layer
- Toggle Drawer Layer
- Toggle All Component Layers

#### Profile Rendering

- Toggle Scene Management
- Apply Construction Profile
- Component Options Dialog
- Vertical Cabinet Openings
- Horizontal Cabinet Openings

#### ***Profiles Toolbar***



- [Open Profile](#)
- [Save Profile](#)
- [Assign Outside Profile](#)
- [Assign Inside Profile](#)
- [Assign Applied Moulding](#)
- [Assign Panel Profile](#)
- [Render Profiles](#)

Page updated

[Report abuse](#)