




Date: 13 June 2002
Version: 1.0
Status: Final

INMARSAT-C

PSDN & TCP/IP User Interface Manual

This manual describes the Xantic Inmarsat-C terrestrial user interface accessible through PSDN and TCP/IP via the Internet.
(Xantic uses an Inmarsat-C Thrane & Thrane platform)



This edition of this Inmarsat-C PSDN & TCP/IP User Interface Manual has been updated with information available at the date of issue. This edition supersedes all earlier versions of this manual.

This publication has been compiled with the greatest possible care, but no rights may be derived from its contents.

Copyright © 2002 Xantic B.V.

Contents

1	Introduction	5
1.1	Inmarsat-C: general description	5
1.2	Objective of this Manual	6
1.3	Suggestions for improvement	6
1.4	Customer Service Centre contact details	6
2	Access via the Internet TCP/IP and via PSDN	8
2.1	Access via the Internet	8
2.2	PSDN	9
3	Two Stage Acces commands	10
3.1	Conventions used in this document	10
3.2	Log in and log out	10
3.2.1	<i>Welcome line variants</i>	10
3.2.2	<i>Log in</i>	10
3.2.3	<i>Error situations</i>	11
3.2.4	<i>Log out</i>	11
3.3	Command overview	12
3.3.1	<i>Available commands</i>	12
3.3.2	<i>Generic error situations</i>	13
3.3.3	<i>Handling of LES responses</i>	13
3.4	Send	13
3.4.1	<i>Description</i>	13
3.4.2	<i>Send parameters</i>	14
3.4.3	<i>Error situations</i>	16
3.5	Dsend	19
3.5.1	<i>Description</i>	19
3.5.2	<i>Send parameters</i>	19
3.5.3	<i>Error situations</i>	19
3.6	View	20
3.6.1	<i>Description</i>	20
3.6.2	<i>Error situations</i>	20
3.7	Delete	21
3.7.1	<i>Description</i>	21
3.7.2	<i>Error situations</i>	21
3.8	Address	22
3.8.1	<i>Description</i>	22
3.8.2	<i>Error situations</i>	22
3.9	Scan	23
3.9.1	<i>Description</i>	23
3.9.2	<i>Error situations</i>	25
3.10	EGC	25

3.10.1	Description	25
3.10.2	Send parameters	25
3.11	Mail	26
3.11.1	Description	26
3.11.2	Error situations	27
3.12	Read	28
3.12.1	Description	28
3.12.2	Error situations	29
3.13	DNID	29
3.13.1	Description	29
3.13.2	Error situations	31
3.14	Poll	32
3.14.1	Description	32
3.14.2	Send parameters	32
3.14.3	Poll Retry	33
3.15	User	33
3.15.1	Description	33
3.15.2	Error situations	33
3.16	Pin	33
3.16.1	Description	33
3.16.2	Error situations	33
3.17	Help	34
4	Deliver Notifications	35
4.1	General	35
4.2	Negative Delivery Notifications	35
4.3	Positive Delivery Notifications	36
5	EGC Parameters	37
5.1	Ocean	37
5.2	C1, Priority	37
5.3	C2, Service code	37
5.4	C3, Address	38
5.5	C4, Repetition Code	39
5.5.1	Repetition codes for FleetNet, SafetyNET and system messages	39
5.5.2	Repetition codes for SafetyNET and System messages	40
5.6	C5, Presentation	41
5.7	Examples for EGC	41
6	Poll Parameters	42
6.1	OCEAN	42
6.2	P1, Poll type	42
6.3	P2, Data network id (DNID)	42
6.4	P3, Response type	43
6.5	P4, Sub address	43

6.6	P5, Address	43
6.7	P6, Command type	44
6.8	P7, Member number	44
6.9	P8, Start frame	45
6.10	P9, Reports per 24 hours	45
6.11	P10, Acknowledgement	45
6.12	P11, Spot id	45
6.13	Examples of Poll Command	45

Annex A: Inmarsat-C terrestrial access dial in numbers

1 Introduction

1.1 Inmarsat-C: general description

Inmarsat-C is a store and forward messaging system, which enables the user to send and receive messages and data to and from Inmarsat-C mobile terminals.

The Inmarsat-C system offers:

- Message transmission to and from a mobile terminal
- Broadcast messages to groups of mobile terminals.
- Manage position reporting from fleets of mobile terminals.
- Distress Alerting and Distress Priority Messaging

The Xantic Inmarsat-C system is accessible via different terrestrial networks:

- PSTN (telephone network analogue/ISDN),
- PSDN (X.25 data network)
- Telex
- Internet (Email using SMTP and Telnet over TCP/IP)




Figure 1: Sketch of the Inmarsat-C system.

Terrestrial users wanting to communicate with Inmarsat-C mobiles must first deliver their messages to the Xantic Land Earth Station (LES). This can happen in two ways: using one-stage access or two-stage access.

In the one-stage access mode (only available for telex), the user submits the messages to his/her normal telecom provider who will redirect the message to a LES operator.

In the two-stage access mode, the user contacts directly the “**user interface**” of the Xantic LES for sending or retrieving messages. This method requires registration with Xantic, and the user must identify himself/herself to access the system. After entering messages, the LES will transmit these via the satellite to the Inmarsat-C mobiles.

The following table gives an overview of the alternatives.

Network	Terrestrial to Mobile messages / commands (Two-stage access mode: all networks; One-stage: telex only)	Delivery of messages / data reports from Mobile to Terrestrial destinations (auto forwarding)	Delivery of messages / reports from Mobile to Mailbox / file at LES for later retrieval by terrestrial user
Telex	Yes	Yes	Yes
PSTN data	Yes	Yes	Yes
PSTN fax	No	Yes	No
PSDN (X25)	Yes	Yes	Yes
Internet TCP/IP	Yes	No (*)	Yes
Internet SMTP (email)	Yes	Yes	No

(*) Unlike all other interfaces, auto-forwarding of messages and data reports is currently not supported for Internet TCP/IP. This feature may be added in the future. Currently, messages and data reports must be retrieved by the user or can be auto-forwarded to a destination (network address, e-mail address) in one of the other networks.

1.2 Objective of this Manual

This document describes the terrestrial user interface for the PSDN (X25) and Internet TCP/IP (Telnet) access modes to the Xantic Inmarsat-C system. Xantic uses a Thrane & Thrane platform.

Section 2 gives a general description of the PSDN (X25) and Internet TCP/IP (Telnet) access modes. Section 3 describes in detail the Two-stage access method and commands needed when using PSDN and TCP/IP. Section 4 handles delivery notifications. Section 5 and 6 provide a detailed description of the EGC and Poll parameters respectively.

Annex A contains an overview of the Inmarsat-C PSDN and IP addresses Xantic operates for the access modes described in this manual.

This document, although quite detailed and extensive, is not complete. Although we have tried to simulate all possible error situations, it is still possible that we have not covered all of them.

Application developers who would like to have more detailed information about Data Reporting, DNID and Polling, are referred to the corresponding technical documentation provided by Inmarsat. This document can be requested via Xantic Customer Services. A charge of USD 1000.- applies.

1.3 Suggestions for improvement

Please send your comments and ideas to improve this manual to Xantic Customer Services:
service@xantic.net

1.4 Customer Service Centre contact details

Xantic Customer Services

Email: service@xantic.net

Access via Australia

Tel: +61 7 5498 0000

Fax: +61 7 5498 0098

Telex: (71) 22432 TELCSC AA

Access via the Netherlands

Tel: +31 70 343 4543

Fax: +31 70 343 4796

Access from Inmarsat-C terminal:

Special Access Code: 68 (free of charge)

2 Access via the Internet TCP/IP and via PSDN

2.1 Access via the Internet

Access via the Internet is accomplished by having a connection via an Internet Service Provider available at your premises. This can be a dial-up Internet account or a permanent office LAN connection to the Internet. Once having access to the Internet, you connect to the Land Earth Station (LES), and when the connection is accepted, the mobile unit is addressed by issuing various commands. The addressing techniques are thoroughly discussed in chapter 3, Two Stage Acces commands.

Telnet access to Inmarsat-C is currently available in an unencrypted (standard) mode. An encrypted mode may be added in the future.

Standard mode

The IP addresses for standard mode telnet access are provided in **Annex A** to this manual.

After having contacted via Telnet one of the Xantic IP addresses, typically the following initial response will be returned:

(Please note that this initial response may be removed in the future.)

Trying 678...Open

From this point on, the LES behaves as described in chapter 3, Two Stage Acces commands: you will be presented with the Inmarsat-C welcome line and 'Please enter username:' prompt

Caveats

- The local telnet program should not be set to 'local echo'.
- When entering Username / Password, the LES may respond that the password is incorrect.
This is caused by the local telnet program not being in 'raw-tcp' mode.
The default telnet program that comes with Windows 95 / 98 / NT / 2000 seems to default to 'raw-tcp' mode anyway, so this shouldn't be a problem. A few telnet programs on the Macintosh appear to use the 'telnet protocol' as a default. In this case the telnet program will need to be set to 'raw-tcp' or the 'telnet protocol' disabled from the program's options settings. This may also be the case with Unix implementations.
- Username / Password entries not recognised at all.
Check to ensure that 'BSD4.3 CR' is disabled. For all the telnet programs investigated, this has been the default anyway, so it shouldn't be a problem.

The standard mode of access is unencrypted, meaning that all data, including usernames and passwords are not encrypted nor authenticated. The encrypted mode that may be added in the future is expected to use pre-shared key authentication and DES encryption.

2.2 PSDN

Access via PSDN (international X.25 network) is accomplished by having a connection to the X.25-network of your local operator. Once having access to the X.25 network you connect to the Land Earth Station at one of the X.25 addresses provided in **Annex A** to this manual. When the connection is accepted, the LES behaves as described in chapter 3, **Two Stage Access commands**: you will be presented with the Inmarsat-C welcome line and 'Please enter username:' prompt.

3 Two Stage Acces commands

In the Two-Stage Access method, the terrestrial user calls the IP address or X.25 address of the Land Earth Station (LES). Once the connection is established, a conversational command interpreter is invoked and the user will be asked to enter a Username and Password. This means that the two stage access method is only available to users that have registered for this service with Xantic.

3.1 Conventions used in this document

- ***COURIER BOLD ITALICS*** typeface characters in examples are sent by the LES
- ***COURIER BOLD*** typeface characters in examples are sent by the user
- Usernames and passwords used in this document are fictive
- <CR>: Carriage Return character
- <LF>: Line Feed character

3.2 Log in and log out

3.2.1 Welcome line variants

Once the connection is established the LES responds with a welcome line. Each of the two Inmarsat-C LES IDs operated by Xantic has its unique welcome line.

Welcome line for the Burum LES (LES-ID 12):

```
Welcome to BURUM LES PSDN Service
```

Please note that this welcome line is expected to be changed in the future into:
“Welcome to Xantic LES ID 12”

Welcome line for the Perth LES (LES-ID 22):

```
Welcome to Xantic LES ID 22
```

Remark: All examples in this manual show the Burum (LES-ID 12) welcome line.

3.2.2 Log in

Once the connection is established, the LES responds with a welcome line and prompt for username:

```
Welcome to BURUM LES PSDN Service  
Please enter username:
```

After entering the username followed by <CR><LF> the LES prompts for the password:

After entering the password followed by <CR><LF> the LES validates the entered information. If the information is correct, the LES will return the system prompt “>”:

```
Welcome to BURUM LES PSDN Service  
Please enter username: 1234user  
Please enter password: xantic  
>
```

It is also possible to enter the username and the password on the same line after receiving the prompt for username. The LES will validate the entered information and if the information is correct return with the system prompt:

```
Welcome to BURUM LES PSDN Service
Please enter username: 1234user xantic
>
```

3.2.3 Error situations

If either the entered username or the password is not correct, the LES will return the error message “Login incorrect.” Maximum three attempts are allowed to log in. Entering incorrect information in the first two attempts will result in a new prompt for username, as shown in the following example:

```
Welcome to BURUM LES PSDN Service
Please enter username: 1234user
Please enter password: xantic
Login incorrect.
Please enter username:
```

If the information entered for a third attempt is also incorrect, the LES will terminate the connection.

```
Welcome to BURUM LES PSDN Service
Please enter username:
Please enter password:
Login incorrect.
Please enter username:
Please enter password:
Login incorrect.
Please enter username:
Please enter password:
Sorry, access is denied.
```

3.2.4 Log out

The user can log out by entering the command QUIT on the system prompt. After entering this command, the LES will respond with: “Logging off...” and terminate the connection. Example:

```
> quit
Logging off...
```

3.3 Command overview

3.3.1 Available commands

When the system prompt ">" is received from the LES, it is ready to accept input. The expected input from the user is a command specifying the action to be carried out. The following commands are available:

Command	Description
SEND	Send a message to one or several mobile terminals. Within the message, parameters regarding the transmission can be entered.
DSEND	Send a message to one or several mobile terminals using distress priority. Within the message, parameters regarding the transmission can be entered.
VIEW	View one of the previously entered messages.
DELETE	Delete one of the previously entered messages.
ADDRESS	Update the destination address of one of the previously entered messages.
SCAN	Get status on previously entered message(s).
EGC	Send an EGC (Enhanced Group Call) message to one or several mobile terminals.
MAIL	Get an overview of mailbox(es).
READ	Retrieve messages from a mailbox.
DNID	Retrieve data from a closed network id mailbox.
POLL	Enter a polling command to one or several mobiles.
USER	Enter user name and password.
PIN	Change password.
HELP	Get help.
QUIT	End the session.

Commands are recognised by the LES using the first two characters of the input immediately following the prompt ">". Only the first two characters matter (shown in bold in the table above), although it is possible to enter the entire command.

The command interpreter will input one whole line (all characters up to a Carriage Return, an additional Line Feed is optional, but recommended) and then evaluate it. If the command is recognised, it will be carried out. Commands for the LES are not case sensitive.

3.3.2 Generic error situations

The following error situations are applicable to all commands.

Entering an unknown command

Any combination of characters for which the first two characters do not match any command will result in the error message: "Unknown command." And the LES will return to the system prompt.

```
> ab
Unknown command.
>
```

Inactivity time-out

The command interpreter is configured with an inactivity timer, which will clear the call if a certain period of inactivity is detected. The inactivity timer can be up to 30 minutes, but 2-3 minutes is common.

```
Welcome to BURUM LES PSDN Service
Please enter username:
No activity timeout.
Logging off.
```

```
Welcome to BURUM LES PSDN Service
Please enter username: 1234user
Please enter password: xantic
>
No activity timeout.
Logging off.
```

Termination of a command

Should the user want to terminate a command while having started entering the command, this can only be done by clearing the call. For instance if a Send command is initiated and the user wants to cancel the command while entering the message, the only way to do so, is to clear the call (i.e.: terminate the connection with the LES).

3.3.3 Handling of LES responses

Responses to commands issued by the user typically consist of one or more lines of text. This manual provides ample examples for all commands, including responses in case of error situations.

When handling these responses in an automatic way (e.g. in a fleet management application), it is advised to allow for the following situations:

- The LES may issue empty lines between response lines. It is advised to allow for empty lines before or after any non-empty response line.
- Although every effort has been made to include all error situations and corresponding error messages from the LES, it is advised to allow for error responses not documented in this manual.

3.4 Send

3.4.1 Description

The Send command can be used to enter messages to Mobile Inmarsat-C terminals. When the Send command has been issued, a prompt asking for the destination appears:

```
To:
```

After the **To:** prompt, the LES expects a mobile number to be entered, before the text entry state is entered as indicated by the following prompt:

Text:

The user now enters his text. All characters in the text field will be forwarded as received (subject to presentation or character set conversion by the LES), i.e. if the lines in the message text is separated by only a carriage return, then the message will be forwarded with only a carriage return. It is strongly recommended that lines are separated by <CR> followed by <LF>. This will ensure that the mobile unit will handle the message correctly.

The end of message input is provided by entering “.S” at the very beginning of a line followed by a <CR>. (Any characters between the “.S” and <CR> are ignored.) When the message is accepted for subsequent delivery to the mobile terminal, the time and reference number is shown. This reference number is a unique number for this message, which can be referred to later.

```
> send
To: 482380010
Text:
Dear Charlie, please send the documents on Monday
Best regards
John.
.S
72 characters.
Storing message...
Submitted 99-01-31 12:15. Reference number 045678.
>
```

3.4.2 Send parameters

When using the Send command to enter a message, Send parameters can be issued. These parameters control certain aspects regarding the transmission of the message. The following Send parameters are available:

CC <mobile number>	Carbon copy. Sends a copy to other destinations. Several CC parameters can be issued for one transmission, each specifying an extra destination. A maximum of 20 destinations in total can be specified.
TA <hours>	Time Activate The actual delivery will be delayed the specified number of hours. The TA parameter only applies to the first destination entered after this parameter.
TL <hours>	Time Limit. Delivery limited to a certain number of hours from the submission time. If the LES hasn't succeeded to deliver the message within the specified number of hours, the LES stops retrying and the call will be regarded as failed. The TL parameter only applies to the first destination entered after this parameter.
DAR [<address>]	Delivery Acknowledgement Requested. <u>Access via PSDN:</u> Without the DAR parameter, the LES will send a Delivery Notification only when the delivery has failed. By using the DAR parameter, a Delivery Notification will also be sent when the delivery was successful.

	<p>By default, Delivery Notifications will be sent to the X.25 address from which the X.25 connection with the LES was set-up when sending the message (the calling X.25 address). The optional <address> parameter can be added after “DAR” to have the Notification sent to an X.25 address different from the calling X.25 address.</p> <p>The DAR parameter only applies to the first destination entered after this parameter.</p> <p><u>Access via the Internet (TCP/IP)</u></p> <p>The LES will not send Delivery Notifications to IP-addresses, so only a DAR parameter combined with an X.25 address is useful.</p> <p>The DAR parameter (followed by an X.25 address) only applies to the first destination entered after this parameter.</p> <p><u>General</u></p> <p>The format for Delivery Notifications is described in section 4 Deliver Notifications, page 35</p>
ITA2	<p>Forward to mobile using ITA2 (5-bit) alphabet.</p> <p>Default is IA5 (7-bit) alphabet. By using the ITA2 parameter, the transmission over the satellite link will done in 5 bit per character, which is significantly more efficient (and hence more cost effective). This parameter applies to all specified addresses.</p>
DATA <number of bytes>	<p>Forward to mobile using 8 bit data.</p> <p>By using this option, it is possible forward 8 bit data to the mobile unit. All bytes received by the LES from the next line on will be perceived as 8 bit data. In order to avoid any misinterpretation of the <CR><LF> or <CR> ending the keyword line, you may optionally included an <STX> (02 hex) character after the <CR><LF> or <CR> to signal start of data. The <STX> character will not be forwarded. When the LES has received the specified number of bytes, the LES will commence forwarding the data.</p>
LOW	<p>Low priority.</p> <p>By using this option you can specify, that the message is low priority and may be scheduled at a later time.</p>
HIGH	<p>High priority.</p> <p>By using this option you can specify that the message must be delivered as quickly as possible, before any lower priority messages.</p>

The Send parameters can be entered on either of two different locations:

- Together with the Send command on the command line.
Command and parameters need to be separated by comma, colon or space characters on the command line. Separation by comma or colon is recommended. Between the Send parameter and an associated value (if any) only spaces are allowed.
- After the prompt “Text: “ but before the actual message text;
In this case the LES is made aware that it should interpret this input as a Send parameter by putting a “.” (full stop) at the start of a line, followed by the Send parameter. Between the Send parameter and an associated value (if any) only spaces are allowed. Each additional Send parameter used should be put on a separate line before the beginning of the actual message text.

Examples

Example of message entry with the Send parameters on the same line as the Send command:

```
> send dar, to 482380010, ta 24, cc 482380040, ita2
Text:
Dear Charlie, please send the documents on Monday
Best regards
John.
.s
72 characters.
Storing message...
Submitted 99-01-31 12:15. Reference number 045678.
> _
```

Note that also “to “ can be used on the command line. The LES will then skip the “To” prompt. It is recommended to provide only one destination on the command line this way.

Same example of message entry, now the Send parameters are provided after the “Text: “ prompt

```
> send
To:
Text:
.dar
.cc 482380010
.ta 24
.cc 482380040
.ita2
Dear Charlie, please send the documents on Monday.
Best regards
John.
.s
72 characters.
Storing message...
Submitted 99-01-31 12:15. Reference number 045678.
>
```

Please note that Send parameters shall only be prefixed with a dot when they appear in the text field.

The sequence of Send parameters is important: The TA, TL and DAR parameter act only on the first destination address that is entered after the send parameter. Thus it is possible to specify different options for different destinations. In the example above Delivery Acknowledgement is requested for 482380010 but not for 482380040. Message forwarding to 482380040 will commence in another 24 hours.

Below an example is shown on forwarding 8 bit data

```
> SEND 482380010 data 10
Data:
1234567890
10 characters.
Storing message...
Submitted 99-01-31 12:15. Reference number 045678.
> _
```

Please note that you must input exactly the number of characters that has been specified:

- When the LES has received the specified number of bytes, the LES returns *Storing message...*
- If less than the specified number of bytes is received by the LES, it will await further input until the inactivity timer runs out and causes the call to be cleared.
- If more than the specified number of bytes is received by the LES, it will ignore anything beyond the specified number.

3.4.3 Error situations

Mobile terminal number

In the Inmarsat-C environment the mobile terminal unit needs to be commissioned by Inmarsat, before the LES will know of its existence. Once a mobile terminal is commissioned in the Inmarsat-C environment, the terminal can have three states in the database:

- Unbarred and logged in;

The LES will accept messages for delivery to the terminal.

If the terminal is switched on, delivery will normally be successful. However if the terminal is switched off (which may happen without logging out), delivery will not be successful.

- Unbarred but logged out

The LES will not accept messages the terminal.

- Barred (only barred for reception is of interest here)

The LES will not accept messages for the terminal

If a number is used during message submission that does not match a commissioned mobile terminal in the LES database, the LES will terminate the message submission with an error message. The same error message will be used if the entered mobile number is too short, too long or contains not allowed characters.

The table below provides an overview of the error responses.

Possible error messages:	Reason:
The following mobile units cannot be reached: <mobile number>: Unknown. Failed: Cannot reach the mobile(s).	Non existing mobile terminal number entered, or some (typing) error in the mobile number entered.
The following mobile units cannot be reached: <mobile number>: Logged out. Failed: Cannot reach the mobile(s).	Terminal logged out.
The following mobile units cannot be reached: <mobile number>: Barred. Failed: Cannot reach the mobile(s).	Terminal barred for receiving messages.

Examples

```
> send
To: 492345712
Text:
test
.s

The following mobile units cannot be reached:
492345712: Unknown.

Failed: Cannot reach the mobile(s).
>
```

```
> send
To: 400000001
Text:
test
.s

The following mobile units cannot be reached:
400000001: Logged out.

Failed: Cannot reach the mobile(s).
>
```

```

> send
To:
Text:
.cc 400000001
.cc 400000002
.cc 400000003
example.
.S

The following mobile units cannot be reached:
400000001: Logged out.
400000003: Unknown.

10 characters.
Storing message...
Submitted 02-06-08 15:40. Reference number 388784.
>

```

Exceeding maximum message size

If the maximum message size is exceeded, the message will be truncated, i.e. the message will be stored and forwarded when the maximum number of characters have been input. Additional input is ignored. The maximum size is a few bytes less than 32Kb.

Empty text

Once the message LES has issued the “Text: “ prompt, the LES expects to receive message input. If only the .S is entered (so an empty message text), the will prompt for input. Only entering some text before the .S can solve this situation. Example:

```

> send
To: 400000001
Text:
.S
You must enter some text before issuing the '.S' command.
Please go on!
.S
You must enter some text before issuing the '.S' command.
Please go on!
test
.S
6 characters.
Storing message...
Submitted 01-12-05 10:14. Reference number 504127.
>

```

Please note that if the user wants to cancel the Send command, the only way to do so is to clear the call (i.e.: terminate the connection with the LES).

Error situations for Send parameters

With the use of Send parameters the following error situations can occur:

- If an error is made in the use of the Send parameters and the command line interpreter is not able to find a destination address (mobile number) in the line containing the Send command, the entire line after the Send command is discarded and the LES will respond with the “To: “ prompt. If the user (or user application) does not recognise this situation and starts to send the message text, the first characters sent, up until the first <CR>-character will be interpreted as an address. The LES will send the “Text: “ prompt while the user is still sending (message-) text. After the LES has received .S, it

will evaluate the message submission and in this case it will abort the sending of the message and send a response to the user stating that the mobile is unknown.

- If the Send parameters are entered using the full stop at the beginning of the line but after there have been one or more lines pertaining to the message, the Send parameters are not recognised as such and will be forwarded as part of the message text to the mobile terminal. The only exception to this is of course the **.S** signalling end of message input.
- The Send parameters are to be separated by colon, comma or space characters on the command line. The specific parameters pertaining to such send parameters (<hours>, <mobile number>, <number-of-bytes>) need to be separated from the Send parameter name by a space character. If no, or wrong separation is used, the command line interpreter will consider the rest of the command line invalid.

3.5 Dsend

3.5.1 Description

Users authorised to use the Dsend command can use this command to enter messages to Mobile Inmarsat-C terminals that will be sent with distress priority. When the Dsend command has been issued, a prompt asking for the destination appears:

To:

After the **To:** prompt, a mobile number has to be entered, before the text entry state is entered as indicated by the following prompt:

Text:

The user now enters his text and stops the message input by entering **.S** at the very beginning of a line.

3.5.2 Send parameters

The following Send parameters can be used in combination with the Dsend command.

CC <no>	Carbon copy.
TA <hours>	Time Activate
TL <hours>	Time Limit.
DAR [<address>]	Delivery Acknowledgement Requested.
ITA2	Forward to mobile using ITA2 (5-bit) alphabet.
DATA <number of bytes>	Forward to mobile using 8 bit data.

For more information on these Send parameters, see section 3.4.2 Send parameters, page 14.

3.5.3 Error situations

The error situations that can happen are the same as for the Send command, with the addition of the one given in the table below.

Possible error messages:	Reason:
Sorry, you have no access to this service.	The user is not authorised to use the Dsend command.

For more information on the error situations that can happen for the Send command, see section 3.4.3 Error situations, page 16.

3.6 View

3.6.1 Description

The View command can be used to view an earlier entered message, provided the message has not been delivered yet at the time the View command is entered.

Usage: **view** <ref_no>, where:

- <ref_no> is the reference number for a message entered before.

The result of the View command is

- A response line saying “Retrieving file...” followed by a blank line
- An information table per destination containing
 - The destination address;
 - The time for the first attempt (immediate by default or otherwise as specified with the TA parameter in the Send or Address command);
 - The cancel time (immediate after delivery or otherwise as specified by the TL parameter in the Send or Address command);
 - a field that indicates whether a Delivery Notification was requested;
- Followed by a blank line and the message text.

Example for a message sent to a single destination.

```
> vi 624641
Retrieving file...

Called Number      : 400000001
First Try Time     : 1-MAR-02 11:41
Cancel Time        : 2-MAR-02 11:41
Notification       : Not Requested

test message
>
```

Example for a message sent to a number of destinations (a multi-address message).

```
> vi 625490
Retrieving file...

Called Number      : 400000001
First Try Time     : 21-MAR-02 11:54
Cancel Time        : 22-MAR-02 11:54
Notification       : Not Requested

Called Number      : 400000002
First Try Time     : 21-MAR-02 11:54
Cancel Time        : 22-MAR-02 11:54
Notification       : Not Requested

Called Number      : 400000003
First Try Time     : 21-MAR-02 11:54
Cancel Time        : 22-MAR-02 11:54
Notification       : Requested

test message
>
```

3.6.2 Error situations

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Failed: Unknown message.	A wrong message reference number was used.
Failed: Message has been delivered.	The message has already been delivered, and the message text cannot be viewed as its is not available in the system anymore.
Failed: Message has been aborted.	The LES has already tried to deliver the message, but was unsuccessful, e.g. because the mobile terminal is switched off.
Failed: Message has been rerouted.	The message has been rerouted to another LES that handles the traffic for the Ocean Region the terminal is logged in.

Examples

```
> vi 624614
Retrieving file...

Failed: Unknown message.

>
```

```
> vi 628051
Retrieving file...

Failed: Message has been delivered.

>
```

3.7 Delete

3.7.1 Description

The Delete command can be used to remove a message sent earlier, provided the message has not been delivered yet and is not being processed by the LES at the time the Delete command is entered.

Usage: **delete** <ref_no>, where:

- <ref_no> is the reference number for message entered before.

Example

```
> de 625268
Message is now deleted!

>
```

3.7.2 Error situations

Possible error messages:	Reason:
Failed: Message has been delivered.	Once a messages has been delivered, it can not be deleted anymore.
Failed: Unknown message.	Wrong message reference number was used.
Failed: Message is being processed. Try again later.	The message was being processed at the time of command entry

Examples.

```
> delete 255969
Failed: Message has been delivered.

>
```

```
> de 628051
Failed: Message is being processed. Try again later.

>
```

3.8 Address**3.8.1 Description**

The Address command can be used to change the destination address of a message sent earlier, provided the message has not been delivered yet and is not being processed by the LES at the time the Address command is entered.

Usage: **address** <ref_no> <old_address> <new_address>, where:

- <ref_no> is the reference number for the message entered before;
- <old_address> is the destination address entered before for the message
- <new_address> is the new destination address for the message entered before.

In addition to these mandatory parameters, also the following Send parameters can be used in combination with the Address command.

TA <hours>	Time Activate
TL <hours>	Time Limit.
DAR [<address>]	Delivery Acknowledgement Requested.

These Send parameters can be added at the command line after the last mandatory parameter (i.e. <new addr>). For more information on these Send parameters, see section 3.4.2 Send parameters, page 14.

Example

```
> ad 625490 400000001 400000002
Address is now changed!

>
```

3.8.2 Error situations

Possible error messages:	Reason:
Failed: Message has been delivered.	Message had already been delivered by the LES.
Failed: Message has been deleted.	Message had already been deleted by the user.
Failed: Message has been aborted.	Message had already been aborted by LES.
Failed: Unknown message.	Wrong message reference number and/or old address was used.
Failed: Message is being processed. Try again later.	The message which was being processed at the time of command entry.

Examples

```
> ad 626528 400000001 400000002
Failed: Unknown message.

>
```

```
> ad 625268 400000001 400000002
Failed: Message has been deleted.

>
```

```
> ad 625379 400000001 400000002
Failed: Message is being processed. Try again later.

>
```

3.9 Scan**3.9.1 Description**

The Scan command can be used to retrieve status information on messages sent before.

Scan a specific message

To retrieve status information for a specific message, its message reference number must be entered.

Usage: **Scan** <ref_no>, where:

- <ref_no> is the reference number for a message entered before;

The LES returns a line with status information to this command. The general format of the status information is:

<ref_no> <address> <msg type> <date> <time> <status> <attempts> <reason>

where:

<ref_no>	is reference number of the message
<address>	is the destination address for the message: <div style="margin-left: 40px;"><mobile number> group/area</div>
<msg type>	is the actual type of message: <div style="margin-left: 40px;">msg poll EGC</div>
<date>	the date of submission, format: DD-MMM-YY
<time>	the time of submission, format: HH:SS
<status>	the current status of the message: <div style="margin-left: 40px;">in progress delivered aborted deleted by user pending rerouting</div>

<attempts> number of attempts by the LES to deliver the message:
 <nr> attempts

<reason> reason why last attempt failed, examples:
 dest busy
 dest timeout
 dest disconn
 no conn possible
 ses logged out
 ses barred
 ses not in ocean region

Example

```
> scan 583011
583011 482380001 msg 23-JAN-99 16:05 delivered 1 attempts
>
```

Scan several messages by date range

To retrieve status information for message in a certain date range, the “-d” option can be used.

Usage: scan -d <from_time> <to_time>, where:

- <from_time> is the date from which retrieval should start, format: YYMMDD
- <to_time> is date for which retrieval should end, format: YYMMDD

Example

```
> scan -d 990101 990301
583000 482380001 poll 23-JAN-99 14:27 deleted
583011 482380001 msg 23-JAN-99 16:05 delivered 1 attempts
583022 482380001 msg 23-JAN-99 17:01 delivered 1 attempts
583023 482380002 msg 23-JAN-99 17:02 delivered 1 attempts
306213 482380001 msg 24-JAN-99 11:48 delivered 1 attempts
800210 482380002 msg 25-JAN-99 15:53 delivered 1 attempts
800210 482380001 msg 25-JAN-99 15:53 delivered 1 attempts
800211 482380002 msg 25-JAN-99 15:54 delivered 1 attempts
800211 482380001 msg 25-JAN-99 15:54 delivered 2 attempts
047700 482380001 msg 25-JAN-99 16:41 aborted 6 attempts dest disconn
784502 482380001 msg 26-JAN-99 14:26 delivered 1 attempts
784503 482380001 msg 26-JAN-99 14:27 deleted by user
059401 482380002 poll 27-JAN-99 14:27 delivered 0 attempts
138631 482380001 msg 06-FEB-99 14:12 deleted by user
059509 group/area poll 09-FEB-99 11:11 delivered 0 attempts
059510 group/area poll 09-FEB-99 11:13 delivered 0 attempts
359991 482380001 msg 09-FEB-99 13:20 in progress 0 attempts
>
```

Scan several messages by reference number range

To retrieve status information for all messages with a message reference number in a certain reference number range, the option “-r” can be used..

Usage: scan -r <ref_num_low> <ref_num_high>, where:

- <ref_num_low> is the smallest reference number for which information should be retrieved
- <ref_num_high> is the highest reference number for which information should be retrieved.

Scan all not delivered messages

To get a list of all undelivered messages, the option “-u” can be used.

Usage: **scan -u**

3.9.2 Error situations

Possible error messages:	Reason:
Failed: No message(s).	No messages available for which status information could be retrieved, or wrong message reference number used.
Failed: Invalid time.	Error in time range specification (option -d)
Illegal parameters in scan command.	Some error found in the parameters, for example: an option other than -d, -r or -u; option -r without a reference number range.

Examples

```
> scan -d 010101 020101
Failed: No message(s).
>
```

```
> scan -d 0101 020101
Failed: Invalid time.
>
```

```
> scan -r
Illegal parameters in scan command.
>
```

3.10 EGC

3.10.1 Description

The EGC command is used to send a FleetNET or SafetyNET message to one or more mobile terminals.

Usage: **EGC <Ocean>,<c1>,<c2>,<c3>,<c4> <c5>**

The EGC command parameters <Ocean>, <C1> .. <C5> and possible error situations are described in section 5, EGC Parameters, starting at page 37.

When the EGC command has been issued with proper parameters, the LES will display the prompt: “**Text:** “. The user then enters his text and stops the entry by typing “.S”.

3.10.2 Send parameters

The following table lists the Send parameters available when inputting the EGC message. Please note that these parameters can only be issued after the “Text: “ prompt, preceded by a “.” (dot) at the first position on the line.

TA <hours>	Time Activate
TL <hours>	Time Limit.
DAR [<address>]	Delivery Acknowledgement Requested.
ITA2	Forward to mobile using ITA2 (5-bit) alphabet. This option overrides the presentation set in parameter <C5>
DATA <number of bytes>	Forward to mobile using 8 bit data. This option overrides the presentation set in parameter <C5>.

For more information on these Send parameters, see section 3.4.2, Send parameters, page 14.

3.11 Mail

3.11.1 Description

The Mail command can be used to check the contents of one or more mailboxes assigned to a registered user. A distinction is made in PSTN and PSDN network types. Mobile users sending to a mailbox need to send a message to a number on either PSTN or PSTN network type as if it was a normal PSDN or PSTN destination number. The LES will recognise that the number (as assigned by Xantic) is in fact the identification of a mailbox and will store the received message in the mailbox. Also Delivery Notifications can be forwarded to a mailbox. The default mailbox type is PSDN. Unless otherwise indicated when using the Mail command, the LES will assume the user is looking for messages in a PSDN mailbox. The Read command is used to actually retrieve the messages from the mailbox(es).

List all mailboxes

Entering the Mail command from the command prompt without parameters will list all mailboxes associated with a registered user. The response includes mailbox type, the mail box identification number and information about the number of messages and deliver notifications.

Usage: **mail**

Example

```
> mail
Retrieving mailbox list...
PSTN          318690 is holding      2 not retrieved msgs and DN's
>
```

List one mailbox

Entering the Mail command followed by the mailbox number and possibly the type, will list all messages in the mailbox.

Usage: **mail** <mailbox number> [PSTN], where:

- <mailbox number> is the identification of the mailbox;
- PSTN is the type of mailbox, only used to indicate a PSTN mailbox instead of the default PSDN mailbox type.

In the following example the Mail command results in an overview where both retrieved and not retrieved messages are listed.

```

> ma 318690 pstn
Retrieving list of mailbox contents...
555210 400000001      1-JUN-02 05:12      48 bytes, MSG      retrieved
555878 400000002      1-JUN-02 05:21      48 bytes, MSG      retrieved
123979 400000001      6-JUN-02 08:01      46 bytes, MSG      retrieved
124686 400000001      6-JUN-02 08:07      47 bytes, MSG not retrieved
>

```

In the overview, the first 6-digit number is the message reference number, followed by the mobile number that sent the message. Following the mobile number is the date and time the message was stored, the size of the message and the status (retrieved or not retrieved). Messages that have been retrieved using the Read command are no longer available on the system, but the control information is still there for some limited time.

Example for an empty mailbox

```

> ma 318690 pstn
Retrieving mailbox list...
PSTN          318690 is holding      0 not retrieved msgs and DN's
>

```

List all not retrieved messages

Entering the Mail command with the option “-u” gives a list of all not retrieved messages.

Usage: **mail -u <mailbox number> [PSTN]**, where:

- <mailbox number> is the identification of the mailbox;
- PSTN is the type of mailbox, only used to indicate a PSTN mailbox instead of the default PSDN).

Example

```

> ma -u 318690 PSTN
Retrieving list of mailbox contents...
555210 400000001      1-JUN-02 05:12      48 bytes, MSG not retrieved
555878 400000002      1-JUN-02 05:21      48 bytes, MSG not retrieved
>

```

3.11.2 Error situations

Possible error messages:	Reason:
Failed: Unknown mailbox	Wrong mailbox number entered, or mailbox type PSTN omitted in case of a PSTN mailbox type, or an unknown mailbox type entered.

Example

```
> ma -u 311234 PSTN
Retrieving list of mailbox contents...

Failed: Unknown mailbox.

>
```

3.12 Read**3.12.1 Description**

The Read command can be used to retrieve the contents of a mailbox. One or more mailboxes can be assigned to a registered user. A distinction is made in PSTN and PSDN network types. Mobile users sending to a mailbox need to send a message to a number on either PSTN or PSTN network type as if it was a normal PSDN or PSTN destination number. The LES will recognise that the number (as assigned by Xantic) is in fact the identification of a mailbox and will store the received message in the mailbox. Also Delivery Notifications can be forwarded to a mailbox. The default mailbox type is PSDN. Unless otherwise indicated when using the Read command, the LES will assume the user is looking for messages in a PSDN mailbox. The Mail command can be used to see if there are messages in the mailbox(es).

Get all messages from a mailbox

Usage: **read** <mailbox number> [PSTN], where

- <mailbox number> is the identification number of the mailbox;
- PSTN is the type of mailbox, only used to indicate a PSTN mailbox instead of the default PSDN).

Example

```
> re 318690 pstn
Retrieving mailbox data...

from master SS Albatros

end of message

>
```

Get one message from a mailbox

Usage: **mail** <mailbox number> <ref_no> [PSTN] , where

- <mailbox number> is the identification of the mailbox;
- <ref_no> is the reference number a message;
- PSTN is the type of mailbox, only used to indicate a PSTN mailbox instead of the default PSDN.

In the following example one particular message is retrieved from the mailbox, using the message reference number which was obtained using the Mail command.

```
> ma 318690 pstn
```

```

Retrieving list of mailbox contents...
555210 400000001      1-JUN-02 05:12      48 bytes, MSG      retrieved
555878 400000002      1-JUN-02 05:21      48 bytes, MSG      retrieved
123979 400000001      6-JUN-02 08:01      46 bytes, MSG      retrieved
124686 400000001      6-JUN-02 08:07      47 bytes, MSG not retrieved

> re 318690 124686 pstn
Retrieving mailbox data...

from master SS Albatros

end of message

>

```

Example for an empty mailbox

```

> re 318690 pstn
Retrieving mailbox data...

Failed: No message(s).

>

```

3.12.2 Error situations

Possible error messages:	Reason:
Failed: Unknown mailbox	Wrong mailbox number entered, or mailbox type PSTN omitted in case of a PSTN mailbox type, or an unknown mailbox type entered.
Failed: No message(s).	Mailbox empty.

3.13 DNID

3.13.1 Description

The DNID command can be used to retrieve the contents of a DNID file. Typically the contents of a DNID file will be Data Reports received from mobile terminals. Mobile terminals must always address Data Reports to a DNID (which will then be stored in the corresponding DNID-file), but it is also possible for a mobile terminal to address messages to a DNID. Before a mobile terminal can address Data Reports to a DNID, this number has to be downloaded into the mobile terminal first, using the one of the Poll command variants, see section 6 Poll Parameters, starting at page 42.

DNID-numbers and associated DNID files are configured in the LES on request from a registered user. One or more DNID-numbers can be assigned to a registered user. A DNID is always associated with a particular Ocean Region. Of course the same DNID-number can be assigned for a number of Ocean Regions.

Retrieve contents of a DNID file

To retrieve the contents of a DNID file, the DNID command must be used as follows:

Usage: **dnid** <dnid number> <ocean>, where:

- <dnid number> is the identification of the DNID-file;

- <ocean> is the Ocean Region the DNID is associated with,
 - 0 = Atlantic Ocean Region West
 - 1 = Atlantic Ocean Region East
 - 2 = Pacific Ocean Region
 - 3 = Indian Ocean Region

A number of possibilities exist for the format used by the LES to present the contents of a DNID file. Within the possibilities available, the format can be set according to the requirements of the user. More information can be obtained via Xantic Customer Service (service@xantic.net)

Examples

In the example below, a DNID file was retrieved for Atlantic West Ocean Region, containing a position report. In this specific example, one of the available formats was used to present such position report.

```
> dnid 1001 2

Retrieving DNID data...

Maritime Mobile Position Report

Pacific Ocean Region, DNID : 1001, Member Number : 8

Position : 31 48.28' S, 115 53.28' E

Speed : 0.0 knots, Course : 0 degree

Time of position : 07-JUN-02 06:32

>
```

In the following example a Data Report was retrieved, not matching the format for a position report.

```
> dnid 1001 2

Retrieving DNID data...

Unknown Type Position Report

Pacific Ocean Region, DNID : 1001, Member Number : 1

Nothing Decoded

>
```

In the following example the DNID file did not contain any data reports.

```
> dnid 1001 2

Retrieving DNID data...

Failed: No message(s).

>
```

Registration variants for DNID files

DNID files can be registered as:

- Mailbox:
The user must always retrieve the data himself by the DNID command as described above.

- Immediate forwarding:
All data will be forwarded immediately when received from mobile units to a destination specified by the user (e.g. an e-mail address).
- Auto forward:
The data in the DNID file will be forwarded automatically according to a schedule to a user specified destination (e.g. an e-mail address). The schedule can be specified/changed by the user with the DNID -c command as described below. The user must be authorised to do so.

Change the time for forwarding DNID files

To change the schedule for auto forwarding DNID files, the DNID command must be used as follows:

Usage: **dnid -c <dnid number> <ocean> <forwarding schedule>**, where:

- <dnid number> is the identification of the DNID-file;
- <ocean> is the Ocean Region the DNID is associated with,
 - 0 = Atlantic Ocean Region West
 - 1 = Atlantic Ocean Region East
 - 2 = Pacific Ocean Region
 - 3 = Indian Ocean Region
- <forwarding schedule> is the schedule to be used by the LES (see below). Reference for this schedule is UTC.

The <forwarding schedule> consists of the following three parameters, separated by a space character:

- <minutes string> specifies specific minut(s) and/or range(s) of minutes.
- <hours string> specifies specific hour(s) and/or range(s) of hours.
- <days string>: specifies specific day(s) and/or range of days (Sunday is 0).

For each parameter, multiple values can be entered; these values need to be separated by a comma. 'Wildcards' are applicable: a * indicates all possible values, a hyphen indicates a from-to range. Some examples:

Example forwarding schedules:

5,15 6,18 1-5

Forward at: 06:05, 06:15, 18:05; 18:15 from Monday till Friday

10 14 *

Forward at: 14:10 every day of the week

Example

```
> dnid -c 8690 0 5,35 8,20 1,5
>
```

Please note that the LES does not confirm the command in any way other than the normal prompt.

3.13.2 Error situations

Possible error messages:	Reason:
Unknown DNID.	Unknown DNID was entered.
Usage: dnid <dnid no> <ocean>	Returned when entering e.g. an Ocean Region value other than 0,1,2 or 3
Failed: Invalid time	Error in forwarding schedule,

Sorry, you have no access to this service	User is not authorised to change to forwarding schedule.
---	--

Examples

```
> dnid 1234567 1
Retrieving DNID data...

Failed: Unknown DNID.

>
```

```
> dnid 3 8690
Usage: dnid <dnid no> <ocean>

>
```

```
> dn -c 8690 3 5,15 6,
Failed: Invalid time.

>
```

```
> dnid -c 8690 0 15,30 6,18 *

Sorry, you have no access to this service.

>
```

3.14 Poll

3.14.1 Description

The Poll command is used to send a poll to one or more mobile terminals.

Usage: Poll <Ocean>,<P1>,<P2>,<P3>,<P4>,<P5>,<P6>,<P7>,<P8>,<P9>,<P10>,<P11>

The Poll parameters <Ocean> , <P1> .. <P11> and possible error situations are described in section 6, Poll Parameters, page 42.

When the Poll command has been issued with proper parameters, the LES will display the prompt:

Text: “. The user then enters his text and stops the entry by typing “.S”.

The minimum number of characters or bytes that can be sent using the Poll command is 250. The actual maximum depends on the Poll parameters.

3.14.2 Send parameters

The following table lists the Send parameters available when inputting the Poll message. Please note that these parameters can only be issued after the “Text: “ prompt, preceded by a “.” (dot) at the first position on the line.

DAR [<address>]	Delivery Acknowledgement Requested. .DAR must be on the very first line after the “Text: “ prompt.
DATA <number of bytes>	Forward to mobile using 8 bit data.

For more information on these Send parameters, see section 3.4.2, Send parameters, page 14.

3.14.3 Poll Retry

To retry a poll, you must specify the message reference number. The LES will then retransmit the original poll.

Usage: **Poll -r <ref_no>**, where:

- <ref_no> is the reference number of a previously entered Poll command.

3.15 User

3.15.1 Description

By entering the User command, it is possible to change to another user account while the connection to the LES is open

Usage: **User <username> <password>**, where:

- <username> is the username for the other user account
- <password> is the password associated with that user account.

3.15.2 Error situations

Possible error messages:	Reason:
Login incorrect.	Incorrect username and/or password entered.

3.16 Pin

3.16.1 Description

Using the Pin command, the password can be changed. It is recommended to regularly change the password.

Usage: **Pin <username> <old password> <new password>**, where:

- <username> is the username for which the password is to be changed.
- <old password> is the password currently associated with the user account
- <new password> is the new password to be associated with the user account.

The LES will prompt the user to have the password re-entered. The password will only be changed if both passwords are the same. Example:

```
> pin 1234user xantic newxantic
Please re-enter your new password: newxantic
New password is now saved.
>
```

A password can be up to 19 characters long and contain all IA5 characters except the command line separation characters: "," (comma), ":" (colon) and " " (space).

3.16.2 Error situations

Possible error messages:	Reason:
--------------------------	---------

Failed: Unknown user.	<Username> entered on the command line was not correct.
Failed: Illegal field value.	<Old password> entered on the command line was not correct.
Failed: Passwords doesn't match.	Re-entered password different from new password on command line.

Examples

```
> pin 1234user xantic newxantic
Please re-enter your new password: wrong
Failed: Passwords doesn't match.
>
```

```
> pin 1234user wrong newxantic
Please re-enter your new password: newxantic
Failed: Illegal field value.
>
```

3.17 Help

Entering the Help command without any additional information will result in the LES returning a list of valid commands for the user, followed by a system prompt:

```
> help
Address ... Change an address for a message.
Delete .... Delete an earlier entered message.
Dnid ..... Manage closed network information.
Egc ..... Send broadcast message.
Mail ..... List mailbox(es).
Pin ..... Change the password.
Poll ..... Send poll command.
Quit ..... End this session.
Scan ..... Scan messages in store.
Read ..... Get mailbox data.
Send ..... Send message to mobile unit.
User ..... Register with username and password.
View ..... View an earlier entered message.
>
```

The Help command can also be used to obtain additional help information for a specific command. By entering **HELP <command>**, the LES will return the requested information.

The availability of commands to the user is controlled by the settings in the user registration data base and depends on the type of services that the user has requested. Commands that are not available to the customer are not listed in the output of the Help command. In the example above the Dsend command is not shown for this reason.

4 Deliver Notifications

4.1 General

Deliver Notifications provide information about the delivery of a message: a Negative Delivery Notification (NDN) provides the reason why a message could not be delivered. A Positive Delivery Notification (PDN) provides the date and time when the message was delivered to the mobile terminal. Deliver Notifications can be delivered via PSDN to an X.25 address or into a mailbox. For more information on delivery to an X.25 address see section 3.4.2 Send parameters, page 14, DAR parameter. In a single X.25 connection initiated by the LES, more than one Deliver Notification can be delivered. *Note* that Deliver Notifications cannot be delivered to an IP address on the Internet.

4.2 Negative Delivery Notifications

An NDN consists of two lines in the following format:

```
msg <reference number> to <address> not delivered due to <reason>
<store time>
```

The items between brackets are the following variables:

- **reference number** is 6-digit number in the range 000001 to 999999 (with leading zeroes);
- **address** is the destination of the original message, i.e. the mobile number that the message was sent to;
- **reason** is the reason why the message could not be delivered
- **store time** is the time the message was stored on the LES, the format of the time stamp is DD-MM-YY HH:MM

Example

```
msg 041491 to 400000001 not delivered due to no conn possible
21-NOV-01 14:42
```

Overview of reasons

Reason in NDN	Description
mess deleted by user	Indicates that the message has been deleted by the user.
mess deleted by operator	Indicates that the message has been deleted by the LES operator.
ocean region not served	Used only in case of poll and EGC. It indicates that a request was made to sent to a not covered ocean region. Should not happen als Xantic serves all ocean regions.
ses unknown	Indicates that the addressed mobile is unknown to the LES.
ses barred	Indicates that access to the addressed mobile is barred.
ses logged out	Indicates that the addressed mobile is logged out.
ses not in ocean region	Indicates that the addressed mobile is not (anymore) in the ocean region.
ses not commisioned	Indicates that the addressed mobile is not yet commisioned for commercial traffic.
no conn possible	Indicates that the message delivery has failed because the mobile

	does not answer to announcements. This is typically because the mobile is not reachable (e.g. switched off or has no view to the satellite) without having been logged out.
mess timed out	Indicates that the message has timed out without any forwarding attempts being made. This is typically because a queue of messages to the same mobile exist and this message is not the first message in the queue and at the same time the mobile is not reachable without having logged out.
dest timeout	Indicates that some error has occurred in the inmarsat c protocol between the LES and the mobile causing a timeout situation.
std c error	Indicates that the Inmarsat-C network or mobile did not operate correctly according to the Inmarsat C protocols.
ces not in service	Indicates that the LES is out of service, this is typically due to special modes of operation that rarely occur.
Tdm congested	Indicates that congestion exists for LES-to-mobile traffic..
Tdm not available	Indicates that the LES currently has no satellite channels for delivery of messages.
dest busy	Indicates that the mobile is continuously busy in the mobile-to-LES direction.
internal error	Indicates that an unusual internal error has occurred within the LES during message delivery.

4.3 Positive Delivery Notifications

A PDN consists of two lines in the following format:

```
msg <reference number> to <address>
delivered <delivery-time>
```

The items between brackets are the following variables:

- **reference number** is 6-digit number in the range 000001 to 999999 (with leading zeroes);
- **address** is the destination of the original message, i.e. the mobile number that the message was sent to;
- **delivery time** is the time the message was successfully delivered to the destination, the format of the time stamp is DD-MM-YY HH:MM

Example

```
msg 041466 to 400000001
delivered 21-NOV-01 14:44
```

5 EGC Parameters

EGCs are divided into three groups – FleetNET, SafetyNET and System. FleetNET is available to users authorised by Xantic, while access to SafetyNET and System services have restrictions and can only be granted with appropriate authority. (e.g. IMO or Inmarsat). The EGC command is used to send a FleetNET, SafetyNET or System message to one or more mobile terminals.

Usage: **EGC** <ocean>, <C1>, <C2>, <C3>, <C4>, <C5>

Comma, colon or space may be used to separate the EGC parameters on the command line.

5.1 Ocean

One digit, indicating the ocean region where the EGC-broadcast should be transmitted.

- 0 - Atlantic Ocean West
- 1 - Atlantic Ocean East
- 2 - Pacific Ocean
- 3 - Indian Ocean.
- 9 - All oceans

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal ocean region parameter	A value other than 0,1,2,3 or 9 was selected.

5.2 C1, Priority

One digit indicating the priority of the message, coded as follows:

- 0 - Routine
- 1 - Safety
- 2 - Urgent
- 3 - Distress

The LES will perform various checks on the input. If validation failed, the following error messages will appear:

Possible error messages:	Reason:
Illegal priority parameter	A value other than 0, 1, 2 or 3 was selected.
Usage: egc <ocean> <priority> <service> <address> <repetition> <presentation> Use help <command_name> for further help!	Syntax error.

5.3 C2, Service code

EGC's are divided into three groups – FleetNET, SafetyNET and System. FleetNET is available to users authorised by Xantic, while access to SafetyNET and System services have restrictions and can only be granted with appropriate authority. (e.g. IMO or Inmarsat)

EGC type group call messages for FleetNET need an EGC Network ID (ENID), which has to be downloaded once into each individual Inmarsat-C terminal belonging to the group. See examples on how to download an ENID.

Two digits indicating the type of EGC message is to be sent, coded as follows:

Code	Explanation	Message type
00	General Call	System
02	Group call	FleetNET
04	Urgency Message, Navigational Warnings to Rectangular areas.	SafetyNET
11	Inmarsat system messages	System
13	Coastal Warning	SafetyNET
14	Shore-ship Distress alert to circular area	SafetyNET
23	EGC system message	System
24	Urgency Message or Meteorological and navigational Warnings to circular areas	SafetyNET
31	Meteorological or Navarea warning or Meteorological Forecast.	SafetyNET
33	Download Group Identity	System
34	Search and Rescue Co-ordination to rectangular area	SafetyNET
44	Search and Rescue Co-ordination to circular area	SafetyNET
72	Chart correction service	FleetNET
73	Chart Correction Service for fixed areas	SafetyNET

In the list is also indicated whether the service is of SafetyNET, FleetNET or System type, this information is needed to interpret the repetition parameter.

The LES will perform various checks on the input. If validation failed, the following error messages will appear:

Possible error messages:	Reason:
Sorry, you have no access to this service	A service code was selected for which the user is not authorised.
Usage: egc <ocean> <priority> <service> <address> <repetition> <presentation> Use help <command_name> for further help!	A non-existing service code was entered.

5.4 C3, Address

An address string of up to 12 digits coded as relevant to the specific service code.

Code	Type of message	Address	Remarks
00	General Call	0	

02	Group call.	Up to 5 digits	ENID
04	Urgency message, NAV warning to rectangular area	12 characters	ex: 09N045E12123
11	Inmarsat system message.	Up to 2 digits	
13	Coastal Warning	4 digits	<Navarea><sub adr> <subject>
14	Shore ship Distress alert to circular area	10 characters	ex: 11N023E123
23	EGC system message.	9 digits	Mobile no
24	Urgency Message MET/NAV Warning to circular Area.	10 characters	ex: 56N025W123
31	Meteorological or Navarea Warning or Meteorological Forecast.	Up to 2 digits	Navarea
33	Download ENID	9 digits	mobile no
34	SAR Co-ordination to rectangular area	12 characters	ex: 34S120E56010
44	SAR Co-ordination to circular area.	10 characters	ex: 56N025W123
72	Chart correction services.	Up to 5 digits	ENID
73	Chart Correction Service for fixed areas	7 digits	

The LES will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal Address parameter	An illegal address parameter was entered, e.g. too many digits or characters entered..
Failed: Unknown ENID	An ENID was entered that is not assigned to the user.
Failed: Mobile 4xxxxxxx barred Failed: Cannot reach the mobile	The addressed terminal is barred.
Failed: Mobile 4xxxxxxx unknown Failed: Cannot reach the mobile	The mobile number does not exist in the Inmarsat-C environment.
Failed: Mobile 4xxxxxxx logged out Failed: Cannot reach the mobile	The mobile terminal is logged out.

5.5 C4, Repetition Code

5.5.1 Repetition codes for FleetNet, SafetyNET and system messages

Two digits indicating the repetition, coded as follows:

Code	Repetition scheme
01	transmit once after receipt
11	transmit on receipt followed by repeat 6 minutes later
61	transmit 1 hour after initial broadcast (twice)
62	transmit 2 hour after initial broadcast (twice)
63	transmit 3 hour after initial broadcast (twice)

64	transmit 4 hour after initial broadcast (twice)
66	transmit 12 hour after initial broadcast (twice)
67	transmit 24 hour after initial broadcast (twice)
70	transmit 12 hours after initial and 12 hours after 2. broadcast (three times)
71	transmit 24 hour after initial broadcast and 12 hours after 2. broadcast (three times)

NB 1: Use the Delete command to cancel the transmission of an earlier entered message.

NB 2: If a mobile terminal has successfully received the first transmission of a message, then the mobile terminal will ignore all later repetitions of that message.

The LES will perform various checks on the input. If validation failed, the following error messages will appear:

Possible error messages:	Reason:
Illegal repetition code parameter	A non-existing repetition code was selected.

5.5.2 Repetition codes for SafetyNET and System messages

The repetition codes are of the form <Multiplier><Delay> where <Multiplier> specifies the number of delay periods between each broadcast and <Delay> is a fixed number of hours.

The Multiplier digit may be any digit from 1 to 5 as follows:

Code	Explanation
1	1 specified delay period between broadcasts
2	2 specified delay periods between broadcasts
3	3 specified delay period between broadcasts
4	4 specified delay periods between broadcasts
5	5 specified delay periods between broadcasts

The delay digit coding is as follows:

Code	Explanation
2	1 hour delay; no echo
3	1 hour delay; with echo
4	6 hour delay; no echo
5	6 hour delay; with echo
6	12 hour delay; no echo
7	12 hour delay; with echo
8	24 hour delay; no echo
9	24 hour delay; with echo

5.6 C5, Presentation

The presentation field is coded as follows:

Code	Explanation
0	IA 5 alphabet
6	ITA 2 alphabet
7	8 bit data

The LES will perform various checks on the input. If validation failed, the following error messages will appear:

Possible error messages:	Reason:
Illegal EGC parameters	A non-existing presentation code was selected.

5.7 Examples for EGC

Example 1: ENID Download

Make ship 482380001 member of ENID 34, and delete ENID 622:

```
> EGC 1,0,33,482380001,1,0
Text:
/2
/N/34
/D/622/
131,CNN International
.s
40 characters.
Storing message...
Submitted 02-04-22 12:41. Reference number 233885.
>
```

The first line after the “Text: “ prompt specifies how many commands the packet contains, preceded by “/”. Then each command takes a single line, starting with “/”, followed by the command, “/”, and the ENID number. Legal commands are D for delete and N for new member. After the commands, the three digit LES ID for this particular ocean region and the name of the information provider are given, separated by a comma. The name of the information provider can be up to 25 characters.

Example 2: submission of a EGC message

Broadcast FleetNET message to ENID 10311:

```
> EGC 1,0,2,10311,1,0
Text:
Hamon fishing fleet rendezvous with mother ship at position 55 North,
36 W
.s
80 characters.
Storing message...
Submitted 02-04-22 12:41. Reference number 233887.
>
```

6 Poll Parameters

All Poll commands need a Data Network id (DNID), which has to be downloaded once into each individual Inmarsat-C terminal belonging to the (closed) data network. See examples for how to download a DNID.

Usage: poll <ocean,> <P1>, <P2>, <P3>,<P4>, <P5> <,P6>, <P7>, <P8>, <P9>, <P10>, <P11>

In the following, a description of all the Poll parameters is given.

Comma, colon or space may be used to separate the Poll parameters on the command line. Where applicable, a default poll parameter value is “selected” by leaving the respective poll parameter position on the command line empty. For this reason it is recommended to always use comma or colon as separator, not space.

6.1 OCEAN

One digit , indicating the ocean where the broadcast should be transmitted.

- 0 - Atlantic Ocean west
- 1 - Atlantic Ocean east
- 2 - Pacific Ocean.
- 3 - Indian Ocean

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal ocean region parameter.	The user selected a value other than 0,1,2 or 3

6.2 P1, Poll type

One character, indicating the type of the poll:

- G - group poll.
- I - Individual poll.
- N - Area poll, Navarea.
- R - Area poll, Rectangular.
- C - Area poll, Circular.

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal poll type parameter.	Parameter entered for poll type was other than G, I, N, R or C.

6.3 P2, Data network id (DNID)

Up to 5 digits signifying the Date Network ID.

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Failed: Unknown DNID.	The user entered a DNID not defined against the Ocean Region.

6.4 P3, Response type

One character, specifying the way the mobile terminal is expected to respond:

D – using a data report.

M – using a message

N - no response.

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal response type parameter.	Parameter entered for response type was other than D, M or N.

6.5 P4, Sub address

The sub-address within the mobile unit, in the range of 0-255. The default sub-address value is 0. Leading zero's are ignored.

The service does not check if the value entered is actually smaller than 256. For values higher than 255, the service takes the remainder after the value has been divided by 256.

Use of non-numeric characters for this parameter on the command line will not result in an error message. However, the result is unspecified.

6.6 P5, Address

Address corresponding to the address type as listed in the table below.

Poll type	Address	Remarks
Group Poll	0	No address applies. '0' must be entered on the command line.
Individual Poll	9 digits	Mobile number
Navarea Poll	Up to 2 digits	Navarea
Rectangular area Poll	12 digits	e.g.: 34S020E56010
Circular area Poll	10 digits	e.g.: 56N025W123

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Failed: Mobile <mobile number> Unknown. Failed: Cannot reach the mobile.	Mobile number does not exist (terminal not commissioned).

Failed: Mobile <mobile number> Barred. Failed: Cannot reach the mobile.	Mobile is barred for communication in Fixed to Mobile direction or bothways. Also see note 1).
Failed: Mobile <mobile number> Logged out. Failed: Cannot reach the mobile.	Mobile is not logged on in any ocean region.
Address error. Illegal address parameter.	Address value not correct, e.g.: - a mobile number with less than 9 digits; - an incorrect area address format; - group poll with a mobile number added; - individual poll without a mobile number;
Failed: Mobile not in ocean region.	Mobile is not in the selected ocean region. NB: The LES does prompt the user for text to be entered, followed by “.s”, before returning this error response.

6.7 P6, Command type

Cmd Type	Meaning	Poll Type, P1
00	Send unreserved report as required in response	G,I,N,R,C
01	Program Reserved data reporting. *)	I
02	Initiate Reserved data reporting. *)	G,I,N,R,C
03	Stop Reserved data reporting. *)	G,I,N,R,C
04	Program unreserved data reporting.	G,I,N,R,C
05	Initiate unreserved data reporting.	G,I,N,R,C
06	Stop unreserved data reporting.	G,I,N,R,C
07	Define macro-encoded message. *)	G,I,N,R,C
08	Macro encoded message. *)	G,I,N,R,C
09	Data transmission.	G,I,N,R,C
10	Download DNID.	I
11	Delete DNID.	I,G
64..127	User defined.	G,I,N,R,C

*) Not implemented, the LES will respond with “Illegal command type.”

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal command type.	Value entered for Command Type is not within the allowed ranges.
Sorry, you have no access to DNID management.	The privilege to download/delete DNIDs (Command Types 10 and 11) is blocked for the user.

6.8 P7, Member number

3 digits signifying the member number in the range 1-255. Used in download DNID Poll command. The default value is 1. The mobile terminal will provide this member number in subsequent reports.

The service does not check if the value entered is actually smaller than 256. For values higher than 255, the service takes the remainder after the value has been divided by 256.

Use of non-numeric characters for this parameter on the command line will not result in an error message. However, the result is unspecified.

6.9 P8, Start frame

4 digit start frame number used to program regular unreserved data reporting. Frame numbering starts at 0 at 0:00 UTC and one frame equals 8.64 seconds. Range is 0-9999
Default start frame value is 0.

The service will perform various checks on the input. If validation failed, the following error messages may appear:

Possible error messages:	Reason:
Illegal parameters in program command.	Example: frame number greater than 9999 specified.

6.10 P9, Reports per 24 hours

3-digit number indicating the count of data reports to be sent over 24 hours. Range is 1-500. Default number of reports is 10. The interval (in minutes) between reports can be derived by dividing 1440 (minutes in a day) by the number of reports specified.

The service does not check if the value entered is actually within range. Use of non-numeric characters for this parameter on the command line will not result in an error message. However, in these situations the result is unspecified.

6.11 P10, Acknowledgement

A single digit, indicating whether the Poll command is to be acknowledged (1) or not (0) by the mobile terminal. Default value is 0 (no acknowledgement).

Acknowledgements are returned in a predefined data report format.

The service does not check if the value entered is actually within range. Use of non-numeric characters for this parameter on the command line will not result in an error message. However, in these situations the result is unspecified.

6.12 P11, Spot id

This parameter is obsolete and - when entered – will be ignored. In the future this parameter may get another purpose.

6.13 Examples of Poll Command

Example

DNID download poll sent to MES logged into POR, DNID 4444 and 15 as member number.
Acknowledgement requested.

```
> poll 2,i,4444,d,0,400000001,010,015,0,0,1
Text:
.s
0 characters.
Storing message...
Submitted 02-03-18 06:35. Reference number 239792.
> scan 239792
239792 400000001 poll 18-MAR-02 06:35 delivered 1 attempts
```

Example

DNID delete poll sent to MES addressed to an ocean region that the MES is not logged onto:

```
> poll 3,i,4444,d,0,400000001,011,,,1
Text:
.s
0 characters.
Storing message...
Failed: Mobile not in ocean region.
>
```

Example

Example of group delete poll to all members of DNID 9400 in the Indian Ocean Region.

```
> poll 3,g,9400,d,0,0,11
Text:
Delete
.s
7 characters.
Storing message...
Submitted 02-04-09 05:32. Reference number 783170.
> scan 783170
783170 group/area poll 9-APR-02 05:32 delivered 1 attempts
```

Example

Example of Individual Download Poll command.

Start Frame (P8) = 1667 [One Frame equals 8.64 seconds. 5000 x 8.64sec = 1200UTC]

Reports per 24 hours (P9) = 144 [Every 10 Minutes.]

```
> poll 2,i,12345,d,0,400000001,04,1,1667,144,1
Text:
program poll frame 5000 equal 1200UTC every 10 minutes.
.s
56 characters.
Storing message...
Submitted 02-04-04 03:46. Reference number 256597.
```

Example

Example of Individual Poll with Command Type 00, requesting the MES to send unreserved data report as response.

```

> poll 2,i,12345,d,0,400000001,00,1,0,0,1
Text:
individual poll with ord response
.s
34 characters.
Storing message...
Submitted 02-04-04 05:03. Reference number 262994.
> scan 262994
262994 group/area poll 4-APR-02 05:03 in progress

```

Example

Example of group poll to all members of DNID 12345 in the Pacific Ocean Region.

```

> poll 2,g,12345,d,0,0,00
Text:
group poll to dnid in pacific
.s
30 characters.
Storing message...
Submitted 02-04-04 06:38. Reference number 273029.
> scan 273029
273029 group/area poll 4-APR-02 06:38 in progress

```

Example: Area Poll - Rectangular

This example shows a Rectangular area poll where southwest corner is at 33 degrees south and 110 degrees east and the extent of the rectangular area is 10 degrees north and 015 degrees east. Ie. '33S110E10015'.

```

> poll 2,r,12345,d,0,33s110e10015,00,1,0,0,1
Text:
rectangular area poll
.s
22 characters.
Storing message...
Submitted 02-04-04 05:47. Reference number 267345.
> scan 267345
267345 group/area poll 4-APR-02 05:47 in progress

```

Example: Area Poll - Circular

For circular area addressing, the addressed area is defined as a centre point, specified in terms of its latitude and longitude co-ordinates, and a radius in nautical miles (1 Nmi = 1852 m).

An Area Address Poll command addressed to a circular area is in the format DD(N/S)DDD(E/W)MMM (10 Characters). In the circular area poll example shown, the centre is 31 degrees south and 115 degrees east and the extent of the radius is 010 nautical miles. Ie. '31s115e010'.

```

> poll 2,c,12345,d,0,31s115e010,00,1,0,0,1
Text:
circular poll 31s115e010
.s
25 characters.
Storing message...
Submitted 02-04-04 06:13. Reference number 270270.

```

Annex A:**Xantic INMARSAT-C terrestrial access dial-in numbers
for both LES IDs 12 and 22 (T&T platform)**

Access mode	Access number in	Dial in numbers for LES 12 T&T platform	Dial in numbers for LES 22 T&T platform From 21/6/02
PSDN (X25)	Netherlands	02041594044	None
	Australia	0505293050012 (a)	0505293050022 (b)
Internet TCP/ IP Unencrypted	Australia & Netherlands	203.38.76.152	203.38.76.154 (b)
Internet TCP/ IP Encrypted	Australia & Netherlands	203.38.76.151 (c)	203.38.76.153 (c)

- (a) Asia-Pacific PSDN (X25) access to LES id 12 planned to be ready on 21st June 2002
- (b) Available from 21 June 2002 for the Atlantic Ocean Regions East and West and from 24 October 2002 for IOR and POR (HNS decommissioned in Perth).
- (c) Not available yet. Planned to be ready on 24th October 2002. Consult Xantic Customer Services for information related to this release after that date.