

---

## Wireless CbM Mote Firmware Guide (1.0.5R Project Revision)

---

*Rev.7*

Code base: C code

---

Created: 25/10/2018 2:21 P.M.

Author: Tom Sharkey

Last Modified: 06/01/2025

Modified by: Tom Sharkey

---

## Contents

1 Overview.....	3
2 Tool Requirements and Environment Setup.....	5
3 Code Structure .....	12
3.1 Initialisation:.....	14
3.2 Communication State Machine: .....	15
3.3 Data Handle, State Machine: .....	17

## Revision History:

Rev.0 - Initial Document

Rev.1 – General Edits

Rev.2 – General Edits

Rev.3 – Addition of Tool Requirements and Environment Setup section

Rev. 4 – General Edits

Rev. 5 – Addition of download and debugging note, made document font consistent.

Rev. 6 – Updating descriptions after firmware version update to 0.5

Rev 7 – Minor fixes to diagrams

## 1 Overview

This document provides an overview of the example firmware provided with the Condition Based Monitoring (CBM) kit. Companion documents are the “Getting Started Guide” provided with the CBM kit. This particular document version is based on the features available in the CBM code version referred to in the document title.

The purposes of this document are to enable the user to setup the firmware project in IAR Embedded Workbench, and to provide a high-level understanding of the programme structure, flow, and interactions, and to be able to customise the code. Please note that this code example is purely that – an example, and has not been tested or qualified in any way for production.


The embedded C code for the hardware in this project makes use of SmartMesh IP mesh network technology. The guide depicts a sample application that has been built on top of this SmartMesh framework. There are many functions which will not be discussed in this guide but can be investigated further using SmartMesh documentation. [<https://dustcloud.atlassian.net/wiki/spaces/ALLDOC/overview?mode=glob>]

A summary of the various C project files is given below:

- Main user application files:
  - o main\_prog.c \*(top level application code with state machine)
  - o scheduler.c (kernel module for managing scheduling timers, main loop)
  - o SmartMesh\_RF\_cog.c (SmartMesh functions for mote communication and callbacks)
  - o ADC\_channel\_read.c (initialise adc and holds adc sampling and fft math functions)
  - o shutdown.c (implements functions for putting microcontroller into low power sleep modes and waking it back up with a real-time clock)
  - o ext\_flash.c (functions which enable data storage and retrieval from the 1GB external flash chip which is connected to the microcontroller via SPI2)
  - o SPI0\_ADXL362.c (SPI functions for interfacing with the ADXL362)
  - o SPI1\_AD7685.c (SPI functions for interfacing with the AD7685)
- ADuCM4050 drivers and libraries – provided in the relevant IAR CMSIS pack.
- SmartMesh library source files:
  - o dn\_endianness.c
  - o dn\_hdlc.c
  - o dn\_ipmt.c
  - o dn\_lock.c
  - o dn\_serial\_mt.c
  - o dn\_uart\_handle.c

# WCBM Mote Firmware Guide

In the following code structure section, the high-level functionality of the main user application files will be explained.



**Figure 1: Hardware Overview**

## 2 Tool Requirements and Environment Setup


This project has been compiled and built in the IAR Embedded Workbench IDE version 8.22.2. The use of older versions may result in broken project options and/or project options not being fully transferred over and dependencies not working – these will then need to be manually set up.

The project depends on the installation of the appropriate CMSIS pack in IAR Embedded Workbench, which enables the correct ADuCM4050 drivers and libraries to be installed, as these are not shipped with the source code. The relevant SmartMESH libraries are included in the source code. If the project does not open correctly due to version mismatch – for example – the project can be set up from scratch as shown in the next steps.


Download the project from the [CBM Voyager GitHub](#) (further details on this are included in the CBM Setup Guide). Copy the directories provided in the 'C firmware' folder to your PC (src, ext, include, project) maintaining the same directory structure. If you are using IAR EWB ver. 8.22.2 or newer, the project should open successfully. The project is found in the 'project' directory of the provided files. Open the 'cbm.eww' workspace file in IAR EWB. If this opens successfully, with no broken project options, follow steps 3-8 below to install the correct CMSIS driver package for the ADuCM4050 microcontroller. It is also worth checking the remaining steps to ensure that the Project Options are set correctly and all of the required source files are present.

If the project cannot be opened successfully, follow all of the steps below to set up the project from scratch in IAR Embedded Workbench.

1. Delete all of the files with the name 'cbm.\*' in the 'project' folder (e.g. cbm.eww, cbm.ewt etc). Delete the 'project\settings' folder. These will be recreated in the next steps. Ensure that the 'ADuCM4050\_moreSRAM.icf' file is NOT deleted.
2. File->New Workspace
3. Project->CMSIS-Pack->Pack Installer
4. Select ADuCM4x50\_DFP->3.2.0, right-click this package, and select install
5. Select ARM -> CMSIS -> 5.7.0, right-click and install, then press OK. Versions may vary for the DFP and CMSIS packages, but the version installed should be the same or newer than the versions shown.




6. Project->Create New Project->Empty CMSIS Pack Project
7. Select ADuCM4x50




8. Select Pack Components shown below. These components may be highlighted in orange until all the correct options are highlighted, but should turn green when all options are selected correctly.

Software Components	Sel.	Variant	Vendor	Version	Description
ADuCM4050			Analog Devices		ARM Cortex-M4 52 MHz, 96 kB RAM, 508 kB ROM
> Board Support		EV-COG-AD405	AnalogDevices	3.1.0	Analog Devices EV-COG-AD4050LZ Evaluation Board
> CMSIS					Cortex Microcontroller Software Interface Components
CORE	<input checked="" type="checkbox"/>		ARM	5.4.0	CMSIS-CORE for Cortex-M, SC000, SC300, ARMv8-M, ARMv8.1-M
DSP	<input type="checkbox"/>	Source	ARM	1.8.0	CMSIS-DSP Library for Cortex-M, SC000, and SC300
NN Lib	<input type="checkbox"/>		ARM	1.3.0	CMSIS-NN Neural Network Library
> RTOS (API)				1.0.0	CMSIS-RTOS API for Cortex-M, SC000, and SC300
> RTOS2 (API)				2.1.3	CMSIS-RTOS API for Cortex-M, SC000, and SC300
> CMSIS Driver					Unified Device Drivers compliant to CMSIS-Driver Specifications
> Device					Startup, System Setup
Cycle Count	<input type="checkbox"/>		AnalogDevices	3.4.0	Common utility functions for ADuCM4x50 examples
> Drivers					Analog Devices driver components for ADuCM4x50 devices
ADC	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	ADC
BEEP	<input type="checkbox"/>		AnalogDevices	3.4.0	BEEP
CRC	<input type="checkbox"/>		AnalogDevices	3.4.0	CRC
Crypto	<input type="checkbox"/>		AnalogDevices	3.4.0	Crypto
DMA	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	DMA
Flash	<input type="checkbox"/>		AnalogDevices	3.4.0	Flash Controller
GPIO	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	GPIO
I2C	<input type="checkbox"/>		AnalogDevices	3.4.0	I2C
Interrupt	<input type="checkbox"/>		AnalogDevices	3.4.0	External Interrupt
Power	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	System Clock and Power Management
RNG	<input type="checkbox"/>		AnalogDevices	3.4.0	Random Number Generator
RTC	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	RTC
SPI	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	SPI
SPORT	<input type="checkbox"/>		AnalogDevices	3.4.0	SPORT
TMR	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	GP Timer
UART	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	UART
WDT	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	WDT
Examples Support	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	Common utility functions for ADuCM4x50 examples
Global Configura	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	Global configuration files for ADuCM4x50 drivers
Silicon Revision	<input checked="" type="checkbox"/>	0.0	AnalogDevices	3.4.0	Silicon Revision 0.0
Startup	<input checked="" type="checkbox"/>		AnalogDevices	3.4.0	System Startup for ADuCM4x50


9. Save the project in the 'project' folder. The source files will then be at the correct level relative to the project.
10. Project->Add Files: Add the source files provided, to the project (user application files, and SmartMESH library files) from the src, src/system, and ext/SmartMesh/src folders. These can be organized in Groups if desired (Project->Add Group). There is no need to add the header files in the various 'include' folders to the project explicitly as these will be added as compiler search options in step 10.



- Project->Options->C/C++ Compiler: Add the include directories shown below \$PROJ\_DIR\$\\.\include and \$PROJ\_DIR\$\\.\ext\SmartMesh\include




- Project->Options->General Options->Target: Select the floating-point unit VFPv4 single precision







## 13. Project->Options->General Options->Library Configuration: Ensure that DSP library is checked



## 14. Project->Options->Linker, Select Override default and enter \$PROJ\_DIR\$\ADuCM4050\_moreSRAM.icf




15. Project->Options->Debugger->Setup. Select J-Link/J-Trace in the Driver selection. Ensure also that in the Download tab for the Debugger options, Use flash loader is selected.




16. File->Save Workspace (in the 'project' directory)
17. Project->Rebuild All

The project should compile and link without errors and be ready to download and debug to the mote.

Note, the first time you download and debug this program, you may get the following prompt:



- Select OK, and proceed to the next page




- Select Cancel. It is not necessary to specify a device. The flashing process will begin once this menu has been closed.

### 3 High Level Overview of Operation

A summary of the high-level operation of Voyager 3 can be seen in the below figure. Note, the sequence of events shown in this figure are collectively known as a **Stage**. The code goes through a simple order of operations: Idle, Sample, FFT, Transmit and optionally Sleep. However, because SmartMesh IP has a packet size limit of 90 bytes, any data sent that is greater than 90 bytes in length must be broken into smaller packets which are transmitted separately which is explained further in Section 5.4.

When a mote is connected to the manager via the GUI, Stages are repeated until the GUI is disconnected.

If the mote is connected to the manager through the Terminal Mode, the user passes in the argument NUM\_STAGES to control how many times to repeat the sequence.



VOYAGER 3 TIMELINE OF EVENTS. THIS COLLECTION OF EVENTS IS CALLED A STAGE

## 5 Code Structure

The function of the main program is to:

- Initiate a connection between mote and manager
- Sample acceleration data via ADC
- Store data in an external flash if the number of ADC samples per frames is greater than 1024
- Transmit raw and FFT data
- Put microcontroller into a low-power sleep mode for user-defined number of seconds
- Handle changing sampling parameters from the manager

The overall operation of the program is depicted in Figure 2, with the initialization, communication state machine, and data handling state machine, scheduler timing, and data format depicted in the following sections.




Figure 2: High Level Diagram

## 5.1 Initialisation:

Name	Description
<b>Clock dividers</b>	Simple constants that set frequencies corresponding to hardware clock frequencies. These are used throughout the code, such as when setting clock dividers later in initialization.
<b>Mote parameters</b>	My reply and my error are variables set for the user to make use of. They are currently not used in this version of the program. NET_ID is used to store the network ID number of the manager. Join_duty is a value between 0 and 255, and decides how quickly the mote will join the network, at the cost of greater energy usage. Ms_per_packet is used to set the millisecond gap between packets received.
<b>Initialisation of Mote and Variables and Peripherals (UART)</b>	Initializes variables necessary for application function. Calls dn_uart_init which initializes the UART of the microcontroller.
<b>Start Scheduler</b>	Begins and verifies correct function of the timer.
<b>State machines</b>	The main body of the program. The CONNECT and TRANSMIT state machines are described in further detail below. They are responsible for joining the mote to the network and beginning the flow of data between mote and manager (both directions).




Figure 3: Initialisation

## 5.2 Communication State Machine:




Figure 4: Communication State Machine

---

## WCBM Mote Firmware Guide

State	Description
<b>Boot Status</b>	A state that is only used for program startup.
<b>Mote Status</b>	This is the “idle” state for the mote. The mote begins the state machine here (after moving on from boot status. The program will return to this state if it reaches a program timeout, meaning it could not successfully connect to the network.
<b>Open Socket</b>	Here the mote schedules a connection to the manager. The mote is initializing a TCP three-way handshake by sending a request to begin a session with the manager.
<b>Bind Socket</b>	If the manager returns an OK to the open socket request, the mote moves into the bind socket state. A socket must be bound before data can be streamed from mote to manager.
<b>Set NetID</b>	If the bind socket state returns a success, the set NetID state is entered. This sets the ID of the network with a constant (NETID) chosen before program launch– the default is 2425.
<b>Get NetID</b>	Stores the network ID chosen by the set NetID state as a variable.
<b>Set JoinDC</b>	Sets the join duty cycle. This variable goes between 1 and 255 and determines how quickly a mote joins the manager. Choosing a high duty cycle (255 -> 100%) will allow the network to form more rapidly but the motes will also use more power.
<b>Join</b>	The mote will attempt to search for a network with the same NetID and join it.
<b>Request Service</b>	Request new / changed service level – triggers on bandwidth change event.
<b>SendTo</b>	Final state of the mote. In this state, the mote will send the adcData Buffer to the manager whenever the data is available.




## WCBM Mote Firmware Guide

### 5.3 Data Handle, State Machine:


State	Description
<b>RADIO SETUP</b>	The microcontroller will wait in this state until the communication state machine reaches its SendTo state.
<b>WAIT FOR READY</b>	The microcontroller will remain in this state until it gets a ready signal from the manager so that it is not collecting samples which will never be observed.
<b>NEW_PARAM</b>	<p>This state acts as a “double buffer” for parameter changes to the mote. It checks for updates to the sampling frequency and resolution at the beginning of the state machine. These parameters cannot be changed again until we return to the new parameter state. This ensures that key parameters do not change during the execution of the state machine as a result of multithreading.</p> <p>The microcontroller will also not progress from this state unless it has received a ready signal from the manager.</p>
<b>ACQ</b>	Here the mote acquires data from the ADC. It reads in the data from the UART to the adcBuffer. When this stage has completed, we have a buffer that is full of “RAW” adc data, but the FFT has not yet been calculated and appended to the buffer.
<b>SEND TO FLASH</b>	<p>If the user sets the number of samples per frame to be greater than 1024 then the 1GB external flash will be used. Data is sent to the external flash via SPI2 port. Up to 1/3GB can be collected per axis at the user defined sampling frequency because the data storage operation happens in parallel with the data sampling operation.</p> <p>Note, if external flash is used then FFT calculations will not be performed and only the raw data will be transmitted over the radio.</p>
<b>CALC</b>	<p>In this state we make use of some basic ARM math functions to fourier transform the raw data. It then appends this fft data to the adcBuffer, which is now ready to be transmitted to the manager. The transmission of data also begins in this state.</p> <p>Note, if external flash is used then FFT calculations will not be performed and only the raw data will be transmitted over the radio.</p>
<b>GET DATA FROM FLASH</b>	If the user sets the number of samples per frame to be greater than 1024 then the 1GB external flash will be used. Data will be read from the flash one page at a time (1024 samples per page) into the microcontroller’s RAM and transmitted via the radio.
<b>TX</b>	TX is the transmission state, and the mote will remain here until it detects that the entire ADC data buffer has been successfully sent.
<b>WAIT</b>	<p>This state is only entered if sleep duration has been defined to be zero seconds.</p> <p>Following transmission of the data, the mote enters the wait state. The mote remains in the wait state until a flag is set indicating that a timer has expired.</p>
<b>SLEEP MCU</b>	<p>This state is only entered if sleep duration has been defined to be greater than zero seconds.</p> <p>Following transmission of the data, the mote enters the low power sleep state. Upon entry to sleep a real-time clock (RTC0) is programmed and begins counting up to the target sleep duration. The minimum granularity for sleep duration is one second because RTC0 runs at 1Hz.</p>
<b>WAKEUP</b>	This state re-enables certain functions that were disabled prior to entering the sleep state

## WCBM Mote Firmware Guide



## 5.4 Packet Formatting

Formatting data to be sent (shown for a sample size of 512 words):



*Figure 8: Packets for transmission*

If external flash is used then the FFT calculations will not be performed and only the raw data shall be transmitted.

---

## WCBM Mote Firmware Guide

### 6 External Flash

Voyager has a 1GB NAND flash memory device connected to the microcontroller via SPI2. The part name of the flash is “Micron MT29F1G01ABAFDWB-IT” and its datasheet can be found [here](#).

Firmware Version 0.5 and onwards makes use of this flash memory which allows up to 1GB to be collected in a single Stage, without interruption to the selected sampling frequency.

If the user selects that more than 1024 samples should be collected per frame, then the firmware automatically stores and retrieves data to/from flash.

**NOTE:** If external flash is used then FFT will not be calculated.

The flash chip is divided into 64 pages. Each page contains 1024 blocks. Each block contains 2048B of data and 128B of error correction codes which are automatically enabled.

Each axis has 1/3 of the flash memory dedicated to it, as shown in **Error! Reference source not found.:**

FLASH DIVISION