

SUMMARY OF INDICATIONS

Acupoints

Head









- Head injury or pain: 8, 3, 7, 6, 2, 10, 1, 11, 20, 23
- Headaches:
 - in general: 1, 3, 7, 4, 6, 2, 10, 11, 19, 20
 - migraine: 1, 7, 12
- Throat: 10, 3, 14, 1, 7, 12
- Toothache: 4, 1, 18, 21
- Ears: 3, 1









Trunk

- (Nocturnal) leg cramps: 4
- Chest: 3, 2, 1, 7
- Abdomen:
 - upper: 5, 6
 - lower: 9, 5, 6, 2, 19
- Ovaries and uterus: 8, 13, 5, 6
- Hernia: 5, 6, 19
- Sciatica: 9, 4, 5, 6, 24, 22
- Muscle cramps: 25, 26
- Lungs: 7
- Stomach: 8, 5, 6, 2
- Menstruation: 13, 5, 2, 15, 26, 19
- Neck: 8, 1, 7, 16, 17, 26, 23
- Backache:
 - in general: 9, 4, 5, 6, 17, 20, 22, 23
 - upper back: 17, 22, 23, 9, 4
 - lower back: 4, 5, 6, 20
- Muscle pain brought on by straining or twisting: 4
- Lumbago: 9, 4, 5, 6, 14, 1, 7, 24
- Testicles: 4, 5, 6
- Urinary tract /genitals: 13, 25, 26, 19
- Neck whiplash: 8, 4, 1, 7
- Neuralgia: 4


Arms and legs

- Arms: 8, 3, 2, 12, 17, 23
- Arthritis/arthritis, gout: Use paingone plus at the site of the pain
- Legs: 9, 4, 5, 6
- Thighs: 9
- Elbows: 8, 3, 2, 14, 1, 23
- Ankles: 4, 5, 6, 1, 25, 18, 19, 20
- Hands: 3, 2, 10, 1, 12
- Hips: 4, 5, 6
- Knees: 9
- Armpits: 2, 12
- Forearms: 8, 2, 10, 1, 12
- Wrists: 7, 3, 12
- Shoulders: 8, 3, 2, 14, 1, 7, 17, 26
- Fingers: 10, 3, 2, 1, 12
- Feet: 4, 5, 6, 1, 25, 18, 19, 20





17




18




19




20




21




22




23




24



25



26



Troubleshooting

The device is not emitting any pulse

- a) Check that you are holding the device correctly, being sure to make contact with the metal ring. See page 4 for further details.
- b) Check that the battery has been inserted the correct way. See the symbol on the reverse of the device for an illustration of the correct polarity.
- c) The battery may no longer contain any charge. Insert a new battery.
- d) If you believe the device suffers from a manufacturing fault, DO NOT attempt to repair the device. Return to the point of purchase. Devices with manufacturing faults are covered by a 12-month replacement guarantee.