

Booting Android

Bootloaders, fastboot and boot images



License



These slides are available under a Creative Commons Attribution-ShareAlike 3.0 license. You can read the full text of the license [here](http://creativecommons.org/licenses/by-sa/3.0/legalcode)

<http://creativecommons.org/licenses/by-sa/3.0/legalcode>

You are free to

- copy, distribute, display, and perform the work
- make derivative works
- make commercial use of the work

Under the following conditions

- Attribution: you must give the original author credit
- Share Alike: if you alter, transform, or build upon this work, you may distribute the resulting work only under a license identical to this one (i.e. include this page exactly as it is)
- For any reuse or distribution, you must make clear to others the license terms of this work

The originals are at <http://2net.co.uk/slides/android-boot-slides-2.0.pdf>

About Chris Simmonds



- Consultant and trainer
- Working with embedded Linux since 1999
- Android since 2009
- Speaker at many conferences and workshops

"Looking after the Inner Penguin" blog at <http://2net.co.uk/>



<https://uk.linkedin.com/in/chrisdsimmonds/>



<https://google.com/+chrissimmonds>

Overview


- Android system images: boot, recovery, system, userdata and cache
- Bootloaders for Android
- The fastboot protocol
- Using fastboot to program new system images

Image files

- A typical build for an Android device produces five image files in `out/target/product/[name]`

Image	Description
boot.img	Kernel + ramdisk used for normal boot
recovery.img	Kernel + ramdisk used to boot into recovery mode
system.img	File system image for /system
userdata.img	File system image for /data
cache.img	File system image for /cache

Typical flash memory layout



The bootloader

- All systems need a bootloader
- Responsible for:
 - Early hardware initialisation
 - Load and boot kernel and initial ram file system
 - System maintenance, including loading and flashing new kernel and system images
- Example: U-Boot
 - Open source
 - Used in many dev boards (Beaglebone, Raspberry Pi) and in many shipping products
 - <http://www.denx.de/wiki/U-Boot/WebHome>

Booting Android

- It is possible to boot Android using a normal bootloader such as U-Boot
- However, most devices include Android-specific features:
 - Support normal and recovery boot modes
 - Ability to load kernel + ramdisk blobs (boot.img and recovery.img)
 - The fastboot protocol
- Example: LK (Little Kernel)
 - A version of LK is at [git://codeaurora.org/kernel/lk.git](https://codeaurora.org/kernel/lk.git)
 - Supports many Qualcomm-based devices as well as Beagleboard and PC-x86


The Android bootloader

- Pre JB 4.2, AOSP had source for a simple bootloader in `bootable/bootloader/legacy`
 - Used in early handsets (Android Dev Phone, HTC Dream)
 - Not updated since the Eclair release
 - Some of this code may have found its way into proprietary bootloaders


Android boot and recovery images

- The files `boot.img` and `recovery.img` are created by the tool `mkbootimg` (the code is in `system/core/mkbootimg`)
- They contain a compressed kernel, the kernel command line and, optionally, a ramdisk in the normal Linux compressed `cpio` format
- Most Android bootloaders can read and load these images into memory
- The format is defined in `bootimg.h`

Boot and recovery image format



Boot sequence



Reverse-engineering a boot image

- Sometimes it is useful to extract the files from a boot or recovery image
- There are numerous tools to do so, for example boot-extract

<https://github.com/csimmonds/boot-extract>

```
$ boot-extract recovery.img
Boot header
  flash page size 2048
  kernel size 0x432358
  kernel load addr 0x10008000
  ramdisk size 0x173740
  ramdisk load addr 0x11000000
  name
  cmdline
zImage extracted
ramdisk offset 4403200 (0x433000)
ramdisk.cpio.gz extracted
$ ls
ramdisk.cpio.gz  recovery.img  zImage
```

Extracting files from a ramdisk

- The ramdisk is just a compressed cpio archive
- Extract the files like so:

```
$ zcat ramdisk.cpio.gz | cpio -i
5665 blocks
$ ls
charger          fstab.manta      property_contexts
...
```

Creating a new ramdisk

- Do the following

```
$ cd some-directory
$ find . | cpio -H newc --owner root:root -ov > ~/ramdisk.cpio
$ cd ~
$ gzip ramdisk.cpio
```

- The end result will be `ramdisk.cpio.gz`

Creating a new boot image

- You can create a boot or recovery image using the `mkbootimg` command
- For example:

```
$ mkbootimg --kernel zImage --ramdisk ramdisk.cpio.gz \  
--base 0x10000000 --pagesize 2048 -o recovery-new.img
```

- `--base` is used by `mkbootimg` to calculate the kernel and ramdisk load addresses as follows:
 - `kernel_addr = base + 0x00008000`
 - `ramdisk_addr = base + 0x01000000`

Fastboot

- Fastboot is a USB protocol and a command language for various maintenance and development tasks
- The fastboot protocol is defined in
 - `bootable/bootloader/legacy/fastboot_protocol.txt` (up to JB 4.1)
 - `system/core/fastboot/fastboot_protocol.txt` (JB 4.3 and later)

NOTE: fastboot is not about the speed of booting; it is about making the development process simpler (and faster)

Booting into the bootloader

- On a typical Android device you can boot into the bootloader by:
 - powering on while pressing various buttons (Google for details)
 - from a running device, typing:

```
$ adb reboot-bootloader
```

- Once the device has booted into the bootloader you can use the *fastboot* command on the development machine to communicate with it

fastboot commands (1/3)

Basic commands

Command	Description
devices	List devices attached that will accept fastboot commands
getvar	Get a variable
continue	Continue boot process as normal
reboot	Reboot device
reboot-bootloader	Reboot back into bootloader

fastboot commands (2/3)

Flashing commands

Command	Description
<code>erase <partition></code>	Erase <partition>
<code>flash <partition></code>	Erase and program <partition> with <partition>.img of <i>current product</i>
<code>flash <partition> <filename></code>	Erase and program <partition> with <filename>
<code>flashall</code>	Erase and program boot.img, recovery.img and system.img of <i>current product</i> and then reboot

Where

<partition> is one of boot, recovery, system, userdata, cache
current product is \$ANDROID_PRODUCT_OUT

Note: the location and size of partitions is hard-coded in the bootloader

fastboot commands (3/3)

Special commands

Command	Description
oem	Device-specific operations
boot <kernel> <ramdisk>	Load and boot kernel and ramdisk

Example:

```
$ fastboot -c "kernel command line" boot zImage ramdisk.cpio.gz
```

fastboot variables

The getvar command should return values for at least these

Variable	Meaning
version	Version of the protocol: 0.4 is the one documented
version-bootloader	Version string of the Bootloader
version-baseband	Version string of the Baseband Software
product	Name of the product
serialno	Product serial number
secure	If "yes" the bootloader requires signed images


Unlocking the bootloader

- Most devices ship with the bootloader locked
 - `fastboot getvar secure` returns *true*
- Unlocking - where it is allowed - is device specific
- For example, on recent Nexus devices you use a `fastboot oem` command

```
$ fastboot oem unlock
```

- Answer *yes* to the on-screen prompt
- For security reasons, this wipes the data and cache partitions

What goes where?



Flash memory devices

- In almost all cases data is stored in flash memory devices
- There are three main types
- Raw NAND: NAND flash chip(s) soldered to the board
- SD and MicroSD cards: Flash memory and controller in a removable package
- eMMC: SD card memory encapsulated in a chip soldered onto the board

NAND flash

- NAND flash chips are accessed via the Linux MTD (Memory Technology Device) drivers
- Partitions are named /dev/block/mtdblockN where N is the partition number
- /proc/mtd lists the partitions and sizes

```
# cat /proc/mtd
dev:      size      erasesize  name
mtd0: 05660000 00020000 "system"
mtd1: 04000000 00020000 "userdata"
mtd2: 04000000 00020000 "cache"
```

SD and eMMC

- The controller chip splits flash memory into 512-byte sectors just like hard drives
- Accessed via the Linux mmcblk driver
- Partition device nodes have names of the form *mmcblk[chip number]p[partition number]*
- For example:

```
/dev/block/mmcblk0p3 /system  
/dev/block/mmcblk0p8 /data  
/dev/block/mmcblk0p4 /cache
```

File systems for raw NAND flash

- NAND flash devices require special file system support, such as:
- jffs2 (Journalling Flash File System 2)
 - Note: incompatible with the Dalvik run-time (no writeable mmaped files)!
- yaffs2 (Yet Another Flash File System 2)
- ubifs (Unsorted Block Image File System)
- Most Android devices with NAND flash use yaffs2

File systems for eMMC

- eMMC devices "look" like hard drives
- So they use the same file system types
- The preferred type in most Android devices is *ext4*

SD cards and other removable media

- This includes SD, microSD and USB flash drives
- For compatibility with other operating systems they come pre-formatted with FAT32
- Use the Linux vfat driver

Summary

- Many Android devices have a bootloader that supports the fastboot protocol
- Using fastboot, you can program the image files produced by the Android build into a device