

**SONY®**

DATA PROJECTOR

<b>VPL-CX61</b>	<b>VPL-FX40</b>
<b>VPL-CX63</b>	<b>VPL-FX40L</b>
<b>VPL-CX75</b>	<b>VPL-FX51</b>
<b>VPL-CX76</b>	<b>VPL-FX52</b>
<b>VPL-CX80</b>	<b>VPL-FX52L</b>
<b>VPL-CX85</b>	<b>VPL-PX35</b>
<b>VPL-CX86</b>	<b>VPL-PX40</b>
<b>VPL-FE40</b>	<b>VPL-PX41</b>
<b>VPL-FE40L</b>	

PROTOCOL MANUAL  
1st Edition (Revised 10)

## **警告**

このマニュアルは、サービス専用です。

お客様が、このマニュアルに記載された設置や保守、点検、修理などを行うと感電や火災、人身事故につながる可能性があります。

危険をさけるため、サービストレーニングを受けた技術者のみご使用ください。

## **WARNING**

This manual is intended for qualified service personnel only.

To reduce the risk of electric shock, fire or injury, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

## **WARNUNG**

Die Anleitung ist nur für qualifiziertes Fachpersonal bestimmt.

Alle Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal ausgeführt werden. Um die Gefahr eines elektrischen Schlages, Feuergefahr und Verletzungen zu vermeiden, sind bei Wartungsarbeiten strikt die Angaben in der Anleitung zu befolgen. Andere als die angegeben Wartungsarbeiten dürfen nur von Personen ausgeführt werden, die eine spezielle Befähigung dazu besitzen.

## **AVERTISSEMENT**

Ce manuel est destiné uniquement aux personnes compétentes en charge de l'entretien. Afin de réduire les risques de décharge électrique, d'incendie ou de blessure n'effectuer que les réparations indiquées dans le mode d'emploi à moins d'être qualifié pour en effectuer d'autres. Pour toute réparation faire appel à une personne compétente uniquement.

# Table of Contents

## 1. Introduction

## 2. RS-232C (VPL-CX75 and VPL-CX76 are excluded.)

2-1. Communication Specifications .....	1
2-2. Command Block Format .....	2
2-3. Block Format .....	3
2-4. Connection .....	4
2-5. Communication Procedure .....	4
2-5-1. Outline of Communication .....	4
2-6. Communication Rules .....	5
2-7. Approximate Return Waiting Times .....	5

## 3. NETWORK

3-1. Introduction .....	6
3-1-1. Advertisement .....	6
3-1-1-1. Function .....	6
3-1-1-2. Setup Items .....	6
3-1-2. Remote Control .....	7
3-1-2-1. Function .....	7
3-1-2-2. Setup Items .....	7
3-2. SDAP Protocol .....	8
3-3. SDCP Protocol .....	9
3-3-1. Format .....	9
3-3-1-1. Header .....	9
3-3-1-2. Community .....	9
3-3-1-3. Command .....	10
3-3-1-4. SET Request .....	11
3-3-1-5. GET Request .....	11
3-3-1-6. ERROR Response .....	11
3-3-2. Items .....	12
3-3-2-1. Model Dependent Category .....	12
3-3-2-2. Equipment Information Acquisition (80**h) .....	12
3-3-2-3. Network Information Acquisition (90**h) .....	13

3-3-3. Error Code .....	14
3-3-3-1. Item Error .....	15
3-3-3-2. Community Error .....	15
3-3-3-3. Request Error .....	16
3-3-3-4. Network Error .....	16
3-3-3-5. Comm Error .....	17
3-3-3-6. NVRAM Error .....	17
3-4. PJLink .....	18
3-4-1. Command Details .....	18
3-4-2. PJ-Link Protocol Connection .....	20
3-4-3. PJ-Link Protocol Command .....	20
3-5. DDDP .....	25

## Appendix A. Setup Method For VPL-PX35 and PX40

A-1. Command .....	26
A-1-1. Setting .....	26
A-1-2. Display .....	27
A-2. Setting Command .....	28

## Appendix B



# 1. Introduction

This protocol manual describes the basic configuration and basic operations of various commands used for projector. Projector can be controlled using the commands provided in “Appendix”. Using an external CONTROLLER , etc., inputs can be switched and the power can also be turned on and off. In the following paragraphs, “CONTROLLER” means an external device such as a PC which controls projector using these commands.

## 2. RS-232C (VPL-CX75 and VPL-CX76 are excluded.)

### 2-1. Communication Specifications

#### <RS-232C Communication Signal>

- Full duplex communication channels (Flow control not performed.)
- Start-stop synchronism system
- Baud rate: 38.4 kbps (bits per second)
- The bit configuration is defined as follows.

1 START Bit + 8 DATA Bits + 1 PARITY Bit + 1 STOP Bit

START BIT	D0 (LSB)	D1	D2	D3	D4	D5	D6	D7 (MSB)	PARITY (EVEN)	STOP BIT
--------------	-------------	----	----	----	----	----	----	-------------	------------------	-------------

EVEN Parity.....Total number of “1”s from D0 to D7 is an even number.

2-2. Command Block Format

The code from B0 to B7 as described below are transmitted.

	Transmission from the Master side	Reception in the Master side	Reception in the Master side (With Data)		
B0	START CODE : 0 × A9				
B1	ITEM NUMBER	ACK / NAK	ITEM NUMBER		
B2					
B3	SET / GET	ACK	REPLY		
B4	DATA	DUMMY DATA	DATA		
B5					
B6	CHECK SUM				
B7	END CODE : 0 × 9A				

B0 START CORD  
Common in the all FORMAT

B6 CHECK SUM  
B1 to B5 are calculated by OR;

<Example of Calculation>					
0 × A9	1010	1001	0 × A9	1010	1001
0 × A9	1010	1001	0 × 9A	1001	1010
Answer	1010	1001	Answer	1011	1011
		0 × A9			0 × BB

B7 END CODE  
Common in the all FORMAT

## 2-3. Block Format

Transmission from the Master side		Data transmission to the Projector
B0	START CODE	Start of Command
B1	ITEM NUMBER	Set the Data Category Value desired. Refer to the Appendix B Table 1 for details.
B2		
B3	SET / GET	SET: 0 x 00 (Set data) GET: 0 x 01 (Get data)
B4	DATA	SET: Data to be set (Refer to the Appendix B Table 2) GET: Unused. Set Dummy data [0 x 00, 0 x 00]
B5		
B6	CHECK SUM	Check Sum
B7	END CODE	End of Command
Reception in the Master side		Receive results of the data transmission from the Projector.
B0	START CODE	Start of Command
B1	ACK / NAK	Results correspond with the data transmission Refer to the Appendix B Table 3 for the data in detail.
B2		
B3	ACK	[0 x 03] Express Reply data either of ACK, or NAK
B4	DUMMY DATA	This data does not mean any senses. Dummy Data [0 x 00, 0 x 00] is stored.
B5		
B6	CHECK SUM	Check Sum
B7	END CODE	End of Command
Reception in the Master side (With Data)		Receive data from the Projector
B0	START CODE	Start of Command
B1	ITEM NUMBER	Data to acquire Refer to the Appendix B Table 1 in detail.
B2		
B3	REPLY	[0 x 02] Express data to be Reply data
B4	DATA	Received data Refer to the Appendix B Table 2 in detail.
B5		
B6	CHECK SUM	Check Sum
B7	END CODE	End of Command

## 2-4. Connection

### <RS-232C Connection>

Communication is enabled by the use of a D-Sub 9 Pin cross (reverse) cable.  
The pin assignment of D-Sub 9 Pin and D-Sub 25 Pin is as follows.

D-Sub 9 Pin	D-Sub 25 Pin	Name	
Shell = FG	1	FG	Grounding for safety protection or cable shield
3	2	TxD	Transmission data
2	3	RxD	Reception data
7	4	RTS	Transmission request
8	5	CTS	Transmission permission
6	6	DSR	Data set ready
5	7	SG	GND for signal
1	8	DCD	Data channel signal carrier detection
4	20	DTR	Data terminal ready
9	22	RI	Calling display (Presence/absence of calling signal)

Pins indicated as D-Sub 25 Pin are not used.

Assured cable length: 15 m (However, assurance may not be applicable for some cables.)

The software for controlling the projector from a PC is intended for performing transmission and reception for only the TxD and RxD lines.

Therefore there is no handshake normally performed by RS-232C.

## 2-5. Communication Procedure

### 2-5-1. Outline of Communication

All communication between CONTROLLER (PC, etc.) and DEVICE (PROJECTOR) is performed by the command block format. Communication is started by the issue of a command at CONTROLLER and ended when the return Data is sent to CONTROLLER after DEVICE receives the command. CONTROLLER is prohibited from sending several commands at one time. This means that after CONTROLLER sends one command, it cannot send other commands until DEVICE returns the return Data. DEVICE sends the return Data after processing the command. The time from when CONTROLLER sends the command until the return Data is returned differs according to the contents of the command.

#### Note

When Sircs Direct Command is sent, return Data may not be returned in some cases.



## 2-6. Communication Rules

- When sending a command from CONTROLLER, the return Data from PROJECTOR should be received first before sending the next command. Even if the next command is sent before receiving the return Data, since PROJECTOR will not be able to receive that command, it does not return a response to CONTROLLER. Consequently, no error code is also sent.

The following lists the approximate waiting times for PROJECTOR to return the return Data after CONTROLLER sends the command.

- When a communication error occurs, PROJECTOR ignores the Data received until now, and set into the reception standby state.
- For undefined commands or commands determined as invalid by PROJECTOR, PROJECTOR will send the “NAK” return Data to CONTROLLER .
- Take note that when Data is written when the input signal of PROJECTOR is unstable, that Data (value) will not be incorporated.
- When INDEX specified SIRCS direct command is transmitted, leave an interval of 45 msec until the next transmission. (Do not return the return Data (ACK, NAK) when the SIRCS direct command is received.)

## 2-7. Approximate Return Waiting Times

The await-return time differs according to the model.

Refer to Appendix B.

## 3. NETWORK

### 3-1. Introduction

This section describes the specifications, performance and operations of the network service that is going to be installed in the target projector.

#### 3-1-1. Advertisement

The advertisement service is provided to facilitate development of a PC application that can automatically detect a projector on the network. This function is achieved by broadcasting the equipment information periodically to the network.

##### 3-1-1-1. Function

The equipment information shown below is transmitted as the broadcast packet periodically (at certain intervals).

Information	Description
Category	Category of the equipment
Equipment name	Name of the equipment
Serial number	Serial number of the equipment
Installation information	Installation location of the equipment
Community	Community name of the equipment
Power status	Power status of the equipment

##### Notes

- The category of projector is 0x0a.
- The power status sets ffffh if communication error occurs.

##### Protocol

The SDAP protocol is defined in order to provide this service.

Item	Description
Protocol name	SDAP (Simple Display Advertisement Protocol)
Transport	UDP
Port number	53862
BC interval	Once every 30 seconds (initial value)

#### 3-1-1-2. Setup Items

The items that can be set for the advertisement service are described below.

Setup items	Description
Port	Port number
Interval	Broadcast interval

### 3-1-2. Remote Control

The remote control service is provided that can control the target equipment from remote location via network. The SDCP protocol that serves to acquire the basic information such as equipment name and serial numbers is installed in this projector.

#### 3-1-2-1. Function

This responds to the control command and requests for acquiring the status and information supplied from clients.

##### Control request

Enables the input to be selected and picture control to be adjusted.

##### SIRCS request

Enables remote control by sending the SIRCS code.

##### Status request

Enables equipment status information such as power status, error information and power-on time to be acquired.

##### Information request

Enables equipment information such as equipment name, serial number and installation information to be acquired.

#### Protocol

Item	Description
Protocol name	SDCP (Simple Display Control Protocol)
Transport	TCP
Port number	53484
TCP connection timeout	30 seconds

#### 3-1-2-2. Setup Items

The items that can be set for the remote control service are described below.

Setup item	Description
Port	Port number
Timeout	TCP connection timeout time

3-2. SDAP Protocol

This section describes the SDAP packet structure.




Fig.1 Packet structure

- 1) Header
The header consists of ID (16 bit), version (8 bit) and category (8 bits).




Fig. 2 Header

ID
It is fixed to "DA".

Version
This indicates the version number of protocol.
It is fixed to 01h (version 1).

Category
Category number 0x0a of the projector is entered here.

- 2) Community
The community that is set in the display equipment is entered. Community consists of four alphanumeric characters (case sensitive). The display equipment has the default value "SONY" when shipped from the factory.




Fig. 3 Community

- 3) Equipment Information

Product Name
Name of equipment (Maximum twelve characters)
In case, less than twelve characters, 00h is entered in the blank space.

Serial No.
Serial number is entered.

Power Status.
Power supply status of the equipment is entered.

Location
Information of installation location (Maximum twenty four characters)
In case, less than twenty four characters, 00h is entered in the blank space.

### 3-3. SDCP Protocol

This section describes the packet structure of SDCP.



Fig. 1 Packet structure

#### 3-3-1. Format

##### 3-3-1-1. Header

The header consists of Version (8 bits) and Category (8 bits).




Fig. 2 Header structure

##### Version

This indicates the version number of protocol.


It is fixed to 02h (version 2).

##### Category

Category number 0x0a of the projector is entered here. Projector checks the category number. If a different category number is entered, the request is ignored.

##### 3-3-1-2. Community

When the community Data matches the community that is set in the display equipment, the request is executed. Community consists of four alphanumeric characters (case sensitive). All display equipment has the default value “SONY” when shipped from the factory.




##### Note

Community should be entered with four characters. Three characters or less are not accepted.

### 3-3-1-3. Command

This section describes the format of the request command and the response command.



#### (1) Request

This section describes the format of the request command that is issued from the host PC to the projector.

#### Community

This is the same alphanumeric characters as those of community that is set in the projector to which request is going to be sent.

#### Request

There are only two types of request. One is the GET request to acquire the projector information and status. The other is the SET request to modify the projector setup.

Request	Contents
SET (00h)	Used to control turning the power on/off and to control the input selector, and to change the various setups.
SET (01h)	Used to acquire the installation information, equipment status and various setup values.

#### Item No.

This is the item number of the request target.

#### Data Length

This is the length of the Data accompanying the request. The maximum length is 128 bytes. If there is no Data, it is 0.

#### Data

This is the Data accompanying the request.

#### (2) Response

This section describes the format of the response command which is used to return a response to the host PC from the projector.

#### Community

The same alphanumeric characters as those of the request is entered.

#### Response

The response returns the result of executing the request from the host PC.

Response	Contents
NG (00h)	Indicates that the request is illegal or cannot be executed.
OK (01h)	Indicates that the request was executed correctly.

#### Item No.

The same value as those of the request is entered.

#### Data Length

This is the length of the Data accompanying the response. The maximum length is 128 bytes. If there is no Data, it is 0.

#### Data

This is the Data accompanying the response.

### 3-3-1-4. SET Request

The SET request is used to set a new value in the specified item. Details of the request and the response are described below.

#### Request

Request	Item No.	Data Length	Data
00h	Item No.	n	Set Data (n byte)

#### Response

OK (01h)	Item No.	0
----------	----------	---

### 3-3-1-5. GET Request

The GET request is used to acquire the value of the specified item. Details of the request and the response are described below.

#### Request

Request	Item No.	Data Length
01h	Item No.	0

#### Response

OK (01h)	Item No.	n	Get Data (n byte)
----------	----------	---	-------------------

### 3-3-1-6. ERROR Response

When an error occurs in the contents of a request or in the result of execution, NG is returned as the response.

NG (00h)	Item No.	2	Error Code (16)
----------	----------	---	-----------------

### 3-3-2. Items

Category	Contents	SET	GET
00**h	Used to control and to change the various setups.	○	○
01**h	Used to acquire the status.		○
03**h	Used to reset memory.	○	
17**h	Sircs (15 bit category)	○	
19**h	Sircs (20 bit category)	○	
80**h	Used to acquire equipment information.		○
90**h	Used to acquire network setup information.		○

#### 3-3-2-1. Model Dependent Category

The supported contents of 00\*\*h, 01\*\*h, 03\*\*h, 17\*\*h and 19\*\*h change depending on the model.  
Details are shown on Appendix.

#### 3-3-2-2. Equipment Information Acquisition (80\*\*h)

Used to acquire the equipment information.

Lower byte	Contents	SET	GET
00h	Category Code		○
01h	Model name		○
02h	Serial number		○
03h	Installation location	○	○

#### 0x8000 Category code

1 byte

#### 0x8001 Model name

Alphanumeric 12 characters

If the number of characters is less than 12, the remaining digits are filled with 00h.

#### 0x8002 Serial number

4 bytes

##### Note

The serial number is in the range of 00000000 to 99999999.

#### 0x8003 Installation location

Alphanumeric 24 characters

If the number of characters is less than 24, the remaining digits are filled with 00h.



### 3-3-2-3. Network Information Acquisition (90\*\*h)

Used to acquire the network setup information.

Lower bytes	Contents	SET	GET
00h	MAC Address		<input type="radio"/>
01h	IP Address		<input type="radio"/>
02h	Subnet Mask		<input type="radio"/>
03h	Default Gateway		<input type="radio"/>
04h	DHCP		<input type="radio"/>

#### 0x9000 Mac Address

6 bytes

#### 0x9001 IP Address

4 bytes

#### 0x9002 Subnet Mask

4 bytes

#### 0x9003 Default Mask

4 bytes

#### 0x9004 DHCP

1 byte

DHCP invalid : 0

DHCP valid : 1

### 3-3-3. Error Code

The error code list is shown below with a detailed description of each.

Category	Error	Error Code
Item Error (01**h)	Invalid Item	01h
	Invalid Item Request	02h
	Invalid Length	03h
	Invalid Data	04h
	Short Data	11h
	Not Applicable Item	80h
Community Error (02**h)	Different Community	01h
Request Error (10**h)	Invalid Version	01h
	Invalid Category	02h
	Invalid Request	03h
	Short Header	11h
	Short Community	12h
	Short Command	13h
Network Error (20**h)	Timeout	01h
Comm Error (F0**h)	Timeout	01h
	Check Sum Error	10h
	Framing Error	20h
	Parity Error	30h
	Over Run Error	40h
	Other Comm Error	50h
	Unknown Response	F0h
NVRAM Error (F1**h)	Read Error	10h
	Write Error	20h

### **3-3-3-1. Item Error**

This error occurs when the Item No. of a request is illegal or its Data is illegal. The conditions for occurrence of the respective errors are shown below.

#### **Invalid Item**

An unsupported Item No. is specified.

Example 1: The unsupported category 0xA\*\* is specified.

Example 2: The unsupported Item No. 0x8010 is specified.

#### **Invalid Item Request**

The Item No. is supported but an unsupported Request is issued.

Example: An attempt is made to set Data in the Model Name (0x8001).

#### **Invalid Length**

Data Length of the specified Item No. is too long.

Example: An attempt is made to set 25 byte Data in the installation location (0x8003).

#### **Invalid Data**

Data of the specified Item No. is outside the setting range.

Example: An attempt is made to set 101 in the Item when the setting range of the Item is 1 to 100.

#### **Short Data**

The length of Data is shorter than the value specified by the Data Length.

Example: The actual Data length is 9 bytes but Data Length is 10.

#### **Not Applicable Item**

An item that is not valid at present is specified.

Example: The item to switch the display is specified when the main power is off.

### **3-3-3-2. Community Error**

This error occurs when community is different.

Example: “ABCD” is specified when “SONY” is set.

### 3-3-3-3. Request Error

This error occurs when Header or Command is illegal. The conditions of occurrence of the respective errors are shown below.

#### Invalid Version

The version of the Header is other than 2.

##### Note

When another version is supported, an error occurs in all versions other than the supported version.

#### Invalid Category

The category does not match.

Example: 0x0B is specified in the device of Category = 0x0A.

#### Invalid Request

An unsupported request is specified.

Example: Request = 0x02 is specified.

#### Short Header

The received Data is 1 byte.

#### Short Community

The received Data is in the range of 2 to 5 bytes.

#### Short Command

The received Data is in the range of 6 to 9 bytes.

### 3-3-3-4. Network Error

This is an error that occurs in TCP/IP. The conditions of occurrence of the respective errors are shown below.

#### Timeout

Communication was interrupted.

### **3-3-3-5. Comm Error**

This is an error in communication with the main control microprocessor of the display.

#### **Timeout**

Reception Data is not returned after Data is sent.

#### **Check Sum Error**

A check sum error occurred in the main control microprocessor of the display.

#### **Framing Error**

A framing error occurred.

#### **Parity Error**

A parity error occurred.

#### **Over Run Error**

An overrun error occurred.

#### **Other Comm Error**

Another error occurred.

#### **Unknown Response**

The Data cannot be processed was received.

### **3-3-3-6. NVRAM Error**

#### **Read Error**

Reading from NVRAM was failed.

#### **Write Error**

Writing to NVRAM was failed.

## 3-4. PJLink

The following model is equipped with the PJLink class1 protocol.

For details about this protocol, refer to the PJLink specifications published from JBMIA.

You can turn on or off the PJLink protocol and set a password from the Web setting screen > Setup >

Advanced Menu > PJLINK. Up to three controllers can be connected at the same time.

When the authentication setting is changed, the connected controller will be disconnected.

This protocol is set to ON by default.

### PJLink class1 corresponding model

VPL-FE40, VPL-FE40L, VPL-FX40, VPL-FX40L

#### 3-4-1. Command Details

Command	Data	Remark
POWER	0	Changes the projector's power status to 'Standby'.
	1	Changes the projector's power status to 'Lamp ON'.
POWER ?		The following value1s are returned:
		0 : Standby
		1 : Lamp ON
		2 : Cooling state
		3 : Warm-up state
		4 : Unacceptable period
		5 : Projector defect
INPT	1*	Changes the projector input to 'RGB*'.
	2*	Changes the projector input to 'VIDEO*'.
	3*	Changes the projector input to 'DIGITAL*'.
	4*	Changes the projector input to 'STORAGE*'.
	5*	Changes the projector input to 'NETWORK*'.
INPT ?		The following values are returned:
		1*: RGB
		2*: VIDEO
		3*: DIGITAL
		4*: STORAGE*
		5*: NETWORK*
AVMT	10	Cancels the projector's video mute.
	11	Sets the projector's video mute.
	20	Cancels the projector's audio mute.
	21	Sets the projector's audio mute.
	30	Cancels the projector's video + audio mute.
	31	Sets the projector's video + audio mute.
AVMT ?		The following values are returned:
		10 : Projector video mute OFF
		11 : Projector video mute ON
		20 : Projector audio mute OFF
		21 : Projector audio mute ON
		30 : Projector video + audio mute OFF
		31 : Projector video + audio mute ON

Command	Data	Remark
ERST ?		The following values are returned:
		6th digit : Fan error
		5th digit : Lamp error
		4th digit : Temperature error
		3rd digit : Cover open error
		2nd digit : Filter error
		1st digit : Other error
		The following values are assigned to each digit :
		0 : No error, or detection impossible
		1 : Warning
		2 : Error occurring
LAMP ?		The following values are returned:
		Lamp accumulative time (0 to 99999)
		'1' when the lamp is on, '0' when off.
		Returns data for each lamp
		if there are multiple lamps.
INST ?		The following values are returned:
		Source No. of the input that can be switched
		For source Nos., refer to the section on INPT.
NAME ?		Returned value is a projector name (Max. 64 characters)
INF1 ?		Returned value is a manufacturer name (Max. 32 characters)
INF2 ?		Returned value is a model name (Max. 32 characters)
INFO ?		Returned value is desired information (Max. 32 characters)
CLSS ?		Returned value is the class of the corresponding PJLINK.

## Specifications

The specifications of PJLink installed on the projector are as follows:

- Used port  
4352
- Maximum number of controllers simultaneously connected  
3 units
- Authentication setting  
Can be set on the Web screen.  
The default settings are as follows:  
Authentication setting : Enabled  
Password : JBMIAPjectorLink

### Note

When the authentication setting is changed, the connected controller will be disconnected.

- **Commands**

The following 14 commands are supported :

- (01) [Power control command] POWR
- (02) [Power status inquiry] POWR ?
- (03) [Input switch command] INPT
- (04) [Input switch inquiry] INPT ?
- (05) [AV mute command] AVMT
- (06) [AV mute status inquiry] AVMT ?
- (07) [Error status inquiry] ERST ?
- (08) [Lamp count/lamp time inquiry] LAMP ?
- (09) [Input switch list inquiry] INST ?
- (10) [Projector name inquiry] NAME ?
- (11) [Manufacturer name inquiry] INF1 ?
- (12) [Model name inquiry] INF2 ?
- (13) [Other information inquiry] INFO ?
- (14) [Class information inquiry] CLSS ?

### 3-4-2. PJ-Link Protocol Connection

When connecting a controller, the authentication procedure is required.

The projector responds as follows at the time of authentication:

When starting connection with authentication setting enabled :	Returns "PJLINK 1 random number". The random number converts a four-byte integer into a character string.
When authentication is successful :	Waits for a command.
When authentication failed :	Returns "PJLINK ERR".

When starting connection with authentication setting disabled : Returns "PJLINK 0", and then waits for a command.

### 3-4-3. PJ-Link Protocol Command

This section provides explanation for each command.

#### 1. [Power control command] POWR

This command sets the projector's power status.

The available parameters are as follows:

Parameter 1 :	Projector power ON
Parameter 0 :	Projector power OFF

The projector responds as follows:

When processed properly : Returns "OK".

When parameter is out of range :	Returns "ERR2".
Unacceptable period (when the power status is other than Standby or Power ON) :	Returns "ERR3".
Projector error occurring (including warning) :	Returns "ERR4".



## 2 [Power status inquiry] POWR?

This command obtains the projector's power status.

The projector responds as follows:

Returns the following values when the power status is obtained:

Standby or power-saving state : Returns "0".

Power ON state : Returns "1".

Cooling state, or cooling state during power-saving state : Returns "2".

Startup state : Returns "3".

Projector error occurring (including warning) : Returns "ERR4".

## 3. [Input switch command] INPT

This command switches the projector's inputs.

The available parameters are as follows:

Parameter 21 : Projector input	Video
Parameter 22 : Projector input	S-Video
Parameter 31 : Projector input	Input A
Parameter 32 : Projector input	Input B
Parameter 33 : Projector input	Input C
Parameter 34 : Projector input	Input D
Parameter 51 : Projector input	Input E (network)

The projector responds as follows:

When processed properly : Returns "OK".

When inexistent input is specified : Returns "ERR2".

Unacceptable period (when the power status is other than Power ON) : Returns "ERR3".

Projector error occurring (including warning) : Returns "ERR4".

## 4. [Input switch inquiry] INPT?

This command obtains the projector's input status.

The projector responds as follows:

Returns the following values when the input status is obtained:

When the projector input is Video : Returns "21".

When the projector input is S-Video : Returns "22".

When the projector input is Input A : Returns "31".

When the projector input is Input B : Returns "32".

When the projector input is Input C : Returns "33".

When the projector input is Input D : Returns "34".

When the projector input is Input E (network) : Returns "51".

Unacceptable period (when the power status is other than Power ON) : Returns "ERR3".

Projector error occurring (including warning) : Returns "ERR4".

## 5. [AV mute command] AVMT

This command sets the projector's AV mute setting.

The available parameters are as follows:

Parameter 11 : Projector video mute ON

Parameter 10 : Projector video mute OFF

Parameter 21 : Projector audio mute ON

Parameter 20 : Projector audio mute OFF

Parameter 31 : Projector video + audio mute ON

Parameter 30 : Projector video + audio mute OFF

The projector responds as follows:

When processed properly : Returns "OK".

When parameter is out of range :

Returns "ERR2".

Unacceptable period (when the power status is other than Power ON) : Returns "ERR3".

Projector error occurring (including warning) :

Returns "ERR4".

## 6. [AV mute status inquiry] AVMT?

This command obtains the projector's AV mute status.

The projector responds as follows:

Returns the following values when the AV mute status is obtained:

When the projector video mute is ON : Returns "11".

When the projector video mute is OFF : Returns "10".

When the projector audio mute is ON : Returns "21".

When the projector audio mute is OFF : Returns "20".

When the projector video + audio mute is ON : Returns "31".

When the projector video + audio mute is OFF : Returns "30".

Unacceptable period (when the power status is other than Power ON) : Returns "ERR3".

Projector error occurring (including warning) : Returns "ERR4".

## 7. [Error status inquiry] ERST?

This command obtains the projector's error status.

The projector responds as follows:

Returns the response for the error status in the following format.

The error status is expressed with a six-digit number.

6th digit : Fan error

5th digit : Lamp error

4th digit : Temperature error

3rd digit : Cover open error

2nd digit : Filter error

1st digit : Other error

The number in each digit has the following meaning:

0 : No error detected

1 : Warning

2 : Error

For example, when the Fan error and the Temperature warning occur, the response will be as follows:

"201000"

## 8. [Lamp count/lamp time inquiry] LAMP?

This command obtains the number of the projector's lamps and the lamp time.

The projector responds as follows:

When normal :

Returns the accumulative time and the illumination time of the lamp for each lamp.

The number of lamp in the projector is 1.

"1" is displayed when the lamp is on, "0" when the lamp is off.

For example, when the accumulative time is 40 hours and the lamp is on, the response will be as follows:

"40 1"

Projector error occurring (including warning) : Returns "ERR4".

## 9. [Input switch list inquiry] INST?

This command obtains the input switch list.

The projector responds as follows:

When normal :

Returns a source No. whose input can be switched.

The source Nos. are as follows :

Source No. 21 : Projector input Video

Source No. 22 : Projector input S-Video

Source No. 31 : Projector input Input A

Source No. 32 : Projector input Input B

Source No. 33 : Projector input Input C

Source No. 34 : Projector input Input D

Source No. 51 : Projector input Input E (network)

Therefore, the response will be as follows:

“21 22 31 32 33”

Unacceptable period (when the power status is other than Power ON) : Returns “ERR3”.

Projector error occurring (including warning) : Returns “ERR4”.

## 10. [Projector name inquiry] NAME?

This command obtains the projector name.

The projector responds as follows :

When normal :

Returns a projector name. (The projector name is displayed as a nickname for the projector's GUI.)

Returns a space when no projector name is set.

Projector error occurring (including warning) : Returns “ERR4”.

## 11. [Manufacturer name inquiry] INF1?

This command obtains the manufacturer name.

The projector responds as follows:

When normal : Returns a manufacturer name (SONY).

Projector error occurring (including warning) : Returns “ERR4”.

## 12. [Model name inquiry] INF2?

This command obtains the model name.

The projector responds as follows:

When normal : Returns a model name.

Projector error occurring (including warning) : Returns “ERR4”.

### **13. [Other information inquiry] INFO?**

This command obtains other information.

The projector responds as follows:

When normal : Returns a space.

Projector error occurring (including warning) : Returns “ERR4”.

### **14. [Class information inquiry] CLSS?**

This command obtains the class information.

The projector responds as follows:

When normal : Returns “1”.

Projector error occurring (including warning) : Returns “ERR4”.

## **3-5. DDDP**

The following model is equipped with the protocol conforming DDDP stipulated by AMX.

For details about DDDP, contact AMX.

You can turn on or off DDDP from the Web setting screen > Setup > Advanced Menu > Service.

This protocol is set to OFF by default.

### **DDDP corresponding model**

VPL-FE40, VPL-FE40L, VPL-FX40, VPL-FX40L

# Appendix A. Setup Method For VPL-PX35 and PX40

Establishing the network setup such as IP address can be implemented from the PC browser, and the information such as installation location can be viewed on the PC browser.

## A-1. Command

### A-1-1. Setting

Enter the following command using the format shown below in a browser as URL, and then the simple response is returned.

#### Format

http://IP address/Item?Value

IP address	The IP address that is assigned to the network block
Item	Name of the setup item
Value	Setting value

#### Response

The following HTML is returned that enables to confirm OK or NG simply.

<HTML>  
<TITLE>  
IP address  
</TITLE>  
<BODY>  
&lt; Equipment name: Serial number&gt;<BR><BR>  
Result [Item = Value]  
</BODY>  
</HTML>

IP address	The IP address that is assigned to the network block
Equipment name	Name of the equipment in which setup is implemented
Serial number	Serial number of the equipment in which setup is implemented
Result	Result (OK or NG) is displayed.
Item	Name of the setup item
Value	Setting value

## A-1-2. Display

Enter the following command using the format shown below in a browser as URL, and then value of the setting item is displayed.

### Format

http://IP address/Item

IP address	The IP address that is assigned to the network block
Item	Name of the setup item

### Response

The following HTML is returned.

```
<HTML>
<TITLE>
IP address
</TITLE>
<BODY>
< Equipment name: Serial number><BR><BR>
Result [Item = Value]
</BODY>
</HTML>
```

IP address	The IP address that is assigned to the network block
Equipment name	Name of the equipment that has acquired the setup value
Serial number	Serial number of the equipment that has acquired the setup value
Result	Result (OK or NG) is displayed.
Item	Name of the setup item
Value	Setting value

## A-2. Setting Command

Each setting item is described below.

### Equipment information

Item	Description	Default
location	Sets location of the equipment installation. (Maximum 24 alphanumeric characters)	—
Community	Sets the equipment community. (Maximum 4 alphanumeric characters)	SONY

#### Note

Location and community do not support Japanese character.

### Network setup

Item	Description	Default
dhcp	Specifies method of setting IP address.	No
ipaddr	IP address	192.168.0.1
subnet	Subnet mask	255.255.0.0
gateway	Default gateway	0.0.0.0
restart	Restarts the network block to make the network setup effective.	

#### Notes

- When the network setup is changed, execute restart to make the setup effective.
- For the setup of dhcp, set 1 to make DHCP effective and set 0 to make DHCP ineffective.

### Service setup

Item	Description	Default
ad_port	Port number of the Advertisement service	53862
ad_interval	Broadcast interval of the Advertisement service (in units of second)	30 (seconds)
ad_ip	IP address of the Advertisement service	0.0.0.0
rc_port	Port number of the Remote Control service	53484
rc_timeout	TCP connection timeout time of the Remote Control service (in units of second)	30 (seconds)

#### Notes

- When network setup is changed, executing restart is required to make the network setup effective.
- When ad\_interval value is set to 0, the advertisement service is stopped.
- The ad\_interval can be set to 0 or a value in the range of 10 to 65535.
- The rc\_timeout can be set to a value in the range of 0 to 65535.



## Appendix B

(VPL-FX51)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
INPUT	00h	01h	VIDEO	00h	00h	Set/Get
			S VIDEO	00h	01h	
			INPUT A	00h	02h	
			INPUT B	00h	03h	
			INPUT C	00h	04h	
CONTRAST	00h	10h	Setting value (0 to 100)	00h	00h to 64h	
BRIGHTNESS	00h	11h	Setting value (0 to 100)	00h	00h to 64h	
COLOR	00h	12h	Setting value (0 to 100)	00h	00h to 64h	
HUE	00h	13h	Setting value (0 to 100)	00h	00h to 64h	
SHARPNESS	00h	14h	Setting value (0 to 100)	00h	00h to 64h	
RGB ENHANCER	00h	15h	Setting value (0 to 100)	00h	00h to 64h	
COL TEMP	00h	17h	LOW	00h	00h	
			HIGH	00h	01h	
DDE	00h	18h	OFF	00h	00h	
			PROGRESSIVE	00h	01h	
			FILM	00h	02h	
ASPECT	00h	20h	16 : 9	00h	00h	
			4 : 3	00h	01h	
SCAN CONV	00h	21h	OFF	00h	00h	
			ON	00h	01h	
PICTURE MUTING	00h	30h	OFF	00h	00h	
			ON	00h	01h	
INPUT A	00h	32h	COMPUTER	00h	00h	
			COMPONENT	00h	01h	
			VIDEO GBR	00h	02h	
LAMP MODE	00h	40h	HIGH	00h	00h	
			STANDARD	00h	01h	
GAIN RED	00h	80h	Setting value (0 to 255)	00h	00h to FFh	
GAIN GREEN	00h	81h	Setting value (0 to 255)	00h	00h to FFh	
GAIN BLUE	00h	82h	Setting value (0 to 255)	00h	00h to FFh	
BIAS RED	00h	83h	Setting value (0 to 255)	00h	00h to FFh	
BIAS GREEN	00h	84h	Setting value (0 to 255)	00h	00h to FFh	
BIAS BLUE	00h	85h	Setting value (0 to 255)	00h	00h to FFh	
STATUS ERROR	01h	01h	NO ERROR	00h	00h	Get only
			LAMP ERROR	00h	01h	
			FAN ERROR	00h	02h	
			COVER ERROR	00h	04h	
			TEMP ERROR	00h	08h	
			D5V ERROR	00h	10h	
			POWER ERROR	00h	20h	
			WARNING ERROR	00h	40h	

**(VPL-FX51)**

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
STATUS POWER	01h	02h	STANBY	00h	00h	Get only
			START UP	00h	01h	
			STARTUP LAMP	00h	02h	
			POWER ON	00h	03h	
			COOLING1	00h	04h	
			COOLING2	00h	05h	
			SAVING COOLING1	00h	06h	
			SAVING COOLING2	00h	07h	
			SAVING STABY	00h	08h	
CONTROL MODE SEL	01h	05h	USER	00h	00h	
			SERVICE	00h	01h	
LAMP TIMER	01h	13h	USE TIME	0000h-ffffh*1		
ROM VERSION	01h	1Dh	MAIN ROM VERSION	*2		
SC ROM VERSION	01h	1Eh	SC ROM VERSION	*2		
Channel Memory Reset	03h	01h		00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B Low Save		05h				
W/B High Save		06h				
Sircs (15bit category)	17h	Refer to table 4	—	00h	00h	Set only*3
Sircs (20bit category)	19h	Refer to table 5	—	00h	00h	

\*1Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3It is corresponded to single command only.

**(VPL-FX51)**

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	—	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

Approximate Return Waiting Times

The await-return time is approx. 50 msec.

**Note**

This is the case, unless the communications are interfered anyway.

## (VPL-FX52/FX52L)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h	00h	Set/Get
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
			Input-C	00h	04h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0-100)	00h	00h to 64h	
Brightness	00h	11h	Setting value (0-100)	00h	00h to 64h	
Color	00h	12h	Setting value (0-100)	00h	00h to 64h	
Hue	00h	13h	Setting value (0-100)	00h	00h to 64h	
Sharpness	00h	14h	Setting value (0-100)	00h	00h to 64h	
RGB Enhancer	00h	15h	Setting value (0-100)	00h	00h to 64h	
ColTemp	00h	17h	High	00h	00h	
			Low	00h	01h	
DDE	00h	18h	Off	00h	00h	
			Progressive	00h	01h	
			Film	00h	02h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
Picture Muting	00h	30h	Off	00h	00h	
			On	00h	01h	
Input-C Signal Sel	00h	32h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
Gain Red	00h	80h	Setting value (0-255)	00h	00h to FFh	
Gain Green	00h	81h	Setting value (0-255)	00h	00h to FFh	
Gain Blue	00h	82h	Setting value (0-255)	00h	00h to FFh	
Bias Red	00h	83h	Setting value (0-255)	00h	00h to FFh	
Bias Green	00h	84h	Setting value (0-255)	00h	00h to FFh	
Bias Blue	00h	85h	Setting value (0-255)	00h	00h to FFh	

## (VPL-FX52/FX52L)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Status Error	01h	01h	No Error	00h	00h	Get only
			Lamp Error	00h	01h	
			Fan Error	00h	02h	
			Cover Error	00h	04h	
			Temp Error	00h	08h	
			D5V Error	00h	10h	
			Power Error	00h	20h	
			Warning Error	00h	40h	
Status Power	01h	02h	Stanby	00h	00h	
			Start Up	00h	01h	
			Start Up Lamp	00h	02h	
			Power On	00h	03h	
			Cooling1	00h	04h	
			Cooling2	00h	05h	
			Saving Cooling1	00h	06h	
			Saving Cooling2	00h	07h	
			Saving Staby	00h	08h	
Control Mode Select	01h	05h	User Mode	00h	00h	
			Service Mode	00h	01h	
Lamp Timer	01h	13h	Lamp Use Time	0000h-FFFFh*1		
ROM Version	01h	1Dh	MAIN ROM Version	*2		
SC ROM Version	01h	1Eh	SC ROM Version	*2		
Status Security*3	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B High Save		05h				
W/B Low Save		06h				
Sircs (15 bit category)	17h	Refer to table 6	—	00h	00h	Set only*4
Sircs (20 bit category)	19h	Refer to table 7	—	00h	00h	

## (VPL-FX52/FX52L)

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	-	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not. During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

Approximate Return Waiting Times  
The await-return time is approx. 50 msec.

**Note**  
This is the case, unless the communications are interfered anyway.

**(VPL-PX35, PX40, PX41)**

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h	00h	Set/Get
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
			Input-C	00h	04h	
			Input-D	00h	05h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0-100)	00h	00h to 64h	
Brightness	00h	11h	Setting value (0-100)	00h	00h to 64h	
Color	00h	12h	Setting value (0-100)	00h	00h to 64h	
Hue	00h	13h	Setting value (0-100)	00h	00h to 64h	
Sharpness	00h	14h	Setting value (0-100)	00h	00h to 64h	
RGB Enhancer	00h	15h	Setting value (0-100)	00h	00h to 64h	
Volume	00h	16h	Setting value (0-100)	00h	00h to 64h	
CoITemp	00h	17h	High	00h	00h	
			Low	00h	01h	
DDE	00h	18h	Off	00h	00h	
			Progressive	00h	01h	
			Film	00h	02h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
Picture Muting	00h	30h	Off	00h	00h	
			On	00h	01h	
Audio Muting	00h	31h	Off	00h	00h	
			On	00h	01h	
Input-D Signal Sel	00h	33h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
GAIN RED	00h	80h	Setting value (0-255)	00h	00h to FFh	
GAIN GREEN	00h	81h	Setting value (0-255)	00h	00h to FFh	
GAIN BLUE	00h	82h	Setting value (0-255)	00h	00h to FFh	
BIAS RED	00h	83h	Setting value (0-255)	00h	00h to FFh	
BIAS GREEN	00h	84h	Setting value (0-255)	00h	00h to FFh	
BIAS BLUE	00h	85h	Setting value (0-255)	00h	00h to FFh	

## (VPL-PX35, PX40, PX41)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
STATUS ERROR	01h	01h	NO ERROR	00h	00h	Get only
			LAMP ERROR	00h	01h	
			FAN ERROR	00h	02h	
			COVER ERROR	00h	04h	
			TEMP ERROR	00h	08h	
			D5V ERROR	00h	10h	
			POWER ERROR	00h	20h	
			WARNING ERROR	00h	40h	
STATUS POWER	01h	02h	STANBY	00h	00h	
			START UP	00h	01h	
			STARTUP LAMP	00h	02h	
			POWER ON	00h	03h	
			COOLING1	00h	04h	
			COOLING2	00h	05h	
			SAVING COOLING1	00h	06h	
			SAVING COOLING2	00h	07h	
CONTROL MODE SEL	01h	05h	SAVING STABY	00h	08h	
			USER MODE	00h	00h	
			SERVICE MODE	00h	01h	
LAMP TIMER	01h	13h	LAMP USE TIME	0000h-ffffh*1		
ROM VERSION	01h	1Dh	MAIN ROM VERSION	*2		
SC ROM VERSION	01h	1Eh	SC ROM VERSION	*2		
STATUS SECURITY*3	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B High Save		05h				
W/B Low Save		06h				
Sircs (15 bit category)	17h	Refer to table 8	—	00h	00h	Set only*4
Sircs (20 bit category)	19h	Refer to table 9	—	00h	00h	

## (VPL-PX35, PX40, PX41)

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	-	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not. During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

Approximate Return Waiting Times  
The await-return time is approx. 50 msec.

**Note**

This is the case, unless the communications are interfered anyway.

## (VPL-CX75, CX76)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	Set/Get
Input	00h	01h	Video	00h	00h	
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0 - 100)	00h	00h - 64h	
Brightness	00h	11h	Setting value (0 - 100)	00h	00h - 64h	
Color	00h	12h	Setting value (0 - 100)	00h	00h - 64h	
Hue	00h	13h	Setting value (0 - 100)	00h	00h - 64h	
Sharpness	00h	14h	High	00h		
			Middle	01h		
			Low	02h		
Volume	00h	16h	Setting value (0 - 100)	00h	00h - 64h	
ColTemp	00h	17h	High	00h	00h	
			Low	00h	01h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
PictureMuting	00h	30h	Off	00h	00h	
			On	00h	01h	
AudioMuting	00h	31h	Off	00h	00h	
			On	00h	01h	
Input-A Signal Sel	00h	32h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Input-B Select	00h	33h	Memory Stick	00h	03h	
			Air Shot	00h	04h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
Gain Red	00h	80h	Setting value (0 - 255)	00h	00h - FFh	
Gain Green	00h	81h	Setting value (0 - 255)	00h	00h - FFh	
Gain Blue	00h	82h	Setting value (0 - 255)	00h	00h - FFh	
Bias Red	00h	83h	Setting value (0 - 255)	00h	00h - FFh	
Bias Green	00h	84h	Setting value (0 - 255)	00h	00h - FFh	
Bias Blue	00h	85h	Setting value (0 - 255)	00h	00h - FFh	

## (VPL-CX75, CX76)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Status Error	01h	01h	No Error	00h	00h	Get only
			Lamp Error	00h	01h	
			Fan Error	00h	02h	
			Cover Error	00h	04h	
			Temp Error	00h	08h	
			D5V Error	00h	10h	
			POWER ERROR	00h	20h	
			Warning Error	00h	40h	
Status Power	01h	02h	Stanby	00h	00h	
			Start Up	00h	01h	
			Start Up Lamp	00h	02h	
			Power On	00h	03h	
			Cooling1	00h	04h	
			Cooling2	00h	05h	
			Saving Cooling1	00h	06h	
			Saving Cooling2	00h	07h	
			Saving Stanby	00h	08h	
Control Mode Select	01h	05h	User Mode	00h	00h	
			Service Mode	00h	01h	
Lamp Timer	01h	13h	Lamp Use Time	0000h-FFFFh *1		
ROM Version	01h	1Dh	MAIN ROM Version	*2		
SC ROM Version	01h	1Eh	SC ROM Version	*2		
Status Security	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B Low Save		05h				
W/B High Save		06h				
Sircs(15bit category)	17h	Refer to table 10	—	00h	00h	Set only*4
Sircs(20bit category)	19h	Refer to table 11	—	00h	00h	

## (VPL-CX75, CX76)

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	-	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not. During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

The await-return time of return value is approx. 50 msec.

**Note**

This is the case, unless the communications are interfered anyway.



## (VPL-CX80)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h	00h	Set/Get
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0-100)	00h	00h-64h	
Brightness	00h	11h	Setting value (0-100)	00h	00h-64h	
Color	00h	12h	Setting value (0-100)	00h	00h-64h	
Hue	00h	13h	Setting value (0-100)	00h	00h-64h	
Sharpness	00h	14h	High	00h		
			Middle	01h		
			Low	02h		
Volume	00h	16h	Setting value (0-100)	00h	00h-64h	
CoITemp	00h	17h	High	00h	00h	
			Low	00h	01h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
Picture Muting	00h	30h	Off	00h	00h	
			On	00h	01h	
Audio Muting	00h	31h	Off	00h	00h	
			On	00h	01h	
Input-A Signal Sel	00h	32h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
Gain Red	00h	80h	Setting value (0-255)	00h	00h-FFh	
Gain Green	00h	81h	Setting value (0-255)	00h	00h-FFh	
Gain Blue	00h	82h	Setting value (0-255)	00h	00h-FFh	
Bias Red	00h	83h	Setting value (0-255)	00h	00h-FFh	
Bias Green	00h	84h	Setting value (0-255)	00h	00h-FFh	
Bias Blue	00h	85h	Setting value (0-255)	00h	00h-FFh	

## (VPL-CX80)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Status Error	01h	01h	No Error	00h	00h	Get only
			Lamp Error	00h	01h	
			Fan Error	00h	02h	
			Cover Error	00h	04h	
			Temp Error	00h	08h	
			D5V Error	00h	10h	
			Power ERROR	00h	20h	
			Warning Error	00h	40h	
Status Power	01h	02h	Stanby	00h	00h	
			Start Up	00h	01h	
			Startup Lamp	00h	02h	
			Power On	00h	03h	
			Cooling1	00h	04h	
			Cooling2	00h	05h	
			Saving Cooling1	00h	06h	
			Saving Cooling2	00h	07h	
			Saving Stanby	00h	08h	
Control Mode Select	01h	05h	User Mode	00h	00h	
			Service Mode	00h	01h	
Lamp Timer	01h	13h	Lamp Use Time	0000h-FFFFh*1		
ROM Version	01h	1Dh	MAIN ROM Version	*2		
SC ROM Version	01h	1Eh	SC ROM Version	*2		
Status Security	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B Low Save		05h				
W/B High Save		06h				
Sircs (15 Bit Category)	17h	Refer to table 12	—	00h	00h	Set only*4
Sircs (20 Bit Category)	19h	Refer to table 13	—	00h	00h	

## (VPL-CX80)

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	—	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not.  
During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

The await-return time of return value is approx. 50 msec.

**Notes**

- This is the case, unless the communications are interfered anyway.
- If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

## (VPL-CX85, CX86)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h	00h	Set/Get
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
			Input-C	00h	04h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0-100)	00h	00h-64h	
Brightness	00h	11h	Setting value (0-100)	00h	00h-64h	
Color	00h	12h	Setting value (0-100)	00h	00h-64h	
Hue	00h	13h	Setting value (0-100)	00h	00h-64h	
Sharpness	00h	14h	High	00h		
			Middle	01h		
			Low	02h		
Volume	00h	16h	Setting value (0-100)	00h	00h-64h	
ColTemp	00h	17h	High	00h	00h	
			Low	00h	01h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
Picture Muting	00h	30h	Off	00h	00h	
			On	00h	01h	
Audio Muting	00h	31h	Off	00h	00h	
			On	00h	01h	
Input-A Signal Sel	00h	32h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Input-C Select	00h	33h	Memory Stick	00h	03h	
			Air Shot	00h	04h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
Gain Red	00h	80h	Setting value (0-255)	00h	00h-FFh	
Gain Green	00h	81h	Setting value (0-255)	00h	00h-FFh	
Gain Blue	00h	82h	Setting value (0-255)	00h	00h-FFh	
Bias Red	00h	83h	Setting value (0-255)	00h	00h-FFh	
Bias Green	00h	84h	Setting value (0-255)	00h	00h-FFh	
Bias Blue	00h	85h	Setting value (0-255)	00h	00h-FFh	

## (VPL-CX85, CX86)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	Get only
Status Error	01h	01h	No Error	00h	00h	
			Lamp Error	00h	01h	
			Fan Error	00h	02h	
			Cover Error	00h	04h	
			Temp Error	00h	08h	
			D5V Error	00h	10h	
			Power Error	00h	20h	
			Warning Error	00h	40h	
Status Power	01h	02h	Stanby	00h	00h	
			Start Up	00h	01h	
			Startup Lamp	00h	02h	
			Power On	00h	03h	
			Cooling1	00h	04h	
			Cooling2	00h	05h	
			Saving Cooling1	00h	06h	
			Saving Cooling2	00h	07h	
Control Mode Select	01h	05h	User Mode	00h	00h	
			Service Mode	00h	01h	
Lamp Timer	01h	13h	Lamp Use Time	0000h-FFFFh*1		
ROM Version	01h	1dh	MAIN ROM Version	*2		
SC ROM Version	01h	1eh	SC ROM Version	*2		
Status Security*3	01h	1fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B High Save		05h				
W/B Low Save		06h				
Sircs (15 Bit Category)	17h	Refer to table 14	—	00h	00h	Set only*4
Sircs (20 Bit Category)	19h	Refer to table 15	—	00h	00h	

## (VPL-CX85, CX86)

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	—	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not.  
During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

The await-return time of return value is approx. 50 msec.

**Notes**

• This is the case, unless the communications are interfered anyway.

• If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.

A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

**(VPL-CX61, CX63)**

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h	00h	Set/Get
			S-Video	00h	01h	
			Input-A	00h	02h	
			Input-B	00h	03h	
Picture Mode	00h	02h	Dynamic	00h	00h	
			Standard	00h	01h	
Contrast	00h	10h	Setting value (0-100)	00h	00h-64h	
Brightness	00h	11h	Setting value (0-100)	00h	00h-64h	
Color	00h	12h	Setting value (0-100)	00h	00h-64h	
Hue	00h	13h	Setting value (0-100)	00h	00h-64h	
Sharpness	00h	14h	High	00h		
			Middle	01h		
			Low	02h		
Volume	00h	16h	Setting value (0-100)	00h	00h-64h	
ColTemp	00h	17h	High	00h	00h	
			Low	00h	01h	
Wide Mode	00h	20h	Off	00h	00h	
			On	00h	01h	
Scan Conv	00h	21h	Off	00h	00h	
			On	00h	01h	
Picture Muting	00h	30h	Off	00h	00h	
			On	00h	01h	
Audio Muting	00h	31h	Off	00h	00h	
			On	00h	01h	
Input-A Signal Sel	00h	32h	Computer	00h	00h	
			Component	00h	01h	
			Video GBR	00h	02h	
Input-C Select	00h	33h	Memory Stick	00h	03h	
			Air Shot	00h	04h	
Lamp Mode	00h	40h	High	00h	00h	
			Standard	00h	01h	
Gain Red	00h	80h	Setting value (0-255)	00h	00h-FFh	
Gain Green	00h	81h	Setting value (0-255)	00h	00h-FFh	
Gain Blue	00h	82h	Setting value (0-255)	00h	00h-FFh	
Bias Red	00h	83h	Setting value (0-255)	00h	00h-FFh	
Bias Green	00h	84h	Setting value (0-255)	00h	00h-FFh	
Bias Blue	00h	85h	Setting value (0-255)	00h	00h-FFh	

**(VPL-CX61, CX63)**

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Status Error	01h	01h	No Error	00h	00h	Get only
			Lamp Error	00h	01h	
			Fan Error	00h	02h	
			Cover Error	00h	04h	
			Temp Error	00h	08h	
			D5V Error	00h	10h	
			Power Error	00h	20h	
			Warning Error	00h	40h	
Status Power	01h	02h	Stanby	00h	00h	
			Start Up	00h	01h	
			Startup Lamp	00h	02h	
			Power On	00h	03h	
			Cooling1	00h	04h	
			Cooling2	00h	05h	
			Saving Cooling1	00h	06h	
			Saving Cooling2	00h	07h	
			Saving Stanby	00h	08h	
Control Mode Select	01h	05h	User Mode	00h	00h	
			Service Mode	00h	01h	
Lamp Timer	01h	13h	Lamp Use Time	0000h-FFFFh*1		
ROM Version	01h	1Dh	MAIN ROM Version	*2		
SC ROM Version	01h	1Eh	SC ROM Version	*2		
Status Security*3	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Channel Memory Reset	03h	01h	—	00h	00h	Set only
Status Memory Reset		02h				
Set Memory Reset		03h				
W/B All Save		04h				
W/B Low Save		05h				
W/B High Save		06h				
Sircs (15 Bit Category)	17h	Refer to table 16	—	00h	00h	Set only*4
Sircs (20 Bit Category)	19h	Refer to table 17	—	00h	00h	

**(VPL-CX61, CX63)**

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	—	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

\*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.

\*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.

\*3 While the set is security locked, after power switch is turned on, you can check that pass sword input screen is indicated or not.  
During pass word input screen indicating, return values are [00h] upper byte and [01h] lower byte.

\*4 It is corresponded to single command only.

The await-return time of return value is approx. 50 msec.

**Notes**

- This is the case, unless the communications are interfered anyway.
- If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

## (VPL-FE40/FE40L/FX40/FX40L)

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
Input	00h	01h	Video	00h		Set/Get
			S-Video	01h		
			Input A	02h		
			Input B	03h		
			Input C	04h		
			Input D	05h		
			Input E	06h		
Picture Mode	00h	02h	Dynamic	00h		
			Standard	01h		
Contrast	00h	10h		00h to 64h (0 to 100)		
Brightness	00h	11h		00h to 64h (0 to 100)		
Color	00h	12h		00h to 64h (0 to 100)		
Hue	00h	13h		00h to 64h (0 to 100)		
Sharpness	00h	14h		00h to 64h (0 to 100)		
Volume	00h	16h		00h to 64h (0 to 100)		
CoITemp	00h	17h	High	00h		
			Low	01h		
DDE	00h	1Bh	Off	00h		
			Progressive	01h		
			Film	02h		
Black Level Adj.	00h	1Ch	Off	00h		
			Low	01h		
			High	02h		
Aspect	00h	20h	Normal	01h		
			Zoom	03h		
			Full1	07h		
			Full2	08h		
			4:3	09h		
			16:9	0Ah		
OverScan	00h	23h	Off	00h		
			On	01h		
Picture Muting	00h	30h	Off	00h		
			On	01h		
Audio Muting	00h	31h	Off	00h		
			On	01h		
Input-C Signal Sel	00h	34h	AUTO	00h		
			Computer	01h		
			Component	02h		
			Video GBR	03h		
Lamp Mode	00h	40h	High	00h		
			Standard	01h		

**(VPL-FE40/FE40L/FX40/FX40L)**

<Table 1>			<Table 2>			Remarks
Item Number			Data			
Item	Upper byte	Lower byte	Data	Upper byte	Lower byte	
STATUS ERROR	01h	01h	NO ERROR	00h		Get only
			LAMP ERROR	01h		
			FAN ERROR	02h		
			COVER ERROR	04h		
			TEMP ERROR	08h		
			D5V ERROR	10h		
			POWER ERROR	20h		
			WARNING ERROR	40h		
			NVM Data ERROR	80h		
STATUS POWER	01h	02h	STANBY	00h		
			START UP	01h		
			STARTUP LAMP	02h		
			POWER ON	03h		
			COOLING1	04h		
			COOLING2	05h		
			SAVING COOLING1	06h		
			SAVING COOLING2	07h		
			SAVING STABY	08h		
LAMP TIMER	01h	13h	USE TIME	0000h-ffffh*1		
SUB ROM VERSION	01h	1Dh	SUB ROM VERSION	*2		
SC1 ROM VERSION	01h	1Eh	SC ROM VERSION	*2		
STATUSSECURITY	01h	1Fh	Disable	00h	00h	
			Enable	00h	01h	
Sircs (PROJECTORn Category)	17h	Refer to table 18	—	00h	00h	Set only*3
Sircs (PROJECTORnE Category)	19h	Refer to table 19	—	00h	00h	

**(VPL-FE40/FE40L/FX40/FX40L)**

<Table 3>			
Item Number		Data	
Item	Data	Upper byte	Lower byte
ACK	–	00h	00h
NAK	Undefined Command	01h	01h
	Size Error		04h
	Select Error		05h
	Range Over		06h
	Not Applicable		0Ah
	Check Sum Error	F0h	10h
	Framing Error		20h
	Parity Error		30h
	Over Rub Error		40h
	Other Comm Error		50h

- \*1 Example) In case the lamp timer indicates 1000H, return values are [03h] upper byte and [E8h] lower byte.
- \*2 Example) In case the software version is 1.03, return values are [01h] upper byte and [03h] lower byte.
- \*3 It is corresponded to single command only.

The await-return time of return value is approx. 200 msec.

**Notes**

- This is the case, unless the communications are interfered anyway.
- It takes longer time according to the command.
- The standby mode is set to "Low", and when the main body of the projector is a standby, only POWER ON/OFF and POWER ON of the PROJECTERn category of SIRCS are effective.



## List of SIRCS CODE

(1) 15BIT Category (VPL-FX51 only)

<Table 4>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x						POWER ON/OFF			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH	SHARPNESS + SHARP	SHARPNESS - SOFT	PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT	BLANKING		ENTER				MEMORY	S VIDEO
6x																INPUT C
7x			LENS SHIFT ↑	LENS SHIFT ↓	FOCUS F	FOCUS N		ZOOM L	ZOOM S			RESET			PATTERN	

&lt;Table 5&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											KEYSTONE					
4x																
5x																
6x	APA	DOT PHASE	LENS ZOOM	LENS SHIFT	LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS TOGGLE							

(3) 15BIT Category (VPL-FX52/FX52L)

<Table 6>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x						POWER ON/OFF			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH	SHARPNESS + SHARP	SHARPNESS - SOFT	PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x				W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																INPUT C
7x				LENS SHIFT ↑	FOCUS F	FOCUS N		ZOOM L	ZOOM S			RESET				

&lt;Table 7&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											V KEYSTONE					
4x													DDE TOGGLE			
5x																
6x	APA	DOT PHASE	LENS ZOOM	LENS SHIFT	LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS TOGGLE							

(5) 15BIT Category (VPL-PX35, PX40, PX41)

<Table 8>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME+ UP	VOLUME- DOWN	AUDIO MUTING	POWER ON/OFF			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH	SHARPNESS + SHARP	SHARPNESS - SOFT	PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																INPUT C
7x	INPUT D											RESET				

&lt;Table 9&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											V KEYSTONE					
4x													DDE TOGGLE			
5x																
6x	APA	DOT PHASE						FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS CONT TOGGLE							

(7) 15BIT Category (VPL-CX75, CX76)

<Table 10>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME + UP	VOLUME - DOWN	AUDIO MUTING	POWER ON/OFF *1			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH			PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON *1	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																
7x					LENS FOCUS F	LENS FOCUS N	AUTO FOCUS	LENS ZOOM L	LENS ZOOM S			RESET				

\*1 If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

&lt;Table 11&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											TILT/ KEYSTONE/ SIDE SHOT		MS PLAY	AIR SHOT	H KEYSTONE +	H KEYSTONE -
4x																
5x																
6x	APA	DOT PHASE	LENS ZOOM		LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS CONT TOGGLE							



(9) 15BIT Category (VPL-CX80)

<Table 12>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME + UP	VOLUME - DOWN	AUDIO MUTING	POWER ON/OFF *1			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH			PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON *1	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																
7x					LENS FOCUS F	LENS FOCUS N		LENS ZOOM L	LENS ZOOM S			RESET				

\*1 If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

&lt;Table 13&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											TILT/ KEYSTONE/ SIDE SHOT				H KEYSTONE +	H KEYSTONE -
4x																
5x																
6x	APA	DOT PHASE	LENS ZOOM		LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS CONT TOGGLE							

(11) 15BIT Category (VPL-CX85, CX86)

<Table 14>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME + UP	VOLUME - DOWN	AUDIO MUTING	POWER ON/OFF *1			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH			PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON *1	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																INPUT C
7x					LENS FOCUS F	LENS FOCUS N		LENS ZOOM L	LENS ZOOM S			RESET				

\*1 If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

&lt;Table 15&gt;

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											TILT/ KEYSTONE/ SIDE SHOT		MS PLAY	AIR SHOT	H KEYSTONE +	H KEYSTONE -
4x																
5x																
6x	APA	DOT PHASE	LENS ZOOM		LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS CONT TOGGLE							

(11) 15BIT Category (VPL-CX61, CX63)

<Table 16>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME + UP	VOLUME - DOWN	AUDIO MUTING	POWER ON/OFF *1			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE +	HUE - GREENISH			PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON *1	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x			W/B GAIN	W/B BIAS				INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																
7x					LENS FOCUS F	LENS FOCUS N		LENS ZOOM L	LENS ZOOM S			RESET				

\*1 If standby mode is set as "low", the main part of a projector will go into power-saving mode in about 1 minute after standby.  
A command is executed by resending, although "Not Applicable" will return, if a command is sent into power-saving mode.

<Table 17>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x																
2x																
3x											KEYSTONE					
4x																
5x																
6x	APA	DOT PHASE	LENS ZOOM		LENS FOCUS			FREEZE			DIGITAL ZOOM +	DIGITAL ZOOM -				
7x									LENS CONT TOGGLE							

(13) PROJECTORn category (Only VPL-FE40/FX40L/FX40/FX40L)

<Table 18>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x																
1x			VOLUME+ UP	VOLUME- DOWN	AUDIO MUTING	POWER ON/OFF			CONTRAST + HIGH	CONTRAST - LOW	COLOR + HIGH	COLOR - LOW			BRIGHTNESS + BRIGHT	BRIGHTNESS - DARK
2x	HUE + PURPLISH	HUE - GREENISH	SHARPNESS + SHARP	SHARPNESS - SOFT	PICTURE MUTING	STATUS ON	STATUS OFF			MENU	VIDEO	INPUT A	INPUT B		POWER ON	POWER OFF
3x				CURSOR →	CURSOR ←	CURSOR ↑	CURSOR ↓									
4x		ADJ R	ADJ G	ADJ B				RGB SIZE	RGB SHIFT							
5x								INPUT SELECT			ENTER				MEMORY	S VIDEO
6x																INPUT C
7x	INPUT D	INPUT E	LENS SHIFT ↑	LENS SHIFT ↓	LENS FOCUS F	LENS FOCUS N		LENS ZOOM L	LENS ZOOM S			RESET				

(2) PROJECTORnE category (Only VPL-FE40/FE40L/FX40/FX40L)

<Table 19>

	x0	x1	x2	x3	x4	x5	x6	x7	x8	x9	xA	xB	xC	xD	xE	xF
0x	V KEYSTONE+KEYSTONE	V KEYSTONE	LENS SHIFT←	LENS SHIFT→						PICTURE ADJ TGL						
1x																
2x																
3x											V KEYSTONE			AIR SHOT		
4x													DDE TOGGLE			
5x																
6x	APA	DOT PHASE	LENS ZOOM	LENS SHIFT	LENS FOCUS			FREEZE							ASPECT TOGGLE	
7x									LENS CONT TOGGLE							



このマニュアルに記載されている事柄の著作権は当社にあります。

従って、当社の許可なしに無断で複写したり、説明内容（操作、保守等）と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

VPL-CX61 (SY)  
VPL-CX63 (SY)  
VPL-CX75 (SY)  
VPL-CX76 (SY)  
VPL-CX80 (SY)  
VPL-CX85 (SY)  
VPL-CX86 (SY)  
VPL-FE40 (SY)  
VPL-FE40L (SY)  
VPL-FX40 (SY)  
VPL-FX40L (SY)  
VPL-FX51 (SY)  
VPL-FX52 (SY)  
VPL-FX52L (SY)  
VPL-PX35 (SY)  
VPL-PX40 (SY)  
VPL-PX41 (SY) E  
9-968-277-02

**Sony EMCS Corporation**  
Ichinomiya Tec

English  
2006LR16-1  
©2002