


CAM	ESP32	SD	ESP32
D0	PIN5	CLK	PIN14
D1	PIN18	CMD	PIN15
D2	PIN19	DATA0	PIN2
D3	PIN21	DATA1/Flash	PIN4
D4	PIN36	DATA2	PIN12
D5	PIN39	DATA3	PIN13
D6	PIN34		
D7	PIN35		
XCLK	PIN0		
PCLK	PIN22		
VSYNC	PIN25		
HREF	PIN23		
SDA	PIN26		
SCL	PIN27		
POWER PIN	PIN32		

PCB antenna/IPEX seat choose one Description



1. The module default value is the onboard antenna at position 1. The gain is 2dB.
2. If you need to use the IPEX base to connect an external antenna, you only need to connect 2 OR resistor (you need to change the OR resistor position yourself).
3. OR resistors can only be placed in positions①or②, respectively, corresponding to the use of different antennas, not at the same time!