
Vantage Connect 6620 (GSM/2G) Status LEDs:

Vantage Connect 6620 Weather Station Status: Normal

LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
	Blinks green, on and off	Searching for weather station signal	Wait for next step.
	Green stays on	Receiving weather station packets, normal function	No action needed.

Vantage Connect 6620 Cell Status: Normal






LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
Slowly blinks blue on and off		Searching for cellular signal	Wait for next step.
Solid blue		Logged on to cellular network, normal function.	No action needed.

Vantage Connect (6620) Error Messages

LED Behavior		Indicates	What to do
Lower LED (Network)	Upper LED (Wx Status)		
Rapidly flashes blue on and off, while upper red LED blinks to indicate the error code. Pauses and repeats.	Blinks red once, pauses and repeats.	No cellular signal found.	Move the Vantage Connect to a different location.
	Blinks red twice, pauses and repeats.	Low cellular signal strength.	Vantage Connect may function in this location, but you may want to move if possible.
	Blinks red a specific number (3 to 10) of times	There is a cell error. The number of red flashes indicates the error code number.	Contact Tech Support and report the error code.
Rapidly flashes blue	Alternates flashing green and red	The system has encountered a problem and is restarting	Wait for restart.
Slowly blinks blue	Alternates flashing green and yellow	Upgrading firmware over the air.	Wait; this can take several minutes.
	Solid red	There is an error in receiving weather data from the transmitter(s).	Contact Tech Support.

Vantage Connect 6621 & 6622 (CDMA & 3G): Normal and Error LEDs

Vantage Connect 6621 & 6622 (CDMA & 3G) Status LEDs

LED Position and What it Indicates	Color Indicates		
	Green	Yellow	Red
Upper LED: Weather Station Status 	Receiving weather station packets, normal function.	Searching for weather station signal.	No weather station signal. Contact Tech Support.
Cell Status 1: Modem Activation 	Modem activated.	Modem is activating.	Modem not activated. Contact Tech Support.
Cell Status 2: Cellular Signal Strength 	Strong signal.	Low signal. Vantage Connect will function in this location, but move if possible.	No signal. Vantage Connect will not function in this location.
Cell Status 3: Network Registration 	Registered.	Searching for tower.	Registration failed. Contact Tech Support.
Cell Status 4: Communication with WeatherLink.com 	Good.	Waiting for connection.	Communication error. Contact Tech Support.