

iDynamo Reader PROGRAMMING REFERENCE MANUAL

PART NUMBER 99875568-1

Please refer to **99875483** for the low-level communication reference manual.

MAY 2012

Confidential

This document contains the proprietary information of MagTek. Its receipt or possession does not convey any rights to reproduce or disclose its contents or to manufacture, use or sell anything it may describe. Reproduction, disclosure or use without specific written authorization of MagTek is strictly forbidden.

Unpublished – All Rights Reserved

MAGTEK[®]

REGISTERED TO ISO 9001:2008

1710 Apollo Court

Seal Beach, CA 90740

Phone: (562) 546-6400

FAX: (562) 546-6301

Technical Support: (651) 415-6800

www.magtek.com

Copyright© 2001-2012
MagTek®, Inc.
Printed in the United States of America

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of MagTek, Inc.

MagTek is a registered trademark of MagTek, Inc.

REVISIONS

Rev Number	Date	Notes
1.01	2011 Dec 22	Initial Release
1.02	2011 Aug 2	Remove Audio reader
1.03	2012 Feb 29	Added Functionality
1.04	2012 Mar 26	Added getBatteryLevel
1.05	2012 Apr 19	Added getSDKVersion & getOperationStatus
1.06	2012 May 01	Made iDynamo-specific

SOFTWARE LICENSE AGREEMENT

IMPORTANT: YOU SHOULD CAREFULLY READ ALL THE TERMS, CONDITIONS AND RESTRICTIONS OF THIS LICENSE AGREEMENT BEFORE INSTALLING THE SOFTWARE PACKAGE. YOUR INSTALLATION OF THE SOFTWARE PACKAGE PRESUMES YOUR ACCEPTANCE OF THE TERMS, CONDITIONS, AND RESTRICTIONS CONTAINED IN THIS AGREEMENT. IF YOU DO NOT AGREE WITH THESE TERMS, CONDITIONS, AND RESTRICTIONS, PROMPTLY RETURN THE SOFTWARE PACKAGE AND ASSOCIATED DOCUMENTATION TO THE ABOVE ADDRESS, ATTENTION: CUSTOMER SUPPORT.

TERMS, CONDITIONS, AND RESTRICTIONS

MagTek, Incorporated (the "Licensor") owns and has the right to distribute the described software and documentation, collectively referred to as the "Software".

LICENSE: Licensor grants you (the "Licensee") the right to use the Software in conjunction with MagTek products. LICENSEE MAY NOT COPY, MODIFY, OR TRANSFER THE SOFTWARE IN WHOLE OR IN PART EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT. Licensee may not decompile, disassemble, or in any other manner attempt to reverse engineer the Software. Licensee shall not tamper with, bypass, or alter any security features of the software or attempt to do so.

TRANSFER: Licensee may not transfer the Software or license to the Software to another party without the prior written authorization of the Licensor. If Licensee transfers the Software without authorization, all rights granted under this Agreement are automatically terminated.

COPYRIGHT: The Software is copyrighted. Licensee may not copy the Software except for archival purposes or to load for execution purposes. All other copies of the Software are in violation of this Agreement.

TERM: This Agreement is in effect as long as Licensee continues the use of the Software. The Licensor also reserves the right to terminate this Agreement if Licensee fails to comply with any of the terms, conditions, or restrictions contained herein. Should Licensor terminate this Agreement due to Licensee's failure to comply, Licensee agrees to return the Software to Licensor. Receipt of returned Software by the Licensor shall mark the termination.

LIMITED WARRANTY: Licensor warrants to the Licensee that the disk(s) or other media on which the Software is recorded are free from defects in material or workmanship under normal use.

THE SOFTWARE IS PROVIDED AS IS. LICENSOR MAKES NO OTHER WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Because of the diversity of conditions and PC hardware under which the Software may be used, Licensor does not warrant that the Software will meet Licensee specifications or that the operation of the Software will be uninterrupted or free of errors.

IN NO EVENT WILL LICENSOR BE LIABLE FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE, OR INABILITY TO USE, THE SOFTWARE. Licensee's sole remedy in the event of a defect in material or workmanship is expressly limited to replacement of the Software disk(s) if applicable.

GOVERNING LAW: If any provision of this Agreement is found to be unlawful, void, or unenforceable, that provision shall be removed from consideration under this Agreement and will not affect the enforceability of any of the remaining provisions. This Agreement shall be governed by the laws of the State of California and shall inure to the benefit of MagTek, Incorporated, its successors or assigns.

ACKNOWLEDGMENT: LICENSEE ACKNOWLEDGES THAT HE HAS READ THIS AGREEMENT, UNDERSTANDS ALL OF ITS TERMS, CONDITIONS, AND RESTRICTIONS, AND AGREES TO BE BOUND BY THEM. LICENSEE ALSO AGREES THAT THIS AGREEMENT SUPERSEDES ANY AND ALL VERBAL AND WRITTEN COMMUNICATIONS BETWEEN LICENSOR AND LICENSEE OR THEIR ASSIGNS RELATING TO THE SUBJECT MATTER OF THIS AGREEMENT.

QUESTIONS REGARDING THIS AGREEMENT SHOULD BE ADDRESSED IN WRITING TO MAGTEK, INCORPORATED, ATTENTION: CUSTOMER SUPPORT, AT THE ABOVE ADDRESS, OR E-MAILED TO support@magtek.com.

Table of Contents

Section 1. MagTekSCRA Class	1
Methods.....	3
openDevice:	3
closeDevice:	3
isDeviceConnected	3
clearBuffers	3
getMaskedTracks	4
getTrack1	4
getTrack2	4
getTrack3	4
getTrack1Masked.....	5
getTrack2Masked.....	5
getTrack3Masked.....	5
getMagnePrint.....	5
getMagnePrintStatus	6
getDeviceSerial	6
getSessionID	6
getKSN.....	6
getTagValue.....	7
getDeviceSerial	7
getMagTekDeviceSerial	7
getFirmware	7
getDeviceName.....	7
getDeviceCaps	8
getDeviceStatus.....	8
getTLVVersion	8
getDevicePartNumber.....	8
sendCommandToDevice.....	9
getCapMSR.....	9
getCapTracks	9
getCapMagStripeEncryption.....	9
setDeviceProtocolString	10
listenForEvents	10
getDeviceType	10
getCardPANLength.....	10
getResponseData.....	10
getCardName	11
getCardIIN	11
getCardLast4	11
getCardExpDate.....	11
getCardServiceCode	11
getCardStatus	12

getTrackDecodeStatus	12
getResponseTypes	12
setDeviceType.....	12
isDeviceOpened	13
getBatteryLevel.....	14
getSDKVersion	14
getOperationStatus	14
Notification	15
trackDataReadyNotification	15
devConnectionNotification	15
Enum	16
MTSCRADeviceType.....	16
MTSCRATransactionStatus	16
MTSCRATransactionData.....	16
Section 2. CoMMANDs.....	18
Discovery	18
Section 3. Code Examples	20
Open Device:	20
Close Device:	20
Get Tracks Data From Reader:	20
Get Connection Status Of Reader:	21

SECTION 1. MagTekSCRA CLASS

Classes	Description
MagTekSCRA	This class allows you to perform reader functions.

Methods:

openDevice:	Open device
closeDevice:	Close device
isDeviceConnected	Check the connection status of reader
clearBuffers	Clear card data that is stored through the setCardData function
getMaskedTracks	Retrieves the existing stored masked track data
getTrack1	Retrieves encrypted track1
getTrack2	Retrieves encrypted track2
getTrack3	Retrieves encrypted track3
getTrack1Masked	Retrieves masked track1
getTrack2Masked	Retrieves masked track2
getTrack3Masked	Retrieves masked track3
getMagnePrint	Retrieves encrypted MagnePrint
getMagnePrintStatus	Retrieves encrypted MagnePrintStatus
getDeviceSerial	Retrieves device serial number
getSessionID	Retrieves session ID
getKSN	Retrieves key serial number
getTagValue	Retrieves tag value in tracks data
getMagTekDeviceSerial	Retrieves device serial number created by MagTek
getDeviceName	Retrieves device model name
getDeviceCaps	Retrieves device capabilities
getDeviceStatus	Retrieves device status
getTLVVersion	Retrieves TLV version
getDevicePartNumber	Retrieves device part number
sendCommandToDevice	Send command to device
getCapMSR	Retrieve MSR Capability
getCapTracks	Retrieve Tracks Capability
getCapMagStripeEncryption	Retrieve MagStripe Encryption Capability
setDeviceProtocolString	Sets the protocol String for iDynamo
listenForEvents	Setup the events to listen for
getDeviceType	Retrieves the Device Type
getCardPANLength	Retrieves the Length of teh PAN
getResponseData	Retrieved the whole Response from the reader
getCardName	Retrieves the Name in the Card
getCardIIN	Retrieves the IIN in the Card
getCardLast4	Retrieves the Last 4 of the PAN
getCardExpDate	Retrieves the Expiration Date
getCardServiceCode	Retrieves the Service Code
getCardStatus	Retrieves the Card Status
getTrackDecodeStatus	Retrieves the Track Decode Status
getResponseType	Retrieve Response Type
setDeviceType	Sets the type of device to Open
isDeviceOpened	Retrieves device opened status

Notifications:

trackDataReadyNotification	Receives notification when track data is available on reader
devConnectionNotification	Receives notification when reader's connection status is changed
getSDKVersion	Retrieves SDK version
getOperationStatus	Retrieves operation status

Enum:

MTSCRADeviceType	MAGTEKAUDIOREADER
MTSCRATransactionStatus	TRANS_STATUS_OK TRANS_STATUS_START TRANS_STATUS_ERROR
MTSCRATransactionData	TLV_OPSTS TLV_CARDSTS TLV_TRACKSTS TLV_CARDNAME TLV_CARDIIN TLV_CARDLAST4 TLV_CARDEXPDATE TLV_CARDSVCCODE TLV_CARDPANLEN TLV_ENCTK1 TLV_ENCTK2 TLV_ENCTK3 TLV_DEVSN TLV_DEVSNMAGTEK TLV_DEVFW TLV_DEVNAME TLV_DEVCAPS TLV_TLVVERSION TLV_DEVPARTNUMBER TLV_KSN TLV_CMAC

Methods

openDevice:

This function opens the reader.

- (BOOL) openDevice

Parameters

Return Value

YES if the device is opened successfully. Otherwise, return NO.

closeDevice:

This function close the reader.

- (BOOL) closeDevice

Parameters

Return Value

YES if the device is closed successfully. Otherwise, return NO.

isDeviceConnected

This function retrieves the connection status of the reader.

- (BOOL) isDeviceConnected

Parameters

Return Value

YES if the device is connected. Otherwise, return NO.

clearBuffers

Clears all the buffer that is stored during card swipe or command response.

- (void) clearBuffers

Parameters

Return Value

getMaskedTracks

Retrieves existing stored Masked data, only supported for iDynamo, it will return a empty string in audio reader

- (**NSString** *) getMaskedTracks

Parameters

Return Value

Return stored masked tracks data string.

getTrack1

Retrieve Encrypted Track1 if any

- (**NSString** *) getTrack1

Parameters

Return Value

Return stored encrypted track1 data string.

getTrack2

Retrieve Encrypted Track2 if any

- (**NSString** *) getTrack2

Parameters

Return Value

Return stored encrypted track2 data string.

getTrack3

Retrieve Encrypted Track3 if any

- (**NSString** *) getTrack3

Parameters

Return Value

Return stored encrypted track3 data string.

getTrack1Masked

Retrieve Masked Track1 if any

- (**NSString** *) getTrack1

Parameters

Return Value

Return stored masked track1 data string.

getTrack2Masked

Retrieve Masked Track2 if any

- (**NSString** *) getTrack2

Parameters

Return Value

Return stored masked track2 data string.

getTrack3Masked

Retrieve Masked Track3 if any

- (**NSString** *) getTrack3

Parameters

Return Value

Return stored masked track3 data string.

getMagnePrint

Retrieve Encrypted MagnePrint, only supported for iDynamo, it will return a empty string in audio reader

- (**NSString** *) getMagnePrint

Parameters

Return Value

Return stored MagnePrint string.

getMagnePrintStatus

MagnePrint Status, only supported for iDynamo, it will return a empty string in audio reader

- (**NSString** *) getMagnePrintStatus

Parameters

Return Value

Return stored MagnePrintStatus string.

getDeviceSerial

Retrieve device serial number.

- (**NSString** *) getDeviceSerial

Parameters

Return Value

Return stored device serial number.

getSessionID

Retrieve Session ID, only supported for iDynamo, it will return a empty string in audio reader

- (**NSString** *) getSessionID

Parameters

Return Value

Return stored session ID.

getKSN

Retrieve key serial number.

- (**NSString** *) getKSN

Parameters

Return Value

Return stored key serial number.

getTagValue

Retrieve individual tag value, only supported in audio reader

- (**NSString** *) getTagValue: (UInt32) tag

Parameters

tag A MISCRATransactionData Enum type.

Return Value

Return tag value.

getDeviceSerial

Retrieve Device Serial Number

- (**NSString** *) getDeviceSerial

Parameters

Return Value

Return stored key serial number.

getMagTekDeviceSerial

Retrieve Device Serial Number created by MagTek

- (**NSString** *) getMagTekDeviceSerial

Parameters

Return Value

Return stored key serial number created by MagTek.

getFirmware

Retrieve firmware version number.

- (**NSString** *) getFirmware

Parameters

Return Value

Return firmware version.

getDeviceName

Get device model name.

- (**NSString** *) getDeviceName

Parameters

Return Value

Return device model name.

getDeviceCaps

Get device capabilities.

- (**NSString** *) getDeviceCaps

Parameters**Return Value**

Return device capabilities.

getDeviceStatus

Get device status.

- (**NSString** *) getDeviceStatus

Parameters**Return Value**

Return device status.

getTLVVersion

Get TLV Version of firmware.

- (**NSString** *) getTLVVersion

Parameters**Return Value**

Return TLV version of firmware.

getDevicePartNumber

Get device part number.

- (**NSString** *) getDevicePartNumber

Parameters**Return Value**

Return device part number.

sendCommandToDevice

Send command to device.

- (Void *) sendCommandToDevice: (NSString *)pData

Parameters

Command string.

Return Value

Send command to device. Please refer to Section 2 for command list.

getCapMSR

Retrieve MSR Capability

- (NSString *) getCapMSR

Parameters

Return Value

Return MSR Capability

getCapTracks

Retrieve Tracks Capability

- (NSString *) getCapTracks

Parameters

Return Value

Return Tracks Capability

getCapMagStripeEncryption

Retrieve MagStripe Encryption Capability

- (NSString *) getCapMagStripeEncryption

Parameters

Return Value

Return MagStripe Encryption Capability

setDeviceProtocolString

Sets the protocol String for iDynamo

- (void) setDeviceProtocolString: (NSString *)pData

Parameters

Protocol String

Return Value

listenForEvents

Setup the events to listen for

- (void) setDeviceProtocolString: (UInt32 *)event

Parameters

Event

Return Value

getDeviceType

Retrieves the Device Type

- (int) getDeviceType

Parameters

Return Value

Device Type

getCardPANLength

Retrieves the Length of teh PAN

- (int) getCardPANLength

Parameters

Return Value

Card PAN Length

getResponseData

Retrieves the whole Response from the reader

- (NSString *) getResponseData

Parameters

Return Value
Response Data

getCardName

Retrieves the Name in the Card

- (**NSString ***) getCardName

Parameters

Return Value
Card Name

getCardIIN

Retrieves the IIN in the Card

- (**NSString ***) getCardIIN

Parameters

Return Value
IIN

getCardLast4

Retrieves the Last 4 of the PAN

- (**NSString ***) getCardLast4

Parameters

Return Value
Last 4 of the PAN

getCardExpDate

Retrieves the Expiration Date

- (**NSString ***) getCardExpDate

Parameters

Return Value
Expiration Date

getCardServiceCode

Retrieves the Service Code

- (**NSString ***) getCardServiceCode

Parameters

Return Value
Service Code

getCardStatus

Retrieves the Card Status

- (NSString *) getCardStatus

Parameters

Return Value
Card Status

getTrackDecodeStatus

Retrieves the Track Decode Status

- (NSString *) getTrackDecodeStatus

Parameters

Return Value
Track Decode Status

getResponseTypes

Retrieves the Response Types

- (NSString *) getResponseTypes

Parameters

Return Value
Response Types

setDeviceType

Sets the type of device to Open

- (void) setDeviceType: (UInt32 *) deviceType

Parameters
Device Type

Return Value

isDeviceOpened

Retrieves device opened status

- (**BOOL**) isDeviceOpened

Parameters

Return Value

Boolean whether device is opened or not

getBatteryLevel

Retrieves device battery level

- (**long**) getBatteryLevel

Parameters

Return Value

Battery Level

getSDKVersion

Retrieves the SDK Version

- (**NSString ***) getSDKVersion

Parameters

Return Value

SDK Version

getOperationStatus

Retrieves the operation status

- (**NSString ***) getOperationStatus

Parameters

Return Value

Operation Status

Notification

trackDataReadyNotification

Notification received when tracks data is available on reader.

devConnectionNotification

Notification received when the connection status of the reader is changed.

Enum

MTSCRADeviceType

`MAGTEKAUDIOREADER` is used to open/close audio reader.

MTSCRATransactionStatus

`TRANS_STATUS_OK` is triggered when transaction succeed.

`TRANS_STATUS_START` is triggered when reader starts sending data.

`TRANS_STATUS_ERROR` is triggered when reader fails sending data.

MTSCRATransactionData

TLV_OPSTS
Operation Status

TLV_CARDSTS
Card Information

TLV_TRACKSTS
Card tracks status

TLV_CARDNAME
Card holder name

TLV_CARDIIN
Card issuer identification number

TLV_CARDLAST4
Last four digits of PAN number

TLV_CARDEXPDATE
Card Expiration date

TLV_CARDSVCCODE
Card service code

TLV_CARDPANLEN
The length of PAN number

TLV_ENCTK1
Encrypted track 1

TLV_ENCTK2

Encrypted track 2

TLV_ENCTK3

Encrypted track 3

TLV_DEVSN

Device serial number

TLV_DEVSNMAGTEK

Device serial number created by Magek

TLV_DEVFW

Device firmware version

TLV_DEVNAME

Device model name

TLV_DEVCAPS

Device capabilities

TLV_DEVSTATUS

Device status

TLV_TLVVERSION

Firmware TLV version

TLV_DEVPARTNUMBER

Device part number

TLV_KSN

KSN

TLV_CMAC

CMAC

SECTION 2. COMMANDS

Discovery

Send discovery command to device.

- (Void *) sendCommandToDevice: (NSString *)command

Parameters

Command string: use "C10206C20503C30100" as command string.

Return Value

Following device information will can be retrieved.

Device SN, internal

Device serial number created by chip manufacturer.

use getDeviceSerial method to retrieve data.

Device SN, MagTek

Device serial number created by MagTek.

use getDeviceSerialMagTek method to retrieve data.

Device Firmware Part Number

Device firmware part number.

use getFirmware method to retrieve data.

Device Model Name

Device model name.

use getDeviceName method to retrieve data.

Device TLV Version

Device TLV version.

use getTLVVersion method to retrieve data.

Device Part Number

Device part number.

use getDevicePartNumber method to retrieve data.

Capability - MSR

0 = No MSR, 1 = MSR

use getCapMSR method to retrieve data.

Capability - TRACKS

0 = Supported tracks: None.

1 = Supported tracks: Track1.

2 = Supported tracks: Track2.

3 = Supported tracks: Track1, Track2.

4 = Supported tracks: Track3.

5 = Supported tracks: Track1, Track3.
6 = Supported tracks: Track2, Track3.
7 = Supported tracks: Track1, Track2, Track3.

use getCapTracks method to retrieve data.

Capability - MagStripe Encryption

0 = No Encryption, 1 = TripDES DUKPT

use getCapMagStripeEncryption method to retrieve data.

SECTION 3. CODE EXAMPLES

Open Device:

```
self.mtSCRALib = [[MTSCRA alloc] init];
[self.mtSCRALib
listenForEvents: (TRANS_EVENT_OK | TRANS_EVENT_START | TRANS_EVENT_ERROR)];

//iDynamo
[self.mtSCRALib setDeviceType: (MAGTEKI_DYNAMO)];
[self.mtSCRALib setDeviceProtocolString: ("com.magtek.i.dynamo")];
[self.mtSCRALib setDeviceType: (MAGTEKI_DYNAMO)];
//Audio
//[self.mtSCRALib setDeviceType: (MAGTEKAUDIOREADER)];
[self.mtSCRALib openDevice];
```

Close Device:

```
[self.mtSCRALib closeDevice];
```

Get Tracks Data From Reader:

```
[[NSNotificationCenter defaultCenter] addObserver:self
selector:@selector(trackDataReady:) name:@"trackDataReadyNotification"
object:nil];

- (void)trackDataReady: (NSNotification *)notification
{
    NSNumber *status = [[notification userInfo]
valueForKey:@"status"];

    [self performSelectorOnMainThread:@selector(onDataEvent:)
withObject:status waitUntilDone:YES];
}

- (void)onDataEvent: (id)status
{
    //[self clearLabels];

    switch ([status intValue]) {
        case TRANS_STATUS_OK:

            NSLog(@"TRANS_STATUS_OK");
            break;

        case TRANS_STATUS_ERROR:
```

```

        NSLog(@"TRANS_STATUS_ERROR");
        break;
    default:
        break;
    }
}

```

Get Connection Status Of Reader:

```

[[NSNotificationCenter defaultCenter] addObserver:self
selector:@selector(devConnStatusChange)
name:@"devConnectionNotification" object:nil];

- (void)devConnStatusChange
{
    BOOL isDeviceConnected = [self.mtSCRALib isDeviceConnected];
    if (isDeviceConnected)
    {
        self.deviceStatus.text = @"Device Connected";
    }
    else
    {
        self.deviceStatus.text = @"Device Disconnected";
    }
}

```