

EXAM Testreport

Starttime 16:45:05 19. August 2013

Title General tests

Project RPP tests

Department ČVUT FEL

Subject 5766

Operator

Phone

Mail hubnepa1@fel.cvut.cz

Comment

RPP_2013-08-19__16-45-05_SN_5766



test-statistic on 18 evaluated tests(s)		
pass	open	fail
8	0	0


1. General-Data

(default)	
mail	hubnepa1@fel.cvut.cz
project	RPP tests
title	General tests
subject	5766
department	ČVUT FEL
CodeSync	
Date of last code synchronization	2013-08-19 16:44:30
SystemConfigurations	
RPPTTest.EnvironmentConfig	
Versions	
Environment	
Modules	
de.exam.testrunner.modules.core	3.1.5
de.tracetrone.exam.tracecheck	2.0.0.201202231635
Python	
Python	2.5.4 (r254:67916, Dec 23 2008, 15:10:54) [MSC v.1310 32 bit (Intel)]
Tools	
EXAM	3.1.6 BuildID: M_20120928 191048
Description	

2. Statistic-Data

number of executed tests:	18
number of tests without script-errors:	18
number of tests with detected script-errors:	0
number of executed administrativeCases:	10
number of executed testCases:	8
number of inactive testCases:	0
complete test-time:	00:00:00:53

 pass: 8 tests = 100.00%
 open: 0 tests = 0.00%



■ fail: 0 tests = 0.00%

3. Overview-Data

4.1 Group - initialization	INFO	
4.1.1 Test - initialization	INFO	---
4.2 Group - LOUT	PASS	
4.2.1 Test - initLOUT	INFO	---
4.2.2 Test - LOUT	PASS	---
4.3 Group - MOUT	PASS	
4.3.1 Test - initMOUT	INFO	---
4.3.2 Test - MOUT	PASS	---
4.4 Group - HOUT	PASS	
4.4.1 Test - initHOUT	INFO	---
4.4.2 Test - HOUT	PASS	---
4.5 Group - HBR	PASS	
4.5.1 Test - initHBR	INFO	---
4.5.2 Test - HBR	PASS	---
4.6 Group - ADIN	PASS	
4.6.1 Test - initADIN	INFO	---
4.6.2 Test - ADIN	PASS	---
4.7 Group - DIN0to7	PASS	
4.7.1 Test - initDIN0to7	INFO	---
4.7.2 Test - DIN0to7	PASS	---
4.8 Group - DIN8to15	PASS	
4.8.1 Test - initDIN8to15	INFO	---
4.8.2 Test - DIN8to15	PASS	---
4.9 Group - DAC	PASS	
4.9.1 Test - initDAC	INFO	---

4.9.2 Test - DAC	PASS	---
4.10 Group - deInitialization	INFO	
4.10.1 Test - deInitialization	INFO	---

4. Testresult-Data

4.1 Group - initialization

Group -Valuation	INFO
Group -Start-/Execution-Time	2013-08-19 16:45:06 / 00:00:00:00
Group -Description	Initializes the test suite (starts TCP server and open channel for communication over RS232).

4.1.1 Test - initialization

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:06 / 00:00:00:00
Test -Description	This test case open channel for communication over RS232 and over TCP. RS232 parameters: COM3, baudrate: 115200, parity: none, stopbits: 1, databits: 8, buffersize: 1024, timeout: 20 TCP parameters: IP address: localhost, port: 8890

4.1.1 initialization -- Metadata

(default)	
duration	--:--:--

4.1.1 initialization -- Run

Test flow -- RPPTTest.basics.initialization
This test case open channel for communication over RS232 and over TCP. RS232 parameters: COM3, baudrate: 115200, parity: none, stopbits: 1, databits: 8, buffersize: 1024, timeout: 20 TCP parameters: IP address: localhost, port: 8890

4.2 Group - LOUT

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:06 / 00:00:00:03
Group -Description	TestGroup
TestGroup	

4.2.1 Test - initLOUT

Test -Full-Scoped-Name : Full Scoped Name	
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:06 / 00:00:00:00
Test -Description	
Administrative testcase initLOUT calls init function and sets the range of tested pins.	

4.2.1 initLOUT -- Metadata

(default)	
duration	--:--:--

4.2.1 initLOUT -- Run

Test flow -- RPPTTest.pins.LOUT.testCases.initLOUT	
Administrative testcase initLOUT calls init function and sets the range of tested pins.	

4.2.2 Test - LOUT

Test -Full-Scoped-Name : Full Scoped Name	
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:06 / 00:00:00:03
Test -Description	
LOUT testcase: RPP board generates digital signals measured by hummusoft card (digital in).	

4.2.2 LOUT -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e44057ae5b014058457fc500e8
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.2.2 LOUT -- Run

Test flow -- RPPTTest.pins.LOUT.testCases.LOUT
LOUT testcase: RPP board generates digital signals measured by hummusoft card (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).

Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.

Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.LOUT.testSequences.setLogValue
This sequence sets logical values to the LOUT pin.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.LOUT.testSequences.checkValueOverTCP
This sequence reads the LOUT periphery by hummusoft cards (digital in).

4.2.2 LOUT -- Subtest

LOUT1

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT1set	0	0	logical	PASS	Set logical value over RS232.
LOUT1 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT1 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT1set	1	1	logical	PASS	Set logical value over RS232.
LOUT1 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT1 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT2

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT2set	0	0	logical	PASS	Set logical value over RS232.
LOUT2 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT2 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT2set	1	1	logical	PASS	Set logical value over RS232.
LOUT2 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT2 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT3

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT3set	0	0	logical	PASS	Set logical value over RS232.
LOUT3 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT3 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT3set	1	1	logical	PASS	Set logical value over RS232.
LOUT3 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT3 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT4

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT4set	0	0	logical	PASS	Set logical value over RS232.
LOUT4 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT4 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT4set	1	1	logical	PASS	Set logical value over RS232.
LOUT4 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT4 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT5

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT5set	0	0	logical	PASS	Set logical value over RS232.
LOUT5 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT5 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT5set	1	1	logical	PASS	Set logical value over RS232.
LOUT5 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT5 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT6

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT6set	0	0	logical	PASS	Set logical value over RS232.
LOUT6 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT6 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT6set	1	1	logical	PASS	Set logical value over RS232.
LOUT6 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT6 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT7

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT7set	0	0	logical	PASS	Set logical value over RS232.
LOUT7 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT7 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT7set	1	1	logical	PASS	Set logical value over RS232.
LOUT7 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT7 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

LOUT8

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
LOUT8set	0	0	logical	PASS	Set logical value over RS232.
LOUT8 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
LOUT8 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
LOUT8set	1	1	logical	PASS	Set logical value over RS232.
LOUT8 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
LOUT8 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

4.3 Group - MOUT

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:10 / 00:00:00:03
Group -Description	

TestGroup

TestGroup

4.3.1 Test - initMOUT

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:10 / 00:00:00:00
Test -Description	
Administrative testcase initMOUT calls init function and sets the range of tested pins.	

4.3.1 initMOUT -- Metadata

(default)	
duration	--:--:--

4.3.1 initMOUT -- Run

Test flow -- RPPTTest.pins.MOUT.testCases.initMOUT
Administrative testcase initMOUT calls init function and sets the range of tested pins.

4.3.2 Test - MOUT

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:10 / 00:00:00:03
Test -Description	
LOUT testcase: RPP board generates digital signals measured by hummusoft card (digital in).	

4.3.2 MOUT -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e44062016501406216b09c00b1
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.3.2 MOUT -- Run

Test flow -- RPPTTest.pins.MOUT.testCases.MOUT
LOUT testcase: RPP board generates digital signals measured by hummusoft card (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).

Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.

Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).
Test flow -- RPPTTest.pins.MOUT.testSequences.setLogValue
This sequence sets logical values to the MOUT pin.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverRS232
This sequence checks if the logical value is set.
Test flow -- RPPTTest.pins.MOUT.testSequences.checkValueOverTCP
This sequence reads the MOUT periphery by hummusoft cards (digital in).

4.3.2 MOUT -- Subtest

MOUT1					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT1set	0	0	logical	PASS	Set logical value over RS232.
MOUT1 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT1 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT1set	1	1	logical	PASS	Set logical value over RS232.
MOUT1 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT1 check [TCP]	1	1	logical	PASS	Check logical value over TCP.
MOUT2					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT2set	0	0	logical	PASS	Set logical value over RS232.
MOUT2 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT2 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT2set	1	1	logical	PASS	Set logical value over RS232.
MOUT2 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT2 check [TCP]	1	1	logical	PASS	Check logical value over TCP.
MOUT3					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT3set	0	0	logical	PASS	Set logical value over RS232.
MOUT3 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT3 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT3set	1	1	logical	PASS	Set logical value over RS232.
MOUT3 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT3 check [TCP]	1	1	logical	PASS	Check logical value over TCP.
MOUT4					

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT4set	0	0	logical	PASS	Set logical value over RS232.
MOUT4 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT4 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT4set	1	1	logical	PASS	Set logical value over RS232.
MOUT4 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT4 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

MOUT5

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT5set	0	0	logical	PASS	Set logical value over RS232.
MOUT5 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT5 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT5set	1	1	logical	PASS	Set logical value over RS232.
MOUT5 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT5 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

MOUT6

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
MOUT6set	0	0	logical	PASS	Set logical value over RS232.
MOUT6 check [RS232]	0	0	logical	PASS	Check logical value over RS232.
MOUT6 check [TCP]	0	0	logical	PASS	Check logical value over TCP.
MOUT6set	1	1	logical	PASS	Set logical value over RS232.
MOUT6 check [RS232]	1	1	logical	PASS	Check logical value over RS232.
MOUT6 check [TCP]	1	1	logical	PASS	Check logical value over TCP.

4.4 Group - HOUT

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:13 / 00:00:00:16
Group -Description	
TestGroup	
TestGroup	

4.4.1 Test - initHOUT

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:13 / 00:00:00:00
Test -Description	
Administrative testcase initHOUT calls init function and sets the range of tested pins.	

4.4.1 initHOUT -- Metadata

(default)	
duration	--:--:--

4.4.1 initHOUT -- Run

Test flow -- RPPTTest.pins.HOUT.testCases.initHOUT
Administrative testcase initHOUT calls init function and sets the range of tested pins.

4.4.2 Test - HOUT

Test -Full-Scoped-Name : Full Scoped Name	
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:13 / 00:00:00:16
Test -Description	
HOUT testcase: RPP board generates various periods and duty cycles and hummusoft card (analog in) measured the size of voltage.	

4.4.2 HOUT -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e4407161c4014071deaa7a01fa
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.4.2 HOUT -- Run

Test flow -- RPPTTest.pins.HOUT.testCases.HOUT
HOUT testcase: RPP board generates various periods and duty cycles and hummusoft card (analog in) measured the size of voltage.
Test flow -- RPPTTest.pins.HOUT.testSequences.startPWM
This sequence starts generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.

[illegible]

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.stopPWM
This sequence stops generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.startPWM
This sequence starts generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

22 / 108

[illegible]

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.stopPWM
This sequence stops generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.startPWM
This sequence starts generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM

This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.stopPWM
This sequence stops generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.startPWM
This sequence starts generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

30 / 108

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.stopPWM
This sequence stops generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.startPWM
This sequence starts generating of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

[illegible]

[illegible]

This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.

Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.setPWM
This sequence sets period and duty cycle of PWM.
Test flow -- RPPTTest.pins.HOUT.testSequences.checkPWM
This sequence determinates if the measured voltage corresponds to the set period and duty cycle of HOUT bridge.
Test flow -- RPPTTest.pins.HOUT.testSequences.stopPWM
This sequence stops generating of PWM.

4.4.2 HOUT -- Subtest

HOUT connected.					
HOUT1 start					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT1 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.
HOUT - period: 1000 us, tolerance: 1500 mV.					

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT1[5%] check	385	420	mV	PASS	Checked over TCP.
HOUT1[15%] check	1000	1260	mV	PASS	Checked over TCP.
HOUT1[25%] check	2998	2100	mV	PASS	Checked over TCP.
HOUT1[35%] check	2578	2940	mV	PASS	Checked over TCP.
HOUT1[45%] check	4028	3780	mV	PASS	Checked over TCP.
HOUT1[55%] check	4008	4620	mV	PASS	Checked over TCP.
HOUT1[65%] check	4912	5460	mV	PASS	Checked over TCP.
HOUT1[75%] check	5717	6300	mV	PASS	Checked over TCP.
HOUT1[85%] check	6689	7140	mV	PASS	Checked over TCP.
HOUT1[95%] check	7924	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT1[5%] check	458	420	mV	PASS	Checked over TCP.
HOUT1[15%] check	1381	1260	mV	PASS	Checked over TCP.
HOUT1[25%] check	1948	2100	mV	PASS	Checked over TCP.
HOUT1[35%] check	2968	2940	mV	PASS	Checked over TCP.
HOUT1[45%] check	3662	3780	mV	PASS	Checked over TCP.
HOUT1[55%] check	4448	4620	mV	PASS	Checked over TCP.
HOUT1[65%] check	5478	5460	mV	PASS	Checked over TCP.
HOUT1[75%] check	6279	6300	mV	PASS	Checked over TCP.
HOUT1[85%] check	7207	7140	mV	PASS	Checked over TCP.
HOUT1[95%] check	8046	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT1[5%] check	659	420	mV	PASS	Checked over TCP.
HOUT1[15%] check	1538	1260	mV	PASS	Checked over TCP.
HOUT1[25%] check	2353	2100	mV	PASS	Checked over TCP.
HOUT1[35%] check	3159	2940	mV	PASS	Checked over TCP.
HOUT1[45%] check	3964	3780	mV	PASS	Checked over TCP.
HOUT1[55%] check	4926	4620	mV	PASS	Checked over TCP.
HOUT1[65%] check	5742	5460	mV	PASS	Checked over TCP.
HOUT1[75%] check	6557	6300	mV	PASS	Checked over TCP.
HOUT1[85%] check	7373	7140	mV	PASS	Checked over TCP.
HOUT1[95%] check	8256	7980	mV	PASS	Checked over TCP.

HOUT1 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT1 stop	1	1	logical	PASS	Houtstopppwm command.

HOUT2 start

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT2 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.

HOUT - period: 1000 us, tolerance: 1500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT2[5%] check	473	420	mV	PASS	Checked over TCP.
HOUT2[15%] check	1752	1260	mV	PASS	Checked over TCP.
HOUT2[25%] check	2758	2100	mV	PASS	Checked over TCP.
HOUT2[35%] check	1689	2940	mV	PASS	Checked over TCP.
HOUT2[45%] check	3461	3780	mV	PASS	Checked over TCP.
HOUT2[55%] check	5556	4620	mV	PASS	Checked over TCP.
HOUT2[65%] check	6621	5460	mV	PASS	Checked over TCP.
HOUT2[75%] check	6674	6300	mV	PASS	Checked over TCP.
HOUT2[85%] check	7495	7140	mV	PASS	Checked over TCP.
HOUT2[95%] check	8208	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT2[5%] check	488	420	mV	PASS	Checked over TCP.
HOUT2[15%] check	1352	1260	mV	PASS	Checked over TCP.
HOUT2[25%] check	2260	2100	mV	PASS	Checked over TCP.
HOUT2[35%] check	3007	2940	mV	PASS	Checked over TCP.
HOUT2[45%] check	4013	3780	mV	PASS	Checked over TCP.
HOUT2[55%] check	4501	4620	mV	PASS	Checked over TCP.
HOUT2[65%] check	5625	5460	mV	PASS	Checked over TCP.
HOUT2[75%] check	6259	6300	mV	PASS	Checked over TCP.
HOUT2[85%] check	7211	7140	mV	PASS	Checked over TCP.
HOUT2[95%] check	7978	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.
--

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT2[5%] check	649	420	mV	PASS	Checked over TCP.
HOUT2[15%] check	1533	1260	mV	PASS	Checked over TCP.
HOUT2[25%] check	2343	2100	mV	PASS	Checked over TCP.
HOUT2[35%] check	3149	2940	mV	PASS	Checked over TCP.
HOUT2[45%] check	3969	3780	mV	PASS	Checked over TCP.
HOUT2[55%] check	4912	4620	mV	PASS	Checked over TCP.
HOUT2[65%] check	5732	5460	mV	PASS	Checked over TCP.
HOUT2[75%] check	6547	6300	mV	PASS	Checked over TCP.
HOUT2[85%] check	7373	7140	mV	PASS	Checked over TCP.
HOUT2[95%] check	8251	7980	mV	PASS	Checked over TCP.

HOUT2 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT2 stop	1	1	logical	PASS	Houtstop pwm command.

HOUT3 start

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT3 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.

HOUT - period: 1000 us, tolerance: 1500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT3[5%] check	639	420	mV	PASS	Checked over TCP.
HOUT3[15%] check	1738	1260	mV	PASS	Checked over TCP.
HOUT3[25%] check	1044	2100	mV	PASS	Checked over TCP.
HOUT3[35%] check	3647	2940	mV	PASS	Checked over TCP.
HOUT3[45%] check	2954	3780	mV	PASS	Checked over TCP.
HOUT3[55%] check	5097	4620	mV	PASS	Checked over TCP.
HOUT3[65%] check	4409	5460	mV	PASS	Checked over TCP.
HOUT3[75%] check	5698	6300	mV	PASS	Checked over TCP.
HOUT3[85%] check	6752	7140	mV	PASS	Checked over TCP.
HOUT3[95%] check	7792	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT3[5%] check	473	420	mV	PASS	Checked over TCP.
HOUT3[15%] check	1381	1260	mV	PASS	Checked over TCP.
HOUT3[25%] check	2045	2100	mV	PASS	Checked over TCP.
HOUT3[35%] check	2807	2940	mV	PASS	Checked over TCP.
HOUT3[45%] check	3911	3780	mV	PASS	Checked over TCP.
HOUT3[55%] check	4638	4620	mV	PASS	Checked over TCP.
HOUT3[65%] check	5400	5460	mV	PASS	Checked over TCP.
HOUT3[75%] check	6323	6300	mV	PASS	Checked over TCP.
HOUT3[85%] check	7089	7140	mV	PASS	Checked over TCP.
HOUT3[95%] check	7993	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT3[5%] check	659	420	mV	PASS	Checked over TCP.
HOUT3[15%] check	1538	1260	mV	PASS	Checked over TCP.
HOUT3[25%] check	2348	2100	mV	PASS	Checked over TCP.
HOUT3[35%] check	3178	2940	mV	PASS	Checked over TCP.
HOUT3[45%] check	3974	3780	mV	PASS	Checked over TCP.
HOUT3[55%] check	4921	4620	mV	PASS	Checked over TCP.
HOUT3[65%] check	5678	5460	mV	PASS	Checked over TCP.
HOUT3[75%] check	6494	6300	mV	PASS	Checked over TCP.
HOUT3[85%] check	7373	7140	mV	PASS	Checked over TCP.
HOUT3[95%] check	8256	7980	mV	PASS	Checked over TCP.

HOUT3 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT3 stop	1	1	logical	PASS	Houtstop pwm command.

HOUT4 start

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT4 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.

HOUT - period: 1000 us, tolerance: 1500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT4[5%] check	346	420	mV	PASS	Checked over TCP.
HOUT4[15%] check	1816	1260	mV	PASS	Checked over TCP.
HOUT4[25%] check	2622	2100	mV	PASS	Checked over TCP.
HOUT4[35%] check	3354	2940	mV	PASS	Checked over TCP.
HOUT4[45%] check	3500	3780	mV	PASS	Checked over TCP.
HOUT4[55%] check	4238	4620	mV	PASS	Checked over TCP.
HOUT4[65%] check	5122	5460	mV	PASS	Checked over TCP.
HOUT4[75%] check	5473	6300	mV	PASS	Checked over TCP.
HOUT4[85%] check	6606	7140	mV	PASS	Checked over TCP.
HOUT4[95%] check	8178	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT4[5%] check	493	420	mV	PASS	Checked over TCP.
HOUT4[15%] check	1215	1260	mV	PASS	Checked over TCP.
HOUT4[25%] check	2001	2100	mV	PASS	Checked over TCP.
HOUT4[35%] check	3017	2940	mV	PASS	Checked over TCP.
HOUT4[45%] check	3950	3780	mV	PASS	Checked over TCP.
HOUT4[55%] check	4658	4620	mV	PASS	Checked over TCP.
HOUT4[65%] check	5673	5460	mV	PASS	Checked over TCP.
HOUT4[75%] check	6196	6300	mV	PASS	Checked over TCP.
HOUT4[85%] check	7158	7140	mV	PASS	Checked over TCP.
HOUT4[95%] check	8002	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT4[5%] check	639	420	mV	PASS	Checked over TCP.
HOUT4[15%] check	1533	1260	mV	PASS	Checked over TCP.
HOUT4[25%] check	2285	2100	mV	PASS	Checked over TCP.
HOUT4[35%] check	3154	2940	mV	PASS	Checked over TCP.
HOUT4[45%] check	3964	3780	mV	PASS	Checked over TCP.
HOUT4[55%] check	4916	4620	mV	PASS	Checked over TCP.
HOUT4[65%] check	5722	5460	mV	PASS	Checked over TCP.
HOUT4[75%] check	6538	6300	mV	PASS	Checked over TCP.
HOUT4[85%] check	7358	7140	mV	PASS	Checked over TCP.
HOUT4[95%] check	8203	7980	mV	PASS	Checked over TCP.

HOUT4 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT4 stop	1	1	logical	PASS	Houtstoppwm command.

HOUT5 start

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT5 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.

HOUT - period: 1000 us, tolerance: 1500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT5[5%] check	585	420	mV	PASS	Checked over TCP.
HOUT5[15%] check	1738	1260	mV	PASS	Checked over TCP.
HOUT5[25%] check	1069	2100	mV	PASS	Checked over TCP.
HOUT5[35%] check	3940	2940	mV	PASS	Checked over TCP.
HOUT5[45%] check	4980	3780	mV	PASS	Checked over TCP.
HOUT5[55%] check	3588	4620	mV	PASS	Checked over TCP.
HOUT5[65%] check	5815	5460	mV	PASS	Checked over TCP.
HOUT5[75%] check	7016	6300	mV	PASS	Checked over TCP.
HOUT5[85%] check	6640	7140	mV	PASS	Checked over TCP.
HOUT5[95%] check	7915	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT5[5%] check	434	420	mV	PASS	Checked over TCP.
HOUT5[15%] check	1386	1260	mV	PASS	Checked over TCP.
HOUT5[25%] check	2260	2100	mV	PASS	Checked over TCP.
HOUT5[35%] check	2919	2940	mV	PASS	Checked over TCP.
HOUT5[45%] check	3823	3780	mV	PASS	Checked over TCP.
HOUT5[55%] check	4765	4620	mV	PASS	Checked over TCP.
HOUT5[65%] check	5634	5460	mV	PASS	Checked over TCP.
HOUT5[75%] check	6372	6300	mV	PASS	Checked over TCP.
HOUT5[85%] check	7250	7140	mV	PASS	Checked over TCP.
HOUT5[95%] check	8027	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.
--

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT5[5%] check	664	420	mV	PASS	Checked over TCP.
HOUT5[15%] check	1552	1260	mV	PASS	Checked over TCP.
HOUT5[25%] check	2358	2100	mV	PASS	Checked over TCP.
HOUT5[35%] check	3173	2940	mV	PASS	Checked over TCP.
HOUT5[45%] check	3989	3780	mV	PASS	Checked over TCP.
HOUT5[55%] check	4946	4620	mV	PASS	Checked over TCP.
HOUT5[65%] check	5747	5460	mV	PASS	Checked over TCP.
HOUT5[75%] check	6567	6300	mV	PASS	Checked over TCP.
HOUT5[85%] check	7387	7140	mV	PASS	Checked over TCP.
HOUT5[95%] check	8281	7980	mV	PASS	Checked over TCP.

HOUT5 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT5 stop	1	1	logical	PASS	Houtstoppwm command.

HOUT6 start

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT6 start	[1, 1]	[1, 1]	logical	PASS	Houtpwm and houtstartpwm command.

HOUT - period: 1000 us, tolerance: 1500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT6[5%] check	268	420	mV	PASS	Checked over TCP.
HOUT6[15%] check	600	1260	mV	PASS	Checked over TCP.
HOUT6[25%] check	2817	2100	mV	PASS	Checked over TCP.
HOUT6[35%] check	3081	2940	mV	PASS	Checked over TCP.
HOUT6[45%] check	2509	3780	mV	PASS	Checked over TCP.
HOUT6[55%] check	3554	4620	mV	PASS	Checked over TCP.
HOUT6[65%] check	6689	5460	mV	PASS	Checked over TCP.
HOUT6[75%] check	6708	6300	mV	PASS	Checked over TCP.
HOUT6[85%] check	6591	7140	mV	PASS	Checked over TCP.
HOUT6[95%] check	8110	7980	mV	PASS	Checked over TCP.

HOUT - period: 400 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT6[5%] check	454	420	mV	PASS	Checked over TCP.
HOUT6[15%] check	1298	1260	mV	PASS	Checked over TCP.
HOUT6[25%] check	1958	2100	mV	PASS	Checked over TCP.
HOUT6[35%] check	3012	2940	mV	PASS	Checked over TCP.
HOUT6[45%] check	3911	3780	mV	PASS	Checked over TCP.
HOUT6[55%] check	4824	4620	mV	PASS	Checked over TCP.
HOUT6[65%] check	5600	5460	mV	PASS	Checked over TCP.
HOUT6[75%] check	6406	6300	mV	PASS	Checked over TCP.
HOUT6[85%] check	7158	7140	mV	PASS	Checked over TCP.
HOUT6[95%] check	7983	7980	mV	PASS	Checked over TCP.

HOUT - period: 50 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT6[5%] check	668	420	mV	PASS	Checked over TCP.
HOUT6[15%] check	1547	1260	mV	PASS	Checked over TCP.
HOUT6[25%] check	2348	2100	mV	PASS	Checked over TCP.
HOUT6[35%] check	3173	2940	mV	PASS	Checked over TCP.
HOUT6[45%] check	3979	3780	mV	PASS	Checked over TCP.
HOUT6[55%] check	4931	4620	mV	PASS	Checked over TCP.
HOUT6[65%] check	5751	5460	mV	PASS	Checked over TCP.
HOUT6[75%] check	6562	6300	mV	PASS	Checked over TCP.
HOUT6[85%] check	7387	7140	mV	PASS	Checked over TCP.
HOUT6[95%] check	8291	7980	mV	PASS	Checked over TCP.

HOUT6 stop.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HOUT6 stop	1	1	logical	PASS	Houtstopppwm command.

4.5 Group - HBR

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:29 / 00:00:00:02
Group -Description	
TestGroup	
TestGroup	

4.5.1 Test - initHBR

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO

Test -Start-/Execution-Time	2013-08-19 16:45:29 / 00:00:00:00
Test -Description	
Administrative testcase initHBR calls init function and sets the range of tested pins.	

4.5.1 initHBR -- Metadata

(default)	
duration	--:--:--

4.5.1 initHBR -- Run

Test flow -- RPPTest.pins.HBR.testCases.initHBR
Administrative testcase initHBR calls init function and sets the range of tested pins.
Test flow -- RPPTest.pins.HBR.testSequences.disablePin
This sequence disables HBR bridge.

4.5.2 Test - HBR

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:29 / 00:00:00:02
Test -Description	
HBR testcase: RPP board generates various periods and duty cycles and hummusoft card (analog in) measured the size of voltage.	

4.5.2 HBR -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e4405cd03801405db5418f010e
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.5.2 HBR -- Run

Test flow -- RPPTTest.pins.HBR.testCases.HBR
HBR testcase: RPP board generates various periods and duty cycles and hummusoft card (analog in) measured the size of voltage.
Test flow -- RPPTTest.pins.HBR.testSequences.enablePin
This sequence enables HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.

[illegible]

Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.disablePin
This sequence disables HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.enablePin
This sequence enables HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.

[illegible]

Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.disablePin
This sequence disables HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.enablePin
This sequence enables HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.

54 / 108



Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.setDutyCycle
This sequence sets duty cycle of HBR bridge.
Test flow -- RPPTest.pins.HBR.testSequences.checkVoltage
Test flow -- RPPTest.pins.HBR.testSequences.disablePin
This sequence disables HBR bridge.

4.5.2 HBR -- Subtest

HBR - period: 1000 us, tolerance: 1500 mV.
--

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HBR [10%]	[410, 24]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [20%]	[1811, 19]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [30%]	[3486, 19]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [40%]	[4511, 24]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [50%]	[4062, 19]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [60%]	[4130, 19]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [70%]	[5473, 19]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [80%]	[7026, 19]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [90%]	[7358, 19]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [100%]	[8344, 19]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-100%]	[8359, 24]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-90%]	[7353, 24]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-80%]	[6567, 19]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-70%]	[6250, 24]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-60%]	[5947, 19]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-50%]	[3540, 19]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-40%]	[4555, 24]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-30%]	[3388, 19]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-20%]	[2119, 19]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-10%]	[468, 24]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [0%]	[19, 24]	[0, 0]	mV	PASS	Active half of bridge is always wrote down first.

HBR - period: 200 us, tolerance: 500 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HBR [10%]	[864, 24]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [20%]	[1689, 19]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [30%]	[2563, 24]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [40%]	[3374, 19]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [50%]	[4169, 19]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [60%]	[5009, 19]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [70%]	[5854, 19]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [80%]	[6743, 19]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [90%]	[7548, 19]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [100%]	[8344, 24]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-100%]	[8364, 24]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-90%]	[7539, 19]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-80%]	[6708, 19]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-70%]	[5888, 19]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-60%]	[5092, 19]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-50%]	[4189, 24]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-40%]	[3334, 24]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-30%]	[2534, 19]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-20%]	[1674, 24]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-10%]	[878, 19]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [0%]	[19, 24]	[0, 0]	mV	PASS	Active half of bridge is always wrote down first.

HBR - period: 50 us, tolerance: 250 mV.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
HBR [10%]	[898, 24]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [20%]	[1704, 24]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [30%]	[2524, 24]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [40%]	[3325, 19]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [50%]	[4267, 24]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [60%]	[5068, 63]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [70%]	[5883, 19]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [80%]	[6699, 19]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [90%]	[7509, 14]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [100%]	[8344, 24]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-100%]	[8364, 24]	[8400, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-90%]	[7539, 24]	[7560, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-80%]	[6733, 24]	[6720, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-70%]	[5883, 19]	[5880, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-60%]	[5122, 24]	[5040, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-50%]	[4291, 24]	[4200, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-40%]	[3359, 19]	[3360, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-30%]	[2548, 19]	[2520, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-20%]	[1738, 24]	[1680, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [-10%]	[922, 19]	[840, 0]	mV	PASS	Active half of bridge is always wrote down first.
HBR [0%]	[19, 24]	[0, 0]	mV	PASS	Active half of bridge is always wrote down first.

4.6 Group - ADIN

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:31 / 00:00:00:06
Group -Description	
TestGroup	
TestGroup	

4.6.1 Test - initADIN

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:31 / 00:00:00:00
Test -Description	
Administrative testcase initADIN calls init function and sets the range of tested pins.	

4.6.1 initADIN -- Metadata

(default)	
duration	--:--:--

4.6.1 initADIN -- Run

Test flow -- RPPTTest.pins.ADIN.testCases.initADIN
Administrative testcase initADIN calls init function and sets the range of tested pins.

4.6.2 Test - ADIN

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:31 / 00:00:00:06
Test -Description	
ADIN testcase: TCP server sets varius output voltages on hummusoft card (analog out). The voltage is brought to selected ADIN pin. To the surrounding pins are brought different voltages to see if it caused any interference to measured pin. All even-numbered pins are connected, likewise are connected all odd-numbered pins. The maximum measured voltage is 10 V.	

4.6.2 ADIN -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e4404d63f401404ed6b67207df
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.6.2 ADIN -- Run

Test flow -- RPPTTest.pins.ADIN.testCases.ADIN
ADIN testcase: TCP server sets various output voltages on hummusoft card (analog out). The voltage is brought to selected ADIN pin. To the surrounding pins are brought different voltages to see if it caused any interference to measured pin. All even-numbered pins are connected, likewise are connected all odd-numbered pins. The maximum measured voltage is 10 V.
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).


This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).

65 / 108

This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).

68 / 108

This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).

This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).

This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).

Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.setVoltage
This sequence sets voltage generated by hummusoft card (analog out).
Test flow -- RPPTTest.pins.ADIN.testSequences.checkVoltage
This sequence reads (ADINx) voltage generated by hummusoft card (analog out).

4.6.2 ADIN -- Subtest

ADIN1 [tolerance: 0.3 V]					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN1	0.5425	0	V	PASS	Check voltage over RS232
ADIN1	1.0325	1	V	PASS	Check voltage over RS232
ADIN1	1.9575	2	V	PASS	Check voltage over RS232
ADIN1	2.9275	3	V	PASS	Check voltage over RS232
ADIN1	3.9075	4	V	PASS	Check voltage over RS232
ADIN1	4.8975	5	V	PASS	Check voltage over RS232
ADIN1	5.8725	6	V	PASS	Check voltage over RS232
ADIN1	6.8475	7	V	PASS	Check voltage over RS232
ADIN1	7.8325	8	V	PASS	Check voltage over RS232
ADIN1	8.8175	9	V	PASS	Check voltage over RS232
ADIN1	9.7825	10	V	PASS	Check voltage over RS232
ADIN2 [tolerance: 0.3 V]					

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN2	0.5575	0	V	PASS	Check voltage over RS232
ADIN2	1.0325	1	V	PASS	Check voltage over RS232
ADIN2	1.9575	2	V	PASS	Check voltage over RS232
ADIN2	2.9375	3	V	PASS	Check voltage over RS232
ADIN2	3.9175	4	V	PASS	Check voltage over RS232
ADIN2	4.9025	5	V	PASS	Check voltage over RS232
ADIN2	5.8825	6	V	PASS	Check voltage over RS232
ADIN2	6.8575	7	V	PASS	Check voltage over RS232
ADIN2	7.8375	8	V	PASS	Check voltage over RS232
ADIN2	8.8275	9	V	PASS	Check voltage over RS232
ADIN2	9.8025	10	V	PASS	Check voltage over RS232

ADIN3 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN3	0.5675	0	V	PASS	Check voltage over RS232
ADIN3	1.0375	1	V	PASS	Check voltage over RS232
ADIN3	1.9475	2	V	PASS	Check voltage over RS232
ADIN3	2.9225	3	V	PASS	Check voltage over RS232
ADIN3	3.8875	4	V	PASS	Check voltage over RS232
ADIN3	4.8725	5	V	PASS	Check voltage over RS232
ADIN3	5.8325	6	V	PASS	Check voltage over RS232
ADIN3	6.8125	7	V	PASS	Check voltage over RS232
ADIN3	7.7875	8	V	PASS	Check voltage over RS232
ADIN3	8.7625	9	V	PASS	Check voltage over RS232
ADIN3	9.7375	10	V	PASS	Check voltage over RS232

ADIN4 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN4	0.5475	0	V	PASS	Check voltage over RS232
ADIN4	1.0325	1	V	PASS	Check voltage over RS232
ADIN4	1.9575	2	V	PASS	Check voltage over RS232
ADIN4	2.9375	3	V	PASS	Check voltage over RS232
ADIN4	3.9225	4	V	PASS	Check voltage over RS232
ADIN4	4.8925	5	V	PASS	Check voltage over RS232
ADIN4	5.8725	6	V	PASS	Check voltage over RS232
ADIN4	6.8525	7	V	PASS	Check voltage over RS232
ADIN4	7.8275	8	V	PASS	Check voltage over RS232
ADIN4	8.8175	9	V	PASS	Check voltage over RS232
ADIN4	9.7925	10	V	PASS	Check voltage over RS232

ADIN5 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN5	0.5525	0	V	PASS	Check voltage over RS232
ADIN5	1.0275	1	V	PASS	Check voltage over RS232
ADIN5	1.9525	2	V	PASS	Check voltage over RS232
ADIN5	2.9325	3	V	PASS	Check voltage over RS232
ADIN5	3.9075	4	V	PASS	Check voltage over RS232
ADIN5	4.8925	5	V	PASS	Check voltage over RS232
ADIN5	5.8675	6	V	PASS	Check voltage over RS232
ADIN5	6.8475	7	V	PASS	Check voltage over RS232
ADIN5	7.8225	8	V	PASS	Check voltage over RS232
ADIN5	8.8025	9	V	PASS	Check voltage over RS232
ADIN5	9.7825	10	V	PASS	Check voltage over RS232

ADIN6 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN6	0.5775	0	V	PASS	Check voltage over RS232
ADIN6	1.0325	1	V	PASS	Check voltage over RS232
ADIN6	1.9475	2	V	PASS	Check voltage over RS232
ADIN6	2.9225	3	V	PASS	Check voltage over RS232
ADIN6	3.9025	4	V	PASS	Check voltage over RS232
ADIN6	4.8775	5	V	PASS	Check voltage over RS232
ADIN6	5.8475	6	V	PASS	Check voltage over RS232
ADIN6	6.8275	7	V	PASS	Check voltage over RS232
ADIN6	7.7975	8	V	PASS	Check voltage over RS232
ADIN6	8.7775	9	V	PASS	Check voltage over RS232
ADIN6	9.7425	10	V	PASS	Check voltage over RS232

ADIN7 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN7	0.5725	0	V	PASS	Check voltage over RS232
ADIN7	1.0375	1	V	PASS	Check voltage over RS232
ADIN7	1.9625	2	V	PASS	Check voltage over RS232
ADIN7	2.9375	3	V	PASS	Check voltage over RS232
ADIN7	3.9125	4	V	PASS	Check voltage over RS232
ADIN7	4.8925	5	V	PASS	Check voltage over RS232
ADIN7	5.8625	6	V	PASS	Check voltage over RS232
ADIN7	6.8425	7	V	PASS	Check voltage over RS232
ADIN7	7.8225	8	V	PASS	Check voltage over RS232
ADIN7	8.7975	9	V	PASS	Check voltage over RS232
ADIN7	9.7725	10	V	PASS	Check voltage over RS232

ADIN8 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN8	0.5675	0	V	PASS	Check voltage over RS232
ADIN8	1.0375	1	V	PASS	Check voltage over RS232
ADIN8	1.9525	2	V	PASS	Check voltage over RS232
ADIN8	2.9425	3	V	PASS	Check voltage over RS232
ADIN8	3.9225	4	V	PASS	Check voltage over RS232
ADIN8	4.9025	5	V	PASS	Check voltage over RS232
ADIN8	5.8775	6	V	PASS	Check voltage over RS232
ADIN8	6.8625	7	V	PASS	Check voltage over RS232
ADIN8	7.8425	8	V	PASS	Check voltage over RS232
ADIN8	8.8225	9	V	PASS	Check voltage over RS232
ADIN8	9.7975	10	V	PASS	Check voltage over RS232

ADIN9 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN9	0.5625	0	V	PASS	Check voltage over RS232
ADIN9	1.0375	1	V	PASS	Check voltage over RS232
ADIN9	1.9625	2	V	PASS	Check voltage over RS232
ADIN9	2.9525	3	V	PASS	Check voltage over RS232
ADIN9	3.9325	4	V	PASS	Check voltage over RS232
ADIN9	4.9125	5	V	PASS	Check voltage over RS232
ADIN9	5.8975	6	V	PASS	Check voltage over RS232
ADIN9	6.8775	7	V	PASS	Check voltage over RS232
ADIN9	7.8575	8	V	PASS	Check voltage over RS232
ADIN9	8.8525	9	V	PASS	Check voltage over RS232
ADIN9	9.8275	10	V	PASS	Check voltage over RS232

ADIN10 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN10	0.5425	0	V	PASS	Check voltage over RS232
ADIN10	1.0125	1	V	PASS	Check voltage over RS232
ADIN10	1.9425	2	V	PASS	Check voltage over RS232
ADIN10	2.9175	3	V	PASS	Check voltage over RS232
ADIN10	3.9025	4	V	PASS	Check voltage over RS232
ADIN10	4.8775	5	V	PASS	Check voltage over RS232
ADIN10	5.8575	6	V	PASS	Check voltage over RS232
ADIN10	6.8375	7	V	PASS	Check voltage over RS232
ADIN10	7.8125	8	V	PASS	Check voltage over RS232
ADIN10	8.8025	9	V	PASS	Check voltage over RS232
ADIN10	9.7725	10	V	PASS	Check voltage over RS232

ADIN11 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN11	0.5575	0	V	PASS	Check voltage over RS232
ADIN11	1.0375	1	V	PASS	Check voltage over RS232
ADIN11	1.9475	2	V	PASS	Check voltage over RS232
ADIN11	2.9225	3	V	PASS	Check voltage over RS232
ADIN11	3.9075	4	V	PASS	Check voltage over RS232
ADIN11	4.8825	5	V	PASS	Check voltage over RS232
ADIN11	5.8575	6	V	PASS	Check voltage over RS232
ADIN11	6.8325	7	V	PASS	Check voltage over RS232
ADIN11	7.8025	8	V	PASS	Check voltage over RS232
ADIN11	8.7875	9	V	PASS	Check voltage over RS232
ADIN11	9.7575	10	V	PASS	Check voltage over RS232

ADIN12 [tolerance: 0.3 V]

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
ADIN12	0.5575	0	V	PASS	Check voltage over RS232
ADIN12	1.0425	1	V	PASS	Check voltage over RS232
ADIN12	1.9625	2	V	PASS	Check voltage over RS232
ADIN12	2.9425	3	V	PASS	Check voltage over RS232
ADIN12	3.9225	4	V	PASS	Check voltage over RS232
ADIN12	4.9025	5	V	PASS	Check voltage over RS232
ADIN12	5.8775	6	V	PASS	Check voltage over RS232
ADIN12	6.8475	7	V	PASS	Check voltage over RS232
ADIN12	7.8325	8	V	PASS	Check voltage over RS232
ADIN12	8.8175	9	V	PASS	Check voltage over RS232
ADIN12	9.7875	10	V	PASS	Check voltage over RS232

4.7 Group - DIN0to7

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:38 / 00:00:00:09
Group -Description	
TestGroup	
TestGroup	

4.7.1 Test - initDIN0to7

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:38 / 00:00:00:00
Test -Description	
Administrative testcase initDIN0to7 calls init function and sets the range of tested pins.	

4.7.1 initDIN0to7 -- Metadata

(default)	
duration	--:--:--

4.7.1 initDIN0to7 -- Run

Test flow -- RPPTTest.pins.DIN._0to7.testCases.initDIN0to7
Administrative testcase initDIN0to7 calls init function and sets the range of tested pins.

4.7.2 Test - DIN0to7

Test -Full-Scoped-Name :	Full Scoped Name
--------------------------	------------------

Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:38 / 00:00:00:09
Test -Description	
<p>DIN0to7 testcase: This test case consists of two parts.</p> <p>The first part tests unconnected DIN0-7 periphery. It calls dinsetup to set DIN0-7 pins to be pull-down and active, then it sets pull-up and active. Every time this test case measured if the result of dinget command is correct.</p> <p>The second part tests connected DIN0-7 periphery. RPP board reads digital signals generated by hummusoft card (digital out).</p>	

4.7.2 DIN0to7 -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e4407bb65b01407c0ac81e0055
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.7.2 DIN0to7 -- Run

Test flow -- RPPTTest.pins.DIN._0to7.testCases.DIN0to7
<p>DIN0to7 testcase: This test case consists of two parts.</p> <p>The first part tests unconnected DIN0-7 periphery. It calls dinsetup to set DIN0-7 pins to be pull-down and active, then it sets pull-up and active. Every time this test case measured if the result of dinget command is correct.</p> <p>The second part tests connected DIN0-7 periphery. RPP board reads digital signals generated by hummusoft card (digital out).</p>
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin

85 / 108

Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin

This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT

This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin

This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setPin
This sequence sets DIN pin (pull-type, active or tri-state, wake or non-wake).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.setHumDOUT
This sequence calls function that sets the voltage generated by hummusoft card (digital out).
Test flow -- RPPTTest.pins.DIN._0to7.testSequences.readPin
This sequence reads DIN pin input.

4.7.2 DIN0to7 -- Subtest

Floating DIN0-7.					
Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DIN0 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN0 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN1 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN1 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN2 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN2 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN3 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN3 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN4 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN4 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN5 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN5 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN6 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN6 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN7 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN7 check	0	0	logical	PASS	[pullType : 0, active: 1]
DIN0-7 connected.					

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DIN0 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN0 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN1 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN1 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN2 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN2 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN3 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN3 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN4 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN4 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN5 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN5 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN6 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN6 check	1	1	logical	PASS	[pullType : 0, active: 0]
DIN7 check	0	0	logical	PASS	[pullType : 0, active: 0]
DIN7 check	1	1	logical	PASS	[pullType : 0, active: 0]

4.8 Group - DIN8to15

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:47 / 00:00:00:09
Group -Description	
TestGroup	
TestGroup	

4.8.1 Test - initDIN8to15

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:47 / 00:00:00:00
Test -Description	
Administrative testcase initDIN8to15 calls init function and sets the range of tested pins.	

4.8.1 initDIN8to15 -- Metadata

(default)	
duration	--:--:--

4.8.1 initDIN8to15 -- Run

Test flow -- RPPTest.pins.DIN_8to15.testCases.initDIN8to15
Administrative testcase initDIN8to15 calls init function and sets the range of tested pins.

4.8.2 Test - DIN8to15

Test -Full-Scoped-Name : Full Scoped Name	
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:47 / 00:00:00:09
Test -Description	
DIN8to15 testcase: This test case consists of two parts. The first part tests unconnected DIN8-15 periphery. It calls dinsetup to set DIN0-7 pins to be pull-up and active, then it sets pull-up and tri-state. Every time this test case measured if the result of dinget command is correct. The second part tests connected DIN8-15 periphery. RPP board reads different analog signals generated by hummusoft card (analog out) and it determinates the threshold for every pin.	

4.8.2 DIN8to15 -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e44081d83b014081eabfff00de
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.8.2 DIN8to15 -- Run

Test flow -- RPPTTest.pins.DIN._8to15.testCases.DIN8to15
<p>DIN8to15 testcase: This test case consists of two parts.</p> <p>The first part tests unconnected DIN8-15 periphery. It calls dinsetup to set DIN0-7 pins to be pull-up and active, then it sets pull-up and tri-state. Every time this test case measured if the result of dinget command is correct.</p> <p>The second part tests connected DIN8-15 periphery. RPP board reads different analog signals generated by hummusoft card (analog out) and it determinates the threshold for every pin.</p>
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.readPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD
Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.setHumAD

Test flow -- RPPTTest.pins.DIN._8to15.testSequences.checkPin

4.8.2 DIN8to15 -- Subtest

Floating DIN8-15.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DIN8 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN8 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN9 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN9 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN10 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN10 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN11 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN11 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN12 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN12 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN13 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN13 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN14 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN14 check	1	1	logical	PASS	[pullType : 1, active: 0]
DIN15 check	0	0	logical	PASS	[pullType : 1, active: 1]
DIN15 check	1	1	logical	PASS	[pullType : 1, active: 0]

DIN8-15 connected.

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DIN8 check	1	1	logical	PASS	Voltage: 0 V.
DIN8 check	1	1	logical	PASS	Voltage: 3 V.
DIN8 check	0	0	logical	PASS	Voltage: 5 V.
DIN8 check	0	0	logical	PASS	Voltage: 8 V.
DIN8 check	0	0	logical	PASS	Voltage: 10 V.
DIN9 check	1	1	logical	PASS	Voltage: 0 V.
DIN9 check	1	1	logical	PASS	Voltage: 3 V.
DIN9 check	0	0	logical	PASS	Voltage: 5 V.
DIN9 check	0	0	logical	PASS	Voltage: 8 V.
DIN9 check	0	0	logical	PASS	Voltage: 10 V.
DIN10 check	1	1	logical	PASS	Voltage: 0 V.
DIN10 check	1	1	logical	PASS	Voltage: 3 V.
DIN10 check	0	0	logical	PASS	Voltage: 5 V.
DIN10 check	0	0	logical	PASS	Voltage: 8 V.
DIN10 check	0	0	logical	PASS	Voltage: 10 V.
DIN11 check	1	1	logical	PASS	Voltage: 0 V.
DIN11 check	1	1	logical	PASS	Voltage: 3 V.
DIN11 check	0	0	logical	PASS	Voltage: 5 V.
DIN11 check	0	0	logical	PASS	Voltage: 8 V.
DIN11 check	0	0	logical	PASS	Voltage: 10 V.
DIN12 check	1	1	logical	PASS	Voltage: 0 V.
DIN12 check	1	1	logical	PASS	Voltage: 3 V.
DIN12 check	0	0	logical	PASS	Voltage: 5 V.
DIN12 check	0	0	logical	PASS	Voltage: 8 V.
DIN12 check	0	0	logical	PASS	Voltage: 10 V.
DIN13 check	1	1	logical	PASS	Voltage: 0 V.
DIN13 check	1	1	logical	PASS	Voltage: 3 V.
DIN13 check	0	0	logical	PASS	Voltage: 5 V.
DIN13 check	0	0	logical	PASS	Voltage: 8 V.
DIN13 check	0	0	logical	PASS	Voltage: 10 V.
DIN14 check	1	1	logical	PASS	Voltage: 0 V.
DIN14 check	1	1	logical	PASS	Voltage: 3 V.
DIN14 check	0	0	logical	PASS	Voltage: 5 V.
DIN14 check	0	0	logical	PASS	Voltage: 8 V.
DIN14 check	0	0	logical	PASS	Voltage: 10 V.
DIN15 check	1	1	logical	PASS	Voltage: 0 V.
DIN15 check	1	1	logical	PASS	Voltage: 3 V.
DIN15 check	0	0	logical	PASS	Voltage: 5 V.
DIN15 check	0	0	logical	PASS	Voltage: 8 V.

DIN15 check	0	0	logical	PASS	Voltage: 10 V.
-------------	---	---	---------	------	----------------

4.9 Group - DAC

Group -Valuation	PASS
Group -Start-/Execution-Time	2013-08-19 16:45:57 / 00:00:00:01
Group -Description	
TestGroup	
TestGroup	

4.9.1 Test - initDAC

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:57 / 00:00:00:00
Test -Description	
Administrative testcase initDAC calls init function and sets the range of tested pins.	

4.9.1 initDAC -- Metadata

(default)	
duration	--:--:--

4.9.1 initDAC -- Run

Test flow -- RPPTTest.pins.DAC.testCases.initDAC
Administrative testcase initDAC calls init function and sets the range of tested pins.

4.9.2 Test - DAC

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	PASS
Test -Start-/Execution-Time	2013-08-19 16:45:57 / 00:00:00:01
Test -Description	
DAC testcase: The DAC periphery generates voltage measured by hummusoft card (analog in). Every pins is measured separately. The maximum measured voltage is 10 V.	

4.9.2 DAC -- Metadata

(default)	
version	
shadowTestCaseState	not yet specified
testCaseStateComment	
testCaseState	not yet specified
testCaseId	13a0d6e44057ae5b01405913f4fc047a
implementationPriority	low
functionalRequirement	
duration	--:--:--
riskEvaluation	latent

4.9.2 DAC -- Run

Test flow -- RPPTTest.pins.DAC.testCases.DAC
DAC testcase: The DAC peripheral generates voltage measured by hummusoft card (analog in). Every pins is measured separately. The maximum measured voltage is 10 V.
Test flow -- RPPTTest.pins.DAC.testSequences.enablePin
This sequence enables measured pin of DAC peripheral.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage

This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.disablePin
This sequence disables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.enablePin
This sequence enables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage

This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.disablePin
This sequence disables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.enablePin
This sequence enables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage

This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.disablePin
This sequence disables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.enablePin
This sequence enables measured pin of DAC periphery.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTTest.pins.DAC.testSequences.setVoltage

This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.setVoltage
This sequence sets voltage to DAC pin and determinates if the voltage is set.
Test flow -- RPPTest.pins.DAC.testSequences.checkVoltage
This sequence reads voltage by hummusoft card (analog in) and determinates the size of voltage.
Test flow -- RPPTest.pins.DAC.testSequences.disablePin
This sequence disables measured pin of DAC periphery.

4.9.2 DAC -- Subtest

DAC1

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DAC1 enable	1	1	logical	PASS	dacpinenable command.
DAC1set	0	0	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	19	0	mV	PASS	Check voltage over TCP.
DAC1set	2000	2000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	2031	2000	mV	PASS	Check voltage over TCP.
DAC1set	4000	4000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	4047	4000	mV	PASS	Check voltage over TCP.
DAC1set	6000	6000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	6093	6000	mV	PASS	Check voltage over TCP.
DAC1set	8000	8000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	8120	8000	mV	PASS	Check voltage over TCP.
DAC1set	10000	10000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	9995	10000	mV	PASS	Check voltage over TCP.
DAC1set	12000	12000	mV	PASS	Set voltage to DAC over RS232.
DAC1 check[TCP]	9995	12000	mV	PASS	Check voltage over TCP.
DAC1 disable	0	0	logical	PASS	dacpinenable command.

DAC2

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DAC2 enable	1	1	logical	PASS	dacpinenable command.
DAC2set	0	0	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	19	0	mV	PASS	Check voltage over TCP.
DAC2set	2000	2000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	2011	2000	mV	PASS	Check voltage over TCP.
DAC2set	4000	4000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	4038	4000	mV	PASS	Check voltage over TCP.
DAC2set	6000	6000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	6059	6000	mV	PASS	Check voltage over TCP.
DAC2set	8000	8000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	8105	8000	mV	PASS	Check voltage over TCP.
DAC2set	10000	10000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	9995	10000	mV	PASS	Check voltage over TCP.
DAC2set	12000	12000	mV	PASS	Set voltage to DAC over RS232.
DAC2 check[TCP]	9995	12000	mV	PASS	Check voltage over TCP.
DAC2 disable	0	0	logical	PASS	dacpinenable command.

DAC3

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DAC3 enable	1	1	logical	PASS	dacpinenable command.
DAC3set	0	0	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	14	0	mV	PASS	Check voltage over TCP.
DAC3set	2000	2000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	1992	2000	mV	PASS	Check voltage over TCP.
DAC3set	4000	4000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	4013	4000	mV	PASS	Check voltage over TCP.
DAC3set	6000	6000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	6044	6000	mV	PASS	Check voltage over TCP.
DAC3set	8000	8000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	8076	8000	mV	PASS	Check voltage over TCP.
DAC3set	10000	10000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	9995	10000	mV	PASS	Check voltage over TCP.
DAC3set	12000	12000	mV	PASS	Set voltage to DAC over RS232.
DAC3 check[TCP]	9995	12000	mV	PASS	Check voltage over TCP.
DAC3 disable	0	0	logical	PASS	dacpinenable command.

DAC4

Label	Actual-Value	Rated-Value	Dimension	Valuation	Comment
DAC4 enable	1	1	logical	PASS	dacpinenable command.
DAC4set	0	0	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	19	0	mV	PASS	Check voltage over TCP.
DAC4set	2000	2000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	1987	2000	mV	PASS	Check voltage over TCP.
DAC4set	4000	4000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	3999	4000	mV	PASS	Check voltage over TCP.
DAC4set	6000	6000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	6049	6000	mV	PASS	Check voltage over TCP.
DAC4set	8000	8000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	8095	8000	mV	PASS	Check voltage over TCP.
DAC4set	10000	10000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	9995	10000	mV	PASS	Check voltage over TCP.
DAC4set	12000	12000	mV	PASS	Set voltage to DAC over RS232.
DAC4 check[TCP]	9995	12000	mV	PASS	Check voltage over TCP.
DAC4 disable	0	0	logical	PASS	dacpinenable command.

4.10 Group - delinitialization

Group -Valuation	INFO
Group -Start-/Execution-Time	2013-08-19 16:45:59 / 00:00:00:00

Group -Description
Cleans up the test suite.
De-Initialisiert die TestSuite.

4.10.1 Test - delInitialization

Test -Full-Scoped-Name :	Full Scoped Name
Test -Valuation	INFO
Test -Start-/Execution-Time	2013-08-19 16:45:59 / 00:00:00:00
Test -Description	
This class ends TCP server and close RS232 communication channel.	

4.10.1 delInitialization -- Metadata

(default)	
duration	--:--:--

4.10.1 delInitialization -- Run

Test flow -- RPPTTest.basics.delInitialization
This class ends TCP server and close RS232 communication channel.