

1.) Prepare the x86\_64 Debian Host

`mkdir /home/youruser/assets` this will be the target for the final image

Install all required packages for QEMU

`sudo apt install qemu-efi-aarch64 qemu-system-arm virt-manager`

Download the arm64 mini.iso from Debian

<https://d-i.debian.org/daily-images/arm64/daily/netboot/>

2.) Setup Virtual Machine in QEMU

open Virtual Machine Manager

select "Local install media (ISO image or CDROM)"

in "Architecture options" select Architecture: **aarch64** and Machine Type: **virt**

next select the just downloaded **mini.iso**

next choose the operating system **Debian 10**

next set Memory to **1024** and CPUs to **4**

next create a disk image and set size to **4 GiB**

finally click "Finish" and click "Yes" to make Virtual Network active

3.) Install Debian for arm64 in your Virtual Machine

click into the black area of the VMs Window to capture Mouse and Keyboard

hit Enter to start text based Debian Installer

create **root** password and **youruser** with password as they will be on the final image

partition manually the disk image as follows

Partition 1: Size **100 M**, Name **efi**, Use as **EFI System Partition**, Bootable flag **on**

Partition 2: Size **100 M**, Name **boot**, Use as **Ext 2 file system**, Mount point **/boot**

Bootable flag **off**

Partition 3: Size **max**, Use as **Ext 4 journaling file system**, Mount point **/**

Bootable flag **off**

confirm that you don't want to create Swap Space by clicking **<NO>**

in "Software selection" select only **SSH server** and **standard system utilities**

and finish the installation, once finished reboot into the newly installed system

4.) DTB file handling

`mkdir /boot/dtbs`

`nano /etc/kernel/postinst.d/copy-dtbs`

`#!/bin/sh`

`set -e  
version="$1"`

`echo Copying current dtb files to /boot/dtbs....  
cp -a /usr/lib/linux-image-`${version}`. /boot/dtbs/`

`chmod +x /etc/kernel/postinst.d/copy-dtbs`

`/etc/kernel/postinst.d/copy-dtbs `uname -r``

5.) Bootloader configuration

```
mkdir /boot/extlinux
```

```
nano /boot/extlinux/extlinux.conf
```

```
TIMEOUT 2
```

```
DEFAULT debian
```

```
LABEL debian
```

```
    MENU LABEL Debian
```

```
    KERNEL /vmlinuz
```

```
    INITRD /initrd.img
```

```
    FDT /dtbs/allwinner/sun50i-h6-pine-h64-model-b.dtb
```

```
    APPEND console=tty1 root=LABEL=root rw rootwait
```

```
apt purge grub-efi-arm64
```

```
apt autoremove
```

```
apt autoclean
```

```
shutdown -h now
```

6.) Creating tar archives of our VM

```
sudo modprobe nbd max_part=8
```

```
sudo qemu-nbd --connect=/dev/nbd0 /var/lib/libvirt/images/debian10-aarch64.qcow2
```

```
sudo mount /dev/nbd0p2 /mnt
```

```
cd /mnt
```

```
sudo tar cvfzp /home/youruser/assets/debian-aarch64-bootfs.tar.gz .
```

```
cd ..
```

```
sudo umount /mnt
```

```
sudo mount /dev/nbd0p3 /mnt
```

```
cd /mnt
```

```
sudo tar cvfzp /home/youruser/assets/debian-aarch64-rootfs.tar.gz .
```

```
cd ..
```

```
sudo umount /mnt
```

```
sudo qemu-nbd -d /dev/nbd0
```

7.) Install Cross Compiler for building U-Boot on our x86\_64 Debian Host

```
sudo apt install gcc make device-tree-compiler build-essential libssl-dev python3-dev bison
```

```
sudo apt install flex libssl-dev swig gcc-aarch64-linux-gnu gcc-arm-none-eabi bc git
```

8.) Build U-Boot on our x86\_64 Debian Host

```
cd /home/youruser/assets
```

```
git clone https://github.com/ARM-software/arm-trusted-firmware
```

```
cd arm-trusted-firmware
```

```
git tag
```

remember last stable (v2.4)

```
git checkout v2.4
```

```
make CROSS_COMPILE=aarch64-linux-gnu- PLAT=sun50i_h6 bl31
```

```
cd ..
```

```
git clone git://git.denx.de/u-boot.git
cd u-boot
git tag
git checkout v2021.01
ln -s /home/youruser/assets/arm-trusted-firmware/build/sun50i_h6/release/bl31.bin bl31.bin
make CROSS_COMPILE=aarch64-linux-gnu- BL31=bl31.bin pine_h64_defconfig
make -j4 CROSS_COMPILE=aarch64-linux-gnu- BL31=bl31.bin

cp -r /home/youruser/assets/u-boot/u-boot-sunxi-with-spl.bin /home/youruser/assets/
cd ..
```

## 9.) Flashing Debian to our Pine64 H64B SBC

```
sudo fdisk /dev/sdX
```

type **o** this will clear out any partitions on the drive  
type **p** to list partitions, there should be no partitions left  
type **n**, then **p** for primary, **1** for the first partition on the drive, **2048** for the first sector, and **647167** for the last sector, then type **a**, then type **n**, then **p** for primary, **2** for the second partition on the drive, **647168** for the first sector, and **28211199** for the last sector, then type **n**, then **p** for primary, **3** for the third partition on the drive, **28211200** for the first sector, and **30308351** for the last sector, then type **t**, and **3** for the third partition, and **82** for the Hex Code, then write the partition table and exit by typing **w**

```
cd /home/youruser/assets
mkdir boot
mkdir root
```

this is in your home directory ! → /home/youruser/assets/boot  
this is in your home directory ! → /home/youruser/assets/root

```
sudo mkfs.ext2 -m0 -L boot /dev/sdX1
sudo mount /dev/sdX1 /home/youruser/assets/boot
cd /home/youruser/assets/boot
sudo tar xzvpf /home/youruser/assets/debian-aarch64-bootfs.tar.gz .
sync
cd ..

sudo cp /home/youruser/assets/sun50i-h6-pine-h64-model-b.dtb /home/youruser/assets/boot/dtbs/allwinner/sun50i-h6-pine-h64-model-b.dtb
sudo umount /home/youruser/assets/boot
```

```
sudo mkfs.ext4 -L root /dev/sdX2
sudo mount /dev/sdX2 /home/youruser/assets/root
cd /home/youruser/assets/root
sudo tar xzvpf /home/youruser/assets/debian-aarch64-rootfs.tar.gz .
sync
cd ..
```

```
sudo nano /home/youruser/assets/root/etc/fstab
```

amend as below

```
# /etc/fstab: static file system information.
#
# Use 'blkid' to print the universally unique identifier for a
# device; this may be used with UUID= as a more robust way to name devices
# that works even if disks are added and removed. See fstab(5).
#
# systemd generates mount units based on this file, see systemd.mount(5).
# Please run 'systemctl daemon-reload' after making changes here.
#
# <file system> <mount point> <type> <options> <dump> <pass>
/dev/mmcblk1p1 /boot ext2 defaults 0 2
/dev/mmcblk1p2 / ext4 errors=remount-ro 0 1
/dev/mmcblk1p3 swap swap defaults 0 0
/dev/sr0 /media/cdrom0 udf,iso9660 user,noauto 0 0
```

```
sudo nano /home/youruser/assets/root/etc/network/interfaces
```

 change interface to eth0

```
# This file describes the network interfaces available on your system
# and how to activate them. For more information, see interfaces(5).
source /etc/network/interfaces.d/*
```

```
# The loopback network interface
auto lo
iface lo inet loopback
```

```
# The primary network interface
auto eth0
allow-hotplug eth0
iface eth0 inet dhcp
```

```
sudo umount /home/youruser/assets/root
```

```
sudo mkswap /dev/sdX3
```

```
cd home/youruser/assets/
sudo dd if=u-boot-sunxi-with-spl.bin of=/dev/sdX bs=1024 seek=8 conv=notrunc
```

- 10.) Install the eMMC-Module onto your Pine64 H64B SBC, connecting HDMI, Mouse and Keyboard and power it up and log-in as **root**.

```
ip a
```

 check that network is working

- 11.) Activate non-free repositories of Debian

edit the config of Debians Advanced Package Tool as below

```
nano /etc/apt/sources.list
```

```
# deb http://deb.debian.org/debian/ bullseye main
```

```
deb http://deb.debian.org/debian bullseye main contrib non-free
deb-src http://deb.debian.org/debian/ bullseye main contrib non-free
```

```
deb http://security.debian.org/debian-security bullseye-security main contrib non-free
deb-src http://security.debian.org/debian-security bullseye-security main contrib non-free
```

now update the system with

```
apt update
apt upgrade
apt dist-upgrade
apt autoremove
apt autoclean
```

- 12.) Add missing WiFi/Bluetooth driver for PineH64B board

install the firmware for RTL8723BS Chipset with

```
apt install firmware-realtek
```

```
shutdown -r now
```

 reboots the system

13.) Configure WiFi, working Ethernet connection required ;-)

`apt install iw iwd`

`systemctl enable iwd.service`  
`systemctl start iwd.service`  
`systemctl status iwd.service`

installs wireless service iwd  
starts iwd  
check if iwd is running

`iwctl`

bash changes to iwd interactive prompt

`device list`  
`device wlan0 show`  
`station wlan0 scan`  
`station wlan0 get-networks`  
`station wlan0 connect SSID`  
`station wlan0 show`

shows all wireless devices  
shows details about wireless device  
scans for wireless networks  
shows all available wireless networks  
connects to specified network, may ask for passphrase  
check connection status of wireless network

`known-networks list`  
`known-networks SSID forget`

shows all previously connected wireless networks  
deletes previously connected wireless network

`quit`

reverts back to bash

`nano /etc/network/interfaces`

amend as below to add WiFi

`# This file describes the network interfaces available on your system`  
`# and how to activate them. For more information, see interfaces(5).`  
`source /etc/network/interfaces.d/*`

`# The loopback network interface`  
`auto lo`  
`iface lo inet loopback`

`# The primary network interface`  
`auto eth0`  
`allow-hotplug eth0`  
`iface eth0 inet dhcp`

`# The wireless network interface`  
`auto wlan0`  
`iface wlan0 inet dhcp`

`nano /etc/resolv.conf`

`nameserver 192.168.1.xxx`

xxx should match your DNS Server

`shutdown -r now`

once board is up, check with `ip a` for success

14.) Activate Filesystem Checks at startup

`tune2fs -c 1 /dev/mmcblk1p1`  
`tune2fs -c 1 /dev/mmcblk1p2`

Done, enjoy your setup.