

# FCM<sub>k</sub>II DESIGN SCRATCH

## COMMUNICATIONS

STANDARDIZED PORT NUMBERS
<b>S. Listener (Broadcast):</b> 65000
<b>S. MISO:</b> 65001
<b>S. MOSI:</b> 65002

BREAKDOWN	
Master	Slave
Parts	
<ul style="list-style-type: none"><li>• Broadcast Thread<ul style="list-style-type: none"><li>– Standard broadcast</li><li>– Update broadcast</li><li>– Shutdown broadcast</li></ul></li><li>• Listener thread<p>NOTE: Here, responding Slaves can categorized are known and unknown</p><ul style="list-style-type: none"><li>– List new, unknown Slaves for adding</li><li>– Mark known, disconnected Slaves for reconnection</li><li>– Ignore messages from connected Slaves</li><li>– Send startup messages to Bootloaders when appropriate</li></ul></li><li>• Slave threads<p>Depending on target Slave status..</p><p><b>DISCONNECTED:</b> Wait for Slave to be marked by Listener thread</p><p><b>AVAILABLE:</b> Attempt handshake to connect. Mark as disconnected upon failure</p><p><b>CONNECTED:</b> Listen for messages, count timeouts when applicable, fetch commands from user</p></li></ul>	<ul style="list-style-type: none"><li>• Listener thread:<p>Listen for broadcasts. Depending on broadcast type...</p><p><b>Standard:</b> If disconnected, send reply; if connected, reset Master timeout counter.</p><p><b>*Master timeout:</b> Ping Master before assuming disconnection</p><p><b>*Network timeout:</b> Ping self before rebooting</p><p><b>Update broadcast:</b> Shutdown Processor and reboot</p><p><b>Shutdown broadcast:</b> Shutdown Processor and reboot</p><p><b>Launch application:</b> (For Bootloader) Ignore when in MkII; launch MkII when in Bootloader</p></li><li>• MISO thread:<p>Send updates to Master when connected:</p><ul style="list-style-type: none"><li>– Fetch updates from Processor, if any, or send empty message to maintain connection</li><li>– Send ping requests when flagged by Listener</li><li>– Remain idle when disconnected. NOTE: Empty processor Queue</li></ul></li><li>• MOSI thread:<ul style="list-style-type: none"><li>– Listen for messages from Master (when connected) and add them to Processor buffer</li><li>– Reset timeout counter whenever a Message is received</li></ul></li></ul>
Connection and Disconnection	
<ul style="list-style-type: none"><li>• Use broadcast thread to keep Slave connected</li><li>• Use MISO-side of Slave thread to listen for periodic Slave-side updates to know when to assume disconnection</li><li>• NOTE: Send Disconnect message to Slave when assuming disconnection</li><li>• Send multiple MOSI messages (use index)</li></ul>	<ul style="list-style-type: none"><li>• Use listener thread to know if Master is still connected (based on broadcast)</li><li>• Ping Master when considering disconnection</li><li>• Send Disconnect message to Master when assuming disconnection</li><li>• Ping self to check network status before assuming network error and rebooting</li><li>• Also reset Master timeout counter upon reception in MOSI thread</li><li>• Shutdown Processor when assuming disconnection from Master</li></ul>

MESSAGE FORMATS	
MOSI	MISO
Broadcast-side	
<ul style="list-style-type: none"> <li>Standard broadcast: <u>N</u> PASSCODE <u>M.L.PORT</u></li> <li>Update broadcast: <u>U</u> PASSCODE <u>M.L.PORT</u> <u>FILE.NAME</u> <u>FILE.SIZE.BYTES</u></li> <li>Shutdown broadcast: <u>R</u> PASSCODE</li> <li>Launch MkII: <u>L</u> PASSCODE</li> </ul>	<ul style="list-style-type: none"> <li>Standard broadcast reply (MkII): <u>A</u> PASSCODE <u>S.MAC</u> <u>S.MISO.P</u> <u>S.MOSI.P</u> <u>VERSION</u></li> <li>Standard broadcast reply (Bootloader): <u>B</u> PASSCODE <u>S.MAC</u></li> </ul>
Communications and Control	
<ul style="list-style-type: none"> <li>Set DC: <u>MOSI_INDEX</u> <u>S</u> <u>D</u>:DC:00000000000000000000 Here each character in the string of zeroes corresponds to a fan in the target Slave's array. A '1' means the fan is to be set to the specified DC, and a '0' means it is to be left unchanged.</li> <li>Chase RPM: <u>MOSI_INDEX</u> <u>S</u> <u>C</u>:RPM:00000000000000000000 See "Set DC" for the meaning of the string of zeroes.</li> <li>Handshake: <u>0</u> <u>H</u> <u>COMMS_CONFIG</u> <u>H</u>:<u>ARRAY_CONFIG</u> <u>COMMS_CONFIG</u> is a comma-separated list with the following: <ol style="list-style-type: none"> <li>MISO port</li> <li>MOSI port</li> <li>Period (ms)</li> <li>Max. Master timeouts</li> </ol> <u>ARRAY_CONFIG</u> is a colon-separated list with the following: <ol style="list-style-type: none"> <li>Pinout code</li> <li>Fan mode</li> <li>Num. active fans</li> <li>PWM frequency (Hz)</li> <li>Counter counts</li> <li>Pulses per rotation</li> <li>Max. RPM</li> <li>Min. RPM</li> <li>Min. DC</li> <li>Chaser tolerance (%)</li> <li>Max. fan timeout</li> </ol> </li> <li>Disconnect: <u>MOSI_INDEX</u> <u>X</u></li> <li>Reboot: <u>MOSI_INDEX</u> <u>Z</u></li> <li>Reset index: <u>MOSI_INDEX</u> <u>I</u> Slave will reset its MOSI index to 0.</li> <li>Ping: <u>MOSI_INDEX</u> <u>P</u></li> </ul>	<ul style="list-style-type: none"> <li>Maintain connection: <u>MISO_INDEX</u> <u>M</u> Sent to Master when there are no updates from Processor, but a MISO message is due to maintain connection.</li> <li>Standard update: <u>MISO_INDEX</u> <u>T</u> <u>DUTY_CYCLES</u> <u>RPMS</u> Here DUTY_CYCLES and RPMS are comma-separated lists of the DC and RPM values of each fan in the array, in order. Negative values will be used for RPMS of fans being "Chased."</li> <li>Error (MkII): <u>MISO_INDEX</u> <u>E</u> <u>ERROR_MESSAGE</u> For Slave-side exception handling and documenting; will also be used to indicate Slave-side assumption of disconnection.</li> <li>Error (Bootloader): <u>B</u> PASSCODE <u>E</u> <u>S.MAC</u> <u>ERROR_MESSAGE</u> To be received by Master's listener thread.</li> <li>Ping request: <u>MISO_INDEX</u> <u>P</u></li> <li>MISO index reset: <u>MISO_INDEX</u> <u>I</u> Master will reset its MISO index to 0.</li> </ul>

Legend	
<b>N</b> “NORMAL” i.e. Standard broadcast <b>U</b> “UPDATE” i.e. Update broadcast <b>R</b> “REBOOT” i.e. Reboot MCU <b>L</b> “LAUNCH” i.e. Launch MkII <b>S</b> “STANDARD” i.e. Standard command for Processor <b>D</b> “DUTY CYCLE” i.e. Set Duty Cycle <b>C</b> “CHASE” i.e. Chase RPM <b>H</b> “HANDSHAKE” i.e. Handshake to start connection <b>X</b> “DISCONNECT” i.e. Assume disconnection (Shutdown Processor) <b>Z</b> “REBOOT” i.e. Reboot MCU <b>I</b> “INDEX” i.e. Reset MISO Index	<b>A</b> “APPLICATION” i.e. Message from MkII <b>B</b> “BOOTLOADER” i.e. Message from Bootloader <b>M</b> “MAINTAIN” i.e. Maintain connection <b>T</b> “STANDARD” i.e. Standard update message <b>E</b> “ERROR” i.e. Error message <b>P</b> “PING” i.e. Ping request <b>I</b> “INDEX” i.e. MISO index reset

To Do
Mon. 6/25/18 - Tue. 6/25/18
<ol style="list-style-type: none"> <li>1. <u>Fix Bootloader 404 and empty file bugs</u></li> <li>2. Add missing pinout, PSU pins and external LED pins</li> <li>3. Add placeholder for runtime pinout configuration</li> <li>4. <u>Implement new message standard</u> Among other things... <ul style="list-style-type: none"> <li>- Receive S.Error and B.Error messages in both Slave threads and listener thread</li> <li>- Use extra warnings in the event of a Bootloader error</li> </ul> </li> <li>5. <b><u>Implement Slave self-pinging</u></b></li> </ol>
Wed. 6/25/18 - Fri 6/29/18
<ol style="list-style-type: none"> <li>1. Implement runtime pinout configuration</li> <li>2. Implement Master-side firmware uploads</li> <li>3. “Fully” modularize Master</li> <li>4. Implement “verifications” and shutdown button</li> <li>5. Implement user configuration and “null” settings</li> <li>6. <b>Implement multiprocessing</b></li> </ol>
Mon. 7/2/18
<ol style="list-style-type: none"> <li>1. Fix PWM resolution</li> <li>2. Fix Chaser</li> <li>3. <b>Fix RPM spikes (if applicable)</b></li> </ol>
Tue. 7/3/18 - Fri. 7/6/18
<ol style="list-style-type: none"> <li>1. + Implement hotkeys</li> <li>2. + Implement plotter</li> <li>3. + Document</li> <li>4. + Add ”help” section</li> <li>5. + Compile Master-side</li> <li>6. + Credits and licensing (And comments!)</li> </ol>