

Cisco Router Configuration Basics

Bamma Ravind
For Open University of Mauritius

Router Components

- ❑ Bootstrap – stored in ROM microcode – brings router up during initialisation, boots router and loads the IOS.
- ❑ POST – Power On Self Test - stored in ROM microcode – checks for basic functionality of router hardware and determines which interfaces are present
- ❑ ROM Monitor – stored in ROM microcode – used for manufacturing, testing and troubleshooting
- ❑ Mini-IOS – a.k.a RXBOOT/boot loader by Cisco – small IOS ROM used to bring up an interface and load a Cisco IOS into flash memory from a TFTP server; can also perform a few other maintenance operations

Router Components

- ❑ RAM – holds packet buffers, ARP cache, routing table, software and data structure that allows the router to function; running-config is stored in RAM, as well as the decompressed IOS in later router models
- ❑ ROM – starts and maintains the router
- ❑ Flash memory – holds the IOS; is not erased when the router is reloaded; is an EEPROM [Electrically Erasable Programmable Read-Only Memory] created by Intel, that can be erased and reprogrammed repeatedly through an application of higher than normal electric voltage
- ❑ NVRAM – Non-Volatile RAM - holds router configuration; is not erased when router is reloaded

Router Components

❑ Config-Register

- controls how router boots;
- value can be seen with `"show version"` command;
- is typically 0x2102, which tells the router to load the IOS from flash memory and the `startup-config` file from NVRAM

Purpose of the Config Register

- ❑ Reasons why you would want to modify the config-register:
 - Force the router into ROM Monitor Mode
 - Select a boot source and default boot filename
 - Enable/Disable the Break function
 - Control broadcast addresses
 - Set console terminal baud rate
 - Load operating software from ROM
 - Enable booting from a TFTP server

System Startup

- ❑ POST – loaded from ROM and runs diagnostics on all router hardware
- ❑ Bootstrap – locates and loads the IOS image; default setting is to load the IOS from flash memory
- ❑ IOS – locates and loads a valid configuration from NVRAM; file is called `startup-config`; only exists if you copy the `running-config` to NVRAM
- ❑ `startup-config` – if found, router loads it and runs embedded configuration; if not found, router enters setup mode

Overview

- ❑ Router configuration controls the operation of the router's:
 - Interface IP address and netmask
 - Routing information (static, dynamic or default)
 - Boot and startup information
 - Security (passwords and authentication)

Where is the Configuration?

- ❑ Router always has two configurations:
- ❑ Running configuration
 - In RAM, determines how the router is currently operating
 - Is modified using the `configure` command
 - To see it: `show running-config`
- ❑ Startup configuration
 - In NVRAM, determines how the router will operate after next reload
 - Is modified using the `copy` command
 - To see it: `show startup-config`

Where is the Configuration?

- ❑ Can also be stored in more permanent places:
 - External hosts, using TFTP (Trivial File Transfer Protocol)
 - In flash memory in the router
- ❑ Copy command is used to move it around
 - `copy run start` `copy run tftp`
 - `copy start tftp` `copy tftp start`
 - `copy flash start` `copy start flash`

Router Access Modes

- ❑ User EXEC mode – limited examination of router
 - Router>
- ❑ Privileged EXEC mode – detailed examination of router, debugging, testing, file manipulation (router prompt changes to an octothorp)
 - Router#
- ❑ ROM Monitor – useful for password recovery & new IOS upload session
- ❑ Setup Mode – available when router has no `startup-config` file

External Configuration Sources

- ❑ Console
 - Direct PC serial access
- ❑ Auxiliary port
 - Modem access
- ❑ Virtual terminals
 - Telnet/SSH access
- ❑ TFTP Server
 - Copy configuration file into router RAM
- ❑ Network Management Software
 - e.g. CiscoWorks

Changing the Configuration

- ❑ Configuration statements can be entered interactively
 - changes are made (almost) immediately, to the running configuration
- ❑ Can use direct serial connection to console port, or
- ❑ Telnet/SSH to vty's ("virtual terminals"), or
- ❑ Modem connection to aux port, or
- ❑ Edited in a text file and uploaded to the router at a later time via tftp; `copy tftp start` or `config net`

Logging into the Router

- ❑ Connect router to console port or telnet to router

```
router>
```

```
router>enable
```

```
password
```

```
router#
```

```
router#?
```

- ❑ Configuring the router

- Terminal (entering the commands directly)

```
router# configure terminal
```

```
router(config)#
```

Connecting your FreeBSD Machine to the Router's Console Port

- ❑ Connect your machine to the console port using the rollover serial cable provide
- ❑ Go to /etc/remote to see the device configured to be used with "tip". you will see at the end, a line begin with com1

```
bash$ tip com1 <enter>
router>
router>enable
router#
```

New Router Configuration Process

- ❑ Load configuration parameters into RAM

- Router#configure terminal

- ❑ Personalize router identification

- Router#(config)hostname RouterA

- ❑ Assign access passwords

- RouterA#(config)line console 0

- RouterA#(config-line)password cisco

- RouterA#(config-line)login

New Router Configuration Process

- ❑ Configure interfaces
 - RouterA# (config) interface ethernet 0/0
 - RouterA# (config-if) ip address n.n.n.n
m.m.m.m
 - RouterA# (config-if) no shutdown
- ❑ Configure routing/routed protocols
- ❑ Save configuration parameters to NVRAM
 - RouterA# copy running-config startup-config
 - (or write memory)

Router Prompts – How to tell where you are on the router

- ❑ You can tell in which area of the router's configuration you are by looking at the router prompts:
 - **Router>** – USER prompt mode
 - **Router#** – PRIVILEGED EXEC prompt mode
 - **Router(config)** – terminal configuration prompt
 - **Router(config-if)** – interface configuration prompt
 - **Router(config-subif)** – sub-interface configuration prompt

Router Prompts – How to tell where you are on the router

- ❑ You can tell in which area of the router's configuration you are by looking at the router prompts:
 - `Router(config-route-map)#` – route-map configuration prompt
 - `Router(config-router)#` – router configuration prompt
 - `Router(config-line)#` – line configuration prompt
 - `rommon 1>` - ROM Monitor mode

Configuring your Router

- ❑ Set the enable (secret) password:
 - `router(config)# enable secret "your pswd"`
 - ❑ This MD5 encrypts the password
 - The old method was to use the `enable password` command. But this is not secure (weak encryption) and is ABSOLUTELY NOT RECOMMENDED. DO NOT USE!
- ❑ Ensure that all passwords stored on router are (weakly) encrypted rather than clear text:
 - `router(config)# service password-encryption`

Configuring Your Router

- ❑ To configure interface you should go to interface configuration prompt

```
router(config)# interface ethernet0 (or 0/x)
```

```
router(config-if)#
```

- ❑ Save your configuration

- router#copy running-config startup-config

- (or write memory)

Configuring Your Router

❑ Global:

```
enable secret e2@fnog
```

❑ Interface:

```
interface ethernet 0/0
```

```
ip address n.n.n.n m.m.m.m
```

❑ Router:

```
router ospf 1
```

```
network n.n.n.n w.w.w.w area 0
```

❑ Line:

```
line vty 0 4
```

Global Configuration

- ❑ Global configuration statements are independent of any particular interface or routing protocol, *e.g.*:
 - `hostname e2-@fnog`
 - `enable secret tracke2`
 - `service password-encryption`
 - `logging facility local0`
 - `logging n.n.n.n`

Global Configuration

- ❑ IP specific global configuration statements:

`ip classless`

`ip name-server n.n.n.n`

- ❑ Static Route Creation

`ip route n.n.n.n m.m.m.m g.g.g.g`

n.n.n.n = network block

m.m.m.m = network mask denoting block size

g.g.g.g = next hop gateway destination packets are sent to

The NO Command

- ▣ Used to reverse or disable commands e.g

```
ip domain-lookup  
no ip domain-lookup
```

```
router ospf 1  
no router ospf 1
```

```
ip address 1.1.1.1 255.255.255.0  
no ip address
```


Interface Configuration

- ❑ Interfaces are named by slot/type; *e.g.*:
 - ethernet0, ethernet1,... Ethernet5/1
 - Serial0/0, serial1 ... serial3
- ❑ And can be abbreviated:
 - ethernet0 or eth0 or e0
 - Serial0/0 or ser0/0 or s0/0

Interface Configuration

- ❑ Administratively enable/disable the interface

```
router(config-if)#no shutdown
```

```
router(config-if)#shutdown
```

- ❑ Description

```
router(config-if)#description ethernet  
link to admin building router
```

Looking at the Configuration

- ❑ Use `"show running-configuration"` to see the current configuration
- ❑ Use `"show startup-configuration"` to see the configuration in NVRAM, that will be loaded the next time the router is rebooted or reloaded

Storing the Configuration on a Remote System

- ▣ Requires: 'tftpd' on a unix host; destination file must exist before the file is written and must be world writable...

```
router#copy run tftp
Remote host []? n.n.n.n
Name of configuration file to write [hoste2-rtr-
  cfg]? hoste2-rtr-cfg
Write file hoste2-rtr-cfg on Host n.n.n.n?
  [confirm]
Building configuration...

Writing hoste2-rtr-cfg !! [OK]
router#
```

Restoring the Configuration from a Remote System

- Use 'tftp' to pull file from UNIX host, copying to running config or startup

```
router#copy tftp start
Address of remote host [255.255.255.255]? n.n.n.n
Name of configuration file [hoste2-rtr-config]?
Configure using hoste1-rtr-config from n.n.n.n?
[confirm]
Loading hoste2-rtr-config from n.n.n.n (via
Ethernet0/0): !
[OK - 1005/128975 bytes]
[OK]
hoste2-rtr# reload
```

Getting Online Help

- ❑ IOS has a built-in help facility;
 - use "?" to get a list of possible configuration statements
- ❑ "?" after the prompt lists all possible commands:
 - `router#?`
- ❑ "<partial command> ?" lists all possible subcommands, e.g.:
 - `router#show ?`
 - `router#show ip ?`

Getting Online Help

- "<partial command>?" shows all possible command completions

```
router#con?
```

```
configure connect
```

- This is different:

```
hostel-rtr#conf ?
```

```
memory
```

```
Configure from NVRAM
```

```
network
```

```
Configure from a TFTP network host
```

```
overwrite-network
```

```
Overwrite NV memory from TFTP...
```

```
network host
```

```
terminal
```

```
Configure from the terminal
```

```
<cr>
```

Getting Online Help

- ▣ This also works in configuration mode:

```
router(config)#ip a?
```

```
accounting-list accounting-threshold
```

```
accounting-transits address-pool
```

```
alias as-path
```

```
router(config)#int e0/0
```

```
router(config-if)#ip a?
```

```
access-group accounting address
```


Getting Online Help

- Can “explore” a command to figure out the syntax:

```
router(config-if)#ip addr ?
```

```
A.B.C.D  IP address
```

```
router(config-if)#ip addr n.n.n.n ?
```

```
A.B.C.D  IP subnet mask
```

```
router(config-if)#ip addr n.n.n.n m.m.m.m ?
```

```
secondary  Make this IP address a secondary address
```

```
<cr>
```

```
router(config-if)#ip addr n.n.n.n m.m.m.m
```

```
router(config-if)#
```

Getting Lazy Online Help

- ▣ TAB character will complete a partial word

```
hostel-rtr(config)#int<TAB>
```

```
hostel-rtr(config)#interface et<TAB>
```

```
hostel-rtr(config)#interface ethernet 0
```

```
hostel-rtr(config-if)#ip add<TAB>
```

```
hostel-rtr(config-if)#ip address n.n.n.n m.m.m.m
```

- ▣ Not really necessary; partial commands can be used:

```
router#conf t
```

```
router(config)#int e0/0
```

```
router(config-if)#ip addr n.n.n.n
```

Getting Lazy Online Help

❑ Command history

- IOS maintains short list of previously typed commands
- up-arrow or `^p` recalls previous command
- down-arrow or `^n` recalls next command

❑ Line editing

- left-arrow, right-arrow moves cursor inside command
- `^d` or backspace will delete character in front of cursor
- Ctrl-a takes you to start of line
- Ctrl-e takes you to end of line

Connecting your FreeBSD machine to the Router's Console port

- ❑ Look at your running configuration
- ❑ Configure an IP address for e0/0 depending on your table
 - use n.n.n.n for table A etc
- ❑ Look at your running configuration and your startup configuration
- ❑ Check what difference there is, if any

Deleting your Router's Configuration

- ❑ To delete your router's configuration

Router#erase startup-config

OR

Router#write erase

Router#reload

- Router will start up again, but in setup mode, since startup-config file does not exist

Getting to the ROM Monitor

- ❑ Windows using HyperTerminal for the console session
 - Ctrl-Break
- ❑ FreeBSD/UNIX using Tip for the console session
 - <Enter>, then ~# OR
 - Ctrl-], then Break or Ctrl-C
- ❑ Linux using Minicom for the console session
 - Ctrl-A F

Disaster Recovery:

How to Recover a Lost Password

- ❑ Connect your PC's serial port to the router's console port
- ❑ Configure your PC's serial port:
 - 9600 baud rate
 - No parity
 - 8 data bits
 - 1 stop bit
 - No flow control

Disaster Recovery:

How to Recover a Lost Password

- ❑ Your configuration register should be 0x2102; use "**show version**" command to check
- ❑ Reboot the router and apply the Break-sequence within 60 seconds of powering the router, to put it into ROMMON mode

```
Rommon 1>confreg 0x2142
```

```
Rommon 2>reset
```

- Router reboots, bypassing startup-config file

Disaster Recovery:

How to Recover a Lost Password

Type Ctrl-C to exit Setup mode

```
Router>enable
```

```
Router#conf m OR copy start run (only!!!)
```

```
Router#show running OR write terminal
```

```
Router#conf t
```

```
Router(config)enable secret forgotten
```

```
Router(config)int e0/0...
```

```
Router(config-if)no shut
```

```
Router(config)config-register 0x2102
```

```
Router(config)Ctrl-Z or end
```

```
Router#copy run start OR write memory
```

```
Router#reload
```

Cisco Router Configuration Basics



**"THE
DIFFERENCE
BETWEEN
ORDINARY AND
EXTRAORDINARY
IS PRACTICE."**

Vladimir Horowitz

THE VIOLIN CHANNEL