

INTERFACE DOCUMENTATION SHEET

Engineering Project No. 05
2023/2024

ODAI : Optical Devices Made with AI

Optical design and AI: the case of wide-field eyepieces designed using
unsupervised learning



Client/Supervisor :	TWARDOWSKI Patrice
Supervisor/Doctoral fellow ICUBE :	MAUREY Hugo
Mentor :	BURGADE Louis
Project leader :	ARGY Aurélien
Projects leaders :	BAUMANN Florin
	BELHEINE Jelil
	BIBAL-SOBEAUX Pierre Gabriel
	BROUILLET Benoit

Version history

Version	Date	Autor	Added value
1.0	08/04/2024	Aurélien	Document creation

Table of contents

Introduction

I - Detailed explanation of sub-windows and functions

Introduction

General presentation :

This interface uses the parameters of the initial system, the optimisation parameters and the environment to optimise the system for a chosen number of lenses.

Target audience :

Requires a basic knowledge of optics and a minimum knowledge of CodeV software.

System requirements:

- CodeV
- Python (and “pip install -r requirement.txt”)

I - Detailed explanation of sub-windows and functions

The screenshot shows a software window titled "Optical System Configuration Interface". It has a menu bar with "Environment", "SP Parameters", "Tree", "Starting System", "Console Output", and "Output". The "Environment" tab is active, displaying "Environment Settings".

Under "Environment Settings", there is a "+ Add Wavelength" button. Below it are five rows of input fields for wavelengths, each with a value and a unit (indicated by a dash):

Wavelength	Unit
486.1327	-
546.074	-
587.5618	-
632.2	-
657.2722	-

Below the wavelength fields is a "+ Add Field" button. Under it are three rows of input fields for field positions, each with a value and a unit (indicated by a dash):

Field Position	Unit
0	3
0	6
0	35

Below the field position fields is a label "EFL" (Effective Focal Length) and a single input field with the value "1". Below that is a label "fd" (f/d ratio) and a single input field with the value "5".

At the bottom of the window, there is a "Submit" button and a "HELP" button.

Wavelength: Sets the wavelengths for which the optical system should be optimised, to target superior performance on the light frequencies essential to your specific application

Field: Specifies field positions to test optical quality at different points in the field of view, from centre to periphery, to ensure a sharp image across the entire field of view

EFL (effective focal length): Specifies the desired effective focal length for the system, a key parameter that influences the system's ability to focus light

fd: Sets the f/d ratio to define the aperture of the system, influencing both the amount of light captured and the depth of field of the optics

Optical System Configuration Interface

Environment SP Parameters Tree Starting System Console Output Output

SP Parameters

Epsilon
0.5

+ Add Lens Thickness Step

0.05 -

0.1 -

0.15 -

0.4 -

Air Distance Steps
0

Lens Thickness
0.4

Base Material
NBK7_SCHOTT

Submit

HELP

Epsilon: Determines the precision of the convergence of the optimization, which influences the tolerance for stopping the iteration when the solution approaches the saddle point sufficiently

Lens Thickness Step: Establishes the increments in which the lens thickness will be adjusted during optimisation with the last value determining the final lens thickness

Air Distance Step: Defines the distance between two lenses during the optimisation phase

Lens thickness: Enter an initial value in which must correspond to the final value specified in 'Lens Thickness Step', thus establishing the target thickness for the lens after optimisation

Base material: Determines the lens material used during saddle point optimization

The screenshot shows a software window titled "Optical System Configuration Interface". It has a tabbed interface with the following tabs: "Environment", "SP Parameters", "Tree" (which is the active tab), "Starting System", "Console Output", and "Output". The "Tree" tab contains a large, empty rectangular area labeled "Tree". To the right of this area are three input fields: "Starting Depth:" with the value "0", "Target Depth:" with the value "1", and "Base File Path:" with the value "C:/CVUSER". At the bottom center of the window is a "Submit" button, and at the bottom right is a "HELP" button.

Starting Depth: Specifies the basic complexity of the optical system at which optimisation will begin: '0' for a single lens, '1' for a doublet, '2' for a triplet, indicating the number of pre-existing lenses to be refined

Target Depth: Determines the desired final complexity of the optical system after optimisation: '0' to develop a doublet, '1' for a triplet, '2' for a quadruplet, thus increasing the number of lenses in the target design

Base File Path: Specifies the file system location where optical system master data and optimisation results will be saved and retrieved


The screenshot shows a software window titled "Optical System Configuration Interface". It has a tabbed interface with the following tabs: "Environment", "SP Parameters", "Tree", "Starting System", "Console Output", and "Output". The "Starting System" tab is currently selected. Inside this tab, there is a section titled "Starting System Parameters". This section contains three input fields: "Surface 1 Radius" with the value "59.33336", "Lens Thickness" with the value "0.2", and "Base Material" with the value "NBK7_SCHOTT". Below these, there are two more input fields: "Surface 2 Radius" with the value "-391.44174" and "Lens Thickness" with the value "97.703035". At the bottom of the window, there is a "Submit" button and a "HELP" button.

Starting System Parameters		
Surface 1 Radius:	59.33336	Base Material: NBK7_SCHOTT
Surface 2 Radius:	-391.44174	Lens Thickness: 97.703035

Surface 1 Radius & Surface 2 Radius: Defines the radius of the first and second surfaces of your starting lens to determine the curvature of each face

Lens thickness: Defines the initial thickness for the lens


Base material: Selects the base material for the lens, which will be applied evenly to both surfaces of the starting lens



Consol Output: Provides a real-time summary of optimisation status, enabling users to track progress and understand where they are in the evolution of the optical system

Optical System Configuration Interface				
Environment SP Parameters Tree Starting System Console Output Output				
Optimization Results				
Node ID	Parent ID	Merit Function	EFL	SEQ File Path
8	6	0.38576926	1.0	C:/CVUSER/FinalOpti
7	6	0.76607676	1.0	C:/CVUSER/FinalOpti
5	4	1.11952243	1.0	C:/CVUSER/FinalOpti
<div> <div>C:/CVUSER/FinalOptimized_Node8.seq</div> <div>Open</div> <div>Actions</div> </div> <div>Submit</div> <div>HELP</div>				


Gives the node IDs, parent IDs, merit function, EFL, and path to the .seq file containing the optimised system



You can choose the .seq file you want from the drop-down menu

Open: Opens the selected .seq file

Action: Choose to display directly: MTF, spot diagram and spot diameter



Spot Diagram: The spot diagram is a graphical representation of the dispersion of light rays that pass through the optical system and strike the image plane. It is essentially a map of how a perfect point of light from an object would be spread out (or "smeared") into a "spot" due to imperfections in the optical system, such as aberrations. A smaller, more concentrated spot diagram is a sign of better optical quality, indicating that the system is producing sharper images with fewer aberrations

MTF: MTF is a measure of an optical system's ability to reproduce (or transfer) object detail to the image as a function of spatial frequency. It is usually presented as a curve showing the contrast (or modulation) of the reproduced image as a function of spatial frequency, with higher values indicating better performance. Spatial frequency is measured in cycles per millimetre or lines per millimetre, and describes the level of detail in the object

Spot diagram: Represents how the size of the light spots changes as you move to different heights in the field of view