

Amazon Fire HD Tablet User Manual

Cover Starting Guide:

1. Power on your Amazon Fire HD tablet by pressing and holding the power button until the screen lights up.
2. Swipe the screen from right to left to access the home screen.
3. Locate and tap on the "Settings" icon, which is usually represented by a gear or cogwheel.
4. Tap on "Device Options" or "About Device" to access additional settings.
5. Tap on "Cover" or "Cover & Sleep" to access the cover settings.

Connections:

1. Connect your Amazon Fire HD tablet to a Wi-Fi network to access the internet and download apps.
2. You can also connect your tablet to a Bluetooth device, such as a keyboard or game controller, for additional functionality.
3. To connect to a Wi-Fi network, go to the "Settings" menu, tap on "Wi-Fi," and then select your desired network. Enter the network password if required.
4. To connect to a Bluetooth device, go to the "Settings" menu, tap on "Bluetooth," and then turn on the Bluetooth feature. Search for the desired device and tap on it to connect.

Wi-Fi and Bluetooth:

1. Wi-Fi: Wi-Fi is a wireless network that allows your Amazon Fire HD tablet to connect to the internet. You can access Wi-Fi networks at home, work, or public places that offer Wi-Fi access.
2. Bluetooth: Bluetooth is a wireless technology that allows your Amazon Fire HD tablet to connect to other devices, such as keyboards, game controllers, and speakers.
3. To turn on Wi-Fi or Bluetooth, go to the "Settings" menu, tap on "Wi-Fi" or "Bluetooth," and then turn on the feature.
4. To connect to a Wi-Fi network, go to the "Settings" menu, tap on "Wi-Fi," and then select your desired network. Enter the network password if required.
5. To connect to a Bluetooth device, go to the "Settings" menu, tap on "Bluetooth," and then turn on the Bluetooth feature. Search for the desired device and tap on it to connect.

Settings:

1. General: The "General" settings menu allows you to customize various aspects of your Amazon Fire HD tablet. You can adjust the screen brightness, sound settings, language, and more.
2. Accessibility: The "Accessibility" settings menu allows you to customize the accessibility features of your tablet. You can enable text-to-speech, adjust the screen timeout, and more.
3. Accounts: The "Accounts" settings menu allows you to manage your accounts, such as Amazon, Google, and Facebook. You can add new accounts, sign in to existing accounts, and manage your data.
4. Device Options: The "Device Options" settings menu allows you to customize various settings related to your tablet, such as screen lock, device name, and parental controls.

5. Apps: The "Apps" settings menu allows you to manage the apps installed on your Amazon Fire HD tablet. You can uninstall apps, update apps, and manage app permissions.

Apps:

1. Amazon Appstore: The Amazon Appstore is the official app store for the Amazon Fire HD tablet. You can download and install apps, games, and other software from the Appstore.
2. Google Play Store: The Google Play Store is the official app store for Android devices. You can download and install apps, games, and other software from the Play Store.
3. Third-Party App Stores: There are many third-party app stores available for the Amazon Fire HD tablet. You can download and install apps, games, and other software from these app stores.
4. App Recommendations: The Amazon Fire HD tablet comes with a built-in app recommendations feature that suggests apps based on your usage patterns and interests. You can access app recommendations by tapping on the "Apps" tab in the home screen.
5. App Permissions: When you install an app on your Amazon Fire HD tablet, you may be asked to grant certain permissions to the app. These permissions allow the app to access certain features of your tablet, such as your location or contacts. You can manage app permissions by going to the "Settings" menu, tapping on "Apps," and then selecting the app you want to manage.

Troubleshooting:

1. If your Amazon Fire HD tablet is not charging, check the power adapter and charging cable. Make sure they are properly connected and functioning.
2. If your tablet is not responding to touch, try restarting it by pressing and holding the power button for about 20 seconds until the screen goes black. Then, press and hold the power button again to turn it back on.
3. If your tablet is running slow or freezing, try clearing the cache and data by going to the "Settings" menu, tapping on "Apps," and then selecting the app you want to clear. Then, tap on "Storage" and select "Clear Cache" or "Clear Data."
4. If you are having trouble connecting to the internet, try resetting your Wi-Fi network by going to the "Settings" menu, tapping on "Wi-Fi," and then selecting your desired network. Enter the network password if required.
{PASSWORD-1}. If you are having trouble installing an app, try restarting your tablet and then trying again. If the issue persists, try uninstalling the app and then reinstalling it.

Set Up Email on Your Fire Tablet:

Set up the Email app on your tablet using information from your existing email account.

1. Select the **Email** app from the **Home** screen.
2. Enter your email address then select **Next**.
3. Enter the password for your existing email account then select **Next**.
4. After configuring your email account select **Go to Inbox**.

Fire Tablet Isn't Turning On:

Can't get your Fire Tablet device to power on? Follow these tips until the device turns on.

- Try removing any tablet case or cover as it may interfere with the power button.

- Use the power cable and adapter included with your Fire Tablet device.
- Charge your device for at least 30 minutes.
- Press and hold the power button for 40 seconds to reboot device.
- Try a different charging cable.
- Try charging the device by plugging it to a wall outlet.
- Unplug the charging cable and plug cable back into device, then try turning on the device.
- Plug your device to charge and hold power button for 60 seconds.
- Unplug the charging cable and hold the power button for 40 seconds. Then, reconnect device to charging cable.
- Try putting device into [recovery mode](#) and restarting.
 1. For most devices, press and hold the "power" and "volume down" buttons simultaneously.
 2. Release the buttons after five seconds or Amazon logo appears.
 3. Select reboot system now by pressing the power button and confirm.

If your device still isn't charging, you may be eligible for a warranty replacement.

Clear Browser Search Results on Fire Tablet:

Clear browsing history, cookies, and other data from the Silk browser. Select Apps & Games from the Settings menu.

Select Amazon Application Settings > Silk Browser > Privacy > Clear browsing data.

Check the boxes next to data you want to clear then select Clear Data.

Restart Your Fire Tablet:

Solve intermittent issues by rebooting your device.

Press and hold the power button for up to three seconds until you see a shutdown request message.

Select OK and your device turns off.

Press the power button for two to three seconds to turn it back on.

Download Books to Your Fire Tablet:

Can't find your book? Kindle Store purchases are saved to the Cloud. Download them anytime from your Amazon account library.

Device not on hand? Download your book from: Manage Your Content

<https://amazon.com/mycontent>.

Navigate to the Home page of your tablet.

Select Books or open the Kindle app, then select Library.

To see all your previously purchased items, select All from your tablet's library.

Select the cover of the item you'd like to retrieve to download it again.