

Bastl-Instruments 4/9/2017 - updated B Whyte 22/9/2020
 Editor v1.1.0 and firmware version 1.1.0 needed

This chart shows how the 60Knobs Editor is communicating with the device for custom preset configuration. According to the Editor interface, this chart shows parameters in Decimal unit.
 60Knobs editor patches are developed in Cycling74 Max 6 and are available under CC-BY-SA license on bastl github: <https://github.com/bastl-instruments/60Knobs/tree/master/Editor>

SysEx start/end
Data Bytes
Description

SysEx KNOB SETTINGS										
Byte 1	2	3	4	5	6	7	8	9		
SysEx START	Bastl ID	COMMAND	PARAM1 (Knob Num)	PARAM2	PARAM3	PARAM4	PARAM5			
240	48	1 CC	n (0-59)	# (0-127)	0	**247				
240	48	2 NRPN bipolar	n (0-59)	LSB (0-127)	MSB (0-127) (0-16383)	r (1-63)		247		
240	48	3 NRPN unipolar	n (0-59)	LSB (0-127)	MSB (0-127) (0-16383)	r (1-127)		247		
240	48	4 DX7	n (0-59)	MSB (0-1)	LSB (0-127) (0-144)	r (1-99)		247		
240	48	11 CC with Range	n (0-59)	# (0-127)	Min (0-126)	Max (1-127)		MIDI CH# (1-16)	247	
240	48	12 CC with Range on MIDI CH#	n (0-59)	# (0-127)	Min (0-126)	Max (1-127)		247		
240	48	15 CC on MIDI CH#	n (0-59)	# (0-127)	MIDI CH# (1-16)	247				
240	48	16 disable knob	n (0-59)	247						
* 240	48	17 invert direction (max→min)	n (0-59)	yes/no (1/0)	247					
240	58	18 NRPN exponent	n (0-59)	LSB (0-127)	MSB (0-127) (0-16383)	r (1-4) 164/200/1600/2000		247		

* this sysex has to be sent also for each knob.

** 247 ends this message - each message type has different lengths as only some of the 5 PARAMs are used

SysEx GLOBAL SETTINGS (after each knob has been set)					
Byte 1	2	3	4	5	
SysEx START	Bastl ID	COMMAND	PARAM1	SysEx END	
240	48	9 GLOBAL	CH# (1-16) MIDI channel	247	
*** 240	48	19 NRPN LSB data	on/off (0-1) 1 disables LSB	247	
240	48	5 PRESET SAVE	s (0-4) memory SLOT	247	

*** this command enables NRPN data LSB on CC# 38 (optional according to MIDI standard).

PARAMETERS ARE SHOWN IN DECIMAL UNIT. According to which MIDI compiler you're using, conversion to HEXADECIMAL UNIT might be required.

example

knob parameters

knob direction

//		
1st knob CC #55	240 48 1 0 55 0 247	240 48 17 0 0 247
2nd knob NRPNb #127 range 11	240 48 2 1 127 0 11 247	240 48 17 1 0 247
3rd knob NRPNu #199 range 127	240 48 3 2 71 1 127 247	240 48 17 2 0 247
4th knob DX7 #39 range 31	240 48 4 3 0 39 31 247	240 48 17 3 0 247
5th knob CC #70 Min 0 Max 7	240 48 11 4 70 0 7 247	240 48 17 4 0 247
6th Knob CC #31 Min 32 Max 64 on MIDI CH 4	240 48 12 5 31 32 64 4 247	240 48 17 5 0 247
7th knob CC #127 on MIDI CH 16	240 48 15 6 127 16 247	240 48 17 6 0 247
8th knob disabled	240 48 16 7 0 0 247	240 48 17 7 0 247
9th knob CC #21 range inverted	240 48 1 8 21 0 247	240 48 17 8 1 247
10th knob NRPNp #407 range 1600	240 48 18 9 23 3 247	240 48 17 9 0 247

example

command line

//	
Set GLOBAL MIDI CH to 1	240 48 9 1 247
Disable NRPN LSB data out	240 48 19 1 247
Save ALL settings on memory slot 1	240 48 5 0 247