


Weather Station Over MQTT



Requirements

1 Hardware Components

- DHT11 (for temperature & humidity)
- ESP8266 (NodeMCU) (for WiFi & MQTT)
- Jumper Wires (for connections)

2 Software

- Arduino IDE (with ESP8266 & DHT sensor libraries)
- Mosquitto MQTT Broker (We have a VPS at 157.173.101.159)
- WiFi Connection

Code | Function 1

```
21 // Function to Connect to WiFi
22 void setup_wifi() {
23     Serial.print("Connecting to WiFi...");
24     WiFi.begin(ssid, password);
25     while (WiFi.status() != WL_CONNECTED) {
26         delay(500);
27         Serial.print(".");
28     }
29     Serial.println("\nConnected to WiFi!");
30 }
```

Code | Function 2

```
32 // Function to Connect to MQTT Broker
33 void reconnect_mqtt() {
34     while (!client.connected()) {
35         Serial.print("Connecting to MQTT...");
36         if (client.connect("ESP8266")) {
37             Serial.println("Connected to MQTT!");
38         } else {
39             Serial.print("Failed, retrying in 5 seconds...");
40             delay(5000);
41         }
42     }
43 }
```

Code | Function 3

```
45 // Function to Read Sensor Data
46 void read_sensor(float &temperature, float &humidity) {
47     temperature = dht.readTemperature();
48     humidity = dht.readHumidity();
49
50     if (isnan(temperature) || isnan(humidity)) {
51         Serial.println("Failed to read from DHT sensor!");
52         temperature = -1; // Invalid value
53         humidity = -1;    // Invalid value
54     }
55 }
```

Code | Function 4

```
58 void publish_sensor_data(float temperature, float humidity) {
59     if (temperature == -1 || humidity == -1) {
60         return; // Do not publish invalid values
61     }
62
63     String temp_payload = String(temperature);
64     String hum_payload = String(humidity);
65
66     client.publish("/work_group_01/room_temp/temperature", temp_payload.c_str());
67     client.publish("/work_group_01/room_temp/humidity", hum_payload.c_str());
68
69     Serial.println("Published: Temperature = " + temp_payload + "°C");
70     Serial.println("Published: Humidity = " + hum_payload + "%");
71 }
```

Code | `setup()` and `loop()`, native functions of the Arduino Framework

```
73 void setup() {    //run once at the beginning
74     Serial.begin(115200);
75     setup_wifi(); //call Function1
76     client.setServer(mqtt_server, 1883);
77     dht.begin();
78 }
79
80 void loop() {    //run forever
81     if (!client.connected()) {
82         reconnect_mqtt(); //call Function2
83     }
84     client.loop();
85
86     float temperature, humidity;
87     read_sensor(temperature, humidity); //call Function3
88     publish_sensor_data(temperature, humidity); //call Function4
89
90     delay(5000); // Send data every 5 seconds
91 }
```

Code is at <https://github.com/benax-rw>



<> Code

Issues

Pull requests

Actions

Projects

Wiki

Security

Insights

Settings



main

MQTT-based-projects / weather / weather_station_MQTT / weather_station_MQTT.ino



Gabriel Baziramwabo updated code

Code

Blame

92 lines (75 loc) · 2.46 KB



Code 55% faster with GitHub Copilot

Raw



```
1  #include <ESP8266WiFi.h>
2  #include <PubSubClient.h>
3  #include <DHT.h>
4
5  // WiFi Credentials
6  const char* ssid = "MY_WIFI_SSID";
7  const char* password = "MY_WIFI_KEY";
8
9  // MQTT Broker (VPS)
10 const char* mqtt_server = "157.173.101.159"; // Replace with your VPS IP
11
12 // DHT Sensor Configuration
13 #define DHTPIN 2
14 #define DHTTYPE DHT11 // Change to DHT22 if using DHT22
15 DHT dht(DHTPIN, DHTTYPE);
16
17 // MQTT Setup
18 WiFiClient espClient;
19 PubSubClient client(espClient);
20
21 // Function1 to Connect to WiFi
22 void setup_wifi() {
```


Viewing real-time sensor data from MQTT

[illegible]

◆ Installing Mosquitto (Depends on Your OS)

📌 On Linux (Ubuntu/Debian)

```
sh
```

```
sudo apt update  
sudo apt install -y mosquitto mosquitto-clients
```

📌 On macOS (Homebrew)

```
sh
```

```
brew install mosquitto
```

◆ After installing, **start Mosquitto as a background service:**

```
sh
```

```
brew services start mosquitto
```

📌 On Windows

1 Download Mosquitto from the official website:

👉 <https://mosquitto.org/download/>

2 Install it and ensure the mosquitto binaries are in your system path.