

ASUSTeK COMPUTER INC.	EAH5450 Standard Operation Procedure	Doc. No:	
		Date: Feb, 19, 2014 Revision: 2.06	
		Page: 14	Grade:

Rev.	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		First Release	GTC	Ariel_wang	Jan.29,2010
1.01		Add new P/N(C1CP20-A01)	GTC	Ariel_wang	Feb.8,2010
1.02		Add new P/N(C1CP25-A01)	GTC	Ariel_wang	Mar.31,2010
1.03		Add new P/N(C1CP2A-A01)	GTC	Ariel_wang	Mar.31,2010
1.04		Add new PCBA(C1CP20-B02)	GTC	Ariel_wang	Apr.12,2010
1.05		Add new PCBA(C1CP20-B11)	GTC	Ariel_wang	Apr.12,2010
1.06		Add new PCBA(C1CNX0-B02)	GTC	Ariel_wang	Apr.12,2010
1.07		Add new P/N(C1CNX5-B02)	GTC	Ariel_wang	Apr.12,2010
1.08		Add new P/N(C1CNXA-A01)	GTC	Ariel_wang	Apr.27,2010
1.09		Add new P/N(C1CNXA-A11)	GTC	Chongling	Oct.19.2010
1.10		Add new P/N(C1CNX0-B12)	GTC	Chongling	Oct.25.2010
1.11		Add new P/N(C1CP2A-B11)	GTC	Chongling	Oct.26.2010
1.12		Add new P/N(C1CP25-B21)	GTC	Chongling	Oct.27.2010
1.13		Add new P/N(C1CP20-B22)	GTC	Chongling	Nov.1.2010
1.14		Add new P/N(C1CNX0-B22)	GTC	Chongling	Nov.2.2010
1.15		Add new P/N(C1CNXF-A02)	GTC	Ariel_wang	Dec.24.2010
1.16		Add new PCBA(C1CP2A-B22)	GRMA	Ariel_wang	Dec.27.2010
1.17		Add new PCBA(C1CP20-B34)	GRMA	Ariel_wang	Jan.19.2011
1.18		Add new PCBA(C1CNX0-B34)	GRMA	Ariel_wang	Jan.19.2011
1.19		Add new PCBA(C1CNXF-A11)	GRMA	Ariel_wang	Feb.12.2011
1.20		Add new P/N(C1CP2K-A11)	GRMA	Ariel_wang	Feb.16.2011
1.21		Add new P/N(C1CP2U-A01)	GRMA	Ariel_wang	Feb.16.2011
1.22		Add new P/N(C1CP2Z-A01)	GRMA	Ariel_wang	Feb.23.2011
1.23		Add new P/N(C1CNXK-A01)	GRMA	Ariel_wang	Feb.25.2011
1.24		Add new PCBA(C1CP2A-B32)	GRMA	Ariel_wang	Mar.1.2011
1.25		Add new P/N(C1CP2P-A01)	GRMA	Ariel_wang	Mar.1.2011
1.26		Add new P/N(C1CQJ5-A01)	GRMA	Ariel_wang	Mar.16.2011
1.27		Add new PCBA(C1CNXK-A11)	GRMA	Ariel_wang	Mar.17.2011
1.28		Add new PCBA(C1CP2P-A11)	GRMA	Ariel_wang	Mar.21.2011
1.29		Add new P/N(C1CQJ0-A01)	GRMA	Ariel_wang	Mar.30.2011
1.30		Add new P/N(C1CQJK-A01)	GRMA	Ariel_wang	Apr.2.2011
1.31		Add new PCBA(C1CP2K-X12)	GRMA	Ariel_wang	Apr.6.2011
1.32		Add new PCBA(C1CP2U-A12)	GRMA	Ariel_wang	Apr.12.2011
1.33		Add new P/N(C1CQJA-A01)	GRMA	Ariel_wang	Apr.13.2011

Authorize by		Review by		Originator By	Ariel
--------------	--	-----------	--	---------------	-------

ASUSTeK COMPUTER INC		EAH5450 Standard Operation Procedure		Doc. No:	
				Date: Feb.19, 2014	
				Rev. : 2.06 Page: 1	
1.34		Add new P/N(C1CQJF-A01)	GRMA	Ariel_wang	Apr.25.2011
1.35		Add new P/N(C1CQJP-A01)	GRMA	Ariel_wang	Apr.29.2011
1.36		Add new PCBA(C1CP2U-B01)	GRMA	Ariel_wang	May.5.2011
1.37		Add new PCBA(C1CP2U-B11)	GRMA	Ariel_wang	May.5.2011
1.38		Add new PCBA(C1CNXK-A21)	GRMA	Ariel_wang	May.13.2011
1.39		Add new PCBA(C1CQJA-A12)	GRMA	Ariel_wang	Jul.15.2011
1.40		Add new PCBA(C1CP2U-Y02)	GRMA	Ariel_wang	Jul.20.2011
1.41		Add new PCBA(C1CP2U-X04)	GRMA	Ariel_wang	Jul.20.2011
1.42		Add new PCBA(C1CNXK-X11)	GRMA	Ariel_wang	Jul.20.2011
1.43		Add new PCBA(C1CP2K-U12)	GRMA	Ariel_wang	Jul.27.2011
1.44		Add new PCBA(C1CP2U-C01)	GRMA	Ariel_wang	Aug.8.2011
1.45		Add new PCBA(YV00J2-C11)	GRMA	Ariel_wang	Aug.8.2011
1.46		Add new PCBA(YV00I1-A31)	GRMA	Ariel_wang	Aug.17.2011
1.47		Add new PCBA(C1CNXK-U11)	GRMA	Ariel_wang	Aug.17.2011
1.48		Add new PCBA(YV00J2-V03)	GRMA	Ariel_wang	Aug.17.2011
1.49		Add new PCBA(YV00J2-U05)	GRMA	Ariel_wang	Aug.17.2011
1.50		Add new PCBA(YV00J5-A22)	GRMA	Ariel_wang	Aug.17.2011
1.51		Add new PCBA(YV00J3-A22)	GRMA	Ariel_wang	Aug.17.2011
1.52		Add new PCBA(YV00J5-A32)	GRMA	Ariel_wang	Aug.30.2011
1.53		Add new PCBA(YV00J1-B52)	GRMA	Ariel_wang	Aug.30.2011
1.54		Add new PCBA(YV00J4-B42)	GRMA	Ariel_wang	Aug.30.2011
1.55		Add new PCBA(YV00J2-C21)	GRMA	Ariel_wang	Aug.30.2011
1.56		Add new P/N(YV00J7-A01)	GRMA	Singo_wang	Sep.7.2011
1.57		Add new PCBA(YV00J5-A42)	GRMA	Singo_wang	Sep.8.2011
1.58		Add new PCBA(YV00J8-B01)	GRMA	Singo_wang	Sep.8.2011
1.59		Add new P/N(YV00J6-A01)	GRMA	Singo_wang	Sep.8.2011
1.60		Add new P/N(YV00J9-A11)	GRMA	Ariel_wang	Sep.16.2011
1.61		Add new P/N(YV00J4-B52)	GRMA	Ariel_wang	Sep.30.2011
1.62		Add new PCBA(YV00J8-A01)	GRMA	Ariel_wang	Oct.8.2011
1.63		Add new PCBA(YV00J7-U01)	GRMA	Ariel_wang	Oct.24.2011
1.64		Add new PCBA(YV00J2-W21)	GRMA	Ariel_wang	Oct.24.2011
1.65		Add new PCBA(YV00JB-A01)	GRMA	Ariel_wang	Oct.28.2011
1.66		Add new PCBA(YV00J8-C01)	GRMA	Ariel_wang	Nov.11.2011
1.67		Add new PCBA(YV00J6-U01)	GRMA	Ariel_wang	Nov.15.2011
1.68		Add new PCBA(YV00JC-A14)	GRMA	Ariel_wang	Dec.6.2011
1.69		Add new PCBA(YV00J2-C32)	GRMA	Ariel_wang	Jan.10.2012
1.70		Add new PCBA(YV00J6-A21)	GRMA	Ariel_wang	Mar.12.2012
1.71		Add new PCBA(YV00J5-A52)	GRMA	Ariel_wang	Mar.20.2012
1.72		Add new P/N(YV00JE-A01)	GRMA	Ariel_wang	Mar.23.2012
1.73		Add new PCBA(YV00JE-A11)	GRMA	Ariel_wang	Mar.23.2012
1.74		Add new P/N(YV00JF-A01)	GRMA	Ariel_wang	Mar.23.2012
1.75		Add new PCBA(YV00JF-A11)	GRMA	Ariel_wang	Mar.23.2012
1.76		Add new PCBA(YV00J6-A31)	GRMA	Ariel_wang	May.8.2012

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No:
		Date: Feb.19, 2014
		Rev. : 2.06 Page: 2

1.77		Add new PCBA(YV00J2-C52)	GRMA	Ariel_wang	May.17.2012
1.78		Add new PCBA(YV00J2-C42)	GRMA	Ariel_wang	Jul.2.2012
1.79		Add new PCBA(YV00J6-A13)	GRMA	Ariel_wang	Jul.2.2012
1.80		Add new PCBA(YV00J2-C63)	GRMA	Ariel_wang	Jul.13.2012
1.81		Add new PCBA(YV00I1-A52)	GRMA	Ariel_wang	Jul.24.2012
1.82		Add new PCBA(YV00J8-A32)	GRMA	Ariel_wang	Aug.7.2012
1.83		Add new PCBA(YV00J8-A23)	GRMA	Ariel_wang	Aug.21.2012
1.84		Add new PCBA(YV00J2-C73)	GRMA	Ariel_wang	Aug.21.2012
1.85		Add new PCBA(YV00JF-A21)	GRMA	Ariel_wang	Sep.11.2012
1.86		Add new PCBA(YV00JF-A31)	GRMA	Ariel_wang	Sep.11.2012
1.87		Add new PCBA(YV00J5-A62)	GRMA	Ariel_wang	Sep.11.2012
1.88		Add new PCBA(YV00J2-S32)	GRMA	Ariel_wang	Sep.18.2012
1.89		Add new PCBA(YV00J8-C11)	GRMA	Ariel_wang	Nov.16.2012
1.90		Add new PCBA(YV00JB-A13)	GRMA	Ariel_wang	Nov.16.2012
1.91		Add new PCBA(YV00J2-C83)	GRMA	Ariel_wang	Dec.10.2012
1.92		Add new PCBA(YV00J2-C94)	GRMA	Ariel_wang	Dec.24.2012
1.93		Add new PCBA(YV00J8-A44)	GRMA	Ariel_wang	Jan.3.2013
1.94		Add new PCBA(YV00J8-A54)	GRMA	Ariel_wang	Jan.3.2013
1.95		Add new PCBA(YV00J2-S84)	GRMA	Ariel_wang	Jan.3.2013
1.96		Add new PCBA(YV00JF-A42)	GRMA	Ariel_wang	Jan.15.2013
1.97		Add new PCBA(YV00JF-A52)	GRMA	Ariel_wang	Jan.15.2013
1.98		Add new PCBA(YV00J2-CA4)	GRMA	Ariel_wang	Jan.23.2013
1.99		Add new PCBA(YV00J2-CB4)	GRMA	Ariel_wang	Jan.23.2013
2.00		Add new PCBA(YV00J2-SA5)	GRMA	Ariel_wang	Mar.19.2013
2.01		Add new PCBA(YV00J8-Q45)	GRMA	Jory_yuan	Aug.21.2013
2.02		Add new P/N(YV00J0-C01)	GRMA	Jory_yuan	Oct.23.2013
2.03		Add new PCBA(YV00J0-C11)	GRMA	Jory_yuan	Dec.4.2013
2.04		Add new P/N(YV00I3-A01)	GRMA	Jory_yuan	Dec.18.2013
2.05		Add new PCBA(YV00JI-A11)	GRMA	Jory_yuan	Jan.22.2014
2.06		Add new P/N(YV0601-A01)	GRMA	Jory_yuan	Feb.19.2014

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No:
		Date: Feb.19, 2014
		Rev. : 2.06 Page: 3

1.Objectives

Create test procedure.

2.Scope

Model: EAH5450

3.Test Item

3.1 Diagnostic test in 32-bit/64-bit Linux system

3.2 3DMark03(contain HDMI test)

3.3 Temperature test

4.Relevant Document

None.

5.Definition :1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration

Note:Some new P/N or new PCBA of EAH5450 is tested in 64-bit linux system, please refer to the SOP carefully.

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No:
		Date: Feb.19, 2014
		Rev. : 2.06 Page: 4

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. **(Please install windows test environment by yourself).**

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No:
		Date: Feb.19, 2014 Rev. : 2.06 Page: 5

6.2 Fixture connect

6.2.1 Install Intel P5/P7 CPU & CPU Fan.

6.2.2 Install DDR2 1GB/DDR3 Memory to DIMM1~4. **(a minimum memory of 2GB for Linux test)**

6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.

6.2.4 Plug VGA Card EAH5450 into PCIEX16_1.




C1CNX0

6.2.5 Connect SATA HDD & SATA con via SATA cable



6.2.6 Plug 4PIN 12V power **(a minimum power of 600W)** cable into CON12V.

6.2.7 Plug ATX Power on Power **(a minimum power of 600W)** Connector.




ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No: Date: Feb.19, 2014 Rev. : 2.06 Page: 6
----------------------	---	---

6.3 Certain test.

6.3.1 Diagnostic test in **32-bit LINUX system or 64-bit LINUX system.**

6.3.1.1 Please connect LCD monitor & card's DVI CON via a DVI cable.



Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.



6.3.1.2 Press Power Switch then turn on power button.

6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults.



6.3.1.4 Run test program in linux.

Below P/N is tested in 32-bit linux system

Path:eah5450\c1cnx0a0.sh or c1cp20a0.sh or c1cp2aa0.sh or c1cnxaa0.sh or
c1cnxaa1.sh or c1cnx0b1.sh or c1cp2ab1.sh or c1cp25b2.sh or
c1cp2za0.sh or c1cp2pa0.sh

Path:eah54501\c1cp25a0.sh

Path:eah54502\c1cp20b0.sh or c1cp20b1.sh or c1cnx0b0.sh or c1cnx5b0.sh

Path:eah54503\c1cp20b2.sh or c1cnx0b2.sh or c1cnxfa0.sh or c1cnx0b1.sh or
c1cnx0b3.sh or c1cp20b3.sh or c1cnxfal.sh

Path:eah54504\c1cp2ab2.sh or c1cp2ka1.sh or c1cp2ua0.sh or c1cnxka0.sh or

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No: Date: Feb.19, 2014 Rev. : 2.06 Page: 7
<p>clcp2ab3.sh or clcqj5a0.sh or clcnxka1.sh or clcp2pa1.sh or clcqj0a0.sh or clcqjka0.sh or clcp2kx1.sh or clcp2ua1.sh or clcqjaa0.sh or clcqjfa0.sh or clcqjpa0.sh or clcp2ub0.sh or clcp2ub1.sh or clcnxka2.sh or clcqjaa1.sh or clcp2ku1.sh or clcp2uc0.sh or yv00j2c1.sh or yv00i1a3.sh or yv00j3a2.sh or clcnxku1.sh or yv00j2v0.sh or yv00j2u0.sh or yv00j5a2.sh or yv00j5a3.sh or yv00i1a5.sh</p> <p>Path:eah54505\clcp2uy0.sh or clcp2ux0.sh or clcnxkx1.sh</p> <p>Below P/N is tested in 64-bit linux system</p> <p>Path:eah54506\yv00j1b5.sh or yv00j4b4.sh or yv00j2c2.sh or yv00j7a0.sh or yv00j5a4.sh or yv00j8b0.sh or yv00j6a0.sh or yv00j9a1.sh or yv00j8a0.sh or yv00j7u0.sh or yv00j2w2.sh or yv00jba0.sh or yv00j6u0.sh or yv00jca1.sh or yv00j2c3.sh or yv00j6a2.sh or yv00j5a5.sh or yv00jea0.sh or yv00jea1.sh or yv00jfa0.sh or yv00jfa1.sh or yv00j6a3.sh</p> <p>Path:eah54507\yv00j2c5.sh or yv00j2c4.sh or yv00j6a1.sh or yv00j2c6.sh or yv00j8a3.sh or yv00j2c7.sh or yv00j8a2.sh or yv00jfa2.sh or yv00jfa3.sh or yv00j5a6.sh or yv00j2s3.sh or yv00j8c1.sh or yv00jba1.sh or yv00j2c8.sh or yv00j2c9.sh or yv00j8a4.sh or yv00j8a5.sh or yv00j2s8.sh or yv00jfa4.sh or yv00jfa5.sh or yv00j2ca.sh or yv00j2cb.sh or yv00j2sa.sh or yv00j8q4.sh or yv00j0c1.sh or yv00i3a0.sh or yv00j1a1.sh or yv0601a0.sh</p> <p>Please enter into the file of eah5450 or eah54501 or eah54502 or eah54503 or eah54504, enter the following command :cd ./eah5450 or cd ./eah54501 or cd ./eah54502 or cd ./eah54503 or cd ./eah54504</p> <p>Then,please run ./clcnx0a0.sh or clcp20a0.sh or ./clcp2aa0.sh or ./clcnxaa0.sh or ./clcnxaa1.sh or ./clcnx0b1.sh or clcp2ab1.sh or ./clcp25b2.sh or./clcp25a0.sh or ./clcp20b0.sh or ./clcp20b1.sh or ./clcnx0b0.sh or ./clcnx5b0.sh or ./clcp20b2.sh or ./clcnx0b2.sh or ./clcnxfa0.sh or ./clcp2ab2.sh or ./clcp20b3.sh or ./clcnx0b3.sh or ./clcnxfal.sh or ./clcp2ka1.sh or ./clcp2ua0.sh or ./clcp2za0.sh or clcnxka0.sh or ./clcp2ab3.sh or ./clcqj5a0.sh or ./clcnxka1.sh or ./clcp2pa1.sh or ./clcqj0a0.sh or ./clcqjka0.sh or ./clcp2kx1.sh or ./clcp2ua1.sh or ./clcqjaa0.sh or ./clcqjfa0.sh or ./clcqjpa0.sh or clcp2ub0.sh or clcp2ub1.sh or ./clcnxka2.sh or ./clcqjaa1.sh or ./clcp2uy0.sh or ./clcp2ux0.sh or ./clcnxkx1.sh or ./clcp2ku1.sh or ./clcp2uc0.sh or ./yv00j2c1.sh or ./yv00i1a3.sh or ./yv00j3a2.sh or ./clcnxku1.sh or ./yv00j2v0.sh or ./yv00j2u0.sh or ./yv00j5a2.sh or ./yv00j5a3.sh or ./yv00j1b5.sh or ./yv00j4b4.sh or ./yv00j2c2.sh or ./yv00j7a0.sh or ./yv00j5a4.sh or ./yv00j8b0.sh or ./yv00j6a0.sh or ./yv00j9a1.sh or ./yv00j8a0.sh or ./yv00j7u0.sh or ./yv00j2w2.sh or ./yv00jba0.sh or ./yv00j6u0.sh or ./yv00jca1.sh or ./yv00j2c3.sh or ./yv00j6a2.sh or ./yv00j5a5.sh or ./yv00jea0.sh or ./yv00jea1.sh or ./yv00jfa0.sh or ./yv00jfa1.sh or ./yv00j6a3.sh or ./yv00j2c5.sh or ./yv00j2c4.sh or ./yv00j6a1.sh or ./yv00j2c6.sh or ./yv00j8a3.sh or ./yv00j2c7.sh or ./yv00j8a2.sh or ./yv00jfa2.sh or ./yv00jfa3.sh or ./yv00j5a6.sh or ./yv00j2s3.sh or./yv00j8c1.sh or ./yv00jba1.sh ./yv00j2c8.sh ./yv00j2c9.sh or ./yv00j8a4.sh or ./yv00j8a5.sh or ./yv00j2s8.sh or ./yv00jfa4.sh or ./yv00jfa5.sh or ./yv00j2ca.sh or ./yv00j2cb.sh or ./yv00j2sa.sh</p> <p>6.3.1.5 Memory test</p> <p>If you want to test memory,please run ./tserver-exec -test=memfal.1</p>		

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No: Date: Feb.19, 2014 Rev. : 2.06 Page: 8
<p> Path:eah5450\ Path:eah54501\ Path:eah54502\ Path:eah54503\ If you want to test memory,please run <code>./tserver -test=memfa</code> Path:eah54504\ Path:eah54505\ Path:eah54506\ Path:eah54507\ </p> <p>6.3.1.6 BIOS Version</p> <p>If you want to see the version of bios, please run <code>./atiflash -ai 0</code> or <code>./biosinfo</code>.</p> <p> Path:eah5450\ Path:eah54501\ Path:eah54502\ Path:eah54503\ Path:eah54504\ Path:eah54505\ Path:eah54506\ Path:eah54507\ </p> <p>6.3.1.7 BIOS flash</p> <p>Please use the following command to flash bios and notice the size of character.</p> <p> Path:eah5450\ Path:eah54501\ Path:eah54502\ Path:eah54503\ Path:eah54504\ Path:eah54505\ Path:eah54506\ Path:eah54507\ </p> <p>Command:<code>./atiflash -p -f 0 xxx.rom</code></p> <p>Notice:</p> <p>If you can not flash bios because of the bios locked, please use <code>./atiflash -unlockrom 0</code> to unlock bios. And then, please use <code>./atiflash -lockrom 0</code> to lock bios after updating latest bios.</p> <p>6.3.1.8 After finish Linux testing, please enter Windows environment to test 3DMark.</p>		

ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No: Date: Feb.19, 2014 Rev. : 2.06 Page: 9
----------------------	---	---

6.3.2 3DMark test(contain HDMI test)

6.3.2.1 Please install 3DMark program by yourself.

6.3.2.2 Please connect VGA card to LCD via HDMI cable.



HDMI CON

6.3.2.3 Please install VGA card driver in Windows(You must use the latest individual driver of this card).


6.3.2.4 Please run 3DMark03 base on this card (please test 1 cycle).

6.3.2.5 Press “Select” to enter Select test menu. You can choose “GT1” for default setting.


(For C1CNX0(A01)C1CNXA(A01)C1CP20(A01)C1CP2A(A01)C1CNXF(A02))

Press “Select” to enter Select test menu. You can choose “GT4” for default setting.

(For C1CN25(A01))



6.3.2.6 Press “Demo” to enter Demo menu. You can choose “Sounds” for default setting.



6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on.
If there's no problem, it can be judged OK!

6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.




ASUSTeK COMPUTER INC	EAH5450 Standard Operation Procedure	Doc. No:
		Date: Feb.19, 2014 Rev. : 2.06 Page: 11


6.4 Temperature test

6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.


6.4.2 Please run ThermalTest.exe.



6.4.3 If test ok, show pass.



6.4.4 If test fail, show fail.



6.4.5 If test OK, please NTF test.

7.Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	Dell 30 inches (3008WFP) (Buying a local LCD by yourself)			1	
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 1200W)			1	
5	INTEL Celeron E1200			1	
6	Intel CPU Intel(R) Core(TM)2 CPU		local	1	
7	Heat sink + FAN	22-240000160		1	
8	DDR3 1333 2G	20-TT2605618	local	4	
9	TEST HDD			1	
10	SATA HDD Cable	14-000107070	ASUS	1	
11	PCIEX16 VGA CARD			1	
12	Dual link DVI cable (Buying a local DVI cable by yourself)			1	
13	HDMI extend cable (Buying a local HDMI cable by yourself)			1	
14	Display port cable (Buying a local HDMI cable by yourself)			1	
15	P5E MB	80- MBB7X0-*		1	
16	P7H55-M/USB3 (C1CQJA-A12 and later)	80-MIBBKA-G0*	ASUS	1	