



AACLC Encoder

Build Procedure Document

Document Name	IA-AACLC-Enc-ARM9E-BP
Release Version	3.5.00
Date	07-04-2010

Ittiam Systems (P) Ltd,
The Consulate, 1 Richmond Road,
Bangalore 560 025, India

Notice

Ittiam Systems reserves the right to make changes to its products or discontinue any of its products or offerings without notice.

Ittiam warrants the performance of its products to the specifications applicable at the time of sale in accordance with Ittiam's standard warranty.

Copyright © 2008, Ittiam Systems (P) Ltd

Contents

1.	Building the Sample Application.....	1
1.1	Introduction	1
1.2	Pre-requisites for the build	1
1.2.1	Files Required.....	1
1.2.1.1	Build tools configuration files	1
1.2.1.2	Algorithm library	1
1.2.1.3	Codec package building files	1
1.2.1.4	Hardware resource library	2
1.2.1.5	ARM application build files	2
1.2.1.6	ARM application include files	2
1.2.1.7	ARM application source files.....	2
1.2.1.8	Binary files and executables	2
1.3	Usage Instructions	2
2.	References	4

1. Building the Sample Application

1.1 Introduction

The document mentions the following details:

- Pre-requisites for the build: This section contains all the pre-requisites for building the test application like the files required etc.
- Usage Instructions: A step by step process of how to build and run the test application

1.2 Pre-requisites for the build

1.2.1 Files Required

1.2.1.1 Build tools configuration files

- \Makefile.prod
- \packages-production\user.bld
- \packages-production\config.bld

1.2.1.2 Algorithm library

```
(\packages-production\ittiam\codecs\aaclc_enc)  
■ lib_production\aaclc_enc_prod.a
```

1.2.1.3 Codec package building files

```
(\packages-production\ittiam\codecs\aaclc_enc)  
■ ce\AACLC_ENC.xdc  
■ ce\AACLC_ENC.xs  
■ ce\package.bld  
■ ce\package.xdc  
■ ce\package.xs  
■ AACLC_ENC.xdc  
■ link.xdt  
■ package.bld
```

- package.xdc
- package.xs

1.2.1.4 Hardware resource library

```
(\packages-production\ittiam\codecs\aaclc_enc\ce)
  ■ lib\resource.a470MV
```

1.2.1.5 ARM application build files

```
(\packages-production\ittiam\app\aaclc_enc_app)
  ■ aaclc_enc_app.cfg
  ■ package.bld
  ■ package.xdc
  ■ aaclc_enc_app.x470MV (application executable obtained after
    building)
```

1.2.1.6 ARM application include files

```
(\packages-production\ittiam\app\aaclc_enc_app)
  ■ enhaacplusenc_ittiam.h
  ■ ienhaacplusenc.h
  ■ ia_error_handler.h
  ■ ia_error_standards.h
  ■ ia_type_def.h
```

1.2.1.7 ARM application source files

```
(\packages-production\ittiam\app\aaclc_enc_app)
  ■ ceapp.c
  ■ app.c
  ■ ia_aaclc_enc_error_handler.c
```

1.2.1.8 Binary files and executables

```
(\packages-production\ittiam\app\aaclc_enc_app\test)
  ■ loadmodules.sh (script to initialize kernel modules)
  ■ aaclc_enc_params.txt (input config file for the app)
  ■ aaclc_enc_app.x470MV (Pre-built application, this will be
    updated when the package is built)
```

1.3 Usage Instructions

To build and run the application, follow the given steps:

1. Set the path variables in the file `Makefile.prod`. You need to change the paths of `CE_INSTALL_DIR`, `XDC_INSTALL_DIR`, `XDCPATH` appropriately. In case the directory `'(CE_INSTALL_DIR)/cetools/packages'` does not exist in your CE installation package, then you should also include the paths of `xdais`, `framework` components and `cmem` in `XDCPATH`.
2. Set the right ARM code generation tools path in `user.bld`
3. Set the right ARM compiler tool chain path in `user.bld`
4. Set the target platform in `user.bld`
5. Clean the workspace before building, using the command below

```
make -f Makefile.prod clean
```
6. Build the workspace using the command below

```
make -f Makefile.prod all
```

This command will build codec and the application
7. Running the executable
 - a. Copy the `'test'` folder (containing `aacalc_enc_app.x470MV`, `loadmodules.sh`, `aacalc_enc_params.txt`, `*.wav`) under `packages-production/ittiam/app/aacalc_enc_app` into your working folder on the target device's file system
 - b. Go to `test/` directory.
 - c. Run the `./loadmodules.sh` on command line for `cmem` kernel module.
 - d. The sample application runs using a parameter file called `aacalc_enc_params.txt` using which the input and output test-vector list is provided. The details to configure `aacalc_enc_params.txt` are provided in [1].
 - e. Run `./aacalc_enc_app.x470MV` on command line. The output created can be compared for bit-exactness with reference output `*_ref.aac`.
8. There is a compilation switch `ARM_PROFILE` in `packages-production/ittiam/app/aacalc_enc_app/app.c` to enable or disable profiling of the component's process call.
9. There is a compilation switch `USE_ITTIAM_ERROR_CODE` in `packages-production/ittiam/app/aacalc_enc_app/app.c` to enable or disable the usage of include files `ia_error_handler.h`, `ia_error_standards.h` and `ia_type_def.h`

2. References

- [1] Getting started Guide