

```

#ifndef NextionLib_h
#define NextionLib_h
/*
The MIT License (MIT)
Copyright (c) 2022 Robert E Bridges
Permission is hereby granted, free of charge, to any person obtaining a copy of
this software and associated documentation files (the "Software"), to deal in
the Software without restriction, including without limitation the rights to
use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of
the Software, and to permit persons to whom the Software is furnished to do so,
subject to the following conditions:
The above copyright notice and this permission notice shall be included in all
copies or substantial portions of the Software.
THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS
FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR
COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER
IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN
CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.
On a personal note, if you develop an application or product using this library
and make millions of dollars, I'm happy for you!

Code by Robert E Bridges bob@bricomp-uk.com
This library is intended to be used to create your own Nextion Library. Most of it is done for you.
The fn (fn) that you will mostly alter is the "respondToReply()" fn.
I developed this library to control the valves in my Home Heating system, so there are fns
that pertain to the opening/closing of valves. This can be used as an example as to how to use/develop
the Library.
I mostly communicate with the nextion through the passing of data into/from numeric variables.
I have a TimerEvent which runs at 600mS intervals, slow I know but fast enough for my current needs.
When, for example this timer notices that the numeric variable "SetTime" is not zero it takes the value
from this variable and sets the time. The format of the data in this variable is (in HEX) "HHMMSS".
After having set the time the variable is set back to 0 again.
Other variables are interrogated and responded to in a similar way by the code for this Timer Event.
An example is to give an impression of a flashing led, turning on or off a radio button with a different
colour for on and off.

Below is the Nextion code snippet to set the RTC time.

//=====
//Set RTC time if SetTime > 0 NOTE: Variables declared in Nextion Programs.s
//=====
if(SetTime!=0)
{
  xx=SetTime
  xx=xx>>16
  rtc3=xx // Set the hour
  xx=SetTime
  xx=xx&0xFF00
  xx=xx>>8 // Set the minutes
  rtc4=xx
  xx=SetTime&0xFF
  rtc5=xx // Set the seconds
  SetTime=0
}

```

Revision	Date	Author	Description
1.00	16/04/2022	Robert E Bridges	- Initial release
1.10	17/04/2022	Robert E Bridges	- Added printMoreTextToNextion and improved explanation.
1.15	18/04/2022	Robert E Bridges	- Changed to reflect Nextion use of Global Variables in Program.s
1.20	22/04/2022	Robert E Bridges	- Added nextionError. Set when Nextion returns an error or an invalid number of characters returned - Added errorCode. Set to the Nextion returned error or thr error code for invalid num chars. errorCode is cleared if getReply() is called and there are chars from Nextion. - All the following added: preserveTopTextLine writeToTopTextLine releaseTopTextLine clearTextScreen clearTopTextLine setBackLight getNumVarValue setNumVarValue
1.25	01/05/2022	Robert E Bridges	- Completed respondToReply. Now handles the return of Text from the Nextion. - Added setTextBuffer. Adds a text buffer where text data is placed from Nextion.
1.30	08/05/2022	Robert E Bridges	- Added askSerialBufferClear           use       THIS and isSerialBufferClear       before THIS
1.35	09/05/2022	Robert E Bridges	- Added setBkcmdLevel and handling of successful command completion when bkcmd = 1 or 3. see setBkcmdLevel for explanation.
1.40	10/05/2022	Robert E Bridges	- Added lastComdCompletedOk as a complement to setBkcmdLevel above. - Added timeout to getReply
1.50	25/05/2022	Robert E Bridges	- Added setScreenDimTime - Changed getNumVarValue error return to -1 from 0xFFFF. - Added a const char revision to reflect the revision. duplicated with revisionNum to better allow checking/comparison.
1.55	29/05/2022	Robert E Bridges	- Added gotoPage.
1.56	03/06/2022	Robert E Bridges	- Inseted MISSING break in Nextion reset code.
1.60	04/06/2022	Robert E Bridges	- Added getNumVarFloat and second form of getNumVarValue. - Added setStrVarValue. - Added viewDebugText (or NOT). - Corrected getNumVarValue - previously did not wait long enough for some numbers - getNumVarValue sets it's own error code on error and also sets nextionError - Introduced a variable timeout for getNumVarValue, initially at 1000 ms; - Introduced a variable timeout for getStringVarValue, initially at 1000 ms; - getNumVarValue sets it's own error code on error and also sets nextionError - getStringVarValue corrected. - gotoPage corrected. - Tidied up various timeout values.
1.65	05/06/2022	Robert E Bridges	- Added setNumVarFloat.
1.66	11/04/2023	Robert E Bridges	- Minor change to remove compiler warning for Nextion.begin in cpp file.
1.67	13/09/2023	Robert E Bridges	- Minor change onOffFlashingTyp off, on, flashing changed to ledOn, ledOff, ledFlashing. - programmer may have used off and on elsewhere and may conflict.
1.68	29/09/2023	Robert E Bridges	- setTextBuffer           changed from void setTextBuffer( const char* textBuffer, uint8_t textBufferSize); to    void setTextBuffer(        char* textBuffer, uint8_t textBufferSize);
1.69	06/02/2024	Robert E Bridges	- Added SetDate to complement SetTime.
1.70	18/02/2024	Robert E Bridges	- Added variables and functions associated with getting date/time from Nextion: - Added getDateTIme() to get date/time from Nextion - works with the NEW example HMI. - Added setMcuDateTimeCallback,   - works with the NEW example HMI. - added variables nextionDateTimeUpdt, packedDateTime                               - works with the NEW example HMI. - Added variable and function to get EEPROM data from Nextion: - Added fns setEEPromDataBuffer and getEEPromData                                   - works with the NEW example HMI. - Added eeepromDataChanged   - works with the NEW example HMI.

```
(*****
(*)          Below at vs 1.71 is a MAJOR Potential Error Fix          *)
(*****
1.71  19/02/2024    Robert E Bridges    - GetReply() changed. An error could occur if the Nextion data was coming too fast.
                                           - Added getPage() - works with the NEW example HMI.
1.72  22/02/2024    Robert E Bridges    - Added getDaylightSavingOn(), setSystemResetCallback(), setButtonPressCallback(),
                                           setGlobalNumVarValue().
(*****
(*)          New Version 2.00          *)
(*****
2.00  27/02/2024    Robert E Bridges    - New version with some simplification and expansion of usefulness
                                           - Renamed as Nextion2.h
2.01  11/03/2024    Robert E Bridges    - Error corrected..when sending global variables (without suffix) "." was still sent.
                                           - getPage has been altered to return a uint8_t and uses "sendme" rather than "get dp".
                                           This results in 3 fewer serial bytes being transmitted.
```

```
(*****
(*)          Changes at vs 2.00 and update suggestions from vs 1.72          *)
(*****
1)      In get or set routines, instead of having to put "val" or "txt" to identify an attribute type as in n1.val=1235, identifiers
are used to identify the variable's attributes. They now encompass all the variable attributes.
The get attributes identifiers are contained in varAttributeEnum (these are READ attribute) and the set identifiers are
contained in setVarAttributeEnum. Note that NOT all these latter attributes can be written to.
They are Nextion READ only attributes and are prefixed with invalid, as in invalidtype.
```

DO NOT ALTER OR CHANGE ANY OF THESE Enums AS IT WILL RENDER THE LIBRARY USELESS.

<<<< Function Changes >>>>

<<< Get Numeric Values from Nextion Variables >>>

The two fns below have been replaced with the two following

```
int32_t getNumVarValue(const char* varName);
int32_t getNumVarValue(const char* varName, const char* attributeName);

int32_t getVariableValue(const char* varName);
int32_t getVariableValue(const char* varName, varAttributeEnum attributeId);
```

<<< Set data in Nextion Variables >>>

```
bool setNumVarValue(const char* varName, int32_t var);
```

has been replaced with setVariableValue in three forms:

```
a) bool setVariableValue( const char* varName, setVarAttributeEnum setAttributeId, int32_t var);
b) bool setVariableValue( const char* varName, const char* var, bool terminateText = true );
c) bool setVariableValue( const char* varName, int32_t var);
```

a: is used to set a numeric value into a variable attribute, be it .val, .bco. infact any of the non read only attributes.  
c: is used to set the value of global variables. These, such as sys0, sys1,etc, do not have an attributee.  
b: is used to set text to a variable. No attribute id is required since it can only be txt and this is added automatically.

The third parameter terminateText is used to indicate whether the trailing " should be sent.

If you just want to set a button's text (say b10) to Button #10 then use:-

```
setVariableValue( "b10", "Button #10" );
```

if on the other hand you want to name the button with data from a variable you might use:-

```
uint32_t number1 = 99;
setVariableValue( "b10", "Button #", false );
sendNumberAsText( number1 );
```

sendNumberAsText is a new command and just echoes the number to the Nextion. Again it has the option to terminate the Text stream with a " or not. You might want to append something else to the text string after the number.

Complementing sendNumberAsText is sendText. This works in the same way appending txt to the text string.

```
bool sendNumberAsText( uint32_t num, bool terminate = true );
bool sendText( const char* txt, bool terminate = true );
```

NOTE: The data is NOT confirmed to the Nextion ( by sending three FF ) until such time as the string is terminated.

If you forget to terminate any txt commands, it will automatically be terminated with any other get or set functions.

set setGlobalNumVarValue in it's two forms have been replaced by setGlobalVariableValue in three forms.

They work the same as setVariableValue described above, except the variable name is replaced with its global identifiers p and b as in p[2].b[33].val=2467

```
bool setGlobalNumVarValue( uint8_t p, uint8_t b, int32_t var);
bool setGlobalNumVarValue( uint8_t p, uint8_t b, const char* sub, int32_t var);
```

```
A) bool setGlobalVariableValue( uint8_t p, uint8_t b, setVarAttributeEnum setAttributeId, int32_t var);
B) bool setGlobalVariableValue( uint8_t p, uint8_t b, const char* var, bool terminateText = true);
C) bool setGlobalVariableValue( uint8_t p, uint8_t b, int32_t var);
```

setStrVarValue and setGlobalStrVarValue have been deleted from the library as their function is carried out by the functions above.

Replace	setStrVarValue( "b10", "Button #" ) ;	with	setVariableValue( "b10", "Button #" );
and replace	setGlobalStrVarValue( 2, 33, "Button #" );	with	setGlobalVariableValue( 2, 33, "Button #" );

NOTE: Within the enums varAttributeEnum and setVarAttributeEnum the normal Nextion identifiers x,y,w,h have been changed to getX, getY, getW, geHh and setX, setY. setW and setH are not appropriate as they are READ ONLY.

\*/

```

#include "Arduino.h"

#pragma pack(push,1)

/*****
*      These are all the data types used to communicate with the Nextion. More correctly
*      they are the data types for data returned FROM the Nextion display.
*      Some data returns only need 4 bytes, the Id and the Nextion terminating string,
*      \0xFF\0xFF\0xFF, whilst others require much more right up to the reset fn which
*      returns two data sets in one go i.e. startUp message and ready message
*      |----- Start up message -----| |- Ready Message -|
*      0x00 0x00 0x00 0xFF 0xFF 0xFF  0x88 0xFF 0xFF 0xFF
*
*      All the comms are put into the variable nextionEvent which is of nextionEventType.
*      this consists of the Id of the message which is returned in nextionEvent.Id. The
*      remaining bytes are put into nextionEvent.reply3, or nextionEvent.reply4 etc.
*      The relevant reply type is examined to interpret the data.
*      Infact when data is returned from the Nextion it is placed in
*      nextionEvent.resetReply because this is the largest structure and can accomodate
*      all types of reply.
*      Note that there is sometimes the need to convert from little endian to big endian
*      due to Teensy and Nextion using different endians.
*****/

struct rep3Type {
    uint32_t      nextTerm;  // = 0xFFFFFFFF swap little endian to big endian =  0xFFFFFFFF00
};
struct rep4Type {
    uint8_t       pageNum;
    uint32_t      nextTerm;
};
struct rep5Type {
    uint8_t       ans[2];
    uint32_t      nextTerm;
};
struct rep6Type {
    uint8_t       pageNum;
    uint8_t       component;
    uint8_t       pressed;
    uint32_t      nextTerm;
};
struct rep7Type {
    union {
        uint8_t      ans[4];
        uint16_t     num[2];
        uint32_t     number32bit;
    };
    uint32_t      nextTerm;
};
struct rep7IntType {
    union {
        uint8_t      ans[4];
        uint16_t     num[2];
        int32_t      number32bitInt;
    };
    uint32_t      nextTerm;
};

```

```

struct rep8Type {
    union {
        uint8_t      x[2];
        uint16_t     xPos;
    };
    union {
        uint8_t      y[2];
        uint16_t     yPos;
    };
    uint8_t          pressed;
    uint32_t         nextTerm;
};

// After Reset Nextion Returns 00 00 00 FF FF followed by 88 FF FF FF
struct resetReplyType {
    // first 00 in nextionEvent char Id68
    uint32_t startup4Bytes; // 00 00 FF FF swap little endian to big endian = 0x0FFFFF0000
    uint8_t  startupByte;   // FF
    uint32_t readyReply;    // 88 FF FF FF swap little endian to big endian = 0x0FFFFFFF88
    uint32_t overflow;      // Just to allow a 4 byte buffer if extra erroneous bytes are
                           // sent during "reset" (Have Seen It in error conditions)
};

struct nextionEventType {
    uint8_t id; // *** CHANGED FROM char
    union {
        rep3Type      reply3;
        rep4Type      reply4;
        rep5Type      reply5;
        rep6Type      reply6;
        rep7Type      reply7;
        rep7IntType    reply7int;
        rep8Type      reply8;
        resetReplyType resetReply; //-- The largest Type
        uint8_t        data[sizeof(resetReplyType)]; // Just so that data can be analysed for debug purposes
    };
}; // nextionEvent;
#pragma pack(pop)

enum onOffFlashingType {
    ledOff = 0,
    ledOn, // = 1,
    ledFlashing // = 2
};

enum topMidBottomType {
    top = 0,
    mid, // = 1,
    bottom // = 2,
};

enum varAttributeEnum { type = 0,
    id,
    vscope,
    drag,
    aph,
    effect,
    sta,
    style,
    font,
    bco,

```

```

        bco2,
        pco,
        pco2,
        xcen,
        ycen,
        txt,
        txt_maxl,
        isbr,
        spax,
        spay,
        getX,
        getY,
        getW,
        getH,
// number specific
        val,
        length,
        format,
// page specific
        up,
        down,
        left,
        right,
// float Variable specific
        ws0,
        ws1,
// timer specific
        tim,
        en,
// switch specific
        dez,
        dis,
// comment box specific
        key,
// System Variables
        sysVar
};

enum setVarAttributeEnum {    invalidtype = 0,
                             invalidid,
                             invalidvscope,
                             setDrag,
                             SetAph,
                             setEffect,
                             invalidsta,
                             invalidstyle,
                             setFont,
                             setBco,
                             setBco2,
                             setPco,
                             setPco2,
                             setXcen,
                             setYcen,
                             setTxt,
                             invalidtxt_maxl,
                             setIsbr,
                             setSpax,

```

```
        setSpay,  
        setX,  
        setY,  
            invalidw,  
            invalidh,  
// number specific  
        setVal,  
        setLength,  
        setFormat,  
// page specific  
        setUp,  
        setDown,  
        setLeft,  
        setRight,  
// float Variable specific  
        setWs0,  
        setWs1,  
// timer specific  
        setTim,  
        setEn,  
// switch specific  
        setDez,  
        setDis,  
// comment box specific  
        invalidkey,  
// System Variables  
        setSysVar
```

```
}
```



```

/*****
*
*      This is an explanation of the data returned from the Nextion.
*      I think it's self explanatory, but then I wrote it!!
*      There is the Id returned by the Nextion, followed by the number of following bytes,
*      followed by an explanation of those bytes. It is only because we have this
*      information that this library was able to be written. All is based upon this info.
*
*****/
/*
      /----- Id Codes Returned by Nextion
      /
      /----- Number of Char/Bytes returned after Id Char/Byte
      /
      /----- Char/Bytes returned after Id Char/Byte
      /
      |-----| */
const uint8_t nextionStartUp      = 0x00; // 5      0x00 0x00 0x00 0xFF 0xFF 0xFF      Returned when Nextion has started or
      //                                     reset
const uint8_t instructionSuccess  = 0x01; // 3      0x01 0xFF 0xFF 0xFF      (ONLY SENT WHEN bkcmd = 1 or 3)
const uint8_t touchEvent          = 0x65; // 6      0x65 0x00 0x01 0x01 0xFF 0xFF 0xFF      Returned when Touch occurs
      //                                     data: Page 0, Component 1, Pressed      Returns page, component and pressed
      //                                     or not, 0 or 1
const uint8_t currentPageNumber   = 0x66; // 4      0x66 0x01 0xFF 0xFF 0xFF      Returned when the sendme command is used.
      //                                     data : page 1
const uint8_t touchCoordinateAwake = 0x67; // 8      0x67 0x00 0x7A 0x00 0x1E 0x01 0xFF 0xFF 0xFF      Returned when sendxy = 1 and not
      //                                     data: (122, 30) Pressed      in sleep mode
const uint8_t touchCoordinateSleep = 0x68; // 8      0x68 0x00 0x7A 0x00 0x1E 0x01 0xFF 0xFF 0xFF      Returned when sendxy = 1 and
      //                                     data: (122, 30) Pressed (0 for NOT pressed)      exiting sleep
const uint8_t stringDataEnclosed  = 0x70; // 0      means variable amount
      //                                     0x70 0x61 0x62 0x31 0x32 0x33 0xFF 0xFF 0xFF      Returned when using get command
      //                                     data: ab123      for string.
const uint8_t numericDataEnclosed = 0x71; // 7      0x71 0x01 0x02 0x03 0x04 0xFF 0xFF 0xFF      Each byte is converted to char.
      //                                     data: 67305985      Returned when get command to
      //                                     return a number
const uint8_t autoEnteredSleepMode = 0x86; // 3      0x86 0xFF 0xFF 0xFF      4 byte 32 bit value in little endian Order.
      //                                     Returned when Nextion enters sleep
      //                                     automatically.
const uint8_t autoAwakeFromSleepMode = 0x87; // 3      0x87 0xFF 0xFF 0xFF      Using sleep = 1 will not return an 0x86
      //                                     Returned when Nextion leaves sleep
      //                                     automatically
const uint8_t nextionReady        = 0x88; // 3      0x88 0xFF 0xFF 0xFF      Using sleep = 0 will not return an 0x87
      //                                     Returned when Nextion has powered up and is
      //                                     now initialized successfully
const uint8_t powerOnMicroSDCardDet = 0x89; // 3      0x89 0xFF 0xFF 0xFF      Returned when power on detects inserted
      //                                     microSD and begins Upgrade by microSD process.
const uint8_t transparentDataFin  = 0xFD; // 3      0xFD 0xFF 0xFF 0xFF      Returned when all requested bytes of
      //                                     Transparent Data mode have been received,
      //                                     and is now leaving transparent data mode
      //                                     (See 1.16)

```

```

const uint8_t transparentDataReady = 0xFE; // 3 0xFE 0xFF 0xFF 0xFF
//
// (see 1.16)
Returned when requesting Transparent Data
mode, and device is now ready to begin
receiving the specified quantity of data

/*****
*
* Below are the error codes returned by the Nextion
* Whether they are returned or not depends upon the value by the Nextion bkcmd.
* This can be set to Level 0 ... to Level 3. Below are shown the bkcmd level at which
* the error/state message is returned. The default is Level 2.
*
*****/

/* Error/event codes (ONLY 0x01 is an event code)

/----- Error/Event Code
/----- Error/Event Code returned when bkcmd equals value shown

const uint8_t invalidInstruction = 0x00; // bkcmd 2,3 0x00 0xFF 0xFF 0xFF Returned when instruction sent by user has failed
//const uint8_t instructionSuccess = 0x01; // bkcmd 1,3 0x01 0xFF 0xFF 0xFF (ONLY SENT WHEN bkcmd = 1 or 3 )
const uint8_t invalidComponentId = 0x02; // bkcmd 2,3 0x02 0xFF 0xFF 0xFF Returned when invalid Component ID or name was used
const uint8_t invalidPageId = 0x03; // bkcmd 2,3 0x03 0xFF 0xFF 0xFF Returned when invalid Page ID or name was used
const uint8_t invalidPictureId = 0x04; // bkcmd 2,3 0x04 0xFF 0xFF 0xFF Returned when invalid Picture ID was used
const uint8_t invalidFontId = 0x05; // bkcmd 2,3 0x05 0xFF 0xFF 0xFF Returned when invalid Font ID was used
const uint8_t invalidFileOperation = 0x06; // bkcmd 2,3 0x06 0xFF 0xFF 0xFF Returned when File operation fails
const uint8_t invalidCrc = 0x09; // bkcmd 2,3 0x09 0xFF 0xFF 0xFF Returned when Instructions with CRC validation fails
// their CRC check
const uint8_t invalidBaudRateSetting = 0x11; // bkcmd 2,3 0x11 0xFF 0xFF 0xFF Returned when invalid Baud rate was used
const uint8_t invalidWaveformIdChan = 0x12; // bkcmd 2,3 0x12 0xFF 0xFF 0xFF Returned when invalid Waveform ID or Channel # was used
const uint8_t invalidVarNameAttrib = 0x1A; // bkcmd 2,3 0x1A 0xFF 0xFF 0xFF Returned when invalid Variable name or invalid
// attribute was used
const uint8_t invalidVarOperation = 0x1B; // bkcmd 2,3 0x1B 0xFF 0xFF 0xFF Returned when Operation of Variable is invalid.
// ie: Text assignment t0.txt = abc or t0.txt = 23,
// or Numeric assignment j0.val = "50?" or j0.val = abc
const uint8_t assignmentFailed = 0x1C; // bkcmd 2,3 0x1C 0xFF 0xFF 0xFF Returned when attribute assignment failed to assign
const uint8_t EEPROMOperationFailed = 0x1D; // bkcmd 2,3 0x1D 0xFF 0xFF 0xFF Returned when an EEPROM Operation has failed
const uint8_t invalidQtyParams = 0x1E; // bkcmd 2,3 0x1E 0xFF 0xFF 0xFF Returned when the number of instruction parameters is
// invalid
const uint8_t ioOperationFailed = 0x1F; // bkcmd 2,3 0x1F 0xFF 0xFF 0xFF Returned when an IO operation has failed
const uint8_t invalidEscapeChar = 0x20; // bkcmd 2,3 0x20 0xFF 0xFF 0xFF Returned when an unsupported escape uint8_tacter is used
const uint8_t variableNameTooLong = 0x23; // bkcmd 2,3 0x23 0xFF 0xFF 0xFF Returned when variable name is too long.Max length is
// 29 characters: 14 for page + "." + 14 for component.
const uint8_t serialBufferOverflow = 0x24; // always 0x24 0xFF 0xFF 0xFF Returned when a Serial Buffer overflow occurs
// Buffer will continue to receive the current instruction,
// all previous instructions are lost.

```

```

/*
 * Error code generated by this library when incorrect number of characters returned by Nextion
 */
const uint8_t errorReadingPageNumber = 0x3B;
const uint8_t errorReadingNumber     = 0x3C;
const uint8_t errorReadingNumber_1   = 0x3D;
const uint8_t errorReadingNumber_2   = 0x3E;
const uint8_t invalidNumCharsReturned = 0x3F;

enum bkcmdStateType {
    noReturn,//      = 0,
    onSuccess,      // = 1,
    onFailure,      // = 2 Default
    always          // = 3
};

const uint8_t boilerButton      = 5;
const uint8_t hwButton         = 6;

class Stream;

class Nextion2 {
public:
    typedef void (*setNextionBaudCallbackFunc) (uint32_t); // create function pointer type
    typedef void (*nextionTurnValveOnOffCallbackFunc) (uint32_t, bool); // create function pointer type
    typedef void (*setMcuDateTimeCallbackFunc) (); // create function pointer type
    typedef void (*systemResetCallbackFunc) (); // create function pointer type
    typedef void (*buttonPressCallbackFunc) (uint32_t); // create function pointer type

    const char          revision[5]          = "2.01";
    const uint16_t      revisionNum          = 201;

    uint32_t            baudRate              = 9600;
    const uint32_t      resetNextionBaud      = baudRate;
    uint32_t            recoveryBaudRate      = baudRate; // used for recovery when changing baud rate does not work
    bool               nextionError          = false;
    bool               cmdExecOk              = false; // only used for bkcmd = 1 or 3
    bool               stringWaiting          = false;
    uint8_t            errorCode              = instructionSuccess;
    bkcmdStateType     bkcmd                  = onFailure;
    uint32_t            getNumVarTimeout      = 1000;
    uint32_t            getStrVarTimeout      = 1000;
    uint32_t            getEPromDataTimeout  = 1000;
    bool               eepromDataChanged     = true;
    bool               nextionDateTimeUpdt    = false;
    uint32_t            packedDateTime        = 0;
    int32_t            sndDateTimeHotSPage    = 0;
    bool               daylightSaving         = false;

    nextionEventType    nextionEvent;

    // s is the serial stream to use e.g. Serial1
    Nextion2(Stream* s);

```

```

/*****
*
*                                     Description of Nextion Public Variables
*
*****/
*
*      baudRate          = 9600;      The baud rate used for Nextion Comms.
*      resetNextionBaud  = baudRate;  The baud rate used after a reset. Needs to match
*                                     the value used in Program.s if changed from the default 9600
*      recoveryBaudRate  = baudRate;  Used for recovery when changing baud rate doesn't work.
*      nextionError      = false;     Returns true if a Nextion error has occurred
*      comdExecOk        = false;     // only used for bkcmd = 1 or 3
*      stringWaiting     = false;     Returns true if a string has been collected from Nextion.
*      errorCode         = instructionSuccess; Error code returned if nextionError is true.
*      bkcmd             = onFailure; NOT TESTED FOR CHANGE FROM THIS DEFAULT SETTING.
*      getNumVarTimeout  = 1000;      Timeout (mS) for getting numeric value from Nextion
*      getStrVarTimeout  = 1000;      Timeout (mS) for getting string result from Nextion
*      getEPromDataTimeout = 1000;    Timeout (mS) for getting Eeprom data from Nextion.
*      eepromDataChanged = true;      Returns true if Eeprom data has changed and should be read
*                                     from Nextion using getEEPromData.
*                                     Using this sets eepromDataChanged to false.
*      packedDateTime    = 0;         The variable used to hold the packed date/time returned
*                                     from the Nextion.
*      nextionDateTimeUpdt = false;   The date/time has been changed on the Nextion.
*                                     and automatically collected into packedDateTime.
*                                     If setMcuDateTimeCallback() has been used the CallBack fn
*                                     will be used to set the mcuDate/Time.
*                                     If false getDateTime() will need to be used to get the
*                                     date/time.
*                                     This will set nextionDateTimeUpdt to false.
*      sndDateTimeHotSPage = 0        The page nuumber holding the sndDateTime Hotspot.
*      daylightSaving     = false     Set when time from Nextion packedDateTime decoded.
*
*****/

```

```

/*****
*
*                                     Description of Nextion functions
*
*****/

/*****
*
*   begin(uint32_t br, setNextionBaudCallbackFunc func = nullptr) - passes the Nextion
*   baud rate to the library. This is put into the variable baudRate. No changes to the
*   baudRate are made by this Function. Also, if passed, sets the call back function
*   so that this library can have control over the Teensy baudrate.
*   Turns on automatic control of Teensy baudrate if passed.
*
*-----
*
*   Usage:
*
*       begin( baudRate ) - autoSetting of Teensy baud rate set off.
*       begin( baudRate, setNextionBaud ) - passes the baud rate and function to change
*                                           Teensy baudRate.
*
*****/

void begin(uint32_t br, setNextionBaudCallbackFunc func = nullptr);

/*****
*
*   sendCommand(const char* command); - Sends command to Nextion.
*   sendCommand(const char* command, uint32_t num); - Sends command & num to Nextion.
*   sendCommand(const char* command, uint32_t txt, encloseText); - Sends command & txt
*
*-----
*
*   In the 3rd form above, if encloseTxt is true then txt is enclosed between
*   quotation marks ".
*   So sendCommand( "page0.CommentBox.txt=", "Hello There", true); results in
*   page0.CommentBox.txt="Hello There"\xFF\xFF\xFF being sent to the Nextion.
*
*-----
*
*   Sends the command to Nextion. If bkcmd level has been set to 1 or 3 the code is
*   setup to look for a response from the Nextion.
*   if bkcmd set to 1 or 3, use the command lastComdCompletedOk(uint32_t timeout)
*   below after a command or before the next command to determine that the (last)
*   command completed ok.
*
*****/

void sendCommand(const char* command);
void sendCommand(const char* command, uint32_t num);
void sendCommand(const char* command, const char* txt, bool encloseText);

/*****
*
*   setBkCmdLevel(bkcmdStateType level) - Sets Nextion bkcmd value
*
*-----
*
*   The default value is onFailure (2)
*   When set to 1 or 3, use the command bool lastComdCompletedOk(uint32_t timeout)
*   below after a command or before the next command to determine that the (last)
*   command completed ok.
*   level is ONLY allowed to be 1 or 3 if compiled with #define bkcmdlor3allowed in
*   Nextiopn.cpp.
*
*****/

void setBkCmdLevel(bkcmdStateType level);

```

```

/*****
*      setNextionBaudRate(uint32_t br) - Sets the baud rate on Nextion and Teensy.
*-----
*      This routine saves the current baud rate in a variable recoveryBaudRate so that
*      this recoveryBaudRate can be tried first by the recoverNextionComms() function
*      thus saving some time in the recovery.
*      In order for this function to work correctly it requires that the
*      setNextionBaudCallbackFunc was passed to the Library with the Nextion.display.begin
*      function. If not it will be the responsibility of the calling program to set the
*      Teensy BaudRate accordingly.
*****/
void setNextionBaudRate(uint32_t br);

/*****
*      lastComdCompletedOk(uint32_t timeout) - ret true/false if last comd completed ok
*-----
*      This command is to be used if bkcmd level is set to 1 or 3 and ONLY where a
*      command is used to set a state on the Nextion.
*      Where a request for information      is sent to nextion, as in "get varName", the
*      returned value is the handshake.
*      If other values are used (0 or 2) it is transparent and will return true.
*      This is not an indication that the command completed ok as handshaking is off.
*****/
bool lastComdCompletedOk(uint32_t timeout);

/*****
*      Set the Text Area to be used for the Return of Text data from Nextion
*      If text is sent from the Nextion (following the 0x70 identifier) it will be
*      sent to SerialUSB if this function has not been used to specify a variable
*      to hold the text data. The parameter must be the size of the textBuffer
*      variable. If more text is returned than there is space for in textBuffer
*      it will be sent to the SerialUSB.
*-----
*      Usage:   setTextBuffer( textBuffer, sizeof( textBuffer ));
*****/
void setTextBuffer(/*const*/ char* textBuffer, uint8_t textBufferSize);

/*****
*      Set the EEPROM Data Area to be used for the Return of EEPROM data from Nextion by
*      the fn bool getEEPromData(uint32_t start, uint32_t len)
*-----
*      Usage:   setEEPromDataBuffer( eepromDataBuffer, sizeof(eepromDataBuffer));
*****/
void setEEPromDataBuffer(/*const*/ char* eepromDataBuffer, uint8_t eepromBufferSize);

/*****
*      clearBuffer() - Clears the Teensy (Nextion) serial input.
*      Use where things have perhaps gone wrong and you need to clear out erroneous
*      replies.
*****/
void clearBuffer();

```

```

/*****
*      commsOk() - Checks that valid communications exist with the Nextion Display.      *
*      It sends the command "sendme\xff\xff\xff" and looks for a reply. It does not look *
*      for the page number for a reply, because comms may have been lost due to using   *
*      the wrong baud rate, in which case a reply might be 0x23FFFFFF - variable name  *
*      too long or some other error reply. Instead it looks for any valid reply.      *
*****/
bool commsOk();

/*****
*      reset(baudRate) - Resets the Nextion Display and sets the baud rate to "baudRate" *
*-----*
*      Sends a reset command to the Nextion. Sets the Teensy baud rate to 9600 if that  *
*      baud rate NOT already in use. ( upon reset the Nextion defaults to this baud rate ) *
*      and waits for a valid reply. The Teensy baud rate is set using the callBack     *
*      function registered using the display.begin function.                          *
*      When a valid reply has been seen the Nextion AND Teensy have the buadRate changed *
*      to the baud rate passed in the function call.                                *
*      The function returns true if valid comms with the Nextion can be established.    *
*      Sets bkcmd to onFailure (Default)                                              *
*-----*
*      Usage:
*      reset() - If no baud rate is passed then the baudRate defaults to the reset 9600 *
*      reset(1) - Sets the Baud Rate to that in use at the entry to the Reset function. *
*      reset(115200) - Will do a reset and set the baudRate to 115200.               *
*****/
bool reset(uint32_t br = 0);

/*****
*      recoverNextionComms() - attempts to recover Nextion Comms once they have been lost *
*-----*
*      First sets the Teensy baud rate to the recoverBaudRate (see setNextionBaudRate   *
*      below). Uses the commsOK function to determine that comms have been re-established. *
*      If that does not work then all the baud rates that the Nextion might use are cycled *
*      through until a valid baud rate can be found.                                *
*      Returns the value of the baud rate found.                                    *
*      If NO valid baud rate can be found then returns 0.                            *
*****/
uint32_t recoverNextionComms();

```

```

/*****
*      Check if char(s) returned from Nextion. If not do something else and come back      *
*      later to check again. Wait for timeout. Default is 0..don't wait.                  *
*-----*
*      If there is a reply from Nextion then the Reply Char is received and the required   *
*      number of following char/bytes dependent upon the value of the Id.                *
*      The Id char is placed in nextionEvent.id.                                         *
*      The remaining chars are placed in nextionEvent.reply8 ready to be decoded.        *
*      True is returned if there is an Id char and the required number of chars         *
*      are returned. Otherwise, false is returned.                                     *
*      If the first char is received within timeout a further timeout of 1 second        *
*      is allowed for remaining characters.                                              *
*      This proc does NOT get any strings returned from Nextion,Use respondToReply()     *
*      for that.                                                                        *
*****/
bool getReply(uint32_t timeout = 0);

/*****
*      respondToReply() - returns true if something needs responding to.                  *
*-----*
*      This is where you need to put your code. Use getReply() to get any info from the  *
*      Nextion (see above) and this function to decode the reply and respond to it.      *
*      It returns true if further response is needed.                                  *
*-----*
*      I like to have requests from the Nextion Display embedded into numbers. Within this *
*      code I want to turn valves on or off. The number returned by the Nextion contains  *
*      the valve to be moved and whether it should be opened or closed (0 or 1)         *
*      If you have handled the Nextion response fully then set needsResponse to false.   *
*****/
bool respondToReply();

/*****
*      printAnyReturnCharacters(uint32_t nextionTime, uint8_t id).                        *
*      This function is intended to be used in debugging your code. It prints out to the  *
*      SerialUSB the value "nextionTime" and "Id", both values that might be useful in   *
*      tracking down where your error occurred, followed by any values that are in the    *
*      Serial input stream from the Nextion.                                           *
*      It might be that you have used "respondToReply", with your code in it, but still  *
*      there is something being returned that needs to be responded to. Use this function *
*      to see what unexpected data is being sent from the Nextion Display.             *
*      ALL data is output in HEX.                                                       *
*****/
void printAnyReturnCharacters(uint32_t nextionTime, uint8_t id);

```



```

/*****
*      setNextionBaudRate(uint32_t br) - Sets the baud rate on Nextion and Teensy.      *
*-----*
*      This routine saves the current baud rate in a variable recoveryBaudRate so that  *
*      recoveryBaudRate can be tried first by the recoverNextionComms() function,      *
*      thus saving some time in the recovery.                                         *
*      In order for this function to work correctly it requires that the               *
*      setNextionBaudCallbackFunc was passed to the Library with the Nextion.display.begin *
*      function. If not it will be the responsibility of the calling program to set the *
*      Teensy BaudRate accordingly.                                                  *
*****/
void setNextionBaudRate(uint32_t br);

/*****
*      gotoPage(uint32_t which); - Sets which is active displayed page.              *
*****/
void gotoPage(uint32_t which);

/*****
*      getPage(); - Returns the number of the active displayed page.                  *
*      On Error besides setting nextionError to true also returns 255 as page number and *
*      errorCode is set to errorReadingPageNumber.                                  *
*****/
uint8_t getPage();

/*****
*      setBackLight(uint32_t backLight) - Sets the display BackLight(0..100).        *
*-----*
*      Any value greater than 100 will default to 100.                             *
*      0 is off 100 is MAX brightness.                                              *
*****/
void setBackLight(uint32_t backLight);

```

```

/*****
*      getVariableValue(const char* varName, varAttributeEnum attributeId);
*      - Gets the value of Nextion Variable given by the attributeId.
*
*-----
*      Waits for up to 1000ms for a reply. If no reply returns -1.
*      The wait time is controlled by the variable getNumVarTimeout which is initially
*      set to 1000 ms.
*      Since -1 can also be a valid return value nextionError is set on error and the
*      error is reported in errorCode as errorReadingNumber.
*
*-----
*      In reality this command should only be sent when the Nextion Serial buffer is
*      empty, otherwise, any reply may be from previously stacked up Nextion commands
*      and therefore be erroneous.
*
*-----
*      NOTE: That if the attribute id is 'txt' then the getStringVarValue fn will be used to
*      get the string. The result is placed in the string setup with the setTextBuffer fn.
*      If no string has been setup it will simply be echoed to the screen (Serial).
*      Returns true if string returned successfully. stringWaiting is also set to true.
*      The numeric value returned will be 0 or 1.
*      In reality it would be better to use the getStringVarValue fn if a string is
*      required.
*
*-----
*      In the second case returns the value of a System Variable which have no attribute.
*      System Variable are declared in Program.S such as sys0, sys1 etc.
*
*-----
*      The varName MUST exist.
*****/
int32_t getVariableValue(const char* varName);
int32_t getVariableValue(const char* varName, varAttributeEnum attributeId);

/*****
*      getNumVarFloat(const char* varName) - Gets the value of Nextion Float Variable.
*
*-----
*      getNumVarFloat uses getNumVarValue to get the various components of a Nextion
*      float. Wait times will be a combination of the two betNumVarValue wait times.
*      If an error occurs nextionError will be set to true and the returned value
*      should NOT be relied upon.
*      The error is reported in errorCode as errorReadingNumber_2
*
*-----
*      In reality this command should only be sent when the Nextion Serial buffer is
*      empty otherwise, any reply may be from previously stacked up Nextion commands
*      and therefore be erroneous.
*      The varName MUST exist.
*****/
float_t getNumVarFloat(const char* varName);

```

```

/*****
*      getStringVarValue(const char* varName) - Gets the text from Nextion Variable.      *
*-----*
*      Waits for up to 1000ms for a reply. If no reply returns false.                  *
*      The wait time is controlled by the variable getStrVarTimeout which is initially  *
*      set to 1000 ms.                                                                *
*-----*
*      In reality this command should only be sent when the Nextion Serial buffer is   *
*      empty, otherwise any reply may be from previously stacked up Nextion commands  *
*      and therefore be erroneous.                                                    *
*      The varName MUST exist.                                                        *
*-----*
*      The result is placed in the string setup with the setTextBuffer function.      *
*      If no string has been setup it will simply be echoed to the screen (Serial).    *
*      Returns true if string returned successfully. stringWaiting is also set to true. *
*-----*
*      NOTE there is no need to send the ".txt" suffix to the string variable.        *
*      getStringVarValue("va0") will send "get va0.txtFFFFFF" to the Nextion and wait for *
*      an answer.                                                                    *
*****/
bool getStringVarValue(const char* varName);

/*****
*      bool getEEPromData(uint32_t start, uint32_t len) - Gets the EEPROM data from start for *
*      len bytes.*
*-----*
*      Waits for up to 1000ms for a reply. If no reply returns false.                  *
*      The wait time is controlled by the variable getEPromDataTimeout which is initially set to *
*      1000 ms. *
*-----*
*      In reality this command should only be sent when the Nextion Serial buffer is   *
*      empty, otherwise any reply may be from previously stacked up Nextion commands  *
*      and therefore be erroneous.                                                    *
*-----*
*      The result is placed in the EEPROMDataBuffer setup with the setEEPromDataBuffer *
*      fn returned true if len bytes collected. The number of bytes collected is placed in *
*      the global variable eepromBytesRead.                                          *
*      A valid getEPromData also sets eepromDataChanged to false.                    *
*      Initially it is set to true to force initial collection of Nextion eeprom data. *
*      If no EEPROMDataBuffer has been setup it will simply return false.            *
*****/
bool getEEPromData(uint32_t start, uint8_t len);

```

```

/*****
*      setVariableValue(const char* varNamevar, setVarAttributeEnum attributeId, int32_t var )      *
*      - Sets Nextion Variable.attributeId to var.                                          *
*-----*
*      NOTE that, if appropriate, the val varName attribute MUST be sent.                  *
*      Program.S variables DO NOT need the ".val" attribute whereas Nextion Display variables do.*
*-----*
*      For example to set a sys0 value just use setVariableValue("sys0",100); but for a      *
*      display variable va2, use setVariableValue("va2", val ,100);                        *
*-----*
*      The varName MUST exist.                                                            *
*****/
bool setVariableValue(const char* varName, setVarAttributeEnum setAttributeId, int32_t var);
bool setVariableValue(const char* varName, const char* var, bool terminateText = true);
bool setVariableValue(const char* varName, int32_t var);

/*****
*      setGlobalVariableValue( uint8_t p, uint8_t b, varAttributeEnum setAttributeId, int32_t var);*
*-----*
*      Sends p[p].b[b].val=var is sent to the nextion.                                  *
*      This fn CANNOT be used for Program.S variables                                    *
*-----*
*      The p and b id's MUST exist and be appropriate for the type of data being sent.      *
*      NOTE that p and b numbers can change when items are added or deleted from          *
*      the Nextion display rendering your program invalid.                              *
*      Much care MUST be taken when using global variables.                            *
*****/
bool setGlobalVariableValue(uint8_t p, uint8_t b, setVarAttributeEnum setAttributeId, int32_t var);
bool setGlobalVariableValue(uint8_t p, uint8_t b, const char* var, bool terminateText = true);
bool setGlobalVariableValue(uint8_t p, uint8_t b, int32_t var);

bool sendText(const char* txt, bool terminate = true );
bool sendNumberAsText(uint32_t num, bool terminate = true );

```

```

/*****
*      bool setNumVarFloat(const char* varName, float_t fvar, uint8_t dp, bool round)      *
*      - Sets Nextion Variable to fvar, with dp decimal points rounded to dp (or not).    *
*-----*
*      NOTE that the ".val" varName suffix MUST NOT be sent.                          *
*-----*
*      Usage:                                                                           *
*      if (display.setNumVarFloat( "x0", 1234.5678, 2, true ) {... displays 1234.57 in x0.*
*      if (display.setNumVarFloat( "x0", 1234.5678, 2, false ) {... displays 1234.56 in x0.*
*-----*
*      The varName MUST exist.                                                         *
*****/
bool setNumVarFloat(const char* varName, float_t fvar, uint8_t dp, bool round);

/*****
*      askSerialBufferClear() - Ask Nextion if Serial Buffer Clear (Empty)              *
*-----*
*      Sends "get clrBuf" to Nextion. Nextion will reply with 0xFDFD when it gets to    *
*      this request in the SerialBuffer, indicating it has executed this last command   *
*      in the Serial Buffer. If other commands are sent after this one the Serial      *
*      Buffer WILL NOT BE CLEAR.                                                         *
*      Use the command isSerialBufferClear(), below to confirm Serial Buffer Clear.     *
*      Requires this line "int clrBuf=65021" in Nextion Program.s                      *
*****/
void askSerialBufferClear();

/*****
*      isSerialBufferClear() - Query answer from askSerialBufferClear() above          *
*-----*
*      NOTE that if other commands are stacked up which will give a reply from Nextion, *
*      then they will be handled by the calls to getReply and respondToReply used by   *
*      this function. They may return a reply, but if it is NOT a Numeric reply with   *
*      0xFDFD they will NOT return true.                                               *
*****/
bool isSerialBufferClear();

/*****
*      bool askSerialBufferClear(uint32_t timeout) - As above but waits for a reply    *
*-----*
*      Combines askSerialBufferClear() and isSerialBufferClear() with a timeout to     *
*      determine if the Nextion input Serial Buffer is Clear.                         *
*****/
bool askSerialBufferClear(uint32_t timeout);

/*****
*      turnNextionButton(uint8_t which, bool on)                                     *
*      I have Nextion buttons named Sw0..Sw6. I use this function to set the relevant  *
*      button on (1) or off (0)                                                       *
*      I have ghosted this function with the phrase "turnNextionValve" since some of the *
*      buttons are controlling valves and it makes more sense in the code to refer to  *
*      them as valves.                                                                *
*****/
#define turnNextionValve turnNextionButton

```

```

void turnNextionButton(uint8_t which, bool on);

/*****
*      setHotWaterOnForMins (uint8_t howLong)
*-----*
*      This is somewhat clever. Teensy sets the hot water on and sends a command to the
*      Nextion to turn off the hot water in "howLong" minutes.
*      When the Nextion receives this command (via a numeric value in a Number Variable)
*      it turns the display for the valve open "on" and when the timeout occurs it sends
*      a command to the Teensy to turn off the hot water. This is done via the callback
*      setup via the setValveCallback(nextionTurnValveOnOffCallbackFunc func) function.
*      Thus some timing control is offloaded to the Nextion.
*****/
void setHotWaterOnForMins (uint8_t howLong);

/*****
*      setTime(uint32_t time) - Sets the time on the Nextion.
*-----*
*      The time is sent as HEX HHMMSS in the variable "SetTime=HHMMSS0xFF0xFF0xFF"
*      When the Nextion sees that SetTime is not zero it sets the Nextion time.
*      The SetTime variable is then set to 0.
*-----*
*      Usage:
*          uint32_t time = Hours * 0x10000 + Minutes * 0x100 + Seconds
*          display.setTime(time)
*****/
void setTime(uint32_t time);

/*****
*      setDate(uint32_t date) - Sets the date on the Nextion.
*-----*
*      The time is sent as HEX YYMMDD in the variable "page0.SetDate=YYMMDD0xFF0xFF0xFF"
*      When the Nextion sees that StDate is not zero it sets the Nextion date.
*      The StDate variable is then set to 0.
*-----*
*      Usage:
*          uint32_t date = (Year-2000) * 0x10000 + Month * 0x100 + Day
*          display.setDate(date)
*****/
void setDate(uint32_t date);

```

```

/*****
*      getDateTime() - Gets the date and Time from Nextion.      *
*-----*
*      Gets the Date/Time set in the Nextion.      *
*      The packed date/time is placed in the global variable packedDateTime.      *
*      It can be decoded as shown below:      *
*-----*
*      dow      =  packedDateTime >> 29;      // (sun=0)      *
*      dst      =  ( packedDateTime >> 28 ) & 0x01;      (known as BST in the UK)      *
*      year     =  ( packedDateTime >> 21 ) & 0x7F + 2000;      *
*      month    =  ( packedDateTime >> 17 ) & 0x0F;      *
*      day      =  ( packedDateTime >> 12 ) & 0x1F;      *
*      hour     =  ( packedDateTime >> 6 ) & 0x1F;      *
*      minute   =  ( packedDateTime )      & 0x3F;      *
*-----*
*      NOTE: This fn should only be called when the page holding the hotspot SndDateTime      *
*      is displayed. On the new example HMI file it is on page 0.      *
*-----*
*      Usage:      *
*      display.getDateTime()      *
*****/
bool getDateTime();

/*****
*      turnDebugOn(bool on) - Turn Nextion debug variable on or off      *
*-----*
*      Usage:      *
*      turnDebugOn( true ) - Turn debug on      *
*      turnDebugOn( false ) - Turn debug off      *
*****/
bool turnDebugOn(bool on);

/*****
*      setScreenDimTime(uint32_t dimTime) - Sets the time, in seconds, after which the      *
*      screen will dim if screen dimming is turned on.      *
*      The default is 3 minutes.      *
*****/
bool setScreenDimTime(uint32_t dimTime);

/*****
*      turnScreenDimOn(bool on) - Turn Nextion dimAllowed variable on or off      *
*-----*
*      Usage:      *
*      turnScreenDimOn( true ) - Turn Dim on      *
*      turnScreenDimOn( false ) - Turn Dim off      *
*****/
bool turnScreenDimOn(bool on);

```

```

/*****
*      printAnyReturnCharacters(uint32_t nextionTime, uint8_t id).
*      This function is intended to be used in debugging your code. It prints out to the
*      SerialUSB the value "nextionTime" and "Id", both values that might be useful in
*      tracking down where your error occurred, followed by any values that are in the
*      Serial input stream from the Nextion.
*      It might be that you have used "respondToReply", with your code in it, but still
*      there is something being returned that needs to be responded to. Use this function
*      to see what unexpected data is being sent from the Nextion Display.
*      ALL data is output in HEX.
*****/
void printAnyReturnCharacters(uint32_t nextionTime, uint8_t id);

/*****
*      setValveCallBack(nextionTurnValveOnOffCallbackFunc func) - passes the Nextion the
*      call back function      tu turn a valve on or off
*****/
void setValveCallBack(nextionTurnValveOnOffCallbackFunc func);

/*****
*      setMcuDateTimeCallback(setMcuDateTimeCallbackFunc func) - passes the Nextion the
*      call back fn to Set the MCU date and time. It also sets autoUpdateDateTime to true.
*      This setMcuDateTimeCallbackFunc is called when Nextion reports a change in date/time
*****/
void setMcuDateTimeCallback(setMcuDateTimeCallbackFunc func);

/*****
*      setSystemResetCallback(systemResetCallbackFunc func) - passes the Nextion the
*      call back fn to carry out a System Reset.
*****/
void setSystemResetCallback(systemResetCallbackFunc func);

/*****
*      setButtonPressCallback(buttonPressCallbackFunc func) - passesm to Nextion then
*      call back fn to carry out a button # which press event.
*****/
void setButtonPressCallback(buttonPressCallbackFunc func);

/*****
*      setLedState - Sets the state of the leds in top, middle or bottom Row.
*      which = led (0..7) and state is on (1), off (0) or flashing (2).
*      -----
*      Just sets the state in variable holding leds row state. There is no change
*      to the leds display until setNextionLeds( row ) is used.
*      -----
*      Usage:      setLedState( mid, 4, flashing );
*****/
void setLedState(topMidBottomType whichLed, uint8_t which/*0..7*/, onOffFlashingType state);

```



```

/*****
*      setNextionLeds actually sends command to Nextion to change the state of
*      which leds ( top, middle or bottom row ) set with setLedState function above.
*-----*
*      Usage:  setNextionLeds( top );
*****/
void setNextionLeds(topMidBottmType which);

/*****
*      clearLeds sets the leds state variable to all (top, middle and bottom) off.
*      Uses setNextionLeds to send command to update all rows on Nextion.
*-----*
*      void clearLeds();
*****/
/*****
*      click(const char* objectToClick, bool touch)
*      click(uint8_t page, const char* objectToClick, bool touch)
*-----*
*      Two options, the first assumes that the Nextion is on the page where the item to be
*      clicked is located, trhe second version will actually change to the page given
*      before execuring the click function.
*-----*
*      Usage: click("MyFavouriteHotspot", true ) sends click MyFavouriteHotSpot,1
*      to cause a Touch Press Event, passing false would cause a TouchRelease event.
*      Or: click(4, "MyFavouriteHotspot", true ) sends:-
*              page(4)
*              click MyFavouriteHotSpot,1
*****/
bool click(const char* objectToClick, bool touch);
bool click(uint8_t page, const char* objectToClick, bool touch);

/*****
*      printTimeEmbeddedTextToNextion - Sends Text to Nextion to be placed in variable
*      page0.msg.txt. If transmit is set to true the text is terminated with a "
*      character and m0,1 is clicked to cause the screen on pagel to be updated using
*      the finishNextionTextTransmittion() command (see below).
*      The procedure sends page0.msg.txt=" to the Nextion followed by the text.
*-----*
*      Usage: printTimeEmbeddedTextToNextion( "This is a load of text for pagel", true );
*-----*
*      A string representing the Nextion time in the format " HH:MM:SS " is inserted
*      AFTER the first character.      This is carried out by the Nextion display.
*****/
void printTimeEmbeddedTextToNextion(const char* p, bool transmit);

```

```

/*****
*      printTextToNextion - Sends Text to Nextion to be placed in variable      *
*      pagel.va0.txt. If transmit is set to true the text is terminated with a "  *
*      character and m0,0 is clicked to cause the screen on pagel to be updated using *
*      the finishNextionTextTransmittion() command (see below).                  *
*      The procedure sends pagel.va0.txt=" to the Nextion followed by the text.    *
*-----*
*      Usage:  printTextToNextion( "This is a load of text for pagel", true );    *
*****/
void printTextToNextion(const char* p, bool transmit);

/*****
*      printMoreTextToNextion - It is the same as the printTextToNextion function except *
*      that the page0.msg.txt=" is NOT sent.                                     *
*-----*
*      Usage:  printMoreTextToNextion( "This is a load of text for pagel", true ); *
*      NOTE: DO NOT use this without first using printTextToNextion( "text", false ); *
*****/
void printMoreTextToNextion(const char* p, bool transmit) {

/*****
*      printNumericText - Sends number to Nextion. This command MUST have been preceded *
*      by the printTextToNextion command shown above. If transmit is set to true the text *
*      is terminated with a "character and m0 is clicked to cause the screen on pagel to *
*      be updated using the finishNextionTextTransmittion() command (see below).      *
*-----*
*      Usage:  printNumericText( n, true ); // where n is a uint32_t              *
*      NOTE: DO NOT use this without first using printTextToNextion( "text", false ); *
*****/
void printNumericText(uint32_t num, bool transmit);

```

```

/*****
*      finishNextionTextTransmittion() - Terminate the text transmitted to Nextion with a
*      " character and terminate the command correctly. Also issues the relevant
*      click m0 command dependant upon which printText command was used to cause the
*      screen on page1 to be updated.
*      ( Uses "click m0,1" or "click m0,0" as appropriate )
*-----
*      Usage:   finishNextionTextTransmittion()
*****/
void finishNextionTextTransmittion();

/*****
*      I like to keep a monitor of what has happened in the system. This display is on
*      page1 of the Nextion display. I use the first character position to indicate the
*      type of message/source of message. e.g. C for command, E for error message. After
*      this character I inser the Time in " HH:MM:SS " format. This is done by the
*      Nextion Display.
*-----
*      printCommandOrErrorTextMessage - sends the commandOrError charater followed by the
*      textMessage to the Nextion using the printTextToNextion command above.
*      If transmit is set to true the text is terminated with a "character and m0 is
*      clicked to cause the screen on page1 to be updated using the
*      finishNextionTextTransmittion() command (see above).
*****/
void printCommandOrErrorTextMessage(const char* commandOrError, const char* textMessage, bool transmit);

/*****
*      preserveTopTextLine() - Top text line writing inhibited.
*-----
*      All general text commands do not use top line if this command actuated.
*****/
void preserveTopTextLine();

/*****
*      writeToTopTextLine(const char* textMessage)
*****/
void writeToTopTextLine(const char* textMessage);

/*****
*      releaseTopTextLine() - Allows writing to the Top Text Line
*-----
*      All general text commands can use top line again (Default Setting).
*****/
void releaseTopTextLine();

/*****
*      clearTextScreen()- Clears the Nextion Text Screen (page1)
*-----
*      If the Top Line is preserved that is not cleared, use clearTopTextLine instead.
*****/
void clearTextScreen();

```

```

/*****
*      clearTopTextLine() - Clears the Nextion Text Screen Top Text Line      *
*****/
void clearTopTextLine();

/*****
*      setDaylightSavingOn( on) - Turn Nextion daylight saving variable on or off      *
*-----*
*      Usage:                                                                *
*      setDaylightSavingOn( true ) - Turn on                                  *
*      setDaylightSavingOn( false ) - Turn off                               *
*****/
bool setDaylightSavingOn( bool on);

/*****
*      getDaylightSavingOn() - Returns Nextion daylight saving variable (true=on)      *
*-----*
*      Usage:                                                                *
*      getDaylightSavingOn()                                                *
*****/
bool getDaylightSavingOn();

/*****
*      viewDebugText(bool view) - Displays the debugTxt Text Line (or NOT)      *
*****/
void viewDebugText(bool view);

```