

EMISSION CONTROL SYSTEM

CONTENTS


1. SPECIFICATIONS	17A-1-1
GENERAL SPECIFICATIONS	17A-1-1
SERVICE SPECIFICATIONS	17A-1-1
TORQUE SPECIFICATIONS	17A-1-1
SEALANTS	17A-1-1
2. PARTS LOCATION	17A-2-1
3. INSPECTION	17A-3-1
EGR VALVE	17A-3-1
COOLANT TEMPERATURE SENSOR	17A-3-1

GENERAL SPECIFICATIONS

NOTE: The emission control systems differ in their specifications depending on the models and destinations. From the emission control parts listed in the GENERAL SPECIFICATIONS, the optimum ones have been selected and installed.

NOTES

2. PARTS LOCATION




NOTES

3. INSPECTION

EGR VALVE

- (1) Remove the EGR valve and check it for sticking, deposit of carbon, etc.
If such condition exists, clean with adequate solvent to ensure correct valve seat contact.



- (2) Connect a hand vacuum pump to the EGR valve.
- (3) Apply a vacuum of 500 mmHg (19.7 inHg) and check air tightness.
- (4) Blow in air from one passage of the EGR to check condition as follows.

