
Installation Quick Start User Manual for RAppID Boot Loader

Rev July 14, 2013





Contents

Section number	Title	Page
	Chapter 1	
	Installation	
1.1	Minimum Platform Requirements.....	5
1.2	Installation Steps.....	5
1.2.1	Run RAppID Boot Loader Setup.....	5
1.2.2	.NET Framework Required.....	6



Chapter 1

Installation

Installing the RAppID Boot Loader is your first step to start using RAppID Boot Loader utility.

1.1 Minimum Platform Requirements

The minimum recommended PC platform is Window XP, Vista, and Windows 7 with a minimum CPU Speed of 2.0 GHz and Minimum of 2GB of RAM.

1.2 Installation Steps

This installation steps include:

1. Run installation downloaded from the Freescale website and follow instructions.
2. Run RAppID Boot Loader setup.exe.

1.2.1 Run RAppID Boot Loader Setup

To install RAppID Boot Loader Setup, perform the following steps.

NOTE

It is best if this is NOT installed on a network drive.

1. Run the Setup.exe.

This activates the installer. The **RAppID Boot Loader Wizard** dialog box appears.

2. Click **Next** to proceed.

3. Accept the end users license agreement.
4. Click **Next** to proceed.

The **Choose destination directory** dialogue box appears.

5. The default install directory is `C:\RAppIDBL\`. To change the install directory by click **Browse**.
6. Click **Next** to proceed.

A confirmation of installation settings screen appears.

7. Click **Install** to proceed.
8. Click **Finish** to exit and complete the installation.

1.2.2 .NET Framework Required

The RAppID Boot Loader utility requires Microsoft .NET Framework version 4.0, which is included with the RAppID Boot Loader installation package.

Index

.NET [6](#)

B

Boot [5](#)

F

Framework [6](#)

I

Installation [5](#)

L

Loader [5](#)

M

Minimum [5](#)

P

Platform [5](#)

R

RAppID [5](#)

Required [6](#)

Requirements [5](#)

Run [5](#)

S

Setup [5](#)

Steps [5](#)

How to Reach Us:**Home Page:**freescale.com**Web Support:**freescale.com/support

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale, the Freescale logo, Altivec, C-5, CodeTest, CodeWarrior, ColdFire, ColdFire+, C-Ware, Energy Efficient Solutions logo, Kinetis, mobileGT, PowerQUICC, Processor Expert, QorIQ, Qorivva, StarCore, Symphony, and VortiQa are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Airfast, BeeKit, BeeStack, CoreNet, Flexis, Layerscape, MagniV, MXC, Platform in a Package, QorIQ Qonverge, QUICC Engine, Ready Play, SafeAssure, SafeAssure logo, SMARTMOS, Tower, TurboLink, Vybrid, and Xtrinsic are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2013 Freescale Semiconductor, Inc.

Revision July 14, 2013

