

# CSE User's Manual

## California Simulation Engine

# Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
1.1	Greetings . . . . .	4
1.2	Manual Organization . . . . .	4
1.3	Installation . . . . .	5
1.3.1	Hardware and Software Requirements . . . . .	5
1.3.2	Installation Procedure . . . . .	5
<b>2</b>	<b>Operation</b>	<b>5</b>
2.1	Command Line . . . . .	5
2.2	Locating Files . . . . .	5
2.3	Output File Names . . . . .	6
2.4	Errorlevel . . . . .	6
<b>3</b>	<b>Input Structure</b>	<b>6</b>
3.1	Introduction . . . . .	6
3.2	Form of the CSE Data . . . . .	7
3.3	Overview of CSE Input Language . . . . .	8
3.3.1	Statements – Overview . . . . .	8
3.3.2	Nested Objects . . . . .	9
3.3.3	Expressions – Overview . . . . .	10
3.3.4	The Preprocessor – Overview . . . . .	11
3.4	The Preprocessor . . . . .	11
3.4.1	Line splicing . . . . .	12
3.4.2	Macro definition and expansion . . . . .	12
3.4.3	File inclusion . . . . .	13
3.4.4	Conditional inclusion of text . . . . .	13
3.4.5	Preprocessor examples . . . . .	14
3.5	CSE Input Language Statements . . . . .	15
3.5.1	Object Statements . . . . .	15
3.5.2	Member Statements . . . . .	19
3.5.3	Action Commands . . . . .	20
3.6	Expressions . . . . .	20
3.6.1	Expression Types . . . . .	21
3.6.2	Constants . . . . .	22
3.6.3	Operators . . . . .	23
3.6.4	System Variables . . . . .	24
3.6.5	Built-in Functions . . . . .	26
3.6.6	User-defined Functions . . . . .	32
3.6.7	Probes . . . . .	32
3.6.8	Variation Frequencies Revisited . . . . .	34
<b>4</b>	<b>Input Data</b>	<b>35</b>
4.1	TOP Members . . . . .	35
4.1.1	TOP General Data Items . . . . .	35
4.1.2	TOP Daylight Saving Time Items . . . . .	39
4.1.3	TOP Model Control Items . . . . .	40
4.1.4	TOP Weather Data Items . . . . .	42
4.1.5	TOP TDV (Time Dependent Value) Items . . . . .	47
4.1.6	TOP Report Data Items . . . . .	48
4.1.7	TOP Autosizing . . . . .	50
4.1.8	TOP Debug Reporting . . . . .	51
4.2	HOLIDAY . . . . .	51
4.3	MATERIAL . . . . .	54

4.4	CONSTRUCTION	56
4.5	FOUNDATION	56
4.6	FNDBLOCK	60
4.7	LAYER	64
4.8	GLAZETYPE	66
4.9	METER	69
4.10	DHWMETER	70
4.11	ZONE	71
4.11.1	ZONE General Members	71
4.11.2	ZONE Infiltration	75
4.11.3	ZONE Exhaust Fan	76
4.12	GAIN	77
4.13	SURFACE	81
4.14	WINDOW	89
4.15	SHADE	94
4.16	SGDIST	97
4.17	DOOR	98
4.18	PERIMETER	102
4.19	IZXFER	103
4.20	RSYS	110
4.21	DUCTSEG	120
4.22	DHWDAYUSE	123
4.23	DHWUSE	125
4.24	DHWSYS	127
4.25	DHWHEATER	133
4.26	DHWLOOPHEATER	141
4.27	DHWHEATREC	141
4.28	DHWTANK	143
4.29	DHWPUMP	145
4.30	DHWLOOP	146
4.31	DHWLOOPPUMP	147
4.32	DHWLOOPSEG	149
4.33	DHWLOOPBRANCH	150
4.34	DHWSOLARSYS	152
4.35	DHWSOLARCOLLECTOR	154
4.36	PVARRAY	156
4.37	SHADEX	165
4.38	BATTERY	166
4.39	REPORTFILE	169
4.40	REPORT	171
4.41	REPORTCOL	176
4.42	EXPORTFILE	178
4.43	EXPORT	179
4.44	EXPORTCOL	182
4.45	IMPORTFILE	184
<b>5</b>	<b>Output Reports</b>	<b>186</b>
5.1	Units	186
5.2	Time	186
5.3	METER Reports	186
5.4	Energy Balance Report	186
5.5	Air Handler Load Report	187
5.6	Air Handler Report	188

<b>6</b>	<b>Probe Definitions</b>	<b>189</b>
6.1	ahRes . . . . .	189
6.2	airHandler . . . . .	193
6.3	Battery . . . . .	228
6.4	boiler (owner: heatPlant) . . . . .	229
6.5	chiller (owner: coolPlant) . . . . .	232
6.6	construction . . . . .	237
6.7	coolPlant . . . . .	238
6.8	DESCOND . . . . .	246
6.9	DHWDAYUse . . . . .	246
6.10	DHWHeater (owner: DHWSys) . . . . .	247
6.11	DHWHeatRec (owner: DHWSys) . . . . .	252
6.12	DHWLoop (owner: DHWSys) . . . . .	253
6.13	DHWLoopBranch (owner: DHWLoopSeg) . . . . .	255
6.14	DHWLoopHeater . . . . .	257
6.15	DHWLoopPump (owner: DHWLoop) . . . . .	261
6.16	DHWLoopSeg (owner: DHWLoop) . . . . .	261
6.17	DHWmeter . . . . .	264
6.18	DHWPump (owner: DHWSys) . . . . .	264
6.19	DHWSolarCollector (owner: DHWSolarSys) . . . . .	265
6.20	DHWSolarSys . . . . .	266
6.21	DHWSys . . . . .	269
6.22	DHWTank (owner: DHWSys) . . . . .	280
6.23	DHWUse (owner: DHWDAYUse) . . . . .	280
6.24	door (owner: surface) . . . . .	281
6.25	DuctSeg (owner: RSYS) . . . . .	293
6.26	export (owner: exportFile) . . . . .	296
6.27	exportCol (owner: export) . . . . .	298
6.28	exportFile . . . . .	298
6.29	foundation . . . . .	299
6.30	foundationBlock (owner: foundation) . . . . .	299
6.31	gain (owner: zone) . . . . .	300
6.32	glazeType . . . . .	300
6.33	heatPlant . . . . .	302
6.34	holiday . . . . .	308
6.35	impFileFldNames . . . . .	308
6.36	importFile . . . . .	309
6.37	Inverse . . . . .	310
6.38	izXfer . . . . .	310
6.39	kiva . . . . .	315
6.40	layer (owner: construction) . . . . .	316
6.41	mass . . . . .	316
6.42	material . . . . .	320
6.43	meter . . . . .	320
6.44	perimeter (owner: zone) . . . . .	327
6.45	PVArray . . . . .	327
6.46	report (owner: reportFile) . . . . .	331
6.47	reportCol (owner: report) . . . . .	332
6.48	reportFile . . . . .	332
6.49	RSYS . . . . .	333
6.50	RSYSRes . . . . .	345
6.51	sgdist (owner: window) . . . . .	348
6.52	shade (owner: window) . . . . .	349
6.53	SHADEX . . . . .	349

6.54	surface (owner: zone) . . . . .	351
6.55	terminal (owner: zone) . . . . .	364
6.56	top . . . . .	374
6.57	towerPlant . . . . .	388
6.58	weather . . . . .	394
6.59	weatherFile . . . . .	398
6.60	weatherNextHour . . . . .	401
6.61	window (owner: surface) . . . . .	404
6.62	xsurf . . . . .	417
6.63	zhx (owner: zone) . . . . .	429
6.64	znRes . . . . .	430
6.65	zone . . . . .	461

## 1 Introduction

### 1.1 Greetings

The purpose of this manual is to document the California Simulation Engine computer program, CSE. CSE is an hourly building and HVAC simulation program which calculates annual energy requirements for building space conditioning and lighting. CSE is specifically tailored for use as internal calculation machinery for compliance with the California building standards.

CSE is a batch driven program which reads its input from a text file. It is not intended for direct use by people seeking to demonstrate compliance. Instead, it will be used within a shell program or by technically oriented users. As a result, this manual is aimed at several audiences:

1. People testing CSE during its development.
2. Developers of the CSE shell program.
3. Researchers and standards developers who will use the program to explore possible conservation opportunities.

Each of these groups is highly sophisticated. Therefore this manual generally uses an exhaustive, one-pass approach: while a given topic is being treated, *everything* about that topic is presented with the emphasis on completeness and accuracy over ease of learning.

Please note that CSE is under development and will be for many more months. Things will change and from time to time this manual may be inconsistent with the program.

### 1.2 Manual Organization

This Introduction covers general matters, including program installation.

**Operation** documents the operational aspects of CSE, such as command line switches, file naming conventions, and how CSE finds files it needs.

**Input Structure** documents the CSE input language in general.

**Input Data** describes all of the specific input language statements.

**Output Reports** will describe the output reports.

Lastly, **Probe Definitions** lists all available probes.

## 1.3 Installation

### 1.3.1 Hardware and Software Requirements

CSE is a 32-bit Microsoft Windows console application. That is, it runs at the command prompt on Windows XP, Windows Vista, and Windows 7. Memory and disk space requirements depend on the size of projects being modeled, but are generally modest.

To prepare input files, a text editor is required. Notepad will suffice, although a text editor intended for programming is generally more capable. Alternatively, some word processors can be used in “ASCII” or “text” or “non-document” mode.

### 1.3.2 Installation Procedure

Create a directory on your hard disk with the name \CSE or some other name of your choice. Copy the files into that directory. Add the name of the directory to the PATH environment setting unless you intend to use CSE only from the CSE directory.

## 2 Operation

### 2.1 Command Line

CSE is invoked from the command prompt or from a batch file using the following command:

```
CSE *inputfile* {*switches*}
```

where:

*inputfile* specifies the name of the text input file for the run(s). If the filename has an extension other than “.cse” (the default), it must be included. The name of the file with weather data for the simulation(s) is given in this file (wfName= statement, see [Weather Data Items](#)).

*{switches}* indicates zero or more of the following:

- -D*name* defines the preprocessor symbol *name* with the value “”. Useful for testing with `#ifdef name`, to invoke variations in the simulation without changing the input file. The CSE preprocessor is described “[The Preprocessor](#)”.
- -D*name=value* defines the preprocessor symbol *name* with the specified *value*. *Name* can then be used in the input file to allow varying the simulation without changing the input file – see “[The Preprocessor](#)” for more information. The entire switch should be enclosed in quotes if it contains any spaces – otherwise the command processor will divide it into two arguments and CSE will not understand it.
- -b batch mode: CSE will never stop for a response from the user when an error occurs. Error messages may thus scroll off the screen, but will all be in the error message file.
- -p display all the class and member names that can be “probed” or accessed in CSE expressions. “Probes” are described in “[Probes](#)”. Use with command processor redirection operator “>” to obtain a report in a file. *Inputfile* may be given or omitted when -p is given.
- -q similar to -p, but displays additional member names that cannot be probed or would not make sense to probe in an input file (development aid).
- -x specifies report test prefix; see [TOP](#) repTestPfx. The -x command line setting takes precedence over the input file value, if any.

### 2.2 Locating Files

As with any program, in order to invoke CSE, the directory containing CSE.EXE must be the current directory, or that directory must be on the operating system path, or you must type the directory path

before CSE.

A CSE simulation requires a weather file. The name of the weather file is given in the CSE input file (**wfName=** statement, see **Weather Data Items**). The weather file must be in one of the same three places: current directory, directory containing CSE.EXE, or a directory on the operating system path; or, the directory path to the file must be given in the **wfName=** statement in the usual pathName syntax. ?? Appears that file must be in current directory due to file locating bugs 2011-07

The CSE input file, named on the CSE command line, must be in the current directory or the directory path to it must be included in the command line.

Included input files, named in **#include** preprocessor directives (see “**The Preprocessor**”) in the input file, must be in the current directory or the path to them must be given in the **#include** directive. In particular, CSE will NOT automatically look for included files in the directory containing the input file. The default extension for included files is “.CSE”.

Output files created by default by CSE (error message file, primary report and export files) will be in the same directory as the input file; output files created by explicit command in the input file (additional report and/or export files) will be in the current directory unless another path is explicitly specified in the command creating the file.

## 2.3 Output File Names

If any error or warning messages are generated, CSE puts them in a file with the same name and path as the input file and extension .ERR, as well as on the screen and, usually, in the primary (default) report file. The exception is errors in the command line: these appear only on the screen. If there are no error or warning messages, any prior file with this name is deleted.

By default, CSE generates an output report file with the same name and path as the input file, and extension “.REP”. This file may be examined with a text editor and/or copied to an ASCII printer. If any exports are specified, they go by default into a file with the same name and path as the input file and extension “.EXP”.

In response to specifications in the input file, CSE can also generate additional report and export files with user-specified names. The default extensions for these are .REP and .CSV respectively and the default directory is the current directory; other paths and extensions may be specified. For more information on report and export files, see **REPORTFILE** and **EXPORTFILE** in “**Input Data**”.

## 2.4 Errorlevel

CSE sets the command processor ERRORLEVEL to 2 if any error occurs in the session. This should be tested in batch files that invoke CSE, to prevent use of the output reports if the run was not satisfactory. The ERRORLEVEL is NOT set if only warning messages that do not suppress or abort the run occur, but such messages DO create the .ERR file.

# 3 Input Structure

**DRAFT:** In the following, any text annotated with ?? indicates areas of uncertainty or probable change. As the program and input language develop, these matters will be resolved.

## 3.1 Introduction

The CSE Input Language is the fundamental interface to the CSE program. The language has been designed with three objectives in mind:

1. Providing direct access to all program features (including ones included for self-testing), to assist in program development.

2. Providing a set of parametric and expression evaluation capabilities useful for standards development and program testing.
3. Providing a means for other programs, such as an interactive user interface, to transmit input data and control data to the program.

Thus, the language is not intended to be used by the average compliance or simulation user. Instead, it will be used during program development for testing purposes and subsequently for highly technical parametric studies, such as those conducted for research and standards development. In all of these situations, power, reproducibility, and thorough input documentation take precedence over user-friendliness.

CSE reads its input from a file. The file may be prepared by the user with a text editor, or generated by some other program.

## 3.2 Form of the CSE Data

The data used by CSE consists of *objects*. Each object is of a *class*, which determines what the object represents. For example, objects of class **ZONE** represent thermally distinct regions of the building; each thermally distinct region has its own **ZONE** object. An object's class determines what data items or *members* it contains. For instance, a **ZONE** object contains the zone's area and volume. In addition, each object can have a *name*.

The objects are organized in a hierarchy, or tree-like structure. For example, under each **ZONE** object, there can be **SURFACE** objects to represent the walls, floors, and ceilings of the **ZONE**. Under **SURFACEs** there can be **WINDOW** objects to represent glazings in the particular wall or roof. **SURFACE** is said to be a *subclass* of the class **ZONE** and **WINDOW** a subclass of **SURFACE**; each individual **SURFACE** is said to be a *subobject* of its particular **ZONE** object. Conversely, each individual **SURFACE** is said to be *owned by* its zone, and the **SURFACE** class is said to be owned by the **ZONE** class.

The hierarchy is rooted in the one *top-level object* (or just *Top*). The top level object contains information global to the entire simulation, such as the start and end dates, as well as all of the objects that describe the building to be simulated and the reports to be printed.

Objects and their required data must be specified by the user, except that Top is predefined. This is done with input language *statements*. Each statement begins an object (specifying its class and object name) or gives a value for a data member of the object being created. Each object is specified with a group of statements that are usually given together, and the objects must be organized according to the hierarchy. For example, **SURFACEs** must be specified within **ZONEs** and **WINDOWs** within **SURFACEs**. Each **SURFACE** belongs to (is a subobject of) the **ZONE** within which it is specified, and each **WINDOW** is a subobject of its **SURFACE**.

The entire hierarchy of CSE classes can be represented as follows, using indentation to indicate subclasses:

TODO: review hierarchy

TOP (Top-level class; object of this class supplied automatically by CSE)

```

HOLIDAY
MATERIAL
CONSTRUCTION
    LAYER
METER
DHWMETER
IZXFER
DHWDAYUSE
    DHWUSE
DHWSYS
    DHWHEATER
    DHWTANK
    DHWPUMP

```



```

    DHWLOOP
    DHWLOOPPUMP
    DHWLOOPSEG
        DHWLOOPBRANCH
    DHWSOLARSYS
        DHWSOLARCOLLECTOR
    ZONE
        GAIN
        SURFACE
            WINDOW
                SHADE
                SGDIST
        DOOR
    REPORTFILE
    REPORT
    REPORTCOL
    EXPORTFILE
    EXPORT
    EXPORTCOL

```

### 3.3 Overview of CSE Input Language

The CSE Input Language consists of *commands*, each beginning with a particular word and, preferably, ending with a semicolon. Each command is either an *action-command*, which specifies some action such as starting a simulation run, or a *statement*, which creates or modifies an *object* or specifies a value for a *member* of an object.

#### 3.3.1 Statements – Overview

A statement that creates an object consists basically of the *class name* followed by your name for the object to be created. (The name can be omitted for most classes; optional modifying clauses will be described later.) For example,

```
ZONE "north";
```

begins an object of class **ZONE**; the particular zone will be named “north”. This zone name will appear in reports and error messages, and will be used in other statements that operate on the zone. As well as creating the **ZONE**, this statement sets CSE to expect statements specifying **ZONE** data members or **ZONE** subobjects to follow.

A statement specifying a data member consists of the data member's name, an = sign, an *expression* specifying the value, and a terminating semicolon. An expression is a valid combination of operands and operators as detailed later; commonly it is just a number, name, or text enclosed in quotes. For example,

```
znVol = 100000;
```

specifies that the zone has a volume of 100000 cubic feet. (If the statement occurs outside of the description of a **ZONE**, an error message occurs.) All of the member names for each class are described in the **input data** section; most of them begin with an abbreviation of the class name for clarity.

The description of a zone or any object except Top can be terminated with the word “END”; but this is not essential; CSE will assume the **ZONE** ends when you start another **ZONE** or any object not a subobject of **ZONE**, or when you specify a member of a higher level class (Top for **ZONE**), or give an action-command such as RUN.

Statements are free-form; several can be put on a line, or a single statement can occupy several lines. Indentation according to class hierarchy will help make your input file readable. Spaces may be used freely except in the middle of a word or number. Tab characters may be used. Each statement should end with

a semicolon. If the semicolon is omitted and the statement and the following statement are both correctly formed, CSE will figure out your intent anyway. But when there is an error, CSE gives clearer error messages when the statements are delimited with semicolons.

Capitalization generally does not matter in input language statements; we like to capitalize class names to make them stand out. Words that differ only in capitalization are NOT distinct to CSE.

*Comments* (remarks) may be interspersed with commands. Comments are used to make the input file clearer to humans; they are ignored by CSE. A comment introduced with “//” ends at the end of the line; a comment introduced with “/\*” continues past the next “\*/”, whether on the same line, next line, or many lines down. Additional input language may follow the \*/ on the same line.

### 3.3.2 Nested Objects

The following is a brief CSE input file, annotated with comments intended to exemplify how the input language processor follows the object hierarchy when decoding input describing objects and their subobjects.

```
// short example file

wfName = "CZ12RV2.CEC"; // initially, the current object is Top.
// give weather file name, a Top member
begDay = Jan 1; // start and ...
endDay = Dec 31; // ...end run dates: Top members.

MATERIAL carpet; // create object of class MATERIAL
matThk = .296; // specify 'matThk' member of MATERIAL 'carpet'
matCond = 1./24; // give value of 'matCond' for 'carpet'

CONSTRUCTION slab140C; /* create object of class CONSTRUCTION, named
                        slab140C. Terminates MATERIAL, because
                        CONSTRUCTION is not a subclass of material
                        in the hierarchy shown in another section** */
    LAYER // start an unnamed object of class LAYER.
          /* Since LAYER is a subclass of CONSTRUCTION,
             this will be a subobject of slab140C. */
        lrMat = carpet; /* member of the LAYER. Note use of name of
                        MATERIAL object. */
    // (additional layers would be here)

METER Elec; /* create METER named Elec;
             since METER is a subobject of Top,
             this ends slab140C and its LAYER. */

ZONE North; // start a ZONE named North. Ends METER.
  znArea = 1000; // specify data members of ZONE North.
  znVol = 10; // (you don't have to capitalize these as shown.)
  GAIN NorthLights // create GAIN object named NorthLights.
                  /* Creates a subobject of ZONE North. */
    gnPower = 0.01; // member of NorthLights -- numeric value
    gnMeter = Elec; // member of NorthLights -- object name value

  znCAir = 3.5; /* processor knows that znCAir is a member of ZONE;
                thus this statement terminates the GAIN
                subobject & continues ZONE 'North'. */

/*lrMat = ... would be an error here, because the current
              object is not a LAYER nor a subobject of LAYER */
```

```

RUN;                                /* initiate simulation run with data given.
                                   Terminates ZONE North, since action-commands
                                   terminate all objects being constructed. */

```

\*\* See [Form of the CSE Data](#)

### 3.3.3 Expressions – Overview

*Expressions* are the parts of statements that specify values – numeric values, string values, object name values, and choice values. Expressions are composed of operators and operands, in a manner similar to many programming languages. The available operators and operands will be described in the section on [operators](#).

Unlike most programming languages, CSE expressions have *Variation*. *Variation* is how often a value changes during the simulation run – hourly, daily, monthly, yearly (i.e. does not change during run), etc. For instance, the operand `$hour` represents the hour of the day and has “hourly” variation. An expression has the variation of its fastest-varying component.

Each data member of each object (and every context in which an expression may be used) has its allowed *variability*, which is the fastest variation it will accept. Many members allow no variability. For example, `begDay`, the date on which the run starts, cannot meaningfully change during the run. On the other hand, a thermostat setting can change hourly. Thermostat settings and other scheduled values are specified in CSE with expressions that often make use of variability; there is no explicit SCHEDULE class.

For example, a heating setpoint that was 68 during business hours and 55 at night might be expressed as

```
select( $hour > 8 && $hour < 18, 68, default 55)
```

An example of a complete statement containing the above expression is:

```
tuTH = select( $hour > 8 && $hour < 18, 68, default 55);
```

The preceding is valid a statement if used in a TERMINAL description. The following:

```
begDay = select( $hour > 8 && $hour < 18, 68, default 55);
```

would always get an error message, because `begDay` (the starting day of the run) will not accept hourly variation, and the expression varies hourly, since it contains `$hour`. The expression’s variation is considered “hourly” even though it changes only twice a day, since CSE has no variation category between hourly and daily.

CSE’s expression capability may be used freely to make input clearer. For example,

```
znVol = 15 * 25 * 8;
```

meaning that the zone volume is 15 times 25 times 8 is the same to CSE as

```
znVol = 3000;
```

but might be useful to you to tersely indicate that the volume resulted from a width of 15, a length of 25, and a height of 8. Further, if you wished to change the ceiling height to 9 feet, the edit would be very simple and CSE would perform the volume calculation for you.

CSE computes expressions only as often as necessary, for maximum simulation speed. For example,

```
tuTH = 68;
```

causes 68 to be stored in the heating setpoint once at the start of the run only, even though `tuTH` will accept expressions with variability up to hourly. Furthermore, constant inner portions of variable expressions are pre-evaluated before the run begins.

CSE statements and expressions do not (yet) have user-settable variables in the usual programming language sense. They do, however, have user-defined functions to facilitate using the same computation several places,

and preprocessor macros, to facilitate using the same text several places, specifying parametric values in a separate file, etc.

### 3.3.4 The Preprocessor – Overview

The preprocessor scans and processes input file text before the language processor sees the text. The preprocessor can include (embed) additional files in the input, include sections of input conditionally, and define and expand macros.

Macros are a mechanism to substitute a specified text for each occurrence of a word (the macro name). For example,

```
#define ZNWID 20
#define ZNLEN 30
. . .

znArea = ZNWID * ZNLEN;
znVol  = ZNWID * ZNLEN * 8;
```

The first line above says that all following occurrences of “ZNWID” are to be replaced with “20” (or whatever follows ZNWID on the same line). The effect of the above is that the zone width and length are specified only one place; if the single numbers are editing, both the zone area and zone volume change to match.

Macros can be especially powerful when combined with the file inclusion feature; the generic building description could be in one file, and the specific values for multiple runs supplied by another file. By also using conditional compilation, the values-specifying file can select from a range of features available in the building description file.

The preprocessor is similar to that of the C programming language, and thus will be familiar to C programmers.

The next section describes the preprocessor in detail. The preprocessor description is followed by sections detailing statements, then expressions.

## 3.4 The Preprocessor

*Note: The organization and wording of this section is based on section A12 of Kernigan and Richie [1988]. The reader is referred to that source for a somewhat more rigorous presentation but with the caution that the CSE input language preprocessor does not **completely** comply to ANSI C specifications.*

The preprocessor performs macro definition and expansion, file inclusion, and conditional inclusion/exclusion of text. Lines whose first non-whitespace character is # communicate with the preprocessor and are designated *preprocessor directives*. Line boundaries are significant to the preprocessor (in contrast to the rest of the input language in which a newline is simply whitespace), although adjacent lines can be spliced with \, as discussed below. The syntax of preprocessor directives is separate from that of the rest of the language. Preprocessor directives can appear anywhere in an input file and their effects last until the end of the input file. The directives that are supported by the input language preprocessor are the following:

```
#if
#else
#elif
#endif
#ifndef

#define
#define
#undef
```

```
#include
```

### 3.4.1 Line splicing

If the last character on a line is the backslash `\`, then the next line is spliced to that line by elimination of the backslash and the following newline. Line splicing occurs *before* the line is divided into tokens.

Line splicing finds its main use in defining long macros:

```
// hourly light gain values:
#define LIGHT_GAIN      .024, .022, .021, .021, .021, .026, \
                        .038, .059, .056, .060, .059, .046, \
                        .045, .5  , .5  , .05  , .057, .064, \
                        .064, .052, .050, .055, .044, .027
```

### 3.4.2 Macro definition and expansion

A directive of the form

```
#define _identifier_ _token-sequence_
```

is a macro definition and causes the preprocessor to replace subsequent instances of the identifier with the given token sequence. Note that the token string can be empty (e.g. `#define FLAG`).

A line of the form

```
#define _identifier_( _identifier-list_ ) _token-sequence_
```

where there is no space between the identifier and the `(`, is a macro with parameters given by the identifier list. The expansion of macros with parameters is discussed below.

Macros may also be defined *on the CSE command line*, making it possible to vary a run without changing the input files at all. As described in the [command line](#) section, macros are defined on the CSE command line using the `-D` switch in the forms

```
-D_identifier_
```

```
-D_identifier_= _token-sequence_
```

The first form simply defines the name with no token-sequence; this is convenient for testing with `#ifdef`, `#ifndef`, or `defined()`, as described in the section on [conditional inclusion of tex](#). The second form allows an argument list and token sequence. The entire command line argument must be enclosed in quotes if it contains any spaces.

A macro definition is forgotten when an `#undef` directive is encountered:

```
#undef _identifier_
```

It is not an error to `#undef` an undefined identifier.

A macro may be re-`#defined` without a prior `#undef` unless the second definition is identical to the first. A combined `#undef/#define` directive is available to handle this common case:

```
#redefine _identifier_ _token-sequence_
```

```
#redefine _identifier_( _identifier-list_ ) _token-sequence_
```

When a macro is `#redefined`, it need not agree in form with the prior definition (that is, one can have parameters even if the other does not). It is not an error to `#redefine` an undefined identifier.

Macros defined in the second form (with parameters) are expanded whenever the preprocessor encounters the macro identifier followed by optional whitespace and a comma-separated parameter list enclosed in parentheses. First the comma separated token sequences are collected; any commas within quotes or nested

parentheses do not separate parameters. Then each unquoted instance of the each parameter identifier in the macro definition is replaced by the collected tokens. The resulting string is then repeatedly re-scanned for more defined identifiers. The macro definition and reference must have the same number of arguments.

It is often important to include parentheses within macro definitions to make sure they evaluate properly in all situations. Suppose we define a handy area macro as follows:

```
#define AREA(w, h) w*h           // WRONG
```

Consider what happens when this macro is expanded with arguments 2+3 and 4+1. The preprocessor substitutes the arguments for the parameters, then the input language processor processes the statement containing the macro expansion without regard to the beginning and end of the arguments. The expected result is 25, but as defined, the macro will produce a result of 15. Parentheses fix it:

```
#define AREA(w, h) ((w)*(h))    // RIGHT
```

The outer enclosing set of parentheses are not strictly needed in our example, but are good practice to avoid evaluation errors when the macro expands within a larger expression.

Note 1: The CSE preprocessor does not support the ANSI C stringizing (#) or concatenation (##) operators.

Note 2: Identifiers are case *insensitive* (unlike ANSI C). For example, the text “myHeight” will be replaced by the `#defined` value of MYHEIGHT (if there is one).

*The preprocessor examples at the end of this section illustrate macro definition and expansion.*

### 3.4.3 File inclusion

Directives of the form

```
#include "filename" and
```

```
#include <filename>
```

cause the replacement of the directive line with the entire contents of the referenced file. If the filename does not include an extension, a default extension of .INP is assumed. The filename may include path information; if it does not, the file must be in the current directory.

`#includes` may be nested to a depth of 5.

For an example of the use `#includes`, please see the preprocessor examples at the end of this section.

### 3.4.4 Conditional inclusion of text

Conditional text inclusion provides a facility for selectively including or excluding groups of input file lines. The lines so included or excluded may be either CSE input language text *or other preprocessor directives*. The latter capability is very powerful.

Several conditional inclusion directive involve integer constant expressions. Constant integer expressions are formed according to the rules discussed in the section on **expressions** with the following changes:

1. Only constant integer operands are allowed.
2. All values (including intermediate values computed during expression evaluation) must remain in the 16 bit range (-32768 - 32767). The expression processor treats all integers as signed values and requires signed decimal constants – however, it requires unsigned octal and hexadecimal constants. Thus decimal constants must be in the range -32768 - 32767, octal must be in the range 0 - 0o177777, and hexadecimal in the range 0 - 0xffff. Since all arithmetic comparisons are done assuming signed values, `0xffff < 1` is true (unhappily). Care is required when using the arithmetic comparison operators (<, <=, >=, >).
3. The logical relational operators && and || are not available. Nearly equivalent function can be obtained with & and |.

4. A special operand `defined( )` is provided; it is described below.

Macro expansion *is* performed on constant expression text, so symbolic expressions can be used (see examples below).

The basic conditional format uses the directive

```
#if _constant-expression_
```

If the constant expression has the value 0, all lines following the `#if` are dropped from the input stream (the preprocessor discards them) until a matching `#else`, `#elif`, or `#endif` directive is encountered.

The `defined( identifier )` operand returns 1 if the identifier is the name of a defined macro, otherwise 0. Thus

```
#if defined( _identifier_ )
```

can be used to control text inclusion based on macro flags. Two `#if` variants that test whether a macro is defined are also available. `#ifdef identifier` is equivalent to `#if defined(identifier)` and `#ifndef identifier` is equivalent to `#if !defined(identifier)`.

`Defined()`, `#ifdef`, and `#ifndef` consider a macro name “defined” even if the body of its definition contains no characters; thus a macro to be tested with one of these can be defined with just

```
#define _identifier_
```

or with just “`-Didentifier`” on the CSE command line.

Conditional blocks are most simply terminated with `#endif`, but `#else` and `#elif constant-expression` are also available for selecting one of two or more alternative text blocks.

The simplest use of `#if` is to “turn off” sections of an input file without editing them out:

```
#if 0This text is deleted from the input stream.#endif
```

Or, portions of the input file can be conditionally selected:

```
#define FLRAREA 1000 // other values used in other runs
#if FLRAREA <= 800
    CSE input language for small zones
#elif FLRAREA <= 1500
    CSE input language for medium zones
#else
    CSE input language for large zones
#endif
```

Note that if a set of `#if ... #elif ... #elif` conditionals does not contain an `#else`, it is possible for all lines to be excluded.

Finally, it is once again important to note that conditional directives *nest*, as shown in the following example (indentation is included for clarity only):

```
#if 0
    This text is NOT included.
    #if 1
        This text is NOT included.
    #endif
#else
    This text IS included.
#endif
```

### 3.4.5 Preprocessor examples

This section shows a few combined examples that demonstrate the preprocessor’s capabilities.

The simplest use of macros is for run parameterization. For example, a base file is constructed that derives values from a macro named FLRAREA. Then multiple runs can be performed using `#include`:

```
// Base file
... various input language statements ...

ZONE main
  znArea = FLRAREA
  znVol  = 8*FLRAREA
  znCAir = 2*FLRAREA ...
  ... various other input language statements ...

RUN

CLEAR
```

The actual input file would look like this:

```
// Run with zone area = 500, 1000, and 2000 ft2
#define FLRAREA 500
#include "base."
#define FLRAREA 1000
#include "base."
#define FLRAREA 2000
#include "base."
```

Macros are also useful for encapsulating standard calculations. For example, most U-values must be entered *without* surface conductances, yet many tabulated U-values include the effects of the standard ASHRAE winter surface conductance of 6.00 Btuh/ft<sup>2</sup>-°F. A simple macro is very helpful:

```
#define UWinter(u) ( 1/(1/(u)-1/6.00) )
```

This macro can be used whenever a U-value is required (e.g. `SURFACE ... sfU=UWinter(.11) ...`).

## 3.5 CSE Input Language Statements

This section describes the general form of CSE input language statements that define objects, assign values to the data members of objects, and initiate actions. The concepts of objects and the class hierarchy were introduced in the section on [form of CSE data](#). Information on statements for specific CSE input language classes and their members is the subject of the [input data](#) section.

### 3.5.1 Object Statements

As we described in a [previous section](#), the description of an object is introduced by a statement containing at least the class name, and usually your chosen name for the particular object. In addition, this section will describe several optional qualifiers and modifying clauses that permit defining similar objects without repeating all of the member details, and reopening a previously given object description to change or add to it.

Examples of the basic object-beginning statement:

```
ZONE "North";

METER "Electric - Cooling";

LAYER;
```

As described in [the section on nested objects](#), such a statement is followed by statements giving the object's member values or describing subobjects of the object. The object description ends when you begin another



object that is not of a subclass of the object, or when a member of an embedding (higher level) object previously begun is given, or when END is given.

### 3.5.1.1 Object Names

An object name consists of up to 63 characters. If you always enclose the name in quotation marks, punctuation and spaces may be used freely; if the name starts with a letter or dollar sign and consists only of letters, digits, underscore, and dollar sign, and is different from all of the words already defined in CSE input language (as listed below in this section), you may omit the quotes. Capitalization, and Leading and trailing spaces and tabs, are always disregarded by input language processor. Names of 0 length, and names containing control characters (ASCII codes 0-31) are not allowed.

Examples of valid names that do not require quotes:

```
North
gas_meter
slab140E
```

The following object names are acceptable if always enclosed in quotes:

```
"Front Door"
"M L King Day"
"123"
"3.5-inch wall"
```

We suggest always quoting object names so you won't have to worry about disallowed words and characters.

Duplicate names result in error messages. Object names must be distinct between objects of the same class which are subobjects of the same object. For example, all **ZONE** names must be distinct, since all **ZONEs** are subobjects of Top. It is permissible to have **SURFACEs** with the same name in different **ZONEs** – but it is a good idea to keep all of your object names distinct to minimize the chance of an accidental mismatch or a confusing message regarding some other error.

For some classes, such as **ZONE**, a name is required for each object. This is because several other statements refer to specific **ZONEs**, and because a name is needed to identify **ZONEs** in reports. For other classes, the name is optional. The specific statement descriptions in the **Input Data** Section 5 say which names are required. We suggest always using object names even where not required; one reason is because they allow CSE to issue clearer error messages.

The following *reserved words will not work as object names unless enclosed in quotes*:

*(this list needs to be assembled and typed in)*

### 3.5.1.2 ALTER

ALTER is used to reopen a previously defined object when it is not possible or desired to give the entire description contiguously.

ALTER could be used if you wish to order the input in a special way. For example, **SURFACE** objects are subobjects of **ZONE** and are normally described with the **ZONE** they are part of. However, if you wanted to put all roofs together, you could use input of the general form:

```
ZONE "1"; . . . (zone 1 description)
ZONE "2"; . . .
. . .
ALTER ZONE "1";           // revert to specifying zone 1
    SURFACE "Roof1"; . . . (describe roof of zone 1)
ALTER ZONE "2";
    SURFACE "Roof2"; . . .
```

ALTER can be used to facilitate making similar runs. For example, to evaluate the effect of a change in the size of a window, you might use:

```

ZONE "South";
  SURFACE "SouthWall";
  ...
    WINDOW "BigWindow";
      wnHeight = 6; wnWidth = 20;
  ...
RUN;          // perform simulation and generate reports
// data from simulation is still present unless CLEAR given
ALTER ZONE "South";
  ALTER SURFACE "SouthWall";
  ALTER WINDOW "BigWindow";
    wnHeight = 4; wnWidth = 12; // make window smaller
RUN;          // perform simulation and print reports again

```

ALTER also lets you access the predefined “Primary” **REPORTFILE** and **EXPORTFILE** objects which will be described in the **Input Data** Section:

```

ALTER REPORTFILE "Primary";    /* open description of object automatically
                                supplied by CSE -- no other way to access */
                                rfPageFmt = NO;      /* Turn off page headers and footers --
                                                        not desired when reports are to be
                                                        reviewed on screen. */

```

### 3.5.1.3 DELETE

DELETE followed by a class name and an object name removes the specified object, and any subobjects it has. You might do this after RUN when changing the data for a similar run (but to remove all data, CLEAR is handier), or you might use DELETE after COPYing (below) an object if the intent is to copy all but certain subobjects.

### 3.5.1.4 LIKE clause

LIKE lets you specify that an object being defined starts with the same member values as another object already defined. You then need give only those members that are different. For Example:

```

MATERIAL "SheetRock";          // half inch gypsum board
  matCond = .0925;              // conductivity per foot
  matSpHt = .26;                // specific heat
  matDens = 50;                 // density
  matThk = 0'0.5;               // thickness 1/2 inch
MATERIAL "5/8 SheetRock" LIKE "SheetRock"; // 5/8" gypsum board
  matThk = 0'0.625;             // thickness 5/8 inch
// other members same as "SheetRock", need not be repeated

```

The object named after LIKE must be already defined and must be of the same class as the new object.

LIKE copies only the member values; it does not copy any subobjects of the prototype object. For example, LIKEing a **ZONE** to a previously defined **ZONE** does not cause the new zone to contain the surfaces of the prototype **ZONE**. If you want to duplicate the surfaces, use COPY instead of LIKE.

### 3.5.1.5 COPY clause

COPY lets you specify that the object being defined is the same as a previously defined object including all of the subobjects of that object. For example,

```

. . .
ZONE "West" COPY "North";
  DELETE WALL "East";
  ALTER WALL "South";
  sfExCnd = ambient;

```

Specifies a **ZONE** named “West” which is the same as **ZONE** North except that it does not contain a copy of West’s East wall, and the South wall has ambient exposure.

### 3.5.1.6 USETYPE clause

USETYPE followed by the type name is used in creating an object of a type previously defined with DEFTYPE (next section). Example:

```

SURFACE "EastWall" USETYPE "IntWall";      // use interior wall TYPE (below)
  sfAzm = 90;                               // this wall faces to the East
  sfArea = 8 * 30;                          // area of each wall is different
  sfAdjZn = "East";                         // zone on other side of wall

```

Any differences from the type, and any required information not given in the type, must then be specified. Any member specified in the type may be respecified in the object unless FROZEN (see [this section](#)) in the type (normally, a duplicate specification for a member results in an error message).

### 3.5.1.7 DEFTYPE

DEFTYPE is used to begin defining a TYPE for a class. When a TYPE is created, no object is created; rather, a partial or complete object description is stored for later use with DEFTYPE. TYPES facilitate creating multiple similar objects, as well as storing commonly used descriptions in a file to be #included in several different files, or to be altered for multiple runs in comparative studies without changing the including files. Example (boldface for emphasis only):

```

DEFTYPE SURFACE "BaseWall"                // common characteristics of all walls
  sfType = WALL;                          // walls are walls, so say it once
  sfTilt = 90;                            // all our walls are vertical;
                                           // but sfAzm varies, so it is not in TYPE.
  sfU = .83;                              // surf conductance; override if different
  sfModel = QUICK;

DEFTYPE SURFACE "ExtWall" USETYPE "BaseWall";
  sfExCnd = AMBIENT;                      // other side of wall is outdoors
  sfExAbs = 0.5;                          // member only needed for exterior walls

DEFTYPE SURFACE "IntWall" USETYPE "BaseWall"; // interior wall
  sfExCnd = ADJZN;                        // user must give sfAdjZn.

```

In a TYPE as much or as little of the description as desired may be given. Omitting normally-required members does not result in an error message in the type definition, though of course an error will occur at use if the member is not given there.

At use, member values specified in the TYPE can normally be re specified freely; to prevent this, “freeze” the desired member(s) in the type definition with

```
FREEZE *memberName*;
```

Alternately, if you wish to be sure the user of the TYPE enters a particular member even if it is normally optional, use

```
REQUIRE *memberName*
```

Sometimes in the TYPE definition, member(s) that you do not want defined are defined – for example, if the TYPE definition were itself initiated with a statement containing LIKE, COPY, or USETYPE. In such cases the member specification can be removed with

```
UNSET *memberName*;
```

#### 3.5.1.8 END and ENDxxxx

END, optionally followed by an object name, can be used to unequivocally terminate an object. Further, as of July 1992 there is still available a specific word to terminate each type of object, such as ENDZONE to terminate a **ZONE** object. If the object name is given after END or ENDxxxx, an additional check is performed: if the name is not that of an object which has been begun and not terminated, an error message occurs. Generally, we have found it is not important to use END or ENDxxxx, especially since the member names in different classes are distinct.

### 3.5.2 Member Statements

As introduced in the section on **statements**, statements which assign values to members are of the general form:

```
*memberName* = *expression*;
```

The specific member names for each class of objects are given in Section 5; many have already been shown in examples.

Depending on the member, the appropriate type for the expression giving the member value may be numeric (integer or floating point), string, object name, or multiple-choice. Expressions of all types will be described in detail in the section on **expressions**.

Each member also has its *variability* (also given in the **input data** section), or maximum acceptable *variation*. This is how often the expression for the value can change during the simulation – hourly, daily, monthly, no change (constant), etc. The “variations” were introduced in the **expressions overview** section and will be further detailed in a **section on variation frequencies**.

Three special statements, UNSET, REQUIRE, and FREEZE, add flexibility in working with members.

#### 3.5.2.1 UNSET

UNSET followed by a member name is used when it is desired to delete a member value previously given. UNSETing a member resets the object to the same internal state it was in before the member was originally given. This makes it legal to specify a new value for the member (normally, a duplicate specification results in an error message); if the member is required (as specified in the **input data** section), then an error message will occur if RUN is given without re-specifying the member.

Situations where you really might want to specify a member, then later remove it, include:

- After a RUN command has completed one simulation run, if you wish to specify another simulation run without CLEARing and giving all the data again, you may need to UNSET some members of some objects in order to re-specify them or because they need to be omitted from the new run. In this case, use ALTER(s) to reopen the object(s) before UNSETing.
- In defining a TYPE (see **this section**), you may wish to make sure certain members are not specified so that the user must give them or omit them if desired. If the origin of the type (possibly a sequence of DEFTYPES, LIKEs, and/or COPYs) has defined unwanted members, get rid of them with UNSET.

Note that UNSET is only for deleting *members* (names that would be followed with an = and a value when being defined). To delete an entire *object*, use DELETE (see **this section**).

### 3.5.2.2 REQUIRE

REQUIRE followed by a member name makes entry of that member mandatory if it was otherwise optional; it is useful in defining a TYPE (see [this section](#)) when you desire to make sure the user enters a particular member, for example to be sure the TYPE is applied in the intended manner. REQUIRE by itself does not delete any previously entered value, so if the member already has a value, you will need to UNSET it. ??  
*verify*

### 3.5.2.3 FREEZE

FREEZE followed by a member name makes it illegal to UNSET or redefine that member of the object. Note that FREEZE is unnecessary most of the time since CSE issues an error message for duplicate definitions without an intervening UNSET, unless the original definition came from a TYPE (see [this section](#)). Situations where you might want to FREEZE one or more members include:

- When defining a TYPE (see [this section](#)). Normally, the member values in a type are like defaults; they can be freely overridden by member specifications at each use. If you wish to insure a TYPE is used as intended, you may wish to FREEZE members to prevent accidental misuse.
- When you are defining objects for later use or for somebody else to use (perhaps in a file to be included) and you wish to guard against misuse, you may wish to FREEZE members. Of course, this is not foolproof, since there is at present no way to allow use of predefined objects or types without allowing access to the statements defining them.

## 3.5.3 Action Commands

CSE has two action commands, RUN and CLEAR.

### 3.5.3.1 RUN

RUN tells CSE to do an hourly simulation with the data now in memory, that is, the data given in the preceding part of the input file.

Note that CSE does NOT automatically run the simulator; an input file containing no RUN results in no simulation (you might nevertheless wish to submit an incomplete file to CSE to check for errors in the data already entered). The explicit RUN command also makes it possible to do multiple simulation runs in one session using a single input file.

When RUN is encountered in the input file, CSE checks the data. Many error messages involving inconsistencies between member values or missing required members occur at this time. If the data is good, CSE starts the simulation. When the simulation is complete and the reports have been output, CSE continues reading the input file. Statements after the first run can add to or change the data in preparation for another RUN. Note that the data for the first run is NOT automatically removed; if you wish to start over with complete specifications, use CLEAR after RUN.

### 3.5.3.2 CLEAR

CLEAR removes all input data (objects and all their members) from CSE memory. CLEAR is normally used after RUN, when you wish to perform another simulation run and wish to start clean. If CLEAR is not used, the objects from the prior run's input remain in memory and may be changed or added to produce the input data for the next simulation run.

## 3.6 Expressions

Probably the CSE input language's most powerful characteristic is its ability to accept expressions anywhere a single number, string, object name, or other value would be accepted. Preceding examples have shown the inputting zone areas and volumes as numbers (some defined via preprocessor macros) with \*'s between them to signify multiplication, to facilitate changes and avoid errors that might occur in manual arithmetic. Such

expressions, where all operands are constants, are acceptable *anywhere* a constant of the same type would be allowed.

But for many object members, CSE accepts *live expressions* that *vary* according to time of day, weather, zone temperatures, etc. (etc., etc., etc.). Live expressions permit simulation of many relationships without special-purpose features in the language. Live expressions support controlling setpoints, scheduling HVAC system operation, resetting air handler supply temperature according to outdoor temperature, and other necessary and foreseen functions without dedicated language features; they will also support many unforeseen user-generated functionalities that would otherwise be unavailable.

Additional expression flexibility is provided by the ability to access all of the input data and much of the internal data as operands in expressions (*probes*, see [this section](#)).

As in a programming language, CSE expressions are constructed from operators and operands; unlike most programming languages, CSE determines how often an expression's operands change and automatically compute and store the value as often as necessary.

Expressions in which all operands are known when the statement is being decoded (for example, if all values are constants) are *always* allowed, because the input language processor immediately evaluates them and presents the value to the rest of the program in the same manner as if a single number had been entered. *Most* members also accept expressions that can be evaluated as soon as the run's input is complete, for example expressions involving a reference to another member that has not been given yet. Expressions that vary during the run, say at hourly or daily intervals, are accepted by *many* members. The *variability* or maximum acceptable variation for each member is given in the descriptions in the [input data](#) section, and the *variation* of each non-constant expression component is given in its description in this section.

Interaction of expressions and the preprocessor: Generally, they don't interact. The preprocessor is a text processor which completes its work by including specified files, deleting sections under false #if's, remembering define definitions, replacing macro calls with the text of the definition, removing preprocessor directives from the text after interpreting them, etc., *then* the resulting character stream is analyzed by the input language statement compiler. However, the if statement takes an integer numeric expression argument. This expression is similar to those described here except that it can only use constant operands, since the preprocessor must evaluate it before deciding what text to feed to the input statement statement compiler.

### 3.6.1 Expression Types

The type of value to which an expression must evaluate is specified in each member description (see the [input data](#) section) or other context in which an expression can be used. Each expression may be a single constant or may be made up of operators and operands described in the rest of this section, so long as the result is the required type or can be converted to that type by CSE, and its variation is not too great for the context. The possible types are:

<i>float</i>	A real number (3.0, 5.34, -2., etc.). Approximately 7 digits are carried internally. If an int is given where a real is required, it is automatically converted.
<i>int</i>	An integer or whole number (-1, 0, 1, 2 etc.). If a real is given, an error may result, but we should change it to convert it (discarding any fractional part).
<i>Boolean</i>	Same as int; indicates that a 0 value will be interpreted as "false" and any non-0 value will be interpreted as "true".
<i>string</i>	A string of characters; for example, some text enclosed in quotes.
<i>object name</i>	Name of an object of a specified class. Differs from <i>string</i> in that the name need not be enclosed in quotes if it consists only of letters, digits, <code>_</code> , and <code>\$</code> , begins with a non-digit, and is different from all reserved words now in or later added to the language (see <a href="#">Object Names</a> ).

<i>choice</i>	<p>The object may be defined after it is referred to. An expression using conditional operators, functions, etc. may be used provided its value is known when the RUN action command is reached.; no members requiring object names accept values that vary during the simulation. One of several choices; a list of the acceptable values is given wherever a <i>choice</i> is required. The choices are usually listed in CAPITALS but may be entered in upper or lower case as desired. As with object names, quotes are allowed but not required. Expressions may be used for choices, subject to the variability of the context.</p>
<i>date</i>	<p>May be entered as a 3-letter month abbreviation followed by an <i>int</i> for the day of the month, or an <i>int</i> for the Julian day of the year (February is assumed to have 28 days). Expressions may be used subject to variability limitations. Examples:</p> <pre>Jan 23    // January 23 23        // January 23 32        // February 1</pre>

These words are used in following descriptions of contexts that can accept more than one basic type:

<i>numeric</i>	<i>float</i> or <i>int</i> . When floats and ints are intermixed with the same operator or function, the result is float.
<i>anyType</i>	Any type; the result is the same type as the argument. If floats and ints are intermixed, the result is float. If strings and valid choice names are intermixed, the result is <i>choice</i> . Other mixtures of types are generally illegal, except in expressions for a few members that will accept either one of several choices or a numeric value.

The next section describes the syntax of constants of the various data types; then, we will describe the available operators, then other operand types such as system variables and built-in functions.

### 3.6.2 Constants

This section reviews how to enter ordinary non-varying numbers and other values.

<i>int</i>	<p>optional - sign followed by digits. Don't use a decimal point if your intent is to give an <i>int</i> quantity – the decimal point indicates a <i>float</i> to CSE. Hexadecimal and Octal values may be given by prefixing the value with 0x and 0O respectively (yes, that really is a zero followed by an 'O').</p>
<i>float</i>	<p>optional - sign, digits and decimal point. Very large or small values can be entered by following the number with an "e" and a power of ten. Examples:</p> <pre>1.0  1.   .1  -5534.6  123.e25  4.56e-23</pre> <p>The decimal point indicates a float as opposed to an int. Generally it doesn't matter as CSE converts ints to floats as required, but be careful when dividing: CSE interprets "2/3" as integer two divided by integer 3, which will produce an integer 0 before CSE notices any need to convert to <i>float</i>. If you mean .6666667, say 2./3, 2/3., or .6666667.</p>

<i>feet and inches</i>	Feet and inches may be entered where a <i>float</i> number of feet is required by typing the feet (or a 0 if none), a single quote ', then the inches. (Actually this is an operator meaning “divide the following value by 12 and add it to the preceding value”, so expressions can work with it.) Examples: 3'6 0'.5 (10+20)'(2+3)
<i>string</i>	“Text” – desired characters enclosed in double quotes. Maximum length 80 characters (make 132??). To put a " within the "", precede it with a backslash. Certain control codes can be represented with letters preceded with a backslash as follows: <pre> \\e    escape \\t    tab \\f    form feed \\r    carriage return \\n    newline or line feed </pre>
<i>object name</i>	Same as <i>string</i> , or without quotes if name consists only of letters, digits, _, and \$, begins with a non-digit, and is different from all reserved words now in or later added to the language (see <b>Object Names</b> ). Control character codes (ASCII 0-31) are not allowed.
<i>choice</i>	Same as <i>string</i> ; quotes optional on choice words valid for the member. Capitalization does not matter.
<i>date</i>	Julian day of year (as <i>int</i> constant), or month abbreviation Jan Feb Mar Apr May Jun Jul Aug Sep Oct Nov De c followed by the <i>int</i> day of month. (Actually, the month names are operators implemented to add the starting day of the month to the following <i>int</i> quantity).

### 3.6.3 Operators

For *floats* and *ints*, the CSE input language recognizes a set of operators based closely on those found in the C programming language. The following table describes the available numeric operators. The operators are shown in the order of execution (precedence) when no ()'s are used to control the order of evaluation; thin lines separate operators of equal precedence.

Operator	Name	Notes and Examples
'	Feet-Inches Separator	a ' b yields a + b/12; thus 4'6 = 4.5.
+	Unary plus	The familiar “positive”, as in +3. Does nothing; rarely used.
-	Unary minus	The familiar “minus”, as in -3. -(-3) = +3 etc.
!	Logical NOT	Changes 0 to 1 and any non-0 value to 0. !0 = 1, !17 = 0.
~	One's complement	Complements each bit in an <i>int</i> value.
*	Multiplication	Multiplication, e.g. 3*4 = 12; 3.24*18.54 = 60.07
/	Division	Division, e.g. 4/2 = 2, 3.24/1.42 = 2.28. Integer division truncates toward 0 (e.g. 3/2 = 1, 3/-2 = -1, -3/2 = -1, 2/3 = 0)
%	Modulus	CAUTION! Yields the remainder after division, e.g. 7%2 = 1. The result has the same sign as the left operand (e.g. (-7)%2 = -1). % is defined for both integer and floating point operands (unlike ANSI C).



Operator	Name	Notes and Examples
+	Addition	Yields the sum of the operands, e.g. $5+3 = 8$
-	Subtraction	Yields the difference of the operands, e.g. $5-3 = 2$
>>	Right shift	$a >> b$ yields a shifted right $b$ bit positions, e.g. $8 >> 2 = 2$
<<	Left shift	$a << b$ yields a shifted left $b$ bit positions, e.g. $8 << 2 = 32$
<	Less than	$a < b$ yields 1 if $a$ is less than $b$ , otherwise 0
<=	Less than or equal	$a <= b$ yields 1 if $a$ is less than or equal to $b$ , otherwise 0
>=	Greater than or equal	$a >= b$ yields 1 if $a$ is greater than or equal to $b$ , otherwise 0
>	Greater than	$a > b$ yields 1 if $a$ is greater than $b$ , otherwise 0
==	Equal	$a == b$ yields 1 if $a$ is <i>exactly</i> (bit wise) equal to $b$ , otherwise 0
!=	Not equal	$a != b$ yields 1 if $a$ is not equal to $b$ , otherwise 0
&	Bitwise and	$a \& b$ yields the bitwise AND of the operands, e.g. $6 \& 2 = 2$ .
^	Bitwise exclusive or	$a \wedge b$ yields the bitwise XOR of the operands, e.g. $6 \wedge 2 = 4$ .
	Bitwise inclusive or	$a   b$ yields the bitwise IOR of the operands, e.g. $6   2 = 6$ .
&&	Logical AND	$a \&\& b$ yields 1 if both $a$ and $b$ are non-zero, otherwise 0. $\&\&$ guarantees left to right evaluation: if the first operand evaluates to 0, the second operand is not evaluated and the result is 0.
	Logical OR	$a    b$ yields 1 if either $a$ or $b$ is true (non-0), otherwise 0. $  $ guarantees left to right evaluation: if the first operand evaluates to non-zero, the second operand is not evaluated and the result is 1.
? :	Conditional	$a ? b : c$ yields $b$ if $a$ is true (non-0), otherwise $c$ .

*Dates* are stored as *ints* (the value being the Julian day of the year), so all numeric operators could be used. The month abbreviations are implemented as operators that add the first day of the month to the following *int* value; CSE does not disallow their use in other numeric contexts.

For *strings*, *object names*, and *choices*, the CSE input language currently has no operators except the `?:` conditional operator. A concatenation operator is being considered. Note, though, that the `choose`, `choose1`, `select`, and `hourval` functions described below work with strings, object names, and choice values as well as numbers.

### 3.6.4 System Variables

*System Variables* are built-in operands with useful values. To avoid confusion with other words, they begin with a `$`. Descriptions of the CSE system variables follow. Capitalization shown need not be matched. Most system variables change during a simulation run, resulting in the *variations* shown; they cannot be used where the context will not accept variation at least this fast. (The [Input Data Section](#) gives the *variability*,

or maximum acceptable variation, for each object member.)

\$dayOfYear	Day of year of simulation, 1 - 365; 1 corresponds to Jan-1. (Note that this is not the day of the simulation unless begDay is Jan-1.) <b>Variation:</b> daily.
\$month	Month of year, 1 - 12. <b>Variation:</b> monthly.
\$dayOfMonth	Day of month, 1 - 31. <b>Variation:</b> daily.
\$hour	Hour of day, 1 - 24, in local time; 1 corresponds to midnight - 1 AM. <b>Variation:</b> hourly.
\$hourST	Hour of day, 1 - 24, in standard time; 1 corresponds to midnight - 1 AM. <b>Variation:</b> hourly.
\$subhour	Subhour of hour, 1 - N (number of subhours). <b>Variation:</b> subhourly.
\$dayOfWeek	Day of week, 1 - 7; 1 corresponds to Sunday, 2 to Monday, etc. <b>Variation:</b> daily.
\$DOWH	Day of week 1-7 except 8 on every observed holiday. <b>Variation:</b> daily.
\$isHoliday	1 on days that a holiday is observed (regardless of the true date of the holiday); 0 on other days. <b>Variation:</b> daily.
\$isHoliTrue	1 on days that are the true date of a holiday, otherwise 0. <b>Variation:</b> daily.
\$isWeHol	1 on weekend days or days that are observed as holidays. <b>Variation:</b> daily.
\$isWeekend	1 on Saturday and Sunday, 0 on any day from Monday to Friday. <b>Variation:</b> daily.
\$isWeekday	1 on Monday through Friday, 0 on Saturday and Sunday. <b>Variation:</b> daily.
\$isBegWeek	1 for any day immediately following a weekend day or observed holiday that is neither a weekend day or an observed holiday. <b>Variation:</b> daily.
\$isWorkDay	1 on non-holiday Monday through Friday, 0 on holidays, Saturday and Sunday. <b>Variation:</b> daily.
\$isNonWorkDay	1 on Saturday, Sunday and observed holidays, 0 on non-holiday Monday through Friday. <b>Variation:</b> daily.
\$isBegWorkWeek	1 on the first workday after a non-workday, 0 all other days. <b>Variation:</b> daily.
\$isDT	1 if Daylight Saving time is in effect, 0 otherwise. <b>Variation:</b> hourly.
\$autoSizing	1 during autosizing calculations, 0 during main simulation. <b>Variation:</b> for each phase.
\$dsDay	Design day type, 0 during main simulation, 1 during heating autosize, 2 during cool autosize. <b>Variation:</b> daily.

**Weather variables:** the following allow access to the current hour's weather conditions in you CSE expressions. Units of measure are shown in parentheses. All have **Variation:** hourly.

\$radBeam	Solar beam irradiance (on a sun-tracking surface) this hour (Btu/ft <sup>2</sup> )
\$radDiff	Solar diffuse irradiance (on horizontal surface) this hour (Btu/ft <sup>2</sup> )
\$tDbO	Outdoor drybulb temperature this hour (degrees F)
\$tWbO	Outdoor wetbulb temperature this hour (degrees F)
\$wO	Outdoor humidity ratio this hour (lb H <sub>2</sub> O/lb dry air)
\$windDirDeg	Wind direction (compass degrees)
\$windSpeed	Wind speed (mph)

### 3.6.5 Built-in Functions

Built-in functions perform a number of useful scheduling and conditional operations in expressions. Built-in functions have the combined variation of their arguments; for *hourval*, the minimum result variation is hourly. For definitions of *numeric* and *anyType*, see [Expression Types](#).

#### 3.6.5.1 brkt

<b>Function</b>	limits a value to be in a given range
<b>Syntax</b>	<i>numeric</i> <b>brkt</b> ( <i>numeric min</i> , <i>numeric val</i> , <i>numeric max</i> )
<b>Remark</b>	If <i>val</i> is less than <i>min</i> , returns <i>min</i> ; if <i>val</i> is greater than <i>max</i> , returns <i>max</i> ; if <i>val</i> is in between, returns <i>val</i> .
<b>Example</b>	In an AIRHANDLER object, the following statement would specify a supply temperature equal to 130 minus the outdoor air temperature, but not less than 55 nor greater than 80: <pre>ahTsSp = brkt( 55, 130 - \$tDb0, 80);</pre> This would produce a 55-degree setpoint in hot weather, an 80-degree setpoint in cold weather, and a transition from 55 to 70 as the outdoor temperature moved from 75 to 50.

#### 3.6.5.2 fix

<b>Function</b>	converts <i>float</i> to <i>int</i>
<b>Syntax</b>	<i>int</i> <b>fix</b> ( <i>float val</i> )
<b>Remark</b>	<i>val</i> is converted to <i>int</i> by truncation – <b>fix</b> ( 1.3) and <b>fix</b> ( 1.99) both return 1. <b>fix</b> ( -4.4) returns -4.

#### 3.6.5.3 toFloat

<b>Function</b>	converts <i>int</i> to <i>float</i>
<b>Syntax</b>	<i>float</i> <b>toFloat</b> ( <i>int val</i> )

#### 3.6.5.4 min

<b>Function</b>	returns the lowest quantity from a list of values.
<b>Syntax</b>	<i>numeric</i> <b>min</b> ( <i>numeric value1</i> , <i>numeric value2</i> , ... <i>numeric valuen</i> )
<b>Remark</b>	there can be any number of arguments separated by commas; if floats and ints are intermixed, the result is float.

#### 3.6.5.5 max

<b>Function</b>	returns the highest quantity from a list of values.
<b>Syntax</b>	<i>numeric</i> <b>max</b> ( <i>numeric value1</i> , <i>numeric value2</i> , ... <i>numeric valuen</i> )

#### 3.6.5.6 choose

<b>Function</b>	returns the <i>n</i> th value from a list. If <i>arg0</i> is 0, <i>value0</i> is returned; for 1, <i>value1</i> is returned, etc.
-----------------	---

<b>Syntax</b>	<i>anyType</i> <b>choose</b> ( <i>int</i> <i>arg0</i> , <i>anyType</i> <i>value0</i> , <i>anyType</i> <i>value1</i> , ... <i>anyType</i> <i>valuen</i> ) or <i>anyType</i> <b>choose</b> ( <i>int</i> <i>arg0</i> , <i>anyType</i> <i>value0</i> , ... <i>anyType</i> <i>valuen</i> , <b>default</b> <i>valueDef</i> )
<b>Remarks</b>	Any number of <i>value</i> arguments may be given. If <b>default</b> and another value is given, this value will be used if <i>arg0</i> is less than 0 or too large; otherwise, an error will occur.

## 3.6.5.7 choose1

<b>Function</b>	same as <b>choose</b> except <i>arg0</i> is 1-based. <b>Choose1</b> returns the second argument <i>value1</i> for <i>arg0</i> = 1, the third argument <i>value2</i> when <i>arg0</i> = 2, etc.
<b>Syntax</b>	<i>anyType</i> <b>choose1</b> ( <i>int</i> <i>arg0</i> , <i>anyType</i> <i>value1</i> , <i>anyType</i> <i>value2</i> , ... <i>anyType</i> <i>valuen</i> ) or <i>anyType</i> <b>choose1</b> ( <i>int</i> <i>arg0</i> , <i>anyType</i> <i>value1</i> , ... <i>anyType</i> <i>valuen</i> , <b>default</b> <i>valueDef</i> )
<b>Remarks</b>	<b>choose1</b> is a function that is well suited for use with daily system variables. For example, if a user wanted to denote different values for different days of the week, the following use of <b>choose1</b> could be implemented: <pre>tuTC = choose1(\\$dayOfWeek, MonTemp, TueTemp, ...)</pre> Note that for hourly data, the <b>hourval</b> function would be a better choice, because it doesn't require the explicit declaration of the \$hour system variable.

## 3.6.5.8 select

<b>Function</b>	contains Boolean-value pairs; returns the value associated with the first Boolean that evaluates to true (non-0).
<b>Syntax</b>	<i>anyType</i> ( <i>Boolean</i> <i>arg1</i> , <i>anyType</i> <i>value1</i> , <i>Boolean</i> <i>arg2</i> , <i>anyType</i> <i>value2</i> , ... <b>default</b> <i>anyType</i> ) (the <b>default</b> part is optional)
<b>Remark</b>	<b>select</b> is a function that simulates if-then logic during simulation (for people familiar with C, it works much like a series of imbedded conditionals: (a?b:(a?b:c)) ).
<b>Examples</b>	Select can be used to simulate a <b>dynamic</b> (run-time) <b>if-else statement</b> : <pre>gnPower = select( \$isHoliday, HD_GAIN, // if (\$isHolid a y) default WD_GAIN) // else</pre> This technique can be combined with other functions to schedule items on a hourly and daily basis. For example, an internal gain that has different schedules for holidays, weekdays, and weekends could be defined as follows: <pre>// 24-hour lighting power schedules for weekend, weekda y , holiday: #define WE_LIGHT hourval( .024, .022, .021, .021, .021 , . 026, \ .038, .059, .056, .060, .059, .046, \ .045, .005, .005, .005, .057, .064, \ .064, .052, .050, .055, .044, .027 ) #define WD_LIGHT hourval( .024, .022, .021, .021, .021 , . 026, \ .038, .059, .056, .060, .059, .046, \ .045, .005, .005, .005, .057, .064, \ .064, .052, .050, .055, .044, .027 ) #define HD_LIGHT hourval( .024, .022, .021, .021, .021 , . 026, \ .038, .059, .056, .060, .059, .046, \</pre>

```

        .045, .005, .500, .005, .057, .064, \
        .064, .052, .050, .055, .044, .027 )
// set power member of zone's GAIN object for lighting
gnPower = BTU_Elec( ZAREA*0.1 ) *           // .1 kW/ft2 ti mes...
select( $isHoliday, HD_LIGHT,    // Holidays
        $isWeekend, WE_LIGHT,    // Saturday & Sunday
        default    WD_LIGHT ); // Week Days

```

In the above, three subexpressions using **hourval** (next) are first defined as macros, for ease of reading and later change. Then, gnPower (the power member of a GAIN object) is set, using **select** to choose the appropriate one of the three **hourval** calls for the type of day. The expression for gnPower is a *live expression* with hourly variation, that is, CSE will evaluate it and set gnPower to the latest value each hour of the simulation. The variation comes from **hourval**, which varies hourly (also, \$isHoliday and \$isWeekend vary daily, but the faster variation determines the variation of the result).

### 3.6.5.9 hourval

<b>Function</b>	from a list of 24 values, returns the value corresponding to the hour of day.
<b>Syntax</b>	<i>anyType</i> <b>hourval</b> ( <i>anyType</i> value1, <i>anyType</i> value2, ... <i>anyType</i> value24 ) <i>anyType</i> <b>hourval</b> ( <i>anyType</i> value1, <i>anyType</i> value2, ... <b>default</b> <i>anyType</i> )
<b>Remark</b>	<b>hourval</b> is evaluated at runtime and uses the hour of the day being simulated to choose the corresponding value from the 24 supplied values. If less than 24 <i>value</i> arguments are given, <b>default</b> and another value (or expression) should be supplied to be used for hours not explicitly specified.
<b>Example</b>	see <b>select</b> , just above.

### 3.6.5.10 abs

<b>Function</b>	converts numeric to its absolute value
<b>Syntax</b>	numeric <b>abs</b> ( numeric val)

### 3.6.5.11 sqrt

<b>Function</b>	Calculates and returns the positive square root of <i>val</i> ( <i>val</i> must be $\geq 0$ ).
<b>Syntax</b>	<i>float</i> <b>sqrt</b> ( <i>float</i> val)

### 3.6.5.12 exp

<b>Function</b>	Calculates and returns the exponential of <i>val</i> ( $= e^{val}$ )
<b>Syntax</b>	<i>float</i> <b>exp</b> ( <i>float</i> val)

### 3.6.5.13 logE

<b>Function</b>	Calculates and returns the base e logarithm of <i>val</i> ( <i>val</i> must be $\geq 0$ ).
<b>Syntax</b>	<i>float</i> <b>logE</b> ( <i>float</i> val)

### 3.6.5.14 log10

---

<b>Function</b>	Calculates and returns the base 10 logarithm of <i>val</i> ( <i>val</i> must be $\geq 0$ ).
<b>Syntax</b>	<i>float</i> <b>log10</b> ( <i>float val</i> )

---

**3.6.5.15 sin**


---

<b>Function</b>	Calculates and returns the sine of <i>val</i> (val in radians)
<b>Syntax</b>	<i>float</i> <b>sin</b> ( <i>float val</i> )

---

**3.6.5.16 sind**


---

<b>Function</b>	Calculates and returns the sine of <i>val</i> (val in degrees)
<b>Syntax</b>	<i>float</i> <b>sind</b> ( <i>float val</i> )

---

**3.6.5.17 asin**


---

<b>Function</b>	Calculates and returns (in radians) the arcsine of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>asin</b> ( <i>float val</i> )

---

**3.6.5.18 asind**


---

<b>Function</b>	Calculates and returns (in degrees) the arcsine of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>asind</b> ( <i>float val</i> )

---

**3.6.5.19 cos**


---

<b>Function</b>	Calculates and returns the cosine of <i>val</i> (val in radians)
<b>Syntax</b>	<i>float</i> <b>cos</b> ( <i>float val</i> )

---

**3.6.5.20 cosd**


---

<b>Function</b>	Calculates and returns the cosine of <i>val</i> (val in degrees)
<b>Syntax</b>	<i>float</i> <b>cosd</b> ( <i>float val</i> )

---

**3.6.5.21 acos**


---

<b>Function</b>	Calculates and returns (in radians) the arccosine of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>acos</b> ( <i>float val</i> )

---

**3.6.5.22 acosd**


---

<b>Function</b>	Calculates and returns (in degrees) the arccosine of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>acosd</b> ( <i>float val</i> )

---

**3.6.5.23 tan**

<b>Function</b>	Calculates and returns the tangent of <i>val</i> (val in radians)
<b>Syntax</b>	<i>float</i> <b>tan</b> ( <i>float val</i> )

**3.6.5.24 tand**

<b>Function</b>	Calculates and returns the tangent of <i>val</i> (val in degrees)
<b>Syntax</b>	<i>float</i> <b>tand</b> ( <i>float val</i> )

**3.6.5.25 atan**

<b>Function</b>	Calculates and returns (in radians) the arctangent of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>atan</b> ( <i>float val</i> )

**3.6.5.26 atand**

<b>Function</b>	Calculates and returns (in degrees) the arctangent of <i>val</i>
<b>Syntax</b>	<i>float</i> <b>atand</b> ( <i>float val</i> )

**3.6.5.27 atan2**

<b>Function</b>	Calculates and returns (in radians) the arctangent of y/x (handling x = 0)
<b>Syntax</b>	<i>float</i> <b>atan2</b> ( <i>float y</i> , <i>float x</i> )

**3.6.5.28 atan2d**

<b>Function</b>	Calculates and returns (in degrees) the arctangent of y/x (handling x = 0)
<b>Syntax</b>	<i>float</i> <b>atan2d</b> ( <i>float y</i> , <i>float x</i> )

**3.6.5.29 pow**

<b>Function</b>	Calculates and returns <i>val</i> raised to the <i>x</i> th power ( $= val^x$ ). <i>val</i> and <i>x</i> cannot both be 0. If <i>val</i> < 0, <i>x</i> must be integral.
<b>Syntax</b>	<i>float</i> <b>pow</b> ( <i>float val</i> , <i>numeric x</i> )

**3.6.5.30 enthalpy**

<b>Function</b>	Returns enthalpy of moist air (Btu/lb) for dry bulb temperature (F) and humidity ratio (lb/lb)
<b>Syntax</b>	<i>float</i> <b>enthalpy</b> ( <i>float tDb</i> , <i>float w</i> )

**3.6.5.31 wFromDbWb**

<b>Function</b>	Returns humidity ratio (lb/lb) of moist air from dry bulb and wet bulb temperatures (F)
<b>Syntax</b>	<i>float</i> <b>wFromDbWb</b> ( <i>float tDb</i> , <i>float tWb</i> )

## 3.6.5.32 wFromDbRh

<b>Function</b>	Returns humidity ratio (lb/lb) of moist air from dry bulb temperature (F) and relative humidity (0 – 1)
<b>Syntax</b>	<i>float</i> <b>wFromDbRh</b> ( <i>float</i> <i>tDb</i> , <i>float</i> <i>rh</i> )

## 3.6.5.33 import

<b>Function</b>	Returns <i>float</i> read from an import file.
<b>Syntax</b>	<i>float</i> <b>import</b> ( <i>string</i> <i>importFile</i> , <i>string</i> <i>colName</i> ) <i>float</i> <b>import</b> ( <i>string</i> <i>importFile</i> , <i>int</i> <i>colN</i> )
<b>Remark</b>	Columns can be referenced by name or 1-based index. See <b>IMPORTFILE</b> for details on use of import()

## 3.6.5.34 importStr

<b>Function</b>	Returns <i>string</i> read from an import file.
<b>Syntax</b>	<i>string</i> <b>importStr</b> ( <i>string</i> <i>importFile</i> , <i>string</i> <i>colName</i> ) <i>string</i> <b>importStr</b> ( <i>string</i> <i>importFile</i> , <i>int</i> <i>colN</i> )
<b>Remark</b>	See <b>IMPORTFILE</b> for details on use of importStr()

## 3.6.5.35 contin

<b>Function</b>	Returns continuous control value, e.g. for lighting control
<b>Syntax</b>	<i>float</i> <b>contin</b> ( <i>float</i> <i>mpf</i> , <i>float</i> <i>mlf</i> , <i>float</i> <i>sp</i> , <i>float</i> <i>val</i> )
<b>Remark</b>	<b>contin</b> is evaluated at runtime and returns a value in the range 0 – 1 ???
<b>Example</b>	–

## 3.6.5.36 stepped

<b>Function</b>	Returns stepped reverse-acting control value, e.g. for lighting control
<b>Syntax</b>	<i>float</i> <b>stepped</b> ( <i>int</i> <i>nsteps</i> , <i>float</i> <i>sp</i> , <i>float</i> <i>val</i> )
<b>Remark</b>	<b>stepped</b> is evaluated at runtime and returns a value in the range 0 – 1. If <i>val</i> ≤ 0, 1 is returned; if <i>val</i> ≥ <i>sp</i> , 0 is returned; otherwise, a stepped intermediate value is returned (see example)

example:

**stepped**( 3, 12, *val*) returns

<i>val</i>	<i>result</i>
<i>val</i> < 4	1
4 ≤ <i>val</i> < 8	.667
8 ≤ <i>val</i> < 12	.333
<i>val</i> ≥ 12	0



### 3.6.6 User-defined Functions

User defined functions have the format:

```
type FUNCTION name ( arg decls ) = expr ;
```

*Type* indicates the type of value the function returns, and can be:

```
INTEGER
FLOAT
STRING
DOY      (day of year date using month name and day; actually same as integer).
```

*Arg decls* indicates zero or more comma-separated argument declarations, each consisting of a *type* (as above) and the name used for the argument in *expr*.

*Expr* is an expression of (or convertible to) *type*.

The tradeoffs between using a user-defined function and a preprocessor macro (**#define**) include:

1. Function may be slightly slower, because its code is always kept separate and called, while the macro expansion is inserted directly in the input text, resulting in inline code.
2. Function may use less memory, because only one copy of it is stored no matter how many times it is called.
3. Type checking: the declared types of the function and its arguments allow CSE to perform additional checks.

Note that while macros require line-splicing (“\”) to extend over one line, functions do not require it:

```
// Function returning number of days in ith month of year:
DOY FUNCTION MonthLU (integer i) = choose1 ( i , Jan 31, Feb 28, Mar 31,
                                           Apr 30, May 31, Jun 30,
                                           Jul 31, Aug 31, Sep 30,
                                           Oct 31, Nov 30, Dec 31 ) ;

// Equivalent preprocessor macro:
#define MonthLU (i) = choose1 ( i , Jan 31, Feb 28, Mar 31, \
                               Apr 30, May 31, Jun 30, \
                               Jul 31, Aug 31, Sep 30, \
                               Oct 31, Nov 30, Dec 31 ) ;
```

### 3.6.7 Probes

*Probes* provide a universal means of referencing data within the simulator. Probes permit using the inputtable members of each object, as described in the [Input Data](#) Section, as operands in expressions. In addition, most internal members can be probed; we will describe how to find their names shortly.

Three general ways of using probes are:

1. During input, to implement things like “make this window’s width equal to 10% of the zone floor area” by using the zone’s floor area in an expression:

```
wnWidth = @zone[1].znArea * 0.1;
```

Here “@zone[1].znArea” is the probe.

2. During simulation. Probing during simulation, to make inputs be functions of conditions in the building or HVAC systems, is limited because most of the members of interest are updated *after* CSE has evaluated the user’s expressions for the subhour or other time interval – this is logically necessary since the expressions are inputs. (An exception is the weather data, but this is also available through system variables such as \$tDbO.)

However, a number of *prior subhour* values are available for probing, making it possible to implement relationships like “the local heat output of this terminal is 1000 Btuh if the zone temperature last subhour was below 65, else 500”:

```
tuMnLh = @znres["North"].S.prior.tAir < 65 ? 1000 : 500;
```

- For output reports, allowing arbitrary data to be reported at subhourly, hourly, daily, monthly, or annual intervals. The REPORT class description describes the user-defined report type (UDT), for which you write the expression for the value to be reported. With probes, you can thus report almost any datum within CSE – not just those values chosen for reporting when the program was designed. Even values calculated during the current subhour simulation can be probed and reported, because expressions for reports are evaluated after the subhour's calculations are performed.

Examples:

```
colVal = @airHandler["Hot"].ts;    // report air handler supply temp
colVal = @terminal[NorthHot].cz;   // terminal air flow to zone (Btuh/F)
```

The general form of a probe is

```
@ className [ objName ] . member
```

The initial @ is always necessary. And don't miss the period after the ].

*className* is the CLASS being probed

<i>objName</i>	is the name of the specific object of the class; alternately, a numeric subscript is allowed. Generally, the numbers correspond to the objects in the order created. [ <i>objName</i> ] can be omitted for the TOP class, which has only one member, Top.
<i>member</i>	is the name of the particular member being probed. This must be exactly correct. For some inputtable members, the probe name is not the same as the input name given in the <b>Input Data</b> Section, and there are many probe-able members not described in the <b>Input Data</b> section.

How do you find out what the probe-able member names are? CSE will display the a list of the latest class and member names if invoked with the -p switch. Use the command line

```
CSE -p >probes.txt
```

to put the displayed information into the file PROBES.TXT, then print the file or examine it with a text editor.

A portion of the -p output looks like:

```
@exportCol[1..].      I  R      owner: export
    name              I  R  string      constant
    colHead           I  R  string      input time
    colGap            I  R  integer number input time
    colWid            I  R  integer number input time
    colDec            I  R  integer number input time
    colJust           I  R  integer number constant
    colVal            I  R  un-probe-able end of each subhour
    nxColi            I  R  integer number constant

@holiday[1..].        I
    name              I      string      constant
    hdDateTrue        I      integer number constant
    hdDateObs         I      integer number constant
```

hdOnMonday I integer number constant

In the above “exportCol” and “holiday” are class names, and “name”, “colHead”, “colGap”, . . . are member names for class exportCol. Some members have multiple names separated by ‘.’s, or they may contain an additional subscript. To probe one of these, type all of the names and punctuation exactly as shown (except capitalization may differ); if an additional subscript is shown, give a number in the specified range. An “I” designates an “input” parameter, an R means “runtime” parameter. The “owner” is the class of which this class is a subclass.

The data type and variation of each member is also shown. Note that *variation*, or how often the member changes, is shown here. (*Variability*, or how often an expression assigned to the member may change, is given for the input table members in the [Input Data](#) Section). Members for which an “end of” variation is shown can be probed only for use in reports. A name described as “un-probe-able” is a structure or something not convertible to an integer, float, or string.

surface[].sgdist[].f[]: f[0] is winter solar coupling fraction; f[1] is summer.

### 3.6.8 Variation Frequencies Revisited

At risk of beating the topic to death, we’re going to review once more the frequencies with which a CSE value can change (*variations*), with some comments on the corresponding *variabilities*.

subhourly	changes in each “subhour” used in simulation. Subhours are commonly 15-minute intervals for models using znModel=CNE or 2-minute intervals for CSE znModels.
hourly	changes every simulated hour. The simulated weather and many other aspects of the simulation change hourly; it is customary to schedule setpoint changes, HVAC system operation, etc. in whole hours.
daily	changes at each simulated midnite.
monthly	changes between simulated months.
monthly-hourly, or “hourly on first day of each month”	changes once an hour on the first day of each month; the 24 hourly values from the first day of the month are used for the rest of the month. This variation and variability is used for data dependent on the sun’s position, to save calculation time over computing it every hour of every day.
run start time	value is derived from other inputs before simulation begins, then does not change. Members that cannot change during the simulation but which are not needed to derive other values before the simulation begins have “run start time” <i>variability</i> .
input time	value is known before CSE starts to check data and derive “run start time” values. Expressions with “input time” variation may be used in many members that cannot accept any variation during the run. Many members documented in the <a href="#">Input Data</a> Section as having “constant” variability may actually accept expressions with “input time” variation; to find out, try it: set the member to an expression containing a proposed probe and see if an error message results. “Input time” differs from “constant” in that it includes object names (forward references are allowed, and resolved just before other data checks) and probes that are forward references to constant values.
constant	does not vary. But a “constant” member of a class denoted as R (with no I) in the probes report produced by CSE -p is actually not available until run start time.

Also there are end-of varieties of all of the above; these are values computed during simulation: end of each

hour, end of run, etc. Such values may be reported (using a probe in a UDT report), but will produce an error message if probed in an expression for an input member value.

## 4 Input Data

This section describes the input for each CSE class (object type). For each object you wish to define, the usual input consists of the class name, your name for the particular object (usually), and zero or more member value statements of the form *name=expression*. The name of each subsection of this section is a class name (**HOLIDAY**, **MATERIAL**, **CONSTRUCTION**, etc.). The object name, if given, follows the class name; it is the first thing in each description (hdName, matName, conName, etc.). Exception: no statement is used to create or begin the predefined top-level object “Top” (of class **TOP**); its members are given without introduction.

After the object name, each member's description is introduced with a line of the form *name=type*. *Type* indicates the appropriate expression type for the value:

- *float*
- *int*
- *string*
- \_\_\_\_\_ *name* (object name for specified type of object)
- *choice*
- *date*

These types discussed in the section on **expression types**.

Each member's description continues with a table of the form:

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	x > 0	wnHeight * wnWidth	No	constant

where the column headers have the following meaning:

<i>Units</i>	units of measure (lb., ft, Btu, etc.) where applicable
<i>Legal</i>	limits of valid range for numeric inputs; valid choices
<i>Range</i>	for <i>choice</i> members, etc.
<i>Default</i>	value assumed if member not given; applicable only if not required
<i>Required</i>	YES if you must give this member
<i>Variability</i>	how often the given expression can change: hourly, daily, etc. See sections on <b>expressions</b> , <b>statements</b> , and <b>variation frequencies</b>

### 4.1 TOP Members

The top-level data items (TOP members) control the simulation process or contain data that applies to the modeled building as a whole. No statement is used to begin or create the TOP object; these statements can be given anywhere in the input (they do, however, terminate any other objects being specified – **ZONES**, **REPORTs**, etc.).

#### 4.1.1 TOP General Data Items

**doMainSim=choice**

Specifies whether the simulation is performed when a Run command is encountered. See also doAutoSize.

Units	Legal Range	Default	Required	Variability
	NO,YES	YES	No	constant

#### **begDay=*date***

Date specifying the beginning day of the simulation performed when a Run command is encountered. See further discussion under endDay (next).

Units	Legal Range	Default	Required	Variability
	<i>date</i>	Jan 1	No	constant

#### **endDay=*date***

Date specifying the ending day of the simulation performed when a Run command is encountered.

The program simulates 365 days at most. If begDay and endDay are the same, 1 day is simulated. If begDay precedes endDay in calendar sequence, the simulation is performed normally and covers begDay through endDay inclusive. If begDay follows endDay in calendar sequence, the simulation is performed across the year end, with Jan 1 immediately following Dec 31.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	Dec 31	No	constant

#### **jan1DoW=*choice***

Day of week on which January 1 falls.

Units	Legal Range	Default	Required	Variability
	SUN MON TUE WED THU FRI SAT	THU	No	constant

#### **workDayMask=*int* TODO**

Units	Legal Range	Default	Required	Variability
		Mon-fri?	No	constant

#### **wuDays=*int***

Number of “warm-up” days used to initialize the simulator. Simulator initialization is required because thermal mass temperatures are set to arbitrary values at the beginning of the simulation. Actual mass temperatures must be established through simulation of a few days before thermal loads are accumulated. Heavier buildings require more warm-up; the default values are adequate for conventional construction.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	7	No	constant

**nSubSteps=***int*

Number of subhour steps used per hour in the simulation. 4 is the time-honored value for models using CNE zones. A value of 30 is typically for CSE zone models.

Units	Legal Range	Default	Required	Variability
	$x > 0$	4	No	constant

**tol=***float*

Endtest convergence tolerance for internal iteration in CNE models (no effect for CSE models) Small values for the tolerance cause more accurate simulations but slower performance. The user may wish to use a high number during the initial design process (to quicken the runs) and then lower the tolerance for the final design (for better accuracy). Values other than .001 have not been explored.

Units	Legal Range	Default	Required	Variability
	$x > 0$	.001	No	constant

**humTolF=***float*

Specifies the convergence tolerance for humidity calculations in CNE models (no effect in for CSE models), relative to the tolerance for temperature calculations. A value of .0001 says that a humidity difference of .0001 is about as significant as a temperature difference of one degree. Note that this is multiplied internally by “tol”; to make an overall change in tolerances, change “tol” only.

Units	Legal Range	Default	Required	Variability
	$x > 0$	.0001	No	

**ebTolMon=***float*

Monthly energy balance error tolerance for internal consistency checks. Smaller values are used for testing the internal consistency of the simulator; values somewhat larger than the default may be used to avoid error messages when it is desired to continue working despite a moderate degree of internal inconsistency.

Units	Legal Range	Default	Required	Variability
	$x > 0$	0.0001	No	constant

**ebTolDay=***float*

Daily energy balance error tolerance.

Units	Legal Range	Default	Required	Variability
	$x > 0$	0.0001	No	constant

**ebTolHour=float**

Hourly energy balance error tolerance.

Units	Legal Range	Default	Required	Variability
	$x > 0$	0.0001	No	constant

**ebTolSubhr=float**

Sub-hourly energy balance error tolerance.

Units	Legal Range	Default	Required	Variability
	$x > 0$	0.0001	No	constant

**grndMinDim=float**

The minimum cell dimension used in the two-dimensional finite difference calculations for **FOUNDATIONS**.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	0.066	No	constant

**grndMaxGrthCoeff=float**

The maximum ratio of growth between neighboring cells in the direction away from the near-field area of interest. Used in the two-dimensional finite difference calculations for **FOUNDATIONS**.

Units	Legal Range	Default	Required	Variability
	$x \geq 1.0$	1.5	No	constant

**grndTimeStep=choice**

Allows the user to choose whether to calculate foundation conduction on hourly or subhourly intervals. Hourly intervals require less overall computation time, but with less accuracy.

Units	Legal Range	Default	Required	Variability
	HOURLY, SUBHOURLY	HOURLY	No	constant

**humMeth=choice**

Developmental zone humidity computation method choice for CNE models (no effect for CSE models).

ROB	Rob's backward difference method. Works well within limitations of backward difference approach.
PHIL	Phil's central difference method. Should be better if perfected, but initialization at air handler startup is unresolved, and ringing has been observed.

Units	Legal Range	Default	Required	Variability
	ROB, PHIL	ROB	No	constant

**dfExH=float**

Default exterior surface (air film) conductance used for opaque and glazed surfaces exposed to ambient conditions in the absence of explicit specification.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	2.64	No	constant

**bldgAzm=float**

Reference compass azimuth (0 = north, 90 = east, etc.). All zone orientations (and therefore surface orientations) are relative to this value, so the entire building can be rotated by changing bldgAzm only. If a value outside the range  $0^\circ \leq x < 360^\circ$  is given, it is normalized to that range.

Units	Legal Range	Default	Required	Variability
° (degrees)	unrestricted	0	No	constant

**elevation=float**

Elevation of the building site. Used internally for the computation of barometric pressure and air density of the location.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0 (sea level)	No	constant

**runTitle=string**

Run title for the simulation. Appears in report footers, export headers, and in the title lines to the INP, LOG, and ERR built-in reports (these appear by default in the primary report file; the ERR report also appears in the error message file, if one is created).

Units	Legal Range	Default	Required	Variability
	63 characters	blank (no title)	No	constant

**runSerial=int**

Run serial number for the simulation. Increments on each run in a session; appears in report footers.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 999$	0	No	constant

**4.1.2 TOP Daylight Saving Time Items**

Daylight savings starts by default at 2:00 a.m. of the second Sunday in March. Internally, hour 3 (2:00-3:00 a.m.) is skipped and reports for this day show only 23 hours. Daylight savings ends by default at 2:00 a.m.



of the first Sunday of November; for this day 25 hours are shown on reports. CSE fetches weather data using standard time but uses daylight savings time to calculate variable expressions (and thus all schedules).

### **DT=choice**

Whether Daylight Savings Time is to be used for the current run.

Units	Legal Range	Default	Required	Variability
	YES, NO	YES	No	constant

### **DTbegDay=date**

Start day for daylight saving time (assuming DT=Yes)

Units	Legal Range	Default	Required	Variability
<i>date</i>		<i>second Sunday in March</i>	No	constant

### **DTendDay=date**

End day for daylight saving time (assuming DT=Yes)

Units	Legal Range	Default	Required	Variability
<i>date</i>		<i>first Sunday in November</i>	No	constant

## 4.1.3 TOP Model Control Items

### **ventAvail=choice**

Indicates availability of outdoor ventilation strategies. CSE cannot model simultaneously-operating alternative ventilation strategies. For example, an **RSYS** central fan integrated (CFI) OAV system is never modeled while whole house fan ventilation is available. ventAvail controls which ventilation mode, if any, is available for the current hour. Note that mode availability means that the strategy could operate but may not operate due to other control assumptions.

Choice	Ventilation Strategy Available
NONE	None
WHOLEBUILDING	IZXFER (window and whole-house fan)
RSYSOAV	RSYS central fan integrated (CFI) outside air ventilation (OAV)

As noted, ventAvail is evaluated hourly, permitting flexible control strategy modeling. The following example specifies that RSYSOAV (CFI) ventilation is available when the seven day moving average temperature is above 68 °F, otherwise whole building ventilation is available between 7 and 11 PM, otherwise no ventilation.

```
ventAvail = (@weather.taDbAvg07 > 68) ? RSYSOAV
           : ($hour >= 19 && $hour <= 23) ? WHOLEBUILDING
           : NONE
```

Units	Legal Range	Default	Required	Variability
	<i>Choices above</i>	WHOLEBUILDING	No	hourly

**dhwModel=choice**

Modifies aspects of DHW calculations.

Choice	Effect
T24DHW	Matches results from T24DHW.DLL
2013	Corrected CEC 2013 methods with 2016 updates

  

Units	Legal Range	Default	Required	Variability
	<i>Choices above</i>	2013	No	constant

**exShadeModel=choice**

Specifies advanced exterior shading model used to evaluate shading of **PVARRAYs** by **SHADEXs** or other **PVARRAYs**. Advanced shading is not implemented for building surfaces and this setting has no effect on walls or windows.

Choice	Effect
PENUMBRA	Calculate shading using the Penumbra model
NONE	Disable advanced shading calculations

Units	Legal Range	Default	Required	Variability
	<i>Choices above</i>	PENUMBRA	No	constant

**ANTolAbs=float**

AirNet absolute convergence tolerance. Ideally, calculated zone air pressures should be such that the net air flow into each zone is 0 – that is, there should be a perfect mass balance. The iterative AirNet solution techniques are deemed converged when  $\text{netAirMassFlow} < \max(\text{ANTolAbs}, \text{ANTolRel} * \text{totAirMassFlow})$ .

Units	Legal Range	Default	Required	Variability
lbm/sec	$x > 0$	0.00125 (about 1 cfm)	No	constant

**ANTolRel=float**

AirNet relative convergence tolerance. See AnTolAbs just above.

Units	Legal Range	Default	Required	Variability
	$x > 0$	.0001	No	constant

The ASHWAT complex fenestration model used when **WINDOW** wnModel=ASHWAT yields several heat transfer results that are accurate over local ranges of conditions. Several values control when these value are recalculated. If any of the specified values changes more than the associated threshold, a full ASHWAT calculation is triggered. Otherwise, prior results are used. ASHWAT calculations are computationally expensive and conditions often change only incrementally between time steps.

**AWTrigT=float**

ASHWAT temperature change threshold – full calculation is triggered by a change of either indoor or outdoor environmental (combined air and radiant) temperature that exceeds AWTrigT.

Units	Legal Range	Default	Required	Variability
°F	$x > 0$	1	No	constant

#### AWTrigSlr=*float*

ASHWAT solar change threshold – full calculation is triggered by a fractional change of incident solar radiation that exceeds AWTrigSlr.

Units	Legal Range	Default	Required	Variability
	$x > 0$	.05	No	constant

#### AWTrigH=*float*

ASHWAT convection coefficient change threshold – full calculation is triggered by a fractional change of inside surface convection coefficient that exceeds AWTrigH.

Units	Legal Range	Default	Required	Variability
	$x > 0$	.1	No	constant

#### 4.1.4 TOP Weather Data Items

The following system variables (4.6.4) are determined from the weather file for each simulated hour:

\$radBeam	beam irradiance on tracking surface (integral for hour, Btu/ft <sup>2</sup> ).
\$radDiff	diffuse irradiance on a horizontal surface (integral for hour, Btu/ft <sup>2</sup> ).
\$tDbO	dry bulb temp (°F).
\$tWbO	wet bulb temp (°F).
\$wO	humidity ratio
\$windDirDeg	wind direction (degrees, NOT RADIANS; 0=N, 90=E).
\$windSpeed	wind speed (mph).

The following are the terms determined from the weather file for internal use, and can be referenced with the probes shown.

@Top.depressWbWet bulb depression (F).

@Top.windSpeedSquaredWind speed squared (mph<sup>2</sup>).

#### wfName=*string*

Weather file path name for simulation. The file should be in the current directory, in the directory CSE.EXE was read from, or in a directory on the operating system PATH. Weather file formats supported are CSW, EPW, and ET1. Only full-year weather files are supported.

Note: Backslash (\) characters in path names must be doubled to work properly (e.g. “\\wthr\\mywthr.epw”). Forward slash (/) may be used in place of backslash without doubling.

Units	Legal Range	Default	Required	Variability
	file name,path optional		Yes	constant

Units	Legal Range	Default	Required	Variability
	file name,path optional		Yes	constant

**skyModel=choice**

Selects sky model used to determine relative amounts of direct and diffuse irradiance.

ISOTROPIC	traditional isotropic sky model
ANISOTROPIC	Hay anisotropic model

Units	Legal Range	Default	Required	Variability
	choices above	ANISOTROPIC	No	constant

**skyModelLW=choice**

Selects the model used to derive sky temperature used in long-wave (thermal) radiant heat exchange calculations for **SURFACEs** exposed to ambient conditions. See the RACM alorithms documentation for technical details.

Choice	Description
DEFAULT	Default: tSky from weather file if available else Berdahl-Martin
BERDAHLMARTIN	Berdahl-Martin (tSky depends on dew point, cloud cover, and hour)
DRYBULB	tSky = dry-bulb temperature (for testing)
BLAST	Blast model (tSky depends on dry-bulb)

Units	Legal Range	Default	Required	Variability
	choices above	DEFAULT	No	constant

The reference temperature and humidity are used to calculate a humidity ratio assumed in air specific heat calculations. The small effect of changing humidity on the specific heat of air is generally ignored in the interests of speed, but the user can control the humidity whose specific heat is used through the refTemp and refRH inputs.

**refTemp=float**

Reference temperature (see above paragraph).

Units	Legal Range	Default	Required	Variability
°F	$x \geq 0$	60°	No	constant

**refRH=float**

Reference relative humidity (see above).

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.6	No	constant

### **grndRefl=float**

Global ground reflectivity, used except where other value specified with sfGrndRefl or wnGrndRefl. This reflectivity is used in computing the reflected beam and diffuse radiation reaching the surface in question. It is also used to calculate the solar boundary conditions for the exterior grade surface in two-dimensional finite difference calculations for **FOUNDATIONS**.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.2	No	Monthly-Hourly

The following values modify weather file data, permitting varying the simulation without making up special weather files. For example, to simulate without the effects of wind, use windF = 0; to halve the effects of diffuse solar radiation, use radDiff = 0.5. Note that the default values for windSpeedMin and windF result in modification of weather file wind values unless other values are specified.

### **grndEmit=float**

Long-wave emittance of the exterior grade surface used in two-dimensional finite difference calculations for **FOUNDATIONS**.

Units	Legal Range	Default	Required	Variability
	0.0 <i>le</i> x <i>le</i> 1.0	0.8	No	constant

### **grndRf**

Ground surface roughness. Used for convection and wind speed corrections in two-dimensional finite difference calculations for **FOUNDATIONS**.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0.0$	0.1	No	constant

### **windSpeedMin=float**

Minimum value for wind speed

Units	Legal Range	Default	Required	Variability
mph	$x \geq 0$	0.5	No	constant

### **windF=float**

Wind Factor: multiplier for wind speeds read from weather file. windF is applied *after* windSpeedMin. Note that windF does *not* effect infiltration rates calculated by the Sherman-Grimsrud model (see e.g. ZONE.infELA). However, windF does modify AirNet flows (see **IZXFER**).

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	0.25	No	constant

**terrainClass=int**

Specifies characteristics of ground terrain in the project region.

1	ocean or other body of water with at least 5 km unrestricted expanse
2	flat terrain with some isolated obstacles (buildings or trees well separated)
3	rural areas with low buildings, trees, etc.
4	urban, industrial, or forest areas
5	center of large city

Units	Legal Range	Default	Required	Variability
	$1 \leq x \leq 5$	4	No	constant

**radBeamF=float**

Multiplier for direct normal (beam) irradiance

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	1	No	constant

**radDiffF=float**

Multiplier for diffuse horizontal irradiance.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	1	No	constant

**hConvMod=choice**

Enable/disable convection convective coefficient pressure modification factor.

$$0.24 + 0.76 \cdot P_{Location} / P_{SeaLevel}$$

Units	Legal Range	Default	Required	Variability
	YES, NO	YES	No	constant

**soilDiff=float**

*Note: soilDiff is used as part of the simple ground model, which is no longer supported. Use soilCond, soilSpHt, and SoilDens instead.*

Soil diffusivity, used in derivation of ground temperature. CSE calculates a ground temperature at 10 ft depth for each day of the year using dry-bulb temperatures from the weather file and soilDiff. Ground temperature is used in heat transfer calculations for **SURFACEs** with sfExCnd=GROUND. Note: derivation

of mains water temperature for DHW calculations involves a ground temperature based on soil diffusivity = 0.025 and does not use this soilDiff.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup> /hr	$x > 0$	0.025	No	constant

**soilCond=float**

Soil conductivity. Used in two-dimensional finite difference calculations for FOUNDATIONs.

Units	Legal Range	Default	Required	**Variability
Btuh-ft/ft <sup>2</sup> -°F	$x > 0$	1.0	No	constant

**soilSpHt=float**

Soil specific heat. Used in two-dimensional finite difference calculations for FOUNDATIONs.

Units	Legal Range	Default	Required	Variability
Btu/lb-°F	$x > 0$	0.1	No	constant

**soilDens=float**

Soil density. Used in two-dimensional finite difference calculations for FOUNDATIONs.

Units	Legal Range	Default	Required	Variability
lb/ft <sup>3</sup>	$x > 0$	115	No	constant

**farFieldWidth=float**

Far-field width. Distance from foundation to the lateral, zero-flux boundary condition. Used in two-dimensional finite difference calculations for FOUNDATIONs.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	130	No	constant

**deepGrndCnd=choice**

Deep-ground boundary condition type. Choices are WATERTABLE (i.e., a defined temperature) or ZEROFLUX.

Units	Legal Range	Default	Required	Variability
–	WATERTABLE, ZEROFLUX	ZEROFLUX	No	constant

**deepGrndDepth=float**

Deep-ground depth. Distance from exterior grade to the deep-ground boundary. Used in two-dimensional

finite difference calculations for FOUNDATIONS.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	130	No	constant

**deepGrndT**=*float*

Deep-ground temperature. Used when deepGrndCnd=WATERTABLE.

Units	Legal Range	Default	Required	Variability
F	$x > 0$	Annual average drybulb temperature	No	hourly

#### 4.1.5 TOP TDV (Time Dependent Value) Items

CSE supports an optional comma-separated (CSV) text file that provides hourly TDV values for electricity and fuel. TDV values are read along with the weather file and the values merged with weather data. Several daily statistics are calculated for use via probes. The file has no other effect on the simulation. Only full-year TDV files are supported.

The format of a TDV file is the same as an IMPORTFILE with the proviso that the 4 line header is not optional and certain header items must have specified values. In the following table, non-italic items must be provided as shown (with optional quotes).

Line	Contents	Notes
1	TDV Data (TDV/Btu),	<i>runNumber</i> is not checked
2	<i>runNumber</i>	optionally in quotes
3	<i>timestamp</i>	accessible via @TOP.TDVFileTimeStamp
4	<i>title</i> , hour	<i>title</i> (in quotes if it contains commas)
5	tdvElec, tdvFuel	accessible via @TOP.TDVFileTitle
6		comma separated column names (optionally in quotes)
7	<i>valElec</i> , <i>valFuel</i>	not checked
8		comma separated numerical values (8760 or 8784 rows)
9		tdvElec is always in column 1, tdvFuel always in column 2
10		column names in row 4 do not determine order

Example TDV file –

```
"TDV Data (TDV/Btu)","001"
"Wed 14-Dec-16 12:30:29 pm"
"BEMCmpMgr 2019.0.0 RV (758), CZ12, Fuel NatGas", Hour
"tdvElec","tdvFuel"
7.5638,2.2311
7.4907,2.2311
7.4478,2.2311
7.4362,2.2311
7.5255,2.2311
7.5793,2.2311
```



```

7.6151,2.2311
7.6153,2.2311
7.5516,2.2311
(... continues for 8760 or 8784 data lines ...)

```

Note: additional columns can be included and are ignored.

The table below shows probes available for accessing TDV data in expressions. Except as noted, daily values are updated based on standard time, so they may be inaccurate by small amounts when daylight savings time is in effect.

Probe	Variability	Description
@Weather.tdvElec	Hour	current hour electricity TDV
@Weather.tdvFuel	Hour	current hour fuel TDV
@Weather.tdvElecPk	Day	current day peak electricity TDV (includes future hours). Updated at hour 23 during daylight savings.
@Weather.tdvElecAvg	Day	current day average electricity TDV (includes future hours)
@Weather.tdvElecPvPk	Day	previous day peak electricity TDV
@Weather.tdvElecAvg0 1	Day	previous day average electricity TDV
@weather.tdvElecHrRa nk	Day	hour ranking of TDVElec values. tdvElecHrRank[ 1] is the hour having the highest TDVElec, tdvElecHrRank[ 2] is the next highest, etc. The hour values are adjusted when daylight savings time is in effect, so they remain consistent with system variable \$hour.
@weatherFile.tdvFile TimeStamp	Constant	TDV file timestamp (line 2 of header)
@weatherFile.tdvFile Title	Constant	TDV file title (line 3 of header)
@Top.tdvFName	Constant	TDV file full path

**TDVfName=string**

Note: Backslash (\) characters in path names must be doubled to work properly (e.g. "\\data\\mytdv.tdv"). Forward slash (/) may be used in place of backslash without doubling.

Units	Legal Range	Default	Required	Variability
	file name, path optional	(no TDV file)	No	constant

#### 4.1.6 TOP Report Data Items

These items are used in page-formatted report output files. See [REPORTFILE](#), Section 5.245.21, and [REPORT](#), Section 5.25.

**repHdrL=string**

Report left header. Appears at the upper left of each report page unless page formatting (rfPageFmt) is OFF. If combined length of repHdrL and repHdrR is too large for the page width, one or both will be truncated.

Units	Legal Range	Default	Required	Variability
		blank	No	constant??

**repHdrR=string**

Report right header. Appears at the upper right of each report page unless page formatting (rfPageFmt) is OFF. If combined length of repHdrL and repHdrR is too large for the page width, one or both will be truncated.

Units	Legal Range	Default	Required	Variability
		<i>blank</i> (no right header)	No	constant??

**repLPP=int**

Total lines per page to be assumed for reports. Number of lines used for text (including headers and footers) is repLPP - repTopM - repBotM.

Units	Legal Range	Default	Required	Variability
lines	$x \geq 50$	66	No	constant??

**repTopM=int**

Number of lines to be skipped at the top of each report page (prior to header).

Units	Legal Range	Default	Required	Variability
lines	$0 \leq x \leq 12$	3	No	constant

**repBotM=int**

Number of lines reserved at the bottom of each report page. repBotM determines the position of the footer on the page (blank lines after the footer are not actually written).

Units	Legal Range	Default	Required	Variability
lines	$0 \leq x \leq 12$	3	No	constant

**repCPL=int**

Characters per line for report headers and footers, user defined reports, and error messages. CSE writes simple ASCII files and assumes a fixed (not proportional) spaced printer font. Many of the built-in reports now (July 1992) assume a line width of 132 columns.

Units	Legal Range	Default	Required	Variability
characters	$78 \leq x \leq 132$	78	No	constant

**repTestPfx=string**

Report test prefix. Appears at beginning of report lines that are expected to differ from prior runs. This is useful for “hiding” lines from text comparison utilities in automated testing schemes. Note: the value specified with command line -x takes precedence over this input.

Units	Legal Range	Default	Required	Variability
		<i>blank</i>	No	constant??

#### 4.1.7 TOP Autosizing

**doAutoSize=choice**

Controls invocation of autosizing phase prior to simulation.

Units	Legal Range	Default	Required	Variability
	YES, NO	NO, unless AUTOSIZE commands in input	No	constant

**auszTol=float**

Autosize tolerance. Sized capacity results are deemed final when successive design day calculations produce results within auszTol of the prior iteration.

Units	Legal Range	Default	Required	Variability
		.005	No	constant

**heatDsTDbO=float**

Heating outdoor dry bulb design temperature used for autosizing heating equipment.

Units	Legal Range	Default	Required	Variability
°F			if autosizing	hourly

**heatDsTWbO=float**

Heating outdoor Wet bulb design temperature used for autosizing heating equipment.

Units	Legal Range	Default	Required	Variability
°F		derived assuming RH=.7	No	hourly

**coolDsDay=list of up to 12 days**

Specifies cooling design days for autosizing. Each day will be simulated repeatedly using weather file conditions for that day.

Units	Legal Range	Default	Required	Variability
dates		none	No	constant

**coolDsMo=list of up to 12 months**

Deprecated method for specifying cooling autosizing days. Design conditions are taken from ET1 weather file header, however, the limited available ET1 files do not contain design condition information.

Units	Legal Range	Default	Required	Variability
months		none	No	constant

### 4.1.8 TOP Debug Reporting

**verbose=***int*

Controls verbosity of screen remarks. Most possible remarks are generated during autosizing of CNE models. Little or no effect in CSE models. TODO: document options

Units	Legal Range	Default	Required	Variability
	0 - 5	1	No	constant

The following dbgPrintMask values provide bitwise control of addition of semi-formatted internal results to the run report file. The values and format of debugging reports are modified as required for testing purposes.

**dbgPrintMaskC=***int*

Constant portion of debug reporting control.

Units	Legal Range	Default	Required	Variability
		0	No	constant

**dbgPrintMask=***int*

Hourly portion of debug reporting control (generally an expression that evaluates to non-0 only on days or hours of interest).

Units	Legal Range	Default	Required	Variability
		0	No	hourly

#### Related Probes:

- @top
- @weatherFile
- @weather
- @weatherNextHour

## 4.2 HOLIDAY

HOLIDAY objects define holidays. Holidays have no inherent effect, but input expressions can test for holidays via the \$DOWH, \$isHoliday, \$isHoliTrue, \$isWeHol, and \$isBegWeek system variables (4.6.4).

Examples and the list of default holidays are given after the member descriptions.

**hdName**

Name of holiday: must follow the word HOLIDAY.

Units	Legal Range	Default	Required	Variability
	63 characters	none	Yes	constant

A holiday may be specified by date or via a rule such as “Fourth Thursday in November”. To specify by date, give hdDateTrue, and also hdDateObs or hdOnMonday if desired. To specify by rule, give all three of hdCase, hdMon, and hdDow.

**hdDateTrue=*date***

The true date of a holiday, even if not celebrated on that day.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	<i>blank</i>	No	constant

**hdDateObs=*date***

The date that a holiday will be observed. Allowed only if hdDateTrue given and hdOnMonday not given.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	<i>hdDateTrue</i>	No	constant

**hdOnMonday=*choice***

If YES, holiday is observed on the following Monday if the true date falls on a weekend. Allowed only if hdDateTrue given and hdDateObs not given.

Note: there is no provision to celebrate a holiday that falls on a Saturday on *Friday* (as July 4 was celebrated in 1992).

Units	Legal Range	Default	Required	Variability
	YES NO	YES	No	constant

**hdCase=*choice***

Week of the month that the holiday is observed. hdCase, hdMon, and hdDow may be given only if hdDateTrue, hdDateObs, and hdOnMonday are not given.

Units	Legal Range	Default	Required	Variability
	FIRST SECOND THIRD FOURTH LAST	FIRST	No	constant

**hdMon=*choice***

Month that the holiday is observed.

Units	Legal Range	Default	Required	Variability
	JAN, FEB, MAR, APR, MAY, JUN, JUL, AUG, SEP, OCT, NOV, DEC	<i>none</i>	required if hdCase given	constant

**hdDow=*choice***

Day of the week that the holiday is observed.

Units	Legal Range	Default	Required	Variability
	SUNDAY, MONDAY, TUESDAY, WEDNES- DAY, THURSDAY, FRIDAY, SATURDAY	MONDAY	required if hdCase given	constant

**endHoliday**

Indicates the end of the holiday definition. Alternatively, the end of the holiday definition can be indicated by “END” or simply by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

Examples of valid HOLIDAY object specifications:

- Holiday on May first, observed date moved to following Monday if the first falls on a weekend (hdOnMonday defaults Yes).

```
HOLIDAY MAYDAY;
    hdDateTrue = May 1;
```

- Holiday on May 1, observed on May 3.

```
HOLIDAY MAYDAY;
    hdDateTrue = May 1;
    hdDateObs = May 3;
```

- Holiday observed on May 1 even if on a weekend.

```
HOLIDAY MAYDAY;
    hdDateTrue = May 1;
    hdOnMonday = No;
```

- Holiday observed on Wednesday of third week of March

```
HOLIDAY HYPOTHET;
    hdCase = third;
    hdDow = Wed;
    hdMon = MAR
```

As with reports, Holidays are automatically generated for a standard set of Holidays. The following are the default holidays automatically defined by CSE:

New Year's Day	*January 1
M L King Day	*January 15
President's Day	3rd Monday in February
Memorial Day	last Monday in May
Fourth of July	*July 4
Labor Day	1st Monday in September
Columbus Day	2nd Monday in October
Veterans Day	*November 11

Thanksgiving	4th Thursday in November
Christmas	*December 25

\* *observed on the following Monday if falls on a weekend, except as otherwise noted:*

If a particular default holiday is not desired, it can be removed with a DELETE statement:

```
DELETE HOLIDAY Thanksgiving
```

```
DELETE HOLIDAY "Columbus Day" // Quotes necessary (due to space)
```

```
DELETE HOLIDAY "VETERANS DAY" // No case-sensitivity
```

Note that the name must be spelled *exactly* as listed above.

#### Related Probes:

- @holiday

### 4.3 MATERIAL

MATERIAL constructs an object of class MATERIAL that represents a building material or component for later reference a from LAYER (see below). A MATERIAL so defined need not be referenced. MATERIAL properties are defined in a consistent set of units (all lengths in feet), which in some cases differs from units used in tabulated data. Note that the convective and air film resistances for the inside wall surface is defined within the SURFACE statements related to conductances.

#### matName

Name of material being defined; follows the word "MATERIAL".

Units	Legal Range	Default	Required	Variability
	63 characters	none	Yes	constant

#### matThk=float

Thickness of material. If specified, matThk indicates the discreet thickness of a component as used in construction assemblies. If omitted, matThk indicates that the material can be used in any thickness; the thickness is then specified in each LAYER using the material (see below).

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	(omitted)	No	constant

#### matCond=float

Conductivity of material. Note that conductivity is *always* stated for a 1 foot thickness, even when matThk is specified; if the conductance is known for a specific thickness, an expression can be used to derive matCond.

Units	Legal Range	Default	Required	Variability
Btuh-ft/ft <sup>2</sup> -°F	$x > 0$	none	Yes	constant

#### matCondT=float

Temperature at which matCond is rated. See matCondCT (next).

Units	Legal Range	Default	Required	Variability
°F	$x > 0$	70 °F	No	constant

**matCondCT=float**

Coefficient for temperature adjustment of matCond in the forward difference surface conduction model. Each hour (not subhour), the conductivity of layers using this material are adjusted as follows:  $\text{lrCond} = \text{matCond} * (1 + \text{matCondCT} * (T_{\text{layer}} - \text{matCondT}))$

Units	Legal Range	Default	Required	Variability
°F <sup>-1</sup>		0	No	constant

Note: A typical value of matCondCT for fiberglass batt insulation is 0.00418 F<sup>-1</sup>

**matSpHt=float**

Specific heat of material.

Units	Legal Range	Default	Required	Variability
Btu/lb-°F	$x \geq 0$	0 (thermally massless)	No	constant

**matDens=float**

Density of material.

Units	Legal Range	Default	Required	Variability
lb/ft <sup>3</sup>	$x \geq 0$	0 (massless)	No	constant

**matRNom=float**

Nominal R-value per foot of material. Appropriate for insulation materials only and *used for documentation only*. If specified, the current material is taken to have a nominal R-value that contributes to the reported nominal R-value for a construction. As with matCond, matRNom is *always* stated for a 1 foot thickness, even when matThk is specified; if the nominal R-value is known for a specific thickness, an expression can be used to derive matRNom.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup> -°F/Btuh	$x > 0$	(omitted)	No	constant

**endMaterial**

Optional to indicate the end of the material. Alternatively, the end of the material definition can be indicated by “END” or simply by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**



- @material

## 4.4 CONSTRUCTION

CONSTRUCTION constructs an object of class CONSTRUCTION that represents a light weight or massive ceiling, wall, floor, or mass assembly (mass assemblies cannot, obviously, be lightweight). Once defined, CONSTRUCTIONS can be referenced from SURFACES (below). A defined CONSTRUCTION need not be referenced. Each CONSTRUCTION is optionally followed by LAYERs, which define the constituent LAYERs of the construction.

### conName

Name of construction. Required for reference from SURFACE and DOOR objects, below.

Units	Legal Range	Default	Required	Variability
	63 characters	none	Yes	constant

### conU=float

U-value for the construction (NOT including surface (air film) conductances; see SURFACE statements). If omitted, one or more LAYERs must immediately follow to specify the LAYERs that make up the construction. If specified, no LAYERs can follow.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> - °F	$x > 0$	calculated from LAYERs	if omitted, LAYERs must follow	constant

### endConstruction

Optional to indicates the end of the CONSTRUCTION. Alternatively, the end of the CONSTRUCTION definition can be indicated by “END” or by beginning another object. If END or endConstruction is used, it should follow the construction’s LAYER subobjects, if any.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

### Related Probes:

- @construction

## 4.5 FOUNDATION

Foundation describes the two-dimensional relationship between ground-contact SURFACES (i.e., sfExCnd = GROUND) and the surrounding ground. A FOUNDATION is referenced by Floor SURFACES (see sfFnd). FOUNDATIONS are used to describe the two-dimensional features of foundation designs that cannot be captured by the typical one-dimensional constructions. Dimensions from the one-dimensional CONSTRUCTIONS associated with ground-contact floors and walls will automatically be interpreted into the two-dimensional context.

Any wall SURFACES in contact with the ground must refer to a Floor SURFACE object (see sfFndFloor) to indicate which floor shares the same ground domain as a boundary condition (and establish the two-dimensional context for the basis of the ground calculations).

Figure 1: Two-dimensional context

FOUNDATION objects are used to instantiate instances of heat transfer within Kiva.

**MATERIALs** used in a FOUNDATION cannot have variable properties at this time.

Most of the relevant dimensions and properties in the two-dimensional context are defined in the FOUNDATION object (and **FNDBLOCK** subobjects) with a few exceptions specified by specific SURFACES:

- sfFnd
- sfFndFloor
- sfHeight
- sfExpPerim
- sfCon

Some properties applying to all FOUNDATIONS are defined at the **TOP** level:

- soilCond
- soilSpHt
- soilDens
- grndEmiss
- grndRefl
- grndRf
- farFieldWidth
- deepGrndCnd
- deepGrndDepth
- deepGrndT
- grndMinDim
- grndMaxGrthCoeff
- grndTimeStep

The following data members describe the dimensions and properties of the foundation wall. For below-grade walls, the **CONSTRUCTION** (and corresponding width) of the foundation wall is defined by the Wall **SURFACES** referencing the FOUNDATION object. For on-grade floors, the **CONSTRUCTION** of the foundation wall must be defined using **fdFtCon**. The actual height of the foundation wall (from the top of the wall to the top of the slab) is defined by the corresponding **SURFACE** objects.

Other components of the foundation design (e.g., interior/exterior insulation) as well as other variations in thermal properties within the ground are defined using **FNDBLOCK** (foundation block) objects. Any number of **FNDBLOCKS** can appear after the definition of a FOUNDATION to be properly associated.

#### fdName

Name of foundation; give after the word FOUNDATION. Required for reference from **SURFACE** objects.

Units	Legal Range	Default	Required	Variability
–	63 characters	none	Yes	constant

#### fdWlHtAbvGrd=*float*

Wall height above grade.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0.0	No	constant

#### fdWIDpBlwSlb=*float*

Wall depth below slab.

Figure 2: Foundation wall dimensions

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0.0	No	constant

**fdFtCon=conName**

Name of **CONSTRUCTION** of the footing wall. Only required **IF** it is a slab foundation (i.e., no wall surfaces reference this FOUNDATION object).

Units	Legal Range	Default	Required	Variability
–	Name of a <i>Construction</i>	<i>none</i>	if a slab foundation	constant

**endFoundation**

Indicates the end of the foundation definition. Alternatively, the end of the foundation definition can be indicated by the declaration of another object or by END.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**4.6 FNDBLOCK**

Foundation blocks are materials within the two-dimensional domain beyond those defined by the slab and wall **SURFACES**. Each block is represented as a rectangle in the domain by specifying the X (lateral) and Z (vertical) coordinates of two opposite corners. The coordinate system for each point is relative to the X and Z references defined by the user. As a convention The positive X direction is away from the building, and the positive Z direction is down.

Options for X and Z references are illustrated in the figure below.

The default reference is WALLINT, WALLTOP.

An example of defining a block for interior wall insulation is shown below. Here the two points defining the block (P1 and P2) are both shown relative to their reference points (Ref1 and Ref2, respectively).

Note: X and Z point values of zero imply that a point is the same as the reference point. The default for X and Z point values is zero since points will often align with one or both of the reference values.

It does not matter which of the four corners of a block are used to define the two points as long as they are opposite corners.

**fbMat=matName**

Name of **MATERIAL** of the foundation block.

Units	Legal Range	Default	Required	Variability
–	Name of a <i>Material</i>	<i>none</i>	Yes	constant

**fbX1Ref=choice**

Relative X origin for *fbX1* point. Options are:

- SYMMETRY

Figure 3: Foundation block references

Figure 4: Foundation block example

- WALLINT
- WALLCENTER
- WALLEXT
- FARFIELD

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	WALLINT	No	constant

**fbZ1Ref=choice**

Relative Z origin for *fbZ1* point. Options are:

- WALLTOP
- GRADE
- SLABTOP
- SLABBOTTOM
- WALLBOTTOM
- DEEPGROUND

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	WALLTOP	No	constant

**fbX1=float**

The X position of the first corner of the block relative to *fbX1Ref*.

Units	Legal Range	Default	Required	Variability
ft		0.0	No	constant

**fbZ1=float**

The Z position of the first corner of the block relative to *fbZ1Ref*.

Units	Legal Range	Default	Required	Variability
ft		0.0	No	constant

**fbX2Ref=choice**

Relative X origin for *fbX2* point. Options are:

- SYMMETRY
- WALLINT
- WALLCENTER
- WALLEXT
- FARFIELD

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	WALLINT	No	constant

**fbZ2Ref=choice**



Relative Z origin for *fbZ2* point. Options are:

- WALLTOP
- GRADE
- SLABTOP
- SLABBOTTOM
- WALLBOTTOM
- DEEPGROUND

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	WALLTOP	No	constant

#### **fbX2=float**

The X position of the second corner of the block relative to *fbX2Ref*.

Units	Legal Range	Default	Required	Variability
ft		0.0	No	constant

#### **fbZ2=float**

The Z position of the second corner of the block relative to *fbZ2Ref*.

Units	Legal Range	Default	Required	Variability
ft		0.0	No	constant

#### **endFndBlock**

Indicates the end of the foundation block definition. Alternatively, the end of the foundation block definition can be indicated by the declaration of another object or by END.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

## 4.7 LAYER

LAYER constructs a subobject of class LAYER belonging to the current **CONSTRUCTION**. LAYER is not recognized except immediately following **CONSTRUCTION** or another LAYER. The members represent one layer (that optionally includes framing) within the **CONSTRUCTION**.

The layers should be specified in inside to outside order. A framed layer (lrFrmMat and lrFrmFrac given) is modeled by creating a homogenized material with weighted combined conductivity and volumetric heat capacity. Caution: it is generally preferable to model framed constructions using two separate surfaces (one with framing, one without). At most one framed layer (lrFrmMat and lrFrmFrac given) is allowed per construction.

The layer thickness may be given by lrThk, or matThk of the material, or matThk of the framing material if any. The thickness must be specified at least one of these three places; if specified in more than one place and not consistent, an error message occurs.

#### **lrName**

Name of layer (follows “LAYER”). Required only if the LAYER is later referenced in another object, for example with LIKE or ALTER; however, we suggest naming all objects for clearer error messages and future flexibility.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>None</i>	No	constant

**lrMat=matName**

Name of primary MATERIAL in layer.

Units	Legal Range	Default	Required	Variability
	name of a MATERIAL	<i>none</i>	Yes	constant

**lrThk=float**

Thickness of layer.

Units	Legal Range	Default/Required	Variability
ft	$x > 0$	Required if <i>matThk</i> not specified in referenced <i>lrMat</i>	constant

**lrFrmMat=matName**

Name of framing MATERIAL in layer, if any. At most one layer with lrFrmMat is allowed per CONSTRUCTION. See caution above regarding framed-layer model.

Units	Legal Range	Default	Required	Variability
	name of a MATERIAL	<i>no framed layer</i>	No	constant

**lrFrmFrac=float**

Fraction of layer that is framing. Must be specified if frmMat is specified. See caution above regarding framed-layer model.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	<i>no framed layer</i>	Required if <i>lrFrmMat</i> specified, else disallowed	constant

**endLayer**

Optional end-of-LAYER indicator; LAYER definition may also be indicated by “END” or just starting the definition of another LAYER or other object.

**Related Probes:**

- @layer

## 4.8 GLAZETYPE

GLAZETYPE constructs an object of class GLAZETYPE that represents a glazing type for use in **WINDOWS**.

### gtName

Name of glazetype. Required for reference from WINDOW objects, below.

Units	Legal Range	Default	Required	Variability
	63 characters	none	Yes	constant

### gtModel=choice

Selects model to be used for **WINDOWS** based on this GLAZETYPE.

Units	Legal Range	Default	Required	Variability
	SHGC ASHWAT	SHGC	No	constant

### gtU=float

Glazing conductance (U-factor without surface films, therefore not actually a U-factor but a C-factor). Used as wnU default; an error message will be issued if the U value is not given in the window (wnU) nor in the glazeType (gtU). Preferred Approach: To use accurately with standard winter rated U-factor from ASHRAE or NFRC enter as:

$$gtU = (1/((1/U\text{-factor})-0.85))$$

Where 0.85 is the sum of the interior (0.68) and exterior (0.17) design air film resistances assumed for rating window U-factors. Enter wnInH (usually 1.5=1/0.68) instead of letting it default. Enter the wnExH or let it default. It is important to use this approach if the input includes gnFrad for any gain term. Using approach 2 below will result in an inappropriate internal gain split at the window.

Approach 2. Enter gtU=U-factor and let the wnInH and wnExH default. This approach systematically underestimates the window U-factor because it adds the wnExfilm resistance to 1/U-factor thereby double counting the exterior film resistance. This approach will also yield incorrect results for gnFrad internal gain since the high wnInH will put almost all the gain back in the space.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	none	No	constant

### gtUNFRC=float

Fenestration system (including frame) U-factor evaluated at NFRC heating conditions. For ASHWAT windows, a value for the NFRC U-factor is required, set via gtUNFRC or wnUNFRC.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	none	No	constant

### gtSHGC=float

Glazing Solar Heat Gain Coefficient: fraction of normal beam insolation which gets through glass to space inside. We recommend using this to represent the glass normal transmissivity characteristic only, before

shading and framing effects

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	<i>none</i>	Yes	Constant

#### **gtSMSO=float**

SHGC multiplier with shades open. May be overridden in the specific window input.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	1.0	No	Monthly - Hourly

#### **gtSMSC=float**

SHGC multiplier with shades closed. May be overridden in the specific window input.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	gtSMSO (no shades)	No	Monthly - Hourly

#### **gtFMult=float**

Framing multiplier used if none given in window, for example .9 if frame and mullions reduce the solar gain by 10%. Default of 1.0 implies frame/mullion effects allowed for in gtSHGC's or always specified in Windows.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	gtSHGCO	No	Monthly - Hourly

#### **gtPySHGC =float**

Four float values separated by commas. Coefficients for incidence angle SHGC multiplier polynomial applied to gtSHGC to determine beam transmissivity at angles of incidence other than 90 degrees. The values are coefficients for first through fourth powers of the cosine of the incidence angle; there is no constant part. An error message will be issued if the coefficients do not add to one. They are used in the following computation:

angle = incidence angle of beam radiation, measured from normal to glass.

$\cos I = \cos(\text{angle})$

$\text{angMult} = a * \cos I + b * \cos I^2 + c * \cos I^3 + d * \cos I^4$

$\text{beamXmisvty} = \text{gtSHGCO} * \text{angMult}$  (shades open)

Units	Legal Range	Default	Required	Variability
float	<i>any</i>	<i>none</i>	Yes	Constant

#### **gtDMSHGC=float**

SHGC diffuse multiplier, applied to gtSHGC to determine transmissivity for diffuse radiation.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	none	yes	Constant

**gtDMRBSol=float**

SHGC diffuse multiplier, applied to qtSHGC to determine transmissivity for diffuse radiation reflected back out the window. Misnamed as a reflectance. Assume equal to DMSHGC if no other data available.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	none	yes	Constant

**gtNGlz=int**

Number of glazings in the Glazetype (bare glass only, not including any interior or exterior shades).

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 4$	2	no	Constant

**gtExShd=choice**

Exterior shading type (ASHWAT only).

Units	Legal Range	Default	Required	Variability
	NONE INSCRN	NONE	no	Constant

**gtInShd=choice**

Interior shade type (ASHWAT only).

Units	Legal Range	Default	Required	Variability
	NONE DRAPEMED	NONE	no	Constant

**gtDirtLoss=float**

Glazing dirt loss factor.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	0	no	Constant

**endGlazeType**

Optional to indicate the end of the Glazetype. Alternatively, the end of the GLAZETYPE definition can be indicated by "END" or by beginning another object

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @glazeType

**4.9 METER**

A METER object is a user-defined “device” that records energy consumption of equipment as simulated by CSE. The user defines METERS with the desired names, then assigns energy uses of specific equipment to the desired meters using commands described under each equipment type’s class description (AIRHANDLER, TERMINAL, etc.). Additional energy use from equipment not simulated by CSE (except optionally for its effect on heating and cooling loads) can also be charged to METERS (see **GAIN**). The data accumulated by meters can be reported at hourly, daily, monthly, and annual (run) intervals by using **REPORTs** and **EXPORTs** of type MTR.

Meters account for energy use in the following pre-defined categories, called *end uses*. The abbreviations in parentheses are used in MTR report headings (and for gnMeter input, below). You also get a column for the net total on the meter (abbreviated “Tot”).

---

Clg	Cooling
Htg	Heating (includes heat pump compressor)
HPHTG	Heat pump backup heat
DHW	Domestic (service) hot water
DHWBU	Domestic (service) hot water heating backup (HPWH resistance)
DHWMFL	Domestic (service) hot water heating multi-family loop pumping and loss makeup
FANC	Fans, AC and cooling ventilation
FANH	Fans, heating
FANV	Fans, IAQ venting
FAN	Fans, other purposes
AUX	HVAC auxiliaries such as pumps
PROC	Process
LIT	Lighting
RCP	Receptacles
EXT	Exterior lighting
REFR	Refrigeration
DISH	Dishwashing
DRY	Clothes drying
WASH	Clothes washing
COOK	Cooking
USER1	User-defined category 1
USER2	User-defined category 2
BT	Battery charge power
PV	Photovoltaic power generation

---

The user has complete freedom over how many meters are defined and how equipment is assigned to them. At one extreme, a single meter “Electricity” could be defined and have all of electrical uses assigned to it. On the other hand, definition of separate meters “Elect\_Fan1”, “Elect\_Fan2”, and so forth allows accounting of the electricity use for individual pieces of equipment. Various groupings are possible: for example, in a building with several air handlers, one could separate the energy consumption of the fans from the coils, or one could separate the energy use by air handler, or both ways, depending on the information desired from the run.

The members that assign energy use to meters include:

- GAIN: gnMeter, gnEndUse
- ZONE: xfanMtr

- IZXFER: izfanMtr
- RSYS: rsElecMtr, rsFuelMtr
- DHWSYS: wsElecMtr, wsFuelMtr
- DHWHEATER: whElectMtr, whFuelMtr
- DHWPUMP: wpElecMtr
- DHWLOOPPUMP: wlpElecMtr
- PVARRAY: pvElecMeter
- TERMINAL: tuhcMtr, tfanMtr
- AIRHANDLER: sfanMtr, rfanMtr, ahhcMtr, ahccMtr, ahhcAuxOnMtr, ahhcAuxOffMtr, ahhcAuxFullOnMtr, ahhcAuxOnAtAllMtr, ahccAuxOnMtr, ahccAuxOffMtr, ahccAuxFullOnMtr, ahccAuxOnAtAllMtr
- BOILER: blrMtr, blrpMtr, blrAuxOnMtr, blrAuxOffMtr, blrAuxFullOnMtr, blrAuxOnAtAllMtr
- CHILLER: chMtr, chppMtr, chepMtr, chAuxOnMtr, chAuxOffMtr, chAuxFullOnMtr, chAuxOnAtAllMtr
- TOWERPLANT: tpMtr

The end use can be specified by the user only for **GAINS** and **PVARRAYs**; in other cases it is hard-wired to Clg, Htg, FanC, FanH, FanV, Fan, or Aux as appropriate.

#### mtrName

Name of meter: required for assigning energy uses to the meter elsewhere.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	Yes	constant

#### endMeter

Indicates the end of the meter definition. Alternatively, the end of the meter definition can be indicated by the declaration of another object or by END.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

#### Related Probes:

- @meter

## 4.10 DHWMETER

A DHWMETER object is a user-defined “device” that records water consumption as simulated by CSE. The data accumulated by DHWMETERS can be reported at hourly, daily, monthly, and annual (run) intervals by using **REPORTs** and **EXPORTs** of type DHWMTR. Water use is reported in gallons.

DHWMETERS account for water use in the following pre-defined end uses. The abbreviations in parentheses are used in DHWMTR report headings.

- Total water use (Total)
- Unknown end use (Unknown)
- Miscellaneous draws (Faucet)
- Shower (Shower)
- Bathtub (Bath)
- Clothes washer (CWashr)
- Dishwasher (DWashr)

**DHWSYS** items wsWHhwMtr and wsFXhwMtr specify the DHWMETER(s) to which water consumption is accumulated.

### dhwMtrName

Name of meter: required for assigning water uses to the DHWMETER.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	Yes	constant

### endDhwMeter

#### Related Probes:

- @DHWmeter

## 4.11 ZONE

ZONE constructs an object of class ZONE, which describes an area of the building to be modeled as having a uniform condition. ZONES are large, complex objects and can have many subobjects that describe associated surfaces, shading devices, HVAC equipment, etc.

### 4.11.1 ZONE General Members

#### znName

Name of zone. Enter after the word **ZONE**; no “=” is used.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	Yes	constant

#### znModel=*choice*

Selects model for zone.

CNE	Older, central difference model based on original CALPAS methods. Not fully supported and not suitable for current compliance applications.
CZM	Conditioned zone model. Forward-difference, short time step methods are used.
UZM	Unconditioned zone model. Identical to CZM except heating and cooling are not supported. Typically used for attics, garages, and other ancillary spaces.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	CNE	No	constant

#### znArea=*float*



Nominal zone floor area.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x > 0$	<i>none</i>	Yes	constant

**znVol=float**

Nominal zone volume.

Units	Legal Range	Default	Required	Variability
ft <sup>3</sup>	$x > 0$	<i>none</i>	Yes	constant

**znAzm=float**

Zone azimuth with respect to bldgAzm. All surface azimuths are relative to znAzm, so that the zone can be rotated by changing this member only. Values outside the range 0° to 360° are normalized to that range.

Units	Legal Range	Default	Required	Variability
degrees	unrestricted	0	No	constant

**znFloorZ=float**

Nominal zone floor height relative to arbitrary 0 level. Used re determination of vent heights

Units	Legal Range	Default	Required	Variability
ft	unrestricted	0	No	constant

**znCeilingHt=float**

Nominal zone ceiling height relative to zone floor (typically 8 – 10 ft).

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	$znVol / znArea$	No	constant

**znEaveZ=float**

Nominal eave height above ground level. Used re calculation of local surface wind speed. This in turn influences outside convection coefficients in some surface models and wind-driven air leakage.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	$znFloorZ + infStories*8$	No	constant

**znCAir=float**

Zone “air” heat capacity: represents heat capacity of air, furniture, “light” walls, and everything in zone except surfaces having heat capacity (that is, non-QUICK surfaces).

Units	Legal Range	Default	Required	Variability
Btu/°F	$x \geq 0$	$3.5 * znArea$	No	constant

**znHcAirX=float**

Zone air exchange rate used in determination of interior surface convective coefficients. This item is generally used only for model testing.

Units	Legal Range	Default	Required	Variability
ACH	$x \geq 0$	as modeled	No	subhourly

**znHcFrcF=float**

Zone surface forced convection factor. Interior surface convective transfer is modeled as a combination of forced and natural convection.  $hcFrc = znHcFrcF * znHcAirX^{.8}$ . See CSE Engineering Documentation.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F		.2	No	hourly

**znHIRatio=float**

Zone hygric inertia ratio. In zone moisture balance calculations, the effective dry-air mass =  $znHIRatio * (zone\ dry\ air\ mass)$ . This enhancement can be used to represent the moisture storage capacity of zone surfaces and contents.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	No	constant

**znSC=float**

Zone shade closure. Determines insolation through windows (see **WINDOW** members *wnSCSO* and *wnSCSC*) and solar gain distribution: see **SGDIST** members *sgFSO* and *sgFSC*. 0 represents shades open; 1 represents shades closed; intermediate values are allowed. An hourly variable CSE expression may be used to schedule shade closure as a function of weather, time of year, previous interval HVAC use or zone temperature, etc.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	1 when cooling was used in <i>previous</i> hour, else 0	No	hourly

**znTH=float**

Heating set point for  $znModel=CZM$ .

Units	Legal Range	Default	Required	Variability
°F	$x \geq 0$			subhourly

**znTD=float**

Desired set point (temperature maintained with ventilation if possible) for  $znModel=CZM$

Units	Legal Range	Default	Required	Variability
°F	$x \geq 0$			subhourly

**znTC=float**

Cooling set point for znModel=CZM.

Units	Legal Range	Default	Required	Variability
°F	$x \geq 0$			subhourly

CZM zone heating and cooling is provided either via an **RSYS** HVAC system or by “magic” heat transfers specified by znQxxx items.

**znRSys=rsysName**

Name of **RSYS** providing heating, cooling, and optional central fan integrated ventilation to this zone.

Units	Legal Range	Default	Required	Variability
	<i>RSYS name</i>	(no RSYS)	No	constant

**znQMxH=float**

Heating capacity at current conditions

Units	Legal Range	Default	Required	Variability
Btuh	$x \geq 0$			hourly

**znQMxHRated=float**

Rated heating capacity

Units	Legal Range	Default	Required	Variability
Btuh	$x \geq 0$			constant

**znQMxC=float**

Cooling capacity at current conditions

Units	Legal Range	Default	Required	Variability
Btuh	$x \leq 0$			hourly

**znQMxCRated=float**

Rated cooling capacity

Units	Legal Range	Default	Required	Variability
Btuh	$x \leq 0$			constant

### 4.11.2 ZONE Infiltration

The following control a simplified air change plus leakage area model. The Sherman-Grimsrud model is used to derive air flow rate from leakage area and this rate is added to the air changes specified with infAC. Note that TOP.windF does *not* modify calculated infiltration rates, since the Sherman-Grimsrud model uses its own modifiers. See also AirNet models available via [IZZFER](#).

**infAC=float**

Zone infiltration air changes per hour.

Units	Legal Range	Default	Required	Variability
1/hr	$x \geq 0$	0.5	No	hourly

**infELA=float**

Zone effective leakage area (ELA).

Units	Legal Range	Default	Required	Variability
in <sup>2</sup>	$x \geq 0$	0.0	No	hourly

**infShld=int**

Zone local shielding class, used in derivation of local wind speed for ELA infiltration model, wind-driven AirNet leakage, and exterior surface coefficients. infShld values are –

1	no obstructions or local shielding
2	light local shielding with few obstructions
3	moderate local shielding, some obstructions within two house heights
4	heavy shielding, obstructions around most of the perimeter
5	very heavy shielding, large obstructions surrounding the perimeter within two house heights

Units	Legal Range	Default	Required	Variability
	$1 \leq x \leq 5$	3	No	constant

**infStories=int**

Number of stories in zone, used in ELA model.

Units	Legal Range	Default	Required	Variability
	$1 \leq x \leq 3$	1	No	constant

**znWindFLkg=floatTODO**

Units	Legal Range	Default	Required	Variability
		1	No	constant

### 4.11.3 ZONE Exhaust Fan

Presence of an exhaust fan in a zone is indicated by specifying a non-zero design flow value (xfanVfDs).

Zone exhaust fan model implementation is incomplete as of July, 2011. The current code calculates energy use but does not account for the effects of air transfer on room heat balance. **IZZFER** provides a more complete implementation.

#### **xfanFOn=float**

Exhaust fan on fraction. On/off control assumed, so electricity requirement is proportional to run time.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	1	No	hourly

Example: The following would run an exhaust fan 70% of the time between 8 AM and 5 PM:

```
xfanFOn = select( (\$hour >= 7 && \$hour < 5), .7,
                  default, 0 );
```

#### **xfanVfDs=float**

Exhaust fan design flow; 0 or not given indicates no fan.

Units	Legal Range	Default	Required	Variability
cfm	$x \geq 0$	0 (no fan)	If fan present	constant

#### **xfanPress=float**

Exhaust fan external static pressure.

Units	Legal Range	Default	Required	Variability
inches H <sub>2</sub> O	$0.05 \leq x \leq 1.0$	0.3	No	constant

Only one of xfanElecPwr, xfanEff, and xfanShaftBhp may be given: together with xfanVfDs and xfanPress, any one is sufficient for CSE to determine the others and to compute the fan heat contribution to the air stream.

#### **xfanElecPwr=float**

Fan input power per unit air flow (at design flow and pressure).

Units	Legal Range	Default	Required	Variability
W/cfm	$x > 0$	derived from xfanEff and xfanShaftBhp	If xfanEff and xfanShaftBhp not present	constant

#### **xfanEff=float**

Exhaust fan/motor/drive combined efficiency.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	0.08	No	constant

**xfanShaftBhp=float**

Fan shaft power at design flow and pressure.

Units	Legal Range	Default	Required	Variability
BHP	$x > 0$	derived from xfanElecPwr and xfanVfDs	If xfanElecPwr not present	constant

**xfanMtr=mtrName**

Name of **METER** object, if any, by which fan's energy use is recorded (under end use category "fan").

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**endZone**

Indicates the end of the zone definition. Alternatively, the end of the zone definition can be indicated by the declaration of another object or by "END". If END or endZone is used, it should follow the definitions of the **ZONE's** subobjects such as **GAINS**, **SURFACES**, **TERMINALS**, etc.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- **@zone**
- **@znRes** (accumulated results)

**4.12 GAIN**

A GAIN object adds sensible and/or latent heat to the **ZONE**, and/or adds arbitrary energy use to a **METER**. GAINS may be subobjects of **ZONEs** and are normally given within the input for their **ZONE**. As many GAINS as desired (or none) may be given for each **ZONE**. Alternatively, GAINS may be subobjects of **TOP** and specify gnZone to specify their associate zone.

Each gain has an amount of power (gnPower), which may optionally be accumulated to a **METER** (gnMeter). The power may be distributed to the zone, plenum, or return as sensible heat with an optional fraction radiant, or to the zone as latent heat (moisture addition), or not.

**gnName**

Name of gain; follows the word GAIN if given.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**gnZone=znName**

Name of **ZONE** to which heat gains are added. Omitted when GAIN is given as a **ZONE** subobject. If a **TOP** subobject (i.e., not a **ZONE** subobject) and znZone is omitted, heat gains are discarded but energy use is still recorded to gnMeter. This feature can be used to represent energy uses that occur outside of conditioned zones (e.g. exterior lighting).

Units	Legal Range	Default	Required	Variability
	<i>name of ZONE</i>	<i>parent zone if any</i>	No	constant

**gnPower=float**

Rate of heat addition/energy use. Negative gnPower values may be used to represent heat removal/energy generation. Expressions containing functions are commonly used with this member to schedule the gain power on a daily and/or hourly basis. Refer to the functions section in Section 4 for details and examples.

All gains, including electrical, are specified in Btuh units unless associated with DHW use (see gnCtrlD-HWSYS), in which case gnPower is specified in Btuh/gal. Note that meter reporting of internal gain is in MBtu (millions of Btu) by default.

Units	Legal Range	Default	Required	Variability
Btuh	<i>no restrictions</i>	<i>none</i>	Yes	hourly

**gnMeter=choice**

Name of meter by which this GAIN's gnPower is recorded. If omitted, gain is assigned to no meter and energy use is not accounted in CSE simulation reports; thus, gnMeter should only be omitted for "free" energy sources.

Units	Legal Range	Default	Required	Variability
	<i>name of METER</i>	<i>none</i>	No	constant

**gnEndUse=choice**

Meter end use to which the GAIN's energy use should be accumulated.

Clg	Cooling
Htg	Heating (includes heat pump compressor)
HPHTG	Heat pump backup heat
DHW	Domestic (service) hot water
DHWBU	Domestic (service) hot water heating backup (HPWH resistance)
DHWMFL	Domestic (service) hot water heating multi-family loop pumping and loss makeup
FANC	Fans, AC and cooling ventilation
FANH	Fans, heating
FANV	Fans, IAQ venting
FAN	Fans, other purposes
AUX	HVAC auxiliaries such as pumps
PROC	Process
LIT	Lighting
RCP	Receptacles
EXT	Exterior lighting
REFR	Refrigeration

DISH	Dishwashing
DRY	Clothes drying
WASH	Clothes washing
COOK	Cooking
USER1	User-defined category 1
USER2	User-defined category 2
BT	Battery charge power
PV	Photovoltaic power generation

Units	Legal Range	Default	Required	Variability
	<i>Codes listed above</i>	<i>none</i>	Required if gnMeter is given	constant

The gnFrZn, gnFrPl, and gnFrRtn members allow you to allocate the gain among the zone, the zone's plenum, and the zone's return air flow. Values that total to more than 1.0 constitute an error. If they total less than 1, the unallocated portion of the gain is recorded by the meter (if specified) but not transferred into the building. By default, all of the gain not directed to the return or plenum goes to the zone.

#### **gnFrZn=float**

Fraction of gain going to zone. gnFrLat (below) gives portion of this gain that is latent, if any; the remainder is sensible.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	1.	No	hourly

### **Gain Modeling in zones**

The radiant internal gain is distributed to the surfaces in the zone, rather than going directly to the zone "air" heat capacity (znCAir). A simple model is used – all surfaces are assumed to be opaque and to have the same (infrared) absorptivity – even windows. Along with the assumption that the zone is spherical (implicit in the current treatment of solar gains), this allows distribution of gains to surfaces in proportion to their area, without any absorptivity or transmissivity calculations. The gain for windows and quick-model surfaces is assigned to the znCAir, except for the portion which conducts through the surface to the other side rather than through the surface film to the adjacent zone air; the gain to massive (delayed-model) surfaces is assigned to the side of surface in the zone with the gain.

Radiant internal gains are included in the IgnS (Sensible Internal Gain) column in the zone energy balance reports. (They could easily be shown in a separate IgnR column if desired.) Any energy transfer shows two places in the ZEB report, with opposite signs, so that the result is zero – otherwise it wouldn't be an energy balance. The rest of the reporting story for radiant internal gains turns out to be complex. The specified value of the radiant gain (gnPower \* gnFrZn \* gnFrRad) shows in the IgnS column. To the extent that the gain heats the zone, it also shows negatively in the Masses column, because the zone CAir is lumped with the other masses. To the extent that the gain heats massive surfaces, it also shows negatively in the masses column. To the extent that the gain conducts through windows and quick-model surfaces, it shows negatively in the Conduction column. If the gain conducts through a quick-model surface to another zone, it shows negatively in the Izone (Interzone) column, positively in the Izone column of the receiving zone, and negatively in the receiving zone's Masses or Cond column.

#### **gnFrRad=float**

Fraction of total gain going to zone (gnFrZn) that is radiant rather than convective or latent.



Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.	No	hourly

**gnFrLat=float**

Fraction of total gain going to zone (gnFrZn) that is latent heat (moisture addition).

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.	No	hourly

**gnDlFrPow=float**

Hourly power reduction factor, typically used to modify lighting power to account for daylighting.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	1.	No	hourly

**gnCtrlDHWSYS=dhwsysName**

Name of a **DHWSYS** whose water use modulates gnPower. For example, electricity use of water-using appliances (e.g. dishwasher or clothes washer) can be modeled based on water use, ensuring that the uses are synchronized. When this feature is used, gnPower should be specified in Btuh/gal.

Units	Legal Range	Default	Required	Variability
	<i>name of a DHWSYS</i>	no DHWSYS/GAIN linkage	No	constant

**gnCtrlDHWEndUse=dhwEndUseName**

Name of the **DHWSYS** end use consumption that modulates gnPower. See **DHWMETER** for DHW end use definitions.

Units	Legal Range	Default	Required	Variability
	DHW end use	Total	No	constant

**endGain**

Optional to indicate the end of the GAIN definition. Alternatively, the end of the gain definition can be indicated by END or by the declaration of another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- **@gain**

### 4.13 SURFACE

Surface constructs a **ZONE** subobject of class SURFACE that represents a surrounding or interior surface of the zone. Internally, SURFACE generates a QUICK surface (U-value only), a DELAYED (massive) surface (using the finite-difference mass model), interzone QUICK surface, or interzone DELAYED surface, as appropriate for the specified construction and exterior conditions.

#### sfName

Name of surface; give after the word SURFACE.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

#### sfType=*choice*

Type of surface:

FLOOR	Surface defines part or all of the “bottom” of the zone; it is horizontal with inside facing up. The outside of the surface is not adjacent to the current zone.
WALL	Surface defines a “side” of the zone; its outside is not adjacent to the current zone.
CEILING	Surface defines part or all of the “top” of the zone with the inside facing down. The outside of the surface is not adjacent to the current zone.

sfType is used extensively for default determination and input checking, but does not have any further internal effect. The Floor, Wall, and Ceiling choices identify surfaces that form boundaries between the zone and some other condition.

Units	Legal Range	Default	Required	Variability
	FLOOR WALL CEILING	none	Yes	constant

#### sfArea=*float*

Gross area of surface. (CSE computes the net area for simulation by subtracting the areas of any windows and doors in the surface.).

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x > 0$	none	Yes	constant

#### sfTilt=*float*

Surface tilt from horizontal. Values outside the range 0 to 360 are first normalized to that range. The default and allowed range depend on sfType, as follows:

sfType = FLOOR	sfTilt=180, default = 180 (fixed value)
sfType = WALL	60 < sfTilt < 180, default = 90
sfType = CEILING	0 ≤ sfTilt ≤ 60, default = 0

Units	Legal Range / Default	Required	Variability
degrees	Dependent upon <i>sfType</i> . See above	No	constant

**sfAzm=float**

Azimuth of surface with respect to znAzm. The azimuth used in simulating a surface is bldgAzm + znAzm + sfAzm; the surface is rotated if any of those are changed. Values outside the range 0 to 360 are normalized to that range. Required for non-horizontal surfaces.

Units	Legal Range	Default	Required	Variability
degrees	unrestricted	<i>none</i>	Required if <i>sfTilt</i> $\neq 0$ and <i>sfTilt</i> $\neq 180$	constant

**sfModel=choice**

Provides user control over how CSE models conduction for this surface.

QUICK	Surface is modeled using a simple conductance. Heat capacity effects are ignored. Either sfCon or sfU (next) can be specified.
DELAYED, DELAYED_HOUR, DELAYED_SUBHOUR	Surface is modeled using a multi-layer finite difference technique that represents heat capacity effects. If the time constant of the surface is too short to accurately simulate, a warning message is issued and the Quick model is used. The program <b>cannot</b> use the finite difference model if sfU rather than sfCon is specified.
AUTO	Program selects Quick or the appropriate Delayed automatically according to the time constant of the surface (if sfU is specified, Quick is selected).
FD (or FORWARD_DIFFERENCE)	Selects the forward difference model (used with short time steps and the CZM/UZM zone model).
KIVA	Uses a two-dimensional finite difference model to simulate heat flow through foundation surfaces.

Units	Legal Range	Default	Required	Variability
–	QUICK, DELAYED, DELAYED_HOUR, DE-LAYED_SUBOUR, AUTO, 2D_FND	AUTO	No	constant

Either sfU or sfCon must be specified, but not both.

**sfU=float**

Surface U-value (NOT including surface (air film) conductances). For surfaces for which no heat capacity is to be modeled, allows direct entry of U-value without defining a **CONSTRUCTION**.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	Determined from <i>sfCon</i>	if <i>sfCon</i> not given	constant

**sfCon=conName**

Name of **CONSTRUCTION** of the surface.

Units	Legal Range	Default	Required	Variability
	Name of a <i>CONSTRUCTION</i>	<i>none</i>	unless <i>sfU</i> given	constant

**sfLThkF=float**

Sublayer thickness adjustment factor for FORWARD\_DIFFERENCE conduction model used with *sfCon* surfaces. Material layers in the construction are divided into sublayers as needed for numerical stability. *sfLThkF* allows adjustment of the thickness criterion used for subdivision. A value of 0 prevents subdivision; the default value (0.5) uses layers with conservative thickness equal to half of an estimated safe value. Fewer (thicker) sublayers improves runtime at the expense of accurate representation of rapid changes.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	.5	No	constant

**sfExCnd=choice**

Specifies the thermal conditions assumed at surface exterior, and at exterior of any subobjects (windows or doors) belonging to current surface. The conditions accounted for are dry bulb temperature and incident solar radiation.

AMBIENT	Exterior surface is exposed to the “weather” as read from the weather file. Solar gain is calculated using solar geometry, <i>sfAz</i> , <i>sfTilt</i> , and <i>sfExAbs</i> .
SPECIFIEDT	Exterior surface is exposed to solar radiation as in AMBIENT, but the dry bulb temperature is calculated with a user specified function ( <i>sfExT</i> ). <i>sfExAbs</i> can be set to 0 to eliminate solar effects.
ADJZN	Exterior surface is exposed to another zone, whose name is specified by <i>sfAdjZn</i> . Solar gain is 0 unless gain is targeted to the surface with <i>SGDIST</i> below.
GROUND	The surface is in contact with the ground. Details of the two-dimensional foundation design are defined by <i>sfFnd</i> . Only floor and wall surfaces may use this option.
ADIABATIC	Exterior surface heat flow is 0. Thermal storage effects of delayed surfaces are modeled.

**sfExAbs=float**

Surface exterior absorptivity.

Units	Legal Range	Default	Required	**Variability
(none)	$0 \leq x \leq 1$	0.5	Required if <i>sfExCnd</i> = AMBIENT or <i>sfExCnd</i> = SPECIFIEDT	monthly-hourly

**sfInAbs=float**

Surface interior solar absorptivity.

Units	Legal Range	Default	Required	**Variability
(none)	$0 \leq x \leq 1$	sfType = CEILING, 0.2; sfType = WALL, 0.6; sfType = FLOOR, 0.8	No	monthly-hourly

**sfExEpsLW=float**

Surface exterior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.9	No	constant

**sfInEpsLW=float**

Surface interior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.9	No	constant

**sfExT=float**

Exterior air temperature.

Units	Legal Range	Default	Required	Variability
°F	<i>unrestricted</i>	<i>none</i>	Required if <i>sfExCnd</i> = SPECIFIEDT	hourly

**sfAdjZn=znName**

Name of adjacent zone; used only when *sfExCnd* is ADJZN. Can be the same as the current zone.

Units	Legal Range	Default	Required	Variability
	name of a <i>ZONE</i>	<i>none</i>	Required when <i>sfExCnd</i> = ADJZN	constant

**sfGrndRefl=float**

Ground reflectivity for this surface.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	grndRefl	No	Monthly - Hourly

**sfInH=float**

Inside surface (air film) conductance. Ignored for sfModel = Forward\_Difference. Default depends on the surface type.

sfType = FLOOR or CEILING	1.32
other	1.5

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	see above	No	constant

**sfExH=float**

Outside combined surface (air film) conductance. Ignored for sfModel = Forward\_Difference. The default value is dependent upon the exterior conditions:

sfExCnd = AMBIENT	dffExH (Top-level member, described above)
sfExCnd = SPECIFIEDT	dffExH (described above)
sfExCnd = ADJZN	1.5
sfExCnd = ADIABATIC	not applicable

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	see above	No	constant

When sfModel = Forward\_Difference, several models are available for calculating inside and outside surface convective coefficients. Inside surface faces can be exposed only to zone conditions. Outside faces may be exposed either to ambient conditions or zone conditions, based on sfExCnd. Only UNIFIED and INPUT are typically used. The other models were used during CSE development for comparison. For details, see CSE Engineering Documentation.

Model	Exposed to ambient	Exposed to zone
UNIFIED	default CSE model	default CSE model
INPUT	hc = sfExHcMult	hc = sfxxHcMult
AKBARI	Akbari model	n/a
WALTON	Walton model	n/a
WINKELMANN	Winkelmann model	n/a
DOE2	DOE2 model	n/a
MILLS	n/a	Mills model
ASHRAE	n/a	ASHRAE handbook values
TARP	n/a	TARP model

**sfExHcModel=choice**

Selects the model used for exterior surface convection when `sfModel = Forward_Difference`.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	UNIFIED	No	constant

**sfExHcLChar=***float*

Characteristic length of surface, used in derivation of forced exterior convection coefficients in some models when outside surface is exposed to ambient. See `sfExHcModel`.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	10	No	constant

**sfExHcMult=***float*

Exterior convection coefficient adjustment factor. When `sfExHcModel=INPUT`, `hc=sfExHcMult`. For other `sfExHcModel` choices, the model-derived `hc` is multiplied by `sfExHcMult`.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

**sfExRf=***float*

Exterior surface roughness factor. Used only when surface is exposed to ambient (i.e. with wind exposure). Typical values:

Roughness Index	sfExRf	Example
1 (very rough)	2.17	Stucco
2 (rough)	1.67	Brick
3 (medium rough)	1.52	Concrete
4 (Medium smooth)	1.13	Clear pine
5 (Smooth)	1.11	Smooth plaster
6 (Very Smooth)	1	Glass

Units	Legal Range	Default	**Required	Variability
		<code>sfExHcModel =</code> WINKELMANN: 1.66 else 2.17	No	constant

**sfInHcModel=***choice*

Selects the model used for the inside (zone) surface convection when `sfModel = Forward_Difference`.

Units	Legal Range	Default	Required	Variability
	<i>choices above (see sfExHcModel)</i>	UNIFIED	No	constant

**sfInHcMult=float**

Interior convection coefficient adjustment factor. When sfInHcModel=INPUT, hc=sfInHcMult. For other sfInHcModel choices, the model-derived hc is multiplied by sfInHcMult.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

The items below give values associated with CSE's model for below grade surfaces (sfExCnd=GROUND). See CSE Engineering Documentation for technical details.

**sfFnd=fdName**

Name of **FOUNDATION** applied to ground-contact Floor SURFACES; used only for Floor SURFACES when sfExCnd is GROUND.

Units	Legal Range	Default	Required	Variability
–	Name of a <i>Foundation</i>	<i>none</i>	when <i>sfExCnd</i> = GROUND and <i>sfType</i> = Floor	constant

**sfFndFloor=sfName**

Name of adjacent ground-contact Floor SURFACE; used only for Wall SURFACES when sfExCnd is GROUND.

Units	Legal Range	Default	Required	Variability
–	Name of a <i>Surface</i>	<i>none</i>	when <i>sfExCnd</i> = GROUND and <i>sfType</i> = Wall	constant

**sfHeight=float**

Needed for foundation wall height, otherwise ignored. Maybe combine with sfDepthBG?

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	<i>none</i>	when <i>sfType</i> is WALL and <i>sfExtCnd</i> is GROUND	constant

**sfExpPerim=float**

Exposed perimeter of foundation floors.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	<i>none</i>	when <i>sfType</i> is FLOOR, <i>sfFnd</i> is set, and <i>sfExtCnd</i> is GROUND	constant



**sfDepthBG=float**

*Note: sfDepthBG is used as part of the simple ground model, which is no longer supported. Use sfHeight with sfFnd instead.*

Depth below grade of surface. For walls, sfDepthBG is measured to the lower edge. For floors, sfDepthBG is measured to the bottom face.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$		No	constant

*Note: The following data members are part of the simple ground model, which is no longer supported. Use sfFnd instead.*

**sfExCTGrnd=float****sfExCTaDbAvg07=float****sfExCTaDbAvg14=float****sfExCTaDbAvg31=float****sfExCTaDbAvgYr=float**

Conductances from outside face of surface to the weather file ground temperature and the moving average outdoor dry-bulb temperatures for 7, 14, 31, and 365 days.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x \geq 0$	see above	No	constant

**sfExRConGrnd=float**

Resistance overall construction resistance. TODO: full documentation.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$		No	constant

**endSURFACE**

Optional to indicates the end of the surface definition. Alternatively, the end of the surface definition can be indicated by END, or by beginning another SURFACE or other object definition. If used, should follow the definitions of the SURFACE's subobjects – **DOORS**, **WINDOWS**, **SHADEs**, **SGDISTs**, etc.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- **@surface**
- **@xsurf**
- **@mass**

## 4.14 WINDOW

WINDOW defines a subobject belonging to the current **SURFACE** that represents one or more identical windows. The azimuth, tilt, and exterior conditions of the window are the same as those of the surface to which it belongs. The total window area ( $wnHt \cdot wnWid \cdot wnMult$ ) is deducted from the gross surface area. A surface may have any number of windows.

Windows may optionally have operable interior shading that reduces the overall shading coefficient when closed.

### **wnName**

Name of window: follows the word "WINDOW" if given.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

### **wnHeight=float**

Overall height of window (including frame).

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	<i>none</i>	Yes	constant

### **wnWidth=float**

Overall width of window (including frame).

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	<i>none</i>	Yes	constant

### **wnArea=float**

Overall area of window (including frame).

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x > 0$	$wnHeight * wnWidth$	No	constant

### **wnMult=float**

Area multiplier; can be used to represent multiple identical windows.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	No	constant

### **wnModel=choice**

Selects window model

Units	Legal Range	Default	Required	Variability
	SHGC, ASHWAT	SHGC	No	constant

**wnGt=choice**

**GLAZETYPE** for window. Provides many defaults for window properties as cited below.

**wnU=float**

Window conductance (U-factor without surface films, therefore not actually a U-factor but a C-factor).

Preferred Approach: To use accurately with standard winter rated U-factor from ASHRAE or NFRC enter as:

$$\text{wnU} = (1/((1/\text{U-factor}) - 0.85))$$

Where 0.85 is the sum of the interior (0.68) and exterior (0.17) design air film resistances assumed for rating window U-factors. Enter wnInH (usually 1.5=1/0.68) instead of letting it default. Enter the wnExH or let it default. It is important to use this approach if the input includes gnFrad for any gain term. Using approach 2 below will result in an inappropriate internal gain split at the window.

Approach 2. Enter wnU=U-factor and let the wnInH and wnExH default. Thormally this approach systematically underestimates the window U-factor because it adds the wnExfilm resistance to 1/U-factor thereby double counting the exterior film resistance. This approach will also yield incorrect results for gnFrad internal gain since the high wnInH will put almost all the gain back in the space.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	none	Yes	constant

**wnUNFRC=float**

Fenestration system (including frame) U-factor evaluated at NFRC heating conditions.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	gtUNFRC	Required when $\text{wnModel} = \text{ASHWAT}$	constant

**wnExEpsLW=float**

Window exterior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.84	No	constant

**wnInEpsLW=float**

Window interior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.84	No	constant

**wnInH=float**

Window interior surface (air film) conductance.

Preferred Approach: Enter the appropriate value for each window, normally:

**wnInH** = 1.5

where 1.5 = 1/0.68 the standard ASHRAE value.

The large default value of 10,000 represents a near-0 resistance, for the convenience of those who wish to include the interior surface film in wnU according to approach 2 above.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	10000	No	constant

**wnExH**=*float*

Window exterior surface (air film) conductance.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	same as owning surface	No	constant

Several models are available for calculating inside and outside surface convective coefficients. Inside surface faces can be exposed only to zone conditions. Outside faces may be exposed either to ambient conditions or zone conditions, based on wnExCnd. Only UNIFIED and INPUT are typically used. The other models were used during CSE development for comparison. For details, see CSE Engineering Documentation.

Model	Exposed to ambient	Exposed to zone
UNIFIED	default CSE model	default CSE model
INPUT	hc = wnExHcMult	hc = wnxxHcMult
AKBARI	Akbari model	n/a
WALTON	Walton model	n/a
WINKELMANN	Winkelmann model	n/a
MILLS	n/a	Mills model
ASHRAE	n/a	ASHRAE handbook values

**wnExHcModel**=*choice*

Selects the model used for exterior surface convection when wnModel = Forward\_Difference.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	UNIFIED	No	constant

**wnExHcLChar**=*float*

Characteristic length of surface, used in derivation of forced exterior convection coefficients in some models when outside face is exposed to ambient (i.e. to wind).

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	10	No	constant

**wnExHcMult=float**

Exterior convection coefficient adjustment factor. When wnExHcModel=INPUT, hc=wnExHcMult. For other wnExHcModel choices, the model-derived hc is multiplied by wnExHcMult.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

**wnInHcModel=choice**

Selects the model used for the inside (zone) surface convection when wnModel = Forward\_Difference.

Units	Legal Range	Default	Required	Variability
	<i>choices above (see wnExHcModel)</i>	UNIFIED	No	constant

**wnInHcMult=float**

Interior convection coefficient adjustment factor. When wnInHcModel=INPUT, hc=wnInHcMult. For other wnInHcModel choices, the model-derived hc is multiplied by wnInHcMult.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

**wnSHGC=float**

Rated Solar Heat Gain Coefficient (SHGC) for the window assembly.

Units	Legal Range	Default	Required	Variability
fraction	$0 < x < 1$	gtSHGC	No	constant

**wnFMult=float**

Frame area multiplier = areaGlaze / areaAssembly

Units	Legal Range	Default	Required	Variability
fraction	$0 < x < 1$	gtFMult or 1	No	constant

**wnSMSO=float**

SHGC multiplier with shades open. Overrides gtSMSO.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	gtSMSO or 1	No	Monthly - Hourly

**wnSMSC=float**

SHGC multiplier with shades closed. Overrides gtSMSC

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	wnSMSO or gtSMSC	No	Monthly - Hourly

**wnNGlz=*int***

Number of glazings in the window (bare glass only, not including any interior or exterior shades).

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 4$	gtNGLZ	Required when <i>wnModel</i> = ASHWAT	Constant

**wnExShd=*choice***

Exterior shading type (ASHWAT only).

Units	Legal Range	Default	Required	Variability
	NONE, INSCRN	gtExShd	no	Constant

**wnInShd=*choice***

Interior shade type (ASHWAT only).

Units	Legal Range	Default	Required	Variability
	NONE, DRAPEMED	gtInShd	no	Constant

**wnDirtLoss=*float***

Glazing dirt loss factor.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	0	no	Constant

**wnGrndRefl=*float***

Ground reflectivity for this window.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	sfGrndRefl	No	Monthly - Hourly

**wnVfSkyDf=*float***

View factor from this window to sky for diffuse radiation. For the shading effects of an overhang, a wnVfSkyDf value smaller than the default would be used

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	0.5 - 0.5 * cos(tilt) = .5 for vertical surface	No	Monthly - Hourly

**wnVfGrndDf=*float***

View factor from this window to ground for diffuse radiation. For the shading effects of a fin(s), both wnVfSkyDf and wnVfGrndDf would be used.

Units	Legal Range	Default	Required	Variability
fraction	$0 \leq x \leq 1$	$0.5 + 0.5 *$ $\cos(\text{tilt}) = .5$ for vertical surface	No	Monthly - Hourly

**endWINDOW**

Optionally indicates the end of the window definition. Alternatively, the end of the window definition can be indicated by END or the declaration of another object. END or endWindow, if used, should follow any subobjects of the window (**SHADEs** and/or **SGDISTs**).

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @window
- @xsurf

**4.15 SHADE**

SHADE constructs a subobject associated with the current **WINDOW** that represents fixed shading devices (overhangs and/or fins). A window may have at most one SHADE and only windows in vertical surfaces may have SHADEs. A SHADE can describe an overhang, a left fin, and/or a right fin; absence of any of these is specified by omitting or giving 0 for its depth. SHADE geometry can vary on a monthly basis, allowing modeling of awnings or other seasonal shading strategies.

**shName**

Name of shade; follows the word “SHADE” if given.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**ohDepth=*float***

Depth of overhang (from plane of window to outside edge of overhang). A zero value indicates no overhang.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**ohDistUp=*float***

Distance from top of window to bottom of overhang.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**ohExL=float**

Distance from left edge of window (as viewed from the outside) to the left end of the overhang.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**ohExR=float**

Distance from right edge of window (as viewed from the outside) to the right end of the overhang.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**ohFlap=float**

Height of flap hanging down from outer edge of overhang.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**lfDepth=float**

Depth of left fin from plane of window. A zero value indicates no fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**lfTopUp=float**

Vertical distance from top of window to top of left fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**lfDistL=float**

Distance from left edge of window to left fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

**lfBotUp=float**



Vertical distance from bottom of window to bottom of left fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

#### **rfDepth=float**

Depth of right fin from plane of window. A 0 value indicates no fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

#### **rfTopUp=float**

Vertical distance from top of window to top of right fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

#### **rfDistR=float**

Distance from right edge of window to right fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

#### **rfBotUp=float**

Vertical distance from bottom of window to bottom of right fin.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	0	No	monthly-hourly

#### **endShade**

Optional to indicate the end of the SHADE definition. Alternatively, the end of the shade definition can be indicated by END or the declaration of another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

#### **Related Probes:**

- @shade

## 4.16 SGDIST

SGDIST creates a subobject of the current window that distributes a specified fraction of that window's solar gain to a specified delayed model (massive) surface. Any remaining solar gain (all of the window's solar gain if no SGDISTS are given) is added to the air of the zone containing the window. A window may have up to three SGDISTS; an error occurs if more than 100% of the window's gain is distributed.

Via members sgFSO and sgFSC, the fraction of the insolation distributed to the surface can be made dependent on whether the zone's shades are open or closed (see **ZONE** member znSC).

### sgName

Name of solar gain distribution (follows "SGDIST" if given).

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

### sgSurf=sfName

Name of surface to which gain is targeted.

If there is more than surface with the specified name: if one of the surfaces is in the current zone, it is used; otherwise, an error message is issued.

The specified surface must be modeled with the Delayed model. If gain is targeted to a Quick model surface, a warning message is issued and the gain is redirected to the air of the associated zone.

Units	Legal Range	Default	Required	Variability
	name of a <i>SURFACE</i>	none	Yes	constant

### sgSide=choice

Designates the side of the surface to which the gain is to be targeted:

INTERIOR	Apply gain to interior of surface
EXTERIOR	Apply gain to exterior of surface

Units	Legal Range	Default	Required	Variability
	INTERIOR, EXTERIOR	Side of surface in zone containing window; or INTERIOR if both sides are in zone containing window.	Yes	constant

### sgFSO=float

Fraction of solar gain directed to specified surface when the owning window's interior shading is in the open position (when the window's zone's shade closure (znSC) is 0).

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$ , and sum of window's sgFSO's $\leq 1$	<i>none</i>	Yes	monthly-hourly

**sgFSC=float**

Fraction of solar gain directed to specified surface when the owning window's interior shading is in the closed position. If the zone's shades are partly closed (znSC between 0 and 1), a proportional fraction between sgFSO and sgFSC is used.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$ , and sum of window's sgFSC's $\leq 1$	<i>sgFSO</i>	No	monthly-hourly

**endSGDist**

Optionally indicates the end of the solar gain distribution definition. Alternatively, the end of the solar gain distribution definition can be indicated by END or by just beginning another object.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

**Related Probes:**

- @sgdist

**4.17 DOOR**

DOOR constructs a subobject belonging to the current **SURFACE**. The azimuth, tilt, ground reflectivity and exterior conditions associated with the door are the same as those of the owning surface, although the exterior surface conductance and the exterior absorptivity can be altered.

**drName**

Name of door.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**drArea=float**

Overall area of door.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x > 0$	<i>none</i>	Yes	constant

**drModel=choice**

Provides user control over how CSE models conduction for this door:

QUICK	Surface is modeled using a simple conductance. Heat capacity effects are ignored. Either drCon or drU (next) can be specified.
-------	--

DELAYED, DELAYED_HOUR, DELAYED_SUBOUR	Surface is modeled using a multi-layer finite difference technique which represents heat capacity effects. If the time constant of the door is too short to accurately simulate, a warning message is issued and the Quick model is used. drCon (next) must be specified – the program cannot use the finite difference model if drU rather than drCon is specified.
AUTO	Program selects Quick or appropriate Delayed automatically according to the time constant of the surface (if drU is specified, Quick is selected).
FD or FORWARD_DIFFERENCE	Selects the forward difference model (used with short time steps and the CZM/UZM zone models)

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	AUTO	No	constant

Either drU or drCon must be specified, but not both.

#### drU=*float*

Door U-value, NOT including surface (air film) conductances. Allows direct entry of U-value, without defining a **CONSTRUCTION**, when no heat capacity effects are to be modeled.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	Determined from <i>drCon</i>	if <i>drCon</i> not given	constant

#### drCon=*conName*

Name of construction for door.

Units	Legal Range	Default	Required	Variability
	name of a <b>CONSTRUCTION</b>	<i>None</i>	unless <i>drU</i> given	constant

#### drLThkF=*float*

Sublayer thickness adjustment factor for FORWARD\_DIFFERENCE conduction model used with drCon surfaces. Material layers in the construction are divided into sublayers as needed for numerical stability. drLThkF allows adjustment of the thickness criterion used for subdivision. A value of 0 prevents subdivision; the default value (0.5) uses layers with conservative thickness equal to half of an estimated safe value. Fewer (thicker) sublayers improves runtime at the expense of accurate representation of rapid changes.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	.5	No	constant

#### drExAbs=*float*

Door exterior solar absorptivity. Applicable only if sfExCnd of owning surface is AMBIENT or SPECI-

FIEDT.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	same as owning surface	No	monthly-hourly

**drInAbs=float**

Door interior solar absorptivity.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.5	No	monthly-hourly

**drExEpsLW=float**

Door exterior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.9	No	constant

**drInEpsLW=float**

Door interior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.9	No	constant

**drInH=float**

Door interior surface (air film) conductance. Ignored if drModel = Forward\_Difference

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	same as owning surface	No	constant

**drExH=float**

Door exterior surface (air film) conductance. Ignored if drModel = Forward\_Difference

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	same as owning surface	No	constant

When drModel = Forward\_Difference, several models are available for calculating inside and outside surface convective coefficients. Inside surface faces can be exposed only to zone conditions. Outside faces may be exposed either to ambient conditions or zone conditions, based on drExCnd. Only UNIFIED and INPUT are typically used. The other models were used during CSE development for comparison. For details, see CSE Engineering Documentation.

Model	Exposed to ambient	Exposed to zone
UNIFIED	default CSE model	default CSE model
INPUT	hc = drExHcMult	hc = drxxHcMult
AKBARI	Akbari model	n/a
WALTON	Walton model	n/a
WINKELMANN	Winkelmann model	n/a
MILLS	n/a	Mills model
ASHRAE	n/a	ASHRAE handbook values

**drExHcModel=choice**

Selects the model used for exterior surface convection when drModel = Forward\_Difference.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	UNIFIED	No	constant

**drExHcLChar=float**

Characteristic length of surface, used in derivation of forced exterior convection coefficients in some models when outside face is exposed to ambient (i.e. to wind).

Units	Legal Range	Default	Required	Variability
ft	x > 0	10	No	constant

**drExHcMult=float**

Exterior convection coefficient adjustment factor. When drExHcModel=INPUT, hc=drExHcMult. For other drExHcModel choices, the model-derived hc is multiplied by drExHcMult.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

**drExRf=float**

Exterior roughness factor. Typical roughness values:

Roughness Index	drExRf	Example
1 (very rough)	2.17	Stucco
2 (rough)	1.67	Brick
3 (medium rough)	1.52	Concrete
4 (Medium smooth)	1.13	Clear pine
5 (Smooth)	1.11	Smooth plaster
6 (Very Smooth)	1	Glass

Units	Legal Range	Default	Required	Variability
		drExHcModel = WINKELMANN: 1.66 else 2.17	No	constant

**drInHcModel=choice**

Selects the model used for the inside (zone) surface convection when drModel = Forward\_Difference.

Units	Legal Range	Default	Required	Variability
	choices above (see drExHcModel)	UNIFIED	No	constant

**drInHcMult=float**

Interior convection coefficient adjustment factor. When drInHcModel=INPUT, hc=drInHcMult. For other drInHcModel choices, the model-derived hc is multiplied by drInHcMult.

Units	Legal Range	Default	Required	Variability
		1	No	subhourly

**endDoor**

Indicates the end of the door definition. Alternatively, the end of the door definition can be indicated by the declaration of another object or by END.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @door
- @xsurf
- @mass

**4.18 PERIMETER**

PERIMETER defines a subobject belonging to the current zone that represents a length of exposed edge of a (slab on grade) floor.

**prName**

Optional name of perimeter.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**prLen=float**

Length of exposed perimeter.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$	<i>none</i>	Yes	constant

**prF2=float**

Perimeter conduction per unit length.

Units	Legal Range	Default	Required	Variability
Btuh/ft-°F	$x > 0$	<i>none</i>	Yes	constant

**endPerimeter**

Optionally indicates the end of the perimeter definition.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

**Related Probes:**

- @perimeter
- @xsurf

**4.19 IZXFER**

IZXFER constructs an object that represents an interzone or zone/ambient heat transfer due to conduction and/or air transfer. The air transfer modeled by IZXFER transfers heat only; humidity transfer is not modeled as of July 2011. Note that **SURFACE** is the preferred way represent conduction between **ZONEs**.

The AIRNET types are used in a multi-cell pressure balancing model that finds zone pressures that produce net 0 mass flow into each zone. The model operates in concert with the znType=CZM or znType=UZM to represent ventilation strategies. During each time step, the pressure balance is found for two modes that can be thought of as “VentOff” (or infiltration-only) and “VentOn” (or infiltration+ventilation). The zone model then determines the ventilation fraction required to hold the desired zone temperature (if possible). AIRNET modeling methods are documented in the CSE Engineering Documentation.

Note that fan-driven types assume pressure-independent flow. That is, the specified flow is included in the zone pressure balance but the modeled fan flow does not change with zone pressure. The assumption is that in realistic configurations, zone pressure will generally be close to ambient pressure. Unbalanced fan ventilation in a zone without relief area will result in runtime termination due to excessively high or low pressure.

**izName**

Optional name of interzone transfer; give after the word “IZXFER” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**izNVType=choice**

Choice determining interzone ventilation



NONE	No interzone ventilation
ONEWAY	Uncontrolled flow from izZn1 to izZn2 when izZn1 air temperature exceeds izZn2 air temperature (using ASHRAE high/low vent model).
TOWWAY	Uncontrolled flow in either direction (using ASHRAE high/low vent model).
AIRNETIZ	Single opening to another zone (using pressure balance AirNet model). Flow is driven by buoyancy.
AIRNETEXT	Single opening to ambient (using pressure balance AirNet model). Flow is driven by buoyancy and wind pressure.
AIRNETHORIZ	Horizontal (large) opening between two zones, used to represent e.g. stairwells. Flow is driven by buoyancy; simultaneous up and down flow is modeled.
AIRNETEXTFAN	Fan from exterior to zone (flow either direction).
AIRNETIZFAN	Fan between two zones (flow either direction).
AIRNETEXTFLOW	Specified flow from exterior to zone (either direction). Behaves identically to AIRNETEXTFAN except no electricity is consumed and no fan heat is added to the air stream.
AIRNETIZFLOW	Specified flow between two zones (either direction). Behaves identically to AIRNETIZFAN except no electricity is consumed and no fan heat is added to the air stream.
AIRNETHERV	Heat or energy recovery ventilator. Supply and exhaust air are exchanged with the exterior with heat and/or moisture exchange between the air streams. Flow may or may not be balanced.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>	NONE	No	constant

**izZn1=znName**

Name of primary zone. Flow rates > 0 are into the primary zone.

Units	Legal Range	Default	Required	Variability
	name of a ZONE		Yes	constant

**izZn2=znName**

Name of secondary zone.

Units	Legal Range	Default	Required	Variability
	name of a ZONE		required unless izNVType = AIRNETEXT, AIRNETEXTFAN, AIRNE- TEXTFLOW, or AIRNETHERV	constant

Give izHConst for a conductive transfer between zones. Give izNVType other than NONE and the following variables for a convective (air) transfer between the zones or between a zone and outdoors. Both may be given if desired. Not known to work properly as of July 2011

**izHConst=float**

Conductance between zones.

Units	Legal Range	Default	Required	Variability
Btu/°F	$x \geq 0$	0	No	hourly

**izALo=float**

Area of low or only vent (typically VentOff)

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x \geq 0$	0	No	hourly

**izAHi=float**

Additional vent area (high vent or VentOn). If used in AIRNET, izAHi > izALo typically but this is not required.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x \geq 0$	izALo	No	hourly

**izL1=float**

Length or width of AIRNETHORIZ opening.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$		if izNVType = AIRNETHORIZ	constant

**izL2=float**

Width or length of AIRNETHORIZ opening.

Units	Legal Range	Default	Required	Variability
ft	$x > 0$		if izNVType = AIRNETHORIZ	constant

**izStairAngle=float**

Stairway angle for AIRNETHORIZ opening. Use 90 for an open hole. Note that 0 prevents flow.

Units	Legal Range	Default	Required	Variability
degrees	$x > 0$	34	No	constant

**izHD=float**

Vent center-to-center height difference (for TWOWAY) or vent height above nominal 0 level (for AirNet types)

Units	Legal Range	Default	Required	Variability
ft		0	No	constant

**izNVEff=float**

Vent discharge coefficient.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.8	No	constant

**izfanVfDs=float**

Fan design or rated flow at rated pressure. For AIRNETHERV, this is the net air flow into the zone, gross flow at the fan is derived using izEATR (see below).

Units	Legal Range	Default	Required	Variability
cfm	$x \geq 0$	0 (no fan)	If fan present	constant

**izCpr=float**

Wind pressure coefficient (for AIRNETEXT).

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	0.	No	constant

**izExp=float**

Opening exponent (for AIRNETEXT).

Units	Legal Range	Default	Required	Variability
none	$x > 0$	0.5	No	constant

**izVfMin=float**

Minimum volume flow rate (VentOff mode).

Units	Legal Range	Default	Required	Variability
cfm	$x \geq 0$	izfanVfDs	No	subhourly

**izVfMax=float**

Maximum volume flow rate (VentOn mode)

Units	Legal Range	Default	Required	Variability
cfm	$x \geq 0$	izVfMin	No	subhourly

**izASEF=float**

Apparent sensible effectiveness for AIRNETHERV ventilator. ASEF is a commonly-reported HERV rating and is calculated as (supplyT - sourceT) / (returnT - sourceT). This formulation includes fan heat (in supplyT), hence the term “apparent”. Ignored if izSRE is given. CSE does not HRV exhaust-side condensation, so this model is approximate.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0	No	subhourly

**izSRE=float**

Sensible recovery efficiency (SRE) for AIRNETHERV ventilator. Used as the sensible effectiveness in calculation of the supply air temperature. Note that values of SRE greater than approximately 0.6 imply exhaust-side condensation under HVI rating conditions. CSE does not adjust for these effects. High values of izSRE will produce unrealistic results under mild outdoor conditions and/or dry indoor conditions.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0	No	subhourly

**izASRE=float**

Adjusted sensible recovery efficiency (ASRE) for AIRNETHERV ventilator. The difference izASRE - izSRE is used to calculate fan heat added to the supply air stream. See izSRE notes. No effect when izSRE is 0.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq \text{izSRE}$	0	No	subhourly

**izEATR=float**

Exhaust air transfer ratio for AIRNETHERV ventilator. NetFlow = (1 - EATR)\*(grossFlow).

Units	Legal Range	Default	Required	Variability
cfm	$0 \leq x \leq 1$	0	No	subhourly

**izLEF=float**

Latent heat recovery effectiveness for AIRNETHERV ventilator. The default value (0) results in sensible-only

heat recovery.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0	No	subhourly

### **izRVFanHeatF=float**

Fraction of fan heat added to supply air stream for AIRNETHERV ventilator. Used only when when izSRE is 0 (that is, when izASEF specifies the sensible effectiveness).

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0	No	subhourly

### **izVfExhRat=float**

Exhaust volume flow ratio for AIRNETHERV ventilator = (exhaust flow) / (supply flow). Any value other than 1 indicates unbalanced flow that effects the zone pressure.

Units	Legal Range	Default	Required	Variability
		1 (balanced)	No	subhourly

### **izfanPress=float**

Design or rated fan pressure.

Units	Legal Range	Default	Required	Variability
inches H <sub>2</sub> O	$x > 0$	.3	No	constant

Only one of izfanElecPwr, izfanEff, and izfanShaftBhp may be given: together with izfanVfDs and izfanPress, any one is sufficient for CSE to determine the others and to compute the fan heat contribution to the air stream.

### **izfanElecPwr=float**

Fan input power per unit air flow (at design flow and pressure).

Units	Legal Range	Default	Required	Variability
W/cfm	$x > 0$	derived from izfanEff and izfanShaftBhp	If izfanEff and izfanShaftBhp not present	constant

### **izfanEff=float**

Fan efficiency at design flow and pressure, as a fraction.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	derived from <i>izfanShaftBhp</i> if given, else 0.08	No	constant

**izfanShaftBhp=float**

Fan shaft brake horsepower at design flow and pressure.

Units	Legal Range	Default	Required	Variability
bhp	$x > 0$	derived from <i>izfanEff</i> .	No	constant

**izfanCurvePy= $k_0, k_1, k_2, k_3, x_0$** 

$k_0$  through  $k_3$  are the coefficients of a cubic polynomial for the curve relating fan relative energy consumption to relative air flow above the minimum flow  $x_0$ . Up to five *floats* may be given, separated by commas. 0 is used for any omitted trailing values. The values are used as follows:

$$z = k_0 + k_1 \cdot (x - x_0) + k_2 \cdot (x - x_0)^2 + k_3 \cdot (x - x_0)^3$$

where:

- $x$  is the relative fan air flow (as fraction of *izfanVfDs*;  $0 \leq x \leq 1$ );
- $x_0$  is the minimum relative air flow (default 0);
- $(x - x_0)$  is the “positive difference”, i.e.  $(x - x_0)$  if  $x > x_0$ ; else 0;
- $z$  is the relative energy consumption.

If  $z$  is not 1.0 for  $x = 1.0$ , a warning message is displayed and the coefficients are normalized by dividing by the polynomial's value for  $x = 1.0$ .

Units	Legal Range	Default	Required	Variability
		$0, 1, 0, 0, 0$ ( <i>linear</i> )	No	constant

**izFanMtr=mtrName**

Name of meter, if any, to record energy used by supply fan. End use category used is specified by *izFanEndUse* (next).

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**izFanEndUse=choice**

End use to which fan energy is recorded (in **METER** specified by *izFanMtr*). See **METER** for available end use choices.

Units	Legal Range	Default	Required	Variability
	<i>end use choice</i>	Fan	No	constant

**endIZXFER**

Optionally indicates the end of the interzone transfer definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @izXfer

**4.20 RSYS**

RSYS constructs an object representing an air-based residential HVAC system.

**rsName**

Optional name of HVAC system; give after the word “RSYS” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**rsType=choice**

Type of system.

rsType	Description
ACFURNACE	Compressor-based cooling and fuel-fired heating. Primary heating input energy is accumulated to end use HTG of meter rsFuelMtr.
ACRESISTANCE	Compressor-based cooling and electric (“strip”) heating. Primary heating input energy is accumulated to end use HTG of meter rsElecMtr.
ASHP	Air-source heat pump (compressor-based heating and cooling). Primary (compressor) heating input energy is accumulated to end use HTG of meter rsElecMtr. Auxiliary heating input energy is accumulated to end use HPHTG of meter rsElecMtr.
ASHPHYDRONIC	Air-to-water heat pump with hydronic distribution. Compressor performance is approximated using the air-to-air model with adjusted efficiencies.
AC	Compressor-based cooling; no heating.
FURNACE	Fuel-fired heating. Primary heating input energy is accumulated to end use HTG of meter rsFuelMtr.
RESISTANCE	Electric heating. Primary heating input energy is accumulated to end use HTG of meter rsElecMtr

Units	Legal Range	Default	Required	Variability
	<i>one of above choices</i>	ACFURNACE	No	constant

**rsDesc=string**

Text description of system, included as documentation in debugging reports such as those triggered by rsPerfMap=YES

Units	Legal Range	Default	Required	Variability
	string	<i>blank</i>	No	constant

**rsModeCtrl=choice**

Specifies systems heating/cooling availability during simulation.

OFF	System is off (neither heating nor cooling is available)
HEAT	System can heat (assuming rsType can heat)
COOL	System can cool (assuming rsType can cool)
AUTO	System can either heat or cool (assuming rsType compatibility). First request by any zone served by this RSYS determines mode for the current time step.

Units	Legal Range	Default	Required	Variability
	OFF, HEAT, COOL, AUTO	AUTO	No	hourly

**rsPerfMap=choice**

Generate performance map(s) for this RSYS. Comma-separated text is written to file PM\_[rsName].csv. This is a debugging capability that is not necessarily maintained.

Units	Legal Range	Default	Required	Variability
	NO, YES	NO	No	constant

**rsFanTy=choice**

Specifies fan (blower) position relative to cooling coil.

Units	Legal Range	Default	Required	Variability
	BLOWTHRU, DRAWTHRU	BLOWTHRU	No	constant

**rsFanMotTy=choice**

Specifies type of motor driving the fan (blower). This is used in the derivation of the coil-only cooling capacity for the RSYS.

PSC	Permanent split capacitor
BPM	Brushless permanent magnet (aka ECM)

Units	Legal Range	Default	Required	Variability
	PSC, BPM	PSC	No	constant

**rsElecMtr=mtrName**

Name of **METER** object, if any, by which system's electrical energy use is recorded (under appropriate end uses).



Units	Legal Range	Default	Required	Variability
Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**rsFuelMtr** = *mtrName*

Name of **METER** object, if any, by which system's fuel energy use is recorded (under appropriate end uses).

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**rsAFUE** = *float*

Heating Annual Fuel Utilization Efficiency (AFUE).

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1$	0.9 if furnace, 1.0 if resistance	No	constant

**rsCapH** = *float*

Heating capacity, used when rsType is ACFURNACE, ACRESISTANCE, FURNACE, or RESISTANCE.

Units	Legal Range	Default	Required	Variability
Btu/hr	<i>AUTOSIZE</i> or $x \geq 0$	0	No	constant

**rsTdDesH** = *float*

Nominal heating temperature rise (across system, not at zone) used during autosizing (when capacity is not yet known) and to derive heating air flow rate from heating capacity.

Units	Legal Range	Default	Required	Variability
°F	$x > 0$	30 °F if ASHP or ASHPHYDRONIC else 50 °F	No	constant

**rsFxCapH** = *float*

Heating autosizing capacity factor. If AUTOSIZED, rsCapH or rsCap47 is set to  $\text{rsFxCapH} \times (\text{peak design-day load})$ . Peak design-day load is the heating capacity that holds zone temperature at the thermostat set point during the *last substep* of all hours of all design days.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1.4	No	constant

**rsFanPwrH** = *float*

Heating fan power. Heating air flow is calculated from heating capacity and rsTdDesH.

Units	Legal Range	Default	Required	Variability
W/cfm	$x \geq 0$	.365	No	constant

**rsHSPF=float**

For rsType=ASHP, Heating Seasonal Performance Factor (HSPF).

Units	Legal Range	Default	Required	Variability
Btu/Wh	$x > 0$		Yes if rsType=ASHP	constant

**rsCap47=float**

For rsType=ASHP, rated heating capacity at outdoor dry-bulb temperature = 47 °F.

If both rsCap47 and rsCapC are autosized, they are set to consistent values based on the relative values of heating and cooling loads. If the autosized capC is greater than 75% of the autosized cap47, then rsCapC is set to autosized capC and rsCap47 is derived from rsCapC. Otherwise, rsCap47 is set to 75% of autosized cap47 and rsCapC is derived from rsCap47.

Units	Legal Range	Default	Required	Variability
Btu/Wh	<i>AUTOSIZE</i> or $x > 0$	Calculated from rsCapC	no	constant

**rsCap35=float**

For rsType=ASHP, rated heating capacity at outdoor dry-bulb temperature = 35 °F. rsCap35 typically reflects reduced capacity due to reverse (cooling) heat pump operation for defrost.

Units	Legal Range	Default	Required	Variability
Btu/Wh	$x > 0$	Calculated from rsCap47 and rsCap17	no	constant

**rsCap17=float**

For rsType=ASHP, rated heating capacity at outdoor dry-bulb temperature = 17 °F.

Units	Legal Range	Default	Required	Variability
Btu/Wh	$x > 0$	Calculated from rsCap47	no	constant

**rsCOP47=float**

For rsType=ASHP, rated heating coefficient of performance at outdoor dry-bulb temperature = 47 °F.

Units	Legal Range	Default	Required	Variability
	$x > 0$	Estimated from rsHSPF, rsCap47, and rsCap17	no	constant

**rsCOP35=float**

For rsType=ASHP, rated heating coefficient of performance at outdoor dry-bulb temperature = 35 °F.

Units	Legal Range	Default	Required	Variability
	$x > 0$	Calculated from rsCap35, rsCap47, rsCap17, rsCOP47, and rsCOP17	no	constant

**rsCOP17=float**

For rsType=ASHP, rated heating coefficient of performance at outdoor dry-bulb temperature = 17 °F.

Units	Legal Range	Default	Required	Variability
	$x > 0$	Calculated from rsHSPF, rsCap47, and rsCap17	no	constant

**rsCapAuxH=float**

For rsType=ASHP, auxiliary electric (“strip”) heating capacity. If AUTOSIZED, rsCapAuxH is set to the peak heating load evaluated at the heating design temperature (Top.heatDsTDbo).

Units	Legal Range	Default	Required	Variability
Btu/hr	AUTOSIZE or $x \geq 0$	0	no	constant

**rsDefrostModel=choice**

Selects modeling options for ASHP outdoor coil defrosting when 17 °F < TDbo < 45 °F. In this temperature range, heating capacity and/or efficiency are typically reduced due to frost accumulation on the outdoor coil.

REVCYCLE	Reverse compressor (cooling) operation. Net capacity and efficiency is derived from rsCap17/rsCOP17 and rsCap35/rsCOP35 using linear interpolation. Auxiliary heat is not modeled.			
REVCYCleaUX	Reverse compressor (cooling) operation with provision of sufficient auxiliary heat to make up the loss of heating capacity. Auxiliary heating is typically used to prevent cold air delivery to zones during the defrost cycle.			

Units	Legal Range	Default	Required	Variability
	one of above choices	REVCYCleaUX	No	constant

**rsFxCapAuxH=float**

Auxiliary heating autosizing capacity factor. If AUTOSIZED, rsCapAuxH is set to rsFxCapAuxH × (peak design-day load). Peak design-day load is the heating capacity that holds zone temperature at the thermostat set point during the *last substep* of all hours of all design days.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	No	constant

**rsCOPAuxH=float**

For rsType=ASHP, auxiliary electric (“strip”) heating coefficient of performance. Energy use for auxiliary heat is accumulated to end use HPHTG of meter rsElecMtr (that is, auxiliary heat is assumed to be electric).

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	1.0	no	constant

### rsSEER=float

Cooling rated Seasonal Energy Efficiency Ratio (SEER).

Units	Legal Range	Default	Required	Variability
Btu/Wh	$x > 0$		Yes	constant

### rsEER=float

Cooling Energy Efficiency Ratio (EER) at standard AHRI rating conditions (outdoor drybulb of 95 °F and entering air at 80 °F drybulb and 67 °F wetbulb).

Units	Legal Range	Default	Required	Variability
Btu/Wh	$x > 0$	Estimated from SEER	no	constant

### rsCapC=float

Cooling capacity at standard AHRI rating conditions. If rsType=ASHP and both rsCapC and rsCap47 are autosized, both are set to the larger consistent value.

Units	Legal Range	Default	Required	Variability
Btu/hr	<i>AUTOSIZE</i> or $x \leq 0$ ( $x > 0$ converted to $< 0$ )		Yes if rsType includes cooling	constant

### rsTdDesC=float

Nominal cooling temperature fall (across system, not zone) used during autosizing (when capacity is not yet known).

Units	Legal Range	Default	Required	Variability
°F	$x < 0$	-25	No	constant

### rsFxCapC=float

Cooling autosizing capacity factor. rsCapC is set to rsFxCapC  $\times$  (peak design-day load). Peak design-day load is the cooling capacity that holds zone temperature at the thermostat set point during the *last substep* of all hours of all design days.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1.4	No	constant

**rsFChg=float**

Cooling refrigerant charge adjustment factor. See rsFSize (below).

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	no	constant

**rsFSize=float**

Cooling compressor sizing factor. The effective cooling capacity is adjusted by the factor (rsFChg\*rsFSize) as specified by California Title 24 procedures.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	no	constant

**rsVFPerTon=float**

Standard air volumetric flow rate per nominal ton of cooling capacity.

Units	Legal Range	Default	Required	Variability
cfm/ton	$150 \leq x \leq 500$	350	no	constant

**rsFanPwrC=float**

Cooling fan power.

Units	Legal Range	Default	Required	Variability
W/cfm	$x \geq 0$	.365	No	constant

**rsASHPLockOutT=float**

Source air dry-bulb temperature below which the air source heat pump compressor does not operate.

Units	Legal Range	Default	Required	Variability
°F		(no lockout)	No	hourly

**rsCdH=float**

Heating cyclic degradation coefficient, valid only for compressor-based heating (heat pumps).

Units	Legal Range	Default	**Required	Variability
	$0 \leq x \leq 0.5$	ASHPHYDRONIC: 0.25 ASHP: derived from rsHSPF	No	hourly

**rsCdC=float**

Cooling cyclic degradation coefficient, valid for configurations having compressor-based cooling.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 0.5$	0	No	hourly

**rsFEffH=float**

Heating efficiency factor. At each time step, the heating efficiency is multiplied by rsFEffH.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	no	subhourly

**rsFEffC=float**

Cooling efficiency factor. At each time step, the cooling efficiency is multiplied by rsEffC.

Units	Legal Range	Default	Required	Variability
	$x > 0$	1	no	subhourly

**rsCapNomH=float**

Heating nominal capacity. Provides type-independent probe source for RSYS heating capacity. Daily variability is specified to support value changes during AUTOSIZEing. Values set via input are typically constant.

Units	Legal Range	Default	Required	Variability
Btu/hr	$x \geq 0$	no heating: 0 heat pump: rsCap47 (input or AUTOSIZED) other: rsCapH (input or AUTOSIZED)	no	daily

**rsCapNomC=float**

Cooling nominal capacity. Provides type-independent probe source for RSYS cooling capacity. Daily variability is specified to support value changes during AUTOSIZEing. Values set via input are typically constant.

Units	Legal Range	Default	Required	Variability
Btu/hr	$x \geq 0$	no cooling: 0 other: rsCap95 (input or AUTOSIZED)	no	daily

**rsDSEH=float**

Heating distribution system efficiency. If given, (1-rsDSEH) of RSYS heating output is discarded. Cannot be combined with more detailed DUCTSEG model.

Units	Legal Range	Default	Required	Variability
	$0 < x < 1$	(use DUCTSEG model)	No	hourly

**rsDSEC=float**

Cooling distribution system efficiency. If given, (1-rsDSEC) of RSYS cooling output is discarded. Cannot be combined with more detailed **DUCTSEG** model.

Units	Legal Range	Default	Required	Variability
	$0 < x < 1$	(use DUCTSEG model)	No	hourly

**rsOAVType=choice**

Type of central fan integrated (CFI) outside air ventilation (OAV) included in this RSYS. OAV systems use the central system fan to circulate outdoor air (e.g. for night ventilation).

OAV cannot operate simultaneously with whole building ventilation (operable windows, whole house fans, etc.). Availability of ventilation modes is controlled on an hourly basis via **Top ventAvail**.

NONE	No CFI ventilation capabilities
FIXED	Fixed-flow CFI (aka SmartVent). The specified rsOAVVfDs is used whenever the RSYS operates in OAV mode.
VARIABLE	Variable-flow CFI (aka NightBreeze). Flow rate is determined at midnight based on prior day's average dry-bulb temperature according to a control algorithm defined by the NightBreeze vendor.

Units	Legal Range	Default	Required	Variability
	NONE, FIXED, VARIABLE	NONE	No	constant

**rsOAVVfDs=float**

Design air volume flow rate when RSYS is operating in OAV mode.

Units	Legal Range	Default	Required	Variability
cfm	$\geq 0$	if rsOAVType $\neq$ NONE		constant

**rsOAVVfMinF=float**

Minimum air volume flow rate fraction when RSYS is operating in OAV mode. When rsOAVType=VARIABLE, air flow rate is constrained to rsOAVVfMinF \* rsOAVVfDs or greater.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 1$	0.2	No	constant

**rsOAVFanPwr=float**

RSYS OAV-mode fan power.

**Unit s	Legal Range	Default	Required	Variability
W/cfm	$0 < x \leq 5$	per rsOAVTYPE FIXED: rsFanPwrC VARIABLE: NightBreeze vendor curve based on rsOAVvfDs	No	constant

**rsOAVTDInlet=float**

OAV inlet (source) air temperature. Supply air temperature at the zone is generally higher due to fan heat. Duct losses, if any, also alter the supply air temperature.

Units	Legal Range	Default	Required	**Variability
°F		Dry-bulb temperature from weather file	No	hourly

**rsOAVTdiff=float**

OAV temperature differential. When operating in OAV mode, the zone set point temperature is  $\max(\text{znTD}, \text{inletT} + \text{rsOAVTdiff})$ . Small values can result in inadvertent zone heating, due to fan heat.

Units	Legal Range	Default	Required	Variability
°F	$> 0$	5 °F	No	hourly

**rsOAVReliefZn=znName**

Name of zone to which relief air is directed during RSYS OAV operation, typically an attic zone. Relief air flow is included in the target zone's pressure and thermal balance.

Units	Legal Range	Default	Required	Variability
	<i>name of ZONE</i>	if rsOAVType $\neq$ NONE		constant

**rsParElec=float**

Parasitic electrical power. rsParElec is unconditionally accumulated to rsElecMtr (if specified) and has no other effect.

Units	Legal Range	Default	Required	Variability
W		0	No	hourly

**rsParFuel=float**

Parasitic fuel use. rsParFuel is unconditionally accumulated to rsFuelMtr (if specified) and has no other effect.

Units	Legal Range	Default	Required	Variability
Btuh		0	No	hourly



**rsRhIn=float**

Entering air relative humidity (for model testing).

Units	Legal Range	Default	Required	Variability
W/cfm	$0 \leq x \leq 1$	Derived from entering air state	No	constant

**rsTdbOut=float**

Air dry-bulb temperature at the outdoor portion of this system.

Units	Legal Range	Default	Required	Variability
°F		From weather file	No	hourly

**endRSYS**

Optionally indicates the end of the RSYS definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @rsys
- @RSYSRes (accumulated results)

**4.21 DUCTSEG**

DUCTSEG defines a duct segment. Each **RSYS** has at most one return duct segment and at most one supply duct segment. That is, DUCTSEG input may be completely omitted to eliminate duct losses.

**dsName**

Optional name of duct segment; give after the word “DUCTSEG” if desired.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**dsTy=choice**

Duct segment type.

Units	Legal Range	Default	Required	Variability
	SUPPLY, RETURN		Yes	constant

The surface area of a DUCTSEG depends on its shape. 0 surface area is legal (leakage only). DUCTSEG shape is modeled either as flat or round –

- dsExArea specified: Flat. Interior and exterior areas are assumed to be equal (duct surfaces are flat and corner effects are neglected).

- dsExArea *not* specified: Round. Any two of dsInArea, dsDiameter, and dsLength must be given. Insulation thickness is derived from dsInsulR and dsInsulMat and this thickness is used to calculate the exterior surface area. Overall inside-to-outside conductance is also calculated including suitable adjustment for curvature.

**dsExArea=float**

Duct segment surface area at outside face of insulation for flat duct shape, see above.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x \geq 0$		No	constant

**dsInArea=float**

Duct segment inside surface area (at duct wall, duct wall thickness assumed negligible) for round shaped duct.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	$x \geq 0$	Derived from dsDiameter and dsLength	(see above re duct shape)	constant

**dsDiameter=float**

Duct segment round duct diameter (duct wall thickness assumed negligible)

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	Derived from dsInArea and dsLength	(see above re duct shape)	constant

**dsLength=float**

Duct segment length.

Units	Legal Range	Default	Required	Variability
ft	$x \geq 0$	Derived from dsInArea and dsDiameter	(see above re duct shape)	constant

**dsExCnd=choice**

Conditions surrounding duct segment.

Units	Legal Range	Default	Required	Variability
	ADIABATIC, AMBIENT, SPECIFIEDT, ADJZN	ADJZN	No	constant

**dsAdjZn=znName**

Name of zone surrounding duct segment; used only when dsExCon is ADJZN. Can be the same as a zone served by the **RSYS** owning the duct segment.

Units	Legal Range	Default	Required	Variability
	name of a <i>ZONE</i>	<i>none</i>	Required when <i>dsExCon</i> = ADJZN	constant

**dsEpsLW=float**

Exposed (i.e. insulation) outside surface exterior long wave (thermal) emittance.

Units	Legal Range	Default	Required	Variability
(none)	$0 \leq x \leq 1$	0.9	No	constant

**dsExT=float**

Air dry-bulb temperature surrounding duct segment.

Units	Legal Range	Default	Required	Variability
°F	<i>unrestricted</i>	<i>none</i>	Required if <i>sfExCnd</i> = SPECIFIEDT	hourly

**dsInsulR=float**

Insulation thermal resistance *not including* surface conductances. dsInsulR and dsInsulMat are used to calculate insulation thickness (see below). Duct insulation is modeled as a pure conductance (no mass).

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup> -F-hr / Btu	$x \geq 0$	0	No	constant

**dsInsulMat=matName**

Name of insulation **MATERIAL**. The conductivity of this material at 70 °F is combined with dsInsulR to derive the duct insulation thickness. If omitted, a typical fiberglass material is assumed having conductivity of 0.025 Btu/hr-ft<sup>2</sup>-F at 70 °F and a conductivity coefficient of .00418 1/F (see **MATERIAL**). In addition, insulation conductivity is adjusted during the simulation in response its average temperature. As noted with dsInsulR, duct insulation is modeled as pure conductance – **MATERIAL** matDens and matSpHt are ignored.

Units	Legal Range	Default	Required	Variability
	name of a <i>MATERIAL</i>	fiberglass	No	constant

**dsLeakF=float**

Duct leakage. Return duct leakage is modeled as if it all occurs at the segment inlet. Supply duct leakage is modeled as if it all occurs at the outlet.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1$		No	constant

**dsExH=float**

Outside (exposed) surface convection coefficient.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$x > 0$	.54	No	subhourly

**endDuctSeg**

Optionally indicates the end of the DUCTSEG definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:**

- **@ductSeg**
- **@izXfer** (generated as "<Zone Name>-DLkI" for supply or "<Zone Name>-DLkO" for return)

## 4.22 DHWDAYUSE

Defines an object that represents domestic hot water use for a single day. A DHWDAYUSE contains a collection of **DHWUSE** objects that specify the time, volume, and duration of individual draws. DHWDAYUSES are referenced by **DHWSYS** wsDayUse. Unreferenced DHWDAYUSES are allowed.

DHWDAYUSES and their child **DHWUSEs** are used to construct minute-by-minute hot water use schedules in addition to aggregated hourly schedules. The minute-by-minute schedules are used for modeling resistance and heat pump storage water heaters, see **DHWHEATER** whType=SmallStorage whHeatSrc=ResistanceX or whHeatSrc=ASHPX.

The following illustrates some features of DHWDAYUSE / **DHWUSE** –

DHWDAYUSE "Sample"

```
// 6 AM: 7 min shower, 2 gpm @ 105 F
```

```
DHWUSE whStart=6.0 wuDuration=7 wuFlow=2 wuTemp=105 wuEndUse=Shower wuEventID=1
```

```
// 7 AM: 1 min faucet draw, 100% hot
```

```
DHWUSE whStart=7.0 wuDuration=1 wuFlow=1 wuHotF=1 whEndUse=Faucet wuEventID=2
```

```
// 12:30 PM: dishwasher start, several draws over 70 mins; note common wuEventID
```

```
DHWUSE whStart=12.5 wuDuration=2 wuFlow=2 wuHotF=1 whEndUse=DWashr wuEventID=3
```

```
DHWUSE whStart=12.8 wuDuration=1.5 wuFlow=2 wuHotF=1 whEndUse=DWashr wuEventID=3
```

```
DHWUSE whStart=13.6 wuDuration=3 wuFlow=2 wuHotF=1 whEndUse=DWashr wuEventID=3
```

```
// 7 PM every 2nd day: clothes washer runs
```

```
// even days: 0 gpm (no draw)
```

```
// odd days: 3 gpm, 22% hot
```

```
DHWUSE whStart=19 wuDuration=30 wuFlow = ($dayOfYear%2)*3 whEndUse=CWashr whHotF=.22 wuEventID=4
```

```
// 11:54 PM: 20 min bath, 1.5 gpm, 80% hot water
```

```
// Duration spans midnight: draw is wrapped to beginning of *current* day
```

```
// In this case a 12 M - 12:14 AM draw is modeled -- before (!) the bath start.
```

```
DHWUSE whStart 23.9 wuDuration=20 wuFlow=1.5 wuHotF=.8 whEndUse=Bath wuEventID=99
```

endDHWDAYUSE

```
DHWSYS "DHWSYS1"
```

```
...
wsDayUse = "Sample"
...
```

During the simulation, **DHWUSEs** are evaluated each hour. Many **DHWUSE** values have hourly variability and this allows complicated schemes to be constructed very flexibly. For example:

```
DHWDAYUSE "HourlyFaucet"
// Every hour on the half hour: 5 minute, 2 gpm draw
// Same as 24 DHWUSEs, one for each hour
DHWUSE wuStart=$hour+.5 wuDuration=5 wuFlow=2 wuEndUse=Faucet
endDAYUSE
```

Some **DHWUSE** configurations involve mixing to specified wuTemp. Hot and cold water arriving at the point of use is assumed to be at **DHWSYS** wsUseTemp and wsMainsTemp respectively. It is possible to set up situations where wuTemp cannot be achieved (wuTemp > wsUseTemp, for example). Runtime error messages are produced when impossible conditions are detected.

When more than one **DHWSYS** references the same DHWDAYUSE, **DHWUSEs** are allocated to **DHWSYSs** in wuEventID rotation. This procedure divides the water heating load approximately equally while retaining the peak demand of individual events. When detailed information is available about which loads are served by specific systems, separate DHWDAYUSEs should be given.

### dhwDayUseName

Object name, given after "DHWDAYUSE". Required for referencing from **DHWSYS**.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	Yes	constant

### wduMult=float

Scale factor applied to all draws in this DHWDAYUSE.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	constant

### endDHWDAYUSE

Indicates the end of the DHWDAYUSE definition. endDHWDAYUSE should follow all child **DHWUSEs**. Alternatively, the end of the meter definition can be indicated by the declaration of another object or by END.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

### Related Probes:

- @**DHWD**ayUse

## 4.23 DHWUSE

Defines a single hot water draw as part of a **DHWDAYUSE**. See discussion and examples under **DHWDAYUSE**. As noted there, most DHWUSE values have hourly variability, allowing flexible representation.

### **wuName**

Optional name; give after the word “DHWUSE” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

### **wuStart=float**

The starting time of the hot water draw.

Units	Legal Range	Default	Required	Variability
hr	$0 \leq x \leq 24$	–	Yes	constant

### **wuDuration=float**

Draw duration.  $wuDuration = 0$  is equivalent to omitting the DHWUSE. Durations that extend beyond midnight are included in the current day.

Units	Legal Range	Default	Required	Variability
min	$0 \leq x \leq 1440$	0	N	hourly

### **wuFlow=float**

Draw flow rate at the point of use (in other words, the mixed-water flow rate).  $wuFlow = 0$  is equivalent to omitting the DHWUSE. There is no enforced upper limit on  $wuFlow$ , however, unrealistically large values can cause runtime errors.

Units	Legal Range	Default	Required	Variability
gpm	$0 \leq x$	0	N	hourly

### **wuHotF=float**

Fraction of draw that is hot water. Cannot be specified with  $wuTemp$  or  $wuHeatRecEF$ .

Units	Legal Range	Default	Required	Variability
–	$0 \leq x \leq 1$	1	N	hourly

### **wuTemp=float**

Mixed-water use temperature at the fixture. Cannot be specified when  $wuHotF$  is given.

**Unit s	Legal Range	**Default t	Required	Variability
°F	$0 \leq x$	0	when wuHeatRecEF is given or parent DHWSYS includes DHWHEATREC(s)	hourly

**wuHeatRecEF=float**

Heat recovery effectiveness, allows simple modeling of heat recovery devices such as drain water heat exchangers.

If non-0 (evaluated hourly), hot water use is reduced based on wuTemp, DHWSYS wsTUse, and DHWSYS wsTInlet. DHWHEATREC(s), if any, are ignored for this use. wuTemp must be specified.

If 0, detailed heat recovery modeling *may* apply, see DHWHEATREC.

Units	Legal Range	Default	Required	Variability
–	$0 \leq x \leq 0.9$	0	N	hourly

**wuHWEndUse=choice**

Hot-water end use: one of Shower, Bath, CWashr, DWashr, or Faucet. wuHWEndUse has the following functions –

- Allocation of hot water use among multiple DHWSYSs (if more than one DHWSYS references a given DHWDAYUSE).
- DHWMETER end-use accounting (via DHWSYS).
- Activation of the detailed heat recovery model (available for end use Shower when wuHeatRecEF=0 and the parent DHWSYS includes DHWHEATREC(s)).

Units	Legal Range	Default	Required	Variability
–	One of above choices	(use allocated to Unknown)	N	constant

**wuEventID=integer**

User-defined identifier that associates multiple DHWUSEs with a single event or activity. For example, a dishwasher uses water at several discrete times during a 90 minute cycle and all DHWUSEs would be assigned the same wuEventID. All DHWUSEs having the same wuEventID should have the same wuHWEndUse.

Units	Legal Range	Default	Required	Variability
–	$0 \leq x$	0	N	constant

**endDHWUSE**

Optionally indicates the end of the DHWUSE definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:**

- @DHWUse

## 4.24 DHWSYS

DHWSYS constructs an object representing a domestic hot water system consisting of one or more hot water heaters, storage tanks, loops, and pumps (DHWHEATER, DHWTANK, DHWLOOP, and DHWPUMP, see below) and a distribution system characterized by loss parameters. This model is based on Appendix B of the 2019 Residential ACM Reference Manual and the Ecotope HPWHSim air source heat pump water heater model (called HPWH herein).

The parent-child structure of DHWSYS components is determined by input order. For example, DHWHEATERs belong to the DHWSYS that precedes them in the input file. The following hierarchy shows the relationship among components. Note that any of the commands can be repeated any number of times.

- DHWSYS
  - DHWHEATER
  - DHWLOOPHEATER
  - DHWHEATREC
  - DHWTANK
  - DHWPUMP
  - DHWLOOP
    - \* DHWLOOPPUMP
    - \* DHWLOOPSEG
      - DHWLOOPBRANCH

Minimal modeling is included for physically realistic controls. For example, if several DHWHEATERs are included in a DHWSYS, an equal fraction of the required hot water is assumed to be produced by each heater, even if they are different types or sizes. Thus a DHWSYS is in some ways a collection of components as opposed to an explicitly connected system. This approach avoids requiring detailed input that would impose impractical user burden, especially in compliance applications.

### dhwsysName

Optional name of system; give after the word “DHWSYS” if desired.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

### wsCalcMode=*choice*

Enables preliminary simulation that derives values needed for simulation.

PRERUN	Calculate hot water heating load; at end of run, derive whLDEF for all child DHWHEATERs for which that value is required and defaulted (this emulates methods used in the T24DHW.DLL implementation of CEC DHW procedures). Also derived are average number of draws per day by end use (used in the wsDayWaste scheme).
SIMULATE	Perform full modeling calculations

To use PRERUN efficiently, the recommended input file structure is:

- General input



- DHWSYS(s) and child objects
- RUN
- ALTER DHWSYS input (as needed)
- Building input
- RUN

This order avoids duplicate time-consuming simulation of the full building model.

Units	Legal Range	Default	Required	Variability
	<i>Codes listed above</i>	SIMULATE	No	

#### **wsCentralDHWSYS=***dhwsysName*

Name of the central DHWSYS that serves this DHWSYS, allowing representation of multiple units having distinct distribution configurations and/or water use patterns but served by a central DHWSYS. The child DHWSYS(s) may not include **DHWHEATERs** – they are “loads only” systems. wsCentralDHWSYS and wsLoadShareDHWSYS cannot both be given.

Units	Legal Range	Default	Required	Variability
	<i>name of a DHWSYS</i>	DHWSYS is standalone	No	constant

#### **wsLoadShareDHWSYS=***dhwsysName*

Name of a DHWSYS that serves the same loads as this DHWSYS, allowing representation of multiple water heating systems within a unit. If given, wsUse and wsDayUse are not allowed, hot water requirements are derived from the referenced DHWSYS. wsCentralDHWSYS and wsLoadShareDHWSYS cannot both be given.

For example, two DHWSYSs should be defined to model two water heating systems serving a load represented by wsDayUse DayUseTyp. Each DHWSYS should include **DHWHEATER(s)** and other components as needed. DHWSYS Sys1 should specify wsDayUse=DayUseTyp and DHWSYS Sys2 should have wsLoadShareDHWSYS=Sys1 in place of wsDayUse.

Loads are shared by assigning **DHWUSE** events sequentially by end use to all DHWSYS with compatible fixtures (determined by wsFaucetCount, wsShowerCount etc., see below) in the group. This algorithm approximately divides load for each end use by the number of compatible fixtures in the group. In addition, assigning 0 to a fixture type prevents assignment of an end use load to a DHWSYS – for example, wsDWashrCount=0 could be provided for a DHWSYS that does not serve a kitchen.

Units	Legal Range	Default	Required	Variability
	<i>name of a DHWSYS</i>	No shared loads	No	constant

#### **wsMult=***float*

Number of identical systems of this type (including all child objects). Any value > 1 is equivalent to repeated entry of the same DHWSYS. A value of 0 is equivalent to omitting the DHWSYS. Non-integral values scale all results; this may be useful in parameterized models, for example.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	constant

**wsFaucetCount=integer**  
**wsShowerCount=integer**  
**wsBathCount=integer**  
**wsCWashrCount=integer**  
**wsDWashrCount=integer**

Specifies the count of fixtures served by this DHWSYS that can accommodate draws of each end use (see **DHWUSE**). These counts are used for distributing draws in shared load configurations (multiple DHWSYSs serving the same loads, see wsLoadShareDHWSYS above).

In addition, wsShowerCount participates in assignment of Shower draws to **DHWHEATREC**s (if any).

Unless this DHWSYS is part of a shared-load group or includes **DHWHEATREC**(s), these counts have no effect and need not be specified.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	constant

**wsTInlet=float**

Specifies cold (mains) water temperature supplying this DHWSYS. **DHWHEATER** supply water temperature wsTInlet adjusted (increased) by any **DHWHEATREC** recovered heat and application of wsSSF (approximating solar preheating).

Units	Legal Range	Default	Required	Variability
°F	> 32 °F	Mains temp from weather file	No	hourly

Hot water demand determination

**wsUse=float**

Hourly hot water use (at the point of use). See further info under wsDayUse.

Units	Legal Range	Default	Required	Variability
gal	$\geq 0$	0	No	hourly

**wsDayUse=dhwdayuseName**

Name of **DHWDAYUSE** object that specifies a detailed schedule of mixed water use at points of hot water use (that is, “at the tap”). The mixed water amounts are used to derive hot water requirements based on specified mixing fractions or mixed water temperature (see **DHWDAYUSE** and **DHWUSE**).

The total water use modeled by CSE is the sum of amounts given by wsUse and the DHWDAYUSE schedule. **DHWDAYUSE** draws are resolved to minute-by-minute bins compatible with the HPWH model and wsUse/60 is added to each minute bin. Conversely, the hour total of the **DHWDAYUSE** amounts is included in the draw applied to non-HPWH **DHWHEATERS**.

wsDayUse variability is daily, so it is possible to select different schedules as a function of day type (or any other condition), as follows –

```

DHWSYS "DHW1"
...
wsDayUse = choose( $isWeHol, "DUSEWeekday", "DUSEWeHol")
...

```

Note that while **DHWDAYUSE** selection is updated daily, the **DHWUSE** values within the **DHWDAYUSE** can be altered hourly, providing additional scheduling flexibility.

Units	Legal Range	Default	Required	Variability
<i>name of a DHWDAYUSE</i>		(no scheduled draws)	No	daily

**wsFaucetWaste**=*float*  
**wsShowerWaste**=*float*  
**wsBathWaste**=*float*  
**wsCWashrWaste**=*float*  
**wsDWashrWaste**=*float*

Specifies additional draw volume per **DHWUSE** event (at fixture, by end use). This can be used to account for water discarded during warmup or otherwise adjust the draw volume. Because the values are at the fixture, the impact on hot water demand additionally depends on **DHWUSE** parameters. The value is applied by lengthening (or shortening) the draw duration.

Note that **DHWUSE** draws can be referenced by multiple DHWSYSs; these adjustments apply only to the current DHWSYS.

These adjustments have not impact on draw specified by wsUse.

Units	Legal Range	Default	Required	Variability
gal/draw	–	0	No	hourly

**wsBranchModel**=*choice*

ToDo

**wsDayWasteVol**=*float*

Average amount of waste per day.

**Unit s	Legal Range	Default	**Require d	Variabili t y
gal/day	$\geq 0$	wsDayWasteBranchVolF * (Total DHWLOOPBRANCH vol)	No	constant

**wsDayWasteBranchVolF**=*float*

Day waste scaling factor.

Units	Legal Range	Default	Required	Variability
–	$\geq 0$	1	No	constant

**wsDayWasteFaucetF**=*float*  
**wsDayWasteShowerF**=*float*  
**wsDayWasteBathF**=*float*  
**wsDayWasteCWashrF**=*float*  
**wsDayWasteDWashrF**=*float*

ToDo

*Units** *	*Legal Range** *	*Default** *	*Required** *	*Variability**
	$\geq 0$	0 N	o s	ubhourly

**wsTUse=float**

Hot water delivery temperature (at output of water heater(s) and at point of use). Delivered water is mixed down to wsTUse (with cold water) or heated to wsTUse (with extra electric resistance backup, see **DHWHEATER** whXBUEndUse). Note that draws defined via **DHWDAYUSE** / **DHWUSE** can specify mixing to a lower temperature.

Units	Legal Range	Default	Required	Variability
°F	> 32 °F	120	No	hourly

**wsTSetPoint=float**

Specifies the hot water setpoint temperature for all child **DHWHEATERs**. Used only for HPWH-based **DHWHEATERs** (HPWH models tank temperatures and heating controls), otherwise has no effect.

Units	Legal Range	Default	Required	Variability
°F	> 32 °F	wsTUse	No	hourly

**wsTSetPointLH=float**

Specifies the hot water setpoint temperature for all child **DHWLOOPHEATERs**. Used only for HPWH-based **DHWLOOPHEATERs** (HPWH explicitly models tank temperatures and heating controls), otherwise has no effect.

Units	Legal Range	Default	Required	Variability
°F	> 32 °F	wsTSetPoint	No	hourly

**wsSDLM=float**

Specifies the standard distribution loss multiplier. See App B Eqn 4. To duplicate CEC 2019 methods, this value should be set according to the value derived with App B Eqn 5.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wsDSM=float**

Distribution system multiplier. See RACM App B Eqn 4. To duplicate CEC 2016 methods, wsDSM should be set to the appropriate value from App B Table B-2. Note the NCF (non-compliance factor) included in App B Eqn 4 is *not* a CSE input and thus must be applied externally to wsDSM.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wsWF=float**

Waste factor. See RACM App B Eqn 1. wsWF is applied to hot water draws. The default value (1) reflects the inclusion of waste in draw amounts. App B specifies wsWF=0.9 when the system has a within-unit pumped loop that reduces waste due to immediate availability of hot water at fixtures.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	hourly

**wsSSF=float**

NOTE: Deprecated. Use wsSolarSys instead.

Specifies the solar savings fraction, allowing recognition of externally-calculated solar water heating energy contributions. The contributions are modeled by deriving an increased water heater feed temperature –

$$tWHFeed = tInletAdj + wsSSF * (wsTUse - tInletAdj)$$

where tInletAdj is the source cold water temperature *including any DHWHEATREC tempering* (that is, wsTInlet + heat recovery temperature increase, if any). This model approximates the diminishing returns associated with combined preheat strategies such as drain water heat recovery and solar.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 0.99$	0	No	hourly

**wsSolarSys=dhwSolarSys**

Name of DHWSOLARSYS object, if any, that supplies pre-heated water to this DHWSYS.

Units	Legal Range	Default	Required	Variability
	<i>name of a DHWSOLARSYS</i>	<i>not recorded</i>	No	constant

**wsParElec=float**

Specifies electrical parasitic power to represent recirculation pumps or other system-level electrical devices. Calculated energy use is accumulated to the METER specified by wsElecMtr (end use DHW). No other effect, such as heat gain to surroundings, is modeled.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	0	No	hourly

**wsElecMtr=mtrName**

Name of METER object, if any, to which DHWSYS electrical energy use is recorded (under end use DHW). In addition, wsElecMtr provides the default whElectMtr selection for all DHWHEATERs and DHWPUMPs in this DHWSYS.

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**wsFuelMtr = mtrName**

Name of **METER** object, if any, to which DHWSYS fuel energy use is recorded (under end use DHW). DHWSYS fuel use is usually (always?) 0, so the primary use of this input is to specify the default whFuelMtr choice for **DHWHEATERs** in this DHWSYS.

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**wsWHhwMtr = dhwmtrName**

Name of **DHWMETER** object, if any, to which hot water quantities (at water heater) are recorded by hot water end use.

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**wsFXhwMtr = dhwmtrName**

Name of **DHWMETER** object, if any, to which mixed hot water use (at fixture) quantities are recorded by hot water end use. **DHWDAYUSE** and wsUse input can be verified using **DHWMETER** results.

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**wsWriteDrawCSV = choice**

If Yes, a comma-separated file is generated containing 1-minute interval hot water draw values for testing or linkage purposes.

Units	Legal Range	Default	Required	Variability
	<i>Yes or No</i>	No	No	constant

**endDHWSys**

Optionally indicates the end of the DHWSYS definition.

Units	Legal Range	Default	Required	Variability
<i>n/a</i>	<i>n/a</i>	<i>n/a</i>	No	<i>n/a</i>

**Related Probes:**

- **@DHWSys**

## 4.25 DHWHEATER

DHWHEATER constructs an object representing a domestic hot water heater (or several if identical).

**whName**

Optional name of water heater; give after the word "DHWHEATER" if desired.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**whMult=integer**

Number of identical water heaters of this type. Any value > 1 is equivalent to repeated entry of the same DHWHEATER.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**whType=choice**

Type of water heater. This categorization is based on CEC and federal rating standards that change from time to time.

SMALLSTORAGE	A storage water heater having an energy factor (EF) rating. Generally, a gas-fired storage water heater with input of 75,000 Btuh or less, an oil-fired storage water heater with input of 105,000 Btuh or less, an electric storage water heater with input of 12 kW or less, or a heat pump water heater rated at 24 amps or less.
LARGESTORAGE	Any storage water heater that is not SMALLSTORAGE.
SMALLINSTANTANEOUS	A water heater that has an input rating of at least 4,000 Btuh per gallon of stored water. Small instantaneous water heaters include: gas instantaneous water heaters with an input of 200,000 Btu per hour or less, oil instantaneous water heaters with an input of 210,000 Btu per hour or less, and electric instantaneous water heaters with an input of 12 kW or less.
LARGEINSTANTANEOUS	An instantaneous water heater that does not conform to the definition of SMALLINSTANTANEOUS, an indirect fuel-fired water heater, or a hot water supply boiler.
INSTANTANEOUSUEF	An instantaneous water heater having a UEF rating (as opposed to EF).

Units	Legal Range	Default	Required	Variability
	Codes listed above	SMALLSTORAGE	No	constant

**whHeatSrc=choice**

Heat source for water heater. CSE implements uses efficiency-based models for all whTypes (as documented in RACM, App. B). In addition, the detailed Ecotope HPWH model is available for electric (air source heat pump and resistance) SMALLSTORAGE water heaters.

RESISTANCE	Electric resistance heating element Deprecated for whType=SMALLSTORAGE (use RESISTANCEX)
RESISTANCEX	Electric resistance heating element, detailed HPWH model
ASHP	Air source heat pump, EF model Deprecated for whType=SMALLSTORAGE (use ASHPX)
ASHPX	Air source heat pump, detailed HPWH model
FUEL	Fuel-fired burner

Units	Legal Range	Default	Required	Variability
<i>Codes listed above</i>		FUEL	No	constant

**whVol=float**

Storage tank volume. Must be omitted or 0 for instantaneous whTypes. Used by HPWH model (whHeatSrc=RESISTANCEX or whHeatSrc=ASHPX). Required when whHeatSrc=RESISTANCEX or whHeatSrc=ASHPX with whASHPTType=GENERIC. For all other configurations, whVol is documentation-only.

Units	Legal Range	Default	Required	Variability
gal	$\geq 0.1$ (caution: small values may cause runtime errors)	per whASHPTType if HPWH else 50	For some HPWH configurations, see above	constant

**whEF=float**

Rated energy factor that specifies DHWHEATER efficiency under test conditions. Used by CSE to derive annual water heating efficiency and/or other characteristics as described below. Calculation methods are documented in RACM, Appendix B.

Configuration	whEF default	Use
whType=SMALLSTORAGE whHeatSrc=RESISTANCE or FUEL	0.82	Derivation of whLDEF
whType=SMALLSTORAGE whHeatSrc=ASHP	0.82	Derivation of whLDEF note inappropriate default (deprecated, use ASHPX)
whType=SMALLSTORAGE whHeatSrc=ASHPX whASHPTType=GENERIC	(req'd)	Tank losses Overall efficiency
whType=SMALLSTORAGE whHeatSrc=RESISTANCEX	(req'd)	Tank losses
whType=SMALLINSTANTANEOUS whHeatSrc=RESISTANCE or FUEL	0.82	Note: maximum whEF=0.98. Annual efficiency = whEF*0.92
Any other	(unused)	



Units	Legal Range	**Default t	**Require d	Variability
	> 0 <i>Caution: maximum not checked. Unrealistic values will cause runtime errors and/or invalid results</i>	<i>See above</i>	<i>See above</i>	constant

**whLDEF=float**

Load-dependent energy factor for DHWHEATERS with whType=SMALLSTORAGE and whHeatSrc=FUEL or whHeatSrc=RESISTANCE. If not given, whLDEF is derived using a preliminary simulation activated via **DHWSYS** wsCalcMode=PRERUN. See RACM Appendix B.

Units	Legal Range	Default	Required	Variability
	> 0	Calculated via DHWSYS PreRun mechanism	When whType = SMALLSTORAGE and PreRun not used	constant

**whUEF=float**

Water heater Uniform Energy Factor efficiency rating, used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	–	when whType=INSTANTANEOUSUEF	constant

**whAnnualElec=float**

Annual electricity use assumed in UEF rating derivation. Used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
kWh	$\geq 0$	–	when whType=INSTANTANEOUSUEF	constant

**whAnnualFuel=float**

Annual fuel use assumed in UEF rating derivation, used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
therms	$\geq 0$	–	when whType=INSTANTANEOUSUEF	constant

**whRatedFlow=float**

Maximum flow rate assumed in UEF rating derivation. Used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
gpm	>0	–	when whType=INSTANTANEOUSUEF	constant

**whStbyElec=float**

Instantaneous water heater standby power (electricity consumed when heater is not operating). Used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	4	No	constant

**whLoadCFwdF=float**

Instantaneous water heater load carry forward factor – approximate number of hours the heater is allowed to meet water heating demand that is unmet on a 1 minute basis, used when whType=INSTANTANEOUSUEF.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	Constant

**whZone=znName**

Name of zone where water heater is located, used only in detailed HPWH models (whHeatSrc=ASHPX or whHeatSrc=RESISTANCEX), otherwise no effect. Zone conditions are used for tank heat loss calculations. Heat exchanged with the DHWHEATER are included in the zone heat balance. whZone also provides the default for whASHPSrcZn (see below). whZone and whTEx cannot both be specified.

Units	Legal Range	Default	Required	**Variability
	name of a ZONE	Not in a zone (heat losses discarded)	No	constant

**whTEx=float**

Water heater surround temperature, used only in detailed HPWH models (whHeatSrc=ASHPX or whHeatSrc=RESISTANCEX), otherwise no effect. whZone and whTEx cannot both be specified.

Units	Legal Range	Default	Required	Variability
°F	$\geq 0$	whZone air temperature if specified, else 70 °F	No	hourly

**whASHPType=choice**

Air source heat pump type, valid only if whHeatSrc=ASHPX. These choices are supported by the detailed HPWH model. Except for Generic, all heater characteristics are set by HPWH based on whASHPType.

Choice	Specified type
Generic	General generic (parameterized by wh_EF and wh_vol)
AOSmithPHPT60	60 gallon Voltex
AOSmithPHPT80	80 gallon Voltex
AOSmithHPTU50	50 gallon AOSmith HPTU
AOSmithHPTU66	66 gallon AOSmith HPTU
AOSmithHPTU80	80 gallon AOSmith HPTU
Sanden40	Sanden 40 gallon CO2 external heat pump
Sanden80	Sanden 80 gallon CO2 external heat pump

Choice	Specified type
GE2012	2012 era GeoSpring
GE2014	2014 50 gal GE run in the efficiency mode
GE2014StdMode	2014 50 gal GE run in standard mode
GE2014StdMode80	2014 80 gal GE run in standard mode
RheemHB50	newish Rheem (2014 model?)
RheemHBDR2250	50 gallon, 2250 W resistance Rheem HB Duct Ready
RheemHBDR4550	50 gallon, 4500 W resistance Rheem HB Duct Ready
RheemHBDR2265	65 gallon, 2250 W resistance Rheem HB Duct Ready
RheemHBDR4565	65 gallon, 4500 W resistance Rheem HB Duct Ready
RheemHBDR2280	80 gallon, 2250 W resistance Rheem HB Duct Ready
RheemHBDR4580	80 gallon, 4500 W resistance Rheem HB Duct Ready
Stiebel220E	Stiebel Eltron (2014 model?)
GenericTier1	Generic Tier 1
GenericTier2	Generic Tier 2
GenericTier3	Generic Tier 3
UEF2Generic	Experimental UEF=2
BasicIntegrated	Typical integrated HPWH
ResTank	Resistance heater (no compressor). Superseded by whHeatSrc=RESITANCEX
ResTankNoUA	Resistance heater (no compressor) with no tank losses. Superseded by whHeatSrc=RESISTANCEX.
AOSmithHPTU80DR	80 gallon AOSmith HPTU with fixed backup setpoint (experimental for demand response testing)
AOSmithSHPT50	50 gal AOSmith SHPT
AOSmithSHPT66	66 gal AOSmith SHPT
AOSmithSHPT80	80 gal AOSmith SHPT

Units	Legal Range	Default	Required	Variability
	<i>Codes listed above</i>	–	When whHeatSrc=ASHPX	constant

**whASHPSrcZn=znName**

Name of zone that serves as heat pump heat source used when whHeatSrc=ASHPX. Used for tank heat loss calculations and default for whASHPSrcZn. Heat exchanges are included in zone heat balance. whASHPSrcZn and whASHPSrcT cannot both be specified.

Units	Legal Range	Default	Required	Variability
	name of a ZONE	Same as whZone if whASHPSrcT not specified. If no zone is specified by input or default, heat extracted by ASHP has no effect.	No	constant

**whASHPSrcT=float**

Heat pump source air temperature used when whHeatSrc=ASHPX. Heat removed from this source is added to the heated water but has no other effect. whASHPSrcZn and whASHPSrcT cannot both be specified.

Units	Legal Range	Default	Required	Variability
°F	$\geq 0$	whASHPZn air temperature if specified, else 70 °F	No	hourly

**whASHPResUse=float**

Specifies activation temperature difference for resistance heating, used only when whHeatSrc=ASHPX and whASHPType=GENERIC. Refer to HPWH engineering documentation for model details.

Units	Legal Range	Default	Required	Variability
°C	$\geq 0$	7.22	N	constant

**whResHtPwr=float**

Specifies resistance upper element power, used only with whHeatSrc=RESISTANCEX.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	4500	N	constant

**whResHtPwr2=float**

Specifies resistance lower element power, used only with whHeatSrc=RESISTANCEX.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	whResHtPwr	N	constant

**whUAMult=float**

Tank UA multiplier, used only with whHeatSrc=RESISTANCEX. Used to account for e.g. tank wrap insulation. Note that tank UA is derived from whEF and cannot be directly set.

Units	Legal Range	Default	Required	Variability
	$> 0$	1	N	constant

**whInHtSupply=float****whInHtLoopRet=float**

Fractional tank height of inlets for supply water and DHWLOOP return, used only with HPWH types (whHeatSrc=RESISTANCEX or whHeatSrc=ASHPX). 0 indicates the bottom of the water heater tank and 1 specifies the top. Inlet height influences tank layer mixing and can impact heat pump COP and/or heating activation frequency.

Units	Legal Range	Default	Required *	*Variability**
-	$0 \leq x \leq 1$	HPWH default (0?)	N	constant

**whHPAF=float**

Heat pump adjustment factor, applied to whLDEF when modeling whType=SMALLSTORAGE and whHeatSrc=ASHP. This value should be derived according to RACM App B Table B-6. Deprecated: the

detailed HPWH model (whHeatSrc=ASHPX) is recommended for air source heat pumps.

Units	Legal Range	Default	Required	Variability
> 0	1	When whType=SMALLSTORAGE and whHeatSrc=ASHP		constant

### **whEff=float**

Water heating efficiency, used in modeling whType=LARGESTORAGE and whType=LARGEINSTANTANEOUS.

Units	Legal Range	Default	Required	Variability
	$0 < \text{whEff} \leq 1$	.82	No	constant

### **whSBL=float**

Standby loss, used in modeling whType=LARGESTORAGE.

Units	Legal Range	Default	Required	Variability
Btuh	$\geq 0$	0	No	constant

### **whPilotPwr=float**

Pilot light consumption, included in fuel energy use of DHWHEATERS with whHeatSrc=FUEL.

Units	Legal Range	Default	Required	Variability
Btuh	$\geq 0$	0	No	hourly

### **whParElec=float**

Parasitic electricity power, included in electrical energy use of all DHWHEATERS.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	0	No	hourly

### **whElecMtr=mtrName**

Name of **METER** object, if any, by which DHWHEATER electrical energy use is recorded (under end use DHW).

Units	Legal Range	Default	Required	Variability
<i>name of a METER</i>	<i>Parent DHWSYS wsElecMtr</i>	No		constant

### **whxBUEndUse=choice**

Specifies the whElecMtr end use, if any, to which extra backup energy is accumulated. In some water heater types, extra backup energy is modeled to maintain output temperature at wsTUse. By default, extra backup energy is included in end use dhwBU. whxBUEndUse allows specification of an alternative end use to which extra backup energy is accumulated.

Units	Legal Range	Default	Required	Variability
	<i>end use code</i>	(extra backup accums to dhwbU)	No	constant

**whFuelMtr = *mtrName***

Name of **METER** object, if any, by which DHWHEATER fuel energy use is recorded (under end use DHW).

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>Parent DHWSYS wsFuelMtr</i>	No	constant

**endDHWHEATER**

Optionally indicates the end of the DHWHEATER definition.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	

**Related Probes:**

- @DHWHeater

## 4.26 DHWLOOPHEATER

DHWHEATERLOOP constructs an object representing a hot water heater dedicated to heating **DHWLOOP** return water (or several if identical).

Refer to **DHWHEATER**.

## 4.27 DHWHEATREC

DHWHEATREC constructs an object representing one or more heat recovery devices in a **DHWSYS**. Drain water heat recovered by the device increases parent **DHWSYS** wsInlet temperature and/or fixture cold water feed temperature. This reduces water heating energy consumption.

**wrName**

Optional name of device; give after the word “DHWHEATREC” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**wrMult = *integer***

Number of identical heat recovery devices of this type. Any value >1 is equivalent to repeated entry of the same DHWHEATREC.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wrHWEndUse = *choice***

Hot water end use to which this DHWHEATREC is applied: one of Shower, Bath, CWashr, DWashr, or Faucet. Selects **DHWUSE** draws for heat recovery calculations. Currently, only Shower is supported.

Units	Legal Range	Default	Required	Variability
–	Shower	Shower	No	constant

**wrCountFXDrain=integer**

Number of fixtures (of type wrHWEndUse) whose drain lines pass through this heat recovery device. wrCountFXDrain=0 causes this DHWHEATREC to have no effect (that is, equivalent to omitting the DHWHEATREC command).

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	constant

**wrCountFXCold=integer**

Number of fixtures (of type wrHWEndUse) with cold water supply connected to the DHWHEATREC potable-side outlet and thus use tempered water to mix with hot water.

Units	Legal Range	Default	Required	Variability
	$\geq 0$	1	No	constant

**wrFeedsWH=choice**

Specifies whether the potable-side outlet of the DHWHEATREC is connected to the **DHWHEATER(s)** inlet.

Units	Legal Range	Default	Required	Variability
–	Yes, No	No	No	constant

**wrType=choice**

Specifies the type of heat recovery device: Vertical, Horizontal, or SetEF. Horizontal and Vertical derive effectiveness from wrCSARatedEF, flow rates, and water temperatures. As of Feb. 2019, the same correlation is used for both Horizontal and Vertical, so these choices have no effect on results. Choice SetEF uses wrCSARatedEF without modification as the effectiveness (note hourly variability).

Units	Legal Range	Default	Required	Variability
–	Vertical, Horizontal, SetEF	Vertical	No	constant

**wrCSARatedEF=float**

Specifies the heat recovery effectiveness, generally determined using CSA B55.2 rating conditions. This value is modified during simulation based on water flow rates and temperatures. If wrType=SetEF, wrCSARatedEF is used without modification.

Units	Legal Range	Default	Required	Variability
–	$0 \leq x \leq 1$	–	Yes	hourly

**wrTDInDiff=***float*

Temperature drop between the fixture drain and DHWHEATREC drain-side inlet. The drain-side inlet temperature is thus **DHWUSE** wuTemp - wrTDInDiff.

Units	Legal Range	Default	Required	Variability
°F	$\geq 0$	4.6 °F	N	hourly

**wrTDInWarmup=***float*

Drain-side inlet water temperature during warmup. During the warmup portion of a draw (if any), the drain-side inlet temperature will initially be lower than that based on **DHWUSE** wuTemp. wrTDInWarmup allows input of user estimates for this temperature. Note wrTDInWarmup is *not* adjusted by wrTDInDiff.

Units	Legal Range	Default	Required	Variability
°F	$> 0$	65 °F	N	hourly

**endDHWHEATREC**

Optionally indicates the end of the DHWHEATREC definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:****4.28 DHWTANK**

DHWTANK constructs an object representing one or more unfired water storage tanks in a **DHWSYS**. DHWTANK heat losses contribute to the water heating load.

**wtName**

Optional name of tank; give after the word “DHWTANK” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**wtMult=***integer*

Number of identical tanks of this type. Any value  $> 1$  is equivalent to repeated entry of the same DHWTANK.

Units	Legal Range	Default	Required	Variability
	$> 0$	1	No	constant

Tank heat loss is calculated hourly (note that default heat loss is 0) –

$$q_{\text{Loss}} = \text{wtMult} \cdot (\text{wtUA} \cdot (\text{wtTTank} - \text{wtTEx}) + \text{wtXLoss})$$



**wtUA=float**

Tank heat loss coefficient.

Units	Legal Range	Default	Required	Variability
Btuh/°F	$\geq 0$	Derived from wtVol and wtInsulR	No	constant

**wtVol=float**

Specifies tank volume.

Units	Legal Range	Default	Required	Variability
gal	$\geq 0$	0	No	constant

**wtInsulR=float**

Specifies total tank insulation resistance. The input value should represent the total resistance from the water to the surroundings, including both built-in insulation and additional exterior wrap insulation.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup> -°F/Btuh	$\geq .01$	0	No	constant

**wtTEx=float**

Tank surround temperature.

Units	Legal Range	Default	Required	Variability
°F	$\geq 0$	70	No	hourly

**wtTTank=float**

Tank average water temperature.

Units	Legal Range	Default	Required	Variability
°F	$> 32$ °F	Parent DHWSYSTEM wsTUse	No	hourly

**wtXLoss=float**

Additional tank heat loss. To duplicate CEC 2016 procedures, this value should be used to specify the fitting loss of 61.4 Btuh.

Units	Legal Range	Default	Required	Variability
Btuh	(any)	0	No	hourly

**endDHWTank**

Optionally indicates the end of the DHWTANK definition.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	

**Related Probes:**

- @DHWTank

**4.29 DHWPUMP**

DHWPUMP constructs an object representing a domestic hot water circulation pump (or more than one if identical).

**wpName**

Optional name of pump; give after the word “DHWPUMP” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**wpMult=*integer***

Number of identical pumps of this type. Any value > 1 is equivalent to repeated entry of the same DHWPUMP.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wpPwr=*float***

Pump power.

Units	Legal Range	Default	Required	Variability
W	> 0	0	No	hourly

**wpElecMtr=*mtrName***

Name of **METER** object, if any, to which DHWPUMP electrical energy use is recorded (under end use DHW).

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>Parent DHWSYS wsElecMtr</i>	No	constant

**endDHW Pump**

Optionally indicates the end of the DHWPUMP definition.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	

**Related Probes:**

- @DHW Pump

**4.30 DHWLOOP**

DHWLOOP constructs one or more objects representing a domestic hot water circulation loop. The actual pipe runs in the DHWLOOP are specified by any number of DHWLOOPSEGS (see below). Circulation pumps are specified by DHWLOOPPUMPS (also below).

**wlName**

Optional name of loop; give after the word “DHWLOOP” if desired.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**wlMult=*integer***

Number of identical loops of this type. Any value > 1 is equivalent to repeated entry of the same DHWLOOP (and all child objects).

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wlFlow=*float***

Loop flow rate (when operating).

Units	Legal Range	Default	Required	Variability
gpm	≥ 0	6	No	hourly

**wlTIn1=*float***

Inlet temperature of first DHWLOOPSEG.

Units	Legal Range	Default	Required	Variability
°F	> 0	DHWSYS wsTUse	No	hourly

**wlRunF=*float***

Fraction of hour that loop circulation operates.

Units	Legal Range	Default	Required	Variability
–	≥ 0	1	No	hourly

**wlFUA=*float***

DHWLOOPSEG pipe heat loss adjustment factor. DHWLOOPSEG UA is derived (from wgSize, wgLength, wgInsulK, wgInsulThk, and wgExH) and multiplied by wlFUA. Note: does not apply to child DHWLOOP-

**BRANCHs** (see wbFUA).

Units	Legal Range	Default	Required	Variability
–	> 0	1	No	constant

**wlLossMakeupPwr=float**

Specifies electrical power available to make up losses from **DHWLOOPSEGs** (loss from **DHWLOOP-BRANCHs** is not included). Separate loss makeup is typically used in multi-unit HPWH systems to avoid inefficiencies associated with high condenser temperatures. Loss-makeup energy is calculated hourly and is the smaller of loop losses and wlLossMakeupPwr. The resulting electricity use (including the effect of wlLossMakeupEff) is accumulated to the **METER** specified by wElecMtr (end use dhwMFL). No other effect, such as heat gain to surroundings, is modeled.

Units	Legal Range	Default	Required	Variability
W	$\geq 0$	0	No	hourly

**wlLossMakeupEff=float**

Specifies the efficiency of loss makeup heating if any. No effect when wlLossMakeupPwr is 0.

Units	Legal Range	Default	Required	Variability
–	> 0	1	No	hourly

**wElecMtr=mtrName**

Name of **METER** object, if any, to which DHWLOOP electrical energy use is recorded (under end use dhwMFL).

Units	Legal Range	Default	Required	Variability
<i>name of a METER</i>	<i>Parent DHWSYS wsElecMtr</i>		No	constant

**endDHWLoop**

Optionally indicates the end of the DHWLOOP definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:**

- @DHWLoop

## 4.31 DHWLOOPPUMP

DHWLOOPPUMP constructs an object representing a pump serving part a **DHWLOOP**. The model is identical to **DHWPUMP** *except* that that the electricity use calculation reflects wlRunF of the parent **DHWLOOP**.

**wlpName**

Optional name of pump; give after the word “DHWLOOPPUMP” if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**wlpMult=integer**

Number of identical pumps of this type. Any value > 1 is equivalent to repeated entry of the same **DHW-PUMP**.

Units	Legal Range	Default	Required	Variability
	> 0	1	No	constant

**wlpPwr=float**

Pump power.

Units	Legal Range	Default	Required	Variability
W	> 0	0	No	hourly

**wlpLiqHeatF=float**

Fraction of pump power that heats circulating liquid. The remainder is discarded.

Units	Legal Range *	*Default** *	*Required** *	*Variability**
	$0 \leq x \leq$	1	No	hourly

**wlpElecMtr=mtrName**

Name of **METER** object, if any, to which DHWLOOPPUMP electrical energy use is recorded (under end use dhwMFL).

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>Parent DHWLOOP wlpElecMtr</i>	No	constant

**endDHWLOOPPUMP**

Optionally indicates the end of the **DHWPUMP** definition.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	

**Related Probes:**

- @DHWLoopPump

## 4.32 DHWLOOPSEG

DHWLOOPSEG constructs one or more objects representing a segment of the preceeding **DHWLOOP**. A **DHWLOOP** can have any number of DHWLOOPSEGs to represent the segments of the loop with possibly differing sizes, insulation, or surrounding conditions.

### wgName

Optional name of segment; give after the word "DHWLOOPSEG" if desired.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

### wgTy=*choice*

Specifies the type of segment. RETURN segments, if any, must follow SUPPLY segments.

SUPPLY	Indicates a supply segment (flow is sum of circulation and draw flow, child DHWLOOPBRANCHs permitted).
RETURN	Indicates a return segment (flow is only due to circulation, child DHWLOOPBRANCHs not allowed)

Units	Legal Range	Default	Required	Variability
–		–	Yes	constant

### wgLength=*float*

Length of segment.

Units	Legal Range	Default	Required	Variability
ft	$\geq 0$	0	No	constant

### wgSize=*float*

Nominal size of pipe. CSE assumes the pipe outside diameter = size + 0.125 in.

Units	Legal Range	Default	Required	Variability
in	$> 0$	1	Yes	constant

### wgInsulK=*float*

Pipe insulation conductivity

Units	Legal Range	Default	Required	Variability
Btuh-ft/ft <sup>2</sup> -°F	$> 0$	0.02167	No	constant

### wgInsulThk=*float*

Pipe insulation thickness

Units	Legal Range	Default	Required	Variability
in	$\geq 0$	1	No	constant

**wgExH=float**

Combined radiant/convective exterior surface conductance between insulation (or pipe if no insulation) and surround.

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	$> 0$	1.5	No	hourly

**wgExT=float**

Surrounding equivalent temperature.

Units	Legal Range	Default	Required	Variability
°F	$> 0$	70	No	hourly

**wgFNoDraw=float**

Fraction of hour when no draw occurs.

Units	Legal Range	Default	Required	Variability
°F	$> 0$	70	No	hourly

**endDHWLoopSeg**

Optionally indicates the end of the DHWLOOPSEG definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:**

- @DHWLoopSeg

### 4.33 DHWLOOPBRANCH

DHWLOOPBRANCH constructs one or more objects representing a branch pipe from the preceeding **DHWLOOPSEG**. A **DHWLOOPSEG** can have any number of DHWLOOPBRANCHs to represent pipe runs with differing sizes, insulation, or surrounding conditions.

**wbName**

Optional name of segment; give after the word “DHWLOOPBRANCH” if desired.

Units	Legal Range	Default	Required	Variability
Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**wbMult=float**

Specifies the number of identical DHWLOOPBRANCHs. Note may be non-integer.

Units	Legal Range	Default	Required	Variability
–	> 0	1	No	constant

**wbLength=float**

Length of branch.

Units	Legal Range	Default	Required	Variability
ft	$\geq 0$	0	No	constant

**wbSize=float**

Nominal size of pipe. CSE assumes the pipe outside diameter = size + 0.125 in.

Units	Legal Range	Default	Required	Variability
in	> 0	–	Yes	constant

**wbInsulK=float**

Pipe insulation conductivity

Units	Legal Range	Default	Required	Variability
Btuh-ft/ft <sup>2</sup> -°F	> 0	0.02167	No	constant

**wbInsulThk=float**

Pipe insulation thickness

Units	Legal Range	Default	Required	Variability
in	$\geq 0$	1	No	constant

**wbExH=float**

Combined radiant/convective exterior surface conductance between insulation (or pipe if no insulation) and surround.



Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> -°F	> 0	1.5	No	hourly

**wbFUA=float**

Adjustment factor applied to branch UA. UA is derived (from wbSize, wbLength, wbInsulK, wbInsulThk, and wbExH) and then multiplied by wbFUA. Used to represent e.g. imperfect insulation. Note that parent **DHWLOOP** wFUA does not apply to DHWLOOPBRANCH (only **DHWLOOPSEG**)

Units	Legal Range	Default	Required	Variability
	≥ 0	1	No	constant

**wbExT=float**

Surrounding equivalent temperature.

Units	Legal Range	Default	Required	Variability
°F	> 0	70	No	hourly

**wbFlow=float**

Branch flow rate assumed during draw.

Units	Legal Range	Default	Required	Variability
gpm	≥ 0	2	No	hourly

**wbFWaste=float**

Number of times during the hour when the branch volume is discarded.

Units	Legal Range	Default	Required	Variability
	≥ 0	0	No	hourly

**endDHWLOOPBRANCH**

Optionally indicates the end of the DHWLOOPBRANCH definition.

Units	Legal Range	Default	Required	Variability
		N/A	No	

**Related Probes:**

- @DHWLoopBranch

## 4.34 DHWSOLARSYS

Solar water heating system.

- DHWSOLARSYS
  - DHWSOLARCOLLECTOR
  - DHWSOLARTANK

May have any number of solar collectors, but only one tank.

May have no tank for direct system? What if system has multiple primary tanks?

**swElecMtr=*mtrName***

Name of **METER** object, if any, to which DHWSOLARSYS electrical energy use is recorded (under end use ???).

Units	Legal Range	Default	Required	Variability
F	<i>name of a METER</i>	<i>not recorded</i>	No	constant

**swEndUse**

End use of pump energy; defaults to “DHW”.

**swParElec=*float***

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	0	No	hourly

**swFluidVolSpHt=*float***

Default specific heat for Ethylene Glycol.

Units	Legal Range	Default	Required	Variability
Btu/gal-°F		5.31	No	constant

**swTankHXEff=*float***

Tank heat exchanger effectiveness.

Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 0.99$	0	No	hourly

**swTankUA=*float***

Heat transfer coefficient for the tank multiplied by area.

Units	Legal Range	Default	Required	Variability
Btuh/°F			No	constant

**swTankVol=*float***

Units	Legal Range	Default	Required	Variability
gal			No	constant

**swTankInsulR=float**

Total tank insulation resistance, built-in plus exterior wrap.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup> -°F/Btuh			No	constant

**swTankZn**

Pointer to tank zone location, use sw\_tankTEx if NULL

Units	Legal Range	Default	Required	Variability
			No	constant

**swTankTEx=float**

Surrounding temperature.

Units	Legal Range	Default	Required	Variability
°F			No	hourly

**endDHWSOLARSYS**

Optionally indicates the end of the DHWSOLARSYS definition.

Units	Legal Range	Default	Required	Variability
n/a	n/a	n/a	No	n/a

**4.35 DHWSOLARCOLLECTOR**

Solar Collector Array. May be multiple collectors on the same DHWSOLARSYS system. All inlets come from the DHWSOLARTANK.

Uses SRCC Ratings.

**scArea=float**

Collector area.

Units	Legal Range	Default	Required	Variability
ft <sup>2</sup>	> 0	0	Yes	constant

**scMult**

Number of identical collectors, default 1

Units	Legal Range	Default	Required	Variability
	$> 0$	1	No	constant

**scTilt=float**

Array tilt.

Units	Legal Range	Default	Required	Variability
deg		0	Yes	constant

**scAzm=float**

Array azimuth.

Units	Legal Range	Default	Required	Variability
deg		0	Yes	constant

**scFRUL=float**

Fit slope

Units	Legal Range	Default	Required	Variability
Btuh/ft <sup>2</sup> ·°F		-0.727	No	constant

**scFRTA=float**

Fit y-intercept

Units	Legal Range	Default	Required	Variability
none	$> 0$	0.758	No	constant

**scPumpFlow=float**

Units	Legal Range	Default	Required	Variability
gpm	$x \geq 0$	from <i>scArea</i> , <i>scMult</i>	No	constant

**scPumpPwr=float**

Units	Legal Range	Default	Required	Variability
Btu/h	$x \geq 0$	from <i>scPumpflow</i>	No	constant

**scPumpOnDeltaT=float**

Temperature difference between the tank and collector outlet where pump turns on

Units	Legal Range	Default	Required	Variability
°F		10.0	No	constant

**scPumpOffDeltaT=float**

Temperature difference between the tank and collector outlet where pump turns off

Units	Legal Range	Default	Required	Variability
°F		5.0	No	constant

**endDHWSOLARCOLLECTOR**

Optionally indicates the end of the DHWSOLARCOLLECTOR definition.

Units	Legal Range	Default	Required	Variability
<i>n/a</i>	<i>n/a</i>	<i>n/a</i>	No	<i>n/a</i>

**4.36 PARRAY**

PARRAY describes a photovoltaic panel system. The algorithms are based on the [PVWatts calculator](#).

**pvName**

Name of photovoltaic array. Give after the word PARRAY.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**pvElecMtr=choice**

Name of meter by which this PARRAY's AC power out is recorded. Generated power is expressed as a negative value.

Units	Legal Range	Default	Required	Variability
	<i>name of a METER</i>	<i>none</i>	No	constant

**pvEndUse=choice**

Meter end use to which the PARRAY's generated energy should be accumulated.

Clg	Cooling
Htg	Heating (includes heat pump compressor)
HPHTG	Heat pump backup heat
DHW	Domestic (service) hot water
DHWBU	Domestic (service) hot water heating backup (HPWH resistance)
DHWMFL	Domestic (service) hot water heating multi-family loop pumping and loss makeup
FANC	Fans, AC and cooling ventilation
FANH	Fans, heating
FANV	Fans, IAQ venting

FAN	Fans, other purposes
AUX	HVAC auxiliaries such as pumps
PROC	Process
LIT	Lighting
RCP	Receptacles
EXT	Exterior lighting
REFR	Refrigeration
DISH	Dishwashing
DRY	Clothes drying
WASH	Clothes washing
COOK	Cooking
USER1	User-defined category 1
USER2	User-defined category 2
BT	Battery charge power
PV	Photovoltaic power generation

Units	Legal Range	Default	Required	Variability
<i>Codes listed above</i>		PV	No	constant

**pvDCSysSize=float**

The rated photovoltaic system DC capacity/size as indicated by the nameplate.

Units	Legal Range	Default	Required	Variability
kW	$x \geq 0$	<i>none</i>	Yes	constant

**pvModuleType=choice**

Type of module to model. The module type determines the refraction index and temperature coefficient used in the simulation. Alternatively, the “Custom” module type may be used in conjunction with user-defined input for *pvCoverRefrInd* and *pvTempCoeff*.

Module Type	pvCoverRefrInd	pvTempCoeff
Standard	1.3	-0.00206
Premium	1.3	-0.00194
ThinFilm	1.3	-0.00178
Custom	User-defined	User-defined

Units	Legal Range	Default	Required	Variability
	Standard	Standard	No	constant
	Premium			
	ThinFilm			
	Custom			

**pvCoverRefrInd=float**

The refraction index for the coating applied to the module cover. A value of 1.0 represents refraction through air. Coatings have higher refraction indexes that capture more solar at lower angles of incidence.

Units	Legal Range	Default	Required	Variability
	$x \geq 1.0$	1.3	No	constant

**pvTempCoeff=float**

The temperature coefficient how the efficiency of the module varies with the cell temperature. Values are typically negative.

Units	Legal Range	Default	Required	Variability
1/°F	<i>no restrictions</i>	-0.00206	No	constant

**pvArrayType=choice**

The type of array describes mounting and tracking options. Roof mounted arrays have a higher installed nominal operating cell temperature (INOCT) of 120 °F compared to the default of 113 °F. Array self-shading is not currently calculated for adjacent rows of modules within an array.

Units	Legal Range	Default	Required	Variability
	FixedOpenRack, FixedRoofMount, OneAxisTracking, TwoAxisTracking	FixedOpenRack	No	constant

**pvTilt=float**

The tilt of the photovoltaic array from horizontal. Values outside the range 0 to 360 are first normalized to that range. For one-axis tracking, defines the tilt of the rotation axis. Not used for two-axis tracking arrays. Should be omitted if pvVertices is given.

Units	Legal Range	Default	**Required	Variability
degrees	unrestricted	from pvVertices (if given) else 0	No	hourly

The following figures illustrate the use of both pvTilt and pvAzm for various configurations:

**pvAzm=float**

Photovoltaic array azimuth (0 = north, 90 = east, etc.). If a value outside the range  $0^\circ \leq x < 360^\circ$  is given, it is normalized to that range. For one-axis tracking, defines the azimuth of the rotation axis. Not used for two-axis tracking arrays. Should be omitted if pvVertices is given.

**Units	Legal Range	Default	Required	Variability
degrees	unrestricted	from pvVertices (if given) else 0	No	hourly

**pvVertices=list of up to 36 floats**

Vertices of an optional polygon representing the position and shape of the photovoltaic array. The polygon is used to calculate the shaded fraction using an advanced shading model. Only PARRAYs and SHADEXs are

Figure 5: Fixed, south facing, tilted at  $40^\circ$



Figure 6: One-axis tracker, south facing, tilted at  $20^\circ$

Figure 7: One-axis tracker, horizontal aligned North/South (more common)

Figure 8: One-axis tracker, horizontal aligned East/West (less common)

considered in the advanced shading model – PARRAYs can be shaded by **SHADEXs** or other PARRAYs. If `pvVertices` is omitted, the PARRAY is assumed to be unshaded at all times. Advanced shading must be enabled via **TOP exShadeModel**. Note that the polygon is used only for evaluating shading; array capacity is specified by `pvDCSysSize` (above).

The values that follow `pvVertices` are a series of X, Y, and Z values for the vertices of the polygon using a coordinate system defined from a viewpoint facing north. X and Y values convey east-west and north-south location respectively relative to an arbitrary origin (positive X value are to the east; positive Y values are to the north). Z values convey height relative to the building 0 level and positive values are upward.

The vertices are specified in counter-clockwise order when facing the receiving surface of the PARRAY. The number of values provided must be a multiple of 3. The defined polygon must be planar and have no crossing edges. When `pvMounting=Building`, the effective position of the polygon is modified in response to building rotation specified by **TOP bldgAzm**.

For example, to specify a rectangular photovoltaic array that is 10 x 20 ft, tilted 45 degrees, and facing south

`pvVertices = 0, 0, 15, 20, 0, 15, 20, 7.07, 22.07, 0, 7.07, 22.07`

Units	Legal Range	Default	Required	Variability
ft	unrestricted	no polygon	9, 12, 15, 18, 21, 24, 27, 30, 33, or 36 values	constant

#### **pvSIF=float**

Shading Impact Factor (SIF) of the array used to represent the disproportionate impact on array output of partially shaded modules at the sub-array level. This impact is applied to the effective beam irradiance on the array:

$$I_{poa,beam,eff} = \max(I_{poa,beam} \cdot (1 - SIF \cdot f_{sh}), 0)$$

where  $f_{sh}$  is the fraction of the array that is shaded.

Default value is 1.2, which is representative of PV systems with sub-array microinverters or DC power optimizers. For systems without sub-array power electronics, values are closer to 2.0.

Units	Legal Range	Default	Required	Variability
–	$x \geq 1.0$	1.2	No	constant

#### **pvMounting=choice**

Specified mounting location of this PARRAY. `pvMounting=Site` indicates the array position is not altered by building rotation via **TOP bldgAzm**, while PARRAYs with `pvMounting=Building` are assumed to rotate with the building.

Units	Legal Range	Default	Required	Variability
	Building or Site	Building	No	constant

#### **pvGrndRefl=float**

Ground reflectance used for calculating reflected solar incidence on the array.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1.0$	0.2	No	hourly

**pvDCtoACRatio=float**

DC-to-AC ratio used to intentionally undersize the AC inverter. This is used to increase energy production in the beginning and end of the day despite the possibility of clipping peak sun hours.

Units	Legal Range	Default	Required	Variability
	$x > 0.0$	1.2	No	constant

**pvInverterEff=float**

AC inverter efficiency at rated DC power.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1.0$	0.96	No	constant

**pvSysLosses=float**

Fraction of total DC energy lost. The total loss from a system is aggregated from several possible causes as illustrated below:

Loss Type	Default Assumption
Soiling	0.02
<i>Shading</i>	<i>0 (handled explicitly)</i>
Snow	0
<i>Mismatch</i>	<i>0 (shading mismatch handled explicitly [see pvSIF])</i>
Wiring	0.02
Connections	0.005
Light-induced degradation	0.015
Nameplate rating	0.01
<i>Age</i>	<i>0.05 (estimated 0.5% degradation over 20 years)</i>
Availability	0.03
<b>Total</b>	<b>0.14</b>

*Italic* lines indicate differences from PVWatts assumptions.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1.0$	0.14	No	hourly

**endPVARARRAY**

Optionally indicates the end of the PVARARRAY definition. Alternatively, the end of the definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @PVArray

**4.37 SHADEX**

SHADEX describes an object that shades other building surfaces using an advanced shading model. Advanced shading calculations are provided only for PVARARRAYs. Advanced shading must be enabled via Top exShadeModel.

**sxName**

Name of photovoltaic array. Give after the word SHADEX.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**sxMounting=choice**

Specifies the mounting location of the shade. sxMounting=Site indicates the SHADEX position is fixed and is not modified if the building is rotated. The position of SHADEXs with sxMounting=Building are modified to include the effect of building rotation specified via Top bldgAz

Units	Legal Range	Default	Required	Variability
	Building or Site	Site	No	constant

**sxVertices=list of up to 36 floats**

Vertices of a polygon representing the shape of the shading object.

The values that follow sxVertices are a series of X, Y, and Z values for the vertices of the polygon. The coordinate system is defined from a viewpoint facing north. X and Y values convey east-west and north-south location respectively relative to an arbitrary origin (positive X value are to the east; positive Y values are to the north). Z values convey height relative to the building 0 level and positive values are upward.

The vertices are specified in counter-clockwise order when facing the shading object from the south. The number of values provided must be a multiple of 3. The defined polygon must be planar and have no crossing edges. When sxType=Building, the effective position of the polygon reflects building rotation specified by TOP bldgAzm.

For example, to specify a rectangular shade “tree” that is 10 x 40 ft, facing south, and 100 ft to the south of the nominal building origin –

```
sxVertices = 5, -100, 0, 15, -100, 0, 15, -100, 40, 5, -100, 40
```

Units	Legal Range	Default	Required	Variability
ft	unrestricted	none	9, 12, 15, 18, 21, 24, 27, 30, 33 or 36 values	constant

**endSHADEX**

Optionally indicates the end of the SHADEX definition. Alternatively, the end of the definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

**Related Probes:**

- @SHADEX

**4.38 BATTERY**

BATTERY describes input data for a model of an energy-storage system which is not tied to any specific energy storage technology. The battery model integrates the energy added and removed (accounting for efficiency losses). Note: although we use the term battery, the underlying model is flexible enough to model any energy storage system.

The modeler can set limits and constraints on capacities and flows and the associated efficiencies for this model.

**btName**

Name of the battery system. Given after the word BATTERY.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**btMeter=choice**

Name of a meter by which the BATTERY's power input/output (i.e., charge/discharge) is recorded. Charges to the BATTERY system would be seen as a positive powerflow while discharges from the BATTERY system would be seen as a negative value.

Units	Legal Range	Default	Required	Variability
	meter name	<i>none</i>	No	constant

**btEndUse=choice**

Meter end use to which the BATTERY's charged/discharged energy should be accumulated. Note that the battery end use is seen from the standpoint of a "load" on the electric grid. That is, when the battery is being charged, the end use will show up as positive. When the battery is being discharged (i.e., when it is offsetting other loads), it is seen as negative.

Clg	Cooling
Htg	Heating (includes heat pump compressor)
HPHTG	Heat pump backup heat
DHW	Domestic (service) hot water
DHWBU	Domestic (service) hot water heating backup (HPWH resistance)
DHWMFL	Domestic (service) hot water heating multi-family loop pumping and loss makeup
FANC	Fans, AC and cooling ventilation
FANH	Fans, heating
FANV	Fans, IAQ venting
FAN	Fans, other purposes
AUX	HVAC auxiliaries such as pumps
PROC	Process

LIT	Lighting
RCP	Receptacles
EXT	Exterior lighting
REFR	Refrigeration
DISH	Dishwashing
DRY	Clothes drying
WASH	Clothes washing
COOK	Cooking
USER1	User-defined category 1
USER2	User-defined category 2
BT	Battery charge power
PV	Photovoltaic power generation

Units	Legal Range	Default	Required	Variability
	<i>Codes listed above</i>	BT	No	constant

**btChgEff=float**

The charging efficiency of storing electricity into the BATTERY system. A value of 1.0 means that no energy is lost and 100% of charge energy enters and is stored in the battery.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1$	0.975	No	hourly

**btDschgEff=float**

The discharge efficiency for when the BATTERY system is discharging power. A value of 1.0 means that no energy is lost and 100% of discharge energy leaves the system.

Units	Legal Range	Default	Required	Variability
	$0 < x \leq 1$	0.975	No	hourly

**btMaxCap=float**

This is the maximum amount of energy that can be stored in the BATTERY system in kilowatt-hours. Once the BATTERY has reached its maximum capacity, no additional energy will be stored.

Units	Legal Range	Default	Required	Variability
KW hr	$x \geq 0$	16	No	constant

**btInitSOE=float**

The initial state of energy of the BATTERY system as a fraction of the total capacity. If **btInitSOE** is specified, the battery state-of-energy at the beginning of the actual simulation will be set to the amount specified, regardless of whether there was a warm-up period or not. If **btInitSOE** is NOT specified, it will default to 1.0 (i.e., 100%) at the beginning of the warmup period (if any).



Units	Legal Range	Default	Required	Variability
	$0 \leq x \leq 0$	1.0	No	constant

**btInitCycles**=*int*

The number of cycles on the battery at the beginning of the run.

Units	Legal Range	Default	Required	Variability
number of cycles	$x \geq 0$	0	No	runly

**btMaxChgPwr**=*float*

The maximum rate at which the BATTERY can be charged in kilowatts (i.e., energy flowing *into* the BATTERY).

Units	Legal Range	Default	Required	Variability
kW	$x \geq 0$	4	No	hourly

**btMaxDschgPwr**=*float*

The maximum rate at which the BATTERY can be discharged in kilowatts (i.e., energy flowing *out of* the BATTERY).

Units	Legal Range	Default	Required	Variability
kW	$x \geq 0$	4	No	hourly

**btControlAlg**=*choice*

Selects charge/discharge control algorithm. btChgReq (next) specifies the desired battery charge or discharge rate. btControlAlg allows selection of alternative algorithms for deriving btChgReq.

DEFAULT	btChgReq is used as input or defaulted (see below)
TDVPEAKSAV	btChgReq input (if any) is ignored. Instead, a California-specific algorithm is used
E	that saves battery charge until peak TDV (Time Dependant Valuation) hours of the day, shifting energy generated on site (e.g. PV) to supply feed the grid during critical periods. The algorithm requires availability of hourly TDV data, see Top.tdvFName.

Note btControlAlg has hourly variability, allowing dynamic algorithm selection. In California compliance applications, TDVPEAKSAVE is typically used only on days with high TDV peaks.

Units	Legal Range	Default	Required	Variability
	DEFAULT or TDVPEAKSAVE	DEFAULT	No	hourly

**btChgReq**=*float*

The power request to charge (or discharge if negative) the battery. If omitted, the default strategy is used (attempt to satisfy all loads and absorb all available excess power). btChgReq and the default strategy

requested power are literally *requests*: that is, more power will not be delivered than is available; more power will not be absorbed than capacity exists to store; and the battery's power limits will be respected.

btChgReq can be set by an expression to allow complex energy management/dispatch strategies.

Units	Legal Range	Default	Required	Variability
kW		btMeter net load	No	hourly

**btUseUsrChg=choice**

Former yes/no choice that currently has no effect. Deprecated, will be removed in a future version.

**endBATTERY**

Optionally indicates the end of the BATTERY definition. Alternatively, the end of the definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @battery

## 4.39 REPORTFILE

REPORTFILE allows optional specification of different or additional files to receive CSE reports.

By default, CSE generates several “reports” on each run showing the simulated HVAC energy use, the input statements specifying the run, any error or warning messages, etc. Different or additional reports can be specified using the **REPORT** object, described in Section 5.25, next.

All CSE reports are written to text files as plain ASCII text. The files may be printed (on most printers other than postscript printers) by copying them to your printer with the COPY command. Since many built-in reports are over 80 characters wide; you may want to set your printer for “compressed” characters or a small font first. You may wish to examine the report file with a text editor or LIST program before printing it. (?? Improve printing discussion)

By default, the reports are output to a file with the same name as the input file and extension .REP, in the same directory as the input file. By default, this file is formatted into pages, and overwrites any existing file of the same name without warning. CSE automatically generates a REPORTFILE object called “Primary” for this report file, as though the following input had been given:

```
REPORTFILE "Primary"
  rfFileName = <inputFile>.REP;
  // other members defaulted: rfFileStat=OVERWRITE; rfPageFmt=YES.
```

Using REPORTFILE, you can specify additional report files. **REPORTs** specified within a REPORTFILE object definition are output by default to that file; **REPORTs** specified elsewhere may be directed to a specific report file with the **REPORT** member *rpReportFile*. Any number of REPORTFILES and **REPORTs** may be used in a run or session. Any number of **REPORTs** can be directed to each REPORTFILE.

Using ALTER (Section 4.5.1.2) with REPORTFILE, you can change the characteristics of the Primary report output file. For example:

```
ALTER REPORTFILE Primary
  rfPageFmt = NO;      // do not format into pages
```

```
rfFileStat = NEW;    // error if file exists
```

**rfName**

Name of REPORTFILE object, given immediately after the word REPORTFILE. Note that this name, not the fileName of the report file, is used to refer to the REPORTFILE in **REPORTs**.

Units	Legal Range	Default	Required	Variability
	63 characters		No	constant

**rfFileName=path**

path name of file to be written. If no path is specified, the file is written in the current directory. The default extension is .REP.

Units	Legal Range	Default	Required	Variability
	file name, path and extension optional		Yes	constant

**rfFileStat=choice**

Choice indicating what CSE should do if the file specified by *rfFileName* already exists:

OVERWRITE	Overwrite pre-existing file.
NEW	Issue error message if file exists at beginning of session. If there are several runs in session using same file, output from runs after the first will append.
APPEND	Append new output to present contents of existing file.

If the specified file does not exist, it is created and *rfFileStat* has no effect.

Units	Legal Range	Default	Required	Variability
	OVERWRITE, NEW, APPEND	OVERWRITE	No	constant

**rfPageFmt=Choice**

Choice controlling page formatting. Page formatting consists of dividing the output into pages (with form feed characters), starting a new page before each report too long to fit on the current page, and putting headers and footers on each page. Page formatting makes attractive printed output but is a distraction when examining the output on the screen and may inappropriate if you are going to further process the output with another program.

Yes	Do page formatting in this report file.
No	Suppress page formatting. Output is continuous, uninterrupted by page headers and footers or large blank spaces.

Units	Legal Range	Default	Required	Variability
	Yes, No	Yes	No	constant

Unless page formatting is suppressed, the page formats for all report files are controlled by the **TOP** members

*repHdrL*, *repHdrR*, *repLPP*, *repTopM*, *repBotM*, and *repCPL*, described in Section 5.1.

Each page header shows the *repHdrL* and *repHdrR* text, if given.

Each page footer shows the input file name, run serial number within session (see *runSerial* in Section 5.1), user-input *runTitle* (see Section 5.1), date and time of run, and page number in file.

Vertical page layout is controlled by *repLPP*, *repTopM*, and *repBotM* (Section 5.1). The width of each header and footer is controlled by *repCPL*. Since many built-in reports are now over 80 columns wide, you may want to use *repCPL*=120 or *repCPL*=132 to make the headers and footers match the text better.

In addition to report file *page* headers and footers, individual **REPORTs** have **REPORT** headers and footers related to the report content. These are described under **REPORT**, Section 5.25.

### endReportFile

Optionally indicates the end of the report file definition. Alternatively, the end of the report file definition can be indicated by **END** or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

### Related Probes:

- **@reportFile**

## 4.40 REPORT

**REPORT** generates a report object to specify output of specific textual information about the results of the run, the input data, the error messages, etc. The various report types available are enumerated in the description of *rpType* in this section, and may be described at greater length in Section 6.

**REPORTs** are output by CSE to files, via the **REPORTFILE** object (previous section). After CSE has completed, you may print the report file(s), examine them with a text editor or by **TYPE**ing, process them with another program, etc., as desired.

**REPORTs** that you do not direct to a different file are written to the automatically-supplied “Primary” report file, whose file name is (by default) the input file name with the extension changed to **.REP**.

Each report consists of a report header, one or more data rows, and a report footer. The header gives the report type (as specified with *rpType*, described below), the frequency (as specified with *rpFreq*), the month or date where appropriate, and includes headings for the report’s columns where appropriate.

Usually a report has one data row for each interval being reported. For example, a daily report has a row for each day, with the day of the month shown in the first column.

The report footer usually contains a line showing totals for the rows in the report.

The header-data-footer sequence is repeated as necessary. For example, a daily report extending over more than one month has a header-data-footer sequence for each month. The header shows the month name; the data rows show the day of the month; the footer contains totals for the month.

In addition to the headers and footers of individual reports, the report file has (by default) *page headers* and *footers*, described in the preceding section.

**Default Reports:** CSE generates the following reports by default for each run, in the order shown. They are output by default to the “Primary” report file. They may be **ALTERed** or **DELETED** as desired, using the object names shown.

rpName	rpType	Additional members
Err	ERR	
eb	ZEB	rpFreq=MONTH; rpZone=SUM;
Log	LOG	
Inp	INP	

Any reports specified by the user and not assigned to another file appear in the Primary report file between the default reports “eb” and “Log”, in the order in which the REPORT objects are given in the input file.

Because of the many types of reports supported, the members required for each REPORT depend on the report type and frequency in a complex manner. When in doubt, testing is helpful: try your proposed REPORT specification; if it is incomplete or overspecified, CSE will issue specific error messages telling you what additional members are required or what inappropriate members have been given and why.

### rpName

Name of report. Give after the word REPORT.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

### rpReportfile=rfname

Name of report file to which current report will be written. If omitted, if REPORT is within a **REPORTFILE** object, report will be written to that report file, or else to **REPORTFILE** “Primary”, which (as described in previous section) is automatically supplied and by default uses the file name of the input file with the extension .REP.

Units	Legal Range	Default	Required	Variability
	name of a <i>REPORTFILE</i>	current <i>REPORTFILE</i> , if any, else “Primary”	No	constant

### rpType=choice

Choice indicating report type. Report types may be described at greater length, with examples, in Section 6.

ERR	Error and warning messages. If there are any such messages, they are also displayed on the screen <i>AND</i> written to a file with the same name as the input file and extension .ERR. Furthermore, * *many error messages are repeated in the INP report.
LOG	Run “log”. As of July 1992, contains only CSE version number; should be enhanced or deleted.??
INP	Input echo: shows the portion of the input file used to specify this run. Does not repeat descriptions of objects left from prior runs in the same session when CLEAR is not used. Error and warning messages relating to specific lines of the input are repeated after or near the line to which they relate, prefixed with “?”. Lines not used due to a preprocessor #if command (Section 4.4.4) with a false expression are prefixed with a “0” in the leftmost column; all preprocessor command lines are prefixed with a “#” in that column.
SUM	Run summary. As of July 1992, <i>NOT IMPLEMENTED</i> : generates no output and no error message. Should be defined and implemented, or else deleted??.

ZDD	Zone data dump. Detailed dump of internal simulation values, useful for verifying that your input is as desired. Should be made less cryptic (July 1992)?? Requires <i>rpZone</i> .
ZST	Zone statistics. Requires <i>rpZone</i> .
ZEB	Zone energy balance. Requires <i>rpZone</i> .
MTR	Meter report. Requires <i>rpMeter</i> .
DHWMTR	DHW meter report. Requires <i>rpDHWMeter</i> .
UDT	User-defined table. Data items are specified with REPORTCOL commands (next section). Allows creating almost any desired report by using CSE expressions to specify numeric or string values to tabulate; "Probes" may be used in the expressions to access CSE internal data.

Units	Legal Range	Default	Required	Variability
	<i>see above</i>		Yes	constant

The next three members specify how frequently values are reported and the start and end dates for the REPORT. They are not allowed with *rpTypes* ERR, LOG, INP, SUM, and ZDD, which involve no time-varying data.

#### **rpFreq=choice**

Report Frequency: specifies interval for generating rows of report data:

YEAR	at run completion
MONTH	at end of each month (and at run completion if mid-month)
DAY	at end of each day
HOURL	at end of each hour
HOURLANDSUB	at end of each subhour AND at end of hour
SUBHOURL	at end of each subhour

*rpFreq* values of HOURLANDSUB and SUBHOURL are not supported in some combinations with data selection of ALL or SUM.

We recommend using HOURLy and more frequent reports sparingly, to report on only a few typical or extreme days, or to explore a problem once it is known what day(s) it occurs on. Specifying such reports for a full-year run will generate a huge amount of output and cause extremely slow CSE execution.

Units	Legal Range	Default	Required	Variability
	<i>choices above</i>		per rpType	constant

#### **rpDayBeg=date**

Initial day of period to be reported. Reports for which *rpFreq* = YEAR do not allow specification of *rpDayBeg* and *rpDayEnd*; for MONTH reports, these members default to include all months in the run; for DAY and shorter-interval reports, *rpDayBeg* is required and *rpDayEnd* defaults to *rpDayBeg*.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	first day of simulation if <i>rpFreq</i> = MONTH	Required for <i>rpTypes</i> ZEB, ZST, MTR, AH, and UDT if <i>rpFreq</i> is DAY, HOUR, HOURANDSUB, or SUBHOUR	constant

**rpDayEnd=***date*

Final day of period to be reported, except for YEAR reports.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	last day of simulation if <i>rpFreq</i> = MONTH, else <i>rpDayBeg</i>	No	constant

**rpZone=***znName*

Name of **ZONE** for which a ZEB, ZST, or ZDD report is being requested. For *rpType* ZEB or ZST, you may use *rpZone*=SUM to obtain a report showing only the sum of the data for all zones, or *rpZone*=ALL to obtain a report showing, for each time interval, a row of data for each zone plus a sum-of-zones row.

Units	Legal Range	Default	Required	Variability
	name of a <i>ZONE</i> , ALL, SUM		Required for <i>rpTypes</i> ZDD, ZEB, and ZST.	constant

**rpMeter=***mtrName*

Specifies meter(s) to be reported, for *rpType*=MTR.

Units	Legal Range	Default	Required	Variability
	name of a <i>METER</i> , ALL, SUM		Required for <i>rpType</i> =MTR	constant

**rpDHWMeter=***dhwMtrName*

Specifies DHW meter(s) to be reported, for *rpType*=DHW MTR.

Units	Legal Range	Default	Required	Variability
	name of a <i>DHWMETER</i> , ALL, SUM		Required for <i>rpType</i> =DHW MTR	constant

**rpBtuSf=***float*

Scale factor to be used when reporting energy values. Internally, all energy values are represented in Btu. This member allows scaling to more convenient units for output. *rpBtuSf* is not shown in the output, so if you change it, be sure the readers of the report know the energy units being used. *rpBtuSf* is not applied in UDT reports, but column values can be scaled as needed with expressions.

Units	Legal Range	Default	Required	Variability
	<i>any multiple of ten</i>	1,000,000: energy reported in MBtu.	No	constant

**rpCond=expression**

Conditional reporting flag. If given, report rows are printed only when value of expression is non-0. Permits selective reporting according to any condition that can be expressed as a CSE expression. Such conditional reporting can be used to shorten output and make it easy to find data of interest when you are only interested in the information under exceptional conditions, such as excessive zone temperature. Allowed with *rpTypes* ZEB, ZST, MTR, AH, and UDT.

Units	Legal Range	Default	Required	Variability
	<i>any numeric expression</i>	1 (reporting enabled)	No	subhour /end of interval

**rpCPL=int**

Characters per line for a User-Defined report. If widths specified in **REPORTCOLs** add up to more than this, a message occurs; if they total substantially less, additional whitespace is inserted between columns to make the report more readable. If *rpCpl* = -1, the report width determined based on required space with a single between each column. Not allowed if *rpType* is not UDT.

Units	Legal Range	Default	Required	Variability
	x = -1 or x > 78	top level	<i>repCPL</i> No	constant

**rpTitle=string**

Title for use in report header of User-Defined report. Disallowed if *rpType* is not UDT.

Units	Legal Range	Default	Required	Variability
		"User-defined Report"	No	constant

**rpHeader=choice**

Use NO to suppress the report header which gives the report type, zone, meter, or air handler being reported, time interval, column headings, etc. One reason to do this might be if you are putting only a single report in a report file and intend to later embed the report in a document or process it with some other program (but for the latter, see also **EXPORT**, below).

Use with caution, as the header contains much of the identification of the data. For example, in an hourly report, only the hour of the day is shown in each data row; the day and month are shown in the header, which is repeated for each 24 data rows.

See **REPORTFILE** member *rfPageFmt*, above, to control report *FILE* page headers and footers, as opposed to *REPORT* headers and footers.

Units	Legal Range	Default	Required	Variability
	YES, NO	YES	No	constant

**rpFooter=choice**



Use NO to suppress the report footers. The report footer is usually a row which sums hourly data for the day, daily data for the month, or monthly data for the year. For a report with *rpZone*, *rpMeter*, or *rpAh* = ALL, the footer row shows sums for all zones, meters, or air handlers. Sometimes the footer is merely a blank line.

Units	Legal Range	Default	Required	Variability
	YES, NO	YES	No	constant

### endReport

Optionally indicates the end of the report definition. Alternatively, the end of the report definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

### Related Probes:

- @report

## 4.41 REPORTCOL

Each REPORTCOL defines a single column of a User Defined Table (UDT) report. REPORTCOLs are not used with report types other than UDT.

Use as many REPORTCOLs as there are values to be shown in each row of the user-defined report. The values will appear in columns, ordered from left to right in the order defined. Be sure to include any necessary values to identify the row, such as the day of month, hour of day, etc. CSE supplies *NO* columns automatically.

### colName

Name of REPORTCOL.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

### colReport=*rpName*

Name of report to which current report column belongs. If REPORTCOL is given within a **REPORT** object, then *colReport* defaults to that report.

Units	Legal Range	Default	Required	Variability
	name of a <i>REPORT</i>	current report, if any	Unless in a <i>REPORT</i>	constant

### colVal=*expression*

Value to show in this column of report.

Units	Legal Range	Default	Required	Variability
	any numeric or string expression		Yes	subhour /end interval

**colHead=string**

Text used for column head.

Units	Legal Range	Default	Required	Variability
		<i>colName</i> or blank	No	constant

**colGap=int**

Space between (to left of) column, in character positions. Allows you to space columns unequally, to emphasize relations among columns or to improve readability. If the total of the *colGaps* and *colWids* in the report's REPORTCOLs is substantially less than the **REPORT's** *rpCPL* (characters per line, see **REPORT**), CSE will insert additional spaces between columns. To suppress these spaces, use a smaller *rpCPL* or use *rpCPL* = -1.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	1	No	constant

**colWid=int**

Column width.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	10	No	constant

**colDec=int**

Number of digits after decimal point.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	<i>flexible format</i>	No	constant

**colJust=choice**

Specifies positioning of data within column:

Left	Left justified
Right	Right justified

**endReportCol**

Optionally indicates the end of the report column definition. Alternatively, the end of the report column definition can be indicated by END or by beginning another REPORTCOL or other object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- @reportCol

## 4.42 EXPORTFILE

EXPORTFILE allows optional specification of different or additional files to receive CSE **EXPORTs**.

**EXPORTs** contain the same information as reports, but formatted for reading by other programs rather than by people. By default, CSE generates no exports. Exports are specified via the **EXPORT** object, described in Section 5.28 (next). As for **REPORTs**, CSE automatically supplies a primary export file; it has the same name and path as the input file, and extension .csv.

Input for EXPORTFILES and **EXPORTs** is similar to that for **REPORTFILES** and **REPORTs**, except that there is no page formatting. Refer to their preceding descriptions (Sections 5.24 and 5.25) for more additional discussion.

### xfName

Name of EXPORTFILE object.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>		No	constant

### xfFileName=*string*

path name of file to be written. If no path is specified, the file is written in the current directory. If no extension is specified, .csv is used.

Units	Legal Range	Default	Required	Variability
	<i>file name, path and extension optional</i>		Yes	constant

### xfFileStat=*choice*

What CSE should do if file *xfFileName* already exists:

OVERWRITE	Overwrite pre-existing file.
NEW	Issue error message if file exists.
APPEND	Append new output to present contents of existing file.

If the specified file does not exist, it is created and *xfFileStat* has no effect.

Units	Legal Range	Default	Required	Variability
	OVERWRITE, NEW, APPEND	OVERWRITE	No	constant

### endExportFile

Optionally indicates the end of the export file definition. Alternatively, the end of the Export file definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		<i>N/A</i>	No	constant

**Related Probes:**

- @exportFile

**4.43 EXPORT**

Exports contain the same information as CSE reports, but in a “comma-quote” format intended for reading into a spreadsheet or other program for further processing, plotting, special print formatting, etc.

No exports are generated by default; each desired export must be specified with an EXPORT object.

Each row of an export contains several values, separated by commas, with quotes around string values. The row is terminated with a carriage return/line feed character pair. The first fields of the row identify the data. Multiple fields are used as necessary to identify the data. For example, the rows of an hourly ZEB export begin with the month, day of month, and hour of day. In contrast, reports, being subject to a width limitation, use only a single column of each row to identify the data; additional identification is put in the header. For example, an hourly ZEB Report shows the hour in a column and the day and month in the header; the header is repeated at the start of each day. The header of an export is never repeated.

Depending on your application, if you specify multiple exports, you may need to place each in a separate file. Generate these files with **EXPORTFILE**, preceding section. You may also need to suppress the export header and/or footer, with *exHeader* and/or *exFooter*, described in this section.

Input for EXPORTs is similar to input for **REPORTs**; refer to the **REPORT** description in Section 5.25 for further discussion of the members shown here.

**exName**

Name of export. Give after the word EXPORT.

Units	Legal Range	Default	Required	Variability
	<i>63 characters</i>	<i>none</i>	No	constant

**exExportfile=fname**

Name of export file to which current export will be written. If omitted, if EXPORT is within an **EXPORT-FILE** object, report will be written to that export file, or else to the automatically-supplied **EXPORTFILE** “Primary”, which by default uses the name of the input file with the extension .csv.

Units	Legal Range	Default	Required	Variability
	name of an <i>EXPORTFILE</i>	current <i>EXPORTFILE</i> , if any, else “Primary”	No	constant

**exType=choice**

Choice indicating export type. See descriptions in Section 5.22, **REPORT**. While not actually disallowed, use of *exType* = ERR, LOG, INP, or ZDD is unexpected.

Units	Legal Range	Default	Required	Variability
	ZEB, ZST, MTR, DHWMTR, AH, UDT, or SUM		Yes	constant

**exFreq=choice**

Export Frequency: specifies interval for generating rows of export data:

Units	Legal Range	Default	Required	Variability
	YEAR, MONTH, DAY, HOUR, HOURANDSUB, SUBHOUR		Yes	constant

**exDayBeg=***date*

Initial day of export. Exports for which *exFreq* = YEAR do not allow specification of *exDayBeg* and *exDayEnd*; for MONTH exports, these members are optional and default to include the entire run; for DAY and shorter-interval exports, *exDayBeg* is required and *exDayEnd* defaults to *exDayBeg*.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	first day of simulation if <i>exFreq</i> = MONTH	Required for <i>exTypes</i> ZEB, ZST, MTR, AH, and UDT if <i>exFreq</i> is DAY, HOUR, HOURANDSUB, or SUBHOUR	constant

**exDayEnd=***date*

Final day of export period, except for YEAR exports.

Units	Legal Range	Default	Required	Variability
	<i>date</i>	last day of simulation if <i>exFreq</i> = MONTH, else <i>exDayBeg</i>	No	constant

**exZone=***znName*

Name of **ZONE** for which a ZEB, ZST, or ZDD export is being requested; ALL and SUM are also allowed except with *exType* = ZST.

Units	Legal Range	Default	Required	Variability
	name of a <i>ZONE</i> , ALL, SUM		Required for <i>exTypes</i> ZDD, ZEB, and ZST.	constant

**exMeter=***mtrName*

Specifies meter(s) whose data is to be exported, for *exType*=MTR.

Units	Legal Range	Default	Required	Variability
	name of a *M ETER*, ALL, SUM	Required for	<i>exType</i> =MTR	constant

**exDHWMeter=***dhwMtrName*

Specifies DHW meter(s) whose data is to be exported, for *exType*=DHW MTR.

Units	Legal Range	Default	Required **V	ariability**
	name of a <i>DHWMETER</i> , ALL, SUM		Required for <i>exType</i> =DHW MTR	constant

**exAh=ahName**

Specifies air handler(s) to be exported, for *exType*=AH.

Units	Legal Range	Default	Required	Variability
	name of an <i>AIRHANDLER</i> , ALL, SUM		Required for <i>exType</i> =AH	constant

**exBtuSf=float**

Scale factor used for exported energy values.

Units	Legal Range	Default	Required	Variability
	<i>any multiple of ten</i>	1,000,000: energy exported in MBtu.	No	constant

**exCond=expression**

Conditional exporting flag. If given, export rows are generated only when value of expression is non-0. Allowed with *exTypes* ZEB, ZST, MTR, AH, and UDT.

Units	Legal Range	Default	Required	Variability
	<i>any numeric expression</i>	1 (exporting enabled)	No	subhour /end of interval

**exTitle=string**

Title for use in export header of User-Defined export. Disallowed if *exType* is not UDT.

Units	Legal Range	Default	Required	Variability
		"User-defined Export"	No	constant

**exHeader=choice**

Use NO to suppress the export header which gives the export type, zone, meter, or air handler being exported, time interval, column headings, etc. You might do this if the export is to be subsequently imported to a program that is confused by the header information. Alternatively, one may use COLUMNSONLY to print only the column headings. This can be useful when plotting CSV data in a spreadsheet tool or [DView](#).

The choices YESIFNEW and COLUMNSONLYIFNEW cause header generation when the associated **EXPORTFILE** is being created but suppress headers when appending to an existing file. This is useful for accumulating results from a set of runs where typically column headings are desired only once.

If not suppressed, the export header shows, in four lines:

*runTitle* and *runSerial* (see Section 5.1); the run date and time the export type ("Energy Balance", "Statistics", etc., or *exTitle* if given) and frequency ("year", "day", etc.) a list of field names in the order they will be shown in the data rows ("Mon", "Day", "Tair", etc.)

The *specific* month, day, etc. is NOT shown in the export header (as it is shown in the report header), because it is shown in each export row.

The field names may be used by a program reading the export to identify the data in the rows which follow; if the program does this, it will not require modification when fields are added to or rearranged in the export in a future version of CSE.

Units	Legal Range	Default	Required	Variability
	YES, YESIFNEW, NO, COLUMNSONLY, COLUMNSONLYIFNEW	YES	No	constant

**exFooter=choice**

Use NO to suppress the blank line otherwise output as an export “footer”. (Exports do not receive the total lines that most reports receive as footers.)

Units	Legal Range	Default	Required	Variability
	YES, NO	YES	No	constant

**endExport**

Optionally indicates the end of the export definition. Alternatively, the end of the export definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

**Related Probes:**

- **@export**

## 4.44 EXPORTCOL

Each EXPORTCOL defines a single datum of a User Defined Table (UDT) export; EXPORTCOLs are not used with other export types.

Use as many EXPORTCOLs as there are values to be shown in each row of the user-defined export. The values will appear in the order defined in each data row output. Be sure to include values needed to identify the data, such as the month, day, and hour, as appropriate – these are NOT automatically supplied in user-defined exports.

EXPORTCOL members are similar to the corresponding **REPORTCOL** members. See Section 5.265.1.5 for further discussion.

**colName**

Name of EXPORTCOL.

Units	Legal Range	Default	Required	Variability
	63 characters	none	No	constant

**colExport=exName**

Name of export to which this column belongs. If the EXPORTCOL is given within an **EXPORT** object, then *colExport* defaults to that export.

Units	Legal Range	Default	Required	Variability
	name of an <i>EXPORT</i>	<i>current export, if any</i>	Unless in an <i>EXPORT</i>	constant

**colVal**=*expression*

Value to show in this position in each row of export.

Units	Legal Range	Default	Required	Variability
	<i>any numeric or string expression</i>		Yes	subhour /end interval

**colHead**=*string*

Text used for field name in export header.

Units	Legal Range	Default	Required	Variability
		<i>colName</i> or blank	No	constant

**colWid**=*int*

Maximum width. Leading and trailing spaces and non-significant zeroes are removed from export data to save file space. Specifying a *colWid* less than the default may reduce the maximum number of significant digits output.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	13	No	constant

**colDec**=*int*

Number of digits after decimal point.

Units	Legal Range	Default	Required	Variability
	$x \geq 0$	<i>flexible format</i>	No	constant

**colJust**=*choice*

Specifies positioning of data within column:

Left	Left justified
Right	Right justified

**endExportCol**

Optionally indicates the end of the EXPORTCOL. Alternatively, the end of the definition can be indicated by END or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant



**Related Probes:**

- `@exportCol`

**4.45 IMPORTFILE**

IMPORTFILE allows specification of a file from which external data can be accessed using the `import()` and `importStr()` functions. This allows external values to be referenced in expressions. Any number of IMPORTFILES can be defined and any number of `import()/importStr()` references can be made to a give IMPORTFILE.

Import files are text files containing an optional header and comma-separated data fields. With the header present, the structure of an import file matches that of an **EXPORT** file. This makes it convenient to import unmodified files EXPORTed from prior runs. The file structure is as follows (noting that the header in lines 1-4 should not be present when `imHeader=NO`) –

Line	Contents	Notes
1	<i>runTitle, runNumber</i>	read but not checked
2	<i>timestamp</i>	in quotes, read but not checked
3	<i>title, freq</i>	should match <code>imTitle</code> and <code>imFreq</code> (see below)
4	<i>colName1,colName2,...</i>	comma separated column names optionally in quotes
5 ..	<i>val1,val2,...</i>	comma separated values (string values optionally in quotes)

Example import file `imp1.csv`

```
"Test run",001
"Fri 04-Nov-16 10:54:37 am"
"Daily Data","Day"
Mon,Day,Tdb,Twb
1,1,62.2263,53.2278
1,2,61.3115,52.8527
1,3,60.4496,52.4993
1,4,60.2499,52.4174
1,5,60.9919,52.7216
1,6,61.295,52.8459
1,7,62.3178,53.2654
1,8,62.8282,53.4747
(... continues for 365 data lines ...)
```

Example IMPORTFILE use (reading from `imp1.csv`)

```
// ... various input statements ...

IMPORTFILE Example imFileName="imp1.csv" imFreq=Day imTitle="Daily Data"
...
// Compute internal gain based on temperature read from import file.
// result is 3000 W per degree temperature is above 60.
// Note gnPower can have hourly variability, but here varies daily.
GAIN gnPower = 3000 * max( 0, import(Example,"Tdb") - 60) / 3.412
...
```

**Notes**

- As usual, file order is not important – IMPORTFILES can be referenced before they are defined.
- Columns are referenced by 1-based index or column names (assuming file header is present). In the example above, “Tdb” could be replaced by 3.

- Column names should be case-insensitive unique. CSE issues a warning for each non-unique name found. Reference to a non-unique name in `import()/importStr()` is treated as an error (no run).
- Heading or data string values generally do not need to be quoted except for values that include comma(s).

**imName**

Name of IMPORTFILE object (for reference from `Import()`).

Units	Legal Range	Default	Required	Variability
	63 characters		No	constant

**imFileName=string**

Gives path name of file to be read. If directory is specified, CSE first looks for the file the current directory and searches include paths specified by the `-I` command line parameter (if any).

Units	Legal Range	Default	Required	Variability
	file name, path optional		Yes	constant

**imTitle=string**

Title expected to be found on line 3 of the import file. A warning is issued if a non-blank `imTitle` does not match the import file title.

Units	Legal Range	Default	Required	Variability
	Text string	(blank)	No	constant

**imFreq=choice**

Specifies the interval at which CSE reads from the import file. Data is read at the beginning of the indicated interval and buffered in memory for access in expressions via `import()` or `importStr()`.

Units	Legal Range	Default	Required	Variability
	YEAR, MONTH, DAY, or HOUR		Yes	constant

**imHeader=choice**

Indicates whether the import file include a 4 line header, as described above. If NO, the import file should contain only comma-separated data rows and data items can be referenced only by 1-based column number.

Units	Legal Range	Default	Required	Variability
	YES NO	YES	No	constant

**endImportFile**

Optionally indicates the end of the import file definition. Alternatively, the end of the import file definition can be indicated by `END` or by beginning another object.

Units	Legal Range	Default	Required	Variability
		N/A	No	constant

#### Related Probes:

- @importFile
- @impFileFldNames

## 5 Output Reports

CSE report data is accumulated during simulation and written to the report file at the end of the run. Some reports are generated by default and cannot be turned off. There are a set of predefined reports which may be requested in the input. The user may also define custom reports which include many CSE internal variables. Reports may accumulate data on an a variety of frequencies including subhourly, hourly, daily, monthly, and annual (run) intervals.

### 5.1 Units

The default units for CSE reports are:

Energy	mBtu, millions of Btu (to convert to kWh divide by 292)
Temperature	degrees Fahrenheit
Air Flow	cfm (cubic feet per minute)

### 5.2 Time

Hourly reports show hour 1 through 24 where hour 1 includes the time period from midnight to 1 AM. By default, CSE specifies that January first is a Thursday and the simulation occurs on a non-leap year. Daylight savings is in effect from the second Sunday of March on which CSE skips hour 3 until the first Sunday of November when CSE simulates 25 hours. These calendar defaults can be modified as required.

### 5.3 METER Reports

A Meter Report displays the energy use of a **METER** object, a user-defined “device” that records energy consumption of equipment as simulated by CSE. CSE allows the user to define as many meters as desired and to assign any energy using device to any meter.

Meters account for energy use in pre-defined categories, called *end uses*, that are documented with **METER**.

### 5.4 Energy Balance Report

The Energy Balance Report displays the temperature and sensible and latent heat flows into and out of the air of a single zone. Sign conventions assume that a positive flow increases the air temperature. Heat flow from a warm mass element such as a concrete wall into the zone air is defined as a positive flow, heat flow from air into mass is negative. Solar gain into the zone is defined as a positive heat flow. Solar gain that is incident on and absorbed directly into a mass element is shown as both a positive in the SOLAR column (gain to the zone) and a negative in the MASS column (lost from the zone to the mass).

In a real building zone energy and moisture flows must balance due to the laws of physics. CSE uses approximate solutions for the energy and moisture balances and displays the net balance which is a measure of internal calculation error.

The following items are displayed (using the abbreviations shown in the report headings):

---

Tair	Air temperature in the zone (since CSE uses combined films this is technically the effective temperature and includes radiant effects).
WBair	Wet Bulb temperature in the zone.
Cond	Heat flow through light weight surfaces from or to the outdoors.
InfS	Sensible infiltration heat flow from outdoors.
Slr	Solar gain through glazing (net) and solar gains absorbed by light surfaces and transmitted into the zone air.
IgnS	Sensible internal gains from lights, equipment, people, etc.
Mass	Net heat flow to (negative) and from (positive) the mass elements of the zone.
Izone	Net heat flows to other zones in the building.
MechS	Net heat flows from heating, cooling and ventilation.
BALS	The balance (error) calculated by summing the sensible gains and losses.
InfL	Latent infiltration heat flow.
IgnL	Latent internal gains.
AirL	Latent heat absorbed (negative) or released (positive) by changes in the room air moisture content.
MechL	Latent heat added or removed by cooling or ventilation.
Ball	The balance (error) calculated by summing the sensible gains and losses.

---

## 5.5 Air Handler Load Report

The Air Handler Load Report displays conditions and loads at the peak load hours for the air handler for a single zone. The following items are displayed:

---

PkVf	Peak flow (cfm) at supply fan
VfDs	Supply fan design flow (same as peak for E10 systems)
PkQH	Peak heat output from heating coil.
Hcapt	Rated capacity of heat coil

---

The rest are about the cooling coil. Most of the columns are values at the time of peak part load ratio (plr). Note that, for example, the peak sensible load is the sensible load at the time of peak part load ratio, even if there was a higher sensible load at another time when the part load ratio was smaller.

---

PkMo	Month of cooling coil peak plr, 1-12
Dy	Day of month 1-31 of peak
Hr	Hour of day 1-24 of cooling coil peak plr.
Tout	Outdoor drybulb temperature at time of cooling coil peak plr.
Wbou	Outdoor wetbulb similarly
Ten	Cooling coil entering air temperature at time of peak plr.
Wben	Entering wetbulb similarly
Tex	Exiting air temperature at plr peak
	WbexExiting air wetbulb similarly
-PkQs	Sensible load at time of peak plr, shown positive.
-PkQl	Latent load likewise
-PkQC	Total load – sum of PkQs and PkQl

---

CPlr	Peak part load ratio: highest fraction of coil's capacity used, reflecting both fraction of maximum output under current conditions used when on and fraction of the time the fan is on. The maximum output under actual conditions can vary considerably from the rated capacity for DX coils. The fraction of maximum output used can only be 1.0 if the sensible and total loads happen to occur in the same ratio as the sensible and total capacities. The time the fan is on can be less than 1.0 for residential systems in which the fan cycles on with the compressor. For example, if at the cooling peak the coil ran at .8 power with the fan on .9 of the time, a CPlr of .72 would be reported. The preceding 12 columns are values at the time this peak occurred.
Ccapt	Cooling coil rated total capacity
Ccaps	Rated sensible capacity.

## 5.6 Air Handler Report

The Air Handler Load Report displays conditions and heat flows in the air handler for the time period specified. It is important to note that the air handler report only accumulates data if the air handler is on during an hour. The daily and monthly values are averages of the hours the air handler was on and DO NOT INCLUDE OFF HOUR VALUES. The following items are displayed:

Tout	Outdoor drybulb temperature during hours the air handler was on.
Wbou	Outdoor wetbulb temperature similarly.
Tret	Return air dry bulb temperature during hours the air handler was on before return duct losses or leaks.
Wbre	Return air wetbulb similarly
po	Fraction outside air including economizer damper leakage, but not return duct leakage.
Tmix	Mixed air dry bulb temperature – after return air combined with outside air; after return fan, but before supply fan and coil(s).
Wbmi	Mixed air wet bulb temperature, similarly.
Tsup	Supply air dry bulb temperature to zone terminals – after coil(s) and air handler supply duct leak and loss; (without in zone duct losses after terminals).
WBSu	Supply air wet bulb temperature similarly.
HrsOn	Hours during which the fan operated at least part of the time.
FOn	Fraction of the time the fan was on during the hours it operated (HrsOn). CHECK FOR VAV, IS IT FLOW OR TIME
VF	Volumetric flow, measured at mix point/supply fan/coils; includes air that leaks out of supply duct and is thus non-0 even when zone terminals are taking no flow
Qheat	Heat energy added to air stream by heat coil, if any, MEASURED AT COIL not as delivered to zones (see Qload).
Qsens, Qlat and Qcool	Sensible, latent, and total heat added to air stream (negative values) by cooling coil, MEASURED AT COIL, including heat cancelled by fan heat and duct losses, and heat added to air lost through supply duct leak.
Qout	Net heat taken from outdoor air. Sum of sensible and latent, measured RELATIVE TO CURRENT RETURN AIR CONDITIONS.
Qfan	Heat added to air stream by supply fan, plus return fan if any – but not relief fan..
Qloss	Heat added to air stream by supply and return duct leaks and conductive loss. Computed in each case as the sensible and latent heat in the air stream relative to return air conditions after the leak or loss, less the same value before the leak or loss.
Qload	Net energy delivered to the terminals – Sensible and latent energy, measured relative to return air conditions. INCLUDES DUCT LOSSES after terminals; thus will differ from sum of zone qMech's + qMecLat's.

---

Qbal Sum of all the 'Q' columns, primarily a development aid. Zero indicates consistent and accurate computation; the normal printout is something like .0000, indicating that the value was too small to print in the space allotted, but not precisely zero, due to computational tolerances and internal round-off errors.

---

## 6 Probe Definitions

### 6.1 ahRes

@ahRes[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
Y.n	–	X	unrecognized	end of run (of each phase, autoSize or simulate)	–
Y.tDbO	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.wO	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.tr	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.wr	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.tmix	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.wmix	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.ts	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.ws	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.po	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.frFanOn	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.vf	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qh	–	X	number	end of run (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
Y.qc	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qs	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.ql	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qO	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qFan	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qLoss	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qLoad	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qBal	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.ph	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.pc	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.pAuxH	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.pAuxC	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.pFan	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.hrsOn	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.nSubhr	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.nIter1	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.nIter2	–	X	number	end of run (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
Y.nIter4	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.nIterFan	–	X	number	end of run (of each phase, autoSize or simulate)	–
M.n	–	X	unrecognized	end of each month	–
M.tDbO	–	X	number	end of each month	–
M.wO	–	X	number	end of each month	–
M.tr	–	X	number	end of each month	–
M.wr	–	X	number	end of each month	–
M.tmix	–	X	number	end of each month	–
M.wmix	–	X	number	end of each month	–
M.ts	–	X	number	end of each month	–
M.ws	–	X	number	end of each month	–
M.po	–	X	number	end of each month	–
M.frFanOn	–	X	number	end of each month	–
M.vf	–	X	number	end of each month	–
M.qh	–	X	number	end of each month	–
M.qc	–	X	number	end of each month	–
M.qs	–	X	number	end of each month	–
M.ql	–	X	number	end of each month	–
M.qO	–	X	number	end of each month	–
M.qFan	–	X	number	end of each month	–
M.qLoss	–	X	number	end of each month	–
M.qLoad	–	X	number	end of each month	–
M.qBal	–	X	number	end of each month	–
M.ph	–	X	number	end of each month	–
M.pc	–	X	number	end of each month	–
M.pAuxH	–	X	number	end of each month	–
M.pAuxC	–	X	number	end of each month	–
M.pFan	–	X	number	end of each month	–
M.hrsOn	–	X	number	end of each month	–
M.nSubhr	–	X	number	end of each month	–
M.nIter1	–	X	number	end of each month	–
M.nIter2	–	X	number	end of each month	–
M.nIter4	–	X	number	end of each month	–
M.nIterFan	–	X	number	end of each month	–
D.n	–	X	unrecognized	end of each day	–
D.tDbO	–	X	number	end of each day	–
D.wO	–	X	number	end of each day	–
D.tr	–	X	number	end of each day	–
D.wr	–	X	number	end of each day	–
D.tmix	–	X	number	end of each day	–
D.wmix	–	X	number	end of each day	–
D.ts	–	X	number	end of each day	–
D.ws	–	X	number	end of each day	–
D.po	–	X	number	end of each day	–
D.frFanOn	–	X	number	end of each day	–
D.vf	–	X	number	end of each day	–
D.qh	–	X	number	end of each day	–
D.qc	–	X	number	end of each day	–



Name	Input?	Runtime?	Type	Variability	Description
D.qs	–	X	number	end of each day	–
D.ql	–	X	number	end of each day	–
D.qO	–	X	number	end of each day	–
D.qFan	–	X	number	end of each day	–
D.qLoss	–	X	number	end of each day	–
D.qLoad	–	X	number	end of each day	–
D.qBal	–	X	number	end of each day	–
D.ph	–	X	number	end of each day	–
D.pc	–	X	number	end of each day	–
D.pAuxH	–	X	number	end of each day	–
D.pAuxC	–	X	number	end of each day	–
D.pFan	–	X	number	end of each day	–
D.hrsOn	–	X	number	end of each day	–
D.nSubhr	–	X	number	end of each day	–
D.nIter1	–	X	number	end of each day	–
D.nIter2	–	X	number	end of each day	–
D.nIter4	–	X	number	end of each day	–
D.nIterFan	–	X	number	end of each day	–
H.n	–	X	unrecognized	end of each hour	–
H.tDbO	–	X	number	end of each hour	–
H.wO	–	X	number	end of each hour	–
H.tr	–	X	number	end of each hour	–
H.wr	–	X	number	end of each hour	–
H.tmix	–	X	number	end of each hour	–
H.wmix	–	X	number	end of each hour	–
H.ts	–	X	number	end of each hour	–
H.ws	–	X	number	end of each hour	–
H.po	–	X	number	end of each hour	–
H.frFanOn	–	X	number	end of each hour	–
H.vf	–	X	number	end of each hour	–
H.qh	–	X	number	end of each hour	–
H.qc	–	X	number	end of each hour	–
H.qs	–	X	number	end of each hour	–
H.ql	–	X	number	end of each hour	–
H.qO	–	X	number	end of each hour	–
H.qFan	–	X	number	end of each hour	–
H.qLoss	–	X	number	end of each hour	–
H.qLoad	–	X	number	end of each hour	–
H.qBal	–	X	number	end of each hour	–
H.ph	–	X	number	end of each hour	–
H.pc	–	X	number	end of each hour	–
H.pAuxH	–	X	number	end of each hour	–
H.pAuxC	–	X	number	end of each hour	–
H.pFan	–	X	number	end of each hour	–
H.hrsOn	–	X	number	end of each hour	–
H.nSubhr	–	X	number	end of each hour	–
H.nIter1	–	X	number	end of each hour	–
H.nIter2	–	X	number	end of each hour	–
H.nIter4	–	X	number	end of each hour	–
H.nIterFan	–	X	number	end of each hour	–
S.n	–	X	unrecognized	end of each subhour	–
S.tDbO	–	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
S.wO	–	X	number	end of each subhour	–
S.tr	–	X	number	end of each subhour	–
S.wr	–	X	number	end of each subhour	–
S.tmix	–	X	number	end of each subhour	–
S.wmix	–	X	number	end of each subhour	–
S.ts	–	X	number	end of each subhour	–
S.ws	–	X	number	end of each subhour	–
S.po	–	X	number	end of each subhour	–
S.frFanOn	–	X	number	end of each subhour	–
S.vf	–	X	number	end of each subhour	–
S.qh	–	X	number	end of each subhour	–
S.qc	–	X	number	end of each subhour	–
S.qs	–	X	number	end of each subhour	–
S.ql	–	X	number	end of each subhour	–
S.qO	–	X	number	end of each subhour	–
S.qFan	–	X	number	end of each subhour	–
S.qLoss	–	X	number	end of each subhour	–
S.qLoad	–	X	number	end of each subhour	–
S.qBal	–	X	number	end of each subhour	–
S.ph	–	X	number	end of each subhour	–
S.pc	–	X	number	end of each subhour	–
S.pAuxH	–	X	number	end of each subhour	–
S.pAuxC	–	X	number	end of each subhour	–
S.pFan	–	X	number	end of each subhour	–
S.hrsOn	–	X	number	end of each subhour	–
S.nSubhr	–	X	number	end of each subhour	–
S.nIter1	–	X	number	end of each subhour	–
S.nIter2	–	X	number	end of each subhour	–
S.nIter4	–	X	number	end of each subhour	–
S.nIterFan	–	X	number	end of each subhour	–

## 6.2 airHandler

@airHandler[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
ahTsDsH	X	X	number	hourly	Heating design supply temperature, for sizing coil vs fan. defaulted hourly to ahtsmx.
ahTsDsC	X	X	number	hourly	Cooling ..
ahccSHR	X	X	number	autosize and simulate phase start time	Sensible heat ratio (caps/capt) for cooling coil
coilOversize	X	X	number	autosize and simulate phase start time	Fraction oversize for autosized heat/cool coils

Name	Input?	Runtime?	Type	Variability	Description
fanOversize	X	X	number	autosize and simulate phase start time	Fraction oversize for autosized fan(s)
asRfan	X	X	integer number	run start time (of each phase, autoSize or simulate)	True to autosize return/relief fan (to same capacity as supply fan)
asFlow	X	X	integer number	run start time (of each phase, autoSize or simulate)	True if autosizing supply fan and/or flow of any connected terminal:
hcAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
hcAs.az_a	X	X	number	end of each subhour	–
hcAs.az_b	X	X	number	end of each subhour	–
hcAs.ldPk	X	X	number	end of each subhour	–
hcAs.ldPkAs	X	X	number	end of each day	–
hcAs.ldPkAs1	X	X	number	end of each day	–
hcAs.plrPk	X	X	number	end of each subhour	–
hcAs.plrPkAs	X	X	number	end of each day	–
hcAs.xPk	X	X	number	end of each subhour	–
hcAs.xPkAs	X	X	number	end of each day	–

Name	Input?	Runtime?	Type	Variability	Description
ccAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
ccAs.az_a	X	X	number	end of each subhour	–
ccAs.az_b	X	X	number	end of each subhour	–
ccAs.ldPk	X	X	number	end of each subhour	–
ccAs.ldPkAs	X	X	number	end of each day	–
ccAs.ldPkAs1	X	X	number	end of each day	–
ccAs.plrPk	X	X	number	end of each subhour	–
ccAs.plrPkAs	X	X	number	end of each day	–
ccAs.xPk	X	X	number	end of each subhour	–
ccAs.xPkAs	X	X	number	end of each day	–
fanAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fanAs.az_a	X	X	number	end of each subhour	–
fanAs.az_b	X	X	number	end of each subhour	–
fanAs.ldPk	X	X	number	end of each subhour	–
fanAs.ldPkAs	X	X	number	end of each day	–
fanAs.ldPkAs1	X	X	number	end of each day	–

Name	Input?	Runtime?	Type	Variability	Description
fanAs.plrPk	X	X	number	end of each subhour	–
fanAs.plrPkAs	X	X	number	end of each day	–
fanAs.xPk	X	X	number	end of each subhour	–
fanAs.xPkAs	X	X	number	end of each day	–
bVfDs	X	X	number	end of each subhour	Sfan.vfds. see coil::bcaptrat for ahhc and ahcc.
qcPkS	X	X	number	end of each subhour	Sensible load @ peak total load
qcPkL	X	X	number	end of each subhour	Latent cool coil load ditto
qcPkH	X	X	integer number	end of each subhour	Hour 1-24 of peak total cool coil load
qcPkD	X	X	integer number	end of each subhour	Day of month 1-31 of peak load, not used for autosizing
qcPkM	X	X	integer number	end of each subhour	Month 1-12 of peak load, or 0 for heat design month
qcPkTDbO	X	X	number	end of each subhour	Outdoor temp at time of peak load
qcPkWO	X	X	number	end of each subhour	Outdoor hum rat at time of peak load. w's must follow t's for reports.
qcPkTen	X	X	number	end of each subhour	Entering air temp
qcPkWen	X	X	number	end of each subhour	Hum rat
qcPkTex	X	X	number	end of each subhour	Exiting air temp (b4 remix w bypass air)
qcPkWex	X	X	number	end of each subhour	Hum rat (b4 remix w bypass air)
qcPkSAs	X	X	number	end of each subhour	Sensible load @ peak total load
qcPkLAs	X	X	number	end of each subhour	Latent cool coil load ditto

Name	Input?	Runtime?	Type	Variability	Description
qcPkHAs	X	X	integer number	end of each subhour	Hour 1-24 of peak total cool coil load
qcPkDAs	X	X	integer number	end of each subhour	Day of month 1-31 of peak load, not used for autosizing
qcPkMAs	X	X	integer number	end of each subhour	Month 1-12 of peak load, or 0 for heat design month
qcPkTDbOAs	X	X	number	end of each subhour	Outdoor temp at time of peak load
qcPkWOAs	X	X	number	end of each subhour	Outdoor hum rat at time of peak load. w's must follow t's for reports.
qcPkTenAs	X	X	number	end of each subhour	Entering air temp
qcPkWenAs	X	X	number	end of each subhour	Hum rat
qcPkTexAs	X	X	number	end of each subhour	Exiting air temp (b4 remix w bypass air)
qcPkWexAs	X	X	number	end of each subhour	Hum rat (b4 remix w bypass air)
ahTsSp	X	X	unrecognized	hourly	Supply temperature setpoint or control method: ra, wz, cz, zn, zn2, or number, hourly;
ahFanCycles	X	X	unrecognized	hourly	Yes if fan (and coil) cycles with zone thermostat; hourly;
ahTsMn	X	X	number	hourly	Hourly, default 40.
ahTsMx	X	X	number	hourly	Hourly, default 250.
ahTsRaMn	X	X	number	hourly	Return air temp at which tssp is at ahtsmx. hourly.
ahTsRaMx	X	X	number	hourly	.. ahtsmn. hourly. if return air moves outside this range, tssp does not change further.
ahCtu	X	X	integer number	run start time (of each phase, autoSize or simulate)	Terminal for determining whether to heat or cool under zn, zn2 tsu sp control.
ahWzCzns[0]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.

Name	Input?	Runtime?	Type	Variability	Description
ahWzCzns[1]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[2]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[3]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[4]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[5]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[6]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[7]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[8]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[9]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[10]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.

Name	Input?	Runtime?	Type	Variability	Description
ahWzCzns[11]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[12]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[13]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[14]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahWzCzns[15]	X	X	integer number	autosize and simulate phase start time	Zone names monitored for warmest zone and coolest zone ts sp control, respectively.
ahCzCzns[0]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[1]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[2]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[3]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[4]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.



Name	Input?	Runtime?	Type	Variability	Description
ahCzCzns[5]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[6]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[7]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[8]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[9]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[10]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[11]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[12]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[13]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
ahCzCzns[14]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.

Name	Input?	Runtime?	Type	Variability	Description
ahCzCzns[15]	X	X	integer number	autosize and simulate phase start time	Each input may be all, all_but, and/or zone names, comma-separated. default all.
oaMnCm	X	X	unrecognized	autosize and simulate phase start time	Min oa flow control method, choice of vol or frac, default vol, constant.
oaMnFrac	X	X	number	hourly	Fraction 0-1 of minimum oa to use now, hourly, default 1.0. eg to shut off oa during warmup.
oaVfDsMn	X	X	number	run start time (of each phase, autoSize or simulate)	Design minimum outside air flow (cfm actual air), constant, dfl .15 * area.
oaEcoTy	X	X	unrecognized	autosize and simulate phase start time	Choice of none, nonintegrated, two_stage, integrated. constant. default none.
oaLimT	X	X	unrecognized	hourly	Economizer oa temp hi limit: number -50 to 999, or ra for current return air temp,
oaLimE	X	X	unrecognized	hourly	Economizer oa enthalpy hi limit: number or ra, constant, dfl 999 (enth limit disabled).
oaOaLeak	X	X	number	autosize and simulate phase start time	Outside air damper leakage to mixed air, fraction of supply fan design cfm if have economizer,
oaRaLeak	X	X	number	autosize and simulate phase start time	Return air damper leakage to mixed air, fraction supply fan design cfm,
ahSOLeak	X	X	number	autosize and simulate phase start time	Supply duct leakage to outdoors, 0-.1 of sfanvfds, default .01. use 0 if duct indoors.
ahROLeak	X	X	number	autosize and simulate phase start time	Return duct leakage from outdoors, 0-.1, of sfanvfds, default .01, use 0 if duct indoors.

Name	Input?	Runtime?	Type	Variability	Description
ahSOLoss	X	X	number	autosize and simulate phase start time	Supply duct loss/gain to outdoors, 0-.1, default .02? (taylor 0.5f), use 0 if duct indoors.
ahROLoss	X	X	number	autosize and simulate phase start time	Return duct heat loss/gain to outdoors, 0-.1, default .02? (ditto), use 0 if duct indoors.
ahSch	X	X	unrecognized	hourly	Supply fan and thus air handler schedule; choice of on or off, hourly variable; default on.
sfan.fanTy	X	X	unrecognized	autosize and simulate phase start time	–
sfan.vfDs	X	X	number	end of each subhour	–
sfan.vfDs_As	X	X	number	autosize and simulate phase start time	–
sfan.vfDs_AsNov	X	X	number	autosize and simulate phase start time	–
sfan.vfMxF	X	X	number	autosize and simulate phase start time	–
sfan.press	X	X	number	run start time (of each phase, autoSize or simulate)	–
sfan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sfan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
sfan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
sfan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sfan.motEff	X	X	number	autosize and simulate phase start time	–
sfan.motPos	X	X	unrecognized	autosize and simulate phase start time	–
sfan.curvePy.k[0]	X	X	number	autosize and simulate phase start time	–
sfan.curvePy.k[1]	X	X	number	autosize and simulate phase start time	–
sfan.curvePy.k[2]	X	X	number	autosize and simulate phase start time	–
sfan.curvePy.k[3]	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
sfan.curvePy.k[4]	X	X	number	autosize and simulate phase start time	–
sfan.curvePy.k[5]	X	X	number	autosize and simulate phase start time	–
sfan.mtri	X	X	integer number	autosize and simulate phase start time	–
sfan.endUse	X	X	integer number	autosize and simulate phase start time	–
sfan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
sfan.outPower	X	X	number	subhourly	–
sfan.airPower	X	X	number	subhourly	–
sfan.cMx	X	X	number	end of each subhour	–
sfan.c	X	X	number	end of each subhour	–
sfan.t	X	X	number	end of each subhour	–
sfan.frOn	X	X	number	end of each subhour	–
sfan.p	X	X	number	end of each subhour	–
sfan.q	X	X	number	end of each subhour	Average (not fan-on) output power level for subhour
sfan.dT	X	X	number	end of each subhour	How much warmer than outdoor temp crankcase oil is assumed to be, in subhrs when compr does not run.

Name	Input?	Runtime?	Type	Variability	Description
sfan.qAround	X	X	number	end of each subhour	–
rfan.fanTy	X	X	unrecognized	autosize and simulate phase start time	–
rfan.vfDs	X	X	number	end of each subhour	–
rfan.vfDs_As	X	X	number	autosize and simulate phase start time	–
rfan.vfDs_AsNov	X	X	number	autosize and simulate phase start time	–
rfan.vfMxF	X	X	number	autosize and simulate phase start time	–
rfan.press	X	X	number	run start time (of each phase, autoSize or simulate)	–
rfan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	–
rfan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
rfan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
rfan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
rfan.motEff	X	X	number	autosize and simulate phase start time	–
rfan.motPos	X	X	unrecognized	autosize and simulate phase start time	–
rfan.curvePy.k[0]	X	X	number	autosize and simulate phase start time	–
rfan.curvePy.k[1]	X	X	number	autosize and simulate phase start time	–
rfan.curvePy.k[2]	X	X	number	autosize and simulate phase start time	–
rfan.curvePy.k[3]	X	X	number	autosize and simulate phase start time	–
rfan.curvePy.k[4]	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
rfan.curvePy.k[5]	X	X	number	autosize and simulate phase start time	–
rfan.mtri	X	X	integer number	autosize and simulate phase start time	–
rfan.endUse	X	X	integer number	autosize and simulate phase start time	–
rfan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
rfan.outPower	X	X	number	subhourly	–
rfan.airPower	X	X	number	subhourly	–
rfan.cMx	X	X	number	end of each subhour	–
rfan.c	X	X	number	end of each subhour	–
rfan.t	X	X	number	end of each subhour	–
rfan.frOn	X	X	number	end of each subhour	–
rfan.p	X	X	number	end of each subhour	–
rfan.q	X	X	number	end of each subhour	Average (not fan-on) output power level for subhour
rfan.dT	X	X	number	end of each subhour	How much warmer than outdoor temp crankcase oil is assumed to be, in subhrs when compr does not run.
rfan.qAround	X	X	number	end of each subhour	–



Name	Input?	Runtime?	Type	Variability	Description
cch.cchCM	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Crankcase heater presence and control method choice. nils cchctlmtd.
cch.pMx	X	X	number	autosize and simulate phase start time	Crankcase resistance heater input power; maximum power if cchcm is ptc or ptc_clo.
cch.pMn	X	X	number	autosize and simulate phase start time	Min cch input power. default .04kw. entered in kw, internally in btuh. nils pcchmn.
cch.tMx	X	X	number	autosize and simulate phase start time	Low temp (max power) setpoint... default 0 f. nils tcchptcmx.
cch.tMn	X	X	number	autosize and simulate phase start time	High temp (min power) setpoint for cchcm = ptc or ptc_clo. default 150 f. nils tcchptcmn.
cch.dt	X	X	number	autosize and simulate phase start time	How much warmer than outdoor temp crankcase oil is assumed to be, in subhrs when compr does not run.
cch.tOn	X	X	number	autosize and simulate phase start time	—
cch.tOff	X	X	number	run start time (of each phase, autoSize or simulate)	—
cch.mtri	X	X	integer number	autosize and simulate phase start time	—

Name	Input?	Runtime?	Type	Variability	Description
cch.p47Off	X	X	number	run start time (of each phase, autoSize or simulate)	Power input during off part of one cycle of ari 47 degree cycling test, kwh.
cch.p17	X	X	number	run start time (of each phase, autoSize or simulate)	Power input to crankcase heater in ari 17 degree continuous operation test, kw. niles pcch17.
cch.p47	X	X	number	run start time (of each phase, autoSize or simulate)	Ditto 47 degree test. niles pcch47. p17 and p47 always the same; p47 may be used in code as
cch.frCprOn	X	X	number	end of each subhour	–
cch.tState	X	X	integer number	end of each subhour	Thermostat state for cchcm = tstat: must remember to implement hysteresis
cch.p	X	X	number	end of each subhour	–
ahhc.coilTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Coil type choice according to application, as follows. constant.
ahhc.sched	X	X	unrecognized	hourly	Avail when coil available, off when disabled, hourly, default avail.
ahhc.captRat	X	X	number	end of each subhour	–
ahhc.captRat_As	X	X	number	autosize and simulate phase start time	–
ahhc.captRat_AsNoX		X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
ahhc.bCaptRat	X	X	number	end of each subhour	Start-subhr captrat, to undo size increases not in use as converged at end subhr (ahhc,ahcc).
ahhc.eirRat	X	X	number	hourly	Rated load energy input ratio===heat input ratio===input/output===1/efficiency for dx,gas,oil at least.
ahhc.mtri	X	X	integer number	autosize and simulate phase start time	–
ahhc.auxOn	X	X	number	hourly	Additional input energy used in proportion to plr when coil on, as for induced draft fan,
ahhc.auxOnMtri	X	X	integer number	autosize and simulate phase start time	Mtr to which to charge “auxon”
ahhc.auxOff	X	X	number	hourly	Addl input energy when off for part or all of subhr (proportional to 1-plr), for unforeseen uses.
ahhc.auxOffMtri	X	X	integer number	autosize and simulate phase start time	Mtr for “auxoff”
ahhc.auxOnAtall	X	X	number	hourly	Addl input energy used in toto when coil on for any part of subhour, for unforeseen uses.
ahhc.auxOnAtallMtrX		X	integer number	autosize and simulate phase start time	Mtr for “auzonatall”
ahhc.auxFullOff	X	X	number	hourly	Additional input energy when off for entire subhour (as opposed to in proportion to 1-plr).
ahhc.auxFullOffMtrX		X	integer number	autosize and simulate phase start time	Mtr to which auxfulloff is charged
ahhc.q	X	X	number	end of each subhour	Average (not fan-on) output power level for subhour
ahhc.qPr	X	X	number	end of each subhour	Output at which coil's plant last computed, for call-flagging plant. set: cnhp.cpp. used: cncoil.cpp

Name	Input?	Runtime?	Type	Variability	Description
ahhc.p	X	X	number	end of each subhour	–
ahhc.plr	X	X	number	end of each subhour	Current fan-on (or furnace-on) relative load (part load ratio)
ahhc.plrAv	X	X	number	end of each subhour	Current average relative load (plr * frfanon)
ahhc.eir	X	X	number	end of each subhour	Energy input ratio: current input/output, fan on===average. rob's addition, for probes, 5-92.
ahhc.pAuxOn	X	X	number	end of each subhour	Coil-on proporotinal aux power this subhour
ahhc.pAuxOff	X	X	number	end of each subhour	Coil-off proportional aux power this subhour
ahhc.pAuxOnAtall	X	X	number	end of each subhour	Coil on-at-all aux power this subhour
ahhc.pAuxFullOff	X	X	number	end of each subhour	Auxfulloff (doe2 pilot) power this subhour
ahhc.effRat	X	X	number	autosize and simulate phase start time	Efficiency @ rated load: alternate eir input, converted into eirrat in setup.
ahhc.pyEi.k[0]	X	X	number	autosize and simulate phase start time	–
ahhc.pyEi.k[1]	X	X	number	autosize and simulate phase start time	–
ahhc.pyEi.k[2]	X	X	number	autosize and simulate phase start time	–
ahhc.pyEi.k[3]	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
ahhc.pyEi.k[4]	X	X	number	autosize and simulate phase start time	–
ahhc.stackEffect	X	X	number	hourly	Fraction of unused capacity that must be used (increasing plr) to make up for increased
ahhc.hpi	X	X	integer number	autosize and simulate phase start time	Subscript of heatplant serving hw coil
ahhc.nxTu4hp	X	X	integer number	run start time (of each phase, autoSize or simulate)	Tub subscr of next tu with hw coil on same heatplant. 1st is heatplant.tu1.
ahhc.nxAh4hp	X	X	integer number	run start time (of each phase, autoSize or simulate)	Ahb subscr of next ah with hw coil on same heatplant. 1st is heatplant.ah1.
ahhc.flueLoss	X	X	number	end of each subhour	Part-load flue loss this subhour, gas and oil only
ahhc.qWant	X	X	number	end of each subhour	Hw: desired output===input, dohwcoil to hpcompute, used in determining capf.
ahhc.cap17	X	X	number	autosize and simulate phase start time	Ari steady state rated cap @ 17 out, 70 indoor (return) air, btuh, rqd for ahp, nils pcapss17.
ahhc.cap47	X	X	number	autosize and simulate phase start time	Ari steady state rated cap @ 47 out, 70 indoor (return) air, btuh, rqd for ahp, nils pcapss47.
ahhc.cap35	X	X	number	run start time (of each phase, autoSize or simulate)	Ari steady state rated cap @ 35f outdoor, btuh, default per fd35df, nils pcapss35.

Name	Input?	Runtime?	Type	Variability	Description
ahhc.fd35Df	X	X	number	autosize and simulate phase start time	Default frost/defrost degradation factor at 35 f, default .85, niles fdf35dft.
ahhc.capIa	X	X	number	autosize and simulate phase start time	Capacity correction factor for indoor (return) air temperature, default .004, niles iaccap.
ahhc.supRh	X	X	number	autosize and simulate phase start time	Input (& output) of supplemental resistance reheat coil, kw, default 10, niles psuprh.
ahhc.tFrMn	X	X	number	autosize and simulate phase start time	Lowest temp for frost buildup & defrost effects, default 17f, niles tfrstmn.
ahhc.tFrMx	X	X	number	autosize and simulate phase start time	Highest temp for frost buildup & defrost effects, default 47f, niles tfrstmx.
ahhc.tFrPk	X	X	number	autosize and simulate phase start time	Temp for peak frost buildup & defrost effects, default 42f, niles tfrstp.
ahhc.dfrFMn	X	X	number	autosize and simulate phase start time	Min frac time in reverse cycle cooling, default .0222 (2/90 min), niles tmfcredefmn.
ahhc.dfrFMx	X	X	number	autosize and simulate phase start time	Max frac time in reverse cycle cooling, default .0889 (8/90 min), niles tmfcredefmx.
ahhc.dfrCap	X	X	number	run start time (of each phase, autoSize or simulate)	Cooling capacity (to ah supply air) during defrosting, default 2 * cap17, niles pdefcool.
ahhc.dfrRh	X	X	number	autosize and simulate phase start time	Input (& output) power of addl reheat coil run during defrost, default 5kw, niles pdefrh.

Name	Input?	Runtime?	Type	Variability	Description
ahhc.tOff	X	X	number	autosize and simulate phase start time	–
ahhc.tOn	X	X	number	autosize and simulate phase start time	–
ahhc.in17	X	X	number	autosize and simulate phase start time	Steady state power input @ 17 outdoor, 70 indoor (return). rqd for ahp. niles pinss17.
ahhc.in47	X	X	number	autosize and simulate phase start time	Steady state power input @ 47 outdoor, 70 indoor (return). rqd for ahp. niles pinss47.
ahhc.inIa	X	X	number	autosize and simulate phase start time	Indoor (return) air temp power input correction factor, default .004, niles iacin.
ahhc.cd	X	X	number	autosize and simulate phase start time	Ari cycling degradation coefficient, default .25, niles cd.
ahhc.in17c	X	X	number	run start time (of each phase, autoSize or simulate)	Compressor input power @ 17 degrees out, 70 in: in17 with cch power removed. niles pinss17.
ahhc.in47c	X	X	number	run start time (of each phase, autoSize or simulate)	Ditto 47 degrees. niles pinss47.
ahhc.cdm	X	X	number	run start time (of each phase, autoSize or simulate)	Modified cd: cycling degradation coefficient adjusted to remove cch. niles cdm.

Name	Input?	Runtime?	Type	Variability	Description
ahhc.tIa	X	X	number	end of each subhour	Indoor air temp: copy of tmix or whatever ah variable is chosen
ahhc.qSupLim	X	X	number	end of each subhour	Caller-set heat output limit for when suppl heat in use: kludge when fan cycling
ahhc.frFanOn	X	X	number	end of each subhour	–
ahhc.loTLockout	X	X	integer number	end of each subhour	True if compressor locked out due to low outdoor temp (see toff, ton)
ahhc.supOn	X	X	integer number	end of each subhour	True if supplementary heat enabled (frfanon is ~1.0, with hysteresis to keep ah stable).
ahhc.capCon	X	X	number	end of each subhour	Continuous cpr capac incl frost/defrost @ actual indoor temp, excl def & reg rh. niles pcapmx.
ahhc.pDfrhCon	X	X	number	end of each subhour	Continuous avg power input to defrost heater @ outdoor temp (not cycling). niles pdefrhmx.
ahhc.cap	X	X	number	end of each subhour	Capacity this subhour incl suppl heaters. rob's addition, used by doahpheatcoil re tpossh.
ahhc.frCprOn	X	X	number	end of each subhour	–
ahhc.pCpr	X	X	number	end of each subhour	Power input to compressor (niles pincomp): copy to .p in coilsendsubhr.
ahhc.pRh	X	X	number	end of each subhour	Input===output of reg & dfr supplemental resistance heaters. included in q, not in p. niles prh.
ahccBypass	X	X	number	autosize and simulate phase start time	Fraction of air flow which bypasses cool coil (for better humidity control), constant, dfl 0.
ahcc.coilTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Coil type choice according to application, as follows. constant.
ahcc.sched	X	X	unrecognized	hourly	Avail when coil available, off when disabled, hourly, default avail.
ahcc.captRat	X	X	number	end of each subhour	–



Name	Input?	Runtime?	Type	Variability	Description
ahcc.captRat_As	X	X	number	autosize and simulate phase start time	–
ahcc.captRat_AsNoX	X	X	number	autosize and simulate phase start time	–
ahcc.bCaptRat	X	X	number	end of each subhour hourly	Start-subhr captrat, to undo size increases not in use as converged at end subhr (ahhc,ahcc).
ahcc.eirRat	X	X	number	hourly	Rated load energy input ratio===heat input ratio===input/output===1/efficiency for dx,gas,oil at least.
ahcc.mtri	X	X	integer number	autosize and simulate phase start time	–
ahcc.auxOn	X	X	number	hourly	Additional input energy used in proportion to plr when coil on, as for induced draft fan,
ahcc.auxOnMtri	X	X	integer number	autosize and simulate phase start time	Mtr to which to charge “auxon”
ahcc.auxOff	X	X	number	hourly	Addl input energy when off for part or all of subhr (proportional to 1-plr), for unforeseen uses.
ahcc.auxOffMtri	X	X	integer number	autosize and simulate phase start time	Mtr for “auxoff”
ahcc.auxOnAtall	X	X	number	hourly	Addl input energy used in toto when coil on for any part of subhour, for unforeseen uses.
ahcc.auxOnAtallMtX	X	X	integer number	autosize and simulate phase start time	Mtr for “auzonatall”
ahcc.auxFullOff	X	X	number	hourly	Additional input energy when off for entire subhour (as opposed to in proportion to 1-plr).

Name	Input?	Runtime?	Type	Variability	Description
ahcc.auxFullOffMtrIX		X	integer number	autosize and simulate phase start time	Mtr to which auxfulloff is charged
ahcc.q	X	X	number	end of each subhour	Average (not fan-on) output power level for subhour
ahcc.qPr	X	X	number	end of each subhour	Output at which coil's plant last computed, for call-flagging plant. set: cnhp.cpp. used: cncoil.cpp
ahcc.p	X	X	number	end of each subhour	–
ahcc.plr	X	X	number	end of each subhour	Current fan-on (or furnace-on) relative load (part load ratio)
ahcc.plrAv	X	X	number	end of each subhour	Current average relative load (plr * frfanon)
ahcc.eir	X	X	number	end of each subhour	Energy input ratio: current input/output, fan on===average. rob's addition, for probes, 5-92.
ahcc.pAuxOn	X	X	number	end of each subhour	Coil-on proporotinal aux power this subhour
ahcc.pAuxOff	X	X	number	end of each subhour	Coil-off proportional aux power this subhour
ahcc.pAuxOnAtall	X	X	number	end of each subhour	Coil on-at-all aux power this subhour
ahcc.pAuxFullOff	X	X	number	end of each subhour	Auxfulloff (doe2 pilot) power this subhour
ahcc.capsRat	X	X	number	end of each subhour	Dx: sensible rated capacity <= captrat btu/hr, const for input, *s cuz varies during autosize.
ahcc.capsRat_As	X	X	number	autosize and simulate phase start time	–
ahcc.capsRat_AsNoX		X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
ahcc.minTEvap	X	X	number	autosize and simulate phase start time	Dx: min evaporator (effective surface) temp (below which compressor cuts out), default 35f. (40f til 8-95)
ahcc.k1	X	X	number	autosize and simulate phase start time	Dx, chw: power of relative air flow to which outside number of transfer units is proportional.
ahcc.dsTDdBnd	X	X	number	autosize and simulate phase start time	Design (rating) (dx) condenser temp (outdoor temp pending water option), default = ari = 95f.
ahcc.dsTDdBEn	X	X	number	autosize and simulate phase start time	Design (rating) (dx,chw) entering air dry bulb temp, default = ari = 80f.
ahcc.dsTWBEn	X	X	number	autosize and simulate phase start time	Design (rating) (dx) entering air wet bulb temp, default = ari = 67f. replaces taylor's dseawb.
ahcc.vfR	X	X	number	run start time (of each phase, autoSize or simulate)	Rating (dx,chw) air flow (cfm). default: dx: per vfrperTon. chw: sfan.vfds.
ahcc.vfRperTon	X	X	number	run start time (of each phase, autoSize or simulate)	Dx default vfr per ton (12000 btuh) of captrat. default: 400.
ahcc.minUnldPlr	X	X	number	autosize and simulate phase start time	Part load ratio (fraction of full load) at/above which "compressor unloading" is used. dfl 1.
ahcc.minFsldPlr	X	X	number	autosize and simulate phase start time	Plr above which "false loading" is used (up to minunldplr). dfl minunldplr: no false loading.

Name	Input?	Runtime?	Type	Variability	Description
ahcc.pydxCaptT.k[0]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[1]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[2]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[3]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[4]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[5]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptT.k[6]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptF.k[0]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptF.k[1]X		X	number	autosize and simulate phase start time	—
ahcc.pydxCaptF.k[2]X		X	number	autosize and simulate phase start time	—

Name	Input?	Runtime?	Type	Variability	Description
ahcc.pydxCaptF.k[3]X		X	number	autosize and simulate phase start time	–
ahcc.pydxCaptF.k[4]X		X	number	autosize and simulate phase start time	–
ahcc.pydxCaptFLimX		X	number	autosize and simulate phase start time	Upper limit for value of pydxcaptf, 8-28-95
ahcc.pydxEirT.k[0] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[1] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[2] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[3] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[4] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[5] X		X	number	autosize and simulate phase start time	–
ahcc.pydxEirT.k[6] X		X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
ahcc.pydxEirUl.k[0]	X	X	number	autosize and simulate phase start time	–
ahcc.pydxEirUl.k[1]	X	X	number	autosize and simulate phase start time	–
ahcc.pydxEirUl.k[2]	X	X	number	autosize and simulate phase start time	–
ahcc.pydxEirUl.k[3]	X	X	number	autosize and simulate phase start time	–
ahcc.pydxEirUl.k[4]	X	X	number	autosize and simulate phase start time	–
ahcc.cpi	X	X	integer number	autosize and simulate phase start time	Subscript of coolplant serving chw coil, rqd for chw.
ahcc.gpmDs	X	X	number	autosize and simulate phase start time	Design (i.e. maximum) chilled water flow, gpm, rqd for chw. nils mwd[g].
ahcc.ntuoDs	X	X	number	autosize and simulate phase start time	Outside number of transfer units at design air flow (vfr), default 2. nils ntuoD.
ahcc.ntuiDs	X	X	number	autosize and simulate phase start time	Inside number of transfer units at design water flow (gpmDs), default 2. nils ntuid.
ahcc.wsatMinTEvap	X	X	number	run start time (of each phase, autoSize or simulate)	Hum ratio of saturated air at mintevap (minimum evaporator temp)

Name	Input?	Runtime?	Type	Variability	Description
ahcc.hsatevaporX		X	number	run start time (of each phase, autoSize or simulate)	Enthalpy of saturated air at mintevap
ahcc.efecOR	X	X	number	run start time (of each phase, autoSize or simulate)	(outside) effectiveness at rated conditions (in record for probing only)
ahcc.ntuR	X	X	number	run start time (of each phase, autoSize or simulate)	Number of transfer units (like time constants) at rated conditions
ahcc.eirMinUnldPlrX		X	number	run start time (of each phase, autoSize or simulate)	Pydxeirul(minunldplr): precomputed dx input correction for falseloading; prorated for cycling.
ahcc.menR	X	X	number	run start time (of each phase, autoSize or simulate)	Chw/dx coil rating air flow (lb/hr) (for chw, nils 'mad')
ahcc.nxAh4cp	X	X	integer number	run start time (of each phase, autoSize or simulate)	0 or subscr of next ah with chw coil served by same coolplant. 1st is coolplant.ah1.
ahcc.mwDs	X	X	number	run start time (of each phase, autoSize or simulate)	—
ahcc.wantQflag	X	X	integer number	end of each subhour	Nz if cooling desired (textwant < ten) regardless of sched, etc. docoils->cpeestimate.

Name	Input?	Runtime?	Type	Variability	Description
ahcc.tewd	X	X	number	end of each subhour	—
ahcc.chwQ	X	X	number	end of each subhour	—
ahcc.tr	X	X	number	end of each subhour	—
ahcc.cpTsPr	X	X	number	end of each subhour	Cp ts for which coil last computed, re compute-flagging coil from plant
ahcc.trPr	X	X	number	end of each subhour	Coil tr at last coil compute, re call-flagging cp from coil model
ahcc.fullLoadWet	X	X	integer number	end of each subhour	True if chw coil wet @ full load,
ahcc.frCprOn	X	X	number	end of each subhour	—
ahcc.tWbEn	X	X	number	end of each subhour	—
ahcc.hen	X	X	number	end of each subhour	—
ahcc.tDbCnd	X	X	number	end of each subhour	—
ahcc.efecO	X	X	number	end of each subhour	—
ahcc.capt	X	X	number	end of each subhour	—
ahcc.caps	X	X	number	end of each subhour	—
ahcc.plrVf	X	X	number	end of each subhour	—
ahcc.plrSens	X	X	number	end of each subhour	—
ahcc.qs	X	X	number	end of each subhour	—
ahcc.ql	X	X	number	end of each subhour	—



Name	Input?	Runtime?	Type	Variability	Description
ahcc.xLGain	X	X	number	end of each subhour	Condensation heat added to air (const enthalpy) to fix supersaturated wen, this subhr.
ahcc.xLGainYr	X	X	number	end of each subhour	.. cumulative over run, for message at end run.
ahcc.nSubhrsLX	X	X	number	end of each subhour	Number of subhours in which supersaturated entering air fixed
ahcc.minTLtd	X	X	integer number	end of each subhour	Output limited by mintevap b4 reaching ahtsmn (dx, 7-95)
ahcc.cfm2Few	X	X	integer number	end of each subhour	Too little flow to permit sizing coil to meet load at min temp (dx, 7-95)
tu1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Chain head: tub ss of 1st terminal for air handler. next is tu.nxtu4a.
zhx1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Chain head of ah's zhx's (zone hvac xfers): 0 or zhxb subscript of first. next: zhx.nxzhx4a.
ahMode	X	X	unrecognized	end of each subhour	What ah is doing: set to: ahoff/ahfan/ahheating/ahcooling/ahon(normal).
ts	X	X	number	end of each subhour	–
ws	X	X	number	end of each subhour	–
wsls	X	X	number	subhourly	–
airxTs	X	X	number	end of each subhour	–
tsMnFo	X	X	number	end of each subhour	–
tsMnFoOk	X	X	integer number	end of each subhour	True if tsmnfo has been calc'd since last ahestimate/ahcompute. set/used in gettsmnfo().
tsMxFo	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
tsMxFoOk	X	X	integer number	end of each subhour	True if tsmxfo has been calc'd since last ahestimate/ahcompute. set/used in gettsmxfo().
tr	X	X	number	end of each subhour	–
wr	X	X	number	end of each subhour	–
cr	X	X	number	end of each subhour	–
cMxfcc	X	X	number	end of each subhour	–
frFanOn	X	X	number	end of each subhour	–
leakCO <sub>n</sub>	X	X	number	end of each subhour	–
tr1	X	X	number	end of each subhour	–
wr1	X	X	number	end of each subhour	–
cr1	X	X	number	end of each subhour	–
tr2	X	X	number	end of each subhour	–
r <sub>fanQ</sub>	X	X	number	end of each subhour	Return fan power copied at commitment to this iteration (r <sub>fan.q</sub> is next iter)
tmix	X	X	number	end of each subhour	–
wen	X	X	number	end of each subhour	–
cmix	X	X	number	end of each subhour	–
dtMixEn	X	X	number	end of each subhour	–
ten	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
cen	X	X	number	end of each subhour	—
men	X	X	number	end of each subhour	—
tex	X	X	number	end of each subhour	—
wex	X	X	number	end of each subhour	—
tex1	X	X	number	end of each subhour	—
dtExSen	X	X	number	end of each subhour	—
tSen	X	X	number	end of each subhour	—
dtSenS	X	X	number	end of each subhour	—
aTs	X	X	number	end of each subhour	—
aWs	X	X	number	end of each subhour	—
trNx	X	X	number	end of each subhour	—
wrNx	X	X	number	end of each subhour	—
crNx	X	X	number	end of each subhour	—
cMxnx	X	X	number	end of each subhour	—
frFanOnNx	X	X	number	end of each subhour	—
leakCOnNx	X	X	number	end of each subhour	—
tr1Nx	X	X	number	end of each subhour	—

Name	Input?	Runtime?	Type	Variability	Description
wr1Nx	X	X	number	end of each subhour	–
cr1Nx	X	X	number	end of each subhour	–
tr2Nx	X	X	number	end of each subhour	–
uUseAr	X	X	unrecognized	end of each subhour	‘or’ of tu.usear’s at refine() entry, for detecting pegged terminals, set in zrat, tentative.
fcc	X	X	integer number	end of each hour	True if fan cycles: fan runs only fraction of subhour requested by control terminal, else off.
isZNorZN2	X	X	integer number	end of each hour	True if ahtssp is zn or zn2 this hour. 5-95.
tsSp1	X	X	number	end of each subhour	–
tsFullFlow	X	X	number	end of each subhour	–
ecoEnabled	X	X	integer number	end of each subhour	True if economizer present and currently enabled
coilLockout	X	X	integer number	end of each subhour	True if cooling coil disabled by full-open non-integrated economizer
po	X	X	number	end of each subhour	Current fraction outside air
coilUsed	X	X	unrecognized	end of each subhour	Coil in use, docoils to coilsendsubhr: cunone, cuheat, or cucool. 12-3-92.
fanF	X	X	number	end of each subhour	“fan factor” used in determining current max flows. reduce when fan overloads.
fanFMax	X	X	number	end of each subhour	Fanf value for full flow: max tu vfm <sub>x</sub> /vfd <sub>s</sub> , reflecting both vfm <sub>xh</sub> ’s & vfm <sub>xc</sub> ’s.
fanLimited	X	X	integer number	end of each subhour	True if using full capacity of fan without getting desired flow
coilLimited	X	X	integer number	end of each subhour	True if using full capacity of available coil without getting desired delta-t
tPossH	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
tPossC	X	X	number	end of each subhour	–
ahClf	X	X	integer number	end of each subhour	Call-flag: set nz if must call ahcompute so it can test tr,cr etc to see if computation needed.
ahPtf	X	X	integer number	end of each subhour	Compute-flag: set if must call ahcompute and it should unconditionally recompute this ah:
ahPtf2	X	X	integer number	end of each subhour	Secondary flag for compute only after zones computed again, for non-convergence.

### 6.3 Battery

@Battery[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
meter	X	X	integer number	input time	Meter for system electricity production
endUse	X	X	integer number	autosize and simulate phase start time	End use of energy. defaults to “bt”
useUsrChg	X	X	integer number	run start time (of each phase, autoSize or simulate)	Yes: user specifies charge request;
controlAlg	X	X	unrecognized	hourly	Control algorithm choice
maxCap	X	X	number	run start time (of each phase, autoSize or simulate)	Maximum (usable) battery capacity in kwh
initSOE	X	X	number	run start time (of each phase, autoSize or simulate)	Initial state of energy (0 <= soe <= 1)
initCycles	X	X	number	run start time (of each phase, autoSize or simulate)	Initial number of cycles on battery (>= 0)
chgEff	X	X	number	hourly	Battery efficiency while charging
dschgEff	X	X	number	hourly	Battery efficiency while discharging (fraction)
maxChgPwr	X	X	number	hourly	Maximum allowable charging power (kw)
maxDschgPwr	X	X	number	hourly	Maximum discharge power (kw)

Name	Input?	Runtime?	Type	Variability	Description
chgReq	X	X	number	end of each hour	Battery charge request (kw) +=charge;-=discharge
soeBegIvl	X	X	number	hourly	Battery soe at beginning of interval
loadSeen	X	X	number	end of each hour	The adjusted load seen by the battery for current hour (kw)
soe	X	X	number	end of each hour	Battery state of energy (soe) ( $0 \leq \text{soe} \leq 1$ )
soelh	X	X	number	hourly	Battery state of energy (soe) at end of prior hour
cycles	X	X	number	end of each hour	Accumulated battery cycles
cycleslh	X	X	number	hourly	Accumulated battery cycles, end of prior hour
energy	X	X	number	end of each hour	Current amount of energy in battery (kwh)
energylh	X	X	number	hourly	Amount of energy in battery (kwh)

## 6.4 boiler (owner: heatPlant)

@boiler[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
blrCap	X	X	number	autosize and simulate phase start time	Capacity (btuh). required input.
blrEffR	X	X	number	autosize and simulate phase start time	Efficiency at steady-state full load, default .80.
blrEirR	X	X	number	autosize and simulate phase start time	Energy input ratio (1/eff): alternate input; used internally.
blrPyEi.k[0]	X	X	number	autosize and simulate phase start time	–
blrPyEi.k[1]	X	X	number	autosize and simulate phase start time	–
blrPyEi.k[2]	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
blrPyEi.k[3]	X	X	number	autosize and simulate phase start time	–
blrPyEi.k[4]	X	X	number	autosize and simulate phase start time	–
mtri	X	X	integer number	input time	Subscript of mtr to which to charge boiler input power, default none
blrp.gpm	X	X	number	run start time (of each phase, autoSize or simulate)	–
blrp.hdLoss	X	X	number	autosize and simulate phase start time	–
blrp.motEff	X	X	number	autosize and simulate phase start time	–
blrp.hydEff	X	X	number	autosize and simulate phase start time	–
blrp.ovrunF	X	X	number	run start time (of each phase, autoSize or simulate)	–
blrp.mtri	X	X	integer number	autosize and simulate phase start time	Subscript of mtr to which to charge boiler input power, default none
blrp.mw	X	X	number	run start time (of each phase, autoSize or simulate)	–
blrp.q	X	X	number	run start time (of each phase, autoSize or simulate)	Current output power level (excluding pump heat), share of total of connected coils & hx's
blrp.p	X	X	number	run start time (of each phase, autoSize or simulate)	Current input power
auxOn	X	X	number	hourly	Addl input energy used in proportion to plr when on, default 0, hourly vbl for future flexblty.

Name	Input?	Runtime?	Type	Variability	Description
auxOnMtri	X	X	integer number	input time	Mtr to which to charge "auxon"
auxOff	X	X	number	hourly	Addl input energy when off for part or all of subhr (proportional to 1-plr), for unforeseen uses.
auxOffMtri	X	X	integer number	input time	Mtr for "auxoff"
auxOnAtall	X	X	number	hourly	Addl input energy used in toto when blr on for any part of subhour, for unforeseen uses.
auxOnAtallMtri	X	X	integer number	input time	Mtr for "auzonatall"
auxFullOff	X	X	number	hourly	Additional input energy when off for entire subhour (as opposed to in proportion to 1-plr).
auxFullOffMtri	X	X	integer number	input time	Mtr to which auxfulloff is charged, default c.mtri.
nxBlr4hp	X	X	integer number	run start time (of each phase, autoSize or simulate)	0 or subscript of next boiler for same heatplant. 1st is heatplant.blr1.
used	X	X	integer number	run start time (of each phase, autoSize or simulate)	During input checking (cncult6.cpp), true if a stage uses this boiler
blrMode	X	X	unrecognized	end of each subhour	Mode this subhour: off or on. can be on with 0 q if in heatplant's 1st stage.
plr	X	X	number	end of each subhour	Part load ratio
q	X	X	number	end of each subhour	Current output power level (excluding pump heat), share of total of connected coils & hx's
p	X	X	number	end of each subhour	Current input power



Name	Input?	Runtime?	Type	Variability	Description
pAuxOn	X	X	number	end of each subhour	Blr-on proportional aux power this subhour
pAuxOff	X	X	number	end of each subhour	Blr-off proportional aux power this subhour
pAuxOnAtall	X	X	number	end of each subhour	Blr on-at-all aux power this subhour
pAuxFullOff	X	X	number	end of each subhour	Auxfulloff power this subhour

## 6.5 chiller (owner: coolPlant)

@chiller[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
chCapDs	X	X	number	autosize and simulate phase start time	Capacity at chdsts,chdstend, btuh. required. negative internally. nils capdsn.
chTsDs	X	X	number	autosize and simulate phase start time	Temp leaving chiller at which chcapds applies, default 44. nils twsudsn.
chTcndDs	X	X	number	autosize and simulate phase start time	Temp entering condenser (twodel value) for chcapds, default 85. nils twcnddsn.
chPyCapT.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
chPyCapT.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
chPyCapT.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
chPyCapT.k[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
chPyCapT.k[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyCapT.k[5]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyCapT.k[6]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chCop	X	X	number	autosize and simulate phase start time	Full-load coefficient of performance (output btu/input btu) @ chtsds/chtcndds, reflecting
chEirDs	X	X	number	run start time (of each phase, autoSize or simulate)	Full-load eir (energy input ratio) @ chtsds/chtcndds, relecting motor and chiller efficiency.
chPyEirT.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirT.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirT.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirT.k[3]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirT.k[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
chPyEirT.k[5]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirT.k[6]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirU1.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirU1.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirU1.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirU1.k[3]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chPyEirU1.k[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—
chMinUnldPlr	X	X	number	autosize and simulate phase start time	Min unloading loading part load ratio, default 0.1. nils minunldplr.
chMinFsldPlr	X	X	number	autosize and simulate phase start time	Min false loading part load ratio, default 0.1. nils minfsldplr. must be <= chminunldplr.
chMotEff	X	X	number	autosize and simulate phase start time	Motor efficiency (poorly named), default 1.0, nils motoreff, used only to determine
mtri	X	X	integer number	input time	Meter name (“chmtr”) for accumulating compressor energy used by chiller,

Name	Input?	Runtime?	Type	Variability	Description
chpp.gpm	X	X	number	run start time (of each phase, autoSize or simulate)	–
chpp.hdLoss	X	X	number	autosize and simulate phase start time	–
chpp.motEff	X	X	number	autosize and simulate phase start time	–
chpp.hydEff	X	X	number	autosize and simulate phase start time	–
chpp.ovrunF	X	X	number	run start time (of each phase, autoSize or simulate)	–
chpp.mtri	X	X	integer number	autosize and simulate phase start time	Meter name (“chmtr”) for accumulating compressor energy used by chiller,
chpp.mw	X	X	number	run start time (of each phase, autoSize or simulate)	–
chpp.q	X	X	number	run start time (of each phase, autoSize or simulate)	This chiller’s current primary output power to pri loop
chpp.p	X	X	number	run start time (of each phase, autoSize or simulate)	Compressor power input. also see chpp.p, chcp.p. (niles cndpmppwrin, prmpmppwrin, totpwrin)
chcp.gpm	X	X	number	run start time (of each phase, autoSize or simulate)	–
chcp.hdLoss	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
chcp.motEff	X	X	number	autosize and simulate phase start time	–
chcp.hydEff	X	X	number	autosize and simulate phase start time	–
chcp.ovrunF	X	X	number	run start time (of each phase, autoSize or simulate)	–
chcp.mtri	X	X	integer number	autosize and simulate phase start time	Meter name (“chmtr”) for accumulating compressor energy used by chiller,
chcp.mw	X	X	number	run start time (of each phase, autoSize or simulate)	–
chcp.q	X	X	number	run start time (of each phase, autoSize or simulate)	This chiller's current primary output power to pri loop
chcp.p	X	X	number	run start time (of each phase, autoSize or simulate)	Compressor power input. also see chpp.p, chcp.p. (niles cndpmppwrin, prmpmppwrin, totpwrin)
auxOn	X	X	number	hourly	Addl input energy used in proportion to plr when on, default 0, hourly vbl for future flexblty.
auxOnMtri	X	X	integer number	input time	Mtr to which to charge “auxon”
auxOff	X	X	number	hourly	Addl input energy when off for part or all of subhr (proportional to 1-plr), for unforeseen uses.
auxOffMtri	X	X	integer number	input time	Mtr for “auxoff”
auxOnAtall	X	X	number	hourly	Addl input energy used in toto when chiller on for any part of subhour, for unforeseen uses.

Name	Input?	Runtime?	Type	Variability	Description
auxOnAtallMtri	X	X	integer number	input time	Mtr for “auxonatal”
auxFullOff	X	X	number	hourly	Additional input energy when off for entire subhour (as opposed to in proportion to 1-plr).
auxFullOffMtri	X	X	integer number	input time	Mtr to which auxfulloff is charged, default c.mtri.
nxCh4cp	X	X	integer number	run start time (of each phase, autoSize or simulate)	0 or subscript of next chiller in same coolplant. 1st is coolplant.ch1.
used	X	X	integer number	run start time (of each phase, autoSize or simulate)	Non-0 if a coolplant uses this chiller – else warning
eirMinUnldPlr	X	X	number	run start time (of each phase, autoSize or simulate)	Chpyeirul(minunldplr): precomputed energy input corr for false loading, prorated for cycling
chMode	X	X	unrecognized	end of each subhour	C_offonch_off or _on: whether this chiller is running, set by staging code.
cap	X	X	number	end of each subhour	–
q	X	X	number	end of each subhour	This chiller's current primary output power to pri loop
p	X	X	number	end of each subhour	Compressor power input. also see chpp.p, chcp.p. (niles cndpmppwrin, prmpmppwrin, totpwrin)
pAuxOn	X	X	number	end of each subhour	Chiller-on proportional aux power this subhour
pAuxOff	X	X	number	end of each subhour	Chiller-off proportional aux power this subhour
pAuxOnAtall	X	X	number	end of each subhour	Chiller on-at-all aux power this subhour
pAuxFullOff	X	X	number	end of each subhour	Auxfulloff power this subhour

## 6.6 construction

@construction[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
conU	X	–	number	input time	U-value. entered by user or calculated from associated layers (lrs). 0 allowed.
nLr	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or number of layers (in lr rat). layers are entered in order from inside out.
nFrmLr	X	–	integer number	run start time (of each phase, autoSize or simulate)	# framed layers: error if > 1; is-framed flag.
r	X	–	number	run start time (of each phase, autoSize or simulate)	Thermal resistance of layers accumulated here for conu
hc	X	–	number	run start time (of each phase, autoSize or simulate)	Accumulated heat capacity per square foot
rNom	X	–	number	run start time (of each phase, autoSize or simulate)	Nominal r value

## 6.7 coolPlant

@coolPlant[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
cpSched	X	X	unrecognized	hourly	Schedule, hourly choice of off, avail (default), on.
cpTsSp	X	X	number	hourly	Supply temp cooling setpoint, hourly variable, default 44.
cpPipeLossF	X	X	number	autosize and simulate phase start time	Pipe “loss”: heat gain equal to this fraction of largest stage <– change **
cpTowi	X	X	integer number	input time	Subscript of towerplant supporting this coolplant. input as name “cptowerplant”. rqd.
cpStage1[0]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[1]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[2]	X	X	integer number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
cpStage1[3]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[4]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[5]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[6]	X	X	integer number	autosize and simulate phase start time	–
cpStage1[7]	X	X	integer number	autosize and simulate phase start time	–
cpStage2[0]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[1]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[2]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[3]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[4]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[5]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[6]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage2[7]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no cpstage values entered:
cpStage3[0]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[1]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[2]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[3]	X	X	integer number	autosize and simulate phase start time	–



Name	Input?	Runtime?	Type	Variability	Description
cpStage3[4]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[5]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[6]	X	X	integer number	autosize and simulate phase start time	–
cpStage3[7]	X	X	integer number	autosize and simulate phase start time	–
cpStage4[0]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[1]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[2]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[3]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[4]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[5]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[6]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage4[7]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none(0).
cpStage5[0]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[1]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[2]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[3]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[4]	X	X	integer number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
cpStage5[5]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[6]	X	X	integer number	autosize and simulate phase start time	–
cpStage5[7]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[0]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[1]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[2]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[3]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[4]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[5]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[6]	X	X	integer number	autosize and simulate phase start time	–
cpStage6[7]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[0]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[1]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[2]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[3]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[4]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[5]	X	X	integer number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
cpStage7[6]	X	X	integer number	autosize and simulate phase start time	–
cpStage7[7]	X	X	integer number	autosize and simulate phase start time	–
ch1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st chiller in this coolplant. next is chiller.nxch4cp.
ah1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st ah with chw coil served by this coolplant. next is ah.ahcc.nxah4cp.
nxCp4tp	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of next coolplant using same towerplant. 1st is towerplant.c1.
mwDsCoils	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPPQ[6]	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
stgCPQ[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCPQ[6]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPMw[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
stgPMw[6]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCMw[6]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgN	X	X	integer number	run start time (of each phase, autoSize or simulate)	Max+1 used stage subscript 1-7 (used stages need not be contiguous)
stgMxCap	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript 0-6 of stage with most design power
mxCapDs	X	X	number	run start time (of each phase, autoSize or simulate)	–
mxPMw	X	X	number	run start time (of each phase, autoSize or simulate)	–
mxPMwOv	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
mxCondQ	X	X	number	run start time (of each phase, autoSize or simulate)	–
mxCondGpm	X	X	number	run start time (of each phase, autoSize or simulate)	–
qPipeLoss	X	X	number	run start time (of each phase, autoSize or simulate)	–
cpTs	X	X	number	end of each subhour	–
q	X	X	number	end of each subhour	–
qTow	X	X	number	end of each subhour	–
tTow	X	X	number	end of each subhour	–
mwTow	X	X	number	end of each subhour	–
tCnd	X	X	number	end of each subhour	–
cpClf	X	X	integer number	end of each subhour	Call-flag: set nz if must call cpcompute so it can test tr, etc to see if computation needed.
cpPtf	X	X	integer number	end of each subhour	Compute-flag: set if must call cpcompute and it should unconditionally recompute this plant
cpMode	X	X	unrecognized	end of each subhour	Mode this subhour: off or on: per cpsched; per demand for avail. set in cpeestimate, cpcompute.
qLoadNx	X	X	number	end of each subhour	–
qLoad	X	X	number	end of each subhour	–
tr	X	X	number	end of each subhour	–
stgi	X	X	integer number	end of each subhour	Stage in use, 0-6 for cpstage1-7.
qNeed	X	X	number	end of each subhour	–
cap	X	X	number	end of each subhour	–
plr	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
puteTs	X	X	number	end of each subhour	–
cpTsSpPr	X	X	number	end of each subhour	For cpeestimate
cpTsEstPr	X	X	number	end of each subhour	For cpeestimate
cpModePr	X	X	unrecognized	end of each subhour	For cpcompute
trMxPr	X	X	number	end of each subhour	For cpcompute: tr-assuming-max-flow when last computed
qLoadPr	X	X	number	end of each subhour	For cpcompute
mwTowPr	X	X	number	end of each subhour	For cpcompute, set by tpcompute
tTowPr	X	X	number	end of each subhour	For cpcompute, set by tpcompute

## 6.8 DESCOND

@DESCOND[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
doy	X	X	integer	input time	Calc date for this descond (1-365)
DB	X	X	number	input time	Design dry-bulb temp, f
MCDBR	X	X	number	input time	Coincident daily db range, f
MCWB	X	X	number	input time	Coincident wet-bulb temp, f
MCWBR	X	X	number	input time	Coincident daily wb range, f
wndSpd	X	X	number	input time	Wind speed, mph
tauB	X	X	number	input time	Beam tau
tauD	X	X	number	input time	Diffuse tau
ebnSlrNoon	X	X	number	input time	Solar noon beam normal, btuh/ft2
edhSlrNoon	X	X	number	input time	Solar noon diffuse horiz, btuh/ft2

## 6.9 DHWDayUse

@DHWDayUse[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–

Name	Input?	Runtime?	Type	Variability	Description
mult	X	X	number	hourly	Multiplier applied to all child dhwise wuflows
wuSsBeg	X	X	integer number	run start time (of each phase, autoSize or simulate)	Initial ss
wuSsEnd	X	X	integer number	run start time (of each phase, autoSize or simulate)	Last ss+1
wuCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Count of child dhwses

## 6.10 DHWHeater (owner: DHWSys)

@DHWHeater[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	number	run start time (of each phase, autoSize or simulate)	Count of identical water heaters (default 1)
heatSrc	X	X	unrecognized	input time	Heat source
type	X	X	unrecognized	input time	Heater type
desc	X	X	string	input time	Probe-able description text
fcn	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Function of this dhwheater per whfcnxxx enum
ashpTy	X	X	unrecognized	input time	Air source heat pump type, required iff ashpx, else ignored
znTi	X	X	integer number	input time	Dhwheater location zone re tank loss
tEx	X	X	number	subhourly	–
ashpSrcZnTi	X	X	integer number	input time	Ashp source zone
ashpTsrc	X	X	number	subhourly	Ashp source temperature, f
ashpResUse	X	X	number	input time	Resistance heat parameter for
vol	X	X	number	run start time (of each phase, autoSize or simulate)	Actual storage tank vol, gal (not rated)



Name	Input?	Runtime?	Type	Variability	Description
UA	X	X	number	run start time (of each phase, autoSize or simulate)	Hpwh-type tank ua, btuh/f
insulR	X	X	number	run start time (of each phase, autoSize or simulate)	Hpwh-type tank insulation resistance, hr-f/btuh
inHtSupply	X	X	number	input time	Fractional tank height of supply inlet (0=bottom, 1=top)
inHtLoopRet	X	X	number	input time	Fractional tank height of loop return inlet(s) (0=bottom, 1=top)
EF	X	X	number	input time	Rated energy factor
LDEF	X	X	number	input time	Load-dependent energy factor
UEF	X	X	number	input time	Rated uniform energy factor
ratedFlow	X	X	number	input time	Max rated flow per uef test, gpm
annualFuel	X	X	number	input time	Annual fuel use per uef method, therms/yr
annualElec	X	X	number	input time	Annual electricity use per uef method, kwh/yr
cycLossFuel	X	X	number	run start time (of each phase, autoSize or simulate)	Derived startup fuel use (=cyclic loss) for instuef, btu/cycle
cycLossElec	X	X	number	run start time (of each phase, autoSize or simulate)	Derived startup electricity use (=cyclic loss) for instuef, btu/cycle
maxFlowX	X	X	number	run start time (of each phase, autoSize or simulate)	Derived max flow for instuef, gal/tick-f
maxInpX	X	X	number	run start time (of each phase, autoSize or simulate)	Input at max flow, btu/tick
eff	X	X	number	input time	Efficiency (aka recovery efficiency)

Name	Input?	Runtime?	Type	Variability	Description
SBL	X	X	number	input time	Standby loss, btuh
pilotPwr	X	X	number	hourly	Pilot light power, btuh
parElec	X	X	number	hourly	Parasitic electric use, w
tHWOOut	X	X	number	hourly	–
stbyTicks	X	X	unrecognized	subhourly	Time since last draw, for hpwh and instuef, ticks
loadCFwdF	X	X	number	input time	Load carry-forward allowed (user input frac of capacity)
loadCFwdMax	X	X	number	input time	Max load carry-forward energy (from wh_loadcfwdf), btu
loadCFwd	X	X	number	subhourly	Current load carry forward, btu
nTickFullLoad	X	X	number	subhourly	Instuef: current subhour equiv full load ticks (fractional)
nColdStarts	X	X	number	subhourly	Instuef: current subhour # of cold startups
effSh	X	X	number	end of each subhour	Current subhour efficiency, used to support former hourly
operElec	X	X	number	run start time (of each phase, autoSize or simulate)	Electrical power during operation at rating conditions, btuh
stbyElec	X	X	number	run start time (of each phase, autoSize or simulate)	Electrical power during standby, w
resHtPwr	X	X	number	input time	Upper element resistance heating power, w
resHtPwr2	X	X	number	input time	Lower element resistance heating power, w
HPWH.HSCount	X	X	unrecognized	end of each subhour	# of hpwh heatsources in use for current config

Name	Input?	Runtime?	Type	Variability	Description
HPWH.tEx	X	X	number	end of each subhour	–
HPWH.tASHPSrc	X	X	number	end of each subhour	Temp of heat pump air source, f
HPWH.qTXTick	X	X	number	end of each subhour	Current tick extra tank heat added lower tank nodes, btu
HPWH.nQTXNodes	X	X	unrecognized	end of each subhour	# of tank 1/12s used in hw_qtx extra tank heat
HPWH.fMixUse	X	X	number	end of each subhour	Factor for draw adjustment re hpwh setpoint > dhwsys::ws_tuse
HPWH.fMixRL	X	X	number	end of each subhour	Factor for loop return flow adjustment re hpwh setpoint > dhwsys::ws_tuse
HPWH.inElec[0]	X	X	number	end of each subhour	–
HPWH.inElec[1]	X	X	number	end of each subhour	–
HPWH.HPWHxBU	X	X	number	end of each subhour	–
HPWH.qEnv	X	X	number	end of each subhour	–
HPWH.qLoss	X	X	number	end of each subhour	–
HPWH.qHW	X	X	number	end of each subhour	–
HPWH.qTX	X	X	number	end of each subhour	Current subhr extra heat tank heat, kwh (not btu)
HPWH.tankTempSet	X	X	unrecognized	end of each subhour	Nz iff hpwh tank temp has been initialized
HPWH.tankHCNominal	X	X	number	end of each subhour	Nominal hpwh tank heat content, kwh (at 40 c)
HPWH.tankHCStart	X	X	number	end of each subhour	Current step starting tank heat content, kwh
HPWH.tHWOutF	X	X	number	end of each subhour	Current substep working total re calc of hw_thwout

Name	Input?	Runtime?	Type	Variability	Description
HPWH.nzDrawCount	X	X	unrecognized	end of each subhour	–
HPWH.tHWOOut	X	X	number	end of each subhour	–
HPWH.bWriteCSV	X	X	unrecognized	end of each subhour	–
HPWH.balErrCount	X	X	unrecognized	end of each subhour	–
HPWH.balErrMax	X	X	number	end of each subhour	Maximum substep energy balance error for run, kwh
HPWHxBU	X	X	number	run start time (of each phase, autoSize or simulate)	–
qEnv	X	X	number	end of each subhour	–
qLoss	X	X	number	end of each subhour	–
qHW	X	X	number	end of each subhour	–
nzDrawCount	X	X	unrecognized	end of each subhour	–
bWriteCSV	X	X	unrecognized	end of each hour	–
totHARL	X	X	number	hourly	Cumulative recovery load at heater, btu
hrCount	X	X	unrecognized	hourly	# of hourly values included in wh_totHarl
totOut	X	X	number	hourly	Total heat delivered to hot water, btu
inElecSh	X	X	number	end of each subhour	Primary electricity (including wh_parelec) (note not kwh)
inElecBUSh	X	X	number	end of each subhour	Backup electricity (>0 only for hpwh resistance heat)
inElecXBUSH	X	X	number	end of each subhour	“extra” backup (reheating to maintain ws_tuse)
inFuelSh	X	X	number	end of each subhour	Fuel (including wh_pilotpwr)
inElec	X	X	number	end of each hour	–

Name	Input?	Runtime?	Type	Variability	Description
inElecBU	X	X	number	end of each hour	Backup electricity (>0 only for hpwh resistance heat)
inElecXBU	X	X	number	end of each hour	“extra” backup (reheating to maintain ws_tuse)
inFuel	X	X	number	end of each hour	Fuel (including wh_pilotpwr)
inElecTot	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total electricity, btu
inFuelTot	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total fuel, btu
elecMtri	X	X	integer number	input time	Meter for system electricity use (default = parent ws_elecmttri)
fuelMtri	X	X	integer number	input time	Meter for system fuel use (default = parent ws_electmttri)
xBUEndUse	X	X	integer number	input time	Wh_elecmttri end use for separate accounting of wh_hpwhxbu
unMetSh	X	X	unrecognized	end of each hour	Count of subhrs in this hour
unMetHrs	X	X	unrecognized	end of run (of each phase, autoSize or simulate)	Annual count of hrs having any wh_unmetsh
balErrCount	X	X	unrecognized	end of each subhour	–

## 6.11 DHWHeatRec (owner: DHWSys)

@DHWHeatRec[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	integer number	input time	Multiplier
hwEndUse	X	X	integer number	input time	End use source for this device
type	X	X	unrecognized	input time	Type: c_dwhrtych_

Name	Input?	Runtime?	Type	Variability	Description
nFXDrain	X	X	integer number	input time	Number of fixtures (of type wr_whenduse) draining
nFXCold	X	X	integer number	input time	Number of fixtures (of type wr_whenduse) draining
feedsWH	X	X	integer number	input time	Iff c_noyesch_yes, potable output is plumbed to water heater
effRated	X	X	number	hourly	Rated effectiveness (generally csa rating value)
tdInDiff	X	X	number	hourly	Drain-side inlet water temp drop from fixture mixed temp, f
tdInWarmup	X	X	number	hourly	Drain-side inlet temp during warmup portion of draw
eff	X	X	number	end of each subhour	Effectiveness under current conditions
tpO	X	X	number	end of each subhour	Most recent potable-side output temp, f
vp	X	X	number	end of each subhour	Most recent potable-side flow, gpm

## 6.12 DHWLoop (owner: DHWSys)

@DHWLoop[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	integer number	input time	Multiplier: number of identical loops
wlpCount	X	X	integer number	run start time (of each phase, autoSize or simulate)	Total # of child dhwlooppumps
flow	X	X	number	hourly	Current loop recirculation max flow, gpm
runF	X	X	number	hourly	Current hour recirculation operation fraction

Name	Input?	Runtime?	Type	Variability	Description
tIn1	X	X	number	hourly	Entering temperature at 1st dhwloopseg
fUA	X	X	number	input time	Ua adjustment factor for child dhwloopsegs
lossMakeupPwr	X	X	number	hourly	Loss makeup heating (electrical) power, w
lossMakeupEff	X	X	number	hourly	Loss makeup heating efficiency
elecMtri	X	X	integer number	input time	Meter for loop electricity use (default = parent ws_elecetri)
segTotals.count	X	X	number	run start time (of each phase, autoSize or simulate)	–
segTotals.len	X	X	number	run start time (of each phase, autoSize or simulate)	–
segTotals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	–
segTotals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	–
segTotals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	–
branchTotals.count	X	X	number	run start time (of each phase, autoSize or simulate)	–
branchTotals.len	X	X	number	run start time (of each phase, autoSize or simulate)	–
branchTotals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	–
branchTotals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
branchTotals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	–
volRL	X	X	number	end of each hour	Current hour volume returned to water heater, gal
qLiqLP	X	X	number	end of each hour	Heat added to liquid by dhwlooppump(s), btu
HRLL	X	X	number	end of each hour	Current hour loop seg pipe losses, btu
HRLLnet	X	X	number	end of each hour	Wl_hrll adjusted for pump by pump heat and
HRBL	X	X	number	end of each hour	Current hour branch pipe loss, btu
t24WL	X	X	number	end of each hour	Current hour branch waste loss volume, gal
tRL	X	X	number	end of each hour	Current hour average return temp, f

### 6.13 DHWLoopBranch (owner: DHWLoopSeg)

@DHWLoopBranch[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
absSlr	X	X	number	subhourly	–
awAbsSlr	X	X	number	subhourly	–
epsLW	X	X	number	subhourly	–
zi	X	X	integer number	subhourly	–
F	X	X	number	subhourly	–
Fp	X	X	number	subhourly	–
frRad	X	X	number	subhourly	–
fSky	X	X	number	subhourly	–
fAir	X	X	number	subhourly	–
hcNat	X	X	number	end of each subhour	–
hcFrc	X	X	number	end of each subhour	–
hcMult	X	X	number	end of each subhour	–
hxa	X	X	number	end of each subhour	–



Name	Input?	Runtime?	Type	Variability	Description
hxr	X	X	number	end of each subhour	—
hxtot	X	X	number	end of each subhour	—
uRat	X	X	number	end of each subhour	—
fRat	X	X	number	end of each subhour	—
cx	X	X	number	end of each subhour	—
sgTarg.bm	X	X	number	end of each subhour	—
sgTarg.df	X	X	number	end of each subhour	—
sgTarg.tot	X	X	number	end of each subhour	—
sg	X	X	number	end of each subhour	—
tSrf	X	X	number	end of each subhour	—
tSrfls	X	X	number	subhourly	—
qrAbs	X	X	number	end of each subhour	—
txa	X	X	number	end of each subhour	—
txr	X	X	number	end of each subhour	—
txe	X	X	number	end of each subhour	—
w	X	X	number	end of each subhour	—
qSrf	X	X	number	end of each subhour	—
pDS	X	X	unrecognized	subhourly	—
len	X	X	number	input time	—
size	X	X	number	input time	—
insulK	X	X	number	input time	—
insulThk	X	X	number	input time	—
exH	X	X	number	input time	—
exCnd	X	X	integer number	input time	—
exT	X	X	number	hourly	—
totals.count	X	X	number	run start time (of each phase, autoSize or simulate)	—
totals.len	X	X	number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
totals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	–
fRhoCpX	X	X	number	run start time (of each phase, autoSize or simulate)	–
fvf	X	X	number	end of each hour	–
tIn	X	X	number	end of each hour	–
tOut	X	X	number	end of each hour	–
PLWF	X	X	number	end of each hour	–
PLCD	X	X	number	end of each hour	–
PL	X	X	number	end of each hour	–
mult	X	X	number	input time	# of identical branches
fUA	X	X	number	input time	Ua adjustment factor for this branch
fWaste	X	X	number	hourly	Waste fraction
flow	X	X	number	hourly	Assumed flow during use, gpm
HBUL	X	X	number	end of each hour	... when water in use
HBWL	X	X	number	end of each hour	... waste loss
t24WL	X	X	number	end of each hour	... waste loss volume, gal

## 6.14 DHWLoopHeater

@DHWLoopHeater[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
mult	–	X	number	run start time (of each phase, autoSize or simulate)	–
heatSrc	–	X	unrecognized	input time	–
type	–	X	unrecognized	input time	–
desc	–	X	string	input time	–

Name	Input?	Runtime?	Type	Variability	Description
fcn	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
ashpTy	–	X	unrecognized	input time	–
znTi	–	X	integer number	input time	–
tEx	–	X	number	subhourly	–
ashpSrcZnTi	–	X	integer number	input time	–
ashpTSrc	–	X	number	subhourly	–
ashpResUse	–	X	number	input time	–
vol	–	X	number	run start time (of each phase, autoSize or simulate)	–
UA	–	X	number	run start time (of each phase, autoSize or simulate)	–
insulR	–	X	number	run start time (of each phase, autoSize or simulate)	–
inHtSupply	–	X	number	input time	–
inHtLoopRet	–	X	number	input time	–
EF	–	X	number	input time	–
LDEF	–	X	number	input time	–
UEF	–	X	number	input time	–
ratedFlow	–	X	number	input time	–
annualFuel	–	X	number	input time	–
annualElec	–	X	number	input time	–
cycLossFuel	–	X	number	run start time (of each phase, autoSize or simulate)	–
cycLossElec	–	X	number	run start time (of each phase, autoSize or simulate)	–
maxFlowX	–	X	number	run start time (of each phase, autoSize or simulate)	–
maxInpX	–	X	number	run start time (of each phase, autoSize or simulate)	–
eff	–	X	number	input time	–
SBL	–	X	number	input time	–
pilotPwr	–	X	number	hourly	–
parElec	–	X	number	hourly	–
tHWOut	–	X	number	hourly	–
stbyTicks	–	X	unrecognized	subhourly	–

Name	Input?	Runtime?	Type	Variability	Description
loadCFwdF	–	X	number	input time	–
loadCFwdMax	–	X	number	input time	–
loadCFwd	–	X	number	subhourly	–
nTickFullLoad	–	X	number	subhourly	–
nColdStarts	–	X	number	subhourly	–
effSh	–	X	number	end of each subhour	–
operElec	–	X	number	run start time (of each phase, autoSize or simulate)	–
stbyElec	–	X	number	run start time (of each phase, autoSize or simulate)	–
resHtPwr	–	X	number	input time	–
resHtPwr2	–	X	number	input time	–
HPWH.HSCount	–	X	unrecognized	end of each subhour	–
HPWH.tEx	–	X	number	end of each subhour	–
HPWH.tASHPSrc	–	X	number	end of each subhour	–
HPWH.qTXTick	–	X	number	end of each subhour	–
HPWH.nQTXNodes	–	X	unrecognized	end of each subhour	–
HPWH.fMixUse	–	X	number	end of each subhour	–
HPWH.fMixRL	–	X	number	end of each subhour	–
HPWH.inElec[0]	–	X	number	end of each subhour	–
HPWH.inElec[1]	–	X	number	end of each subhour	–
HPWH.HPWHxBU	–	X	number	end of each subhour	–
HPWH.qEnv	–	X	number	end of each subhour	–
HPWH.qLoss	–	X	number	end of each subhour	–
HPWH.qHW	–	X	number	end of each subhour	–
HPWH.qTX	–	X	number	end of each subhour	–
HPWH.tankTempSet	–	X	unrecognized	end of each subhour	–
HPWH.tankHCNominal	–	X	number	end of each subhour	–
HPWH.tankHCStart	–	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
HPWH.tHWOuF	–	X	number	end of each subhour	–
HPWH.nzDrawCount	–	X	unrecognized	end of each subhour	–
HPWH.tHWOuT	–	X	number	end of each subhour	–
HPWH.bWriteCSV	–	X	unrecognized	end of each subhour	–
HPWH.balErrCount	–	X	unrecognized	end of each subhour	–
HPWH.balErrMax	–	X	number	end of each subhour	–
HPWHxBU	–	X	number	run start time (of each phase, autoSize or simulate)	–
qEnv	–	X	number	end of each subhour	–
qLoss	–	X	number	end of each subhour	–
qHW	–	X	number	end of each subhour	–
nzDrawCount	–	X	unrecognized	end of each subhour	–
bWriteCSV	–	X	unrecognized	end of each hour	–
totHARL	–	X	number	hourly	–
hrCount	–	X	unrecognized	hourly	–
totOut	–	X	number	hourly	–
inElecSh	–	X	number	end of each subhour	–
inElecBUSh	–	X	number	end of each subhour	–
inElecXBUSh	–	X	number	end of each subhour	–
inFuelSh	–	X	number	end of each subhour	–
inElec	–	X	number	end of each hour	–
inElecBU	–	X	number	end of each hour	–
inElecXBU	–	X	number	end of each hour	–
inFuel	–	X	number	end of each hour	–
inElecTot	–	X	number	end of run (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
inFuelTot	–	X	number	end of run (of each phase, autoSize or simulate)	–
elecMtri	–	X	integer number	input time	–
fuelMtri	–	X	integer number	input time	–
xBUEndUse	–	X	integer number	input time	–
unMetSh	–	X	unrecognized	end of each hour	–
unMetHrs	–	X	unrecognized	end of run (of each phase, autoSize or simulate)	–
balErrCount	–	X	unrecognized	end of each subhour	–

### 6.15 DHWLoopPump (owner: DHWLoop)

@DHWLoopPump[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	integer number	input time	–
elecMtri	X	X	integer number	input time	–
pwr	X	X	number	hourly	–
liqHeatF	X	X	number	hourly	–
inElec	X	X	number	end of each hour	–
U0026: Internal error	–	–	ous class name 'DHWLo	opHeater':	–
there are TWO run	–	–	h that .what. Change	one of them.	–

### 6.16 DHWLoopSeg (owner: DHWLoop)

@DHWLoopSeg[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
absSlr	X	X	number	subhourly	–
awAbsSlr	X	X	number	subhourly	–
epsLW	X	X	number	subhourly	–
zi	X	X	integer number	subhourly	–
F	X	X	number	subhourly	–
Fp	X	X	number	subhourly	–
frRad	X	X	number	subhourly	–
fSky	X	X	number	subhourly	–
fAir	X	X	number	subhourly	–

Name	Input?	Runtime?	Type	Variability	Description
hcNat	X	X	number	end of each subhour	—
hcFrc	X	X	number	end of each subhour	—
hcMult	X	X	number	end of each subhour	—
hxa	X	X	number	end of each subhour	—
hxr	X	X	number	end of each subhour	—
hxtot	X	X	number	end of each subhour	—
uRat	X	X	number	end of each subhour	—
fRat	X	X	number	end of each subhour	—
cx	X	X	number	end of each subhour	—
sgTarg.bm	X	X	number	end of each subhour	—
sgTarg.df	X	X	number	end of each subhour	—
sgTarg.tot	X	X	number	end of each subhour	—
sg	X	X	number	end of each subhour	—
tSrf	X	X	number	end of each subhour	—
tSrfls	X	X	number	subhourly	—
qrAbs	X	X	number	end of each subhour	—
txa	X	X	number	end of each subhour	—
txr	X	X	number	end of each subhour	—
txe	X	X	number	end of each subhour	—
w	X	X	number	end of each subhour	—
qSrf	X	X	number	end of each subhour	—
pDS	X	X	unrecognized	subhourly	—
len	X	X	number	input time	—
size	X	X	number	input time	—
insulK	X	X	number	input time	—
insulThk	X	X	number	input time	—
exH	X	X	number	input time	—
exCnd	X	X	integer number	input time	—
exT	X	X	number	hourly	—

Name	Input?	Runtime?	Type	Variability	Description
totals.count	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.len	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	–
totals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	–
fRhoCpX	X	X	number	run start time (of each phase, autoSize or simulate)	–
fvf	X	X	number	end of each hour	–
tIn	X	X	number	end of each hour	–
tOut	X	X	number	end of each hour	–
PLWF	X	X	number	end of each hour	–
PLCD	X	X	number	end of each hour	–
PL	X	X	number	end of each hour	–
ty	X	X	unrecognized	input time	Type: c_dhwlsegytch_sup / _ret
wbCount	X	X	number	run start time (of each phase, autoSize or simulate)	Total # of child dhwloopbranchs
fNoDraw	X	X	number	hourly	Fraction of hour when there is no draw
LL	X	X	number	end of each hour	Current hour loop loss, btu
BL	X	X	number	end of each hour	Current hour child dhwloopbranch losses, btu



Name	Input?	Runtime?	Type	Variability	Description
t24WL	X	X	number	end of each hour	Current hour child dhwloopbranch waste loss volume, gal

## 6.17 DHWmeter

@DHWmeter[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
Y.total	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.unknown	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.faucet	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.shower	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.bath	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.cwashr	X	X	number	end of run (of each phase, autoSize or simulate)	–
Y.dwashr	X	X	number	end of run (of each phase, autoSize or simulate)	–
M.total	X	X	number	end of each month	–
M.unknown	X	X	number	end of each month	–
M.faucet	X	X	number	end of each month	–
M.shower	X	X	number	end of each month	–
M.bath	X	X	number	end of each month	–
M.cwashr	X	X	number	end of each month	–
M.dwashr	X	X	number	end of each month	–
D.total	X	X	number	end of each day	–
D.unknown	X	X	number	end of each day	–
D.faucet	X	X	number	end of each day	–
D.shower	X	X	number	end of each day	–
D.bath	X	X	number	end of each day	–
D.cwashr	X	X	number	end of each day	–
D.dwashr	X	X	number	end of each day	–
H.total	X	X	number	end of each hour	–
H.unknown	X	X	number	end of each hour	–
H.faucet	X	X	number	end of each hour	–
H.shower	X	X	number	end of each hour	–
H.bath	X	X	number	end of each hour	–
H.cwashr	X	X	number	end of each hour	–
H.dwashr	X	X	number	end of each hour	–

## 6.18 DHWPump (owner: DHWSys)

@DHWPump[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	integer number	input time	Count of identical dhw pumps (default 1)
elecMtri	X	X	integer number	input time	Meter for pump electricity use (default = parent ws_elecMtri)
pwr	X	X	number	hourly	Pump power, w
liqHeatF	X	X	number	hourly	Fraction of wp_pwr added to liquid stream
inElec	X	X	number	end of each hour	Electricity (note not kwh)

## 6.19 DHWSolarCollector (owner: DHWSolarSys)

@DHWSolarCollector[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	number	input time	Multiplier (for multiple panels). default 1.
multLR	X	X	number	end of run (of each phase, autoSize or simulate)	Last run multiplier, re probing in chained runs
area	X	X	number	input time	Srcc collector area, ft2
areaTot	X	X	number	run start time (of each phase, autoSize or simulate)	Total area, ft2 (=sc_area*sc_mult)
FRUL	X	X	number	input time	Srcc slope
FRTA	X	X	number	input time	Srcc intercept
tilt	X	X	number	input time	Array tilt, radians (input as degrees)
azm	X	X	number	input time	Array azimuth, radians (input as degrees)
poa	X	X	number	end of each hour	Plane of array incidence, btu/h-ft2
Qpoa	X	X	number	end of each hour	Plane of array incident heat, btu
eff	X	X	number	end of each hour	Fraction of incident heat added to the fluid
Qfluid	X	X	number	end of each hour	Heat added to the fluid, btu
tOutlet	X	X	number	end of each hour	Outlet temperature, f
tOutletP	X	X	number	end of each hour	Potential outlet temperature, f

Name	Input?	Runtime?	Type	Variability	Description
pumpPwr	X	X	number	input time	Pump power, w
pumpLiqHeatF	X	X	number	input time	Fraction of sc_pumppwr added to liquid stream
pumpFlow	X	X	number	input time	Rated flow rate, gpm
pumpOnDeltaT	X	X	number	input time	Temperature difference between the
pumpOffDeltaT	X	X	number	input time	Temperature difference between the
tickVol	X	X	number	end of each subhour	Volume moved during this tick, gal
tickOp	X	X	unrecognized	end of each subhour	Nz iff pump is operating during prior tick
mdot	X	X	number	end of each hour	Actual mass flow rate, lb/hr
pumpInElec	X	X	number	end of each hour	Actual electricity use (note not kwh)

## 6.20 DHWSolarSys

@DHWSolarSys[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
elecMtri	X	X	integer number	input time	Meter for pump and parasitic electricity use
endUse	X	X	integer number	input time	End use of pump energy. defaults to “dhw”
parElec	X	X	number	hourly	Parasitic electricity use, w
wsCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of dhwsyss supplied by this dhwsolarsys
scAreaTot	X	X	number	run start time (of each phase, autoSize or simulate)	Total of child dhwsolarcollectors, ft2
scCount	X	X	number	run start time (of each phase, autoSize or simulate)	# of child dhwsolarcollectors (not necessarily # of panels)

Name	Input?	Runtime?	Type	Variability	Description
tank.HSCount	X	X	unrecognized	end of each subhour	–
tank.tEx	X	X	number	end of each subhour	–
tank.tASHPSrc	X	X	number	end of each subhour	–
tank.qTXXick	X	X	number	end of each subhour	–
tank.nQTXNodes	X	X	unrecognized	end of each subhour	–
tank.fMixUse	X	X	number	end of each subhour	–
tank.fMixRL	X	X	number	end of each subhour	–
tank.inElec[0]	X	X	number	end of each subhour	–
tank.inElec[1]	X	X	number	end of each subhour	–
tank.HPWHxBU	X	X	number	end of each subhour	–
tank.qEnv	X	X	number	end of each subhour	–
tank.qLoss	X	X	number	end of each subhour	–
tank.qHW	X	X	number	end of each subhour	–
tank.qTX	X	X	number	end of each subhour	–
tank.tankTempSet	X	X	unrecognized	end of each subhour	–
tank.tankHCNominal	X	X	number	end of each subhour	–
tank.tankHCStart	X	X	number	end of each subhour	–
tank.tHWOutF	X	X	number	end of each subhour	–
tank.nzDrawCount	X	X	unrecognized	end of each subhour	–
tank.tHWOut	X	X	number	end of each subhour	–
tank.bWriteCSV	X	X	unrecognized	end of each subhour	–
tank.balErrCount	X	X	unrecognized	end of each subhour	–
tank.balErrMax	X	X	number	end of each subhour	–
tankVol	X	X	number	run start time (of each phase, autoSize or simulate)	Tank volume, gal

Name	Input?	Runtime?	Type	Variability	Description
tankUA	X	X	number	run start time (of each phase, autoSize or simulate)	Tank water-to-air ua, btuh/f
tankInsulR	X	X	number	run start time (of each phase, autoSize or simulate)	Total tank insulation resistance, hr-f/btuh
tankZnTi	X	X	integer	input time	Tank location zone
tankTEx	X	X	number	hourly	re tank loss Surrounding temperature, f for tank loss
tankQLoss	X	X	number	end of each hour	Current hour's total tank loss, btu
tankHXEff	X	X	number	hourly	Tank heat exchanger effectiveness
tankTHxLimit	X	X	number	input time	Tank temp limit, f; collector heat
overHeatTkCount	X	X	unrecognized	end of each hour	# of ticks in this hour when collector did not run
tickVol	X	X	number	end of each subhour	Current tick draw to dhwsyss, gal
tickVolT	X	X	number	end of each subhour	Current tick (vol * inlet temp), gal-f
drawVol	X	X	number	end of each hour	Current hour total draw, gal
tankQGain	X	X	number	end of each hour	Current hour's total gain from solar hx, btu
tankTInlet	X	X	number	end of each hour	Tank inlet temperature, f
tankTOutlet	X	X	number	end of each hour	Tank outlet temperature, f
tankTHx	X	X	number	end of each hour	Nominal tank heat exchange temp, f
scFluidSpHt	X	X	number	input time	Collector working fluid specific heat, btu/lbm-f
scFluidDens	X	X	number	input time	Collector working fluid density, lb/ft3
scFluidVHC	X	X	number	run start time (of each phase, autoSize or simulate)	Collector working fluid volumetric heat capacity, btu/gal-f
scTInlet	X	X	number	end of each hour	Mixed collector inlet temperature, f

Name	Input?	Runtime?	Type	Variability	Description
scTOutlet	X	X	number	end of each hour	Mixed collector outlet temperature, f
overHeatHrCount	X	X	unrecognized	end of run (of each phase, autoSize or simulate)	Number of hours during which collector did not
SSFAnnual	X	X	number	end of run (of each phase, autoSize or simulate)	Annual solar savings fraction

## 6.21 DHWSys

@DHWSys[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
calcMode	X	X	unrecognized	input time	Calculation mode
centralDHWSYSi	X	X	integer number	input time	Index of central (parent) dhwsys, 0 if none
mult	X	X	number	input time	Multiplier: model as ws_mult identical systems
elecMtri	X	X	integer number	input time	Meter for system electricity use
fuelMtri	X	X	integer number	input time	Meter for system fuel use
inElec	X	X	number	end of each hour	Electricity (note not kwh)
inFuel	X	X	number	end of each hour	Fuel (for generality, always 0?)
swTi	X	X	integer number	input time	Dhwsolarsys serving preheated water to this system
SSFAnnualSolar	X	X	number	end of run (of each phase, autoSize or simulate)	Annual solar heat added (numerator to calculate ssf), gal-f
SSFAnnualReq	X	X	number	end of run (of each phase, autoSize or simulate)	Annual heat required (denominator to calculate ssf), gal-f
SSFAnnual	X	X	number	end of run (of each phase, autoSize or simulate)	Annual solar savings fraction

Name	Input?	Runtime?	Type	Variability	Description
tInlet	X	X	number	end of each hour	Current hour cold water inlet temp, f for this dhwsys
tInletX	X	X	number	end of each hour	Hour average adjusted cold water temp, f
hwUse	X	X	number	hourly	Current hour hot water use (at fixtures), gal
iTk0DWHR	X	X	unrecognized	end of each hour	1st tick with possible dwhr
iTkNDWHR	X	X	unrecognized	end of each hour	Last+1 tick with possible dwhr
qDWHR	X	X	number	end of each hour	Hour total heat recovered by all dhwheatrec devices, btu
WHhwMtri	X	X	integer number	input time	Dhwmtr for hot water use at water heater(s) (= ws_whuse), gal
FXhwMtri	X	X	integer number	input time	Dhwmtr for hot water use at fixtures (= ws_fxusemix), gal
whUseNoHR	X	X	number	end of each hour	Current hour virtual hot water use w/o heat recovery, gal
fxUseMix.total	X	X	number	end of each hour	–
fxUseMix.unknown	X	X	number	end of each hour	–
fxUseMix.faucet	X	X	number	end of each hour	–
fxUseMix.shower	X	X	number	end of each hour	–
fxUseMix.bath	X	X	number	end of each hour	–
fxUseMix.cwashr	X	X	number	end of each hour	–
fxUseMix.dwashr	X	X	number	end of each hour	–
fxUseMixTot[0]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[1]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal

Name	Input?	Runtime?	Type	Variability	Description
fxUseMixTot[2]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[3]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[4]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[5]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[6]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixTot[7]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total (mixed) water use at fixtures, gal
fxUseMixLH.total	X	X	number	hourly	—
fxUseMixLH.unknown	X	X	number	hourly	—
fxUseMixLH.faucet	X	X	number	hourly	—
fxUseMixLH.shower	X	X	number	hourly	—
fxUseMixLH.bath	X	X	number	hourly	—
fxUseMixLH.cwashr	X	X	number	hourly	—
fxUseMixLH.dwashr	X	X	number	hourly	—
whUse.total	X	X	number	end of each hour	—
whUse.unknown	X	X	number	end of each hour	—
whUse.faucet	X	X	number	end of each hour	—
whUse.shower	X	X	number	end of each hour	—
whUse.bath	X	X	number	end of each hour	—
whUse.cwashr	X	X	number	end of each hour	—
whUse.dwashr	X	X	number	end of each hour	—
whUseTot[0]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal



Name	Input?	Runtime?	Type	Variability	Description
whUseTot[1]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[2]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[3]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[4]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[5]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[6]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
whUseTot[7]	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total hot water use (at ws_tuse), gal
drawMaxDur	X	X	integer number	input time	Draw duration window, hr (user input, default 4)
drawMax	X	X	number	input time	Largest draw total in any conseq ws_drawmaxdur hrs, gal
loadMaxDur	X	X	integer number	input time	Load duration window, hr (user input, default 12)
loadMax	X	X	number	input time	Largest load total in any conseq ws_loadmaxdur hrs, btu
tUse	X	X	number	hourly	Hot water use temp, f
tSetpoint	X	X	number	hourly	Dhwheater set point (for all dhwheters using hpwh model), f

Name	Input?	Runtime?	Type	Variability	Description
tSetpointLH	X	X	number	hourly	Dhwloopheater set point (for all child dhwloopheaters using hpwh model), f
tOutPrimLT	X	X	number	end of each subhour	Primary water heater outlet temp, f
dayUsei	X	X	integer number	daily	Idx of dhwdayuse
dayUseName	X	X	string	daily	Name of dhwdayuse (resolved at runtime)
childDHWDAYUSEFlag	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Nz iff at least one child dhwsys has specified ws_dayusername
parElec	X	X	number	hourly	Electrical parasitic power, w
SDLM	X	X	number	input time	Standard distribution loss multiplier
DSM	X	X	number	input time	Distribution system multiplier (appe table re-2)
SSF	X	X	number	hourly	Solar savings fraction
WF	X	X	number	hourly	Waste factor applied to ws_hwuse and dhwuses
drawCount[0]	X	X	unrecognized	end of each hour	–
drawCount[1]	X	X	unrecognized	end of each hour	–
drawCount[2]	X	X	unrecognized	end of each hour	–
drawCount[3]	X	X	unrecognized	end of each hour	–
drawCount[4]	X	X	unrecognized	end of each hour	–
drawCount[5]	X	X	unrecognized	end of each hour	–
drawsPerDay[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
drawsPerDay[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
drawsPerDay[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
drawsPerDay[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
drawsPerDay[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
drawsPerDay[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–
drawDurF[0]	X	X	number	end of each hour	Water heater draw duration factors by end use
drawDurF[1]	X	X	number	end of each hour	Water heater draw duration factors by end use
drawDurF[2]	X	X	number	end of each hour	Water heater draw duration factors by end use
drawDurF[3]	X	X	number	end of each hour	Water heater draw duration factors by end use
drawDurF[4]	X	X	number	end of each hour	Water heater draw duration factors by end use
drawDurF[5]	X	X	number	end of each hour	Water heater draw duration factors by end use
branchModel	X	X	unrecognized	input time	Branch model selection
drawWaste[0]	X	X	number	hourly	Water waste per draw, gal
drawWaste[1]	X	X	number	hourly	Water waste per draw, gal
drawWaste[2]	X	X	number	hourly	Water waste per draw, gal

Name	Input?	Runtime?	Type	Variability	Description
drawWaste[3]	X	X	number	hourly	Water waste per draw, gal
drawWaste[4]	X	X	number	hourly	Water waste per draw, gal
drawWaste[5]	X	X	number	hourly	Water waste per draw, gal
dayWasteDrawF[0]	X	X	number	input time	Relative draw for day waste scheme
dayWasteDrawF[1]	X	X	number	input time	Relative draw for day waste scheme
dayWasteDrawF[2]	X	X	number	input time	Relative draw for day waste scheme
dayWasteDrawF[3]	X	X	number	input time	Relative draw for day waste scheme
dayWasteDrawF[4]	X	X	number	input time	Relative draw for day waste scheme
dayWasteDrawF[5]	X	X	number	input time	Relative draw for day waste scheme
dayWasteVol	X	X	number	input time	Base daily total draw waste, gal/day
dayWasteBranchVolF	X	X	number	input time	Additional daily draw waste, discards/day
dayWaste	X	X	number	run start time (of each phase, autoSize or simulate)	Daily draw waste, gal/day
dayWasteScale	X	X	number	end of run (of each phase, autoSize or simulate)	–
childDHWSYSCount	X	X	number	run start time (of each phase, autoSize or simulate)	# of child dhwsyss iff central system (else 0)
whCount	X	X	number	run start time (of each phase, autoSize or simulate)	# of (primary) dhwheaters serving this dhwsys
wlhCount	X	X	number	run start time (of each phase, autoSize or simulate)	# of dhwloopheaters in this dhwsys

Name	Input?	Runtime?	Type	Variability	Description
whCountUseTS	X	X	number	run start time (of each phase, autoSize or simulate)	# of dhwheaters serving this dhwsys that respond to ws_tsetpoint
wlhCountUseTS	X	X	number	run start time (of each phase, autoSize or simulate)	# of dhwloopheaters serving this dhwsys that respond to ws_tsetpointlh
wtCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of child dhwtanks
wpCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of child dhwpumps
wlCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of child dhwloops (aka nloopk)
configChecked	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Set non-0 when configuration has been checked (see ws_init())
loopSegTotals.count	X	X	number	run start time (of each phase, autoSize or simulate)	# of segments included in totals
loopSegTotals.len	X	X	number	run start time (of each phase, autoSize or simulate)	Length, ft
loopSegTotals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	Volume, gal
loopSegTotals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	Outside surface area (at insulation surface), ft <sup>2</sup>

Name	Input?	Runtime?	Type	Variability	Description
loopSegTotals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	Fluid-to-surround loss, btuh/f-hr
branchTotals.count	X	X	number	run start time (of each phase, autoSize or simulate)	# of segments included in totals
branchTotals.len	X	X	number	run start time (of each phase, autoSize or simulate)	Length, ft
branchTotals.vol	X	X	number	run start time (of each phase, autoSize or simulate)	Volume, gal
branchTotals.exArea	X	X	number	run start time (of each phase, autoSize or simulate)	Outside surface area (at insulation surface), ft2
branchTotals.UA	X	X	number	run start time (of each phase, autoSize or simulate)	Fluid-to-surround loss, btuh/f-hr
wrCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Total child dhwheatrecs
wrFeedWHCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Count of child dhwheatrecs that provide
wrFxDrainCount	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Count of fixture drains feeding (possibly shared) dhwheatrecs
fxCount[0]	X	X	integer number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
fxCount[1]	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fxCount[2]	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fxCount[3]	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fxCount[4]	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fxCount[5]	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
loadShareDHWSYSi	X	X	integer number	input time	Index of dhwsys with which this dhwsys shares load
loadShareCount[0]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
loadShareCount[1]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
loadShareCount[2]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
loadShareCount[3]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
loadShareCount[4]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
loadShareCount[5]	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
loadShareWS0[0]	X	X	unrecognized	end of each day	Re allocation of shared load
loadShareWS0[1]	X	X	unrecognized	end of each day	Re allocation of shared load
loadShareWS0[2]	X	X	unrecognized	end of each day	Re allocation of shared load
loadShareWS0[3]	X	X	unrecognized	end of each day	Re allocation of shared load
loadShareWS0[4]	X	X	unrecognized	end of each day	Re allocation of shared load
loadShareWS0[5]	X	X	unrecognized	end of each day	Re allocation of shared load
drawCSV	X	X	integer number	input time	Iff c_noyesch_yes, write tick-level draw data to
HHWO	X	X	number	end of each hour	Hourly hot water output (at water heater), btu
DLM	X	X	number	end of each hour	Distribution loss multiplier (calc'd)
volRL	X	X	number	end of each hour	Current hour all-dhwloop return volume, gal
tRL	X	X	number	end of each hour	Current hour all-dhwloop return temp, f
HRBL	X	X	number	end of each hour	Current hour all-dhwloopbranch losses, btu
t24WL	X	X	number	end of each hour	Current hour all-dhwloopbranch waste loss volume, gal
t24WLTot	X	X	number	end of run (of each phase, autoSize or simulate)	Annual total ws_t24wl
HRDL	X	X	number	end of each hour	Current hour recirculation loss, btu



Name	Input?	Runtime?	Type	Variability	Description
HJLsh	X	X	number	end of each subhour	Current subhour jacket losses (from dhwtanks), btu
HJL	X	X	number	end of each hour	Hour total jacket losses (from dhwtanks), btu
HARL	X	X	number	end of each hour	Hour total adjusted recovery load, btu

## 6.22 DHWTank (owner: DHWSys)

@DHWTank[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mult	X	X	integer number	input time	Count of identical dhw tanks (default 1)
UA	X	X	number	input time	Tank water-to-air ua, btuh/f
vol	X	X	number	input time	Tank volume, gal
insulR	X	X	number	input time	Total tank insulation resistance, hr-f/btuh
tTank	X	X	number	hourly	Assumed tank water temperature, f
znTi	X	X	integer number	input time	Dhwtank location zone re tank loss
tEx	X	X	number	hourly	Surrounding temperature, f for tank loss
xLoss	X	X	number	hourly	Other tank temp-independent losses, btuh
qLossSh	X	X	number	end of each subhour	Current subhr loss rate, btuh
qLoss	X	X	number	end of each hour	Current hour's total loss, btu

## 6.23 DHWUse (owner: DHWDayUse)

@DHWUse[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
hwEndUse	X	X	integer number	input time	Hot water end use
eventID	X	X	integer number	input time	User-defined index that identifies dhwuses belonging to a single
start	X	X	number	hourly	Draw starting hour of day, 0 - 23.999

Name	Input?	Runtime?	Type	Variability	Description
dur	X	X	number	hourly	Flow duration, min
flow	X	X	number	hourly	Mixed flow rate, gpm
hotF	X	X	number	hourly	Fraction hot water, default = 1
temp	X	X	number	hourly	Use temperature, f. if given,
heatRecEF	X	X	number	hourly	Heat recovery effectiveness
drawSeqN	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Sequence number of draw by ws_hwenduse

## 6.24 door (owner: surface)

@door[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
ty	X	–	integer	input time	–
area	X	–	number	run start time (of each phase, autoSize or simulate)	–
azm	X	–	number	run start time (of each phase, autoSize or simulate)	–
tilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
depthBG	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
height	X	–	number	run start time (of each phase, autoSize or simulate) input time	... and to compute area b4 mutliplier.
model	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
modelr	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
lThkF	X	–	number	run start time (of each phase, autoSize or simulate)	–
gti	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sco	X	–	number	monthly- hourly	–
scc	X	–	number	monthly- hourly	–
sbcI.absSlr	X	–	number	monthly- hourly	–
sbcI.awAbsSlr	X	–	number	monthly- hourly	–
sbcI.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcI.F	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcNat	X	–	number	end of each subhour	–
sbcI.hcFrc	X	–	number	end of each subhour	–
sbcI.hcMult	X	–	number	end of each subhour	–
sbcI.hxa	X	–	number	end of each subhour	–
sbcI.hxr	X	–	number	end of each subhour	–
sbcI.hxtot	X	–	number	end of each subhour	–
sbcI.uRat	X	–	number	end of each subhour	–
sbcI.fRat	X	–	number	end of each subhour	–
sbcI.cx	X	–	number	end of each subhour	–
sbcI.sgTarg.bm	X	–	number	end of each subhour	–
sbcI.sgTarg.df	X	–	number	end of each subhour	–
sbcI.sgTarg.tot	X	–	number	end of each subhour	–
sbcI.sg	X	–	number	end of each subhour	–
sbcI.tSrf	X	–	number	end of each subhour	–
sbcI.tSrfls	X	–	number	subhourly	–
sbcI.qrAbs	X	–	number	end of each subhour	–
sbcI.txa	X	–	number	end of each subhour	–
sbcI.txr	X	–	number	end of each subhour	–
sbcI.txe	X	–	number	end of each subhour	–
sbcI.w	X	–	number	end of each subhour	–
sbcI.qSrf	X	–	number	end of each subhour	–
sbcI.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.eta	X	–	number	end of each subhour	–
sbcI.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.absSlr	X	–	number	monthly- hourly	–
sbcO.awAbsSlr	X	–	number	monthly- hourly	–
sbcO.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcO.F	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcNat	X	–	number	end of each subhour	–
sbcO.hcFrc	X	–	number	end of each subhour	–
sbcO.hcMult	X	–	number	end of each subhour	–
sbcO.hxa	X	–	number	end of each subhour	–
sbcO.hxr	X	–	number	end of each subhour	–
sbcO.hxtot	X	–	number	end of each subhour	–
sbcO.uRat	X	–	number	end of each subhour	–
sbcO.fRat	X	–	number	end of each subhour	–
sbcO.cx	X	–	number	end of each subhour	–
sbcO.sgTarg.bm	X	–	number	end of each subhour	–
sbcO.sgTarg.df	X	–	number	end of each subhour	–
sbcO.sgTarg.tot	X	–	number	end of each subhour	–
sbcO.sg	X	–	number	end of each subhour	–
sbcO.tSrf	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.tSrfls	X	–	number	subhourly	–
sbcO.qrAbs	X	–	number	end of each subhour	–
sbcO.txa	X	–	number	end of each subhour	–
sbcO.txr	X	–	number	end of each subhour	–
sbcO.txe	X	–	number	end of each subhour	–
sbcO.w	X	–	number	end of each subhour	–
sbcO.qSrf	X	–	number	end of each subhour	–
sbcO.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.eta	X	–	number	end of each subhour	–
sbcO.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–



Name	Input?	Runtime?	Type	Variability	Description
sbcO.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
fenModel	X	–	unrecognized	input time	–
SHGC	X	–	number	input time	–
fMult	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNFRC	X	–	number	input time	–
NGlz	X	–	integer number	input time	–
exShd	X	–	unrecognized	input time	–
inShd	X	–	unrecognized	input time	–
dirtLoss	X	–	number	run start time (of each phase, autoSize or simulate)	–
sfExCnd	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sfExT	X	–	number	subhourly	–
sfAdjZi	X	–	integer number	input time	–
uI	X	–	number	run start time (of each phase, autoSize or simulate)	–
uC	X	–	number	run start time (of each phase, autoSize or simulate)	–
uX	X	–	number	run start time (of each phase, autoSize or simulate)	–
Rf	X	–	number	run start time (of each phase, autoSize or simulate)	–
grndRefl	X	–	number	monthly- hourly	–
vfSkyDf	X	–	number	monthly- hourly	–
vfGrndDf	X	–	number	monthly- hourly	–

Name	Input?	Runtime?	Type	Variability	Description
vfSkyLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
vfGrndLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
uval	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
UANom	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
cFctr	X	–	number	run start time (of each phase, autoSize or simulate)	–
iwshad	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
msi	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model
tLrB[0]	X	–	number	end of each hour	–
tLrB[1]	X	–	number	end of each hour	–

Name	Input?	Runtime?	Type	Variability	Description
tLrB[2]	X	–	number	end of each hour	–
tLrB[3]	X	–	number	end of each hour	–
tLrB[4]	X	–	number	end of each hour	–
tLrB[5]	X	–	number	end of each hour	–
tLrB[6]	X	–	number	end of each hour	–
tLrB[7]	X	–	number	end of each hour	–
tLrB[8]	X	–	number	end of each hour	–
tLrB[9]	X	–	number	end of each hour	–
nsghost	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].FSO	X	–	number	monthly-hourly	–
sgdist[0].FSC	X	–	number	monthly-hourly	–
sgdist[1].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].FSO	X	–	number	monthly-hourly	–
sgdist[1].FSC	X	–	number	monthly-hourly	–
sgdist[2].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[2].FSO	X	–	number	monthly- hourly	–
sgdist[2].FSC	X	–	number	monthly- hourly	–
sgdist[3].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].FSO	X	–	number	monthly- hourly	–
sgdist[3].FSC	X	–	number	monthly- hourly	–
sgdist[4].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].FSO	X	–	number	monthly- hourly	–
sgdist[4].FSC	X	–	number	monthly- hourly	–
sgdist[5].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].FSO	X	–	number	monthly- hourly	–
sgdist[5].FSC	X	–	number	monthly- hourly	–
sgdist[6].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].FSO	X	–	number	monthly- hourly	–
sgdist[6].FSC	X	–	number	monthly- hourly	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[7].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].FSO	X	–	number	monthly-hourly	–
sgdist[7].FSC	X	–	number	monthly-hourly	–
sfClass	X	–	unrecognized	input time	Sfcnul, sfcsurf, sfcdoor, sfcwindow
sfArea	X	–	number	input time	Surface: gross area, net in x.xs_area.
sfU	X	–	number	input time	Uval input if no sfcon given (excl surf films)
sfCon	X	–	integer number	input time	Surface construction (optional)
sfTy	X	–	integer number	constant	Wall/floor/ceil/[intmass1/2]: for input cking.
sfFnd	X	–	integer number	input time	Surface foundation object (floors only, optional)
sfFndFloor	X	–	integer number	input time	Surface foundation floor object (walls only, optional)
sfExpPerim	X	–	number	input time	Foundation floor exposed perimeter (floors only)
width	X	–	number	input time	Width and height: used to compute shading,
height	X	–	number	input time	... and to compute area b4 mutliplier.
mult	X	–	number	input time	Area multiplier (for multiple identical windows)
xi	X	–	integer number	run start time (of each phase, autoSize or simulate)	Subscript in runtime xsrat, to facilitate access by probers 1-92
msi	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model

## 6.25 DuctSeg (owner: RSYS)

@DuctSeg[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–

Name	Input?	Runtime?	Type	Variability	Description
ty	X	X	unrecognized	input time	Type: c_ducttych_ret / _sup
absSlr	X	X	number	subhourly	–
awAbsSlr	X	X	number	subhourly	–
epsLW	X	X	number	subhourly	–
zi	X	X	integer	subhourly	–
			number		
F	X	X	number	subhourly	–
Fp	X	X	number	subhourly	–
frRad	X	X	number	subhourly	–
fSky	X	X	number	subhourly	–
fAir	X	X	number	subhourly	–
hcNat	X	X	number	end of each subhour	–
hcFrc	X	X	number	end of each subhour	–
hcMult	X	X	number	end of each subhour	–
hxa	X	X	number	end of each subhour	–
hxr	X	X	number	end of each subhour	–
hxtot	X	X	number	end of each subhour	–
uRat	X	X	number	end of each subhour	–
fRat	X	X	number	end of each subhour	–
cx	X	X	number	end of each subhour	–
sgTarg.bm	X	X	number	end of each subhour	–
sgTarg.df	X	X	number	end of each subhour	–
sgTarg.tot	X	X	number	end of each subhour	–
sg	X	X	number	end of each subhour	–
tSrf	X	X	number	end of each subhour	–
tSrfls	X	X	number	subhourly	–
qrAbs	X	X	number	end of each subhour	–
txa	X	X	number	end of each subhour	–
txr	X	X	number	end of each subhour	–
txe	X	X	number	end of each subhour	–
w	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
qSrf	X	X	number	end of each subhour	–
pDS	X	X	unrecognized	subhourly	Pointer to parent ductseg
exArea	X	X	number	input time	Exterior heat transfer surface area, ft <sup>2</sup> (outside of insulation)
diam	X	X	number	input time	Duct diameter (w/o insulation), ft
len	X	X	number	input time	Total length (all branches), ft
branchLen	X	X	number	run start time (of each phase, autoSize or simulate)	Average branch length, ft
branchCount	X	X	integer number	input time	# of branches
branchCFA	X	X	number	input time	Floor area served per per branch, ft <sup>2</sup>
airVelDs	X	X	number	input time	Design air velocity, fpm
inArea	X	X	number	input time	Interior surface area, ft <sup>2</sup>
insulR	X	X	number	input time	Rated insulation resistance, ft <sup>2</sup> -f/btuh
insulMati	X	X	integer number	input time	Insulation material, 0 if none
insulKA	X	X	number	run start time (of each phase, autoSize or simulate)	Constants for insul conductivity: $k_{insul} = k_a + k_b \cdot t$
insulKB	X	X	number	run start time (of each phase, autoSize or simulate)	–
insulThk	X	X	number	run start time (of each phase, autoSize or simulate)	Insulation actual thickness, ft
insulThkEff	X	X	number	run start time (of each phase, autoSize or simulate)	Effective insulation thickness, ft
RconvIn	X	X	number	autosize and simulate phase start time	Inside surfce convection resistance, ft <sup>2</sup> -f/btuh
Rduct	X	X	number	end of each hour	Total resistance from duct air to exterior surface of insulation



Name	Input?	Runtime?	Type	Variability	Description
Uduct	X	X	number	end of each hour	1/ds_rduct
insulREff	X	X	number	end of each hour	Effective insulation resistance, ft <sup>2</sup> -f/btuh
exCnd	X	X	integer	input time	Adjacent cond:
leakF	X	X	number	input time	adiabatic/ambient/spect/adjzn.
uaTot	X	X	number	end of each subhour	Leakage fraction, 0-1
beta	X	X	number	end of each subhour	Cur step total conductance between duct air
air[0].tdb	X	X	number	end of each subhour	Cur step conduction loss parameter (1 - effectiveness)
air[0].w	X	X	number	end of each subhour	–
air[1].tdb	X	X	number	end of each subhour	–
air[1].w	X	X	number	end of each subhour	–
air[2].tdb	X	X	number	end of each subhour	–
air[2].w	X	X	number	end of each subhour	–
air[3].tdb	X	X	number	end of each subhour	–
air[3].w	X	X	number	end of each subhour	–
amfFL	X	X	number	end of each subhour	Dry air mass flow rate at full load, lbm/hr
qCondFL	X	X	number	end of each subhour	Full load total conduction losses to surround (+ = out of duct), btuh
qCondAirFL	X	X	number	end of each subhour	... to txa (air)
qCondRadFL	X	X	number	end of each subhour	... to txr (radiant)

## 6.26 export (owner: exportFile)

@export[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
zi	X	–	integer number	input time	Zone for zone-specific reports. can be ti_sum, ti_all.
mtri	X	–	integer number	input time	Meter to report/export for meter-specific reports. can be ti_sum, ti_all.

Name	Input?	Runtime?	Type	Variability	Description
ahi	X	—	integer number	input time	Air handler to report/export for air-handler-specific reports. can be ti_sum, ti_all.
tui	X	—	integer number	input time	Terminal to report/export for terminal-specific reports. can be ti_all
dhwMtri	X	—	integer number	input time	Dhw meter to report/export for dhw meter-specific reports. can be ti_all.
isExport	X	—	integer number	input time	1 if export not report, so same fens can be used with rib and xib records
rpTy	X	—	integer number	constant	Report/export type c_rptych_eb etc
rpFreq	X	—	integer number	constant	R/xport frequency c_ivlch_m etc
rpDayBeg	X	—	integer number	input time	Start 1-based julian day of year, where applicable
rpDayEnd	X	—	integer number	input time	End ..
rpBtuSf	X	—	number	input time	Energy (btu) scale factor
rpCond	X	—	number	end of each subhour	Condition: if given, rpt lines omitted when false (si; li used to hold nan) (li currently unprobeable)
rpTitle	X	—	string	input time	Title, for udt, in dm
rpCpl	X	—	integer number	input time	Chars per line, inputtable re udt's
rpHeader	X	—	unrecognized	input time	Table header or export header yes/no (default yes)
rpFooter	X	—	integer number	input time	Table footer (summary line) or export footer (just blank line?) yes/no (default yes)
coli	X	—	integer number	run start time (of each phase, autoSize or simulate)	Rcolb/xcolb subscript of first column (thence linked by .nxcoli).
nCol	X	—	integer number	run start time (of each phase, autoSize or simulate)	# columns
wid	X	—	integer number	run start time (of each phase, autoSize or simulate)	Total col width for user-defined report

Name	Input?	Runtime?	Type	Variability	Description
vrh	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	Assigned virtual report handle, used from here to build unspoolinfo.

## 6.27 exportCol (owner: export)

@exportCol[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
colHead	X	X	string	input time	Column head string, in dm. *i cuz veoi in cncult.cpp:rpcolt[].
colGap	X	X	integer number	input time	Space to left of column, default 1
colWid	X	X	integer number	input time	Column width
colDec	X	X	integer number	input time	Coldecimals: max digits after point
colJust	X	X	integer number	input time	Justification: c_justch_1 or _r
colVal	X	X	un-probe-able	end of each subhour	Value .val and data type .dt (tyfl/tystr in input, dtfloat/dtchp in run), used at end report interval.
nxColi	X	X	integer number	constant	For runtime: col subscript of next column in this report, 0 if last one

## 6.28 exportFile

@exportFile[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
fileName	X	–	string	input time	File name, path optional, in dm (or pseudocode, but not “text”). *i cuz veoi in cncult.
fileStat	X	–	integer number	run start time (of each phase, autoSize or simulate)	Fresh(overwrite,default)/new(err if exists)/append
pageFmt	X	–	integer number	input time	Page formatting on no/yes
fileStatChecked	X	–	integer number	run start time (of each phase, autoSize or simulate)	Check filestat only once to prevent “file exists” error or re-setting “overwrite” on later run

Name	Input?	Runtime?	Type	Variability	Description
overWrite	X	–	integer number	run start time (of each phase, autoSize or simulate)	Append if 0. set by filestat=fresh, cleared on use, so addl runs do not erase earlier output.
wasNotEmpty	X	–	integer number	run start time (of each phase, autoSize or simulate)	Nz if existed and size > 0 at filestat check

## 6.29 foundation

@foundation[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
wlHtAbvGrd	X	–	number	input time	Height of foundation wall above grade
wlDpBlwSlb	X	–	number	input time	Depth of foundation wall below the slab
ftWlConi	X	–	integer number	input time	Foundation wall construction (con subscript) rqd if

## 6.30 foundationBlock (owner: foundation)

@foundationBlock[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
mati	X	–	integer number	input time	Material (mat subscript) for this component
x1Ref	X	–	unrecognized	input time	Point 1 x reference
z1Ref	X	–	unrecognized	input time	Point 1 z reference
x1	X	–	number	input time	Point 1 x value (relative to reference)
z1	X	–	number	input time	Point 1 z value (relative to reference)
x2Ref	X	–	unrecognized	input time	Point 2 x reference
z2Ref	X	–	unrecognized	input time	Point 2 z reference
x2	X	–	number	input time	Point 2 x value (relative to reference)
z2	X	–	number	input time	Point 2 z value (relative to reference)

**6.31 gain (owner: zone)**

@gain[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
gnPower	X	X	number	hourly	Amount of gain (demand – b4 reduction by gndlfrpow), btuh, hourly expression
mtri	X	X	integer number	input time	Meter to which gain is charged
gnEndUse	X	X	integer number	autosize and simulate phase start time	End use of energy: cooling, heating, receptacles, etc. reqd if gnmeter != none, else disallowed.
gnFrLat	X	X	number	hourly	Fraction of gain which is latent (0 - 1, hourly expression)
gnFrRad	X	X	number	hourly	Fraction of gain which is radiant, added 11-95
gnFrZn	X	X	number	hourly	Fraction of gain going to zone (0 - 1, hourly expression)
gnFrPl	X	X	number	hourly	Fraction of gain going to plenum (0 - 1, hourly expression)
gnFrRtn	X	X	number	hourly	Fraction of gain going to return (0 - 1, hourly expression)
gnDlFrPow	X	X	number	hourly	Fraction power on for daylighting, 0-1, default 1.0, hourly expression
dhwsysi	X	X	integer number	input time	Controlling dhwsys, 0 if none
dhwEndUse	X	X	integer number	input time	With gn_dhwsysi, specifies controlling hw end use

**6.32 glazeType**

@glazeType[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
gtSHGC	X	X	number	input time	Rated shgc of assembly

Name	Input?	Runtime?	Type	Variability	Description
gtSMSO	X	X	number	monthly-hourly	Optional solar heat gain coef multiplier, shades open, used if not spec'd in window, dflt 1.0.
gtSMSC	X	X	number	monthly-hourly	Ditto shades closed, defaults at window level.
gtFMult	X	X	number	input time	Optional frame/mullion multiplier for use when not spec'd in window. constant.
gtPySHGC.k[0]	X	X	number	autosize and simulate phase start time	—
gtPySHGC.k[1]	X	X	number	autosize and simulate phase start time	—
gtPySHGC.k[2]	X	X	number	autosize and simulate phase start time	—
gtPySHGC.k[3]	X	X	number	autosize and simulate phase start time	—
gtPySHGC.k[4]	X	X	number	autosize and simulate phase start time	—
gtPySHGC.k[5]	X	X	number	autosize and simulate phase start time	—
gtDMSHGC	X	X	number	input time	Diffuse shgc multiplier used (in place of polynomial). reqd. constant.
gtDMRBSol	X	X	number	input time	Reflectance for diffuse solar on inside of glass, for cavity absorptance calc'ns (cgsolar.cpp).
gtU	X	X	number	input time	Optional u-value for use when not spec'd in window. constant.

Name	Input?	Runtime?	Type	Variability	Description
gtUNFRC	X	X	number	input time	Overall u-factor evaluated under per nfrc heating conditions
gtNGlz	X	X	integer number	input time	# of glazings bare-glass assembly
gtFenModel	X	X	unrecognized	input time	Fenestration model: user input
gtExShd	X	X	unrecognized	input time	Exterior shade (ashwat only)
gtInShd	X	X	unrecognized	input time	Interior shade (ditto)
gtDirtLoss	X	X	number	input time	Dirt loss fraction (all solar gain reduced by this factor)

### 6.33 *heatPlant*

@heatPlant[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
hpSched	X	X	unrecognized	hourly	Hourly choice of off, avail (default; plant runs on demand), or on (at least 1st stage runs).
hpPipeLossF	X	X	number	autosize and simulate phase start time	Pipe loss, default .01, fraction of largest stage boiler capac whenever any boiler running
hpStage1[0]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[1]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[2]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[3]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[4]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[5]	X	X	integer number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
hpStage1[6]	X	X	integer number	autosize and simulate phase start time	–
hpStage1[7]	X	X	integer number	autosize and simulate phase start time	–
hpStage2[0]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[1]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[2]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[3]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[4]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[5]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[6]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage2[7]	X	X	integer number	autosize and simulate phase start time	Defaulted by code, if no hpstage values entered:
hpStage3[0]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[1]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[2]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[3]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[4]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[5]	X	X	integer number	autosize and simulate phase start time	–
hpStage3[6]	X	X	integer number	autosize and simulate phase start time	–



Name	Input?	Runtime?	Type	Variability	Description
hpStage3[7]	X	X	integer number	autosize and simulate phase start time	–
hpStage4[0]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[1]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[2]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[3]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[4]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[5]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[6]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage4[7]	X	X	integer number	autosize and simulate phase start time	... stage 1: ti_all. stages 2-7: none (0).
hpStage5[0]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[1]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[2]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[3]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[4]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[5]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[6]	X	X	integer number	autosize and simulate phase start time	–
hpStage5[7]	X	X	integer number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
hpStage6[0]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[1]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[2]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[3]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[4]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[5]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[6]	X	X	integer number	autosize and simulate phase start time	–
hpStage6[7]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[0]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[1]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[2]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[3]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[4]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[5]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[6]	X	X	integer number	autosize and simulate phase start time	–
hpStage7[7]	X	X	integer number	autosize and simulate phase start time	–
blr1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st boiler for this heatplant. next is boiler.nxb1r4hp.

Name	Input?	Runtime?	Type	Variability	Description
tu1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st tu with hw coil served by this heatplant. next is tu.tuhc.nxtu4hp.
ah1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st ah with hw coil served by this heatplant. next is ah.ahhc.nxah4hp.
hl1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st hploop with hx for this heatplant
qPipeLoss	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[1]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[2]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[3]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[4]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[5]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgCap[6]	X	X	number	run start time (of each phase, autoSize or simulate)	–
stgPQ[0]	X	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
stgPQ[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgPQ[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgPQ[3]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgPQ[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgPQ[5]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgPQ[6]	X	X	number	run start time (of each phase, autoSize or simulate)	—
stgN	X	X	integer number	run start time (of each phase, autoSize or simulate)	Max+1 used stage subscript 1-7 (used stages need not be contiguous)
stgMxQ	X	X	integer number	run start time (of each phase, autoSize or simulate)	Most powerful stage subscript 0-6
hpClf	X	X	integer number	end of each subhour	Call-flag: set nz if must call hpcompute so it can test tr, etc to see if computation needed.
hpPtf	X	X	integer number	end of each subhour	Compute-flag: set if must call hpcompute and it should unconditionally recompute this plant.
hpMode	X	X	unrecognized	end of each subhour	Mode this subhour: off or on: per hpsched; per demand for avail. set in hpeestimate, hpcompute.
capF	X	X	number	end of each subhour	—
stgi	X	X	integer number	end of each subhour	Stage in use, 0-6 for hpstage1-7.

Name	Input?	Runtime?	Type	Variability	Description
qNx	X	X	number	end of each subhour	–
q	X	X	number	end of each subhour	–
qPk	X	X	number	end of each subhour	Peak load re error autosizing overload message
qPkAs	X	X	number	end of each subhour	Peak load on a converged autosizing design day re error autosizing overload message
hpModePr	X	X	unrecognized	end of each subhour	–
qPr	X	X	number	end of each subhour	–
capFPr	X	X	number	end of each subhour	–

### 6.34 holiday

@holiday[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
hdDateTrue	X	–	integer number	input time	True date of holiday, 1-365
hdDateObs	X	–	integer number	input time	Day holiday is observed, 1-365
hdOnMonday	X	–	integer number	input time	Yes if holiday that falls on weekend is observed on monday
hdCase	X	–	unrecognized	input time	Case: c_holicasech_first, _second, _third, _fourth, _last
hdDow	X	–	integer number	input time	Day of week, sun=1. subtract 1 before using.
hdMon	X	–	unrecognized	input time	Month 1-12

### 6.35 impFileFldNames

@impFileFldNames[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
impfi	–	X	integer number	input time	0 or subscript of impf record for file in impfib/impfb

Name	Input?	Runtime?	Type	Variability	Description
fnmiN	–	X	integer number	input time	Number of named fields seen for this file / max fnmi (+ 1 if 0-based)

## 6.36 importFile

@importFile[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
fileName	X	X	string	autosize and simulate phase start time	File name, path optional, in heap or pseudocode. *i cuz veoi in cncult. rqd.
imTitle	X	X	string	autosize and simulate phase start time	Title string. if given, file's must match.
imPhaseSpare	X	X	integer number	constant	For possible future autosize/mainsim/both choice 6-95
imFreq	X	X	integer number	input time	Frequency of record reads, y m d h; hs and subhour not allowed. rqd.
hasHeader	X	X	integer number	autosize and simulate phase start time	File has header no/yes, default yes.
iffnmi	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of import file field record in ifnmb. holds used names b4 file opened;
isOpen	X	X	integer number	run start time (of each phase, autoSize or simulate)	Non-0 if file is open and buffer has been allocated successfully
fh	X	X	integer number	run start time (of each phase, autoSize or simulate)	File handle. caution: initial value, 0, is a valid file handle.
posEndHdr	X	X	number	run start time (of each phase, autoSize or simulate)	File pointer after header, for repositioning file after warmup
bufSz	X	X	integer number	run start time (of each phase, autoSize or simulate)	0 or allocated size of buffer (actually 1 larger to hold 0)
bufN	X	X	integer number	hourly	Number of characters in buffer === subscript of 1st unused byte

Name	Input?	Runtime?	Type	Variability	Description
eofRead	X	X	integer number	hourly	True after end file has been input to buffer (unused records may remain in buffer)
eof	X	X	integer number	hourly	True after last record has been used
bufI1	X	X	integer number	hourly	Buffer subscript 1: start or next unscanned field in current record
bufI2	X	X	integer number	hourly	Buffer subscript 2: end current record. ==bufI1 if no current record.
lineNo	X	X	integer number	hourly	1-based line number (n count) in file
lineNoEndHdr	X	X	integer number	run start time (of each phase, autoSize or simulate)	Lineno corresponding to posendhdr
nFieldsScanned	X	X	integer number	end of each hour	0 or number of fields already scanned in current record
eorScanned	X	X	integer number	end of each hour	Non-0 if all fields in record have been scanned

### 6.37 Inverse

@Inverse[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
freq	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
X0	X	–	number	run start time (of each phase, autoSize or simulate)	–
Y0	X	–	number	run start time (of each phase, autoSize or simulate)	–
YTarg	X	–	number	run start time (of each phase, autoSize or simulate)	–
X	X	–	number	end of each subhour	–
Y	X	–	number	end of each subhour	–
XEst	X	–	number	input time	–

### 6.38 izXfer

@izXfer[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–

Name	Input?	Runtime?	Type	Variability	Description
zi1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscripts of zones involved (air flow > 0 = into zone 1)
zi2	X	X	integer number	run start time (of each phase, autoSize or simulate)	Iz_zi2 = -1 iff not interzone
ua	X	X	number	hourly	Air-to-air coupling const (btuh/f) thru walls etc.
nventrl	X	X	integer number	input time	Control type for nat vents:
a1	X	X	number	hourly	Vent area 1, ft <sup>2</sup>
a2	X	X	number	hourly	Vent area 2, ft <sup>2</sup>
L1	X	X	number	input time	Opening dim 1, ft (_anhoriz)
L2	X	X	number	input time	Opening dim 2, ft
hz	X	X	number	input time	_an (non fan): height of iz_a1 relative to arbitrary 0 (ft)
stairAngle	X	X	number	input time	Stair angle, deg (_anhoriz) (90 = vert)
cd	X	X	number	input time	Orifice coefficient, dimless (user input, default 0.8)
exp	X	X	number	run start time (of each phase, autoSize or simulate)	Power law exponent, (user input, default 0.5)
cpr	X	X	number	input time	Wind pressure coefficient (ignored if not _anext)
vfMin	X	X	number	subhourly	Min vent flow rate, cfm (for fixed flow types)
vfMax	X	X	number	subhourly	Max vent flow rate, cfm (for fixed flow types)
ASEF	X	X	number	subhourly	Apparent sensible effectiveness (for _anherv)
LEF	X	X	number	subhourly	Latent effectiveness (for _anherv)
SRE	X	X	number	subhourly	Hvi sensible recovery efficiency (for _anherv)



Name	Input?	Runtime?	Type	Variability	Description
ASRE	X	X	number	subhourly	Hvi adjusted sensible recovery efficiency (for _anherv)
RVFanHeatF	X	X	number	subhourly	Fraction of herv fan power that heats supply air (experimental)
vfExhRat	X	X	number	subhourly	Exhaust ratio (for _anherv) = (vfgross exhaust)/(vfgross supply)
EATR	X	X	number	subhourly	Exhaust air transfer ratio (for _anherv)
fan.fanTy	X	X	unrecognized	autosize and simulate phase start time	–
fan.vfDs	X	X	number	end of each subhour	–
fan.vfDs_As	X	X	number	autosize and simulate phase start time	–
fan.vfDs_AsNov	X	X	number	autosize and simulate phase start time	–
fan.vfMxF	X	X	number	autosize and simulate phase start time	–
fan.press	X	X	number	run start time (of each phase, autoSize or simulate)	–
fan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	–
fan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
fan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
fan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
fan.motEff	X	X	number	autosize and simulate phase start time	–
fan.motPos	X	X	unrecognized	autosize and simulate phase start time	–
fan.curvePy.k[0]	X	X	number	autosize and simulate phase start time	–
fan.curvePy.k[1]	X	X	number	autosize and simulate phase start time	–
fan.curvePy.k[2]	X	X	number	autosize and simulate phase start time	–
fan.curvePy.k[3]	X	X	number	autosize and simulate phase start time	–
fan.curvePy.k[4]	X	X	number	autosize and simulate phase start time	–
fan.curvePy.k[5]	X	X	number	autosize and simulate phase start time	–
fan.mtri	X	X	integer number	input time	–
fan.endUse	X	X	integer number	autosize and simulate phase start time	–
fan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
fan.outPower	X	X	number	subhourly	–
fan.airPower	X	X	number	subhourly	–
fan.cMx	X	X	number	end of each subhour	–
fan.c	X	X	number	end of each subhour	–
fan.t	X	X	number	end of each subhour	–
fan.frOn	X	X	number	end of each subhour	–
fan.p	X	X	number	end of each subhour	–
fan.q	X	X	number	end of each subhour	–
fan.dT	X	X	number	end of each subhour	–
fan.qAround	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
nvcoeff	X	X	number	run start time (of each phase, autoSize or simulate)	Nat vent overall coeff btuh/(dt <sup>.5</sup> ). set by izxsetup().
air1.tdb	X	X	number	end of each subhour	—
air1.w	X	X	number	end of each subhour	—
air2.tdb	X	X	number	end of each subhour	—
air2.w	X	X	number	end of each subhour	—
rho1	X	X	number	subhourly	Z1 moist air density, lb/cf
rho2	X	X	number	subhourly	Z2 moist air density, lb/cf (may be ambient)
ad[0].Ae	X	X	number	end of each subhour	Effective vent area, ft2; function of vent type and iz_cd
ad[0].AeLin	X	X	number	end of each subhour	Modified iz_ae, ft2; prevents discontinuity at delplinear
ad[0].delP	X	X	number	end of each subhour	Pressure diff across element, lbf/sf (+ = pz1 > pz2)
ad[0].mdotP	X	X	number	end of each subhour	Air mass flow rate, (lbm moist air)/sec (+ into z1)
ad[0].dmdp	X	X	number	end of each subhour	Derivative of iz_mdotp wrt pressure (0 for fix flow)
ad[0].mdotB	X	X	number	end of each subhour	Add'l buoyancy-driven mass flow, (lbm moist air)/sec
ad[0].mdotX	X	X	number	end of each subhour	Air mass exhaust flow, (lbm moist air)/sec (+ out of z2)
ad[0].xDelpF	X	X	number	end of each subhour	Buoyancy flooding pressure factor
ad[0].xMbm	X	X	number	end of each subhour	Buoyancy max possible flow factor
ad[0].tdFan	X	X	number	end of each subhour	Air stream temp rise across fan, f
ad[0].pFan	X	X	number	end of each subhour	Fan (electrical) power for meter, btuh ( <i>not</i> w)

Name	Input?	Runtime?	Type	Variability	Description
ad[1].Ae	X	X	number	end of each subhour	Effective vent area, ft <sup>2</sup> ; function of vent type and iz_cd
ad[1].AeLin	X	X	number	end of each subhour	Modified iz_ae, ft <sup>2</sup> ; prevents discontinuity at delplinear
ad[1].delP	X	X	number	end of each subhour	Pressure diff across element, lbf/sf (+ = pz1 > pz2)
ad[1].mdotP	X	X	number	end of each subhour	Air mass flow rate, (lbm moist air)/sec (+ into z1)
ad[1].dmdp	X	X	number	end of each subhour	Derivative of iz_mdotp wrt pressure (0 for fix flow)
ad[1].mdotB	X	X	number	end of each subhour	Add'l buoyancy-driven mass flow, (lbm moist air)/sec
ad[1].mdotX	X	X	number	end of each subhour	Air mass exhaust flow, (lbm moist air)/sec (+ out of z2)
ad[1].xDelpF	X	X	number	end of each subhour	Buoyancy flooding pressure factor
ad[1].xMbm	X	X	number	end of each subhour	Buoyancy max possible flow factor
ad[1].tdFan	X	X	number	end of each subhour	Air stream temp rise across fan, f
ad[1].pFan	X	X	number	end of each subhour	Fan (electrical) power for meter, btuh ( <i>not w</i> )
amfNom	X	X	number	end of each subhour	Nominal air mass flow, lbm/sec

### 6.39 kiva

@kiva[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
floor	–	X	integer number	run start time (of each phase, autoSize or simulate)	Floor reference

Name	Input?	Runtime?	Type	Variability	Description
perimWeight	–	X	number	run start time (of each phase, autoSize or simulate)	Weight of this kiva instance for results of corresponding floor

## 6.40 layer (owner: construction)

@layer[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
thk	X	–	number	input time	Thickness of layer, ft. dfl mt_thk else rqd. *i cuz veoi in cncult:lrt[].
mati	X	–	integer number	input time	Primary material (mat subscript). rqd.
frmMati	X	–	integer number	input time	Framing material in layer, 0 if unframed layer
frmFrac	X	–	number	input time	Fraction framing in layer. rqd if lrfmrmati nz.
uvy	X	–	number	run start time (of each phase, autoSize or simulate)	Conductivity: weighted combo of pri & framing; not specific to thickness.
r	X	–	number	run start time (of each phase, autoSize or simulate)	Layer r-value (for thk, per ft2)
vhc	X	–	number	run start time (of each phase, autoSize or simulate)	Volumetric heat capac (dens*spht, framing-weighted)

## 6.41 mass

@mass[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
sfi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Associated surface subscript
sfClass	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	Associated surface class (sfcsurf or sfcdoor)

Name	Input?	Runtime?	Type	Variability	Description
xri	–	X	integer number	run start time (of each phase, autoSize or simulate)	Xsrat subscript: ditto
area	–	X	number	run start time (of each phase, autoSize or simulate)	Area, ft2
isSubhrly	–	X	integer number	run start time (of each phase, autoSize or simulate)	True iff this mass simulated subhourly (else hourly)
isFD	–	X	integer number	run start time (of each phase, autoSize or simulate)	True iff this mass used forward-difference model (always subhourly)
inside.msi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Parent mass subscr
inside.ty	–	X	integer number	run start time (of each phase, autoSize or simulate)	Bound cond type: msbcadiabatic, msbcambient, msbcground, msbczone, or msbcspect.
inside.zi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Zone sbscr if .bc_ty == msbczone.
inside.exTa	–	X	number	hourly	Adjacent air temp, f
inside.exTr	–	X	number	hourly	Adjacent radiant temp, f
inside.rsurf	–	X	number	run start time (of each phase, autoSize or simulate)	Extra surf resis, from masstype, for “light” surf lyrs eg carpet: res for solar to 1st hvy lyr.
inside.h	–	X	number	run start time (of each phase, autoSize or simulate)	Combined surface conductance, air to 1st “heavy” layer (btuh/ft2-f)

Name	Input?	Runtime?	Type	Variability	Description
inside.ha	–	X	number	run start time (of each phase, autoSize or simulate)	Bc_h * area, btuh/f
inside.rIg	–	X	unrecognized	hourly	Radiant internal gain target (float) (btuh). pointed to by znr.rigdist; set/used in cnloads. 11-95
inside.qxhnet	–	X	number	end of each hour	Net heat xfer for hour (btu, + = into mass): signed sum of all transfers.
inside.qxdnet	–	X	number	end of each day	... ditto current day
inside.qxmnet	–	X	number	end of each month	... ditto current month
inside.qxhtot	–	X	number	end of each hour	Total xfer for hour (btu): sum of abs(xfer). used as divisor for determining relative error.
inside.qxdtot	–	X	number	end of each day	... ditto current day
inside.qxmtot	–	X	number	end of each month	... ditto current month
inside.surfTemp	–	X	number	end of each subhour	Probe-able duplicate copy of inside or outside layer surface temp, set in loadssurfaces.
outside.msi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Parent mass subscr
outside.ty	–	X	integer number	run start time (of each phase, autoSize or simulate)	Bound cond type: msbcadiabatic, msbcambient, msbcground, msbczone, or msbcspect.
outside.zi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Zone subscr if .bc_ty == msbczone.

Name	Input?	Runtime?	Type	Variability	Description
outside.exTa	–	X	number	hourly	Adjacent air temp, f
outside.exTr	–	X	number	hourly	Adjacent radiant temp, f
outside.rsurf	–	X	number	run start time (of each phase, autoSize or simulate)	Extra surf resis, from masstype, for “light” surf lyrs eg carpet: res for solar to 1st hvy lyr.
outside.h	–	X	number	run start time (of each phase, autoSize or simulate)	Combined surface conductance, air to 1st “heavy” layer (btuh/ft2-f)
outside.ha	–	X	number	run start time (of each phase, autoSize or simulate)	Bc_h * area, btuh/f
outside.rIg	–	X	unrecognized	hourly	Radiant internal gain target (float) (btuh). pointed to by znr.rigdist; set/used in cnloads. 11-95
outside.qxhnet	–	X	number	end of each hour	Net heat xfer for hour (btu, + = into mass): signed sum of all transfers.
outside.qxdnet	–	X	number	end of each day	... ditto current day
outside.qxmnet	–	X	number	end of each month	... ditto current month
outside.qxhtot	–	X	number	end of each hour	Total xfer for hour (btu): sum of abs(xfer). used as divisor for determining relative error.
outside.qxdtot	–	X	number	end of each day	... ditto current day
outside.qxmtot	–	X	number	end of each month	... ditto current month
outside.surfTemp	–	X	number	end of each subhour	Probe-able duplicate copy of inside or outside layer surface temp, set in loadssurfaces.



Name	Input?	Runtime?	Type	Variability	Description
UNom	–	X	number	run start time (of each phase, autoSize or simulate)	Overall uval incl nominal surface films, btuh/ft2-f
tc	–	X	number	run start time (of each phase, autoSize or simulate)	Time constant (con->hc/sfinh) as used to default sfmodel & issubhrly, for reporting, 1-95
pMM	–	X	un-probe-able	run start time (of each phase, autoSize or simulate)	Pointer to runtime mass model for this mass (type determined per input)

## 6.42 material

@material[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
thk	X	–	number	input time	-1 or optional default thickness, ft
cond	X	–	number	input time	Conductivity, btuh-ft/ft2-f (at mt_condtrat)
condTRat	X	–	number	input time	Rating temp for mt_cond, f (typically 70 f)
condCT	X	–	number	input time	Conductivity temp coefficient, 1/f
spHt	X	–	number	input time	Specific heat, btu/lb-f
dens	X	–	number	input time	0 (massless) or density, lb/ft3
rNom	X	–	number	input time	Nominal r of insulation, ft2-f/btuh-ft
vhc	X	–	number	run start time (of each phase, autoSize or simulate)	Volumetric heat capac (btu/ft3-f): mt_spht*mt_dens

## 6.43 meter

@meter[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
rate	X	X	number	input time	Cost per btu of use

Name	Input?	Runtime?	Type	Variability	Description
dmdRate	X	X	number	input time	Dmdcost per btu of demand, for a month
Y.tot	X	X	number	end of run (of each phase, autoSize or simulate)	Total of following specific end uses. code assumes precedes them.
Y.clg	X	X	number	end of run (of each phase, autoSize or simulate)	Space cooling. code assumes 1st member.
Y.htg	X	X	number	end of run (of each phase, autoSize or simulate)	Space heating incl heat pump compressor
Y.hp	X	X	number	end of run (of each phase, autoSize or simulate)	Heat pump auxiliary (backup) heat
Y.dhw	X	X	number	end of run (of each phase, autoSize or simulate)	Domestic (service) hot water heating
Y.dhwBU	X	X	number	end of run (of each phase, autoSize or simulate)	Domestic (service) hot water backup
Y.dhwMFL	X	X	number	end of run (of each phase, autoSize or simulate)	Domestic (service) multi-family loop energy
Y.fanC	X	X	number	end of run (of each phase, autoSize or simulate)	Fans - cooling and cooling ventilation
Y.fanH	X	X	number	end of run (of each phase, autoSize or simulate)	Fans - heating
Y.fanV	X	X	number	end of run (of each phase, autoSize or simulate)	Fans - iaq ventilation
Y.fan	X	X	number	end of run (of each phase, autoSize or simulate)	Fans - other
Y.aux	X	X	number	end of run (of each phase, autoSize or simulate)	Hvac auxiliaries and parasitics, not including fans

Name	Input?	Runtime?	Type	Variability	Description
Y.proc	X	X	number	end of run (of each phase, autoSize or simulate)	Process energy
Y.lit	X	X	number	end of run (of each phase, autoSize or simulate)	Lighting
Y.rcp	X	X	number	end of run (of each phase, autoSize or simulate)	Receptacles
Y.ext	X	X	number	end of run (of each phase, autoSize or simulate)	External – outdoor lights, etc
Y.refr	X	X	number	end of run (of each phase, autoSize or simulate)	Refrigeration
Y.dish	X	X	number	end of run (of each phase, autoSize or simulate)	Dish washing
Y.dry	X	X	number	end of run (of each phase, autoSize or simulate)	Clothes drying
Y.wash	X	X	number	end of run (of each phase, autoSize or simulate)	Clothes washing
Y.cook	X	X	number	end of run (of each phase, autoSize or simulate)	Cooking
Y.usr1	X	X	number	end of run (of each phase, autoSize or simulate)	User-defined end use 1
Y.usr2	X	X	number	end of run (of each phase, autoSize or simulate)	User-defined end use 2
Y.bt	X	X	number	end of run (of each phase, autoSize or simulate)	Battery output (negative)
Y.pv	X	X	number	end of run (of each phase, autoSize or simulate)	Photovoltaic array output (negative)

Name	Input?	Runtime?	Type	Variability	Description
Y.allEU	X	X	number	end of run (of each phase, autoSize or simulate)	Subtotal, clg .. usr2 (= load w/o bt and pv)
Y.cost	X	X	number	end of run (of each phase, autoSize or simulate)	Accumulated tot*rate
Y.dmdCost	X	X	number	end of run (of each phase, autoSize or simulate)	Largest dmd*dmdrate to month level, then accumulates (cnguts.cpp:mtraccum)
Y.dmd	X	X	number	end of run (of each phase, autoSize or simulate)	Peak use in interval; hourly value same as .tot.
Y.dmdShoy	X	X	unrecognized	end of run (of each phase, autoSize or simulate)	Peak time as subhour of year, subhr unused: $4(hr+24jday)$ .
M.tot	X	X	number	end of each month	Total of following specific end uses. code assumes precedes them.
M.clg	X	X	number	end of each month	Space cooling. code assumes 1st member.
M.htg	X	X	number	end of each month	Space heating incl heat pump compressor
M.hp	X	X	number	end of each month	Heat pump auxiliary (backup) heat
M.dhw	X	X	number	end of each month	Domestic (service) hot water heating
M.dhwBU	X	X	number	end of each month	Domestic (service) hot water backup
M.dhwMFL	X	X	number	end of each month	Domestic (service) multi-family loop energy
M.fanC	X	X	number	end of each month	Fans - cooling and cooling ventilation
M.fanH	X	X	number	end of each month	Fans - heating
M.fanV	X	X	number	end of each month	Fans - iaq ventilation
M.fan	X	X	number	end of each month	Fans - other
M.aux	X	X	number	end of each month	Hvac auxiliaries and parasitics, not including fans
M.proc	X	X	number	end of each month	Process energy
M.lit	X	X	number	end of each month	Lighting
M.rcp	X	X	number	end of each month	Receptacles

Name	Input?	Runtime?	Type	Variability	Description
M.ext	X	X	number	end of each month	External – outdoor lights, etc
M.refr	X	X	number	end of each month	Refrigeration
M.dish	X	X	number	end of each month	Dish washing
M.dry	X	X	number	end of each month	Clothes drying
M.wash	X	X	number	end of each month	Clothes washing
M.cook	X	X	number	end of each month	Cooking
M.usr1	X	X	number	end of each month	User-defined end use 1
M.usr2	X	X	number	end of each month	User-defined end use 2
M.bt	X	X	number	end of each month	Battery output (negative)
M.pv	X	X	number	end of each month	Photovoltaic array output (negative)
M.allEU	X	X	number	end of each month	Subtotal, clg .. usr2 (= load w/o bt and pv)
M.cost	X	X	number	end of each month	Accumulated tot*rate
M.dmdCost	X	X	number	end of each month	Largest dmd*dmdrate to month level, then accumulates (cnguts.cpp:mtraccum)
M.dmd	X	X	number	end of each month	Peak use in interval; hourly value same as .tot.
M.dmdShoy	X	X	unrecognized	end of each month	Peak time as subhour of year, subhr unused: $4(hr+24jday)$ .
D.tot	X	X	number	end of each day	Total of following specific end uses. code assumes precedes them.
D.clg	X	X	number	end of each day	Space cooling. code assumes 1st member.
D.htg	X	X	number	end of each day	Space heating incl heat pump compressor
D.hp	X	X	number	end of each day	Heat pump auxiliary (backup) heat
D.dhw	X	X	number	end of each day	Domestic (service) hot water heating
D.dhwBU	X	X	number	end of each day	Domestic (service) hot water backup
D.dhwMFL	X	X	number	end of each day	Domestic (service) multi-family loop energy
D.fanC	X	X	number	end of each day	Fans - cooling and cooling ventilation

Name	Input?	Runtime?	Type	Variability	Description
D.fanH	X	X	number	end of each day	Fans - heating
D.fanV	X	X	number	end of each day	Fans - iaq ventilation
D.fan	X	X	number	end of each day	Fans - other
D.aux	X	X	number	end of each day	Hvac auxiliaries and parasitics, not including fans
D.proc	X	X	number	end of each day	Process energy
D.lit	X	X	number	end of each day	Lighting
D.rcp	X	X	number	end of each day	Receptacles
D.ext	X	X	number	end of each day	External – outdoor lights, etc
D.refr	X	X	number	end of each day	Refrigeration
D.dish	X	X	number	end of each day	Dish washing
D.dry	X	X	number	end of each day	Clothes drying
D.wash	X	X	number	end of each day	Clothes washing
D.cook	X	X	number	end of each day	Cooking
D.usr1	X	X	number	end of each day	User-defined end use 1
D.usr2	X	X	number	end of each day	User-defined end use 2
D.bt	X	X	number	end of each day	Battery output (negative)
D.pv	X	X	number	end of each day	Photovoltaic array output (negative)
D.allEU	X	X	number	end of each day	Subtotal, clg .. usr2 (= load w/o bt and pv)
D.cost	X	X	number	end of each day	Accumulated tot*rate
D.dmdCost	X	X	number	end of each day	Largest dmd*dmdrate to month level, then accumulates (cnguts.cpp:mtraccum)
D.dmd	X	X	number	end of each day	Peak use in interval; hourly value same as .tot.
D.dmdShoy	X	X	unrecognized	end of each day	Peak time as subhour of year, subhr unused: $4(hr+24jday)$ .
H.tot	X	X	number	end of each hour	Total of following specific end uses. code assumes precedes them.

Name	Input?	Runtime?	Type	Variability	Description
H.clg	X	X	number	end of each hour	Space cooling. code assumes 1st member.
H.htg	X	X	number	end of each hour	Space heating incl heat pump compressor
H.hp	X	X	number	end of each hour	Heat pump auxiliary (backup) heat
H.dhw	X	X	number	end of each hour	Domestic (service) hot water heating
H.dhwBU	X	X	number	end of each hour	Domestic (service) hot water backup
H.dhwMFL	X	X	number	end of each hour	Domestic (service) multi-family loop energy
H.fanC	X	X	number	end of each hour	Fans - cooling and cooling ventilation
H.fanH	X	X	number	end of each hour	Fans - heating
H.fanV	X	X	number	end of each hour	Fans - iaq ventilation
H.fan	X	X	number	end of each hour	Fans - other
H.aux	X	X	number	end of each hour	Hvac auxiliaries and parasitics, not including fans
H.proc	X	X	number	end of each hour	Process energy
H.lit	X	X	number	end of each hour	Lighting
H.rcp	X	X	number	end of each hour	Receptacles
H.ext	X	X	number	end of each hour	External – outdoor lights, etc
H.refr	X	X	number	end of each hour	Refrigeration
H.dish	X	X	number	end of each hour	Dish washing
H.dry	X	X	number	end of each hour	Clothes drying
H.wash	X	X	number	end of each hour	Clothes washing
H.cook	X	X	number	end of each hour	Cooking
H.usr1	X	X	number	end of each hour	User-defined end use 1
H.usr2	X	X	number	end of each hour	User-defined end use 2
H.bt	X	X	number	end of each hour	Battery output (negative)
H.pv	X	X	number	end of each hour	Photovoltaic array output (negative)
H.allEU	X	X	number	end of each hour	Subtotal, clg .. usr2 (= load w/o bt and pv)

Name	Input?	Runtime?	Type	Variability	Description
H.cost	X	X	number	end of each hour	Accumulated tot*rate
H.dmdCost	X	X	number	end of each hour	Largest dmd*dmdrate to month level, then accumulates (cnguts.cpp:mtraccum)
H.dmd	X	X	number	end of each hour	Peak use in interval; hourly value same as .tot.
H.dmdShoy	X	X	unrecognized	end of each hour	Peak time as subhour of year, subhr unused: $4(hr+24jday)$ .

#### 6.44 perimeter (owner: zone)

@perimeter[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
prLen	X	–	number	input time	Length. input.
prF2	X	–	number	input time	Conduction per unit length. input.
xi	X	–	integer number	run start time (of each phase, autoSize or simulate)	Subscript in runtime xsurf rat, to facilitate access by probers 1-92

#### 6.45 PVArray

@PVArray[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mounting	X	X	unrecognized	input time	–
pnIdx	X	X	unrecognized	input time	–
area	X	X	number	input time	–
fBeam	X	X	number	end of each hour	–
fBeamErrCount	X	X	unrecognized	end of each hour	–
vrtInp[0]	X	X	number	input time	–
vrtInp[1]	X	X	number	input time	–
vrtInp[2]	X	X	number	input time	–
vrtInp[3]	X	X	number	input time	–
vrtInp[4]	X	X	number	input time	–
vrtInp[5]	X	X	number	input time	–
vrtInp[6]	X	X	number	input time	–
vrtInp[7]	X	X	number	input time	–
vrtInp[8]	X	X	number	input time	–
vrtInp[9]	X	X	number	input time	–
vrtInp[10]	X	X	number	input time	–



Name	Input?	Runtime?	Type	Variability	Description
vrtInp[11]	X	X	number	input time	—
vrtInp[12]	X	X	number	input time	—
vrtInp[13]	X	X	number	input time	—
vrtInp[14]	X	X	number	input time	—
vrtInp[15]	X	X	number	input time	—
vrtInp[16]	X	X	number	input time	—
vrtInp[17]	X	X	number	input time	—
vrtInp[18]	X	X	number	input time	—
vrtInp[19]	X	X	number	input time	—
vrtInp[20]	X	X	number	input time	—
vrtInp[21]	X	X	number	input time	—
vrtInp[22]	X	X	number	input time	—
vrtInp[23]	X	X	number	input time	—
vrtInp[24]	X	X	number	input time	—
vrtInp[25]	X	X	number	input time	—
vrtInp[26]	X	X	number	input time	—
vrtInp[27]	X	X	number	input time	—
vrtInp[28]	X	X	number	input time	—
vrtInp[29]	X	X	number	input time	—
vrtInp[30]	X	X	number	input time	—
vrtInp[31]	X	X	number	input time	—
vrtInp[32]	X	X	number	input time	—
vrtInp[33]	X	X	number	input time	—
vrtInp[34]	X	X	number	input time	—
vrtInp[35]	X	X	number	input time	—
vrtInp[36]	X	X	number	input time	—
elecMtri	X	X	integer number	input time	Meter for system electricity production
endUse	X	X	integer number	input time	End use of energy. defaults to “pv”
dcCap	X	X	number	input time	System capacity/size (dc nameplate), kw
moduleType	X	X	unrecognized	input time	Type of module (standard, premium, thinfilm)
tempCoeff	X	X	number	input time	Temperature coefficient, 1/f
covRefrInd	X	X	number	input time	Refraction index for coating applied to cover
arrayType	X	X	unrecognized	input time	Type of array (fixed, fixedroof, 1axis, backtracked, 2axis)
tilt	X	X	number	hourly	Array tilt, radians (input as degrees)

Name	Input?	Runtime?	Type	Variability	Description
azm	X	X	number	hourly	Array azimuth, radians (input as degrees)
grndRefl	X	X	number	hourly	Ground reflectance
gcr	X	X	number	input time	Ground coverage ratio (what fraction of the ground is covered by the array). 1.0 implies no spacing.
dcacRat	X	X	number	input time	Dc to ac ratio
sif	X	X	number	hourly	Shading impact factor
invEff	X	X	number	input time	Inverter efficiency at rated power
sysLoss	X	X	number	hourly	System losses
tCell	X	X	number	end of each hour	Cell temperature, f
aoi	X	X	number	end of each hour	Angle of incidence (radians)
panelTilt	X	X	number	end of each hour	Tilt of pv panel (different from array tilt for tracking systems), radians
panelAzm	X	X	number	end of each hour	Azimuth of pv panel (different from array tilt for tracking systems), radians
panelRot	X	X	number	end of each hour	Rotation of pv panel for 1-axis tracking systems, radians clockwise from vertical
poa	X	X	number	end of each hour	Plane of array incidence (before shading), btu/h-ft <sup>2</sup>
poaBeam	X	X	number	end of each hour	Plane of array beam incidence (before shading), btu/h-ft <sup>2</sup>
radIBeam	X	X	number	end of each hour	Beam radiation incident on array, btu/h-ft <sup>2</sup>

Name	Input?	Runtime?	Type	Variability	Description
radIBeamEff	X	X	number	end of each hour	Effective beam radiation incident on array (accounts for shading impact factor), btu/h-ft2
radI	X	X	number	end of each hour	Total radiation incident on array, btu/h-ft2
radIEff	X	X	number	end of each hour	Effective total radiation incident on array (accounts for shading impact factor), btu/h-ft2
radTrans	X	X	number	end of each hour	Transmitted radiation (after accounting for shading impact), btu/h-ft2
dcOut	X	X	number	end of each hour	Dc power output, btu
acOut	X	X	number	end of each hour	Ac power output, btu
tauNorm	X	X	number	run start time (of each phase, autoSize or simulate)	Transmittance at normal incidence
inoct	X	X	number	run start time (of each phase, autoSize or simulate)	Installed nominal operating cell temperature, f
convRatio	X	X	number	run start time (of each phase, autoSize or simulate)	Ratio of back convection to front convection
tGrndRatio	X	X	number	run start time (of each phase, autoSize or simulate)	Ratio of ground-cell temperature diff. to air-cell temperature diff.
radILs	X	X	number	end of each hour	Last step (currently hour) total radiation incident on array, btu/h-ft2
tCellLs	X	X	number	end of each hour	Last step (currently hour) cell temperature, f

**6.46 report (owner: reportFile)**

@report[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	—	string	constant	—
zi	X	—	integer number	input time	Zone for zone-specific reports. can be ti_sum, ti_all.
mtri	X	—	integer number	input time	Meter to report/export for meter-specific reports. can be ti_sum, ti_all.
ahi	X	—	integer number	input time	Air handler to report/export for air-handler-specific reports. can be ti_sum, ti_all.
tui	X	—	integer number	input time	Terminal to report/export for terminal-specific reports. can be ti_all
dhwMtri	X	—	integer number	input time	Dhw meter to report/export for dhw meter-specific reports. can be ti_all.
isExport	X	—	integer number	input time	1 if export not report, so same fcns can be used with rib and xib records
rpTy	X	—	integer number	constant	Report/export type c_rptych_eb etc
rpFreq	X	—	integer number	constant	R/xport frequency c_ivlch_m etc
rpDayBeg	X	—	integer number	input time	Start 1-based julian day of year, where applicable
rpDayEnd	X	—	integer number	input time	End ..
rpBtuSf	X	—	number	input time	Energy (btu) scale factor
rpCond	X	—	number	end of each subhour	Condition: if given, rpt lines omitted when false (si; li used to hold nan) (li currently unprobeable)
rpTitle	X	—	string	input time	Title, for udt, in dm
rpCpl	X	—	integer number	input time	Chars per line, inputtable re udt's
rpHeader	X	—	unrecognized	input time	Table header or export header yes/no (default yes)
rpFooter	X	—	integer number	input time	Table footer (summary line) or export footer (just blank line?) yes/no (default yes)

Name	Input?	Runtime?	Type	Variability	Description
coli	X	–	integer number	run start time (of each phase, autoSize or simulate)	Rcolb/xcolb subscript of first column (thence linked by .nxcoli).
nCol	X	–	integer number	run start time (of each phase, autoSize or simulate)	# columns
wid	X	–	integer number	run start time (of each phase, autoSize or simulate)	Total col width for user-defined report
vrh	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	Assigned virtual report handle, used from here to build unspoolinfo.

### 6.47 reportCol (owner: report)

@reportCol[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
colHead	X	X	string	input time	Column head string, in dm. *i cuz veoi in cncult.cpp:rpcolt[].
colGap	X	X	integer number	input time	Space to left of column, default 1
colWid	X	X	integer number	input time	Column width
colDec	X	X	integer number	input time	Coldecimals: max digits after point
colJust	X	X	integer number	input time	Justification: c_justch_1 or _r
colVal	X	X	un-probe-able	end of each subhour	Value .val and data type .dt (tyfl/tystr in input, dtfloat/dtchp in run), used at end report interval.
nxColi	X	X	integer number	constant	For runtime: col subscript of next column in this report, 0 if last one

### 6.48 reportFile

@reportFile[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
fileName	X	–	string	input time	File name, path optional, in dm (or pseudocode, but not “text”). *i cuz veoi in cncult.

Name	Input?	Runtime?	Type	Variability	Description
fileStat	X	–	integer number	run start time (of each phase, autoSize or simulate)	Fresh(overwrite,default)/new(err if exists)/append
pageFmt	X	–	integer number	input time	Page formatting on no/yes
fileStatChecked	X	–	integer number	run start time (of each phase, autoSize or simulate)	Check filestat only once to prevent “file exists” error or re-setting “overwrite” on later run
overWrite	X	–	integer number	run start time (of each phase, autoSize or simulate)	Append if 0. set by filestat=fresh, cleared on use, so addl runs do not erase earlier output.
wasNotEmpty	X	–	integer number	run start time (of each phase, autoSize or simulate)	Nz if existed and size > 0 at filestat check

## 6.49 RSYS

@RSYS[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
type	X	X	unrecognized	input time	System type (acfurn, acres, ashp, ac, furn, res)
desc	X	X	string	input time	Optional description string (e.g. model #)
perfMap	X	X	integer number	input time	If yes, make performance map (development aid)
areaServed	X	X	number	run start time (of each phase, autoSize or simulate)	Total zone floor area served by this rsys, ft2
zonesServed	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of zones served by this rsys
elecMtri	X	X	integer number	input time	Meter for system electricity use
fuelMtri	X	X	integer number	input time	Meter for system fuel use

Name	Input?	Runtime?	Type	Variability	Description
parElec	X	X	number	hourly	Electrical parasitic power, w
parFuel	X	X	number	hourly	Fuel parasitic consumption, btuh
capNomH	X	X	number	daily	Nominal heating capacity, btuh. default=rs_caph or rs_cap47
capNomC	X	X	number	daily	Nominal cooling capacity, btuh. default=rs_cap95
fan.fanTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
fan.vfDs	X	X	number	end of each subhour	—
fan.vfDs_As	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.vfDs_AsNov	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.vfMxF	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.press	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
fan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
fan.motEff	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.motPos	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[3]	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—
fan.curvePy.k[5]	X	X	number	run start time (of each phase, autoSize or simulate)	—



Name	Input?	Runtime?	Type	Variability	Description
fan.mtri	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
fan.endUse	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
fan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
fan.outPower	X	X	number	subhourly	—
fan.airPower	X	X	number	subhourly	—
fan.cMx	X	X	number	end of each subhour	—
fan.c	X	X	number	end of each subhour	—
fan.t	X	X	number	end of each subhour	—
fan.frOn	X	X	number	end of each subhour	—
fan.p	X	X	number	end of each subhour	—
fan.q	X	X	number	end of each subhour	—
fan.dT	X	X	number	end of each subhour	—
fan.qAround	X	X	number	end of each subhour	—
asRet.tdb	X	X	number	end of each subhour	—
asRet.w	X	X	number	end of each subhour	—
asIn.tdb	X	X	number	end of each subhour	—
asIn.w	X	X	number	end of each subhour	—
twbIn	X	X	number	end of each subhour	Entering air wet bulb (after return ducts)
asOut.tdb	X	X	number	end of each subhour	—
asOut.w	X	X	number	end of each subhour	—
asOutAux.tdb	X	X	number	end of each subhour	—
asOutAux.w	X	X	number	end of each subhour	—

Name	Input?	Runtime?	Type	Variability	Description
asSup.tdb	X	X	number	end of each subhour	–
asSup.w	X	X	number	end of each subhour	–
asSupAux.tdb	X	X	number	end of each subhour	–
asSupAux.w	X	X	number	end of each subhour	–
tSupLs	X	X	number	subhourly	... supply dry-bulb at last step, f
DSEH	X	X	number	hourly	Heating
DSEC	X	X	number	hourly	Cooling
isAuszH	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	True iff currently autosizing heating
isAuszC	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Ditto cooling rsys_cap95
tdDesH	X	X	number	run start time (of each phase, autoSize or simulate)	Design temperature difference (rise) across rsys for heating
tdDesC	X	X	number	run start time (of each phase, autoSize or simulate)	Design temperature difference (fall) across rsys for cooling
fxCap[0]	X	X	number	end of each subhour	Current step excess capacity factor = $\text{amfavailable} / \max(\text{amfrequest})$
fxCap[1]	X	X	number	end of each subhour	Current step excess capacity factor = $\text{amfavailable} / \max(\text{amfrequest})$
fxCapCDay	X	X	number	end of each hour	Current day excess cooling capacity factor
fxCapHDay	X	X	number	end of each hour	Ditto heating
fxCapHTarg	X	X	number	run start time (of each phase, autoSize or simulate)	Target excess capacity factor for heating autosize

Name	Input?	Runtime?	Type	Variability	Description
fxCapHAsF	X	X	number	run start time (of each phase, autoSize or simulate)	Working excess capacity factor for heating autosize
fxCapCTarg	X	X	number	run start time (of each phase, autoSize or simulate)	Target excess capacity factor for cooling autosize
fxCapCAsF	X	X	number	run start time (of each phase, autoSize or simulate)	Working excess capacity factor for cooling autosize
fxCapAuxHTarg	X	X	number	autosize and simulate phase start time	Target excess capacity factor for auxh autosize
auszH.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
auszH.az_a	X	X	number	end of each subhour	—
auszH.az_b	X	X	number	end of each subhour	—
auszH.ldPk	X	X	number	end of each subhour	—
auszH.ldPkAs	X	X	number	end of each day	—
auszH.ldPkAs1	X	X	number	end of each day	—
auszH.plrPk	X	X	number	end of each subhour	—
auszH.plrPkAs	X	X	number	end of each day	—
auszH.xPk	X	X	number	end of each subhour	—
auszH.xPkAs	X	X	number	end of each day	—
auszC.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
auszC.az_a	X	X	number	end of each subhour	—
auszC.az_b	X	X	number	end of each subhour	—

Name	Input?	Runtime?	Type	Variability	Description
auszC.ldPk	X	X	number	end of each subhour	–
auszC.ldPkAs	X	X	number	end of each day	–
auszC.ldPkAs1	X	X	number	end of each day	–
auszC.plrPk	X	X	number	end of each subhour	–
auszC.plrPkAs	X	X	number	end of each day	–
auszC.xPk	X	X	number	end of each subhour	–
auszC.xPkAs	X	X	number	end of each day	–
HSPF	X	X	number	run start time (of each phase, autoSize or simulate)	Rated hspf, btuh/w
cap47	X	X	number	end of each phase (autosize or simulate)	Full speed heating capacity at odb=47 f
COP47	X	X	number	end of each phase (autosize or simulate)	Cop at odb=47 f
cap35	X	X	number	end of each phase (autosize or simulate)	Ditto 35 f
COP35	X	X	number	end of each phase (autosize or simulate)	–
cap17	X	X	number	end of each phase (autosize or simulate)	Ditto 17 f
COP17	X	X	number	end of each phase (autosize or simulate)	–
CdH	X	X	number	end of each phase (autosize or simulate)	Heating cycling degradation factor
inp47	X	X	number	end of each phase (autosize or simulate)	Input power at outdoor dry-bulb = 47 f (btuh (not w))

Name	Input?	Runtime?	Type	Variability	Description
inp35	X	X	number	end of each phase (autosize or simulate)	Ditto 35 f
inp17	X	X	number	end of each phase (autosize or simulate)	Ditto 17 f
ASHPCapF[0]	X	X	number	run start time (of each phase, autoSize or simulate)	Capacity slope: $\text{cap}(t) = \text{cap17} + \text{capf}^*(t - 17)$
ASHPCapF[1]	X	X	number	run start time (of each phase, autoSize or simulate)	Capacity slope: $\text{cap}(t) = \text{cap17} + \text{capf}^*(t - 17)$
ASHPInpF[0]	X	X	number	run start time (of each phase, autoSize or simulate)	Input slope: $\text{inp}(t) = \text{inp17} + \text{inpf}^*(t - 17)$
ASHPInpF[1]	X	X	number	run start time (of each phase, autoSize or simulate)	Input slope: $\text{inp}(t) = \text{inp17} + \text{inpf}^*(t - 17)$
capAuxH	X	X	number	end of each phase (autosize or simulate)	Auxiliary heating capacity (not including fan heat), btuh
capAuxHInp	X	X	number	end of each phase (autosize or simulate)	Rs_capauxh as input (may be autosize)
COPAuxH	X	X	number	autosize and simulate phase start time	Auxiliary heating cop (assumed constant), default 1
ASHPLockOutT	X	X	number	hourly	Air source heat pump compressor lockout temp, f
defrostModel	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Defrost model
AFUE	X	X	number	autosize and simulate phase start time	Heating system rated afue, $0 < \text{afue} \leq 1$

Name	Input?	Runtime?	Type	Variability	Description
capH	X	X	number	end of each phase (autosize or simulate)	Rated heating output (including fan), btuh
capH_As	X	X	number	end of each phase (autosize or simulate)	—
capH_AsNov	X	X	number	end of each phase (autosize or simulate)	—
fanHRtdH	X	X	number	autosize and simulate phase start time	Fan heat included in ashp rated cap/cop/hspf, btuh
fanPwrH	X	X	number	autosize and simulate phase start time	Heating fan power, w/cfm
fanHeatH	X	X	number	end of each phase (autosize or simulate)	Heating fan total electrical power, btuh
amfH	X	X	number	end of each phase (autosize or simulate)	Heating dry air mass flow rate, lbm/hr
effHt	X	X	number	end of each subhour	Current step full load heating efficiency, dimless
capHt	X	X	number	end of each subhour	Current step heating capacity (including fan and ashp defrost heat), btuh
capDefrostHt	X	X	number	end of each subhour	Current step defrost heating capacity, btuh
PLF	X	X	number	end of each subhour	Efficiency degradation due to cycling
SEER	X	X	number	autosize and simulate phase start time	Cooling ahri rated seer, btuh/w
EER95	X	X	number	autosize and simulate phase start time	Cooling ahri rated eer at 95 f, btuh/w
cap95	X	X	number	end of each phase (autosize or simulate)	Rated total cooling capacity at 95 f, btuh todo: decide on sign

Name	Input?	Runtime?	Type	Variability	Description
cap95_As	X	X	number	end of each phase (autosize or simulate)	—
cap95_AsNov	X	X	number	end of each phase (autosize or simulate)	—
vfPerTon	X	X	number	autosize and simulate phase start time	Air flow ratio, cfm/ton (= cfm/(rs_cap95/12000))
fanPwrC	X	X	number	autosize and simulate phase start time	Cooling fan operating power ratio, w/cfm (default 0.365)
fanHeatC	X	X	number	end of each phase (autosize or simulate)	Cooling fan operating electrical power, btuh
fanDeltaTC	X	X	number	end of each phase (autosize or simulate)	Cooling fan heat temperature rise, f
amfC	X	X	number	end of each phase (autosize or simulate)	Cooling dry air mass flow rate, lbm/hr
CdC	X	X	number	end of each phase (autosize or simulate)	Cooling cycling degradation factor
rhInTest	X	X	number	end of each hour	Specified entering air relnum (for testing), 0-1
rhIn	X	X	number	end of each subhour	Plenum entering air relnum, 0-1
twbCoilIn	X	X	number	end of each subhour	Coil entering wet bulb, f (after blow-thru fan if any)
tdbCoilIn	X	X	number	end of each subhour	Coil entering dry bulb, f (ditto)
wetCoil	X	X	unrecognized	end of each subhour	1 = wet coil, 0 = dry coil
SHR	X	X	number	end of each subhour	Cooling sensible heat ratio (derived using coil model)
fChg	X	X	number	autosize and simulate phase start time	Refrigerant charge factor (default 1, 0.9 or 0.96 for ca compliance)

Name	Input?	Runtime?	Type	Variability	Description
fSize	X	X	number	autosize and simulate phase start time	Compressor sizing factor (default 1, 0.95 or 1 for ca compliance)
fanHRtdC	X	X	number	autosize and simulate phase start time	Fan heat included in rated rs_cap95, btuh
capnfX	X	X	number	autosize and simulate phase start time	Constant for rs_capct calc
capAdjF	X	X	number	autosize and simulate phase start time	—
SEERnfX	X	X	number	end of each phase (autosize or simulate)	Constant for rs_seernf calc
EERnfX	X	X	number	end of each phase (autosize or simulate)	Constant for rs_eernfcalc
fCondCap	X	X	number	end of each subhour	Conditions factor, capacity
fCondSEER	X	X	number	end of each subhour	Conditions factor, seer
fCondeER	X	X	number	end of each subhour	Conditions factor, eer
SEERnf	X	X	number	end of each subhour	Seer w/o fan power
EERnf	X	X	number	end of each subhour	Eer w/o fan power
EERt	X	X	number	end of each subhour	Compressor eer, btuh/w (temperature weighted mix of
effCt	X	X	number	end of each subhour	Temp adjusted compressor efficiency (= cet in acm)
capTotCt	X	X	number	end of each subhour	Coil total cooling capacity at current conditions, btuh (<0)
capLatCt	X	X	number	end of each subhour	Coil latent cooling capacity at current conditions, btuh (<0)
capSenCt	X	X	number	end of each subhour	Coil sensible cooling capacity at current conditions, btuh (<0)



Name	Input?	Runtime?	Type	Variability	Description
OAVType	X	X	unrecognized	input time	Type: none, fixedflow (aka smartvent), varflow (aka smartbreeze)
OAVReliefZi	X	X	integer number	input time	Oav relief zone index
OAVTdbInlet	X	X	number	subhourly	Oav inlet dry-bulb temp, f
OAVTdiff	X	X	number	hourly	Oav temperature differential, f
OAVAvfDs	X	X	number	input time	Oav design air flow rate, cfm actual air
OAVFanPwr	X	X	number	input time	Oav design fan power (based on rs_oavvfds), w/cfm
OAVAvfMinF	X	X	number	input time	Oav minimum volume flow (rs_avfoav always >= rs_oavavfminf *rs_oavavfds)
avfOAV	X	X	number	daily	Oav current air volume flow, cfm (set at beg of each day)
fanHeatOAV	X	X	number	daily	Ditto fan power, btuh
amfOAV	X	X	number	daily	Ditto air mass flow, lbm/hr
tdbOut	X	X	number	subhourly	Outdoor dry-bulb temp at condensor or other outdoor components, f
modeCtrl	X	X	unrecognized	hourly	Mode control (off, heat, cool, auto )
mode	X	X	unrecognized	end of each subhour	Mode (rsmoff, rsmheat, rsmcool, rsmoav )
modeLs	X	X	unrecognized	subhourly	Last step mode (rsmoff, rsmheat, rsmcool, rsmoav )
amf	X	X	number	end of each subhour	Full-load (maximum) dry air mass flow rate, lbm/hr
amfReq[0]	X	X	number	end of each subhour	Total amf (at system) requested by zones, lbm/hr
amfReq[1]	X	X	number	end of each subhour	Total amf (at system) requested by zones, lbm/hr
runF	X	X	number	end of each subhour	Run fraction
runFLs	X	X	number	subhourly	Last step run fraction (for probe access at step beg)

Name	Input?	Runtime?	Type	Variability	Description
runFAux	X	X	number	end of each subhour	Auxiliary run fraction
outSen	X	X	number	end of each subhour	Average primary sensible heat delivery rate for last subhr, btuh
outLat	X	X	number	end of each subhour	Ditto latent, btuh
outFan	X	X	number	end of each subhour	Ditto fan heat added to air stream, btuh
outDefrost	X	X	number	end of each subhour	Ditto defrost heat, btuh
outAux	X	X	number	end of each subhour	Ditto auxiliary heat added to air stream, btuh (for ashp)
FEffH	X	X	number	subhourly	Heating
FEffC	X	X	number	subhourly	Cooling
inPrimary	X	X	number	end of each subhour	Primary input, btuh (compressor, burner, )
inFan	X	X	number	end of each subhour	Fan electricity input, btuh (not kwh)
inDefrost	X	X	number	end of each subhour	Defrost heating input, btuh (ashp only)
inAux	X	X	number	end of each subhour	Auxiliary heating input, btuh

## 6.50 RSYRes

@RSYRes[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
Y.n	–	X	unrecognized	end of run (of each phase, autoSize or simulate)	–
Y.hrsOn	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.hrsOnAux	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qh	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qcSen	–	X	number	end of run (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
Y.qcLat	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qFan	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qDefrost	–	X	number	end of run (of each phase, autoSize or simulate)	–
Y.qAux	–	X	number	end of run (of each phase, autoSize or simulate)	–
M.n	–	X	unrecognized	end of each month	–
M.hrsOn	–	X	number	end of each month	–
M.hrsOnAux	–	X	number	end of each month	–
M.qh	–	X	number	end of each month	–
M.qcSen	–	X	number	end of each month	–
M.qcLat	–	X	number	end of each month	–
M.qFan	–	X	number	end of each month	–
M.qDefrost	–	X	number	end of each month	–
M.qAux	–	X	number	end of each month	–
D.n	–	X	unrecognized	end of each day	–
D.hrsOn	–	X	number	end of each day	–
D.hrsOnAux	–	X	number	end of each day	–
D.qh	–	X	number	end of each day	–
D.qcSen	–	X	number	end of each day	–
D.qcLat	–	X	number	end of each day	–
D.qFan	–	X	number	end of each day	–
D.qDefrost	–	X	number	end of each day	–
D.qAux	–	X	number	end of each day	–
H.n	–	X	unrecognized	end of each hour	–
H.hrsOn	–	X	number	end of each hour	–
H.hrsOnAux	–	X	number	end of each hour	–
H.qh	–	X	number	end of each hour	–
H.qcSen	–	X	number	end of each hour	–
H.qcLat	–	X	number	end of each hour	–
H.qFan	–	X	number	end of each hour	–
H.qDefrost	–	X	number	end of each hour	–
H.qAux	–	X	number	end of each hour	–

Name	Input?	Runtime?	Type	Variability	Description
S.n	–	X	unrecognized	end of each subhour	–
S.hrsOn	–	X	number	end of each subhour	–
S.hrsOnAux	–	X	number	end of each subhour	–
S.qh	–	X	number	end of each subhour	–
S.qcSen	–	X	number	end of each subhour	–
S.qcLat	–	X	number	end of each subhour	–
S.qFan	–	X	number	end of each subhour	–
S.qDefrost	–	X	number	end of each subhour	–
S.qAux	–	X	number	end of each subhour	–
prior.Y.n	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
prior.Y.hrsOn	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.hrsOnAux	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.qh	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.qcSen	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.qcLat	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.qFan	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.Y.qDefrost	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
prior.Y.qAux	–	X	number	run start time (of each phase, autoSize or simulate)	–
prior.M.n	–	X	unrecognized	monthly	–
prior.M.hrsOn	–	X	number	monthly	–
prior.M.hrsOnAux	–	X	number	monthly	–
prior.M.qh	–	X	number	monthly	–
prior.M.qcSen	–	X	number	monthly	–
prior.M.qcLat	–	X	number	monthly	–
prior.M.qFan	–	X	number	monthly	–
prior.M.qDefrost	–	X	number	monthly	–
prior.M.qAux	–	X	number	monthly	–
prior.D.n	–	X	unrecognized	daily	–
prior.D.hrsOn	–	X	number	daily	–
prior.D.hrsOnAux	–	X	number	daily	–
prior.D.qh	–	X	number	daily	–
prior.D.qcSen	–	X	number	daily	–
prior.D.qcLat	–	X	number	daily	–
prior.D.qFan	–	X	number	daily	–
prior.D.qDefrost	–	X	number	daily	–
prior.D.qAux	–	X	number	daily	–
prior.H.n	–	X	unrecognized	hourly	–
prior.H.hrsOn	–	X	number	hourly	–
prior.H.hrsOnAux	–	X	number	hourly	–
prior.H.qh	–	X	number	hourly	–
prior.H.qcSen	–	X	number	hourly	–
prior.H.qcLat	–	X	number	hourly	–
prior.H.qFan	–	X	number	hourly	–
prior.H.qDefrost	–	X	number	hourly	–
prior.H.qAux	–	X	number	hourly	–
prior.S.n	–	X	unrecognized	subhourly	–
prior.S.hrsOn	–	X	number	subhourly	–
prior.S.hrsOnAux	–	X	number	subhourly	–
prior.S.qh	–	X	number	subhourly	–
prior.S.qcSen	–	X	number	subhourly	–
prior.S.qcLat	–	X	number	subhourly	–
prior.S.qFan	–	X	number	subhourly	–
prior.S.qDefrost	–	X	number	subhourly	–
prior.S.qAux	–	X	number	subhourly	–

## 6.51 sgdist (owner: window)

@sgdist[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
sgSide	X	–	integer number	input time	C_sidech_interior or _exterior - side rcving gain

Name	Input?	Runtime?	Type	Variability	Description
targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
targTi	X	–	integer number	input time	–
FSO	X	–	number	monthly-hourly	–
FSC	X	–	number	monthly-hourly	–

## 6.52 shade (owner: window)

@shade[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
wWidth	X	X	number	run start time (of each phase, autoSize or simulate)	Wwidth window width. *r: set (from window) by input check/setup (topckf).
wHeight	X	X	number	run start time (of each phase, autoSize or simulate)	Wheight window height
ohDepth	X	X	number	monthly-hourly	Ohdepth depth of overhang. *mh: may change monthly-hourly: m-h user exprs accepted.
ohDistUp	X	X	number	monthly-hourly	Ohwd distance from top of window to bot of oh
ohExL	X	X	number	monthly-hourly	Ohlx overhang extension beyond left edge of window
ohExR	X	X	number	monthly-hourly	Ohrx ditto right edge
ohFlap	X	X	number	monthly-hourly	Ohflap len of flap hanging down from front of overhang
lfDepth	X	X	number	monthly-hourly	Fldepth left fin depth
lfTopUp	X	X	number	monthly-hourly	Fltx left fin top of window to top of fin
lfDistL	X	X	number	monthly-hourly	Flwd left fin distance to left edge of window
lfBotUp	X	X	number	monthly-hourly	Flwbx left fin bottom to window bottom distance
rfDepth	X	X	number	monthly-hourly	Frdepth right fin values analogous to left
rfTopUp	X	X	number	monthly-hourly	Frtx
rfDistR	X	X	number	monthly-hourly	Frwd
rfBotUp	X	X	number	monthly-hourly	Frwbx

## 6.53 SHADEX

@SHADEX[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
mounting	X	X	unrecognized	input time	Mounting
pnIdx	X	X	unrecognized	input time	Penumbra surface index
area	X	X	number	input time	Area derived from polygon, ft <sup>2</sup>
fBeam	X	X	number	end of each hour	Fraction of area receiving direct beam
fBeamErrCount	X	X	unrecognized	end of each hour	Counter for fbeam > 1 errors
virtInp[0]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[1]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[2]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[3]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[4]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[5]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[6]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[7]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[8]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[9]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[10]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[11]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[12]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[13]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[14]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[15]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[16]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[17]	X	X	number	input time	Input vertices (x, y, z), ft
virtInp[18]	X	X	number	input time	Input vertices (x, y, z), ft

Name	Input?	Runtime?	Type	Variability	Description
vrtInp[19]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[20]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[21]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[22]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[23]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[24]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[25]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[26]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[27]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[28]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[29]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[30]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[31]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[32]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[33]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[34]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[35]	X	X	number	input time	Input vertices (x, y, z), ft
vrtInp[36]	X	X	number	input time	Input vertices (x, y, z), ft

### 6.54 *surface (owner: zone)*

@surface[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
ty	X	–	integer	input time	–
area	X	–	number	run start time (of each phase, autoSize or simulate)	–



Name	Input?	Runtime?	Type	Variability	Description
azm	X	–	number	run start time (of each phase, autoSize or simulate)	–
tilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
depthBG	X	–	number	run start time (of each phase, autoSize or simulate)	–
height	X	–	number	run start time (of each phase, autoSize or simulate)	... and to compute area b4 mutliplier.
model	X	–	integer number	input time	–
modelr	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
lThkF	X	–	number	run start time (of each phase, autoSize or simulate)	–
gti	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sco	X	–	number	monthly- hourly	–
scc	X	–	number	monthly- hourly	–
sbcI.absSlr	X	–	number	monthly- hourly	–
sbcI.awAbsSlr	X	–	number	monthly- hourly	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcI.F	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcNat	X	–	number	end of each subhour	–
sbcI.hcFre	X	–	number	end of each subhour	–
sbcI.hcMult	X	–	number	end of each subhour	–
sbcI.hxa	X	–	number	end of each subhour	–
sbcI.hxr	X	–	number	end of each subhour	–
sbcI.hxtot	X	–	number	end of each subhour	–
sbcI.uRat	X	–	number	end of each subhour	–
sbcI.fRat	X	–	number	end of each subhour	–
sbcI.cx	X	–	number	end of each subhour	–
sbcI.sgTarg.bm	X	–	number	end of each subhour	–
sbcI.sgTarg.df	X	–	number	end of each subhour	–
sbcI.sgTarg.tot	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.sg	X	–	number	end of each subhour	–
sbcI.tSrf	X	–	number	end of each subhour	–
sbcI.tSrfls	X	–	number	subhourly	–
sbcI.qrAbs	X	–	number	end of each subhour	–
sbcI.txa	X	–	number	end of each subhour	–
sbcI.txr	X	–	number	end of each subhour	–
sbcI.txe	X	–	number	end of each subhour	–
sbcI.w	X	–	number	end of each subhour	–
sbcI.qSrf	X	–	number	end of each subhour	–
sbcI.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.eta	X	–	number	end of each subhour	–
sbcI.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.absSlr	X	–	number	monthly- hourly	–
sbcO.awAbsSlr	X	–	number	monthly- hourly	–
sbcO.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcO.F	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcNat	X	–	number	end of each subhour	–
sbcO.hcFrc	X	–	number	end of each subhour	–
sbcO.hcMult	X	–	number	end of each subhour	–
sbcO.hxa	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.hxr	X	–	number	end of each subhour	–
sbcO.hxtot	X	–	number	end of each subhour	–
sbcO.uRat	X	–	number	end of each subhour	–
sbcO.fRat	X	–	number	end of each subhour	–
sbcO.cx	X	–	number	end of each subhour	–
sbcO.sgTarg.bm	X	–	number	end of each subhour	–
sbcO.sgTarg.df	X	–	number	end of each subhour	–
sbcO.sgTarg.tot	X	–	number	end of each subhour	–
sbcO.sg	X	–	number	end of each subhour	–
sbcO.tSrf	X	–	number	end of each subhour	–
sbcO.tSrfls	X	–	number	subhourly	–
sbcO.qrAbs	X	–	number	end of each subhour	–
sbcO.txa	X	–	number	end of each subhour	–
sbcO.txr	X	–	number	end of each subhour	–
sbcO.txe	X	–	number	end of each subhour	–
sbcO.w	X	–	number	end of each subhour	–
sbcO.qSrf	X	–	number	end of each subhour	–
sbcO.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.eta	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
fenModel	X	–	unrecognized	input time	–
SHGC	X	–	number	input time	–
fMult	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNFRC	X	–	number	input time	–
NGlz	X	–	integer number	input time	–
exShd	X	–	unrecognized	input time	–
inShd	X	–	unrecognized	input time	–
dirtLoss	X	–	number	run start time (of each phase, autoSize or simulate)	–
sfExCnd	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sfExT	X	–	number	subhourly	–
sfAdjZi	X	–	integer number	input time	–



Name	Input?	Runtime?	Type	Variability	Description
uI	X	–	number	run start time (of each phase, autoSize or simulate)	–
uC	X	–	number	run start time (of each phase, autoSize or simulate)	–
uX	X	–	number	run start time (of each phase, autoSize or simulate)	–
Rf	X	–	number	run start time (of each phase, autoSize or simulate)	–
grndRefl	X	–	number	monthly- hourly	–
vfSkyDf	X	–	number	monthly- hourly	–
vfGrndDf	X	–	number	monthly- hourly	–
vfSkyLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
vfGrndLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
uval	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
UANom	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
hSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
cFctr	X	–	number	run start time (of each phase, autoSize or simulate)	–
iwshad	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
msi	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model
tLrB[0]	X	–	number	end of each hour	–
tLrB[1]	X	–	number	end of each hour	–
tLrB[2]	X	–	number	end of each hour	–
tLrB[3]	X	–	number	end of each hour	–
tLrB[4]	X	–	number	end of each hour	–
tLrB[5]	X	–	number	end of each hour	–
tLrB[6]	X	–	number	end of each hour	–
tLrB[7]	X	–	number	end of each hour	–
tLrB[8]	X	–	number	end of each hour	–
tLrB[9]	X	–	number	end of each hour	–
nsgdist	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[0].FSO	X	–	number	monthly- hourly	–
sgdist[0].FSC	X	–	number	monthly- hourly	–
sgdist[1].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].FSO	X	–	number	monthly- hourly	–
sgdist[1].FSC	X	–	number	monthly- hourly	–
sgdist[2].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].FSO	X	–	number	monthly- hourly	–
sgdist[2].FSC	X	–	number	monthly- hourly	–
sgdist[3].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].FSO	X	–	number	monthly- hourly	–
sgdist[3].FSC	X	–	number	monthly- hourly	–
sgdist[4].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].FSO	X	–	number	monthly- hourly	–
sgdist[4].FSC	X	–	number	monthly- hourly	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[5].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].FSO	X	–	number	monthly- hourly	–
sgdist[5].FSC	X	–	number	monthly- hourly	–
sgdist[6].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].FSO	X	–	number	monthly- hourly	–
sgdist[6].FSC	X	–	number	monthly- hourly	–
sgdist[7].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].FSO	X	–	number	monthly- hourly	–
sgdist[7].FSC	X	–	number	monthly- hourly	–
sfClass	X	–	unrecognized	input time	Sfcnul, sfcsurf, sfcdoor, sf>window
sfArea	X	–	number	input time	Surface: gross area, net in x.xs_area.
sfU	X	–	number	input time	Uval input if no sfcon given (excl surf films)
sfCon	X	–	integer number	input time	Surface construction (optional)
sfTy	X	–	integer number	constant	Wall/floor/ceil/[intmass1/2]: for input cking.
sfFnd	X	–	integer number	input time	Surface foundation object (floors only, optional)
sfFndFloor	X	–	integer number	input time	Surface foundation floor object (walls only, optional)

Name	Input?	Runtime?	Type	Variability	Description
sfExpPerim	X	–	number	input time	Foundation floor exposed perimeter (floors only)
width	X	–	number	input time	Width and height: used to compute shading,
height	X	–	number	input time	... and to compute area b4 mutliplier.
mult	X	–	number	input time	Area multiplier (for multiple identical windows)
xi	X	–	integer number	run start time (of each phase, autoSize or simulate)	Subscript in runtime xsrat, to facilitate access by probers 1-92
msi	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model

## 6.55 terminal (owner: zone)

@terminal[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
tuVfMxHC	X	X	unrecognized	autosize and simulate phase start time	Autosize tuvfmhx and -c same or (default) different.
tuOversize	X	X	number	autosize and simulate phase start time	Fraction oversize to make autosized terminal values
asHcSame	X	X	integer number	run start time (of each phase, autoSize or simulate)	True to autosize tuvfmhx and -c the same – specified with “tuvfmhxc = same”
asKVVol	X	X	integer number	run start time (of each phase, autoSize or simulate)	True to autosize for constant volume – specified with “autosize tuvfmn” (implies ashcsame).
hcAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
hcAs.az_a	X	X	number	end of each subhour	–
hcAs.az_b	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
hcAs.ldPk	X	X	number	end of each subhour	—
hcAs.ldPkAs	X	X	number	end of each day	—
hcAs.ldPkAs1	X	X	number	end of each day	—
hcAs.plrPk	X	X	number	end of each subhour	—
hcAs.plrPkAs	X	X	number	end of each day	—
hcAs.xPk	X	X	number	end of each subhour	—
hcAs.xPkAs	X	X	number	end of each day	—
vhAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
vhAs.az_a	X	X	number	end of each subhour	—
vhAs.az_b	X	X	number	end of each subhour	—
vhAs.ldPk	X	X	number	end of each subhour	—
vhAs.ldPkAs	X	X	number	end of each day	—
vhAs.ldPkAs1	X	X	number	end of each day	—
vhAs.plrPk	X	X	number	end of each subhour	—
vhAs.plrPkAs	X	X	number	end of each day	—
vhAs.xPk	X	X	number	end of each subhour	—
vhAs.xPkAs	X	X	number	end of each day	—
vcAs.az_active	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
vcAs.az_a	X	X	number	end of each subhour	—
vcAs.az_b	X	X	number	end of each subhour	—
vcAs.ldPk	X	X	number	end of each subhour	—
vcAs.ldPkAs	X	X	number	end of each day	—
vcAs.ldPkAs1	X	X	number	end of each day	—

Name	Input?	Runtime?	Type	Variability	Description
vcAs.plrPk	X	X	number	end of each subhour	–
vcAs.plrPkAs	X	X	number	end of each day	–
vcAs.xPk	X	X	number	end of each subhour	–
vcAs.xPkAs	X	X	number	end of each day	–
qhPk	X	X	number	end of each subhour	–
qcPk	X	X	number	end of each subhour	Peak values of qh and qc, for load reports and -pkas's. qc negative.
qhPkAs	X	X	number	end of each subhour	–
qcPkAs	X	X	number	end of each subhour	Peak values for all autosize converged design days, for size reports
bVfMn	X	X	number	end of each subhour	–
bVfMxH	X	X	number	end of each subhour	–
bVfMxC	X	X	number	end of each subhour	–
dtLoHSh	X	X	integer number	end of each subhour	–
dtLoCSh	X	X	integer number	end of each subhour	.. this subhr, set in cnztu.cpp:ztumode, cleared in ztuabs.
aDtLoHSh	X	X	integer number	end of each subhour	–
aDtLoCSh	X	X	integer number	end of each subhour	.. this subhr, set at end of cnah1.cpp:ahcompute
aDtLoTem	X	X	integer number	end of each subhour	Cnah2:antratts to ahcompute temp flag re adtlohsh, csh
dtLoH	X	X	integer number	end of each subhour	–
dtLoC	X	X	integer number	end of each subhour	.. on this autosizing design day iteration (or poss run)
dtLoHAs	X	X	integer number	end of each day	–
dtLoCAs	X	X	integer number	end of each subhour	.. on any converged pass 2 design day: invokes endautosizing() message.
tuTLh	X	X	number	hourly	Local heating set point for tstat control. hourly. default: no tstat control.

Name	Input?	Runtime?	Type	Variability	Description
tuQMnLh	X	X	number	hourly	Desired continuous output (btuh) if no setpoint, or minimum if tutlh given, hourly, default 0.
tuQMxLh	X	X	number	hourly	Max desired power, subject to plant limits, btuh, hourly, rqd if tutlh given, else disallowed.
tuPriLh	X	X	integer number	autosize and simulate phase start time	Priority if setpoint equals another, low #'s used first, dfl 100, disallowed if tutlh not given.
tuLhNeedsFlow	X	X	integer number	autosize and simulate phase start time	Yes to disable lh when tu fan off and central fan off or vav flow 0 (coil in terminal).
tuhc.coilTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
tuhc.sched	X	X	unrecognized	hourly	–
tuhc.captRat	X	X	number	end of each subhour	–
tuhc.captRat_As	X	X	number	autosize and simulate phase start time	–
tuhc.captRat_AsNov	X	X	number	autosize and simulate phase start time	–
tuhc.bCaptRat	X	X	number	end of each subhour	–
tuhc.eirRat	X	X	number	hourly	–
tuhc.mtri	X	X	integer number	autosize and simulate phase start time	–
tuhc.auxOn	X	X	number	hourly	–
tuhc.auxOnMtri	X	X	integer number	autosize and simulate phase start time	–
tuhc.auxOff	X	X	number	hourly	–
tuhc.auxOffMtri	X	X	integer number	autosize and simulate phase start time	–
tuhc.auxOnAtall	X	X	number	hourly	–



Name	Input?	Runtime?	Type	Variability	Description
tuhc.auxOnAtallMtri	X	X	integer number	autosize and simulate phase start time	–
tuhc.auxFullOff	X	X	number	hourly	–
tuhc.auxFullOffMtri	X	X	integer number	autosize and simulate phase start time	–
tuhc.q	X	X	number	end of each subhour	–
tuhc.qPr	X	X	number	end of each subhour	–
tuhc.p	X	X	number	end of each subhour	–
tuhc.plr	X	X	number	end of each subhour	–
tuhc.plrAv	X	X	number	end of each subhour	–
tuhc.eir	X	X	number	end of each subhour	–
tuhc.pAuxOn	X	X	number	end of each subhour	–
tuhc.pAuxOff	X	X	number	end of each subhour	–
tuhc.pAuxOnAtall	X	X	number	end of each subhour	–
tuhc.pAuxFullOff	X	X	number	end of each subhour	–
tuhc.effRat	X	X	number	autosize and simulate phase start time	–
tuhc.pyEi.k[0]	X	X	number	autosize and simulate phase start time	–
tuhc.pyEi.k[1]	X	X	number	autosize and simulate phase start time	–
tuhc.pyEi.k[2]	X	X	number	autosize and simulate phase start time	–
tuhc.pyEi.k[3]	X	X	number	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
tuhc.pyEi.k[4]	X	X	number	autosize and simulate phase start time	–
tuhc.stackEffect	X	X	number	hourly	–
tuhc.hpi	X	X	integer number	autosize and simulate phase start time	–
tuhc.nxTu4hp	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
tuhc.nxAh4hp	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
tuhc.flueLoss	X	X	number	end of each subhour	–
tuhc.qWant	X	X	number	end of each subhour	–
tuTH	X	X	number	hourly	Air heating set point (f). hourly. default: no tstat-controlled air heating.
tuTC	X	X	number	hourly	Air cooling set point (f). hourly. default: no tstat-controlled air cooling.
tuVfMn	X	X	number	end of each subhour	Min flow (cfm actual air); if no setpoints given, this is “specified output”. hourly, dlf 0.
tuVfMn_As	X	X	number	autosize and simulate phase start time	–
tuVfMn_AsNov	X	X	number	autosize and simulate phase start time	–
ai	X	X	integer number	input time	0 or ah ss (subscript) for air handler serving tu (input as air handler name). rqd if sp or mn given.
tuVfMxH	X	X	number	end of each subhour	Heating max flow (cfm actual air) b4 ah limits, hourly, rqd if tuth given else disallowed

Name	Input?	Runtime?	Type	Variability	Description
tuVfMxH_As	X	X	number	autosize and simulate phase start time	–
tuVfMxH_AsNov	X	X	number	autosize and simulate phase start time	–
tuVfMxC	X	X	number	end of each subhour	Cooling max flow (cfm actual air) b4 ah limits, hourly, rqd if tute given else disallowed
tuVfMxC_As	X	X	number	autosize and simulate phase start time	–
tuVfMxC_AsNov	X	X	number	autosize and simulate phase start time	–
tuVfDs	X	X	number	run start time (of each phase, autoSize or simulate)	Design flow (cfm actual air), constant, to apportion flow when ah fan overloads.
tuPriH	X	X	integer number	autosize and simulate phase start time	Heat setpoint priority: lowest # used first when equal setpoints in zone. const. default: 1.
tuPriC	X	X	integer number	autosize and simulate phase start time	Cool likewise. ... rqd if corress sp given, else disallowed.
tuSRLeak	X	X	number	autosize and simulate phase start time	Leakage 0-.5 of supply air to return, increasing supply vol and return temp. constant; dfl .05.
tuSRLoss	X	X	number	run start time (of each phase, autoSize or simulate)	Supply air to return plenum heat loss as a fraction 0 - .5 of supply air to return air
tfanSch	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Terminal fan schedule, choice of off, on, heating, or vav, hourly, rqd if tfantype not none.
tfanOffLeak	X	X	number	run start time (of each phase, autoSize or simulate)	Backdraft leakage when fan off, 0 to .25 of tfanvfds, constant, dfl .1, or 0 if no fan.

Name	Input?	Runtime?	Type	Variability	Description
tfan.fanTy	X	X	unrecognized	autosize and simulate phase start time	–
tfan.vfDs	X	X	number	end of each subhour	–
tfan.vfDs_As	X	X	number	autosize and simulate phase start time	–
tfan.vfDs_AsNov	X	X	number	autosize and simulate phase start time	–
tfan.vfMxF	X	X	number	autosize and simulate phase start time	–
tfan.press	X	X	number	run start time (of each phase, autoSize or simulate)	–
tfan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	–
tfan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
tfan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
tfan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
tfan.motEff	X	X	number	autosize and simulate phase start time	–
tfan.motPos	X	X	unrecognized	autosize and simulate phase start time	–

Name	Input?	Runtime?	Type	Variability	Description
tfan.curvePy.k[0]	X	X	number	autosize and simulate phase start time	–
tfan.curvePy.k[1]	X	X	number	autosize and simulate phase start time	–
tfan.curvePy.k[2]	X	X	number	autosize and simulate phase start time	–
tfan.curvePy.k[3]	X	X	number	autosize and simulate phase start time	–
tfan.curvePy.k[4]	X	X	number	autosize and simulate phase start time	–
tfan.curvePy.k[5]	X	X	number	autosize and simulate phase start time	–
tfan.mtri	X	X	integer number	input time	–
tfan.endUse	X	X	integer number	autosize and simulate phase start time	–
tfan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	–
tfan.outPower	X	X	number	subhourly	–
tfan.airPower	X	X	number	subhourly	–
tfan.cMx	X	X	number	end of each subhour	–
tfan.c	X	X	number	end of each subhour	–
tfan.t	X	X	number	end of each subhour	–
tfan.frOn	X	X	number	end of each subhour	–
tfan.p	X	X	number	end of each subhour	–
tfan.q	X	X	number	end of each subhour	–
tfan.dT	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
tfan.qAround	X	X	number	end of each subhour	–
nxTu4z	X	X	integer number	run start time (of each phase, autoSize or simulate)	Chain: 0 or ss (subscript) of next tu in zone chain. head is znr.tu1.
nxTu4a	X	X	integer number	run start time (of each phase, autoSize or simulate)	Chain: 0 or ss (subscript) of next tu in air handler chain. head is ah.tu1.
xiLh	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of zhx for terminal's local heat capability
xiArH	X	X	integer number	run start time (of each phase, autoSize or simulate)	Ss of zhx for setout air heat/cool or settemp air heat capability
xiArC	X	X	integer number	run start time (of each phase, autoSize or simulate)	Ss of zhx for tu's settemp air cool, if any
cmLh	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Was tucmlh // local heat: none=0; settmph: tstat-controlled (setpoint given); or setout (only output/flow given).
cmAr	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Tucmar // air heat and cool: none=0, setout, settmph, settmpc, settmpboth = settmph settmpc.
ctrlsAi	X	X	integer number	run start time (of each phase, autoSize or simulate)	Ss of ah ctrl'd by this tu under zn/zn2 control method, this hour (setup time).
wantMd	X	X	unrecognized	end of each subhour	Terminal request to ctrl'd ah: heating, cooling, off. set in tu::estimate, ztucompute, ah::wzczxxxx.
lhMn	X	X	number	end of each subhour	–
lhMx	X	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
lhMxMx	X	X	number	end of each subhour	–
cMn	X	X	number	end of each subhour	–
cMxH	X	X	number	end of each subhour	–
cMxC	X	X	number	end of each subhour	–
useLh	X	X	unrecognized	end of each subhour	Local heat use this subhour: unone(0)/uso/umn/usth/umxh.
useAr	X	X	unrecognized	end of each subhour	Air cool/heat use this subhour, same plus ustc/umxc.
qLhWant	X	X	number	end of each subhour	–
cv	X	X	number	end of each subhour	–
cz	X	X	number	end of each subhour	–
aCv	X	X	number	end of each subhour	–
tfanRunning	X	X	integer number	end of each subhour	True if terminal fan running this subhour (no backflow).
tfanBkC	X	X	number	end of each subhour	–

## 6.56 top

@top.

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
bAutoSizeCmd	X	X	integer number	input time	Non-0 if any autosize commands seen in input, set via arg to cul() from cse.cpp. 6-95.
chAutoSize	X	X	integer number	run start time (of each phase, autoSize or simulate)	Whether to do autosizing, default per bautosizecmd
chSimulate	X	X	integer number	input time	Whether to do main simulation, default true, can input false for autosizing only. 6-95.
begDay	X	X	integer number	input time	1st 1-based julian day of year of run
endDay	X	X	integer number	input time	Last ditto, inclusive

Name	Input?	Runtime?	Type	Variability	Description
nDays	X	X	integer number	run start time (of each phase, autoSize or simulate)	Derived: # days in run
jan1DoW	X	X	integer number	input time	January 1 day of week, sun=1 subtract 1 for most internal uses
year	X	X	integer number	run start time (of each phase, autoSize or simulate)	Derived: tdpak generic non-leap year, -1 = jan 1 is monday ... -7 = jan 1 is sunday.
wuDays	X	X	integer number	input time	Number of warmup days
nSubSteps	X	X	integer number	input time	# subhours per hour, determines subhour duration.
wfName	X	X	string	autosize and simulate phase start time	Weather file path string
TDVfName	X	X	string	autosize and simulate phase start time	Tdv (time dependent value) file path string
elevation	X	X	number	run start time (of each phase, autoSize or simulate)	Site elevation (for determining air density) (ft). defaults from weather file 1-95.
refTemp	X	X	number	autosize and simulate phase start time	Temp for computing the hum ratio (w) used in air-density calculations, default 70 f
refRH	X	X	number	autosize and simulate phase start time	Relative humidity (as fraction) ditto, default .6 (60%).
grndRefl	X	X	number	monthly-hourly	Ground surface reflectivity, re solar gain.
grndEmit	X	X	number	input time	Ground surface emittance, re long wave exchange in kiva. dflt .8.
grndRf	X	X	number	input time	Ground surface roughnes, ft, re exterior convection in kiva. dflt 0.1.
soilDiff	X	X	number	input time	Local soil diffusivity, ft <sup>2</sup> /hr, re annual deep ground temp cycle estimation
soilCond	X	X	number	input time	Local soil conductivity, btuh-ft/ft <sup>2</sup> -f, re kiva calcs. dflt=1.0.
soilSpHt	X	X	number	input time	Local soil specific heat, btu/lb-f, re kiva calcs. dflt=0.1.



Name	Input?	Runtime?	Type	Variability	Description
soilDens	X	X	number	input time	Local soil density, lb/ft <sup>3</sup> , re kiva calcs. dflt=115.
farFieldWidth	X	X	number	input time	Far-field boundary distance, ft, re kiva calcs. dflt=130.
deepGrndCnd	X	X	unrecognized	input time	Deep ground boundary type
deepGrndDepth	X	X	number	input time	Deep-ground boundary distance, ft, re kiva calcs. dflt=130.
deepGrndT	X	X	number	input time	Deep-ground boundary temperature, f, re kiva calcs. dflt=annual average db.
tol	X	X	number	input time	(relative) tolerance used in many hvac calculations, default .001f or as changed
humTolF	X	X	number	input time	W change to consider as important as 1f temp re convergedness
ebTolMon	X	X	number	input time	Monthly tolerance
ebTolDay	X	X	number	input time	Daily ..
ebTolHour	X	X	number	input time	Hourly ..
ebTolSubhr	X	X	number	input time	Subhourly ..
grndMinDim	X	X	number	input time	Minimum cell dimension in kiva, ft, default .066f
grndMaxGrthCoeffX		X	number	input time	Maximum cell growth in kiva, default 1.5f
grndTimeStep	X	X	unrecognized	input time	Kiva time step
AWTrigT	X	X	number	input time	Inside or outside environmental temperature, f (default = 1)
AWTrigSlr	X	X	number	input time	Incident solar, fraction (default = .05)
AWTrigH	X	X	number	input time	Total surface coefficient (conv+rad), fraction (default=.1)
ANTolAbs	X	X	number	input time	Absolute tolerance, lbm/sec, dflt=.00125 (about 1 cfm)
ANTolRel	X	X	number	input time	Relative tolerance, dflt = .0001
bldgAzm	X	X	number	input time	Angle to add to all zone/surface azms
skyModel	X	X	integer number	input time	Sky model: c__iso or __aniso
skyModelLW	X	X	unrecognized	input time	Long-wave sky model
exShadeModel	X	X	unrecognized	input time	Exterior shading model (other than overhang/fins)
dhwModel	X	X	unrecognized	input time	Runtime dhw model selection (debug aid)
humMeth	X	X	unrecognized	input time	Humidity calculation method: rob (w = wa/wb) or phil (central difference), 6-92
dflExH	X	X	number	input time	Default ext (air film) cond for os & gz. 2-91
workDayMask	X	X	integer number	input time	Mask with bits set for "work" days, clear for "non-work" days, default mon..fri, 5-95.

Name	Input?	Runtime?	Type	Variability	Description
DT	X	X	integer number	input time	Yes (default) to enable daylight saving time
DTBegDay	X	X	integer number	run start time (of each phase, autoSize or simulate)	Daylight saving start day, 1-365, default 1st sun (sun after 1st sat?) in april
DTEndDay	X	X	integer number	run start time (of each phase, autoSize or simulate)	Daylight saving end day, 1-365, defaulted by cncult2.cpp code to last sun in october
windSpeedMin	X	X	number	input time	Minimum, mph (default=.5)
windF	X	X	number	input time	Factor (default=1)
terrainClass	X	X	integer number	input time	Terrain class (1-5) re wind speed adjustment
radBeamF	X	X	number	input time	Beam radiation fctr. appl sees aniso( ) * beamradfactor. cgwthr.cpp.
radDiffF	X	X	number	input time	Diffuse variant of beamradfactor, ditto.
ventAvail	X	X	unrecognized	hourly	All-zone ventilation availability (default=c_ventavailch_wholehouse)
hConvMod	X	X	integer number	run start time (of each phase, autoSize or simulate)	Enable/disable convection convective coefficient pressure modification factor (tp_hconvf below)
verbose	X	X	integer number	autosize and simulate phase start time	Screen messages: autosizing: 0 none, 1 some (dflt?), 2-5 more
dbgPrintMask	X	X	number	hourly	Debug print mask, controls dbprintf() etc., schedulable via std capabilities
dbgPrintMaskC	X	X	number	input time	Ditto, constant portion (value known during setup)
auszTol	X	X	number	input time	Autosizing result tolerance, dfl .005
heatDsTDbo	X	X	number	hourly	Heat design outdoor temp, dfl per et1 wthr file hdr.
heatDsTWbo	X	X	number	hourly	Heating design outdoor wetbulb temp, dfl for 70% rh @ heatdstdbo.
coolDsMo[0]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[1]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.

Name	Input?	Runtime?	Type	Variability	Description
coolDsMo[2]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[3]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[4]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[5]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[6]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[7]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[8]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[9]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[10]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[11]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsMo[12]	X	X	integer number	input time	Si[13] cooling design month(s) 1-12 + 0 terminator. default per et1 wthr file hdr.
coolDsDay[0]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[1]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[2]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[3]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[4]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[5]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[6]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[7]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[8]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator

Name	Input?	Runtime?	Type	Variability	Description
coolDsDay[9]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[10]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[11]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsDay[12]	X	X	integer number	input time	Doy[13] design day(s) read from weather file + 0 terminator
coolDsCond[0]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[1]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[2]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[3]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[4]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[5]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[6]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[7]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[8]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[9]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[10]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[11]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
coolDsCond[12]	X	X	integer number	input time	Ti[ 13] descond idx(s) + 0 terminator
exePath	X	X	string	run start time (of each phase, autoSize or simulate)	Full path to current .exe
exeInfo	X	X	string	run start time (of each phase, autoSize or simulate)	Info about current .exe (from header)
exeCodeSize	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Code size, bytes (from exe header)

Name	Input?	Runtime?	Type	Variability	Description
progVersion	X	X	string	run start time (of each phase, autoSize or simulate)	Program version identifier as string (for probing); set from ::progversion
HPWHVersion	X	X	string	run start time (of each phase, autoSize or simulate)	Ecotope hpwh (heat pump water heater) model version
cmdLineArgs	X	X	string	run start time (of each phase, autoSize or simulate)	Command line args for current input file
runSerial	X	X	integer number	input time	Run #, 000-999, per (future 11-91) status file (meanwhile, see cnguts:cnrunserial 7-92).
runTitle	X	X	string	input time	User text for report titles, footers, export title 11-22-91.
runDateTime	X	X	string	run start time (of each phase, autoSize or simulate)	Run date & time string, set by cncult2.cpp:topstarprf2(), used in reports & bin res file, 9-94.
brs	X	X	integer number	run start time (of each phase, autoSize or simulate)	Yes to generate basic binary results file, default no. from input file or cmd line switch.
brHrly	X	X	integer number	run start time (of each phase, autoSize or simulate)	Yes to generate hourly binary results file, default no. from input file or cmd line.
brFileName	X	X	string	input time	File name for binary results, extension .brs and/or .bhr added. default: input file name.
brMem	X	X	integer number	run start time (of each phase, autoSize or simulate)	Put binary results in windows global memory and return handles; do not write file.
brDiscardable	X	X	integer number	run start time (of each phase, autoSize or simulate)	Put binary results in discardable memory as well as file, return handles. overrides brfmem.
repHdrL	X	X	string	input time	User-spec'd text for left end of report header line
repHdrR	X	X	string	input time	.. right

Name	Input?	Runtime?	Type	Variability	Description
repCpl	X	X	integer number	input time	Report characters per line
repLpp	X	X	integer number	input time	Total number of lines per page (paper size)
repTopM	X	X	integer number	input time	Top margin in lines; # newlines written above header
repBotM	X	X	integer number	input time	Bottom margin in lines; not actually output
repTestPfx	X	X	string	input time	Prefix pre-pended to e.g. footer lines re hiding lines re automated testing
exshNShade	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of shading surfaces in model
exshNRec	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	# of receiving surfaces in model (may also be shading)
latitude	X	X	number	run start time (of each phase, autoSize or simulate)	Degrees north
longitude	X	X	number	run start time (of each phase, autoSize or simulate)	Degress west
timeZone	X	X	number	run start time (of each phase, autoSize or simulate)	Hours west (fraction ok)
presAtm	X	X	number	run start time (of each phase, autoSize or simulate)	Nominal atmospheric pressure at top.elevation (in hg)
refW	X	X	number	run start time (of each phase, autoSize or simulate)	Humidity ratio for reftemp, refrh (ratio)
refWX	X	X	number	run start time (of each phase, autoSize or simulate)	$1/(1.+rp\_refw)$

Name	Input?	Runtime?	Type	Variability	Description
airSH	X	X	number	run start time (of each phase, autoSize or simulate)	Air specific heat (btu/lbdryair-f) @ tp_refw
airVK	X	X	number	run start time (of each phase, autoSize or simulate)	Specific volume per temp(ft3/lb-f): multiply by abs temp.
airRhoK	X	X	number	run start time (of each phase, autoSize or simulate)	Density*temp (lb-f/ft3): divide by abs temp to get density.
airVshK	X	X	number	run start time (of each phase, autoSize or simulate)	Volumetric specific heat/temp (btu/ft3-f): div by abs temp for heat capacity per ft3
airXK	X	X	number	run start time (of each phase, autoSize or simulate)	Divide by abs temp for specific heat of flow (btuh/cfm-f)
hConvF	X	X	number	run start time (of each phase, autoSize or simulate)	Convective coefficient pressure modification factor
nDesDays	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Number of design days: 1 for heating + number of non-0 cooldsmo's.
auszSmTol	X	X	number	run start time (of each phase, autoSize or simulate)	Autosizing small tolerance, eg ausztol/10 (.001)
auszTol2	X	X	number	run start time (of each phase, autoSize or simulate)	Half of given tolerance – added to values; used in convergence tests.
auszHiTol2	X	X	number	run start time (of each phase, autoSize or simulate)	1 + half of tolerance, eg 1 + ausztol/2.

Name	Input?	Runtime?	Type	Variability	Description
vrSum	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	Vrh for summary report (not written to as of 11/22/91)
dvriY	X	X	integer number	daily	0 or dvrib subscript of 1st rpfreq=year report or export
dvriM	X	X	integer number	daily	.. month report/export currently active
dvriD	X	X	integer number	daily	.. day report/export to write to today
dvriH	X	X	integer number	daily	.. hourly ..
dvriHS	X	X	integer number	daily	.. hourly and subhourly. a vr can only be in one list, so this list is
dvriS	X	X	integer number	daily	.. subhourly ..
hrxFlg	X	X	integer number	daily	Nz if any hour reporting or exporting today: dvrih   -hs
shrxFlg	X	X	integer number	daily	Nz if any subhour reporting or exporting today: dvris   -hs
tmrInput	X	X	number	end of each day	Input processing time, sec
tmrAusz	X	X	number	end of each day	Autosizing time, sec
tmrRun	X	X	number	end of each day	Main simulation time, sec
tmrTotal	X	X	number	end of each day	Total execution time (not including reports), sec
tmrAirNet	X	X	number	end of each day	Add'l timers active iff detailed_timing
tmrAWTot	X	X	number	end of each day	–
tmrAWCalc	X	X	number	end of each day	–
tmrCond	X	X	number	end of each day	–
tmrKiva	X	X	number	end of each day	–
tmrBC	X	X	number	end of each day	–
tmrZone	X	X	number	end of each day	–
subhrDur	X	X	number	subhourly	Duration of subhour, hr (= 1/nsubsteps)
nSubhrTicks	X	X	integer number	run start time (of each phase, autoSize or simulate)	# of subhour ticks for e.g. hpwh simulation



Name	Input?	Runtime?	Type	Variability	Description
tickDurMin	X	X	number	run start time (of each phase, autoSize or simulate)	Duration of subhr tick, min
tickDurHr	X	X	number	run start time (of each phase, autoSize or simulate)	Duration of subhr tick, hr
monStr	X	X	string	monthly	Month being simulated as (non-heap) string
dateStr	X	X	string	daily	Date being simulated as heap string
date	X	X	un-probe-able	daily	Date: .month is 1-12, .mday 1-31, .wday 0-6. set/used: cnguts. used:cuparse;cgsolar;cgresult;cgenbal.
jDay	X	X	integer number	daily	Day of year now simulating, 1..365. set: tp_mainsimi; used:cnguts;cuparse;cgwthr;cgsolar;cgresult.
xJDay	X	X	integer number	daily	Extended jday: same for main sim, 512 heat autosizing, 529-540 cooling autosizing.
iHr	X	X	integer number	hourly	Hour of day, 0-23. set/used: tp_mainsim()
iSubhr	X	X	integer number	subhourly	Subhour of hour being simulated, 0.. . set cnguts.cpp, used cnztu,cnv hac.cnguts,cgresult.cpp.
shoy	X	X	unrecognized	subhourly	Extended subhour of year, for reporting peaks: subhr + 4 * (hr + 24*xjday). set/used: cnguts. 1 if daylight saving time in effect, 0 if not. unspecified time/date variables are daylight.
isDT	X	X	integer number	hourly	Standard time hour of day now simulating, 0-23. set/used cnguts, used cgsolar.cpp.
iHrST	X	X	integer number	hourly	Standard time day of year, 1..365. changes @ 1am ->*h. set/used cnguts, used cgsolar.cpp.
jDayST	X	X	integer number	hourly	Standard time day of year, 1..365. changes @ 1am ->*h. set/used cnguts, used cgsolar.cpp.
autoSizing	X	X	integer number	autosize and simulate phase start time	True if setting up for or doing autosizing, 0 for main simulation setup/run
pass1	X	X	integer number	daily	True autosizing pass 1 (a or b) thru dsn days: find big-enuf sizes with open-ended models
pass1A	X	X	integer number	daily	True for pass 1a of each dsn day: use idealized const-supply-temp models
pass1B	X	X	integer number	daily	True for pass 1b of each dsn day: use real models

Name	Input?	Runtime?	Type	Variability	Description
pass2	X	X	integer number	daily	True autosizing for pass 2 thru dsn days: determine loads, reduce oversize sizes.
sizing	X	X	integer number	daily	True when can increase sizes. eg false during pass 2: warming up.
dsDayI	X	X	unrecognized	daily	Index of design day being simulated: 0 heat, 1-12 cooldsmo[...-1]. set in cnausz.cpp. 6-95.
dsDay	X	X	integer number	daily	0 main sim, 1 heating autosize design day, 2 cooling ausz
auszMon	X	X	integer number	daily	Cool design day month 1-12 or generic month 0 for heat. 6-95.
ivl	X	X	integer number	subhourly	Interval now starting or ending (c_ivlch_y, _m, etc),
isBegOf	X	X	integer number	subhourly	0 or interval now starting (for exprssion eval) (c_ivlch_y, _m, etc; 0 except during expr eval) ...
isEndOf	X	X	integer number	subhourly	Ditto ending. ... set in cnguts.cpp, tested in cueval.cpp.
isBegRun	X	X	integer number	subhourly	1st subhr of warmup, not set for run unless no warmup.
isBegMainSim	X	X	integer number	subhourly	1st subhr of main sim (not warmup, not autosize)
isFirstMon	X	X	integer number	monthly	True if 1st month of main sim. set: dobeg/endivl. used: doivlaccum.
isLastDay	X	X	integer number	daily	Last day of main sim
isLastWarmupDay	X	X	integer number	daily	True iff last day of main sim warmup. set: cgmainssimi. used: cgwthr.cpp. 1-95.
isBegHour	X	X	integer number	subhourly	True if subhour 0 of hour. set cnztu.cpp/cnguts.cpp, used cnguts.cpp, .
isEndHour	X	X	integer number	subhourly	True if last subhour of hour. set cnguts.cpp, used cnguts, cgresult.cpp.
isBegDay	X	X	integer number	hourly	True if hour 0. set: dobegivl. used: dobegivl,doivlaccum; cgresult.cpp
isEndDay	X	X	integer number	hourly	True if hour 23. set: dobegivl. used: doendivl,doivlaccum; cgresult.cpp
isBegMonth	X	X	integer number	daily	1st day of month/run/warmup or 1st rep of dsn day.
isEndMonth	X	X	integer number	daily	Mon/run, not warmup, last day.
isSolarCalcDay	X	X	integer number	daily	True if 1st day of month/run or 1st rep of dsn day: do 24 hours of solar calcs today. cnguts.

Name	Input?	Runtime?	Type	Variability	Description
isWarmup	X	X	integer number	daily	True if main sim warmup. set/used: cgmainssimi. used: dobe-givl,doendivl,doivlaccum,doivlreports;exman,impf.
dowh	X	X	integer number	daily	Autosizing: 8 heat 9 cool, else 7 if observed holiday, else day of week 0-6, for \$dowh.
isHoliday	X	X	integer number	daily	True on observed holiday: monday after certain true holidays on weekend. same as old isholiobs, 7-92.
isHoliTrue	X	X	integer number	daily	True (non-0) on true date of holiday
isWeHol	X	X	integer number	daily	Weekend or holiday
isWeekend	X	X	integer number	daily	Saturday or sunday
isBegWeek	X	X	integer number	daily	Non-wehol after wehol
isWeekday	X	X	integer number	daily	Mon-fri
isWorkDay	X	X	integer number	daily	Workday per top.workdaymask (default mon-fri), 5-95
isNonWorkDay	X	X	integer number	daily	Non-workday ditto 5-95
isBegWorkWeek	X	X	integer number	daily	Workday after non-workday ditto 5-95
notDone	X	X	integer number	daily	Combined results of autosize pass endtests
dsDayNI	X	X	unrecognized	daily	Number of times this design day has been iterated
radBeamHrAv	X	X	number	hourly	Beam irradiance on tracking surface, hour energy = average power, from weather file
radBeamPvHrAv	X	X	number	hourly	.. previous hour (used to generate -shav)
radBeamNxHrAv	X	X	number	hourly	.. next hour (wthr file read ahead) (used to generate -shav)
radBeamShAv	X	X	number	subhourly	.. current beam subhour average power, interpolated, btuh/ft2
radBeamShSpare	X	X	number	constant	—
radDiffHrAv	X	X	number	hourly	Diffuse irradiance on horizontal surface, hour energy = average power, from weather file
radDiffPvHrAv	X	X	number	hourly	.. flavors as for radbeam
radDiffNxHrAv	X	X	number	hourly	..
radDiffShAv	X	X	number	subhourly	.. current diffuse subhour power, interpolated by cgwthr.cpp, btuh/ft2
radDiffShSpare	X	X	number	constant	—
tDbOhr	X	X	number	hourly	Outdoor dry bulb temp at end of hour, from wthr file, deg f.

Name	Input?	Runtime?	Type	Variability	Description
tDbOPvHr	X	X	number	hourly	.. previous hour (used to compute -hrav and -sh)
tDbOHrAv	X	X	number	hourly	.. average over hour (used re hourly masses, bin res files, \$variable)
tDbOSh	X	X	number	subhourly	.. end subhour, interpolated (used re zone temp heat balance)
tDbOPvSh	X	X	number	subhourly	.. end previous subhr (used to compute -shav)
tDbOShAv	X	X	number	subhourly	.. average over subhour (used re subhourly masses)
tWbOHr	X	X	number	hourly	Outdoor wet bulb temp at end of hour, from wthr file wb depression, deg f.
tWbOPvHr	X	X	number	hourly	.. previous hour (used to compute -hrav, -sh)
tWbOHrAv	X	X	number	hourly	.. hour average (for \$ variable)
tWbOSh	X	X	number	subhourly	.. end subhour, interpolated (used re zone temp heat balance)
tSkyHr	X	X	number	hourly	Sky temperature, f
tSkyPvHr	X	X	number	hourly	.. previous hour (used to compute -sh)
tSkySh	X	X	number	subhourly	.. end subhr, interpolated)
windSpeedHr	X	X	number	hourly	Wind speed, mph, at end hour
windSpeedPvHr	X	X	number	hourly	.. previous hour (used to compute -hrav, -sh)
windSpeedHrAv	X	X	number	hourly	.. hour average (for \$ variable)
windSpeedSh	X	X	number	subhourly	.. end subhour, mph, interpolated: for \$variable and ..
windSpeedSquaredSh	X	X	number	subhourly	.. end subhour squared (re zone infiltration), $\text{mph}^2$
windSpeedSqrtSh	X	X	number	subhourly	.. end subhour sqrt (re outside surface convection), $\text{mph}^{.5}$
windSpeedPt8Sh	X	X	number	subhourly	.. end subhour $^{.8}$ (re outside surface convection), $\text{mph}^{.8}$
windDirDegHr	X	X	number	hourly	Wind direction at end hour from wthr file, degrees, 0=n, 90=e. (used for \$variable)
wOHr	X	X	number	hourly	Outdoor humidity ratio at end current hour, computed from tdbo and twbo (used for \$ variable)
wOPvHr	X	X	number	hourly	.. previous hour (used to compute -hrav)
wOHrAv	X	X	number	hourly	.. hour average (for \$ variable)
wOSh	X	X	number	subhourly	.. at end current subhour: used throughout zones and systems models in program
hOSh	X	X	number	subhourly	Outdoor enthalpy at end subhour. used at in ah::doeco, towerplant::towmodel. 9-92.
airxOSh	X	X	number	subhourly	Air flow heat transfer @tdbosh ( $\text{vhc} \cdot 60$ ) ( $\text{btuh}/\text{cfm-f}$ ).

Name	Input?	Runtime?	Type	Variability	Description
rhoMoistOSh	X	X	number	subhourly	Outdoor moist air density at end of subhour, lbm/ft3
rhoDryOSh	X	X	number	subhourly	Outdoor dry air density at end of subhour, lbm/ft3
iter	X	X	integer number	subhourly	Hvac terminal / air handler / plant iteration counter for cnztu.cpp:hvacitersubhr.
qcPeak	X	X	number	hourly	Maximum cooling load for an hour for entire building. negative (if not 0).
qcPeakH	X	X	integer number	hourly	Hour 1-24 of peak cooling load
qcPeakD	X	X	integer number	hourly	Day of month 1-31 of peak load
qcPeakM	X	X	integer number	hourly	Month 1-12 of peak load
qhPeak	X	X	number	hourly	Maximum heating load for entire building during an hour
qhPeakH	X	X	integer number	hourly	Hour 1-24 of peak heating load
qhPeakD	X	X	integer number	hourly	Day of month 1-31 of peak load
qhPeakM	X	X	integer number	hourly	Month 1-12 of peak load
ck5aa5	X	X	integer number	run start time (of each phase, autoSize or simulate)	Stuffed with 0x5aa5 from topcult for verifying initialization & matching versions

## 6.57 towerPlant

@towerPlant[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
ctN	X	X	integer number	autosize and simulate phase start time	Number of towers. nils' ctno. default 1.
tpStg	X	X	unrecognized	autosize and simulate phase start time	Staging choice, default together. nils' stgop.
tpTsSp	X	X	number	hourly	Towers delivered water setpoint temperature (niles' twosp). degrees f, hourly, default 85f.
tpMtr	X	X	integer number	input time	Subscript of meter object to which tower fan energy input will be posted,

Name	Input?	Runtime?	Type	Variability	Description
ctTy	X	X	unrecognized	autosize and simulate phase start time	Cooling tower fan control type choice: onespeed (default), twospeed, or variable.
ctLoSpd	X	X	number	autosize and simulate phase start time	Low speed for a twospeed fan, as a fraction of full cfm. default 0.5.
ctShaftPwr	X	X	number	autosize and simulate phase start time	Shaft power of one tower fan motor. rqd. user name 'shaftbhp'.
ctMotEff	X	X	number	autosize and simulate phase start time	Motor (and drive, if any) efficiency, default 0.88
ctFcOne.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcOne.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcOne.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcLo.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcLo.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcLo.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcHi.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
ctFcHi.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcHi.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcVar.k[0]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcVar.k[1]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcVar.k[2]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcVar.k[3]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctFcVar.k[4]	X	X	number	run start time (of each phase, autoSize or simulate)	—
ctCapDs	X	X	number	run start time (of each phase, autoSize or simulate)	Design capacity, btuh. (replaces niles' design water inlet temperature.)
ctVfDs	X	X	number	autosize and simulate phase start time	Design air flow volume rate through tower / full speed fan flow??, cfm, rqd.
ctGpmDs	X	X	number	run start time (of each phase, autoSize or simulate)	Design water flow rate, gpm. default: sum of connected heat rejection pump capacities / ctn.

Name	Input?	Runtime?	Type	Variability	Description
ctTDbODs	X	X	number	autosize and simulate phase start time	Design outdoor drybulb temperature, f, rqd. (only needed to convert ctvfds from cfm to lb/hr).
ctTWbODs	X	X	number	autosize and simulate phase start time	Design outdoor wetbulb temperature, f, rqd.
ctTwoDs	X	X	number	autosize and simulate phase start time	Design leaving water temperature, f, default 85.
ctCapOd	X	X	number	run start time (of each phase, autoSize or simulate)	Off-design capacity, btuh. (replaces niles' design water inlet temperature.)
ctVfOd	X	X	number	autosize and simulate phase start time	Off-design air flow volume rate through one tower, cfm, must != ctvfds.
ctGpmOd	X	X	number	run start time (of each phase, autoSize or simulate)	Off-design water flow rate, gpm. default: sum of connected heat rejection pump capacities/ ctn.
ctTDbOOd	X	X	number	autosize and simulate phase start time	Off-design outdoor drybulb temperature, f. (only needed to convert ctvfod from cfm to lb/hr).
ctTWbOOd	X	X	number	autosize and simulate phase start time	Off-design outdoor wetbulb temperature, f.
ctTwoOd	X	X	number	autosize and simulate phase start time	Off-design leaving water temperature, f, default 85.
ctK	X	X	number	run start time (of each phase, autoSize or simulate)	Exponent in formula ntua = const * (mw/ma) <sup>ctk</sup> , as alternative to "off design" inputs.
ctStkFlFr	X	X	number	autosize and simulate phase start time	Stack effect flow: air flow that occurs thru tower when fan is off, as a fraction of ctvfds.



Name	Input?	Runtime?	Type	Variability	Description
ctBldn	X	X	number	autosize and simulate phase start time	Blowdown rate: frac inflowing water bled down drain, to reduce impurities buildup. default .01.
ctDrft	X	X	number	autosize and simulate phase start time	Drift rate: frac inflowing water blown out of tower as droplets, w/o evaporating. default 0.
ctTWm	X	X	number	autosize and simulate phase start time	Temperature of water in mains, for makeup water. default 60.
cp1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st coolplant served by this towerplant. next is coolplant.nxcp4tp.
hl1	X	X	integer number	run start time (of each phase, autoSize or simulate)	Subscript of 1st hploop with hx served by this towerplant. next is hploop.nxhl4tp.
oneFanP	X	X	number	run start time (of each phase, autoSize or simulate)	—
maDs	X	X	number	run start time (of each phase, autoSize or simulate)	—
maOd	X	X	number	run start time (of each phase, autoSize or simulate)	—
mwDs	X	X	number	run start time (of each phase, autoSize or simulate)	—
mwOd	X	X	number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
maOverMwDs	X	X	number	run start time (of each phase, autoSize or simulate)	Mads/mwds, precomputed in setup.
ntuADs	X	X	number	run start time (of each phase, autoSize or simulate)	Number of transfer units for air side at design conditions (niles ntuad)
ntuAOd	X	X	number	run start time (of each phase, autoSize or simulate)	.. at off-design conditions, if given. member only as debug aid.
tpTs	X	X	number	end of each subhour	–
tpClf	X	X	integer number	end of each subhour	Call-flag: set nz if must call tpcompute so it can test tr, etc to see if computation needed.
tpPtf	X	X	integer number	end of each subhour	Compute-flag: set if must call tpcompute and it should unconditionally recompute.
trNx	X	X	number	end of each subhour	–
mwAllNx	X	X	number	end of each subhour	–
qLoadNx	X	X	number	end of each subhour	–
tr	X	X	number	end of each subhour	–
mwAll	X	X	number	end of each subhour	–
qLoad	X	X	number	end of each subhour	–
mwil	X	X	number	end of each subhour	–
qNeed	X	X	number	end of each subhour	–
qMax1	X	X	number	end of each subhour	–
qMin1	X	X	number	end of each subhour	–
towldCase	X	X	unrecognized	end of each subhour	Tower load case, tpcompute to endsubhr: facilitates deferring fan power calc

Name	Input?	Runtime?	Type	Variability	Description
qMaxGuess	X	X	number	end of each subhour	For internal values for towmodel initial guess at next call for various towmodel calls.
qMinGuess	X	X	number	end of each subhour	..
qLoGuess	X	X	number	end of each subhour	..
qVarGuess	X	X	number	end of each subhour	.., used via varspeedf
qVarTem	X	X	number	end of each subhour	—
puteTs	X	X	number	end of each subhour	—
nCtOp	X	X	integer	end of each subhour	Number of tower fans operating
f	X	X	number	end of each subhour	Fraction of full speed (fraction on for one speed fan), for lead tower only if lead.
fanP	X	X	number	end of each subhour	Plant's fan input pwr this subhour (btuh!)
q	X	X	number	end of each subhour	Power imparted to water, for change detection/probes/reports 10-19-92
tpTsSpPr	X	X	number	end of each subhour	For tpeestimate
tpTsEstPr	X	X	number	end of each subhour	For tpeestimate
tpTsPr	X	X	number	end of each subhour	For tpccompute
tDbOShPr	X	X	number	end of each subhour	For tpccompute
wOShPr	X	X	number	end of each subhour	For tpccompute

## 6.58 weather

@weather.

Name	Input?	Runtime?	Type	Variability	Description
name	—	X	string	constant	—
sunup	—	X	unrecognized	hourly	Nz if sun is up for any portion of current hour
slAzm	—	X	number	hourly	Azimuth, radians (0=n, +clockwise)
slAlt	—	X	number	hourly	Altitude, radians (0=horizon, +upwards)

Name	Input?	Runtime?	Type	Variability	Description
db	–	X	number	hourly	Air dry bulb temp, deg f
DNI	–	X	number	hourly	Direct normal irradiance from weather file (integrated value for hour, btu/ft2)
DHI	–	X	number	hourly	Diffuse horizontal irradiance from weather file (integrated value for hour, btu/ft2)
bmrad	–	X	number	hourly	Dni as adjusted per anisotropic sky, top.radbeamf, etc (integrated value for hour, btu/ft2)
dfrac	–	X	number	hourly	Dhi as adjusted per anisotropic sky, top.raddiff, etc (integrated value for hour, btu/ft2)
wb	–	X	number	hourly	Air wet bulb temp, deg f
wndDir	–	X	number	hourly	Wind direction, deg, 0=n, 90=e
wndSpd	–	X	number	hourly	Wind speed, mph
glrad	–	X	number	hourly	Global irradiance on horizontal surface, for daylighting calculations
cldCvr	–	X	number	hourly	Total cloud cover in tenths, 0-11, or 15 for missing data
tSky	–	X	number	hourly	Sky temperature, f from weather file or calcskytemp() (berdahl-martin)
tGrnd	–	X	number	hourly	Ground temperature, f
taDp	–	X	number	hourly	Air dew point temp, f
tMains	–	X	number	hourly	Cold water mains temp, f
tdvElec	–	X	number	hourly	Electricity
tdvFuel	–	X	number	hourly	Fuel

Name	Input?	Runtime?	Type	Variability	Description
taDbPk	–	X	number	hourly	Current day peak db (includes future hours), f
taDbAvg	–	X	number	hourly	Current day average db (includes future hours), f
taDbPvPk	–	X	number	hourly	Previous-day peak db, f
taDbAvg01	–	X	number	hourly	Previous-day avg db (not including current day), f
taDbAvg07	–	X	number	hourly	Trailing 7-day avg db (not including current day), f
taDbAvg14	–	X	number	hourly	Trailing 14-day avg db (not including current day), f
taDbAvg31	–	X	number	hourly	Trailing 31-day avg db (not including current day), f
tdvElecPk	–	X	number	hourly	Current day peak tdvelec (includes future hours)
tdvElecPkRank	–	X	integer number	hourly	Current day wd_tdvelecpk rank within year (1-365/366)
tdvElecAvg	–	X	number	hourly	Current day avg tdvelec (includes future hours)
tdvElecPvPk	–	X	number	hourly	Previous-day peak tdvelec
tdvElecAvg01	–	X	number	hourly	Previous-day avg tdvelec (not including current day)
tdvElecHrRank[0]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[1]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[2]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[3]	–	X	integer number	hourly	Hour ranking of tdv values for current day

Name	Input?	Runtime?	Type	Variability	Description
tdvElecHrRank[4]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[5]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[6]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[7]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[8]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[9]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[10]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[11]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[12]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[13]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[14]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[15]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[16]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[17]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[18]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[19]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[20]	–	X	integer number	hourly	Hour ranking of tdv values for current day

Name	Input?	Runtime?	Type	Variability	Description
tdvElecHrRank[21]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[22]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[23]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[24]	–	X	integer number	hourly	Hour ranking of tdv values for current day

## 6.59 weatherFile

@weatherFile.

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
wFileFormat	–	X	integer number	run start time (of each phase, autoSize or simulate)	File format enum: unk, bsgs, et1, etc.
loc	–	X	string	run start time (of each phase, autoSize or simulate)	Char loc[] location (for et, is loc 1 only: city etc).
lid	–	X	string	run start time (of each phase, autoSize or simulate)	Char lid[] location id
yr	–	X	integer number	run start time (of each phase, autoSize or simulate)	Year of weather data (00 - 99, -1 if n/a)
jd1	–	X	integer number	run start time (of each phase, autoSize or simulate)	Julian day of first weather record (-1 if not known)
jd1	–	X	integer number	run start time (of each phase, autoSize or simulate)	Julian day of last weather record (ditto)
lat	–	X	number	run start time (of each phase, autoSize or simulate)	Latitude, degrees n (-90.0 to 90.0)

Name	Input?	Runtime?	Type	Variability	Description
lon	–	X	number	run start time (of each phase, autoSize or simulate)	Longitude, degrees w (-180. to 180.0). us locations are >0, note non-standard
tz	–	X	number	run start time (of each phase, autoSize or simulate)	Time zone, hours w of greenwich (est = +5, note non-standard
elev	–	X	number	run start time (of each phase, autoSize or simulate)	Elevation of locn in ft (-9999. to 99999.)
taDbAvgYr	–	X	number	run start time (of each phase, autoSize or simulate)	Annual average dry-bulb temp, f
tMainsAvgYr	–	X	number	autosize and simulate phase start time	Annual average cold water temp, f
solartime	–	X	integer number	run start time (of each phase, autoSize or simulate)	True if file is in solar time
loc2	–	X	string	run start time (of each phase, autoSize or simulate)	Char[] location 2 (state or country, etc)
isLeap	–	X	integer number	run start time (of each phase, autoSize or simulate)	Non-0 if weather file is for a leap year (feb 29 counted in dates) – possible future use
firstDdm	–	X	integer number	run start time (of each phase, autoSize or simulate)	Month 1-12 of first design day in file
lastDdm	–	X	integer number	run start time (of each phase, autoSize or simulate)	Month 1-12 of last design day in file
winMOE	–	X	integer number	run start time (of each phase, autoSize or simulate)	Winter median of extremes (deg f)



Name	Input?	Runtime?	Type	Variability	Description
win99TDb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Winter 99% design temp (deg f)
win97TDb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Winter 97.5% design temp (deg f)
sum1TDb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 1% design temp (deg f)
sum1TWb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 1% design coincident wb (deg f)
sum2TDb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 2.5% design temp (deg f)
sum2TWb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 2.5% design coincident wb (deg f)
sum5TDb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 5% design temp (deg f)
sum5TWb	–	X	integer number	run start time (of each phase, autoSize or simulate)	Summer 5% design coincident wb (deg f)
range	–	X	integer number	run start time (of each phase, autoSize or simulate)	Mean daily range (deg f)
sumMonHi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Month of hottest design day, 1-12
TDVFileTimeStamp	–	X	string	autosize and simulate phase start time	Timestamp string
TDVFileTitle	–	X	string	autosize and simulate phase start time	Title string (identifies file cz, fuel, vintage, )
TDVFileJHr	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	Last hour (row) in file that has read (1 based)

**6.60 weatherNextHour**

@weatherNextHour.

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
sunup	–	X	unrecognized	hourly	Nz if sun is up for any portion of current hour
slAzm	–	X	number	hourly	Azimuth, radians (0=n, +clockwise)
slAlt	–	X	number	hourly	Altitude, radians (0=horizon, +upwards)
db	–	X	number	hourly	Air dry bulb temp, deg f
DNI	–	X	number	hourly	Direct normal irradiance from weather file (integrated value for hour, btu/ft2)
DHI	–	X	number	hourly	Diffuse horizontal irradiance from weather file (integrated value for hour, btu/ft2)
bmrad	–	X	number	hourly	Dni as adjusted per anisotropic sky, top.radbeamf, etc (integrated value for hour, btu/ft2)
dfrac	–	X	number	hourly	Dhi as adjusted per anisotropic sky, top.raddiff, etc (integrated value for hour, btu/ft2)
wb	–	X	number	hourly	Air wet bulb temp, deg f
wndDir	–	X	number	hourly	Wind direction, deg, 0=n, 90=e
wndSpd	–	X	number	hourly	Wind speed, mph
glrad	–	X	number	hourly	Global irradiance on horizontal surface, for daylighting calculations
cldCvr	–	X	number	hourly	Total cloud cover in tenths, 0-11, or 15 for missing data

Name	Input?	Runtime?	Type	Variability	Description
tSky	–	X	number	hourly	Sky temperature, f from weather file or calcskytemp() (berdahl-martin)
tGrnd	–	X	number	hourly	Ground temperature, f
taDp	–	X	number	hourly	Air dew point temp, f
tMains	–	X	number	hourly	Cold water mains temp, f
tdvElec	–	X	number	hourly	Electricity
tdvFuel	–	X	number	hourly	Fuel
taDbPk	–	X	number	hourly	Current day peak db (includes future hours), f
taDbAvg	–	X	number	hourly	Current day average db (includes future hours), f
taDbPvPk	–	X	number	hourly	Previous-day peak db, f
taDbAvg01	–	X	number	hourly	Previous-day avg db (not including current day), f
taDbAvg07	–	X	number	hourly	Trailing 7-day avg db (not including current day), f
taDbAvg14	–	X	number	hourly	Trailing 14-day avg db (not including current day), f
taDbAvg31	–	X	number	hourly	Trailing 31-day avg db (not including current day), f
tdvElecPk	–	X	number	hourly	Current day peak tdvelec (includes future hours)
tdvElecPkRank	–	X	integer number	hourly	Current day wd_tdvelecpk rank within year (1-365/366)
tdvElecAvg	–	X	number	hourly	Current day avg tdvelec (includes future hours)
tdvElecPvPk	–	X	number	hourly	Previous-day peak tdvelec
tdvElecAvg01	–	X	number	hourly	Previous-day avg tdvelec (not including current day)

Name	Input?	Runtime?	Type	Variability	Description
tdvElecHrRank[0]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[1]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[2]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[3]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[4]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[5]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[6]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[7]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[8]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[9]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[10]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[11]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[12]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[13]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[14]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[15]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[16]	–	X	integer number	hourly	Hour ranking of tdv values for current day

Name	Input?	Runtime?	Type	Variability	Description
tdvElecHrRank[17]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[18]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[19]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[20]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[21]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[22]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[23]	–	X	integer number	hourly	Hour ranking of tdv values for current day
tdvElecHrRank[24]	–	X	integer number	hourly	Hour ranking of tdv values for current day

## 6.61 window (owner: surface)

@window[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	–	string	constant	–
ty	X	–	integer number	input time	–
area	X	–	number	run start time (of each phase, autoSize or simulate)	–
azm	X	–	number	run start time (of each phase, autoSize or simulate)	–
tilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
dircos[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
dircos[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
depthBG	X	–	number	run start time (of each phase, autoSize or simulate)	–
height	X	–	number	run start time (of each phase, autoSize or simulate)	... and to compute area b4 mutliplier.
model	X	–	integer number	input time	–
modelr	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
lThkF	X	–	number	run start time (of each phase, autoSize or simulate)	–
gti	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sco	X	–	number	monthly- hourly	–
scc	X	–	number	monthly- hourly	–
sbcI.absSlr	X	–	number	monthly- hourly	–
sbcI.awAbsSlr	X	–	number	monthly- hourly	–
sbcI.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcI.F	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcNat	X	–	number	end of each subhour	–
sbcI.hcFrc	X	–	number	end of each subhour	–
sbcI.hcMult	X	–	number	end of each subhour	–
sbcI.hxa	X	–	number	end of each subhour	–
sbcI.hxr	X	–	number	end of each subhour	–
sbcI.hxtot	X	–	number	end of each subhour	–
sbcI.uRat	X	–	number	end of each subhour	–
sbcI.fRat	X	–	number	end of each subhour	–
sbcI.cx	X	–	number	end of each subhour	–
sbcI.sgTarg.bm	X	–	number	end of each subhour	–
sbcI.sgTarg.df	X	–	number	end of each subhour	–
sbcI.sgTarg.tot	X	–	number	end of each subhour	–
sbcI.sg	X	–	number	end of each subhour	–
sbcI.tSrf	X	–	number	end of each subhour	–
sbcI.tSrfls	X	–	number	subhourly	–
sbcI.qrAbs	X	–	number	end of each subhour	–
sbcI.txa	X	–	number	end of each subhour	–
sbcI.txr	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.txe	X	–	number	end of each subhour	–
sbcI.w	X	–	number	end of each subhour	–
sbcI.qSrf	X	–	number	end of each subhour	–
sbcI.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.eta	X	–	number	end of each subhour	–
sbcI.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–



Name	Input?	Runtime?	Type	Variability	Description
sbcI.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.absSlr	X	–	number	monthly- hourly	–
sbcO.awAbsSlr	X	–	number	monthly- hourly	–
sbcO.epsLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.zi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sbcO.F	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.Fp	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.frRad	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fSky	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fAir	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcNat	X	–	number	end of each subhour	–
sbcO.hcFrc	X	–	number	end of each subhour	–
sbcO.hcMult	X	–	number	end of each subhour	–
sbcO.hxa	X	–	number	end of each subhour	–
sbcO.hxr	X	–	number	end of each subhour	–
sbcO.hxtot	X	–	number	end of each subhour	–
sbcO.uRat	X	–	number	end of each subhour	–
sbcO.fRat	X	–	number	end of each subhour	–
sbcO.cx	X	–	number	end of each subhour	–
sbcO.sgTarg.bm	X	–	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.sgTarg.df	X	–	number	end of each subhour	–
sbcO.sgTarg.tot	X	–	number	end of each subhour	–
sbcO.sg	X	–	number	end of each subhour	–
sbcO.tSrf	X	–	number	end of each subhour	–
sbcO.tSrfls	X	–	number	subhourly	–
sbcO.qrAbs	X	–	number	end of each subhour	–
sbcO.txa	X	–	number	end of each subhour	–
sbcO.txr	X	–	number	end of each subhour	–
sbcO.txe	X	–	number	end of each subhour	–
sbcO.w	X	–	number	end of each subhour	–
sbcO.qSrf	X	–	number	end of each subhour	–
sbcO.pXS	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.si	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind2	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.eta	X	–	number	end of each subhour	–
sbcO.widNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenCharNat	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.lenEffWink	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosTilt	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.atvDeg	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosAtv	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.hcLChar	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[2]	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.groundModel	X	–	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvgYr	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg31	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg14	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.cTaDbAvg07	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rConGrnd	X	–	number	run start time (of each phase, autoSize or simulate)	–
fenModel	X	–	unrecognized	input time	–
SHGC	X	–	number	input time	–
fMult	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNFRC	X	–	number	input time	–
NGlz	X	–	integer	input time	–
			number		
exShd	X	–	unrecognized	input time	–
inShd	X	–	unrecognized	input time	–
dirtLoss	X	–	number	run start time (of each phase, autoSize or simulate)	–
sfExCnd	X	–	integer	run start time (of each phase, autoSize or simulate)	–
			number		
sfExT	X	–	number	subhourly	–
sfAdjZi	X	–	integer	input time	–
			number		
uI	X	–	number	run start time (of each phase, autoSize or simulate)	–
uC	X	–	number	run start time (of each phase, autoSize or simulate)	–
uX	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
Rf	X	–	number	run start time (of each phase, autoSize or simulate)	–
grndRefl	X	–	number	monthly- hourly	–
vfSkyDf	X	–	number	monthly- hourly	–
vfGrndDf	X	–	number	monthly- hourly	–
vfSkyLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
vfGrndLW	X	–	number	run start time (of each phase, autoSize or simulate)	–
uval	X	–	number	run start time (of each phase, autoSize or simulate)	–
UNom	X	–	number	run start time (of each phase, autoSize or simulate)	–
UANom	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[0]	X	–	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[1]	X	–	number	run start time (of each phase, autoSize or simulate)	–
cFctr	X	–	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
iwshad	X	—	integer number	run start time (of each phase, autoSize or simulate)	—
msi	X	—	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model
tLrB[0]	X	—	number	end of each hour	—
tLrB[1]	X	—	number	end of each hour	—
tLrB[2]	X	—	number	end of each hour	—
tLrB[3]	X	—	number	end of each hour	—
tLrB[4]	X	—	number	end of each hour	—
tLrB[5]	X	—	number	end of each hour	—
tLrB[6]	X	—	number	end of each hour	—
tLrB[7]	X	—	number	end of each hour	—
tLrB[8]	X	—	number	end of each hour	—
tLrB[9]	X	—	number	end of each hour	—
nsghost	X	—	integer number	run start time (of each phase, autoSize or simulate)	—
sgdist[0].targTy	X	—	integer number	run start time (of each phase, autoSize or simulate)	—
sgdist[0].targTi	X	—	integer number	run start time (of each phase, autoSize or simulate)	—
sgdist[0].FSO	X	—	number	monthly- hourly	—
sgdist[0].FSC	X	—	number	monthly- hourly	—
sgdist[1].targTy	X	—	integer number	run start time (of each phase, autoSize or simulate)	—
sgdist[1].targTi	X	—	integer number	run start time (of each phase, autoSize or simulate)	—

Name	Input?	Runtime?	Type	Variability	Description
sgdist[1].FSO	X	–	number	monthly- hourly	–
sgdist[1].FSC	X	–	number	monthly- hourly	–
sgdist[2].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].FSO	X	–	number	monthly- hourly	–
sgdist[2].FSC	X	–	number	monthly- hourly	–
sgdist[3].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].FSO	X	–	number	monthly- hourly	–
sgdist[3].FSC	X	–	number	monthly- hourly	–
sgdist[4].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].FSO	X	–	number	monthly- hourly	–
sgdist[4].FSC	X	–	number	monthly- hourly	–
sgdist[5].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].FSO	X	–	number	monthly- hourly	–
sgdist[5].FSC	X	–	number	monthly- hourly	–



Name	Input?	Runtime?	Type	Variability	Description
sgdist[6].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].FSO	X	–	number	monthly-hourly	–
sgdist[6].FSC	X	–	number	monthly-hourly	–
sgdist[7].targTy	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].targTi	X	–	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].FSO	X	–	number	monthly-hourly	–
sgdist[7].FSC	X	–	number	monthly-hourly	–
sfClass	X	–	unrecognized	input time	Sfcnul, sfcsurf, sfcdoor, sfcwindow
sfArea	X	–	number	input time	Surface: gross area, net in x.xs_area.
sfU	X	–	number	input time	Uval input if no sfcon given (excl surf films)
sfCon	X	–	integer number	input time	Surface construction (optional)
sfTy	X	–	integer number	constant	Wall/floor/ceil/[intmass1/2]: for input cking.
sfFnd	X	–	integer number	input time	Surface foundation object (floors only, optional)
sfFndFloor	X	–	integer number	input time	Surface foundation floor object (walls only, optional)
sfExpPerim	X	–	number	input time	Foundation floor exposed perimeter (floors only)
width	X	–	number	input time	Width and height: used to compute shading,
height	X	–	number	input time	... and to compute area b4 mutliplier.
mult	X	–	number	input time	Area multiplier (for multiple identical windows)
xi	X	–	integer number	run start time (of each phase, autoSize or simulate)	Subscript in runtime xsrat, to facilitate access by probers 1-92

Name	Input?	Runtime?	Type	Variability	Description
msi	X	–	integer number	run start time (of each phase, autoSize or simulate)	0 or msrat msr subscr which will be used if delayed model

## 6.62 xsurf

@xsurf[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
nxXsurf	–	X	integer number	run start time (of each phase, autoSize or simulate)	0 or xsrat subscr of next record for zone. chain head is znr.xsurf1.
nxXsSpecT	–	X	integer number	run start time (of each phase, autoSize or simulate)	Addl chain of records w/ x.sfexcnd==c_excndch_spect: used hourly. head is znr.xsspect1.
ty	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
area	–	X	number	run start time (of each phase, autoSize or simulate)	–
azm	–	X	number	run start time (of each phase, autoSize or simulate)	–
tilt	–	X	number	run start time (of each phase, autoSize or simulate)	–
dircos[0]	–	X	number	run start time (of each phase, autoSize or simulate)	–
dircos[1]	–	X	number	run start time (of each phase, autoSize or simulate)	–
dircos[2]	–	X	number	run start time (of each phase, autoSize or simulate)	–
depthBG	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
height	–	X	number	run start time (of each phase, autoSize or simulate)	–
model	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
modelr	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
lThkF	–	X	number	run start time (of each phase, autoSize or simulate)	–
gti	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sco	–	X	number	monthly- hourly	–
scc	–	X	number	monthly- hourly	–
sbcI.absSlr	–	X	number	monthly- hourly	–
sbcI.awAbsSlr	–	X	number	monthly- hourly	–
sbcI.epsLW	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.zi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sbcI.F	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.Fp	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.frRad	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fSky	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.fAir	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcNat	–	X	number	end of each subhour	–
sbcI.hcFrc	–	X	number	end of each subhour	–
sbcI.hcMult	–	X	number	end of each subhour	–
sbcI.hxa	–	X	number	end of each subhour	–
sbcI.hxr	–	X	number	end of each subhour	–
sbcI.hxtot	–	X	number	end of each subhour	–
sbcI.uRat	–	X	number	end of each subhour	–
sbcI.fRat	–	X	number	end of each subhour	–
sbcI.cx	–	X	number	end of each subhour	–
sbcI.sgTarg.bm	–	X	number	end of each subhour	–
sbcI.sgTarg.df	–	X	number	end of each subhour	–
sbcI.sgTarg.tot	–	X	number	end of each subhour	–
sbcI.sg	–	X	number	end of each subhour	–
sbcI.tSrf	–	X	number	end of each subhour	–
sbcI.tSrfls	–	X	number	subhourly	–
sbcI.qrAbs	–	X	number	end of each subhour	–
sbcI.txa	–	X	number	end of each subhour	–
sbcI.txr	–	X	number	end of each subhour	–
sbcI.txe	–	X	number	end of each subhour	–
sbcI.w	–	X	number	end of each subhour	–
sbcI.qSrf	–	X	number	end of each subhour	–
sbcI.pXS	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.si	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.fcWind2	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.eta	–	X	number	end of each subhour	–
sbcI.widNom	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenNom	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenCharNat	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.lenEffWink	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosTilt	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.atvDeg	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cosAtv	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcModel	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.hcLChar	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcI.hcConst[0]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[1]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.hcConst[2]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.groundModel	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvgYr	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg31	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg14	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTaDbAvg07	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.cTGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcI.rConGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.absSlr	–	X	number	monthly- hourly	–
sbcO.awAbsSlr	–	X	number	monthly- hourly	–
sbcO.epsLW	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.zi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sbcO.F	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.Fp	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.frRad	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fSky	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fAir	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcNat	–	X	number	end of each subhour	–
sbcO.hcFrc	–	X	number	end of each subhour	–
sbcO.hcMult	–	X	number	end of each subhour	–
sbcO.hxa	–	X	number	end of each subhour	–
sbcO.hxr	–	X	number	end of each subhour	–
sbcO.hxtot	–	X	number	end of each subhour	–
sbcO.uRat	–	X	number	end of each subhour	–
sbcO.fRat	–	X	number	end of each subhour	–
sbcO.cx	–	X	number	end of each subhour	–
sbcO.sgTarg.bm	–	X	number	end of each subhour	–
sbcO.sgTarg.df	–	X	number	end of each subhour	–
sbcO.sgTarg.tot	–	X	number	end of each subhour	–
sbcO.sg	–	X	number	end of each subhour	–
sbcO.tSrf	–	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.tSrfls	–	X	number	subhourly	–
sbcO.qrAbs	–	X	number	end of each subhour	–
sbcO.txa	–	X	number	end of each subhour	–
sbcO.txr	–	X	number	end of each subhour	–
sbcO.txe	–	X	number	end of each subhour	–
sbcO.w	–	X	number	end of each subhour	–
sbcO.qSrf	–	X	number	end of each subhour	–
sbcO.pXS	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.si	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.fcWind2	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.eta	–	X	number	end of each subhour	–
sbcO.widNom	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenNom	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenCharNat	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.lenEffWink	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosTilt	–	X	number	run start time (of each phase, autoSize or simulate)	–



Name	Input?	Runtime?	Type	Variability	Description
sbcO.atvDeg	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cosAtv	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcModel	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.hcLChar	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[0]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[1]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.hcConst[2]	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.groundModel	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvgYr	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg31	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg14	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTaDbAvg07	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.cTGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sbcO.rGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–
sbcO.rConGrnd	–	X	number	run start time (of each phase, autoSize or simulate)	–
fenModel	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
SHGC	–	X	number	run start time (of each phase, autoSize or simulate)	–
fMult	–	X	number	run start time (of each phase, autoSize or simulate)	–
UNFRC	–	X	number	run start time (of each phase, autoSize or simulate)	–
NGlz	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
exShd	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
inShd	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
dirtLoss	–	X	number	run start time (of each phase, autoSize or simulate)	–
sfExCnd	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sfExT	–	X	number	subhourly	–
sfAdjZi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
uI	–	X	number	run start time (of each phase, autoSize or simulate)	–
uC	–	X	number	run start time (of each phase, autoSize or simulate)	–
uX	–	X	number	run start time (of each phase, autoSize or simulate)	–
Rf	–	X	number	run start time (of each phase, autoSize or simulate)	–
grndRefl	–	X	number	monthly- hourly	–
vfSkyDf	–	X	number	monthly- hourly	–
vfGrndDf	–	X	number	monthly- hourly	–
vfSkyLW	–	X	number	run start time (of each phase, autoSize or simulate)	–
vfGrndLW	–	X	number	run start time (of each phase, autoSize or simulate)	–
uval	–	X	number	run start time (of each phase, autoSize or simulate)	–
UNom	–	X	number	run start time (of each phase, autoSize or simulate)	–
UANom	–	X	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[0]	–	X	number	run start time (of each phase, autoSize or simulate)	–
rSrfNom[1]	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
hSrfNom[0]	–	X	number	run start time (of each phase, autoSize or simulate)	–
hSrfNom[1]	–	X	number	run start time (of each phase, autoSize or simulate)	–
cFctr	–	X	number	run start time (of each phase, autoSize or simulate)	–
iwshad	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
msi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
tLrB[0]	–	X	number	end of each hour	–
tLrB[1]	–	X	number	end of each hour	–
tLrB[2]	–	X	number	end of each hour	–
tLrB[3]	–	X	number	end of each hour	–
tLrB[4]	–	X	number	end of each hour	–
tLrB[5]	–	X	number	end of each hour	–
tLrB[6]	–	X	number	end of each hour	–
tLrB[7]	–	X	number	end of each hour	–
tLrB[8]	–	X	number	end of each hour	–
tLrB[9]	–	X	number	end of each hour	–
nsghost	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[0].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[0].FSO	–	X	number	monthly- hourly	–
sgdist[0].FSC	–	X	number	monthly- hourly	–
sgdist[1].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[1].FSO	–	X	number	monthly- hourly	–
sgdist[1].FSC	–	X	number	monthly- hourly	–
sgdist[2].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[2].FSO	–	X	number	monthly- hourly	–
sgdist[2].FSC	–	X	number	monthly- hourly	–
sgdist[3].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[3].FSO	–	X	number	monthly- hourly	–
sgdist[3].FSC	–	X	number	monthly- hourly	–
sgdist[4].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[4].FSO	–	X	number	monthly- hourly	–
sgdist[4].FSC	–	X	number	monthly- hourly	–

Name	Input?	Runtime?	Type	Variability	Description
sgdist[5].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[5].FSO	–	X	number	monthly- hourly	–
sgdist[5].FSC	–	X	number	monthly- hourly	–
sgdist[6].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[6].FSO	–	X	number	monthly- hourly	–
sgdist[6].FSC	–	X	number	monthly- hourly	–
sgdist[7].targTy	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].targTi	–	X	integer number	run start time (of each phase, autoSize or simulate)	–
sgdist[7].FSO	–	X	number	monthly- hourly	–
sgdist[7].FSC	–	X	number	monthly- hourly	–

### 6.63 zhx (owner: zone)

@zhx[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
zhxTy	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	Zhx type (cndtypes.def): lhso, lhsth, arso, arsth, arstc, or (future) nv.
sp	–	X	number	hourly	Setpoint if heat xfer is tstat controlled (settmp), else unused (hourly variability)

Name	Input?	Runtime?	Type	Variability	Description
spPri	–	X	integer number	run start time (of each phase, autoSize or simulate)	Setpoint priority: low #'s used first if setpoints equal, so can eg peg air heat b4 using local heat.
ui	–	X	integer number	run start time (of each phase, autoSize or simulate)	Terminal tu subscript if a term cap type
zi	–	X	integer number	run start time (of each phase, autoSize or simulate)	Zone znr subscript always – for term cap or vent zhx. when stable, just use ownti?
ai	–	X	integer number	run start time (of each phase, autoSize or simulate)	0 or ah ss (subscript) of air handler supplying ar zhx (copied from tu).
xiLh	–	X	integer number	run start time (of each phase, autoSize or simulate)	Subscr of local heat zhx for same terminal if any, else 0; not set for self.
xiArH	–	X	integer number	run start time (of each phase, autoSize or simulate)	Was xiheat. subscr of air heat or air set output zhx for same terminal, if any, else 0
xiArC	–	X	integer number	run start time (of each phase, autoSize or simulate)	Xicool. subscr of air cool zhx for same terminal, if any, else 0
nxZhx4z	–	X	integer number	run start time (of each phase, autoSize or simulate)	Chain: 0 or subscript of next terminal zhx for this zone; 0?? if vent; head znr.zhx1.
nxZhxSt4z	–	X	integer number	hourly	Chain: 0 or ss of next settmp zhx for this zone; head znr.zhx1st; kept sorted on sp/pri at runtime.
nxZhx4a	–	X	integer number	run start time (of each phase, autoSize or simulate)	Chain: 0 or subscript of next terminal zhx for this air handler; head ah.zhx1.
mda	–	X	integer number	hourly	For settmp, mode (mdseq[] subscr) in which this is active (ctrl'd by its sp) zhx.

## 6.64 znRes

@znRes[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	–	X	string	constant	–
Y.n	–	X	unrecognized	end of run (of each phase, autoSize or simulate)	Accumulate call count (to convert sums to averages)
Y.nHrHeat	–	X	integer number	end of run (of each phase, autoSize or simulate)	# of hours in which any heating occurred; 1st “# of hours”
Y.nHrCool	–	X	integer number	end of run (of each phase, autoSize or simulate)	Ditto cooling
Y.nHrFanv	–	X	integer number	end of run (of each phase, autoSize or simulate)	Ditto fan vent
Y.nHrNatv	–	X	integer number	end of run (of each phase, autoSize or simulate)	Ditto natural vent
Y.nHrCeilFan	–	X	integer number	end of run (of each phase, autoSize or simulate)	Ditto ceiling fan operation; last “# of hours”
Y.nIter	–	X	number	end of run (of each phase, autoSize or simulate)	# of iterations
Y.nHrUnMetH	–	X	number	end of run (of each phase, autoSize or simulate)	# of hours in this intervals having <i>any</i> unmet heating subhours
Y.nHrUnMetC	–	X	number	end of run (of each phase, autoSize or simulate)	Ditto heating
Y.nShVentH	–	X	number	end of run (of each phase, autoSize or simulate)	# of substeps in this interval when ventilation caused heating
Y.nSubhr	–	X	number	end of run (of each phase, autoSize or simulate)	Subhour counter (convenience)
Y.nSubhrLX	–	X	number	end of run (of each phase, autoSize or simulate)	# subhours with condensation (excess latent gain)



Name	Input?	Runtime?	Type	Variability	Description
Y.tAir	–	X	number	end of run (of each phase, autoSize or simulate)	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
Y.tRad	–	X	number	end of run (of each phase, autoSize or simulate)	Zone radiant temp; meaningful iff convective/radiant model active for this zone
Y.PMV7730	–	X	number	end of run (of each phase, autoSize or simulate)	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
Y.PPD7730	–	X	number	end of run (of each phase, autoSize or simulate)	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
Y.ivAirX	–	X	number	end of run (of each phase, autoSize or simulate)	Zone air exchange rate not including hvac or ducts, ach
Y.pz0	–	X	number	end of run (of each phase, autoSize or simulate)	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
Y.wAir	–	X	number	end of run (of each phase, autoSize or simulate)	Zone air humidity ratio; last float to average
Y.qCond	–	X	number	end of run (of each phase, autoSize or simulate)	Zone wall conduction gain, btu; 1st heat flow and first float to sum
Y.qsInfil	–	X	number	end of run (of each phase, autoSize or simulate)	Zone infiltration sensible gain, btu
Y.qSlr	–	X	number	end of run (of each phase, autoSize or simulate)	Zone solar gain, btu
Y.qsIg	–	X	number	end of run (of each phase, autoSize or simulate)	Zone internal sensible gain, btu

Name	Input?	Runtime?	Type	Variability	Description
Y.qMass	–	X	number	end of run (of each phase, autoSize or simulate)	Zone net sensible transfer from mass, btu. see qlair for moisture.
Y.qsIz	–	X	number	end of run (of each phase, autoSize or simulate)	Interzone gain to zone, btu
Y.qsMech	–	X	number	end of run (of each phase, autoSize or simulate)	Zone total sensible mechanical heat gain, btu
Y.eqfVentHr	–	X	number	end of run (of each phase, autoSize or simulate)	Equivalent full vent hours = sum(zn_fvent)
Y.qlInfil	–	X	number	end of run (of each phase, autoSize or simulate)	Zone infiltration latent gain, btu
Y.qlIg	–	X	number	end of run (of each phase, autoSize or simulate)	Zone internal latent gain, btu
Y.qlIz	–	X	number	end of run (of each phase, autoSize or simulate)	Zone izxfer latent gain (infil, vent, duct leakage)
Y.qlAir	–	X	number	end of run (of each phase, autoSize or simulate)	Latent heat of moisture removed from zone air: moisture analog of zncair.
Y.qlMech	–	X	number	end of run (of each phase, autoSize or simulate)	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
Y.qsBal	–	X	number	end of run (of each phase, autoSize or simulate)	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
Y.qlBal	–	X	number	end of run (of each phase, autoSize or simulate)	Latent balance similarly. consider removing bals after development.

Name	Input?	Runtime?	Type	Variability	Description
Y.qlX	–	X	number	end of run (of each phase, autoSize or simulate)	Latent gain rejected to prevent zone supersaturation === heat of condensation.
Y.unMetHDH	–	X	number	end of run (of each phase, autoSize or simulate)	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
Y.unMetCDH	–	X	number	end of run (of each phase, autoSize or simulate)	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
Y.qcMech	–	X	number	end of run (of each phase, autoSize or simulate)	Zone accumulated cooling (negative) ...
Y.qhMech	–	X	number	end of run (of each phase, autoSize or simulate)	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
Y.qvMech	–	X	number	end of run (of each phase, autoSize or simulate)	... mechanical (oav) vent (negative)
Y.litDmd	–	X	number	end of run (of each phase, autoSize or simulate)	Zone lighting demand and energy use, ...
Y.litEu	–	X	number	end of run (of each phase, autoSize or simulate)	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
M.n	–	X	unrecognized	end of each month	Accumulate call count (to convert sums to averages)
M.nHrHeat	–	X	integer number	end of each month	# of hours in which any heating occurred; 1st “# of hours”
M.nHrCool	–	X	integer number	end of each month	Ditto cooling
M.nHrFanv	–	X	integer number	end of each month	Ditto fan vent
M.nHrNatv	–	X	integer number	end of each month	Ditto natural vent

Name	Input?	Runtime?	Type	Variability	Description
M.nHrCeilFan	–	X	integer number	end of each month	Ditto ceiling fan operation; last “# of hours”
M.nIter	–	X	number	end of each month	# of iterations
M.nHrUnMetH	–	X	number	end of each month	# of hours in this intervals having <i>any</i> unmet heating subhours
M.nHrUnMetC	–	X	number	end of each month	Ditto heating
M.nShVentH	–	X	number	end of each month	# of substeps int this interval when ventilation caused heating
M.nSubhr	–	X	number	end of each month	Subhour counter (convenience)
M.nSubhrLX	–	X	number	end of each month	# subhours with condensation (excess latent gain)
M.tAir	–	X	number	end of each month	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
M.tRad	–	X	number	end of each month	Zone radiant temp; meaningful iff convective/radiant model active for this zone
M.PMV7730	–	X	number	end of each month	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
M.PPD7730	–	X	number	end of each month	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
M.ivAirX	–	X	number	end of each month	Zone air exchange rate not including hvac or ducts, ach
M.pz0	–	X	number	end of each month	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
M.wAir	–	X	number	end of each month	Zone air humidity ratio; last float to average

Name	Input?	Runtime?	Type	Variability	Description
M.qCond	–	X	number	end of each month	Zone wall conduction gain, btu; 1st heat flow and first float to sum
M.qsInfil	–	X	number	end of each month	Zone infiltration sensible gain, btu
M.qSlr	–	X	number	end of each month	Zone solar gain, btu
M.qsIg	–	X	number	end of each month	Zone internal sensible gain, btu
M.qMass	–	X	number	end of each month	Zone net sensible transfer from mass, btu. see qlair for moisture.
M.qsIz	–	X	number	end of each month	Interzone gain to zone, btu
M.qsMech	–	X	number	end of each month	Zone total sensible mechanical heat gain, btu
M.eqfVentHr	–	X	number	end of each month	Equivalent full vent hours = sum(zn_fvent)
M.qIInfil	–	X	number	end of each month	Zone infiltration latent gain, btu
M.qIIg	–	X	number	end of each month	Zone internal latent gain, btu
M.qIIz	–	X	number	end of each month	Zone izxfer latent gain (infil, vent, duct leakage)
M.qIAir	–	X	number	end of each month	Latent heat of moisture removed from zone air: moisture analog of zncair.
M.qIMech	–	X	number	end of each month	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
M.qsBal	–	X	number	end of each month	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
M.qIBal	–	X	number	end of each month	Latent balance similarly. consider removing bals after development.

Name	Input?	Runtime?	Type	Variability	Description
M.qlX	–	X	number	end of each month	Latent gain rejected to prevent zone supersaturation === heat of condensation.
M.unMetHDH	–	X	number	end of each month	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
M.unMetCDH	–	X	number	end of each month	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
M.qcMech	–	X	number	end of each month	Zone accumulated cooling (negative)
M.qhMech	–	X	number	end of each month	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
M.qvMech	–	X	number	end of each month	... mechanical (oav) vent (negative)
M.litDmd	–	X	number	end of each month	Zone lighting demand and energy use, ...
M.litEu	–	X	number	end of each month	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
D.n	–	X	unrecognized	end of each day	Accumulate call count (to convert sums to averages)
D.nHrHeat	–	X	integer number	end of each day	# of hours in which any heating occurred; 1st “# of hours”
D.nHrCool	–	X	integer number	end of each day	Ditto cooling
D.nHrFanv	–	X	integer number	end of each day	Ditto fan vent
D.nHrNatv	–	X	integer number	end of each day	Ditto natural vent
D.nHrCeilFan	–	X	integer number	end of each day	Ditto ceiling fan operation; last “# of hours”

Name	Input?	Runtime?	Type	Variability	Description
D.nIter	–	X	number	end of each day	# of iterations
D.nHrUnMetH	–	X	number	end of each day	# of hours in this intervals having <i>any</i> unmet heating subhours
D.nHrUnMetC	–	X	number	end of each day	Ditto heating
D.nShVentH	–	X	number	end of each day	# of substeps int this interval when ventilation caused heating
D.nSubhr	–	X	number	end of each day	Subhour counter (convenience)
D.nSubhrLX	–	X	number	end of each day	# subhours with condensation (excess latent gain)
D.tAir	–	X	number	end of each day	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
D.tRad	–	X	number	end of each day	Zone radiant temp; meaningful iff convective/radiant model active for this zone
D.PMV7730	–	X	number	end of each day	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
D.PPD7730	–	X	number	end of each day	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
D.ivAirX	–	X	number	end of each day	Zone air exchange rate not including hvac or ducts, ach
D.pz0	–	X	number	end of each day	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
D.wAir	–	X	number	end of each day	Zone air humidity ratio; last float to average
D.qCond	–	X	number	end of each day	Zone wall conduction gain, btu; 1st heat flow and first float to sum

Name	Input?	Runtime?	Type	Variability	Description
D.qsInfil	–	X	number	end of each day	Zone infiltration sensible gain, btu
D.qsSlr	–	X	number	end of each day	Zone solar gain, btu
D.qsIg	–	X	number	end of each day	Zone internal sensible gain, btu
D.qMass	–	X	number	end of each day	Zone net sensible transfer from mass, btu. see qlair for moisture.
D.qsIz	–	X	number	end of each day	Interzone gain to zone, btu
D.qsMech	–	X	number	end of each day	Zone total sensible mechanical heat gain, btu
D.eqfVentHr	–	X	number	end of each day	Equivalent full vent hours = sum(zn_fvent)
D.qlInfil	–	X	number	end of each day	Zone infiltration latent gain, btu
D.qlIg	–	X	number	end of each day	Zone internal latent gain, btu
D.qlIz	–	X	number	end of each day	Zone izxfer latent gain (infil, vent, duct leakage)
D.qlAir	–	X	number	end of each day	Latent heat of moisture removed from zone air: moisture analog of zncair.
D.qlMech	–	X	number	end of each day	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
D.qsBal	–	X	number	end of each day	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
D.qlBal	–	X	number	end of each day	Latent balance similarly. consider removing bals after development.
D.qlX	–	X	number	end of each day	Latent gain rejected to prevent zone supersaturation === heat of condensation.



Name	Input?	Runtime?	Type	Variability	Description
D.unMetHDDH	–	X	number	end of each day	Zone end-of-hour air temp excursion below heating set point, deg-hr ( $\leq 0$ )
D.unMetCDH	–	X	number	end of each day	Zone end-of-hour air temp excursion above cooling set point, deg-hr ( $\geq 0$ )
D.qcMeh	–	X	number	end of each day	Zone accumulated cooling (negative)
D.qhMeh	–	X	number	end of each day	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
D.qvMeh	–	X	number	end of each day	... mechanical (oav) vent (negative)
D.litDmd	–	X	number	end of each day	Zone lighting demand and energy use, ...
D.litEu	–	X	number	end of each day	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
H.n	–	X	unrecognized	end of each hour	Accumulate call count (to convert sums to averages)
H.nHrHeat	–	X	integer number	end of each hour	# of hours in which any heating occurred; 1st “# of hours”
H.nHrCool	–	X	integer number	end of each hour	Ditto cooling
H.nHrFanv	–	X	integer number	end of each hour	Ditto fan vent
H.nHrNatv	–	X	integer number	end of each hour	Ditto natural vent
H.nHrCeilFan	–	X	integer number	end of each hour	Ditto ceiling fan operation; last “# of hours”
H.nIter	–	X	number	end of each hour	# of iterations
H.nHrUnMetH	–	X	number	end of each hour	# of hours in this intervals having <i>any</i> unmet heating subhours

Name	Input?	Runtime?	Type	Variability	Description
H.nHrUnMetC	–	X	number	end of each hour	Ditto heating
H.nShVentH	–	X	number	end of each hour	# of substeps int this interval when ventilation caused heating
H.nSubhr	–	X	number	end of each hour	Subhour counter (convenience)
H.nSubhrLX	–	X	number	end of each hour	# subhours with condensation (excess latent gain)
H.tAir	–	X	number	end of each hour	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
H.tRad	–	X	number	end of each hour	Zone radiant temp; meaningful iff convective/radiant model active for this zone
H.PMV7730	–	X	number	end of each hour	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
H.PPD7730	–	X	number	end of each hour	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
H.ivAirX	–	X	number	end of each hour	Zone air exchange rate not including hvac or ducts, ach
H.pz0	–	X	number	end of each hour	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
H.wAir	–	X	number	end of each hour	Zone air humidity ratio; last float to average
H.qCond	–	X	number	end of each hour	Zone wall conduction gain, btu; 1st heat flow and first float to sum
H.qsInfil	–	X	number	end of each hour	Zone infiltration sensible gain, btu
H.qSlr	–	X	number	end of each hour	Zone solar gain, btu
H.qsIg	–	X	number	end of each hour	Zone internal sensible gain, btu

Name	Input?	Runtime?	Type	Variability	Description
H.qMass	–	X	number	end of each hour	Zone net sensible transfer from mass, btu. see qlair for moisture.
H.qsIz	–	X	number	end of each hour	Interzone gain to zone, btu
H.qsMech	–	X	number	end of each hour	Zone total sensible mechanical heat gain, btu
H.eqfVentHr	–	X	number	end of each hour	Equivalent full vent hours = sum(zn_fvent)
H.qlInfil	–	X	number	end of each hour	Zone infiltration latent gain, btu
H.qlIg	–	X	number	end of each hour	Zone internal latent gain, btu
H.qlIz	–	X	number	end of each hour	Zone izxfer latent gain (infil, vent, duct leakage)
H.qlAir	–	X	number	end of each hour	Latent heat of moisture removed from zone air: moisture analog of zncair.
H.qlMech	–	X	number	end of each hour	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
H.qsBal	–	X	number	end of each hour	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
H.qlBal	–	X	number	end of each hour	Latent balance similarly. consider removing bals after development.
H.qlX	–	X	number	end of each hour	Latent gain rejected to prevent zone supersaturation == heat of condensation.
H.unMetHDH	–	X	number	end of each hour	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)

Name	Input?	Runtime?	Type	Variability	Description
H.unMetCDH	–	X	number	end of each hour	Zone end-of-hour air temp excursion above cooling set point, deg-hr ( $\geq 0$ )
H.qcMech	–	X	number	end of each hour	Zone accumulated cooling (negative)
H.qhMech	–	X	number	end of each hour	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
H.qvMech	–	X	number	end of each hour	... mechanical (oav) vent (negative)
H.litDmd	–	X	number	end of each hour	Zone lighting demand and energy use, ...
H.litEu	–	X	number	end of each hour	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
S.n	–	X	unrecognized	end of each subhour	Accumulate call count (to convert sums to averages)
S.nHrHeat	–	X	integer number	end of each subhour	# of hours in which any heating occurred; 1st “# of hours”
S.nHrCool	–	X	integer number	end of each subhour	Ditto cooling
S.nHrFanv	–	X	integer number	end of each subhour	Ditto fan vent
S.nHrNatv	–	X	integer number	end of each subhour	Ditto natural vent
S.nHrCeilFan	–	X	integer number	end of each subhour	Ditto ceiling fan operation; last “# of hours”
S.nIter	–	X	number	end of each subhour	# of iterations
S.nHrUnMetH	–	X	number	end of each subhour	# of hours in this intervals having <i>any</i> unmet heating subhours
S.nHrUnMetC	–	X	number	end of each subhour	Ditto heating
S.nShVentH	–	X	number	end of each subhour	# of substeps in this interval when ventilation caused heating

Name	Input?	Runtime?	Type	Variability	Description
S.nSubhr	–	X	number	end of each subhour	Subhour counter (convenience)
S.nSubhrLX	–	X	number	end of each subhour	# subhours with condensation (excess latent gain)
S.tAir	–	X	number	end of each subhour	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
S.tRad	–	X	number	end of each subhour	Zone radiant temp; meaningful iff convective/radiant model active for this zone
S.PMV7730	–	X	number	end of each subhour	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
S.PPD7730	–	X	number	end of each subhour	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
S.ivAirX	–	X	number	end of each subhour	Zone air exchange rate not including hvac or ducts, ach
S.pz0	–	X	number	end of each subhour	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
S.wAir	–	X	number	end of each subhour	Zone air humidity ratio; last float to average
S.qCond	–	X	number	end of each subhour	Zone wall conduction gain, btu; 1st heat flow and first float to sum
S.qsInfil	–	X	number	end of each subhour	Zone infiltration sensible gain, btu
S.qSlr	–	X	number	end of each subhour	Zone solar gain, btu
S.qsIg	–	X	number	end of each subhour	Zone internal sensible gain, btu
S.qMass	–	X	number	end of each subhour	Zone net sensible transfer from mass, btu. see qlair for moisture.
S.qsIz	–	X	number	end of each subhour	Interzone gain to zone, btu

Name	Input?	Runtime?	Type	Variability	Description
S.qsMech	–	X	number	end of each subhour	Zone total sensible mechanical heat gain, btu
S.eqfVentHr	–	X	number	end of each subhour	Equivalent full vent hours = sum(zn_fvent)
S.qlInfil	–	X	number	end of each subhour	Zone infiltration latent gain, btu
S.qlIg	–	X	number	end of each subhour	Zone internal latent gain, btu
S.qlIz	–	X	number	end of each subhour	Zone izxfer latent gain (infil, vent, duct leakage)
S.qlAir	–	X	number	end of each subhour	Latent heat of moisture removed from zone air: moisture analog of zncair.
S.qlMech	–	X	number	end of each subhour	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
S.qsBal	–	X	number	end of each subhour	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
S.qlBal	–	X	number	end of each subhour	Latent balance similarly. consider removing bals after development.
S.qlX	–	X	number	end of each subhour	Latent gain rejected to prevent zone supersaturation == heat of condensation.
S.unMetHDH	–	X	number	end of each subhour	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
S.unMetCDH	–	X	number	end of each subhour	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
S.qcMech	–	X	number	end of each subhour	Zone accumulated cooling (negative) ...

Name	Input?	Runtime?	Type	Variability	Description
S.qhMech	–	X	number	end of each subhour	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
S.qvMech	–	X	number	end of each subhour	... mechanical (oav) vent (negative)
S.litDmd	–	X	number	end of each subhour	Zone lighting demand and energy use, ...
S.litEu	–	X	number	end of each subhour	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
prior.Y.n	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	Accumulate call count (to convert sums to averages)
prior.Y.nHrHeat	–	X	integer number	run start time (of each phase, autoSize or simulate)	# of hours in which any heating occurred; 1st “# of hours”
prior.Y.nHrCool	–	X	integer number	run start time (of each phase, autoSize or simulate)	Ditto cooling
prior.Y.nHrFanv	–	X	integer number	run start time (of each phase, autoSize or simulate)	Ditto fan vent
prior.Y.nHrNatv	–	X	integer number	run start time (of each phase, autoSize or simulate)	Ditto natural vent
prior.Y.nHrCeilFan	–	X	integer number	run start time (of each phase, autoSize or simulate)	Ditto ceiling fan operation; last “# of hours”
prior.Y.nIter	–	X	number	run start time (of each phase, autoSize or simulate)	# of iterations

Name	Input?	Runtime?	Type	Variability	Description
prior.Y.nHrUnMetH	–	X	number	run start time (of each phase, autoSize or simulate)	# of hours in this intervals having <i>any</i> unmet heating subhours
prior.Y.nHrUnMetC	–	X	number	run start time (of each phase, autoSize or simulate)	Ditto heating
prior.Y.nShVentH	–	X	number	run start time (of each phase, autoSize or simulate)	# of substeps int this interval when ventilation caused heating
prior.Y.nSubhr	–	X	number	run start time (of each phase, autoSize or simulate)	Subhour counter (convenience)
prior.Y.nSubhrLX	–	X	number	run start time (of each phase, autoSize or simulate)	# subhours with condensation (excess latent gain)
prior.Y.tAir	–	X	number	run start time (of each phase, autoSize or simulate)	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
prior.Y.tRad	–	X	number	run start time (of each phase, autoSize or simulate)	Zone radiant temp; meaningful iff convective/radiant model active for this zone
prior.Y.PMV7730	–	X	number	run start time (of each phase, autoSize or simulate)	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
prior.Y.PPD7730	–	X	number	run start time (of each phase, autoSize or simulate)	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
prior.Y.ivAirX	–	X	number	run start time (of each phase, autoSize or simulate)	Zone air exchange rate not including hvac or ducts, ach



Name	Input?	Runtime?	Type	Variability	Description
prior.Y.pz0	–	X	number	run start time (of each phase, autoSize or simulate)	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
prior.Y.wAir	–	X	number	run start time (of each phase, autoSize or simulate)	Zone air humidity ratio; last float to average
prior.Y.qCond	–	X	number	run start time (of each phase, autoSize or simulate)	Zone wall conduction gain, btu; 1st heat flow and first float to sum
prior.Y.qsInfil	–	X	number	run start time (of each phase, autoSize or simulate)	Zone infiltration sensible gain, btu
prior.Y.qSlr	–	X	number	run start time (of each phase, autoSize or simulate)	Zone solar gain, btu
prior.Y.qsIg	–	X	number	run start time (of each phase, autoSize or simulate)	Zone internal sensible gain, btu
prior.Y.qMass	–	X	number	run start time (of each phase, autoSize or simulate)	Zone net sensible transfer from mass, btu. see qlair for moisture.
prior.Y.qsIz	–	X	number	run start time (of each phase, autoSize or simulate)	Interzone gain to zone, btu
prior.Y.qsMech	–	X	number	run start time (of each phase, autoSize or simulate)	Zone total sensible mechanical heat gain, btu
prior.Y.eqfVentHr	–	X	number	run start time (of each phase, autoSize or simulate)	Equivalent full vent hours = sum(zn_fvent)

Name	Input?	Runtime?	Type	Variability	Description
prior.Y.qlInfil	–	X	number	run start time (of each phase, autoSize or simulate)	Zone infiltration latent gain, btu
prior.Y.qlIg	–	X	number	run start time (of each phase, autoSize or simulate)	Zone internal latent gain, btu
prior.Y.qlIz	–	X	number	run start time (of each phase, autoSize or simulate)	Zone izxfer latent gain (infil, vent, duct leakage)
prior.Y.qlAir	–	X	number	run start time (of each phase, autoSize or simulate)	Latent heat of moisture removed from zone air: moisture analog of zncair.
prior.Y.qlMech	–	X	number	run start time (of each phase, autoSize or simulate)	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
prior.Y.qsBal	–	X	number	run start time (of each phase, autoSize or simulate)	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
prior.Y.qlBal	–	X	number	run start time (of each phase, autoSize or simulate)	Latent balance similarly. consider removing bals after development.
prior.Y.qlX	–	X	number	run start time (of each phase, autoSize or simulate)	Latent gain rejected to prevent zone supersaturation === heat of condensation.
prior.Y.unMetHDH	–	X	number	run start time (of each phase, autoSize or simulate)	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
prior.Y.unMetCDH	–	X	number	run start time (of each phase, autoSize or simulate)	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)

Name	Input?	Runtime?	Type	Variability	Description
prior.Y.qcMech	–	X	number	run start time (of each phase, autoSize or simulate)	Zone accumulated cooling (negative) ...
prior.Y.qhMech	–	X	number	run start time (of each phase, autoSize or simulate)	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
prior.Y.qvMech	–	X	number	run start time (of each phase, autoSize or simulate)	... mechanical (oav) vent (negative)
prior.Y.litDmd	–	X	number	run start time (of each phase, autoSize or simulate)	Zone lighting demand and energy use, ...
prior.Y.litEu	–	X	number	run start time (of each phase, autoSize or simulate)	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
prior.M.n	–	X	unrecognized	monthly	Accumulate call count (to convert sums to averages)
prior.M.nHrHeat	–	X	integer number	monthly	# of hours in which any heating occurred; 1st “# of hours”
prior.M.nHrCool	–	X	integer number	monthly	Ditto cooling
prior.M.nHrFanv	–	X	integer number	monthly	Ditto fan vent
prior.M.nHrNatv	–	X	integer number	monthly	Ditto natural vent
prior.M.nHrCeilFan	–	X	integer number	monthly	Ditto ceiling fan operation; last “# of hours”
prior.M.nIter	–	X	number	monthly	# of iterations
prior.M.nHrUnMetH	–	X	number	monthly	# of hours in this intervals having <i>any</i> unmet heating subhours
prior.M.nHrUnMetC	–	X	number	monthly	Ditto heating
prior.M.nShVentH	–	X	number	monthly	# of substeps int this interval when ventilation caused heating

Name	Input?	Runtime?	Type	Variability	Description
prior.M.nSubhr	–	X	number	monthly	Subhour counter (convenience)
prior.M.nSubhrLX	–	X	number	monthly	# subhours with condensation (excess latent gain)
prior.M.tAir	–	X	number	monthly	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
prior.M.tRad	–	X	number	monthly	Zone radiant temp; meaningful iff convective/radiant model active for this zone
prior.M.PMV7730	–	X	number	monthly	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
prior.M.PPD7730	–	X	number	monthly	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
prior.M.ivAirX	–	X	number	monthly	Zone air exchange rate not including hvac or ducts, ach
prior.M.pz0	–	X	number	monthly	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
prior.M.wAir	–	X	number	monthly	Zone air humidity ratio; last float to average
prior.M.qCond	–	X	number	monthly	Zone wall conduction gain, btu; 1st heat flow and first float to sum
prior.M.qsInfil	–	X	number	monthly	Zone infiltration sensible gain, btu
prior.M.qSlr	–	X	number	monthly	Zone solar gain, btu
prior.M.qsIg	–	X	number	monthly	Zone internal sensible gain, btu
prior.M.qMass	–	X	number	monthly	Zone net sensible transfer from mass, btu. see qlair for moisture.
prior.M.qsIz	–	X	number	monthly	Interzone gain to zone, btu

Name	Input?	Runtime?	Type	Variability	Description
prior.M.qsMech	–	X	number	monthly	Zone total sensible mechanical heat gain, btu
prior.M.eqfVentHr	–	X	number	monthly	Equivalent full vent hours = sum(zn_fvent)
prior.M.qlInfil	–	X	number	monthly	Zone infiltration latent gain, btu
prior.M.qlIg	–	X	number	monthly	Zone internal latent gain, btu
prior.M.qlIz	–	X	number	monthly	Zone izxfer latent gain (infil, vent, duct leakage)
prior.M.qlAir	–	X	number	monthly	Latent heat of moisture removed from zone air: moisture analog of zncair.
prior.M.qlMech	–	X	number	monthly	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
prior.M.qsBal	–	X	number	monthly	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
prior.M.qlBal	–	X	number	monthly	Latent balance similarly. consider removing bals after development.
prior.M.qlX	–	X	number	monthly	Latent gain rejected to prevent zone supersaturation == heat of condensation.
prior.M.unMetHDH	–	X	number	monthly	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
prior.M.unMetCDH	–	X	number	monthly	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
prior.M.qcMech	–	X	number	monthly	Zone accumulated cooling (negative) ...

Name	Input?	Runtime?	Type	Variability	Description
prior.M.qhMech	–	X	number	monthly	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
prior.M.qvMech	–	X	number	monthly	... mechanical (oav) vent (negative)
prior.M.litDmd	–	X	number	monthly	Zone lighting demand and energy use, ...
prior.M.litEu	–	X	number	monthly	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
prior.D.n	–	X	unrecognized	daily	Accumulate call count (to convert sums to averages)
prior.D.nHrHeat	–	X	integer number	daily	# of hours in which any heating occurred; 1st “# of hours”
prior.D.nHrCool	–	X	integer number	daily	Ditto cooling
prior.D.nHrFanv	–	X	integer number	daily	Ditto fan vent
prior.D.nHrNatv	–	X	integer number	daily	Ditto natural vent
prior.D.nHrCeilFan	–	X	integer number	daily	Ditto ceiling fan operation; last “# of hours”
prior.D.nIter	–	X	number	daily	# of iterations
prior.D.nHrUnMetH	–	X	number	daily	# of hours in this intervals having <i>any</i> unmet heating subhours
prior.D.nHrUnMetC	–	X	number	daily	Ditto heating
prior.D.nShVentH	–	X	number	daily	# of substeps int this interval when ventilation caused heating
prior.D.nSubhr	–	X	number	daily	Subhour counter (convenience)
prior.D.nSubhrLX	–	X	number	daily	# subhours with condensation (excess latent gain)
prior.D.tAir	–	X	number	daily	Zone air temp; must be 1st float, is first float to average (see cnguts.h)

Name	Input?	Runtime?	Type	Variability	Description
prior.D.tRad	–	X	number	daily	Zone radiant temp; meaningful iff convective/radiant model active for this zone
prior.D.PMV7730	–	X	number	daily	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
prior.D.PPD7730	–	X	number	daily	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
prior.D.ivAirX	–	X	number	daily	Zone air exchange rate not including hvac or ducts, ach
prior.D.pz0	–	X	number	daily	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
prior.D.wAir	–	X	number	daily	Zone air humidity ratio; last float to average
prior.D.qCond	–	X	number	daily	Zone wall conduction gain, btu; 1st heat flow and first float to sum
prior.D.qsInfil	–	X	number	daily	Zone infiltration sensible gain, btu
prior.D.qSlr	–	X	number	daily	Zone solar gain, btu
prior.D.qsIg	–	X	number	daily	Zone internal sensible gain, btu
prior.D.qMass	–	X	number	daily	Zone net sensible transfer from mass, btu. see qlair for moisture.
prior.D.qsIz	–	X	number	daily	Interzone gain to zone, btu
prior.D.qsMech	–	X	number	daily	Zone total sensible mechanical heat gain, btu
prior.D.eqfVentHr	–	X	number	daily	Equivalent full vent hours = sum(zn_fvent)
prior.D.qlInfil	–	X	number	daily	Zone infiltration latent gain, btu
prior.D.qlIg	–	X	number	daily	Zone internal latent gain, btu

Name	Input?	Runtime?	Type	Variability	Description
prior.D.qlIz	–	X	number	daily	Zone izxfer latent gain (infil, vent, duct leakage)
prior.D.qlAir	–	X	number	daily	Latent heat of moisture removed from zone air: moisture analog of zncair.
prior.D.qlMech	–	X	number	daily	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
prior.D.qsBal	–	X	number	daily	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
prior.D.qlBal	–	X	number	daily	Latent balance similarly. consider removing bals after development.
prior.D.qlX	–	X	number	daily	Latent gain rejected to prevent zone supersaturation === heat of condensation.
prior.D.unMetHDH	–	X	number	daily	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
prior.D.unMetCDH	–	X	number	daily	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
prior.D.qcMech	–	X	number	daily	Zone accumulated cooling (negative)
prior.D.qhMech	–	X	number	daily	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
prior.D.qvMech	–	X	number	daily	... mechanical (oav) vent (negative)
prior.D.litDmd	–	X	number	daily	Zone lighting demand and energy use, ...



Name	Input?	Runtime?	Type	Variability	Description
prior.D.litEu	–	X	number	daily	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
prior.H.n	–	X	unrecognized	hourly	Accumulate call count (to convert sums to averages)
prior.H.nHrHeat	–	X	integer number	hourly	# of hours in which any heating occurred; 1st “# of hours”
prior.H.nHrCool	–	X	integer number	hourly	Ditto cooling
prior.H.nHrFanv	–	X	integer number	hourly	Ditto fan vent
prior.H.nHrNatv	–	X	integer number	hourly	Ditto natural vent
prior.H.nHrCeilFan	–	X	integer number	hourly	Ditto ceiling fan operation; last “# of hours”
prior.H.nIter	–	X	number	hourly	# of iterations
prior.H.nHrUnMetH	–	X	number	hourly	# of hours in this intervals having <i>any</i> unmet heating subhours
prior.H.nHrUnMetC	–	X	number	hourly	Ditto heating
prior.H.nShVentH	–	X	number	hourly	# of substeps int this interval when ventilation caused heating
prior.H.nSubhr	–	X	number	hourly	Subhour counter (convenience)
prior.H.nSubhrLX	–	X	number	hourly	# subhours with condensation (excess latent gain)
prior.H.tAir	–	X	number	hourly	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
prior.H.tRad	–	X	number	hourly	Zone radiant temp; meaningful iff convective/radiant model active for this zone
prior.H.PMV7730	–	X	number	hourly	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale

Name	Input?	Runtime?	Type	Variability	Description
prior.H.PPD7730	–	X	number	hourly	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
prior.H.ivAirX	–	X	number	hourly	Zone air exchange rate not including hvac or ducts, ach
prior.H.pz0	–	X	number	hourly	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
prior.H.wAir	–	X	number	hourly	Zone air humidity ratio; last float to average
prior.H.qCond	–	X	number	hourly	Zone wall conduction gain, btu; 1st heat flow and first float to sum
prior.H.qsInfil	–	X	number	hourly	Zone infiltration sensible gain, btu
prior.H.qSlr	–	X	number	hourly	Zone solar gain, btu
prior.H.qsIg	–	X	number	hourly	Zone internal sensible gain, btu
prior.H.qMass	–	X	number	hourly	Zone net sensible transfer from mass, btu. see qlair for moisture.
prior.H.qsIz	–	X	number	hourly	Interzone gain to zone, btu
prior.H.qsMech	–	X	number	hourly	Zone total sensible mechanical heat gain, btu
prior.H.eqfVentHr	–	X	number	hourly	Equivalent full vent hours = sum(zn_fvent)
prior.H.qlInfil	–	X	number	hourly	Zone infiltration latent gain, btu
prior.H.qlIg	–	X	number	hourly	Zone internal latent gain, btu
prior.H.qlIz	–	X	number	hourly	Zone izxfer latent gain (infil, vent, duct leakage)
prior.H.qlAir	–	X	number	hourly	Latent heat of moisture removed from zone air: moisture analog of zncair.

Name	Input?	Runtime?	Type	Variability	Description
prior.H.qlMech	–	X	number	hourly	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
prior.H.qsBal	–	X	number	hourly	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.
prior.H.qlBal	–	X	number	hourly	Latent balance similarly. consider removing bals after development.
prior.H.qlX	–	X	number	hourly	Latent gain rejected to prevent zone supersaturation === heat of condensation.
prior.H.unMetHDH	–	X	number	hourly	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
prior.H.unMetCDH	–	X	number	hourly	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
prior.H.qcMech	–	X	number	hourly	Zone accumulated cooling (negative)
prior.H.qhMech	–	X	number	hourly	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
prior.H.qvMech	–	X	number	hourly	... mechanical (oav) vent (negative)
prior.H.litDmd	–	X	number	hourly	Zone lighting demand and energy use, ...
prior.H.litEu	–	X	number	hourly	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.
prior.S.n	–	X	unrecognized	subhourly	Accumulate call count (to convert sums to averages)

Name	Input?	Runtime?	Type	Variability	Description
prior.S.nHrHeat	–	X	integer number	subhourly	# of hours in which any heating occurred; 1st “# of hours”
prior.S.nHrCool	–	X	integer number	subhourly	Ditto cooling
prior.S.nHrFanv	–	X	integer number	subhourly	Ditto fan vent
prior.S.nHrNatv	–	X	integer number	subhourly	Ditto natural vent
prior.S.nHrCeilFan	–	X	integer number	subhourly	Ditto ceiling fan operation; last “# of hours”
prior.S.nIter	–	X	number	subhourly	# of iterations
prior.S.nHrUnMetH	–	X	number	subhourly	# of hours in this intervals having <i>any</i> unmet heating subhours
prior.S.nHrUnMetC	–	X	number	subhourly	Ditto heating
prior.S.nShVentH	–	X	number	subhourly	# of substeps int this interval when ventilation caused heating
prior.S.nSubhr	–	X	number	subhourly	Subhour counter (convenience)
prior.S.nSubhrLX	–	X	number	subhourly	# subhours with condensation (excess latent gain)
prior.S.tAir	–	X	number	subhourly	Zone air temp; must be 1st float, is first float to average (see cnguts.h)
prior.S.tRad	–	X	number	subhourly	Zone radiant temp; meaningful iff convective/radiant model active for this zone
prior.S.PMV7730	–	X	number	subhourly	Iso7730 predicted mean vote = predicted comfort per ashrae thermal sensation scale
prior.S.PPD7730	–	X	number	subhourly	Iso7730 predicted percent dissatisfied = % of people not satisfied with conditions
prior.S.ivAirX	–	X	number	subhourly	Zone air exchange rate not including hvac or ducts, ach

Name	Input?	Runtime?	Type	Variability	Description
prior.S.pz0	–	X	number	subhourly	Zone air pressure relative to patm at nominal z=0, lbf/sf (from zn_pz0)
prior.S.wAir	–	X	number	subhourly	Zone air humidity ratio; last float to average
prior.S.qCond	–	X	number	subhourly	Zone wall conduction gain, btu; 1st heat flow and first float to sum
prior.S.qsInfil	–	X	number	subhourly	Zone infiltration sensible gain, btu
prior.S.qSlr	–	X	number	subhourly	Zone solar gain, btu
prior.S.qsIg	–	X	number	subhourly	Zone internal sensible gain, btu
prior.S.qMass	–	X	number	subhourly	Zone net sensible transfer from mass, btu. see qlair for moisture.
prior.S.qsIz	–	X	number	subhourly	Interzone gain to zone, btu
prior.S.qsMech	–	X	number	subhourly	Zone total sensible mechanical heat gain, btu
prior.S.eqfVentHr	–	X	number	subhourly	Equivalent full vent hours = sum( zn_fvent)
prior.S.qlInfil	–	X	number	subhourly	Zone infiltration latent gain, btu
prior.S.qlIg	–	X	number	subhourly	Zone internal latent gain, btu
prior.S.qlIz	–	X	number	subhourly	Zone izxfer latent gain (infil, vent, duct leakage)
prior.S.qlAir	–	X	number	subhourly	Latent heat of moisture removed from zone air: moisture analog of zncair.
prior.S.qlMech	–	X	number	subhourly	Zone latent mechanical heat gain, btu; last heat flow and last float to sum
prior.S.qsBal	–	X	number	subhourly	Sensible balance: sum of sensible heats, should be near 0. set in cnguts.cpp.

Name	Input?	Runtime?	Type	Variability	Description
prior.S.qlBal	–	X	number	subhourly	Latent balance similarly. consider removing bals after development.
prior.S.qlX	–	X	number	subhourly	Latent gain rejected to prevent zone supersaturation === heat of condensation.
prior.S.unMetHDH	–	X	number	subhourly	Zone end-of-hour air temp excursion below heating set point, deg-hr (<=0)
prior.S.unMetCDH	–	X	number	subhourly	Zone end-of-hour air temp excursion above cooling set point, deg-hr (>=0)
prior.S.qcMech	–	X	number	subhourly	Zone accumulated cooling (negative)
prior.S.qhMech	–	X	number	subhourly	... and heating (positive) mechanical heat gains. latent & sensible combined. 10-93.
prior.S.qvMech	–	X	number	subhourly	... mechanical (oav) vent (negative)
prior.S.litDmd	–	X	number	subhourly	Zone lighting demand and energy use, ...
prior.S.litEu	–	X	number	subhourly	... from gains, in addition to posting eu to meter, re daylighting for nrel. 9-94.

## 6.65 zone

@zone[1..].

Name	Input?	Runtime?	Type	Variability	Description
name	X	X	string	constant	–
znModel	X	X	integer	input time	–
znArea	X	X	number	input time	–
znVol	X	X	number	input time	–
floorZ	X	X	number	input time	–

Name	Input?	Runtime?	Type	Variability	Description
ceilingHt	X	X	number	run start time (of each phase, autoSize or simulate)	—
znCAir	X	X	number	input time	—
HIRatio	X	X	number	run start time (of each phase, autoSize or simulate)	—
znAzm	X	X	number	input time	—
plenumRet	X	X	integer number	input time	—
znSC	X	X	number	hourly	—
znTH	X	X	number	subhourly	—
znTD	X	X	number	subhourly	—
znTC	X	X	number	subhourly	—
znQMxH	X	X	number	hourly	—
znQMxHRated	X	X	number	run start time (of each phase, autoSize or simulate)	—
znQMxC	X	X	number	hourly	—
znQMxCRated	X	X	number	run start time (of each phase, autoSize or simulate)	—
rsi	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
hcFrcF	X	X	number	hourly	—
hcAirX	X	X	number	end of each subhour	—
hcAirXIsSet	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	—
xfanFOn	X	X	number	hourly	—
xfan.fanTy	X	X	unrecognized	autosize and simulate phase start time	—
xfan.vfDs	X	X	number	end of each subhour	—

Name	Input?	Runtime?	Type	Variability	Description
xfan.vfDs_As	X	X	number	autosize and simulate phase start time	–
xfan.vfDs_AsNov	X	X	number	autosize and simulate phase start time	–
xfan.vfMxF	X	X	number	autosize and simulate phase start time	–
xfan.press	X	X	number	run start time (of each phase, autoSize or simulate)	–
xfan.eff	X	X	number	run start time (of each phase, autoSize or simulate)	–
xfan.shaftPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
xfan.elecPwr	X	X	number	run start time (of each phase, autoSize or simulate)	–
xfan.motTy	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
xfan.motEff	X	X	number	autosize and simulate phase start time	–
xfan.motPos	X	X	unrecognized	autosize and simulate phase start time	–
xfan.curvePy.k[0]	X	X	number	autosize and simulate phase start time	–



Name	Input?	Runtime?	Type	Variability	Description
xfan.curvePy.k[1]	X	X	number	autosize and simulate phase start time	—
xfan.curvePy.k[2]	X	X	number	autosize and simulate phase start time	—
xfan.curvePy.k[3]	X	X	number	autosize and simulate phase start time	—
xfan.curvePy.k[4]	X	X	number	autosize and simulate phase start time	—
xfan.curvePy.k[5]	X	X	number	autosize and simulate phase start time	—
xfan.mtri	X	X	integer number	input time	—
xfan.endUse	X	X	integer number	autosize and simulate phase start time	—
xfan.ausz	X	X	integer number	run start time (of each phase, autoSize or simulate)	—
xfan.outPower	X	X	number	subhourly	—
xfan.airPower	X	X	number	subhourly	—
xfan.cMx	X	X	number	end of each subhour	—
xfan.c	X	X	number	end of each subhour	—
xfan.t	X	X	number	end of each subhour	—
xfan.frOn	X	X	number	end of each subhour	—
xfan.p	X	X	number	end of each subhour	—
xfan.q	X	X	number	end of each subhour	—
xfan.dT	X	X	number	end of each subhour	—
xfan.qAround	X	X	number	end of each subhour	—
infAC	X	X	number	hourly	—
infELA	X	X	number	hourly	—

Name	Input?	Runtime?	Type	Variability	Description
infShld	X	X	integer number	input time	–
infStories	X	X	integer number	input time	–
eaveZ	X	X	number	run start time (of each phase, autoSize or simulate)	–
windFLkg	X	X	number	subhourly	–
vrZdd	X	X	unrecognized	run start time (of each phase, autoSize or simulate)	–
xsurf1	–	X	integer number	run start time (of each phase, autoSize or simulate)	Chain head (xsrat subscr) of zone's xsurfs: sur- face/window/perim/masswall info. next: xsrat.nxxsurf.
xsSpecT1	–	X	integer number	run start time (of each phase, autoSize or simulate)	0 or chain head of zn's xsurfs with .sfex- cnd==c_excndch_spect: used hourly. next: xsrat.nxxspect.
tu1	–	X	integer number	run start time (of each phase, autoSize or simulate)	Head of chain of zone's terminals: 0 or tub subscript. next: tu.nxtu.
zhx1	–	X	integer number	run start time (of each phase, autoSize or simulate)	Chain head of zone's zhx's (zone hvac xfers): 0 or zhxb subscript. next: zhx.nxzhx4z.
zhx1St	–	X	integer number	run start time (of each phase, autoSize or simulate)	... zone's settmp (tstat-ctrl'd) zhx's. next: zhx.nxzhzst4z.
znSCF	–	X	integer number	run start time (of each phase, autoSize or simulate)	Non-0 if i.znsc given by user; 0 to default shade closure in cnloads.cpp
stackc	–	X	number	run start time (of each phase, autoSize or simulate)	Stack coefficient for zone height (sherman-grimsrud model)

Name	Input?	Runtime?	Type	Variability	Description
windc	–	X	number	run start time (of each phase, autoSize or simulate)	Wind coefficient for zone height and shielding (sherman-grimsrud model)
rIgDistNAI	–	X	integer number	run start time (of each phase, autoSize or simulate)	0 or number of allocated entries in...
rIgDistN	–	X	integer number	run start time (of each phase, autoSize or simulate)	0 or number of used entries in...
rIgDist	–	X	unrecognized	run start time (of each phase, autoSize or simulate)	Null or ptr to heap array of distrubution info for rad int gain originating in zone.
surfA	–	X	number	run start time (of each phase, autoSize or simulate)	Total surface area in zone, ft2 (surfaces, doors, windows, ducts)
surfASlr	–	X	number	run start time (of each phase, autoSize or simulate)	Total “short wave” surface area in zone, ft2
ductA	–	X	number	run start time (of each phase, autoSize or simulate)	Total duct surface area in zone, ft2 (included in zn_surfa)
surfEpsLWAvg	–	X	number	run start time (of each phase, autoSize or simulate)	Area-weighted surface lw emissivity = sum( surfarea * surfepslw) / zn_surfa
airRadXC1	–	X	number	run start time (of each phase, autoSize or simulate)	Constants re zn_airradxarea calc
airRadXC2	–	X	number	run start time (of each phase, autoSize or simulate)	–

Name	Input?	Runtime?	Type	Variability	Description
airRadXArea	–	X	number	run start time (of each phase, autoSize or simulate)	Area of air “surface”, ft2
FAir	–	X	number	run start time (of each phase, autoSize or simulate)	Air f “view factor” (constant during simulation)
airCxF	–	X	number	end of each hour	Air factor for zn_cxsh re lw exchange
airCx	–	X	number	end of each subhour	Air contribution to zn_cxsh, btuh/f
rmTrans[0]	–	X	number	end of each hour on 1st day of month/run	Area-weighted summed diffuse transmissivity of windows in zone,
rmTrans[1]	–	X	number	end of each hour on 1st day of month/run	Area-weighted summed diffuse transmissivity of windows in zone,
rmAbs	–	X	number	end of each hour on 1st day of month/run	Sum of area-weighted solar (sw) absorptivity for opaque room surfaces (dimensionless).
adjRmAbs[0]	–	X	number	end of each hour on 1st day of month/run	Rmabs adjusted for reflected energy that goes out windows (m-h):
adjRmAbs[1]	–	X	number	end of each hour on 1st day of month/run	Rmabs adjusted for reflected energy that goes out windows (m-h):
rmAbsCAir	–	X	number	end of each hour on 1st day of month/run	Sum of area-weighted absorptivity for non-massive room surfaces
cavAbsCAir[0]	–	X	number	end of each hour on 1st day of month/run	Zone cair cavity absorptance === portion insolation to no particular surface
cavAbsCAir[1]	–	X	number	end of each hour on 1st day of month/run	Zone cair cavity absorptance === portion insolation to no particular surface
sgfCavBm[0]	–	X	number	end of each hour on 1st day of month/run	Zone's solar gain factors from its windows not explicitly targeted for hour,

Name	Input?	Runtime?	Type	Variability	Description
sgfCavBm[1]	–	X	number	end of each hour on 1st day of month/run	Zone's solar gain factors from its windows not explicitly targeted for hour,
sgfCavDf[0]	–	X	number	end of each hour on 1st day of month/run	.. to be distributed among surface and cair sgr entries after accumulation.
sgfCavDf[1]	–	X	number	end of each hour on 1st day of month/run	.. to be distributed among surface and cair sgr entries after accumulation.
sgSaBm[0]	–	X	number	end of each hour on 1st day of month/run	Cair adjustments to above for gains getting to other side of (quick) surface or
sgSaBm[1]	–	X	number	end of each hour on 1st day of month/run	Cair adjustments to above for gains getting to other side of (quick) surface or
sgSaDf[0]	–	X	number	end of each hour on 1st day of month/run	.. lost to outdoors due to surface film vs conductance thru (quick) surface
sgSaDf[1]	–	X	number	end of each hour on 1st day of month/run	.. lost to outdoors due to surface film vs conductance thru (quick) surface
sgfCAirBm[0]	–	X	number	end of each hour on 1st day of month/run	Beam solar gain factor this hour to zone cair
sgfCAirBm[1]	–	X	number	end of each hour on 1st day of month/run	Beam solar gain factor this hour to zone cair
sgfCAirDf[0]	–	X	number	end of each hour on 1st day of month/run	Diffuse .. these are multipliers for wthr data, later, via sgr
sgfCAirDf[1]	–	X	number	end of each hour on 1st day of month/run	Diffuse .. these are multipliers for wthr data, later, via sgr
uaSpecT	–	X	number	run start time (of each phase, autoSize or simulate)	Ua to specified temps (excnd=spect surfaces), for bcon. set/used only in cnguts.cpp.

Name	Input?	Runtime?	Type	Variability	Description
ua	–	X	number	run start time (of each phase, autoSize or simulate)	Overall loss to ambient (sum uval*area), constant for run, for bcon and zn_aqldhr. btuh/f.
UANom	–	X	number	run start time (of each phase, autoSize or simulate)	Ua to ambient based on surface unom (derived with default surf conductances), btuh/f
ductCondUANom	–	X	number	run start time (of each phase, autoSize or simulate)	Nominal total ua of ducts in zone, btuh/f (due to conduction, not air leakage)
haMass	–	X	number	run start time (of each phase, autoSize or simulate)	Total ha (surf conductance * area) to mass (btuh/f)
BGWallPerim	–	X	number	run start time (of each phase, autoSize or simulate)	Total below grade wall perimeter, ft
BGWallPA4	–	X	number	run start time (of each phase, autoSize or simulate)	Sum (perim*a4)
BGWallPA5	–	X	number	run start time (of each phase, autoSize or simulate)	Sum (perim*a5)
qSgTot	–	X	number	end of each hour	Hour total solar gain to some
sgTotTarg.bm	–	X	number	end of each subhour	–
sgTotTarg.df	–	X	number	end of each subhour	–
sgTotTarg.tot	–	X	number	end of each subhour	–
qrIgTot	–	X	unrecognized	end of each hour	Total originating in this zone: redundant total for energy balance check only.
qrIgTotO	–	X	unrecognized	end of each hour	Subtotal lost to outdoors thru light surfaces, to show in zeb rpt as -cond.
qrIgTotIz	–	X	unrecognized	end of each hour	Net subtotal to other zones thru light surfaces, to show in zeb rpt as -izone.

Name	Input?	Runtime?	Type	Variability	Description
qrIgAir	–	X	unrecognized	end of each hour	Rad int gain to this zone's cair (for light surfaces/windows), for zn_aqldhr. 11-95.
qrIgMs	–	X	number	end of each hour	Rad int gain to mass sides in this zone, for energy balance, set in cnloads. 11-95.
znSGain	–	X	number	end of each hour	–
znLGain	–	X	number	end of each hour	–
znLitDmd	–	X	number	end of each hour	–
znLitEu	–	X	number	end of each hour	–
znXLGain	–	X	number	end of each subhour	–
znXLGainLs	–	X	number	end of each subhour	–
bcon	–	X	number	run start time (of each phase, autoSize or simulate)	Portion of b constant for run: ua + uaspect. setup time.
qMsSg	–	X	number	end of each subhour	–
qSgAir	–	X	number	end of each subhour	Subhour's solar gain rate (btuh) to air
sgAirTarg.bm	–	X	number	end of each subhour	–
sgAirTarg.df	–	X	number	end of each subhour	–
sgAirTarg.tot	–	X	number	end of each subhour	–
qSgTotSh	–	X	number	end of each subhour	–
sgTotShTarg.bm	–	X	number	end of each subhour	–
sgTotShTarg.df	–	X	number	end of each subhour	–
sgTotShTarg.tot	–	X	number	end of each subhour	–
qIzXAnSh	–	X	number	end of each subhour	Subhourly gain due to non-airnet izxfers (btuh, +=into zone)
qIzSh	–	X	number	end of each subhour	Subhourly part of interzone gain rate (btuh, +=into zone)
pz0W[0]	–	X	number	end of each subhour	Working zone pressures relative to patm at nominal z=0, lbf/sf

Name	Input?	Runtime?	Type	Variability	Description
pz0W[1]	–	X	number	end of each subhour	Working zone pressures relative to patm at nominal z=0, lbf/sf
pz0	–	X	number	end of each subhour	Final zone pressure relative to patm at nominal z=0, lbf/sf
ventUt	–	X	unrecognized	end of each subhour	Vent utility for this substep
qDuctCondAir	–	X	number	end of each subhour	To ta (convection)
qDuctCondRad	–	X	number	end of each subhour	To tr (radiation)
qDuctCond	–	X	number	end of each subhour	Sum from last step (else energy balance trouble)
qDHWLossAir	–	X	number	end of each subhour	To ta (convection)
qDHWLossRad	–	X	number	end of each subhour	To tr (radiation)
qDHWLoss	–	X	number	end of each subhour	Sum
qHPWH	–	X	number	end of each subhour	Heat extracted from zone by heat pump dhwheater(s)
hpwhAirX	–	X	number	end of each subhour	Approximate zone air change rate due to
airNetI[0].tdb	–	X	number	end of each subhour	–
airNetI[0].w	–	X	number	end of each subhour	–
airNetI[0].amf	–	X	number	end of each subhour	–
airNetI[1].tdb	–	X	number	end of each subhour	–
airNetI[1].w	–	X	number	end of each subhour	–
airNetI[1].amf	–	X	number	end of each subhour	–
fVent	–	X	number	end of each subhour	Vent fraction; venting used to hold zone at zntd
tzVent	–	X	number	end of each subhour	Zone air temp with full vent, f (debug aid)
anAmfCpVent	–	X	number	end of each subhour	Vent flow (in excess of zn_airneti[ 0])
anAmfCpTVent	–	X	number	end of each subhour	Ditto *temp
ductLkI.tdb	–	X	number	end of each subhour	–
ductLkI.w	–	X	number	end of each subhour	–
ductLkI.amf	–	X	number	end of each subhour	–
ductLkO.tdb	–	X	number	end of each subhour	–



Name	Input?	Runtime?	Type	Variability	Description
ductLkO.w	–	X	number	end of each subhour	–
ductLkO.amf	–	X	number	end of each subhour	–
sysAirI.tdb	–	X	number	end of each subhour	–
sysAirI.w	–	X	number	end of each subhour	–
sysAirI.amf	–	X	number	end of each subhour	–
sysAirO.tdb	–	X	number	end of each subhour	–
sysAirO.w	–	X	number	end of each subhour	–
sysAirO.amf	–	X	number	end of each subhour	–
OAVRlfO.tdb	–	X	number	end of each subhour	–
OAVRlfO.w	–	X	number	end of each subhour	–
OAVRlfO.amf	–	X	number	end of each subhour	–
sysDepAirIls.tdb	–	X	number	end of each subhour	–
sysDepAirIls.w	–	X	number	end of each subhour	–
sysDepAirIls.amf	–	X	number	end of each subhour	–
qCondQS	–	X	number	end of each subhour	Total quick surface conduction, btuh (+ = into zone)
qCondMS	–	X	number	end of each subhour	Total mass exterior surface conduction, btuh (+ = into zone)
rsAmfSysReq[0]	–	X	number	end of each subhour	Requested rsys air mass flow (at system) to hold current step set point, lbm/hr
rsAmfSysReq[1]	–	X	number	end of each subhour	Requested rsys air mass flow (at system) to hold current step set point, lbm/hr
rsFSize	–	X	number	end of each subhour	Fraction of requested air that rsys could provide
rsAmfSup	–	X	number	end of each subhour	Final rsys supply air mass flow (at register, +=in), lbm/hr
rsAmfRet	–	X	number	end of each subhour	Final rsys return air mass flow (out of zone at grille, +=out), lbm/hr
rsAmfRetLs	–	X	number	subhourly	Last step zn_rsamfret (+ = out)

Name	Input?	Runtime?	Type	Variability	Description
tzsp	–	X	number	end of each subhour	Current step controlling set point, f
hcMode	–	X	integer number	end of each subhour	Heating / cooling mode required per set point (rsmheat, rsmcool, )
unMetHDH	–	X	number	end of each subhour	Tz - znth at end of hour, deg-hr
unMetCDH	–	X	number	end of each subhour	Tz - zntc at end of hour, deg-hr
fConvH	–	X	number	subhourly	Heating
fConvC	–	X	number	subhourly	Cooling
fConv	–	X	number	subhourly	Current step
qsHvac	–	X	number	end of each subhour	Subhour total (sensible) power of all hvac (btuh)
qlHvac	–	X	number	end of each subhour	Subhour total latent power (btuh) (moisture * 1061) likewise
qlIz	–	X	number	end of each subhour	Latent gain from izxfer sources (infil, vent, and duct leakage), btuh
wCase	–	X	number	end of each subhour	Debug aid, see code
airMode	–	X	number	end of each subhour	System mechanical air circulation mode (0=off, 1=on) re evaluation of
rho	–	X	number	end of each subhour	Zone moist air density at nominal w=tp_refw, lb/cf
rho0	–	X	number	end of each subhour	Zone moist air density at nominal z=0, lb/cf; computed from tzls and zn_pz0[ 0]
rho0ls	–	X	number	subhourly	Ditto, prior step
dryAirMass	–	X	number	end of each subhour	Total mass of <i>dry</i> air in zone, lbm
dryAirMassEff	–	X	number	end of each subhour	Effective dry air mass in zone, lbm
ivAirX	–	X	number	end of each subhour	Zone infiltration/ventilation air change rate (changes/hr)
airX	–	X	number	end of each subhour	Overall zone air change rate (changes/hr)
hcAirXls	–	X	number	subhourly	Prior subhour value of i.zn_hcairx
hcFrc	–	X	number	subhourly	Inside surface forced convection coefficient, btuh/ft2-f
windPresV	–	X	number	subhourly	Wind velocity pressure, lbf/ft2
tz	–	X	number	end of each subhour	–
aTz	–	X	number	end of each subhour	–

Name	Input?	Runtime?	Type	Variability	Description
wz	–	X	number	end of each subhour	–
relHum	–	X	number	end of each subhour	Zone relative humidity, 0 - 1
relHumls	–	X	number	subhourly	Zone relative humidity, end last subhour, 0 - 1
relHumlh	–	X	number	hourly	Zone relative humidity, end last hour, 0 - 1
twb	–	X	number	end of each subhour	Zone wet bulb temp, f
aWz	–	X	number	end of each subhour	–
tzls	–	X	number	subhourly	–
wzls	–	X	number	subhourly	–
tzlh	–	X	number	hourly	–
tzlsDelta	–	X	number	constant	–
wzlsDelta	–	X	number	constant	–
tr	–	X	number	end of each subhour	–
trls	–	X	number	end of each subhour	–
trlh	–	X	number	hourly	–
md	–	X	integer	end of each subhour	Current hvac mode:
			number		subscript of mdseq