

# QuadQuad PCB Datasheet

4ch Quadrature Decoder

---

## Description

The QuadQuad microprocessor decodes up to four incremental quadrature encoders simultaneously and provides position, velocity and metadata. The device communicates as SPI slave and data can be either polled or streamed. Home/index inputs are provided.



## Features

- Four quadrature channels (sampled 4x per indent)
- Data provided:
  - Position (8, 16 or 32-bit)
  - Velocity (12-bit resolution)
  - Metadata: status, stream timing
- Velocity up to 10,000 transitions/s
- Velocity precision of 0.1% at rated velocity
- Home/index input for each channel
- SPI slave interface up to 2MHz
- Streamed data packets up to at least 50Hz with 4x channels at maximum rated velocity
- Operating voltage 3.3V to 5.5V
- Supports 4x Pololu HP motors at their maximum rated shaft speed of 30,000 RPM
- Arduino library and demo available

## Contents

Description .....	1
Features .....	1
Physical Connections.....	3
Electrical Characteristics .....	3
Protocol.....	4
SPI Interface .....	4
Packet Format .....	4
Packets .....	4
1 - Get Version .....	4
2 - Get Binary Motion Data .....	5
3 - Binary Stream Data .....	5
4 - Set Stream Period .....	6
5 - Get Stream Period.....	6
6 - Set Data Mask .....	6
7 - Get Data Mask.....	7
8 - Set Stream Config.....	7
9 - Get Stream Config.....	8
10 - Set Position .....	8
11 - Get Position.....	8
12 - Set History Dimensions .....	9
13 - Get History Dimensions .....	10
14 - Set Input Mode.....	10
Worked Examples .....	12
Read Version Numbers .....	12

## Physical Connections



The QuadQuad PCB features one 26-pin connector with the following pins:

Name	Function
Q1A, Q1B...	Quadrature inputs A and B for channels 1-4
Q1in, Q2in...	Home/index inputs for channels 1-4 (Optional. Polarity is software configurable)
Q1out, Q2out...	Outputs for channels 1-4 (Not yet implemented)
GND, V+	Power connections (GND is 0V ground, V+ is 3.3V to 5.5V)
RESET	Reset pin (Active low, can be left unconnected)
SS	SPI Slave Select (Active low)
SCK	SPI Serial Clock
SDI	SPI Serial Data In (Connect to MOSI on master)
SDO	SPI Serial Data Out (Connect to MISO on master)
SBO	SPI Serial Back Off (Handshake line, see section "SPI Interface")
RX, TX	UART Receive and Transmit (Not yet implemented)

## Electrical Characteristics

- Operating power (V+) should be 3.3V to 5.5V. Absolute maximum power range is -0.3V to 6.5V.
- Input pins are Schmitt triggers with low/high thresholds of 0.2V+ and 0.8V+.
- All input pins have internal pull-ups.
- Output pin low/high voltages are max 0.6V and min V+ - 0.7.

# Protocol

## SPI Interface

The SPI master interface must be configured for SPI mode 1 and can be clocked up to 2Mhz.

The QuadQuad SPI interface includes a handshake line from the slave to master, called *Serial Back Off (SBO)*, used to prevent the master from overrunning the slave's buffers. While SBO is asserted low, SCK must not be clocked. The SBO line is also used by the slave to signal when data is available, while SS is de-asserted high.

The following sequence should be followed for a typical packet query:

1. Master asserts *Slave Select (SS)* low.
2. Master waits until slave asserts *Serial Back Off (SBO)* low and then master clocks out one byte. Repeat for entire packet.
3. Master de-asserts *Slave Select (SS)* high. Slave de-asserts *Serial Back Off (SBO)*.
4. Master waits until slave asserts *Serial Back Off (SBO)* low. This indicates slave has packet data to transmit.
5. Master asserts *Slave Select (SS)* low.
6. Master waits until slave asserts *Serial Back Off (SBO)* low and then master reads one byte. Repeat for entire packet. The master may also transmit data at the same time or after reading a packet from the slave, in which case repeat step 3.
7. Master de-asserts *Slave Select (SS)* high. Slave de-asserts *Serial Back Off (SBO)*.

Stream packets are a special case, since they are sent at a steady rate without requiring a query packet. When a stream packet becomes available, the slave asserts SBO and the stream packet can be read by proceeding from step 6.

## Packet Format

Applicable interface protocol version: v1.00.

Size	U8	U8	U8	Variable	U8
Field	STX	Packet Size	Packet ID	Payload	Checksum

*STX* is ASCII character 2.

*Packet Size* is the size of the entire packet, in bytes.

*Checksum* is the 8-bit checksum of the entire packet.

## Packets

The following section contains details of the packets that can be communicated, specifically, the *Payload* field.

Packet ID	Description / Payload			
1 - Get Version	Read firmware and protocol version numbers.			
	Send	None		
	Reply	Size	U8	U8
		Field	Return Code	Firmware Version Major
		Size	U8	U8
		Field	Firmware Version Minor	Protocol Version

2 - Get Binary Motion Data	Read motion data. Each quadrature channel and field in the reply payload, except for <i>Return Code</i> , is optional and configurable using the 6 - <i>Set Data Mask</i> and 8 - <i>Set Stream Config</i> packets. Channels and fields that are deselected will simply be omitted (zero bytes). Alternatively, this data can be streamed using packet 4 - <i>Set Stream Period</i> .																			
	Send	None																		
Reply	<table><tr><td>Size</td><td>U8</td><td>Variable</td><td>Variable</td></tr><tr><td>Field</td><td>Return Code</td><td>[Channel 1 Data]</td><td>[Channel 2 Data]</td></tr><tr><td>Size</td><td>Variable</td><td>Variable</td><td></td></tr><tr><td>Field</td><td>[Channel 3 Data]</td><td>[Channel 4 Data]</td><td></td></tr></table>	Size	U8	Variable	Variable	Field	Return Code	[Channel 1 Data]	[Channel 2 Data]	Size	Variable	Variable		Field	[Channel 3 Data]	[Channel 4 Data]				
		Size	U8	Variable	Variable															
		Field	Return Code	[Channel 1 Data]	[Channel 2 Data]															
		Size	Variable	Variable																
	Field	[Channel 3 Data]	[Channel 4 Data]																	
	<b>Channel Data:</b>																			
	<table><tr><td>Size</td><td>I8/I16/I32</td><td>I16</td><td>U8</td></tr><tr><td>Field</td><td>[Position]</td><td>[Velocity]</td><td>[Status]</td></tr></table>	Size	I8/I16/I32	I16	U8	Field	[Position]	[Velocity]	[Status]											
	Size	I8/I16/I32	I16	U8																
	Field	[Position]	[Velocity]	[Status]																
	<p><b>Position:</b> Number of quadrature transitions forward/backward. There are four transitions per indent. The number of bits used to represent <i>Position</i> can be configured using packet 6 - <i>Set Data Mask</i> and defaults to 32-bits. When less than 32-bit position is specified, the lower 8- or 16 bits will simply be retrieved and wrapping will occur on overflow. When relative position mode is enabled using packet 6 - <i>Set Data Mask</i>, <i>Position</i> will contain the change in position since the last position read.</p>																			
<p><b>Velocity:</b> Rate at which <i>Position</i> is changing, measured as: Transitions Per Second = <i>Velocity</i> * 15,624 / 4,096. There are four transitions per indent. Velocity is unaffected by home/index inputs.</p>																				
<b>Status:</b>																				
<table><tr><td>Bit</td><td>7</td><td>6..1</td><td>0</td></tr><tr><td>Field</td><td>Glitch</td><td>Reserved</td><td>Overspeed</td></tr></table>	Bit	7	6..1	0	Field	Glitch	Reserved	Overspeed												
Bit	7	6..1	0																	
Field	Glitch	Reserved	Overspeed																	
<p><b>Glitch:</b> This bit is set if the two quadrature lines A and B have made an invalid transition. This may be caused by noise on the lines or if quadrature velocity exceeds the rated maximum velocity. <i>Position</i> and <i>Velocity</i> data may be inaccurate.</p>																				
<p><b>Overspeed:</b> Quadrature velocity has exceeded rated maximum velocity and <i>Position</i> and <i>Velocity</i> data may be inaccurate.</p>																				
3 - Binary Stream Data	Stream packet with motion data. Each quadrature channel and field in the reply payload, except for <i>Return Code</i> , is optional and configurable using the 6 - <i>Set Data Mask</i> and 8 - <i>Set Stream Config</i> packets. Fields that are deselected will simply be omitted (zero bytes). Use packet 4 - <i>Set Stream Period</i> to set up streaming. Also see section “SPI Interface” for how to use the <i>Serial Back Off</i> (SBO) handshake line.																			
	Send	This packet must not be sent by the master device.																		
Reply	<table><tr><td>Size</td><td>U16</td><td>U8</td><td>Variable</td></tr><tr><td>Field</td><td>[Stream Period Timing]</td><td>[Stream Periods Elapsed]</td><td>[Channel 1 Data]</td></tr><tr><td>Size</td><td>Variable</td><td>Variable</td><td>Variable</td></tr><tr><td>Field</td><td>[Channel 2 Data]</td><td>[Channel 3 Data]</td><td>[Channel 4 Data]</td></tr></table>	Size	U16	U8	Variable	Field	[Stream Period Timing]	[Stream Periods Elapsed]	[Channel 1 Data]	Size	Variable	Variable	Variable	Field	[Channel 2 Data]	[Channel 3 Data]	[Channel 4 Data]			
		Size	U16	U8	Variable															
		Field	[Stream Period Timing]	[Stream Periods Elapsed]	[Channel 1 Data]															
		Size	Variable	Variable	Variable															
	Field	[Channel 2 Data]	[Channel 3 Data]	[Channel 4 Data]																
<p><b>Stream Period Timing:</b> Time elapsed since start of calculation of previous stream packet until the current stream packet became available for transmission, measured as: Stream Period Timing in Seconds = <i>Stream Period Timing</i> x 4/15625. In short, this number measures how old the stream data is and is typically the configured <i>Stream Period</i> plus a small processing overhead. Example: If you set</p>																				

		<p><i>Stream Period</i> = 100 and measure <i>Stream Period Timing</i> = 108, the processing overhead since capturing the quadrature data for the current packet and making it available for transmission is 8 x 4/15625. If the master fails to read an entire stream packet before the next period, a new stream packet will not be provided until the master reads out the packet. <i>Stream Period Timing</i> excludes time for any missed stream periods. <i>Stream Period Timing</i> will clip at 0xFFFF.</p> <p><b><i>Stream Periods Elapsed</i></b>: Number of <i>Stream Periods</i> elapsed since the last successful stream packet transmission. This will normally be 1, unless <i>Stream Period</i> is set too small such that the master cannot read the packet in time. <i>Stream Periods Elapsed</i> will clip at 0xFF.</p> <p><b>Channel Data</b>: See packet 2 - <i>Get Binary Motion Data</i>.</p>																
4 - Set Stream Period	Set period at which motion data is streamed to the master. Alternatively, this data can be polled using packet 2 - <i>Get Binary Motion Data</i> .																	
	Send	Size	U16															
		Field	Stream Period															
		<p><b><i>Stream Period</i></b>: Time between stream packets, measured as: Stream Period in Seconds = <i>Stream Period</i> x 4/15625. Set <i>Stream Period</i> = 0 to disable the stream. Set <i>Stream Period</i> = 1 to receive stream packets at maximum rate. In reality, stream packets cannot be sent at very high rates such as period = 1. The actual rate is affected by the amount of processing required, such as number of fields in the stream, SPI clock speed and the master response time. Also see <i>Stream Period Timing</i> in packet 3 - <i>Binary Stream Data</i>. Default at start-up: 0 (Disabled)</p>																
	Reply	Size	U8															
		Field	Return Code															
5 - Get Stream Period	Read period at which motion data is streamed to the master.																	
	Send	None																
	Reply	Size	U8	U16														
Field		Return Code	Stream Period															
		<p><b>Stream Period</b>: See packet 4 - <i>Set Stream Period</i>.</p>																
6 - Set Data Mask	Set which channels and fields are to be included in motion data (see packet 2 - <i>Get Binary Motion Data</i> and 3 - <i>Binary Stream Data</i> ).																	
	Send	Size	U8	U8	U8	U8												
		Field	Chan Mask 1	Data Mask 1	[Chan Mask...]	[Data Mask...]												
		<p>Any number of <i>Channel Mask</i> and <i>Data Mask</i> pairs can be concatenated to set multiple masks to multiple channels. If any mask conflicts occur, any latter bit value will override the former.</p> <p><b><i>Channel Mask</i></b>: Bit mask selecting which channels <i>Data Mask</i> will be applied to. Multiple channels can be selected by adding masks.</p> <table><tr><td>Bit</td><td>7..4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>Field</td><td>Unused</td><td>Channel 4</td><td>Channel 3</td><td>Channel 2</td><td>Channel 1</td></tr></table> <p><b><i>Data Mask</i></b>: Bit mask selecting what data to include for channels selected by <i>Channel Mask</i>.</p>					Bit	7..4	3	2	1	0	Field	Unused	Channel 4	Channel 3	Channel 2	Channel 1
Bit	7..4	3	2	1	0													
Field	Unused	Channel 4	Channel 3	Channel 2	Channel 1													

		<table><tr><td>Bit</td><td>7..6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1..0</td></tr><tr><td>Field</td><td>Unused</td><td>Status</td><td>Reserved</td><td>Velocity</td><td>Position Relative</td><td>Position Size</td></tr></table>	Bit	7..6	5	4	3	2	1..0	Field	Unused	Status	Reserved	Velocity	Position Relative	Position Size					
		Bit	7..6	5	4	3	2	1..0													
		Field	Unused	Status	Reserved	Velocity	Position Relative	Position Size													
		<p><b>Position Size:</b> Select how many bits will be used to represent position value.</p>																			
		<table><tr><td>Position Size</td><td>Number of Bits</td></tr><tr><td>0x00</td><td>Position omitted</td></tr><tr><td>0x01</td><td>8-bit signed integer</td></tr><tr><td>0x02</td><td>16-bit signed integer</td></tr><tr><td>0x03</td><td>32-bit signed integer</td></tr></table>	Position Size	Number of Bits	0x00	Position omitted	0x01	8-bit signed integer	0x02	16-bit signed integer	0x03	32-bit signed integer									
Position Size	Number of Bits																				
0x00	Position omitted																				
0x01	8-bit signed integer																				
0x02	16-bit signed integer																				
0x03	32-bit signed integer																				
<p>Default at start-up: 0x03 (32-bit signed integer)</p>																					
<p><b>Position Relative:</b> Set this bit to enable relative position mode. This mode will cause position values to represent the change in position since the last read position value (via either packet 2 - <i>Get Binary Motion Data</i> or 3 - <i>Binary Stream Data</i>) instead of absolute position value. Absolute position value can still be read using packet 11 - <i>Get Position</i>.</p> <p>Default at start-up: 0 (Disabled)</p>																					
<p><b>Velocity:</b> Set this bit to include velocity data.</p> <p>Default at start-up: 1 (Enabled)</p>																					
<p><b>Status:</b> Set this bit to include status data. See packet 2 - <i>Get Binary Motion Data</i>.</p> <p>Default at start-up: 0 (Disabled)</p>																					
	Reply	<table><tr><td>Size</td><td>U8</td></tr><tr><td>Field</td><td>Return Code</td></tr></table>	Size	U8	Field	Return Code															
Size	U8																				
Field	Return Code																				
7 - Get Data Mask	Read which channels and fields are to be included in motion data (packets 2 - <i>Get Binary Motion Data</i> and 3 - <i>Binary Stream Data</i> ).																				
	Send	None																			
	Reply	<table><tr><td>Size</td><td>U8</td><td>U8</td><td>U8</td></tr><tr><td>Field</td><td>Return Code</td><td>Chan 1 Data Mask</td><td>Chan 2 Data Mask</td></tr><tr><td>Size</td><td>U8</td><td>U8</td><td></td></tr><tr><td>Field</td><td>Chan 3 Data Mask</td><td>Chan 4 Data Mask</td><td></td></tr></table>	Size	U8	U8	U8	Field	Return Code	Chan 1 Data Mask	Chan 2 Data Mask	Size	U8	U8		Field	Chan 3 Data Mask	Chan 4 Data Mask				
Size		U8	U8	U8																	
Field		Return Code	Chan 1 Data Mask	Chan 2 Data Mask																	
Size		U8	U8																		
Field		Chan 3 Data Mask	Chan 4 Data Mask																		
The <i>Data Mask</i> for each channel is returned.																					
<b>Data Mask:</b> See packet 6 - <i>Set Data Mask</i> .																					
8 - Set Stream Config	Set which additional fields to include in stream data.																				
	Send	<table><tr><td>Size</td><td>U8</td></tr><tr><td>Field</td><td>Stream Config Mask</td></tr></table>	Size	U8	Field	Stream Config Mask															
Size		U8																			
Field		Stream Config Mask																			
<p><b>Stream Config Mask:</b></p>																					
<table><tr><td>Bit</td><td>7..2</td><td>1</td><td>0</td></tr><tr><td>Field</td><td>Reserved</td><td>Stream Periods Elapsed</td><td>Stream Period Timing</td></tr></table>		Bit	7..2	1	0	Field	Reserved	Stream Periods Elapsed	Stream Period Timing												
Bit	7..2	1	0																		
Field	Reserved	Stream Periods Elapsed	Stream Period Timing																		
<p><b>Stream Period Timing:</b> See packets 3 - <i>Binary Stream Data</i> and 4 - <i>Set Stream Period</i>.</p> <p>Default at start-up: 0 (Disabled)</p>																					
<p><b>Stream Periods Elapsed:</b> See packets 3 - <i>Binary Stream Data</i> and 4 - <i>Set Stream Period</i>.</p> <p>Default at start-up: 0 (Disabled)</p>																					

	Reply	<table><tr><td>Size</td><td>U8</td></tr><tr><td>Field</td><td>Return Code</td></tr></table>	Size	U8	Field	Return Code																																				
Size	U8																																									
Field	Return Code																																									
9 - Get Stream Config	Read which additional fields to include in stream data.																																									
	Send	None																																								
	Reply	<table><tr><td>Size</td><td>U8</td><td>U8</td></tr><tr><td>Field</td><td>Return Code</td><td>Stream Config Mask</td></tr></table> <p><b>Stream Config Mask:</b> See packet 8 - <i>Set Stream Config</i>.</p>	Size	U8	U8	Field	Return Code	Stream Config Mask																																		
Size	U8	U8																																								
Field	Return Code	Stream Config Mask																																								
10 - Set Position	Set absolute position value.																																									
	Send	<table><tr><td>Size</td><td>U8</td><td>I8/I16/I32</td></tr><tr><td>Field</td><td>Channel &amp; Size Mask 1</td><td>Position 1</td></tr><tr><td>Size</td><td>U8</td><td>I8/I16/I32</td></tr><tr><td>Field</td><td>Channel &amp; Size Mask...</td><td>Position...</td></tr></table> <p>Any number of <i>Channel &amp; Size Mask</i> and <i>Position</i> pairs can be concatenated to set different position values for multiple channels.</p> <p><b>Channel &amp; Size Mask:</b> Select which channels to write <i>Position</i> value to and the format of the <i>Position</i> value. Multiple channels can be selected simultaneously.</p> <table><tr><td>Bit</td><td>7..6</td><td>5..4</td><td>3..0</td></tr><tr><td>Field</td><td>Unused</td><td>Position Size</td><td>Channel Mask</td></tr></table> <p><b>Channel Mask:</b> Bit mask selecting which channels <i>Position</i> will be applied to. Multiple channels can be selected by adding masks.</p> <table><tr><td>Bit</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>Field</td><td>Channel 4</td><td>Channel 3</td><td>Channel 2</td><td>Channel 1</td></tr></table> <p><b>Position Size:</b> Select the size of the <i>Position</i> value following. The whole 32-bit position value will be overwritten even if an 8-bit or 16-bit value is specified.</p> <table><tr><td>Position Size</td><td>Number of Bits</td></tr><tr><td>0x00</td><td><i>Position</i> omitted and assumed zero</td></tr><tr><td>0x01</td><td>8-bit signed integer</td></tr><tr><td>0x02</td><td>16-bit signed integer</td></tr><tr><td>0x03</td><td>32-bit signed integer</td></tr></table> <p><b>Position:</b> The <i>Position</i> value to be written. The size must match the size specified in <i>Position Size</i>. If <i>Position Size</i> = 0x00, <i>Position</i> must be omitted and is assumed <i>Position</i> = 0.</p>	Size	U8	I8/I16/I32	Field	Channel & Size Mask 1	Position 1	Size	U8	I8/I16/I32	Field	Channel & Size Mask...	Position...	Bit	7..6	5..4	3..0	Field	Unused	Position Size	Channel Mask	Bit	3	2	1	0	Field	Channel 4	Channel 3	Channel 2	Channel 1	Position Size	Number of Bits	0x00	<i>Position</i> omitted and assumed zero	0x01	8-bit signed integer	0x02	16-bit signed integer	0x03	32-bit signed integer
		Size	U8	I8/I16/I32																																						
		Field	Channel & Size Mask 1	Position 1																																						
		Size	U8	I8/I16/I32																																						
		Field	Channel & Size Mask...	Position...																																						
		Bit	7..6	5..4	3..0																																					
		Field	Unused	Position Size	Channel Mask																																					
		Bit	3	2	1	0																																				
	Field	Channel 4	Channel 3	Channel 2	Channel 1																																					
Position Size	Number of Bits																																									
0x00	<i>Position</i> omitted and assumed zero																																									
0x01	8-bit signed integer																																									
0x02	16-bit signed integer																																									
0x03	32-bit signed integer																																									
Reply	<table><tr><td>Size</td><td>U8</td></tr><tr><td>Field</td><td>Return Code</td></tr></table>	Size	U8	Field	Return Code																																					
Size	U8																																									
Field	Return Code																																									
11 - Get Position	Read absolute position value.																																									
	Send	Three different parameter formats are possible and will determine the contents and format of the reply. The format is identified by the size of the payload.																																								
		<p><b>Size 0:</b> An empty payload will request the position values in the sizes previously configured using <i>Position Size</i> in packet 6 - <i>Set Data Mask</i>, or omitted if the size was set to 0.</p> <table><tr><td>Size</td><td>Zero</td></tr><tr><td>Field</td><td>None</td></tr></table>	Size	Zero	Field	None																																				
Size	Zero																																									
Field	None																																									



	<div><div><div><div><div><div></div><div><b>Size 1:</b> A single byte will specify a channel mask. The position values of the channels selected in <i>Channel Mask</i> will be returned in the reply.</div></div></div><div><table><tr><td>Size</td><td>U8</td></tr><tr><td>Field</td><td>Channel Mask</td></tr></table></div></div></div><div><div><div><div><div><div></div><div><b>Size 4:</b> Four bytes will specify the size/format of the position value, for each channel, to return in the reply.</div></div></div><div><table><tr><td>Size</td><td>U8</td><td>U8</td></tr><tr><td>Field</td><td>Channel 1 Position Size</td><td>Channel 2 Position Size</td></tr><tr><td>Size</td><td>U8</td><td>U8</td></tr><tr><td>Field</td><td>Channel 3 Position Size</td><td>Channel 4 Position Size</td></tr></table></div></div></div><div><div><div><div><div><div></div><div><b>Channel Mask:</b></div></div></div><div><table><tr><td>Bit</td><td>7..4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>Field</td><td>Unused</td><td>Channel 4</td><td>Channel 3</td><td>Channel 2</td><td>Channel 1</td></tr></table></div></div></div><div><div><div><div><div><div></div><div><b>Channel Position Size:</b></div></div></div><div><table><tr><td>Position Size</td><td>Number of Bits</td></tr><tr><td>0x00</td><td>Position omitted</td></tr><tr><td>0x01</td><td>8-bit signed integer</td></tr><tr><td>0x02</td><td>16-bit signed integer</td></tr><tr><td>0x03</td><td>32-bit signed integer</td></tr></table></div></div></div></div><td><div><div><div><div><div></div><div><b>Reply</b></div></div></div><div><table><tr><td>Size</td><td>U8</td><td>I8/I16/I32</td><td>I8/I16/I32</td><td>I8/I16/I32</td><td>I8/I16/I32</td></tr><tr><td>Field</td><td>Return Code</td><td>[Position 1]</td><td>[Position 2]</td><td>[Position 3]</td><td>[Position 4]</td></tr></table></div><div>The presence and size/format of each <i>Position</i> value is determined by the specified parameters.</div></div></div></td></div></div></div>	Size	U8	Field	Channel Mask	Size	U8	U8	Field	Channel 1 Position Size	Channel 2 Position Size	Size	U8	U8	Field	Channel 3 Position Size	Channel 4 Position Size	Bit	7..4	3	2	1	0	Field	Unused	Channel 4	Channel 3	Channel 2	Channel 1	Position Size	Number of Bits	0x00	Position omitted	0x01	8-bit signed integer	0x02	16-bit signed integer	0x03	32-bit signed integer	<div><div><div><div><div></div><div><b>Reply</b></div></div></div><div><table><tr><td>Size</td><td>U8</td><td>I8/I16/I32</td><td>I8/I16/I32</td><td>I8/I16/I32</td><td>I8/I16/I32</td></tr><tr><td>Field</td><td>Return Code</td><td>[Position 1]</td><td>[Position 2]</td><td>[Position 3]</td><td>[Position 4]</td></tr></table></div><div>The presence and size/format of each <i>Position</i> value is determined by the specified parameters.</div></div></div>	Size	U8	I8/I16/I32	I8/I16/I32	I8/I16/I32	I8/I16/I32	Field	Return Code	[Position 1]	[Position 2]	[Position 3]	[Position 4]
Size	U8																																																			
Field	Channel Mask																																																			
Size	U8	U8																																																		
Field	Channel 1 Position Size	Channel 2 Position Size																																																		
Size	U8	U8																																																		
Field	Channel 3 Position Size	Channel 4 Position Size																																																		
Bit	7..4	3	2	1	0																																															
Field	Unused	Channel 4	Channel 3	Channel 2	Channel 1																																															
Position Size	Number of Bits																																																			
0x00	Position omitted																																																			
0x01	8-bit signed integer																																																			
0x02	16-bit signed integer																																																			
0x03	32-bit signed integer																																																			
Size	U8	I8/I16/I32	I8/I16/I32	I8/I16/I32	I8/I16/I32																																															
Field	Return Code	[Position 1]	[Position 2]	[Position 3]	[Position 4]																																															
12 - Set History Dimensions	<div><div><div><div><div></div><div><b>Set maximum history length and averaging time for velocity calculation purposes.</b></div></div></div><div><div><div><div><div></div><div><b>Send</b></div></div></div><div><div><div><div><div><div></div><div><table><tr><td>Size</td><td>U8</td><td>U8</td></tr><tr><td>Field</td><td>History Length</td><td>Maximum Averaging Time in Bits</td></tr></table></div></div></div><div><div><div><div><div><div></div><div><b>History Length:</b> The maximum number of quadrature capture events that will be averaged. A capture event occurs on every fourth quadrature transition, i.e. once per indent. Larger values will produce more accurate velocity averages, but will be slower to respond to changes in velocity. Range: 2-31 Default at start-up: 31</div></div></div><div><div><div><div><div><div></div><div><b>Maximum Averaging Time in Bits:</b> The maximum time over which quadrature capture events are averaged, specified in bits, where: Maximum Averaging Time = <math>2^{\text{Maximum Averaging Time in Bits}}</math> and Maximum Averaging Time in Seconds = <math>\text{Maximum Averaging Time} / 62,500</math></div></div></div><div><table><tr><td>Maximum Averaging Time in Bits</td><td>Maximum Averaging Time</td><td>Maximum Averaging Time in Milliseconds</td></tr><tr><td>10</td><td>1024</td><td>16.4</td></tr><tr><td>11</td><td>2048</td><td>32.8</td></tr><tr><td>12</td><td>4096</td><td>65.5</td></tr><tr><td>13</td><td>8192</td><td>131.1</td></tr><tr><td>14</td><td>16384</td><td>262.1</td></tr><tr><td>15</td><td>32768</td><td>524.3</td></tr><tr><td>16</td><td>65536</td><td>1,048.6</td></tr></table></div><div>At lower velocities, the total duration of <i>History Length</i> quadrature capture events increases and thus the lower the minimum detectable speed will be, but the slower</div></div></div></div></div></div></div></div></div></div></div></div></div></div>	Size	U8	U8	Field	History Length	Maximum Averaging Time in Bits	Maximum Averaging Time in Bits	Maximum Averaging Time	Maximum Averaging Time in Milliseconds	10	1024	16.4	11	2048	32.8	12	4096	65.5	13	8192	131.1	14	16384	262.1	15	32768	524.3	16	65536	1,048.6																					
Size	U8	U8																																																		
Field	History Length	Maximum Averaging Time in Bits																																																		
Maximum Averaging Time in Bits	Maximum Averaging Time	Maximum Averaging Time in Milliseconds																																																		
10	1024	16.4																																																		
11	2048	32.8																																																		
12	4096	65.5																																																		
13	8192	131.1																																																		
14	16384	262.1																																																		
15	32768	524.3																																																		
16	65536	1,048.6																																																		

		average velocity will wind down when motion is significantly slowed down or stopped, since there will be physically less transitions to detect. Larger values will allow lower velocities to be detected. Range: 10-16 Default at start-up: 16  At very low velocities, when <i>History Length</i> quadrature capture events exceeds <i>Maximum Averaging Time</i> , less than <i>History Length</i> capture events will be used for averaging, but allowing for faster responses and longer total averaging times instead.				
	Reply	Size	U8			
		Field	Return Code			
13 - Get History Dimensions	Read maximum history length and averaging time for velocity calculation purposes.					
	Send	None				
	Reply	Size	U8	U8	U8	
		Field	Return Code	History Length	Maximum Averaging Time in Bits	
14 – Set Input Mode	Set the function of quadrature input pins as home / index / disabled.					
	Send	Size	U8	U8	I8/I16/I32	
Field		Channel & Size Mask 1	Input Configuration 1	Position 1		
		Size	U8	U8	I8/I16/I32	
		Field	Channel & Size Mask...	Input Configuration...	Position...	
		Any number of <i>Channel &amp; Size Mask</i> , <i>Input Configuration</i> and <i>Position</i> pairs can be concatenated to set different input modes for multiple channels.				
		<b>Channel &amp; Size Mask:</b> Select for which channels to configure input pints and the format of the <i>Position</i> value. Multiple channels can be selected simultaneously.				
		Bit	7..6	5..4	3..0	
		Field	Unused	Position Size	Channel Mask	
		<b>Channel Mask:</b> Bit mask selecting for which channels <i>Input Mode</i> and <i>Position</i> will be applied to. Multiple channels can be selected by adding masks.				
		Bit	3	2	1	0
		Field	Channel 4	Channel 3	Channel 2	Channel 1
		<b>Position Size:</b> Select the size of the <i>Position</i> value following. Selecting Zero will result in a <i>Position</i> of zero being assumed without having to provide a <i>Position</i> value.				
		Position Size	Number of Bits			
		0x00	Position omitted and assumed zero			
		0x01	8-bit signed integer			
		0x02	16-bit signed integer			
		0x03	32-bit signed integer			
		<b>Input Configuration:</b>				
		Bit	7..4	3	2	1..0
		Field	Unused	Input Polarity	Unused	Input Mode
		<b>Input Polarity:</b> Select whether the input pin will be active when low or high.				
		Input Polarity	Meaning			
		0x00	Input is active when low			
		0x01	Input is active when high			

		<b>Input Mode:</b>		
		Input Mode	Meaning	Description
		0x00	Disabled	Signal on input has no effect.
		0x01	Home mode	While input is active (see <i>Input Polarity</i> ), <i>Position</i> will be written into relevant channel position value. This is typically used on linear actuators where a button or infrared sensor acts as input to indicate that the end stop has been reached.
		0x02	Index mode	While input is active (see <i>Input Polarity</i> ) and quadrature input A = B = 0, <i>Position</i> will be written into relevant channel position value. This is typically used with an index signal output from a quadrature encoder.
	<p><b>Position:</b> The <i>Position</i> value to be written. The size must match the size specified in <i>Position Size</i>. If <i>Position Size</i> = 0x00, <i>Position</i> must be omitted and it is assumed <i>Position</i> = 0. Similarly, if <i>Input Mode</i> is set to <i>Disabled</i>, <i>Position</i> must be omitted.</p>			
	Reply	Size	U8	
		Field	Return Code	

## Worked Examples

### Read Version Numbers

Refer to sections *Physical Connections* and *SPI Interface* and packet 1 - *Get Version* for more detail.

To query the version numbers from the QuadQuad device, send the following packet (in decimal bytes):

Meaning	STX	Packet Size	Packet ID	Checksum
Value	2	4	1	249

You should receive the following reply (in decimal bytes):

Meaning	STX	Packet Size	Packet ID	Return Code	Firmware Version Major	Firmware Version Minor	Protocol Version	Checksum
Value	2	8	1	0	0	1	0	244