

# OptoHybrid Modules & Functionalities

---

Thomas Lenzi ([thomas.lenzi@cern.ch](mailto:thomas.lenzi@cern.ch))

This document describes how to interact with the OptoHybrid (OH) modules and how to parameterize and use the various functionalities integrated in the firmware.

## Contents

---

Contents.....	1
VFAT2 I2C.....	3
Addressing.....	3
Errors.....	3
Errors to avoid.....	3
VFAT2 I2C Extended.....	4
Addressing.....	4
Errors.....	4
Errors to avoid.....	4
Threshold, Latency, and S-Curve Scans.....	5
Addressing.....	5
Description.....	6
Errors.....	6
Errors to avoid.....	6
Note .....	6
Ultra Scan Module .....	7
Addressing.....	7
Description.....	8
Errors.....	8
Errors to avoid.....	8
Note .....	8
T1 Controller .....	9
Addressing.....	9
Errors.....	9

Operation modes .....	9
Mode 0 .....	9
Mode 1 .....	10
Mode 2 .....	10
Notes.....	10
Errors to avoid.....	10
DAC Scans (in development) .....	11
Addressing.....	11
Description .....	11
Errors.....	12
Errors to avoid.....	12
ADC.....	13
Addressing.....	13
Errors.....	13
Errors to avoid.....	13
Counters.....	14
Addressing.....	14
System Registers .....	16
Addressing.....	16
Status Registers.....	17
Addressing.....	17

# VFAT2 I2C

---

This module handles I2C transactions with a single VFAT2 hybrid.

## Addressing

Module ID      0  
Address        0x4000XXYY  
                 0b 0100 0000 0000 0000 000X XXXX YYYY YYYYY

Y register	Mode	Function
VFAT2 registers		
0 - 150	Read / write	Read or write the register on VFAT2 n°X (5 bit chip identifier) 5 MSBits are constant 0s 1 next bit is set when an error occurred 1 next bit is set when the transaction is valid 1 next bit is the read/not write bit of the transaction 8 next bits hold the id of the addressed VFAT2 8 next bits hold the id of the addressed register 8 LSBits hold the response from the VFAT2

## Errors

The module returns an error if the parameters are not in spec or if the VFAT2 is not accessible.

## Errors to avoid

- The VFAT2 number must be in the range 0 to 23.
- The register ID must be in the range 0 to 150.

# VFAT2 I2C Extended

This module broadcasts I2C requests to all the VFAT2s that are not masked by the *mask* register.

## Addressing

Module ID      1  
Address        0x41000YYY  
                 0b 0100 0001 0000 0000 0000 000Y YYYYY YYYYY

Y register	Mode	Function
VFAT2 registers		
0 - 150	Read / write	Read or write the register on all VFAT2s not masked by the <i>mask</i> register
Parameters		
256	Read / write	<i>mask</i> - 24 bits Asserting a bit in this register will remove the corresponding VFAT2 from the broadcast list
Results		
257	Read only	FIFO holding the results of a request. This register will return the response of each individual request made to the VFAT2s: 8 MSBits are constant 0s 8 next bits hold the status of the transaction 8 next bits are the VFAT2 id (0 to 23) 8 LSBits hold response from the VFAT2 If no data is present, an error is returned. If the module is still running, the FIFO will return 0xFFFFFFFF when read. The data will be available once the module is done.
Reset		
258	Write only	Local reset of the module
Misc		
259	Read only	<i>running</i> - 1 bit Asserted when the module is still running

## Errors

The module returns an error if the parameters are not in spec. The errors related to individual VFAT2s are stored in the FIFO.

## Errors to avoid

- The register ID must be in the range 0 to 150 or 256 to 258.
- If the FIFO is read too soon after the start of the request, the operations will not yet be finished. The FIFO will return 0xFFFFFFFF informing the user it is waiting.

# Threshold, Latency, and S-Curve Scans

This module performs a threshold, threshold by channel, latency, or s-curve scan on (channel *channel* of) VFAT2 *vfat2* by varying its threshold/latency/calibration pulse from a minimum value *min* to a maximum value *max* by steps of *step* and by counting the number of events where the SBits/strips are fired in a set of *N* events.

## Addressing

Module ID      2  
 Address        0x4200000Y  
                  0b 0100 0010 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>Control</b>		
<b>0</b>	Write only	Start the scan. This will also empty the FIFO holding the data of the previous scan.
<b>Parameters</b>		
<b>1</b>	Read / write	<i>mode</i> - 3 bits    - [0, 4] 0 = threshold scan using trigger data 1 = threshold scan by channel 2 = latency scan 3 = s-curve 4 = threshold scan full chip using tracking data
<b>2</b>	Read / write	<i>VFAT2</i> - 5 bits    - [0, 23]
<b>3</b>	Read / write	<i>channel</i> - 8 bits    - [0x0, 0xFF] Only used for a threshold scan by channel
<b>4</b>	Read / write	<i>min</i> - 8 bits    - [0x0, <i>max</i> ]
<b>5</b>	Read / write	<i>max</i> - 8 bits    - [ <i>min</i> , 0xFF] Default: 0 = 0xFF
<b>6</b>	Read / write	<i>step</i> - 8 bits    - [0x0, 0xFF] Default: 0 = 0x1
<b>7</b>	Read / write	<i>N</i> - 24 bits   - ]0x0, 0xFFFFFFFF] Default: 0 = 0xFFFFFFFF
<b>Results</b>		
<b>8</b>	Read only	FIFO holding the results of the scan. This register will return the data points collected by the scan using the following data format: 8 MSBits hold the threshold/latency value of the point 24 LSBits hold the number of events that have fired If no data is present, an error is returned.
<b>Monitoring</b>		
<b>9</b>	Read only	<i>Status</i> - 3 bits    - [0, 4] 0-3: 0 = nothing running 1 = threshold scan running 2 = threshold scan by channel running 3 = latency scan running 4 = s-curve scan running 5 = threshold scan using tracking data 4: Error bit (scan did not start due to error) 5: Ready bit (data is ready for readout)
<b>Reset</b>		

### Description

The module will store the value of the register before the scan and reapply the later after the end of the operation.

### Errors

When starting the scan, the returned status of the write operation informs the user about the validity of the parameters. Invalid parameters will return an error and prevent the scan from starting. Other errors related to the VFAT2s are stored in the FIFO.

Two types of errors are stored in the FIFO when running the scan: global errors and local errors.

A global error occurs if the VFAT2 is not present or running at the start of the scan. In that case, a single 32 bits word is stored in the FIFO. No other read operations of the FIFO should occur afterwards:

- 0xF0000000 means that the VFAT2 is not running ;
- 0xFF000000 means that the current value of the register could not be saved.

A local error occurs if one of the I2C operations used to change the value did not succeed. In that case, the value of the 24 LSBits of that particular point is 0xFFFFF. Other data points will still be saved and be present in the FIFO.

### Errors to avoid

- The VFAT2 number must be in the range 0 to 23.
- The maximum value of the register to scan must be higher than the minimum value.
- The register ID must be in the range 0 to 10.

### Note

When performing a threshold scan by channel or an s-curve scan, the user should provide a source of triggers in order to generate tracking data.

# Ultra Scan Module

This module performs a threshold, threshold by channel, latency, or s-curve scan on (channel *channel* of) all VFAT2s NOT masked by *mask* by varying its threshold/latency/calibration pulse from a minimum value *min* to a maximum value *max* by steps of *step* and by counting the number of events where the SBits/strips are fired in a set of *N* events.

## Addressing

Module ID      2  
 Address        0x4D00000Y  
                  0b 0100 1101 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>Control</b>		
<b>0</b>	Write only	Start the scan. This will also empty the FIFO holding the data of the previous scan.
<b>Parameters</b>		
<b>1</b>	Read / write	<i>mode</i> - 3 bits   - [0, 4] 0 = threshold scan using trigger data 1 = threshold scan by channel 2 = latency scan 3 = s-curve 4 = threshold scan full chip using tracking data
<b>2</b>	Read / write	<i>MASK</i> - 23 bits   - [0, 23] Disable individual VFAT2s to not participate in the scan
<b>3</b>	Read / write	<i>channel</i> - 8 bits   - [0x0, 0xFF] Only used for a threshold scan by channel
<b>4</b>	Read / write	<i>min</i> - 8 bits   - [0x0, <i>max</i> ]
<b>5</b>	Read / write	<i>max</i> - 8 bits   - [ <i>min</i> , 0xFF] Default: 0 = 0xFF
<b>6</b>	Read / write	<i>step</i> - 8 bits   - [0x0, 0xFF] Default: 0 = 0x1
<b>7</b>	Read / write	<i>N</i> - 24 bits   - [0x0, 0xFFFFFFFF] Default: 0 = 0xFFFFFFFF
<b>Results</b>		
<b>8 - 31</b>	Read only	FIFOs holding the results of the scan for each VFAT2. This register will return the data points collected by the scan using the following data format: 8 MSBits hold the threshold/latency value of the point 24 LSBits hold the number of events that have fired If no data is present, an error is returned.
<b>Monitoring</b>		
<b>32</b>	Read only	<i>Status</i> - 3 bits   - [0, 4] 0-3: 0 = nothing running 1 = threshold scan running 2 = threshold scan by channel running 3 = latency scan running 4 = s-curve scan running 5 = threshold scan using tracking data 4: Error bit (scan did not start due to error)

5: Ready bit (data is ready for readout) 8-31: Mask (mask with the data that is valid)		
Reset		
33	Write only	Local reset of the module

## Description

The module will store the value of the register before the scan and reapply the later after the end of the operation.

## Errors

When starting the scan, the returned status of the write operation informs the user about the validity of the parameters. Invalid parameters will return an error and prevent the scan from starting. Other errors related to the VFAT2s are stored in the FIFO.

Two types of errors are stored in the FIFO when running the scan: global errors and local errors.

A global error occurs if the VFAT2 is not present or running at the start of the scan. In that case, a single 32 bits word is stored in the FIFO. No other read operations of the FIFO should occur afterwards:

- 0xF0000000 means that the VFAT2 is not running ;
- 0xFF000000 means that the current value of the register could not be saved.

A local error occurs if one of the I2C operations used to change the value did not succeed. In that case, the value of the 24 LSBits of that particular point is 0xFFFFF. Other data points will still be saved and be present in the FIFO.

## Errors to avoid

- The VFAT2 number must be in the range 0 to 23.
- The maximum value of the register to scan must be higher than the minimum value.
- The register ID must be in the range 0 to 10.

## Note

When performing a threshold scan by channel or an s-curve scan, the user should provide a source of triggers in order to generate tracking data.



# T1 Controller

This module sends T1 commands to the VFAT2s according to different operation modes defined by *mode*.

## Addressing

Module ID      3  
Address        0x4300000Y  
                 0b 0100 0011 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>Control</b>		
0	Write only	Toggle the module on and off.
1	Read / write	<i>mode</i> - 2 bits - [0, 2]
<b>Mode 0 &amp; 1 parameters</b>		
2	Read / write	<i>type</i> - 2 bits - [0, 3] 0 = LV1A 1 = Calpulse 2 = Resync 3 = BC0
3	Read / write	<i>N</i> - 32 bits - [0, 0xFFFFFFFF] Default: 0 = infinite
4	Read / write	<i>interval</i> - 32 bits - [3, 0xFFFFFFFF]
5	Read / write	<i>delay</i> - 32 bits - [3, interval - 3]
<b>Mode 2 parameters</b>		
7 & 6	Read / write	<i>lv1a_sequence</i> - 64 bits
9 & 8	Read / write	<i>calpulse_sequence</i> - 64 bits
11 & 10	Read / write	<i>resync_sequence</i> - 64 bits
13 & 12	Read / write	<i>bc0_sequence</i> - 64 bits
<b>Monitoring</b>		
14	Read only	<i>Status</i> - 2 bits - [0, 3] 0 = nothing running 1 = MODE 0 running 2 = MODE 1 running 3 = MODE 2 running
<b>Reset</b>		
15	Write only	Local reset of the module

## Errors

When starting the module, the returned status of the write operation informs the user about the validity of the parameters. Invalid parameters will return an error and prevent the module from starting.

## Operation modes

### Mode 0

Send *N* T1 commands of type *type* with an interval of *interval* BXs. Note that *interval* cannot be smaller than 3 BXs which is the time needed to encode a T1 command on the wire. Example with an *interval* of 4 BXs:



## DAC Scans (to do)

This module performs a scan of a DAC register *dac* on a single VFAT2 *vfat2* by varying its value from a minimum value *min* to a maximum value *max* by steps of *step* and by averaging the value on  $2^N$  readouts.

### Addressing

Module ID      4  
 Address        0x4400000Y  
                  0b 0100 0100 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>Control</b>		
<b>0</b>	Write only	Start the scan. This will also empty the FIFO holding the data of the previous scan. The written value is ignored.
<b>Parameters</b>		
<b>1</b>	Read / write	<i>dac</i> - 4 bits - [0, 9] 0 = IPreampIn 1 = IPreampFeed 2 = IPreampOut 3 = IShaper 4 = IShaperFeed 5 = IComp 6 = VThreshold1 7 = VThreshold2 8 = VCal 9 = CalOut
<b>2</b>	Read / write	<i>VFAT2</i> - 5 bits - [0, 23]
<b>3</b>	Read / write	<i>min</i> - 8 bits - [0x0, <i>max</i> ]
<b>4</b>	Read / write	<i>max</i> - 8 bits - [ <i>min</i> , 0xFF] Note: 0 = 0xFF
<b>5</b>	Read / write	<i>step</i> - 8 bits - [0x0, 0xFF] Note: 0 = 0x1
<b>6</b>	Read / write	<i>N</i> - 4 bits - [0, 15] Events = $2^N$
<b>Results</b>		
<b>7</b>	Read only	FIFO holding the results of the scan. This register will return the data points collected by the scan using the following data format: 8 MSBits hold the DAC value of the point 24 LSBits hold the mean of the ADC values If no data is present, an error is returned.
<b>Monitoring</b>		
<b>8</b>	Read only	<i>Status</i> - 1 bits - {0, 1} 0 = nothing running 1 = DAC scan running
<b>Reset</b>		
<b>9</b>	Write only	Local reset of the module

### Description

The module will store the value of the register before the scan and reapply the later after the end of the operation. It will also set the “Control Register 1” of all the VFAT2s to 0 in order to avoid conflicting scans.

## **Errors**

When starting the scan, the returned status of the write operation informs the user about the validity of the parameters. Invalid parameters will return an error and prevent the scan from starting. Other errors related to the VFAT2s are stored in the FIFO.

Two types of errors are stored in the FIFO when running the scan: global errors and local errors.

A global error occurs if the VFAT2 is not present or running at the start of the scan. In that case, a single 32 bits word of value 0xFF000000 is stored in the FIFO. No other read operations of the FIFO should occur afterwards.

A local error occurs if one of the I2C operations used to change the value did not succeed. In that case, the value of the 24 LSBits of that particular point is 0xFFFFF. Other data points will still be saved and be present in the FIFO.

## **Errors to avoid**

- The DAC number must be in the range 0 to 9.
- The VFAT2 number must be in the range 0 to 23.
- The maximum value of the register to scan must be higher than the minimum value.
- The register ID must be in the range 0 to 9.

# ADC

This module is directly connected to the xADC of the Virtex-6 FPGA. Refer to the following user guide for a full list of register: [http://www.xilinx.com/support/documentation/user\\_guides/ug370.pdf](http://www.xilinx.com/support/documentation/user_guides/ug370.pdf)

## Addressing

Module ID      8  
Address        0x4800000Y  
                 0b 0100 1000 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
ADC registers		
0 - 79	Read only	Returns the conversion value of a given channel 0 = Temperature 1 = VCCINT 2 = VCCAUX 3 = VP/VN 16-31 = VAUX[0:15] 32 = Temperature max 33 = VCCINT max 34 = VCCAUX max 36 = Temperature min 37 = VCCINT min 38 = VCCAUX max 64-66 = Control registers[0:2] 67-71 = Test registers[0:4] 72-79 = Sequencer registers[0:7]

## Errors

The module returns an error if the parameters are not in spec.

## Errors to avoid

- The register ID must be in the range 0 to 79.

# Counters

This module holds all the counters of the OptoHybrid. Writing to a given register will reset its value.

## Addressing

Module ID      10  
 Address        0x4A0000YY  
                  0b 0100 1010 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>Wishbone</b>		
<b>0 - 3</b>	Read	<i>Wishbone masters strobes</i> Order: GTX, Extended I2C, Scan, DAC
<b>4 - 7</b>	Read	<i>Wishbone masters acknowledgments</i>
<b>8 - 21</b>	Read	<i>Wishbone slaves strobe</i> Order: I2C 0, I2C 1, I2C 2, I2C 3, I2C 4, I2C 5, Extended I2C, Scan, T1, DAC, ADC, Clocking, Counters, System
<b>22 - 35</b>	Read	<i>Wishbone slaves acknowledgments</i>
<b>VFAT2</b>		
<b>36 - 59</b>	Read	<i>VFAT2 tracking data valid CRC</i> For each VFAT2 counts the number of data packets that come with a valid CRC
<b>60 - 83</b>	Read	<i>VFAT2 tracking data incorrect CRC</i> For each VFAT2 counts the number of data packets that come with an incorrect CRC
<b>T1 commands</b>		
<b>84 - 87</b>	Read	<i>T1 from AMC13 over GTX</i> Order: LV1A, Calpulse, Resync, BC0
<b>88 - 91</b>	Read	<i>T1 from firmware</i>
<b>92 - 95</b>	Read	<i>T1 from external source</i>
<b>96 - 99</b>	Read	<i>T1 from loopback</i>
<b>100 - 103</b>	Read	<i>T1 sent to the VFAT2</i>
<b>GTX</b>		
<b>104</b>	Read	<i>GTX tracking link error</i>
<b>105</b>	Read	<i>GTX trigger link error</i>
<b>106</b>	Read	<i>Data packets sent over GTX</i>
<b>PLLs</b>		
<b>107</b>	Read	<i>QPLL lock counter</i>
<b>108</b>	Read	<i>QPLL PLL lock counter</i>
<b>GBT</b>		
<b>109</b>	Read	<i>Wishbone master GBT strobes</i>
<b>110</b>	Read	<i>Wishbone master GBT acknowledgments</i>
<b>111 - 114</b>	Read	<i>T1 from AMC13 over GTX</i> Order: LV1A, Calpulse, Resync, BC0
<b>115</b>	Read	<i>GBT link errors</i>
<b>116</b>	Read	<i>Data packets sent over GBT</i>
<b>Rates</b>		
<b>117</b>	Read	<i>Timer</i>
<b>118 - 141</b>	Read	<i>VFAT2 trigger data hits counter</i>

<b>142-165</b>	Read	<i>VFAT2 tracking data hits counter</i>
----------------	------	---

# System Registers

List of system registers

## Addressing

Module ID      11  
 Address        0x4B0000YY  
                  0b 0100 1011 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
<b>VFAT2</b>		
<b>0</b>	Read / write	<i>VFAT2 tracking data mask</i> - 24 bits Allows to mask individual VFAT2s for tracking data readout over the optical link
<b>1</b>	Read / write	<i>VFAT2 T1 source select</i> - 3 bits 0 : T1 from AMC13 over GTX 1 : T1 from OptoHybrid 2 : T1 from external source 3 : Internal loopback on SBits 4 : Logical OR of all sources 5 : T1 from AMC13 over GBT
<b>2</b>	Read / write	<i>T1 loopback SBit select</i> - 5 bits
<b>3</b>	Write only	<i>VFAT2 reset</i> - 1 bit This register automatically returns to a 0 state
<b>4</b>	Read / write	<i>VFAT2 SBits data mask</i> - 24 bits Allows to mask individual VFAT2s for SBits data readout
<b>Misc</b>		
<b>5</b>	Read / write	<i>TDC SBits selects</i> - 30 bits
<b>6</b>	Read / write	<i>Trigger throttling</i> - 32 bits
<b>7</b>	Read / write	<i>Zero suppression</i> - 1 bit
<b>8</b>	Read / write	<i>TDC SBits mode</i> - 2 bits 0 : single VFAT2 1 : Eta row (OR of 3 VFAT2s) 2 : Sector (OR of 4 VFAT2s) 3 : no output
<b>9</b>	Read / write	<i>Clock source</i> - 1 bit Not used
<b>10</b>	Read / write	<i>VFAT2 remove data with bad CRC</i> - 1 bit 0 : keep all the data 1 : ignore data with a bad CRC



# Status Registers

---

List of status registers

## Addressing

Module ID      12  
Address        0x4C0000YY  
                 0b 0100 1011 0000 0000 0000 0000 0000 YYYY

Y register	Mode	Function
Global		
0	Read only	OH firmware version
Clocking		
1	Read only	QPLL locked            - 1 bit
2	Read only	QPLL PLL locked       - 1 bit
Misc		
3	Read only	Firmware version - 32 bits Major      8 bits    = 2 Minor      8 bits Version    8 bits Patch      8 bits    = A for GEB v2a compatible = B for GEB v2b compatible