










File: user_io.sch


File: midi_dac.sch




Sheet: /user_io/		
File: user_io.sch		
Title: User IO Subsystem Schematic		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad 5.1.9		Id: 2/3




Debug Connections




USB Crystal Oscillator Circuit




USB Current Limiter




Output Connectors




Decoupling Capacitors



PCM5102 I2S Converter - Analog Output



Pull Up/Reset/Boot



No idea, but these are set in our project.
Need to look into why these are configured.

Sheet: /midi_dac/
File: midi_dac.sch

Title: USB and DAC subsystem

Size: A4 Date:
KICad E.D.A. kicad 5.1.9

Rev:
Id: 3/3