

# Admin Tools

# Admin Tools Menu – Require Admin Privilege

- **Admin Console**
  - Allows the administrator to configure CSM Server.
- **Import Hosts**
  - Imports hosts via comma-delimited texts.
- **Create User**
  - Creates new users on the system.
- **List/Edit/Delete Users**
  - Displays all the users defined in the system. To make changes, click the user name of interest.
- **System Logs**
  - Displays all the system logs captured by CSM Server. These logs help determine anomalies that have occurred on CSM Server.

# Admin Console

# Admin Console - General

**Process Settings**

CSM Server must be restarted in order for the changes below to take place.

---

Number of Software Inventory Processes	<input type="text" value="5"/>
Number of Install Processes	<input type="text" value="10"/>
Number of SMU Download Processes	<input type="text" value="5"/>

**Software Inventory Settings**

CSM Server must be restarted in order for the changes below to take place.

---

Enable Software Inventory	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Hour to Perform Software Inventory	<input type="text" value="12:00 AM"/>

- **Process Settings**

- The number of processes to use to retrieve software inventory information.
- The number of processes to use to perform scheduled installation.
- The number of processes to use to download SMUs or Service Packs.

- **Software Inventory Settings**

- Enabled by default.
- Specify the hour of the day to perform the software inventory function (i.e. retrieving software package information from managed hosts).
- After the software inventory function is performed, CSM Server will perform other housekeeping tasks (see Housekeeping Settings).

# Admin Console - General

### Software Installation Settings

**Allow Users to Schedule Installations** ☒ Yes ☐ No

**Allow Scheduled Installations to Run** ☒ Yes ☐ No

### Housekeeping Settings

Once the defined threshold is reached, old information will be purged.

<b>Retrieval History Per Host</b>	<input type="text" value="10"/>
<b>Installation History Per Host</b>	<input type="text" value="500"/>
<b>Software Download History Per User</b>	<input type="text" value="100"/>
<b>Total System Logs</b>	<input type="text" value="1000"/>

- **Software Installation Settings**
  - By default, CSM Server enables users to schedule installations on managed hosts.
  - By Default, CSM Server enables scheduled installations to run.
- **Housekeeping Settings**
  - Specify the number of software inventory history records to keep per host.
  - Specify the number of install history records to keep per host.
  - Specify the number of SMU/SP download history records to keep per user.
  - Specify the number of system log records to keep on the system.
  - CSM Server will purge the history records based on the numbers specified on a daily basis (see Software Inventory Settings).

# Admin Console – LDAP Authentication

## LDAP Authentication

If enabled, the designated LDAP Server will be used for CSM Server user login authentication. An example of an LDAP Server URL is `ldaps://ds.cisco.com:636`.

---

Enable LDAP

Yes

No

LDAP Server URL

`ldaps://ds.cisco.com:636`

Grant User Privilege

Viewer

---

To restrict access to certain user group, define the Active Directory Distinguished Names below. An example may be

`CN={},OU=Employees,OU=Cisco Users,DC=cisco,DC=com`

'{}' is a placeholder string and will be replaced with the user login name.

Distinguished Names

`CN={},OU=Employees,OU=Cisco Users`

- The LDAP user interface is only available if python-ldap is installed. Refer to the install guide on how to install python-ldap and required libraries.
- By default, LDAP authentication is disabled. The LDAP Server URL can either be a non-secure or secure URL (i.e., `ldap://` or `ldaps://`).
- If a user does not already exist in the CSM Server database, a new user will be created and assigned an access privilege defined by the Grant User Privilege selector when the user is first authenticated with an LDAP server.
- To restrict access from certain LDAP user groups to CSM Server, specify them in the Distinguished Names box.


# Admin Console – Host Authentication

## Host Authentication

If enabled, the default host username and password will be used for device authentication.

**Use Default Host Authentication** ☒ Yes ☐ No

**Default Host Username**

**Default Host Password**  

Apply the Default Host Authentication to:

- ☒ All Hosts
- ☐ Hosts with no Specified Username and Password

---

If enabled, CSM Server User Credential will be used for device authentication during software installation. This will not affect the daily software inventory retrieval as it will still use the host's username and password (or if the Default Host Authentication is enabled, the default host username and password will be used).

**Use CSM Server User Credential** ☐ Yes ☒ No

- **Default Host Authentication**
  - If enabled, the default host username and password defined will be used either for all hosts or for hosts with no specified username and password, as selected with the radio buttons.
- **Use CSM Server User Credential**
  - If enabled, the CSM Server User Credential will be used for device authentication during software installation. This will not affect the daily software inventory retrieval as it will still use the host's username and password (or if the Default Host Authentication is enabled, the default host username and password will be used).

# Admin Console - CCO

## CCO Connection

If CCO connection is disabled

- The ability to view DDTS information will be disabled.
- The ability to download software will be disabled.
- A request to retrieve software information will cause CSM Server to retrieve previously saved software information from the database instead of from CCO. To refresh the database with up-to-date information, click the Retrieve Software information button.

**Enable CCO Connection**

Yes

No

Retrieve Software Information

- When Enable CCO Connection is set to 'Yes', CSM Server will contact CCO for all software information inquiries.
- Click Retrieve Software Information to manually trigger retrieval of all software information from CCO for all supported platforms and releases. This information will be stored in the database.



# Admin Console - Time Zone

## Time Zone Setting (UTC vs Local Time Zone)

By default, local time zone is used on CSM Server UI. If Coordinated Universal Time (UTC) is selected, all time information will be displayed in UTC time zone.

**Use UTC Time Zone**

Yes

No

- By default, CSM Server uses the web browser's local time zone when displaying or prompting for date time information.
- For managing devices across multiple time zones, it may make sense to configure CSM Server to use UTC time zone.

# Admin Console - Notifications

## Email Notification Settings

Enable Email Notification

Yes

No

Outgoing SMTP Server

smtp.gmail.com

SMTP Server Port

587

Sender Email Address

alex\_gmail@gmail.com

## Logon Information

Server uses Authentication

Yes


No

Username

alex\_gmail


Password

Use Password on File



Secure Connection

TLS



- Email notification is disabled by default. Click Yes to enable it.
- Define the SMTP server information. Some SMTP servers may require user authentication. If that is the case, click Yes and define the user authentication information.
- CSM Server uses the SMTP settings to email users about scheduled install status.

# Import Hosts

# Import Hosts

Import Hosts

GENERAL

IMPORT DATA

If the import data does not contain a region, the region selected below will be used.  
The jump host and software profile are optional.

Region

California USA

Jump Host

Software Profile

Next

- **General**

- Select a default region. If the import data does not contain region information, the selected region will be used as the default.
- Select the Jump Host and Software Profile, if applicable.

# Import Hosts

Import Hosts

GENERAL

IMPORT DATA

Click Import Instructions for more information.

Import Instructions ▾

```
hostname,region,location,roles,ip,username,password,connection,port,enable_password <- header
myhost1,California USA,blg 20,,172.27.22.34,johnsmith,john123,telnet,, <- blank for empty fields
myhost2,California USA,blg 20,PE,172.27.22.35,davidsmith,david123,ssh,"2033,2034",
```

```
hostname,region,location,roles,ip,username,password,connection,port,enable_password
myhost1,California USA,blg 20,,172.27.22.34,johnsmith,john123,telnet,,
myhost2,California USA,blg 20,PE,172.27.22.35,davidsmith,david123,ssh,"2033,2034",
```

Previous

Use IP Range

Finish

## ■ Import Data

- Click the Import Instructions button at the top for detailed instructions for filling out the import data text window.
- Type or paste the import data into the text window. Then, click Finish to import the data.
- Use the 'Use IP Range' button to auto-generate import data based on IP ranges.

# Create Users


# Create Users

## Create User


**Username**

johnsmith

**Password**

.....

**Privilege**

Network Admin

**Active**

Yes

No

## Information

**Full Name**

John Smith

**Email Address**

johnsmith@mycompany.com

Save

Cancel

- Specify the username and password.
- Specify the user privilege.
  - Admin
  - Network Admin
  - Operator
  - Viewer
- Specify whether the user is active or not. Active users will be able to log into CSM Server.

# Security Privileges

## Four levels of security privileges:

- **Admin**
  - Users with this privilege have no limitations.
- **Network Admin**
  - Can create hosts, jump servers, regions, and server repositories.
  - Can schedule/modify/delete installations.
  - Cannot access the Admin-related functions.
- **Operator**
  - Cannot create hosts, jump servers, regions, or server repositories.
  - Can schedule/modify/delete installations.
- **Viewer**
  - Can only view information.



# List/Edit/Delete Users

# List/Edit/Delete Users

**Users**

10 records per page

Search:

Username	Privilege	Full Name	Email Address	Active	Created Date	Modified Date	Action
lab	Viewer	lab	lab	True	08/31/2016 02:12 PM	10/05/2016 02:18 PM	<a href="#">Delete</a>
root	Admin	admin	root@gmail.com	True	10/21/2015 03:53 AM	10/25/2016 11:20 AM	<a href="#">Delete</a>
viewer	Viewer	viewer	viewer	True	10/21/2016 09:16 AM	10/21/2016 09:16 AM	<a href="#">Delete</a>


Showing 1 to 3 of 3 entries

← Previous 1 Next →

- To edit a user, click the username of interest. An Edit User dialog will be displayed.
- The Edit User dialog can be used to change the user privilege level, disable the user login privilege, and edit other information.
- To delete a user, click the Delete link for that user.







# System Logs

# System Logs

System Logs 

10 records per page

Search:

No.	Severity	Message	Created Time	Trace
241	ERROR	Server error!	08/25/2015 08:41 PM	
242	ERROR	Server error!	08/25/2015 08:41 PM	
243	ERROR	bsd_service hit exception pid provided in the request is invalid. Please invoke the service with the valid pid.	08/25/2015 05:36 PM	
244	ERROR	DownloadManager hit exception - download job = 110	08/25/2015 05:36 PM	
245	ERROR	bsd_service hit exception pid provided in the request is invalid. Please invoke the service with the valid pid.	08/25/2015 05:35 PM	
246	ERROR	DownloadManager hit exception - download job = 109	08/25/2015 05:35 PM	
247	ERROR	bsd_service hit exception pid provided in the request is invalid. Please invoke the service with the valid pid.	08/25/2015 05:33 PM	
248	ERROR	DownloadManager hit exception - download job = 109	08/25/2015 05:33 PM	
249	ERROR	bsd_service hit exception pid provided in the request is invalid. Please invoke the service with the valid pid.	08/25/2015 05:30 PM	
250	ERROR	DownloadManager hit exception - download job = 109	08/25/2015 05:30 PM	

Showing 241 to 250 of 2,163 entries

[< Previous](#) [23](#) [24](#) [25](#) [26](#) [27](#) [Next >](#)

- These logs are created when exceptions are encountered by CSM Server. They can be used for system debugging. These exceptions may or may not affect system stability and performance.
- Click the icon next to the page title to download the system logs.