


Solar Soil Sensor Instructions

Date: 10/06/2025 Version: 1.1 By: Matt Little



Add this soil moisture sensor to your pot plants to let you know when to water them.

This checks the moisture level and either blinks an LED or 'chirps' to remind you to water the plant.

It is solar powered, so will never need batteries! It uses an ultra-capacitor to store the solar energy, so will work even if left uncharged for a long time. But it will need to be left in sun to recharge – on a sunny windowsill will work perfectly!

This kit has been designed as a fun and interactive way to introduce solar power and to improve soldering skills. It is designed for indoor use on houseplants.

Parts included:

Piezo		Printed Circuit Board				6 x resistors: 2 x 120 Ω 1 x 1 k Ω 2 x 100 k Ω 1 x 1 M Ω
100 nF Capacitor						
Switch						
						Transistor BC547
Solar Photovoltaic Panel (5V, 30mA)						ATTiny85 Programmed Microcontroller (& holder)
		Diode - 1N5819		LED	Ultra-Capacitor x 2 (0.47F 5.5V)	Sticky Pad

Parts list:


Item	Ref	Item	Ref
2x 0.47F Ultra Capacitor	C1, C3	1 M Ω Resistor	R1
100nF Decoupling Capacitor	C2	100 k Ω Resistor	R2
5mm Red LED	D2	100 k Ω Resistor	R3
1N5819 Schottky Diode	D1	120 Ω Resistor	R4
ATTiny85 Microcontroller (programmed) Plus 8 pin DIL IC Holder	IC1	1 k Ω Resistor	R5
Piezo buzzer	LS1	120 Ω Resistor	R6
Printed Circuit Board	PCB	Solar Photovoltaic Panel (5V, 30mA)	SC1
BC 547C Transistor	Q1	Switch	SW1
		Sticky Pad	

Tools required:



PCB Instructions:

Step: 1 Solder resistors



Value	Ref	Colour
1 M Ω	R1	Brown – Black - Black– Yellow – Brown (5 band)
100 k Ω	R2	Brown – Black – Yellow - Gold
100 k Ω	R3	Brown – Black – Yellow - Gold
120 Ω	R4	Brown – Red – Brown – Gold
1 k Ω	R5	Brown – Black - Black– Brown – Brown (5 band)
120 Ω	R6	Brown – Red – Brown – Gold

Insert and solder the resistors to the locations marked on the PCB. Polarity does not matter for resistors. Ensure they are soldered flat & close to the PCB.

You can use a multi-meter or the colour code chart at the end of these instructions to ensure correct resistor values.


Step: 2 Solder diode D1 and Switch

Ensure correct orientation for D1, the 1N5819 diode.


This has tiny markings saying “1N5819” and also a white band around one end to indicate polarity.

Ensure the white band on the diode aligns with the white band marked on the PCB.

Solder the switch into the four pads marked 'SET'. Due to it's dimensions the switch will only fit in one orientation.



Step: 3 Solder capacitors



Note: There are additional holes on the PCB as these capacitors sometimes come in different sizes. Use the holes that fit the capacitors supplied.

First solder the non-polarised capacitor, C2. Orientation of this does not matter:

Value	Ref	Marking
100nf	C2	104

Next, solder the two polarised ultra-capacitors. Ensure correct orientation of this component.


The negative lead is marked with a white bars. Align the positive lead with the + sign and the negative lead with the white PCB marking.

Value	Ref	Marking
0.47F	C1, C3	0.47F 5.5V

Step: 4 Solder Transistor


Solder the transistor into the part marked Q1. This is a BC547 NPN transistor.

Ensure the flat side of the transistor aligns with the long flat side of the silk screen markings.



Flat side

Step: 5 Solder Piezo



Solder the piezo into the section marked LS1.


This creates the beep sounds.

The orientation of this component does not matter.



Step: 6 Solder IC holders

Solder the 8 pin IC holder. These fit into the area marked IC1.

Ensure correct orientation!
Ensure the notch on the holder aligns with the notch shown on the PCB.



Step: 7 Insert the IC



Carefully push the microcontroller into the 8 pin IC holder.

Ensure that the dot on the microcontroller aligns with the notch on the IC holder and the PCB.


Step: 8 Solder the LED

The LED is soldered to the other side of the PCB in area D2. Please see photos.

Ensure correct orientation!
FOR THIS BATCH OF PCBs THE SILKSCREEN IS PRINTED IN REVERSE!

The longer lead on the LED is positive, so place that into hole next to the FLAT side on the PCB

The negative side has a slightly flat edge on the body of the LED. This goes to the '+' marked hole on the PCB.




NOTE: SILK SCREEN INCORRECT!
The LED long lead goes to the FLAT side on PCB and the LED flat side goes to the + on the PCB

Step: 9**Fit and solder the Solar PV Panel**


Stop and double check that all the components are soldered correctly and in the correct locations. Once the solar PV panel has been soldered in place it will be difficult to fix any soldering issues!

- Use two cut-off resistor leads (1).
- Bend the resistor leads to make two little 'legs' for the solar panel (2).
- Add some solder to the pads of the PV panel, next to the + and – markings. Solder the short bent section of leads to the pads on the PV panel with the longer section pointing upwards (3).
- Add the sticky pad to the centre of the PCB on the solder side. Take off the backing of the sticky pad.
- Align the solar PV panel, ensuring that the + of the solar panel is aligned with the + solder pad. Also ensure the PV panel is aligned with the white outline.
- Stick the solar panel down and then solder the leads on the other side through the large holes (4). Ensure you don't touch any of the other components with the soldering iron (especially anything that may melt, like the piezo).
- Then cut off the excess lead ends (5).

Check the image below for more details.



Step: 9 PCB is finished! Let's test...



Place the finished unit in bright sunlight.

It should charge up enough to work quite quickly (1-5 mins).

To get a full charge it will need to be left in the sun for a while. It can be left on a windowsill and will work very well there.

Please note: This unit is NOT waterproof. Do NOT leave outside if it will get wet. It is designed for indoor houseplants.

Step: 10: Operation

This unit has a few different functions, all controlled through the 'SET' button on the PCB. The unit will only work when it is charged, so this is best performed outside on a sunny day.

You can check to see if the unit is charged by pressing and holding the 'SET' button – if the LED is on and bright then the unit is fully charged. (This check will also change the mode the unit, so make sure you put the unit back into the right mode).

Set the 'I'm OK' moisture level:

We need to calibrate the unit for the moisture level that is "OK". Do this by watering your plant to the perfect amount. Pressing the 'SET' button for a short press (less than 1 second) will read the moisture value of the probes. It will use this value to make decisions on what is under-watered.

This value is stored in memory, even if the unit is fully discharged. The LED will flash quickly 5 times to show it has saved the moisture setting.

When the moisture level drops below this level minus a fixed amount (set in code) then it will trigger a flash and 'Chirp'.

Changing Modes:

Pressing and holding the 'SET' button (for more than 1 second) will cause the unit to cycle through the three modes. Each time the next mode is entered then there will be a beep(s). The number of beeps indicates the mode the unit is in. Release the 'SET' button when you are in the correct mode.

Mode 1: Flash and 'Chirp' on under-water

The unit will wake up every 8 seconds and check the moisture level.

If the moisture level is a bit below the set level (set as explained above), then the unit will 'Chirp' with a rising tone. This means 'water me!'. The LED will also flash.

The 'Chirp' will *only* happen when there is sunlight available (to stop it beeping through the night!). The 'Chirp' only happens every 30 seconds or so (although the LED will flash as a warning every 8 seconds).

Mode 2: Flash ONLY

This is the *quiet* mode. It will never 'chirp' but just flash if under-watered.

Mode 3: Flash and 'Chirp' on under-watered AND over-watered

This mode is similar to Mode 1 and does the same operation as Mode 1. It *also* checks for over-watering. If the plant is over-watered then the unit will do a falling 'Chirp' tone.

Note: *Even in normal operation this unit may discharge overnight or with a few cloudy days (as the capacitor does not hold a huge amount of energy). This is normal and the unit will start again when there is solar power available.*

Step: 11	Re-programming Notes
<i>Note: No programming is needed – the microcontrollers are already programmed! Here are some notes for people wanting to take things a step further...</i>	
<p>The circuit board has a standard ISP (In-System Programming) port for the ATTiny85 microcontroller and full access to the code which can be programmed via the Arduino IDE, if that's your thing.</p> <p>You will need a programmer for the ATTiny85 - an Arduino Uno with wiring set up for programming an ATTiny85 will work (please search internet for this information).</p> <p>You will need to include the ATTiny85 programming board manager into your version of the Arduino IDE (please search internet for this information). I installed "ATTinyCore" via the Arduino boards manager and these devices were programmed with the "ATTiny25/45/85 (no bootloader)", "1MHz (internal)" and B.O.D at "1.8V".</p> <p>You upload code by using the "Arduino as an ISP" option.</p> <p>The Arduino code for this unit (and all other design files) is available at the repository: https://github.com/curiouselectric/solarSoilSensor</p>	

Contact details:

We would like you to be happy with this kit. If you are not happy for any reason, then please contact us and we will help to sort it out.

If any parts are missing from your kit then please email hello@curiouselectric.co.uk with details and, if possible, where the kit was purchased.

More technical information can be found via www.curiouselectric.co.uk

Please email hello@curiouselectric.co.uk with any questions or comments.

You can find us on social media at:

Mastodon: <https://mas.to/@curiouselectric>

Blue Sky: <https://bsky.app/profile/curiouselectric.bsky.social>

Facebook: <https://www.facebook.com/curiouselectriccompany/>


This kit has been designed and produced by:

The Curious Electric Company

hello@curiouselectric.co.uk


www.curiouselectric.co.uk

Circuit Schematic



ATTiny85 Arduino Pins:
 IC Pin: Arduino Ref:
 1 5/A0/RST
 2 3/A3
 3 4/A2
 4 GND
 5 0 - PWM
 6 1 - PWM
 7 2/A1
 8 +Supply

ISP Connections:
 1 - MISO
 2 - Vcc
 3 - SCK
 4 - MOSI
 5 - RESET
 6 - GND



LOG01 LOG02
 P7 P8

Resistor Colour Codes

