

DTC	P0420/94	Catalyst System Efficiency Below Threshold (Bank 1) (European spec. (Except Taiwan))
------------	-----------------	---

DTC	P0430/94	Catalyst System Efficiency Below Threshold (Bank 2)
------------	-----------------	--


CIRCUIT DESCRIPTION

The engine ECU compares the waveform of the oxygen sensor located before the catalyst with the waveform of the oxygen sensor located after the catalyst to determine whether or not catalyst performance has deteriorated.

Air-fuel ratio feedback compensation keeps the waveform of the oxygen sensor before the catalyst repeatedly changing back and forth from rich to lean.


If the catalyst is functioning normally, the waveform of the oxygen sensor after the catalyst switches back and forth between rich and lean much more slowly than the waveform of the oxygen sensor before the catalyst.

But when both waveform change at a similar rate, it indicates that catalyst performance has deteriorated.




DTC No.	DTC Detecting Condition	Trouble Area
P0420/94 P0430/94	After engine and catalyst are warmed up, and while vehicle is driven within set vehicle and engine speed range, waveform of oxygen sensors have same amplitude (2 trip detection logic)	<ul style="list-style-type: none"> • Gas leakage on exhaust system • Oxygen sensor • Three-way catalytic converter

CONFIRMATION ENGINE RACING PATTERN



- (1) Connect the hand-held tester to the DLC3, or connect the probe of the oscilloscope between terminals OX1A, OX1B, OX2A, and E1 of the engine ECU connectors.
- (2) Start the engine and warm it up with all the accessories switched OFF until engine coolant temperature is stable.
- (3) Race the engine at 2,500 – 3,000 rpm for about 3 min.
- (4) After confirming that the waveform of the oxygen sensor (bank 1, 2 sensor 1) (OX1A, OX2A), oscillate around 0.5 V during feedback to the engine ECU, check the waveform of the oxygen sensor (bank 1 sensor 2) (OX1B).



HINT:

If there is a malfunction in the system, the waveform of the oxygen sensor (bank 1 sensor 2) (OX1B) is almost the same as that of the oxygen sensor (bank 1, 2 sensor 1) (OX1A, OX2A) on the left.

There are some cases where, even though a malfunction exists, the CHK ENG may either light up or not light up.

INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand-held tester. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1 Are there any other codes (besides P0420/94 or P0430/94) being output?

YES

Go to relevant DTC chart (See page DI-21).

NO

2

Check gas leakage on exhaust system.

NG

Repair or replace.

OK

3

Check oxygen sensor (bank 1, 2 sensor 1) (See Pub. No. RM588E on page FI-63).

NG

Repair or replace.

OK

4

Check oxygen sensor (bank 1 sensor 2) (See Pub. No. RM588E on page FI-63).

NG

Repair or replace.

OK

Replace three-way catalytic converter.