


CENTER BODY PILLAR (CUT)



F43874A

Weld work for 980 MPa ultra high strength steel

1 Follow the welding conditions below when welding ultra high strength steel to assure sufficient weld strength. (When repairing this model)

*1: When welding 2 panels together including 980 MPa ultra high strength steel.

Spot weld	Pressure	2940 N (300 kgf, 661 lbf)
	Weld current	10000 A
	Weld time	18 Cyc. (0.30 Sec.)
Plug weld	Plug diameter	10 mm (0.39 in.)
	Wire type	AWS A5.18 ER70S-3
	Shield gas	Metal active gas



*2: When welding more than 3 panels together including 980 MPa ultra high strength steel. (When plug welding a panel to the welded panels with the weld condition above.)


Plug weld	Plug diameter	Same as the standard method (See the introduction)
	Wire type	AWS A5.18 ER70S-3
	Shield gas	Metal active gas

HINT:

Be sure to use Metal active gas (Ar 80% + CO₂ 20%) as the shield gas when plug welding. Sufficient weld strength cannot be assured when using 100% CO₂ shield gas.


Symbol meaning

△ △ : Remove Weld Points  : Cut with Disc Sander etc.  : Cut and Join Location

 : Cut Location for Supply Parts

F43246B

REMOVAL




mm (in.)

F43246

REMOVAL POINT

- 1 Do not butt weld or heat repair because the heat decreases the strength of areas where ultra high strength steel is used. (See the introduction)
- 2 *3 indicates welds to remove for easier removal.






mm (in.)

F43247

REMOVAL POINT


- 1 Do not butt weld or heat repair because the heat decreases the strength of areas where ultra high strength steel is used. (See the introduction)
- 2 *4 indicates the location of the foamed sealing material. Be careful when cutting as the foamed sealing material is located near the cutting position.
- 3 *5 is reused.

Symbol meaning

 **M I** : Plug Weld
  : Fillet Weld
  : Butt Weld

F43248B


INSTALLATION



F43248

INSTALLATION POINT

- 1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 3 Follow the welding conditions when welding point *1 to assure sufficient weld strength. (See the introduction)
- 4 After welding the center body inner pillar to the vehicle side, install the center body pillar upper reinforce.





F43249


INSTALLATION POINT

- 1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 3 Follow the welding conditions when welding point *1 to assure sufficient weld strength. (See the introduction)
- 4 After welding the center body pillar upper reinforce to the vehicle side, install the center body outer pillar.

Symbol meaning

□ M I : Plug Weld  : Fillet Weld  : Butt Weld

F43248B



F43250

INSTALLATION POINT

- 1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- 3 Follow the welding conditions when welding point *2 to assure sufficient weld strength. (See the introduction)
- 4 *6 indicates the location of the foamed sealing material. Be careful when welding as the foamed sealing material is located near the area that is cut and joined together.
- 5 After welding the center body inner pillar and center body pillar upper reinforce to the vehicle side, install the center body outer pillar and *7.
- 6 After welding, apply the foamed sealing material to the corresponding parts. (See the paint-coating)
- 7 After welding, apply body sealer to the corresponding parts. (See the paint-coating)
- 8 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.