



Supported platforms for nondisruptive transition

ONTAP MetroCluster

Martin Houser, Thom Illingworth, Zachary Wambold
August 25, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/transition/concept_supported_platforms_for_transition.html on September 24, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Supported platforms for nondisruptive transition 1

Supported platforms for nondisruptive transition

When transitioning to a MetroCluster IP configuration, you must have a combination of supported platform models.

The following table shows the supported platform combinations. You can transition from platforms in the left-hand column to platforms listed as supported in the columns to the right, as indicated by the green table cells.

- A green cell shows that the combination is supported.
- A white (blank) cell indicates that the combination is unsupported.

For example, transitioning from a MetroCluster FC configuration consisting of AFF8060 controller modules to an IP configuration consisting of AFF A400 controller modules is supported.



Transitioning to a Cisco 9336C-FX2 shared switch configuration is not supported.

		Target MetroCluster IP platform												
		AFF A220	AFF A250	FAS500f	FAS2750	FAS8200	AFF A300	AFF A320	FAS8300	AFF A400	FAS8700	FAS9000	AFF A700	AFF A800
Starting MetroCluster FC platform	FAS8020 / FAS8040													
	AFF8040													
	FAS8060 / FAS8200													
	AFF8060 / FAS8080 AFF A300 / FAS8300													
	AFF8080													
	AFF A400													
	AFF A700													
	FAS9000													

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.