



# **Commands for switchover, healing, and switchback**

## **ONTAP MetroCluster**

Ranu Kundu, Zachary Wambold  
July 02, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-metrocluster/manage/reference\\_commands\\_for\\_switchover\\_healing\\_and\\_switchback.html](https://docs.netapp.com/us-en/ontap-metrocluster/manage/reference_commands_for_switchover_healing_and_switchback.html) on September 24, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

Commands for switchover, healing, and switchback ..... 1

# Commands for switchover, healing, and switchback

There are specific ONTAP commands for performing the MetroCluster disaster recovery processes.

If you want to...	Use this command...
Verify that switchover can be performed without errors or vetoes.	<code>metrocluster switchover -simulate</code> at the advanced privilege level
Verify that switchback can be performed without errors or vetoes.	<code>metrocluster switchback -simulate</code> at the advanced privilege level
Switch over to the partner nodes (negotiated switchover).	<code>metrocluster switchover</code>
Switch over to the partner nodes (forced switchover).	<code>metrocluster switchover -forced-on -disaster true</code>
Perform data aggregate healing.	<code>metrocluster heal -phase aggregates</code>
Perform root aggregate healing.	<code>metrocluster heal -phase root-aggregates</code>
Switch back to the home nodes.	<code>metrocluster switchback</code>

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.