



Completing recovery

ONTAP MetroCluster

Thom Illingworth, Zachary Wambold, Martin Houser
August 12, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/disaster-recovery/task_complete_recovery.html on September 24, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- Completing recovery 1
 - Reestablishing object stores for FabricPool configurations 1
 - Verifying licenses on the replaced nodes 1
 - Performing a switchback 3
 - Verifying a successful switchback 5
 - Mirroring the root aggregates of the replacement nodes 7
 - Reconfiguring the ONTAP Mediator service (MetroCluster IP configurations) 9
 - Verifying the health of the MetroCluster configuration 10

Completing recovery

Reestablishing object stores for FabricPool configurations

If one of the object stores in a FabricPool mirror was co-located with the MetroCluster disaster site and was destroyed, you must reestablish the object store and the FabricPool mirror.

About this task

- If the object-stores are remote and a MetroCluster site is destroyed, you do not need to rebuild the object store, and the original object store configurations as well as cold data contents are retained.
- For more information about FabricPool configurations, see the [Disk and Aggregates Power Guide](#).

Step

1. Follow the procedure "Replacing a FabricPool mirror on a MetroCluster configuration" in the [Disk and Aggregates Power Guide](#).

Verifying licenses on the replaced nodes

You must install new licenses for the replacement nodes if the impaired nodes were using ONTAP features that require a standard (node-locked) license. For features with standard licenses, each node in the cluster should have its own key for the feature.

About this task

Until you install license keys, features requiring standard licenses continue to be available to the replacement node. However, if the impaired node was the only node in the cluster with a license for the feature, no configuration changes to the feature are allowed. Also, using unlicensed features on the node might put you out of compliance with your license agreement, so you should install the replacement license key or keys on the replacement node as soon as possible.

The licenses keys must be in the 28-character format.

You have a 90-day grace period in which to install the license keys. After the grace period, all old licenses are invalidated. After a valid license key is installed, you have 24 hours to install all of the keys before the grace period ends.



If all nodes at a site have been replaced (a single node in the case of a two-node MetroCluster configuration), license keys must be installed on the replacement node or nodes prior to switchback.

Steps

1. Identify the licenses on the node:

```
license show
```

The following example displays the information about licenses in the system:

```
cluster_B::> license show
              (system license show)
```

```
Serial Number: 1-80-00050
```

```
Owner: site1-01
```

Package	Type	Description	Expiration
-----	-----	-----	-----
Base	license	Cluster Base License	-
NFS	site	NFS License	-
CIFS	site	CIFS License	-
iSCSI	site	iSCSI License	-
FCP	site	FCP License	-
FlexClone	site	FlexClone License	-

```
6 entries were displayed.
```

2. Verify that the licenses are good for the node after switchback:

```
metrocluster check license show
```

The following example displays the licenses that are good for the node:

```
cluster_B::> metrocluster check license show
```

Cluster	Check	Result
-----	-----	-----
Cluster_B	negotiated-switchover-ready	not-applicable
NFS	switchback-ready	not-applicable
CIFS	job-schedules	ok
iSCSI	licenses	ok
FCP	periodic-check-enabled	ok

3. If you need new license keys, obtain replacement license keys on the NetApp Support Site in the My Support section under Software licenses.



The new license keys that you require are automatically generated and sent to the email address on file. If you fail to receive the email with the license keys within 30 days, you should contact technical support.

4. Install each license key:

```
system license add -license-code license-key, license-key...+
```

5. Remove the old licenses, if desired:

a. Check for unused licenses:

```
license clean-up -unused -simulate
```

b. If the list looks correct, remove the unused licenses:

```
license clean-up -unused
```

Performing a switchback

After you heal the MetroCluster configuration, you can perform the MetroCluster switchback operation. The MetroCluster switchback operation returns the configuration to its normal operating state, with the sync-source storage virtual machines (SVMs) on the disaster site active and serving data from the local disk pools.

Before you begin

- The disaster cluster must have successfully switched over to the surviving cluster.
- Healing must have been performed on the data and root aggregates.
- The surviving cluster nodes must not be in the HA failover state (all nodes must be up and running for each HA pair).
- The disaster site controller modules must be completely booted and not in the HA takeover mode.
- The root aggregate must be mirrored.
- The Inter-Switch Links (ISLs) must be online.
- Any required licenses must be installed on the system.

Steps

1. Confirm that all nodes are in the enabled state:

```
metrocluster node show
```

The following example displays the nodes that are in the enabled state:

```
cluster_B::> metrocluster node show
```

DR Group	Cluster	Node	Configuration State	DR Mirroring	Mode
-----	-----	-----	-----	-----	-----
1	cluster_A				
		node_A_1	configured	enabled	heal roots completed
		node_A_2	configured	enabled	heal roots completed
	cluster_B				
		node_B_1	configured	enabled	waiting for
switchback recovery		node_B_2	configured	enabled	waiting for
switchback recovery					
4 entries were displayed.					

2. Confirm that resynchronization is complete on all SVMs:

```
metrocluster vserver show
```

3. Verify that any automatic LIF migrations being performed by the healing operations have been successfully completed:

```
metrocluster check lif show
```

4. Perform the switchback by running the `metrocluster switchback` command from any node in the surviving cluster.

5. Check the progress of the switchback operation:

```
metrocluster show
```

The switchback operation is still in progress when the output displays "waiting-for-switchback":

```
cluster_B::> metrocluster show
Cluster                               Entry Name                State
-----
Local: cluster_B                     Configuration state        configured
                                      Mode                        switchover
                                      AUSO Failure Domain      -
Remote: cluster_A                    Configuration state        configured
                                      Mode                        waiting-for-switchback
                                      AUSO Failure Domain      -
```

The switchback operation is complete when the output displays "normal":

```
cluster_B::> metrocluster show
Cluster                               Entry Name                State
-----
Local: cluster_B                     Configuration state        configured
                                      Mode                        normal
                                      AUSO Failure Domain      -
Remote: cluster_A                    Configuration state        configured
                                      Mode                        normal
                                      AUSO Failure Domain      -
```

If a switchback takes a long time to finish, you can check on the status of in-progress baselines by using the the following command at the advanced privilege level:

```
metrocluster config-replication resync-status show
```

6. Reestablish any SnapMirror or SnapVault configurations.

In ONTAP 8.3, you need to manually reestablish a lost SnapMirror configuration after a MetroCluster

switchback operation. In ONTAP 9.0 and later, the relationship is reestablished automatically.

Verifying a successful switchback

After performing the switchback, you want to confirm that all aggregates and storage virtual machines (SVMs) are switched back and online.

Steps

1. Verify that the switched-over data aggregates are switched back:

```
storage aggregate show
```

In the following example, `aggr_b2` on node B2 has switched back:

```
node_B_1::> storage aggregate show
Aggregate      Size Available Used% State   #Vols  Nodes           RAID
Status
-----
...
aggr_b2        227.1GB   227.1GB   0% online      0 node_B_2   raid_dp,
mirrored,
normal

node_A_1::> aggr show
Aggregate      Size Available Used% State   #Vols  Nodes           RAID
Status
-----
...
aggr_b2        -         -         - unknown      - node_A_1
```

If the disaster site included unmirrored aggregates and the unmirrored aggregates are no longer present, the aggregate might show up with a state of "unknown" in the output of the `storage aggregate show` command. Contact technical support to remove the out-of-date entries for the unmirrored aggregates.

2. Verify that all sync-destination SVMs on the surviving cluster are dormant (showing an Admin State of "stopped") and the sync-source SVMs on the disaster cluster are up and running:

```
vserver show -subtype sync-source
```

```

node_B_1::> vserver show -subtype sync-source
                                Admin      Root
Name      Name
Vserver    Type      Subtype    State      Volume      Aggregate
Service Mapping
-----
...
vs1a       data      sync-source
                                running    vs1a_vol    node_B_2
file       file
aggr_b2

node_A_1::> vserver show -subtype sync-destination
                                Admin      Root
Name      Name
Vserver    Type      Subtype    State      Volume      Aggregate
Service Mapping
-----
...
cluster_A-vs1a-mc  data      sync-destination
                                stopped    vs1a_vol    sosb_
file       file
aggr_b2

```

Sync-destination aggregates in the MetroCluster configuration have the suffix "-mc" automatically appended to their name to help identify them.

3. Confirm that the switchback operations succeeded by using the `metrocluster operation show` command.

If the command output shows...	Then...
That the switchback operation state is successful.	The switchback process is complete and you can proceed with operation of the system.
That the switchback operation or switchback-continuation-agent operation is partially successful.	Perform the suggested fix provided in the output of the <code>metrocluster operation show</code> command.

After you finish

You must repeat the previous sections to perform the switchback in the opposite direction. If site_A did a switchover of site_B, have site_B do a switchover of site_A.

Mirroring the root aggregates of the replacement nodes

If disks were replaced, you must mirror the root aggregates of the new nodes on the disaster site.

Steps

1. On the disaster site, identify the aggregates which are not mirrored:

```
storage aggregate show
```

```
cluster_A::> storage aggregate show

Aggregate      Size Available Used% State  #Vols  Nodes      RAID
Status
-----
node_A_1_aggr0
1.49TB      74.12GB   95% online    1 node_A_1
raid4,
normal
node_A_2_aggr0
1.49TB      74.12GB   95% online    1 node_A_2
raid4,
normal
node_A_1_aggr1
1.49TB      74.12GB   95% online    1 node_A_1      raid
4, normal
mirrored
node_A_2_aggr1
1.49TB      74.12GB   95% online    1 node_A_2      raid
4, normal
mirrored
4 entries were displayed.

cluster_A::>
```

2. Mirror one of the root aggregates:

```
storage aggregate mirror -aggregate root-aggregate
```

The following example shows how the command selects disks and prompts for confirmation when mirroring the aggregate.

```

cluster_A::> storage aggregate mirror -aggregate node_A_2_aggr0

Info: Disks would be added to aggregate "node_A_2_aggr0" on node
"node_A_2" in
    the following manner:

    Second Plex

        RAID Group rg0, 3 disks (block checksum, raid4)
        Position    Disk                                Type
Size
-----
-----
-      parity      2.10.0                                SSD
      data        1.11.19                                SSD
894.0GB
      data        2.10.2                                SSD
894.0GB

    Aggregate capacity available for volume use would be 1.49TB.

Do you want to continue? {y|n}: y

cluster_A::>

```

3. Verify that mirroring of the root aggregate is complete:

```
storage aggregate show
```

The following example shows that the root aggregates are mirrored.

```
cluster_A::> storage aggregate show
```

Aggregate Status	Size	Available	Used%	State	#Vols	Nodes	RAID
node_A_1_aggr0	1.49TB	74.12GB	95%	online	1	node_A_1	raid4, mirrored, normal
node_A_2_aggr0	2.24TB	838.5GB	63%	online	1	node_A_2	raid4, mirrored, normal
node_A_1_aggr1	1.49TB	74.12GB	95%	online	1	node_A_1	raid4, mirrored, normal
node_A_2_aggr1	1.49TB	74.12GB	95%	online	1	node_A_2	raid4 mirrored, normal

```
4 entries were displayed.
```

```
cluster_A::>
```

4. Repeat these steps for the other root aggregates.

Any root aggregate that does not have a status of mirrored must be mirrored.

Reconfiguring the ONTAP Mediator service (MetroCluster IP configurations)

If you have a MetroCluster IP configuration that was configured with the ONTAP Mediator service, you must remove and reconfigure the association with the mediator.

Before you begin

- You must have the IP address and username and password for the ONTAP Mediator service.
- The ONTAP Mediator service must be configured and operating on the Linux host.

Steps

1. Remove the existing ONTAP Mediator configuration:

```
metrocluster configuration-settings mediator remove
```

2. Reconfigure the ONTAP Mediator configuration:

```
metrocluster configuration-settings mediator add -mediator-address mediator-IP-address
```

Verifying the health of the MetroCluster configuration

You should check the health of the MetroCluster configuration to verify proper operation.

Steps

1. Check that the MetroCluster is configured and in normal mode on each cluster:

```
metrocluster show
```

```
cluster_A::> metrocluster show
Cluster                               Entry Name                State
-----
Local: cluster_A                      Configuration state        configured
                                      Mode                        normal
                                      AUSO Failure Domain       auso-on-cluster-disaster
Remote: cluster_B                     Configuration state        configured
                                      Mode                        normal
                                      AUSO Failure Domain       auso-on-cluster-disaster
```

2. Check that mirroring is enabled on each node:

```
metrocluster node show
```

```
cluster_A::> metrocluster node show
DR                                     Configuration  DR
Group Cluster Node                    State          Mirroring Mode
-----
1      cluster_A
          node_A_1      configured     enabled      normal
          cluster_B
          node_B_1      configured     enabled      normal
2 entries were displayed.
```

3. Check that the MetroCluster components are healthy:

```
metrocluster check run
```

```
cluster_A::> metrocluster check run
```

```
Last Checked On: 10/1/2014 16:03:37
```

Component	Result
nodes	ok
lifs	ok
config-replication	ok
aggregates	ok

4 entries were displayed.

Command completed. Use the "metrocluster check show -instance" command or sub-commands in "metrocluster check" directory for detailed results. To check if the nodes are ready to do a switchover or switchback operation, run "metrocluster switchover -simulate" or "metrocluster switchback -simulate", respectively.

4. Check that there are no health alerts:

```
system health alert show
```

5. Simulate a switchover operation:

- a. From any node's prompt, change to the advanced privilege level:

```
set -privilege advanced
```

You need to respond with `y` when prompted to continue into advanced mode and see the advanced mode prompt (`*>`).

- b. Perform the switchover operation with the `-simulate` parameter:

```
metrocluster switchover -simulate
```

- c. Return to the admin privilege level:

```
set -privilege admin
```

6. For MetroCluster IP configurations using the ONTAP Mediator service, confirm that the Mediator service is up and operating.

- a. Check that the Mediator disks are visible to the system:

```
storage failover mailbox-disk show
```

The following example shows that the mailbox disks have been recognized.

```

node_A_1::*> storage failover mailbox-disk show
Mailbox
Node          Owner      Disk      Name      Disk UUID
-----
still13-vsim-ucs626g
.
.
    local      0m.i2.3L26
7BBA77C9:AD702D14:831B3E7E:0B0730EE:00000000:00000000:00000000:000000
00:00000000:00000000
    local      0m.i2.3L27
928F79AE:631EA9F9:4DCB5DE6:3402AC48:00000000:00000000:00000000:000000
00:00000000:00000000
    local      0m.i1.0L60
B7BCDB3C:297A4459:318C2748:181565A3:00000000:00000000:00000000:000000
00:00000000:00000000
.
.
.
    partner    0m.i1.0L14
EA71F260:D4DD5F22:E3422387:61D475B2:00000000:00000000:00000000:000000
00:00000000:00000000
    partner    0m.i2.3L64
4460F436:AAE5AB9E:D1ED414E:ABF811F7:00000000:00000000:00000000:000000
00:00000000:00000000
28 entries were displayed.

```

b. Change to the advanced privilege level:

```
set -privilege advanced
```

c. Check that the mailbox LUNs are visible to the system:

```
storage iscsi-initiator show
```

The output will show the presence of the mailbox LUNs:

Node	Type	Label	Target	Portal	Target Name
Admin/Op					
-----	-----	-----	-----	-----	-----

.					
.					
.					
.node_A_1					
		mailbox			
		mediator	172.16.254.1		iqn.2012-
		05.local:mailbox.target.db5f02d6-e3d3		up/up	
.					
.					
.					
17 entries were displayed.					

d. Return to the administrative privilege level:

```
set -privilege admin
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.