



Setting up ONTAP

ONTAP MetroCluster

Martin Houser, Thom Illingworth
August 25, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/install-ip/task_sw_config_setup_ontap.html on September 24, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Setting up ONTAP 1

Setting up ONTAP

After you boot each node, you are prompted to perform basic node and cluster configuration. After configuring the cluster, you return to the ONTAP CLI to create aggregates and create the MetroCluster configuration.

Before you begin

- You must have cabled the MetroCluster configuration.
- You must not have configured the Service Processor.

If you need to netboot the new controllers, see [Netbooting the new controller modules](#).

About this task

This task must be performed on both clusters in the MetroCluster configuration.

Steps

1. Power up each node at the local site if you have not already done so and let them all boot completely.

If the system is in Maintenance mode, you need to issue the `halt` command to exit Maintenance mode, and then issue the `boot_ontap` command to boot the system and get to cluster setup.

2. On the first node in each cluster, proceed through the prompts to configure the cluster.
 - a. Enable the AutoSupport tool by following the directions provided by the system.

The output should be similar to the following:

Welcome to the cluster setup wizard.

You can enter the following commands at any time:

"help" or "?" - if you want to have a question clarified,
"back" - if you want to change previously answered questions, and
"exit" or "quit" - if you want to quit the cluster setup wizard.
Any changes you made before quitting will be saved.

You can return to cluster setup at any time by typing "cluster setup".

To accept a default or omit a question, do not enter a value.

This system will send event messages and periodic reports to NetApp Technical

Support. To disable this feature, enter
autosupport modify -support disable
within 24 hours.

Enabling AutoSupport can significantly speed problem determination and

resolution should a problem occur on your system.

For further information on AutoSupport, see:

<http://support.netapp.com/autosupport/>

Type yes to confirm and continue {yes}: yes

.
.
.

b. Configure the node management interface by responding to the prompts.

The prompts are similar to the following:

```
Enter the node management interface port [e0M]:
Enter the node management interface IP address: 172.17.8.229
Enter the node management interface netmask: 255.255.254.0
Enter the node management interface default gateway: 172.17.8.1
A node management interface on port e0M with IP address 172.17.8.229
has been created.
```

c. Create the cluster by responding to the prompts.

The prompts are similar to the following:

```
Do you want to create a new cluster or join an existing cluster?
{create, join}:
create
```

```
Do you intend for this node to be used as a single node cluster?
{yes, no} [no]:
no
```

```
Existing cluster interface configuration found:
```

```
Port MTU IP Netmask
e0a 1500 169.254.18.124 255.255.0.0
e1a 1500 169.254.184.44 255.255.0.0
```

```
Do you want to use this configuration? {yes, no} [yes]: no
```

```
System Defaults:
Private cluster network ports [e0a,e1a].
Cluster port MTU values will be set to 9000.
Cluster interface IP addresses will be automatically generated.
```

```
Do you want to use these defaults? {yes, no} [yes]: no
```

```
Enter the cluster administrator's (username "admin") password:
```

```
Retype the password:
```

```
Step 1 of 5: Create a Cluster
You can type "back", "exit", or "help" at any question.
```

```
List the private cluster network ports [e0a,e1a]:
Enter the cluster ports' MTU size [9000]:
Enter the cluster network netmask [255.255.0.0]: 255.255.254.0
Enter the cluster interface IP address for port e0a: 172.17.10.228
Enter the cluster interface IP address for port e1a: 172.17.10.229
Enter the cluster name: cluster_A
```

```
Creating cluster cluster_A
```

```
Starting cluster support services ...
```

```
Cluster cluster_A has been created.
```

- d. Add licenses, set up a Cluster Administration SVM, and enter DNS information by responding to the prompts.

The prompts are similar to the following:

```
Step 2 of 5: Add Feature License Keys
```

```
You can type "back", "exit", or "help" at any question.
```

```
Enter an additional license key []:
```

```
Step 3 of 5: Set Up a Vserver for Cluster Administration
```

```
You can type "back", "exit", or "help" at any question.
```

```
Enter the cluster management interface port [e3a]:
```

```
Enter the cluster management interface IP address: 172.17.12.153
```

```
Enter the cluster management interface netmask: 255.255.252.0
```

```
Enter the cluster management interface default gateway: 172.17.12.1
```

```
A cluster management interface on port e3a with IP address  
172.17.12.153 has been created. You can use this address to connect  
to and manage the cluster.
```

```
Enter the DNS domain names: lab.netapp.com
```

```
Enter the name server IP addresses: 172.19.2.30
```

```
DNS lookup for the admin Vserver will use the lab.netapp.com domain.
```

```
Step 4 of 5: Configure Storage Failover (SFO)
```

```
You can type "back", "exit", or "help" at any question.
```

```
SFO will be enabled when the partner joins the cluster.
```

```
Step 5 of 5: Set Up the Node
```

```
You can type "back", "exit", or "help" at any question.
```

```
Where is the controller located []: svl
```

- e. Enable storage failover and set up the node by responding to the prompts.

The prompts are similar to the following:

```
Step 4 of 5: Configure Storage Failover (SFO)
You can type "back", "exit", or "help" at any question.
```

```
SFO will be enabled when the partner joins the cluster.
```

```
Step 5 of 5: Set Up the Node
You can type "back", "exit", or "help" at any question.
```

```
Where is the controller located []: site_A
```

- f. Complete the configuration of the node, but do not create data aggregates.

You can use ONTAP System Manager, pointing your web browser to the cluster management IP address (<https://172.17.12.153>).

[Cluster management using System Manager \(Versions 9.0 to 9.6\)](#)

[ONTAP System Manager \(Version 9.7 and later\)](#)

3. Boot the next controller and join it to the cluster, following the prompts.
4. Confirm that nodes are configured in high-availability mode:

```
storage failover show -fields mode
```

If not, you must configure HA mode on each node, and then reboot the nodes:

```
storage failover modify -mode ha -node localhost
```

This command configures high-availability mode but does not enable storage failover. Storage failover is automatically enabled when you configure the MetroCluster configuration later in the process.

5. Confirm that you have four ports configured as cluster interconnects:

```
network port show
```

The MetroCluster IP interfaces are not configured at this time and do not appear in the command output.

The following example shows two cluster ports on node_A_1:

```
cluster_A::*> network port show -role cluster
```

```
Node: node_A_1
```

```
Ignore
```

```

Health
Speed(Mbps) Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status
-----
e4a      Cluster      Cluster      up    9000  auto/40000 healthy
false
e4e      Cluster      Cluster      up    9000  auto/40000 healthy
false

```

Node: node_A_2

Ignore

```

Health
Speed(Mbps) Health
Port      IPspace      Broadcast Domain Link MTU  Admin/Oper  Status
Status
-----
e4a      Cluster      Cluster      up    9000  auto/40000 healthy
false
e4e      Cluster      Cluster      up    9000  auto/40000 healthy
false

```

4 entries were displayed.

6. Repeat these steps on the partner cluster.

What to do next

Return to the ONTAP command-line interface and complete the MetroCluster configuration by performing the tasks that follow.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.