

dastaZ80 Mark II

Programmer's Reference Guide

Disclaimer

The products described in this manual are intended for educational purposes, and should not be used for controlling any machinery, critical component in life support devices or any system in which failure could result in personal injury if any of the described here products fail.

These products are subject to continuous development and improvement. All information of a technical nature and particulars of the products and its use are given by the author in good faith. However, it is acknowledged that there may be errors or omissions in this manual. Therefore, the author cannot accept any liability for any loss or damage arising from the use of any information or particulars in this manual.

Licenses

Hardware is licensed under the **Creative Commons Attribution-ShareAlike 4.0 International License**

<http://creativecommons.org/licenses/by-sa/4.0/>

Software is licensed under **The MIT License**

<https://opensource.org/licenses/MIT>

Documentation is licensed under the **Creative Commons Attribution-ShareAlike 4.0 International License**

<http://creativecommons.org/licenses/by-sa/4.0/>

Document Conventions

The following conventions are used in this manual:

MUST	MUST denotes that the definition is and absolute requirement.
SHOULD	SHOULD denotes that it is recommended, but that there may exist valid reasons to ignore it.
DEVICE	Device names are displayed in bold all upper case letters, and refer to hardware devices.
<i>Courier</i>	Text appearing in the <i>Courier</i> font represents either an OS System Variable a Z80 CPU Register or a Z80 Flag. OS System Variables are identifiers for specific MEMORY addresses that can be used to read statuses and to pass information between routines or programs.
0x14B0	Numbers prefixed by 0x indicate an Hexadecimal value. Unless specified, memory addresses are always expressed in Hexadecimal.
F_abcdef	Text starting with F_ refers to the name of an OS routine that can be called via Jumpblocks.
<i>jp</i> abcdef	Refers to the Z80 mnemonic for <i>jump</i> , which transfers the CPU Program Counter to a specific MEMORY address.

The SD card is referred as **DISK**.

The Floppy Disk Drive is referred as **DISK** or as **FDD**.

The 80 column text VGA output is referred as **CONSOLE** or as **High Resolution Display**.

The 40 column graphics Composite Video output is referred as **Low Resolution Display** or **VDP screen**.

The Operating System may be referred as DZOS, dzOS or simply OS.

MEMORY refers to both **ROM** and **RAM**.

Memory used by the **Low Resolution Display** is referred as **VRAM** (Video RAM).

In the list of routines, the **Destroys** lists the **CPU** registers and **MEMORY** System Variables that are destroyed by the routine in question. But bare in mind that a routine may call other routines that may destroy other registers and variables. Refer to the **Calls** list to check the entire flow. By *Destroys* is understood that the listed register or variable value is overwritten within the routine.

Related Documentation

- dastaZ80 User's Manual[\[1\]](#)
- dastaZ80 Technical Reference Manual[\[2\]](#)
- dzOS Github Repository[\[3\]](#)

Contents

1	Memory Map	1
1.1	ROM	1
1.2	RAM	1
1.2.1	Stack	1
1.2.2	System Variables (SYSVARS)	2
1.2.3	DISK Buffer	6
2	I/O Map	7
3	BIOS Jumpblocks	8
3.1	Non-Maskable Interrupt (NMI)	8
3.1.1	F_BIOS_NMIEND	9
3.1.2	BIOS_NMIJP	9
3.2	General Routines	9
3.2.1	F_BIOS_WBOOT	9
3.2.2	F_BIOS_SYSHALT	9
3.3	Serial Routines	10
3.3.1	F_BIOS_SERIAL_INIT	10
3.3.2	F_BIOS_SERIAL_CONIN_A	10
3.3.3	F_BIOS_SERIAL_CONIN_B	10
3.3.4	F_BIOS_SERIAL_CONOUT_A	10
3.3.5	F_BIOS_SERIAL_CONOUT_B	10
3.4	DISK Routines	11
3.4.1	F_BIOS_SD_BUSY_WAIT	11
3.4.2	F_BIOS_SD_GET_STATUS	11
3.4.3	F_BIOS_SD_PARK_DISKS	11
3.4.4	F_BIOS_SD_MOUNT_DISKS	11
3.4.5	F_BIOS_DISK_READ_SEC	12
3.4.6	F_BIOS_DISK_WRITE_SEC	12
3.4.7	F_BIOS_FDD_BUSY_WAIT	12
3.4.8	F_BIOS_FDD_CHANGE	13
3.4.9	F_BIOS_FDD_LOWLVL_FORMAT	13
3.4.10	F_BIOS_FDD_MOTOR_ON	13
3.4.11	F_BIOS_FDD_MOTOR_OFF	13
3.4.12	F_BIOS_FDD_CHECK_DISKIN	14
3.4.13	F_BIOS_FDD_CHECK_WPROTECT	14
3.5	Real-Time Clock Routines	14
3.5.1	F_BIOS_RTC_GET_TIME	14
3.5.2	F_BIOS_RTC_GET_DATE	14
3.5.3	F_BIOS_RTC_SET_TIME	15
3.5.4	F_BIOS_RTC_SET_DATE	15
3.5.5	F_BIOS_CHECK_BATTERY	15

3.6	NVRAM Routines	15
3.6.1	F_BIOS_NVRAM_DETECT	15
3.7	VDP Routines	16
3.7.1	F_BIOS_VDP_SET_ADDR_WR	16
3.7.2	F_BIOS_VDP_SET_ADDR_RD	16
3.7.3	F_BIOS_VDP_SET_REGISTER	16
3.7.4	F_BIOS_VDP_EI	16
3.7.5	F_BIOS_VDP_DI	17
3.7.6	F_BIOS_VDP_READ_STATREG	17
3.7.7	F_BIOS_VDP_VRAM_CLEAR	17
3.7.8	F_BIOS_VDP_VRAM_TEST	17
3.7.9	F_BIOS_VDP_SET_MODE_G2	18
3.7.10	F_BIOS_VDP_SHOW_DZ_LOGO	18
3.7.11	F_BIOS_VDP_BYTE_TO_VRAM	18
3.7.12	F_BIOS_VDP_VRAM_TO_BYTE	18
3.7.13	F_BIOS_VDP_JIFFY_COUNTER	18
3.7.14	F_BIOS_VDP_VBLANK_WAIT	19
3.7.15	F_BIOS_VDP_LDIR_VRAM	19
3.7.16	F_BIOS_VDP_CHAROUT_ATXY	19
3.8	Dual Joystick Routines	20
3.8.1	F_BIOS_JOYS_GET_STAT	20
4	Kernel Jumpblocks	21
4.1	General Routines	21
4.1.1	F_KRN_SYSHALT	21
4.2	Serial Routines	21
4.2.1	F_KRN_SERIAL_SETFGCOLR	21
4.2.2	F_KRN_SERIAL_WRSTR	21
4.2.3	F_KRN_SERIAL_WRSTRCLR	21
4.2.4	F_KRN_SERIAL_WR6DIG_NOLZEROS	22
4.2.5	F_KRN_SERIAL_RDCHARECHO	22
4.2.6	F_KRN_SERIAL_EMPTYLINES	22
4.2.7	F_KRN_SERIAL_PRN_NIBBLE	22
4.2.8	F_KRN_SERIAL_PRN_BYTE	23
4.2.9	F_KRN_SERIAL_PRN_BYTES	23
4.2.10	F_KRN_SERIAL_PRN_WORD	23
4.2.11	F_KRN_SERIAL_SEND_ANSI_CODE	23
4.2.12	F_KRN_SERIAL_CLR_SIOCHA_BUFFER	23
4.3	DZFS (file system) Routines	24
4.3.1	F_KRN_DZFS_READ_SUPERBLOCK	24
4.3.2	F_KRN_DZFS_READ_BAT_SECTOR	24
4.3.3	F_KRN_DZFS_BATENTRY_TO_BUFFER	24
4.3.4	F_KRN_DZFS_SEC_TO_BUFFER	24
4.3.5	F_KRN_DZFS_GET_FILE_BATENTRY	25

4.3.6	F_KRN_DZFS_LOAD_FILE_TO_RAM	25
4.3.7	F_KRN_DZFS_DELETE_FILE	25
4.3.8	F_KRN_DZFS_CHGATTR_FILE	25
4.3.9	F_KRN_DZFS_RENAME_FILE	26
4.3.10	F_KRN_DZFS_FORMAT_DISK	26
4.3.11	F_KRN_DZFS_CALC_SN	26
4.3.12	F_KRN_DZFS_SECTOR_TO_DISK	27
4.3.13	F_KRN_DZFS_GET_BAT_FREE_ENTRY	27
4.3.14	F_KRN_DZFS_ADD_BAT_ENTRY	27
4.3.15	F_KRN_DZFS_CREATE_NEW_FILE	28
4.3.16	F_KRN_DZFS_CALC_FILETIME	28
4.3.17	F_KRN_DZFS_CALC_FILEDATE	29
4.3.18	F_KRN_DZFS_SHOW_DISKINFO_SHORT	29
4.3.19	F_KRN_DZFS_SHOW_DISKINFO	29
4.3.20	F_KRN_DZFS_CHECK_FILE_EXISTS	30
4.4	Math Routines	30
4.4.1	F_KRN_MULTIPLY816_SLOW	30
4.4.2	F_KRN_MULTIPLY1616	30
4.4.3	F_KRN_DIV1616	30
4.4.4	F_KRN_CRC16_INI	31
4.4.5	F_KRN_CRC16_GEN	31
4.5	String manipulation Routines	31
4.5.1	F_KRN_IS_PRINTABLE	31
4.5.2	F_KRN_IS_NUMERIC	31
4.5.3	F_KRN_TOUPPER	32
4.5.4	F_KRN_STRCMP	32
4.5.5	F_KRN_STRCPY	32
4.5.6	F_KRN_STRLEN	33
4.5.7	F_KRN_STRLENMAX	33
4.5.8	F_KRN_INSTR	33
4.6	Conversion Routines	34
4.6.1	F_KRN_ASCIIADR_TO_HEX	34
4.6.2	F_KRN_ASCII_TO_HEX	34
4.6.3	F_KRN_HEX_TO_ASCII	34
4.6.4	F_KRN_BCD_TO_BIN	34
4.6.5	F_KRN_BIN_TO_BCD4	35
4.6.6	F_KRN_BIN_TO_BCD6	35
4.6.7	F_KRN_BCD_TO_ASCII	35
4.6.8	F_KRN_BITEXTRACT	35
4.6.9	F_KRN_BIN_TO_ASCII	36
4.6.10	F_KRN_DEC_TO_BIN	36
4.6.11	F_KRN_PKEDDATE_TO_DMY	36
4.6.12	F_KRN_PKEDTIME_TO_HMS	37
4.7	MEMORY Routines	37

4.7.1	F_KRN_SETMEMRNG	37
4.7.2	F_KRN_COPYMEM512	37
4.7.3	F_KRN_SHIFT_BYTES_BY1	38
4.7.4	F_KRN_CLEAR_MEMAREA	38
4.7.5	F_KRN_CLEAR_DISKBUFFER	38
4.8	Real-Time Clock Routines	38
4.8.1	F_KRN_RTC_GET_DATE	38
4.8.2	F_KRN_RTC_SHOW_TIME	39
4.8.3	F_KRN_RTC_SHOW_DATE	39
4.8.4	F_KRN_RTC_SET_TIME	39
4.8.5	F_KRN_RTC_SET_DATE	40
5	dastaZ80 File System (DZFS)	41
5.1	DZFS characteristics	41
5.2	DISK anatomy	42
5.2.1	Superblock	42
5.2.2	Block Allocation Table (BAT)	43
5.2.3	Data Area	44
5.3	How Volume Serial Number is calculated	45
5.4	How Dates (creation/last modified) are calculated	45
5.5	How Times (creation/last modified) are calculated	45
5.6	Block Number, Sector Number and Addresses	46
6	How To	48
6.1	Read data from DISK	48
6.2	Write data to DISK	48
6.3	Convert between HEX and DEC and ASCII	48
6.4	Develop software for dzOS	50
6.4.1	Available RAM	50
6.4.2	Storing your variables	50
6.4.3	Receiving parameters from CLI	50
6.4.4	Returning to CLI	50
6.4.5	Developing with Z80 Assembler	51
6.4.6	Developing with SDCC	52
7	Appendixes	53
7.1	ANSI Terminal colours	53
7.2	VDP Composite colours	53
7.3	Jiffy Counter	54
7.4	OS Boot Sequence	54
7.5	dzOS Programming Style	56

1 Memory Map

1.1 ROM

The **ROM** is a 16KB EEPROM, and is divided as follows:

Address		Description	Size (bytes)
0x0000	0x0007	Cold Boot	8
0x0008	0x0215	init SIO/2	526
0x0216	0x133F	BIOS code	4,394
0x1340	0x26C7	Kernel code	5,000
0x26B7	0x26C7	dzOS version build	17
0x26C8	0x3A88	CLI code	5,057
0x3A89	0x3AB6	Bootstrap	46
0x3AB7	0x3E0E	VDP dastaZ80 Logo	856
0x3E4A	0x3EFD	BIOS Jumpblock	180
0x3EFE	0x3FFF	Kernel Jumpblock	258

1.2 RAM

The **RAM** is a 64KB SRAM, and is divided as follows:

Address		Description	Size (bytes)
0x4000	0x401F	Stack	32
0x4020	0x4174	System Variables	373
0x4188	0x421F	Reserved for future use	139
0x4220	0x441F	DISK Buffer	512
0x4420	0xFFFF	Free RAM	48,096

1.2.1 Stack

A *Stack* is a list of words (2 bytes) that uses Last In First Out (LIFO) access method. It is used by the **CPU** to keep track of **MEMORY** addresses when executing a *call* instruction.

The programmer can also store (*PUSH*) or retrieve (*POP*) values on/from the top of the stack.

Usage of the Stack requires very careful attention. doing (*PUSH*) without the corresponding (*POP*) or vice versa, will set the CPU on the wrong path of execution. Most of the time just hanging the computer, but also potentially destroying information if an access to disk is triggered by the wrong call.

1.2.2 System Variables (SYSVARS)

The area of **RAM** called *System Variables (SYSVARS)* is an area heavily used by the OS, but it can also be used by a program to communicate with the OS.

The area has been *split* as follows:

- **SIO**

- 0x4020 - **SIO_CH_A_BUFFER** (64 bytes): Buffer for SIO Channel A.
- 0x4060 - **SIO_CH_A_IN_PTR** (2 bytes)
- 0x4062 - **SIO_CH_A_RD_PTR** (2 bytes)
- 0x4064 - **SIO_CH_A_BUFFER_USED** (1 byte)
- 0x4065 - **SIO_CH_A_LASTCHAR** (1 bytes)
- 0x4066 - **SIO_CH_B_BUFFER** (64 bytes): Buffer for SIO Channel B.
- 0x40A6 - **SIO_CH_B_IN_PTR** (2 bytes)
- 0x40A6 - **SIO_CH_B_RD_PTR** (2 bytes)
- 0x40AA - **SIO_CH_B_BUFFER_USED** (1 byte)

- **DISK Superblock**

- 0x40AB - **DISK_is_formatted** (1 byte): tells to the OS if the **DISK** can be used.
 - * 0xFF = formatted with *DZFS*.
 - * 0x00 = not formatted.
- 0x40AC - **DISK_show_deleted** (1 byte)
 - * 0x00 = do not show deleted files in *cat* command results.
 - * 0x01 = show also deleted files in *cat* command results.
- 0x40AD - **DISK_cur_sector** (2 bytes): current Sector being used by the OS.

- **DISK BAT**

- 0x40AF - **DISK_cur_file_name** (14 bytes): Filename of file currently being load or saved.
- 0x40BD - **DISK_cur_file_attribs** (1 byte): Attributes of file currently being load or saved.

- * Bit 0: if set, file is Read Only.
- * Bit 1: if set, file is Hidden (it does not display in *cat* command results).
- * Bit 2: if set, file is System (it does not display in *cat* command results).
- * Bit 3: if set, file is Executable.
- * Bits 4-7: not used.
- 0x40BE - **DISK_cur_file_time_created** (2 bytes): time when currently being load or saved file was created.
- 0x40C0 - **DISK_cur_file_date_created** (2 bytes): date when currently being load or saved file was created.
- 0x40C2 - **DISK_cur_file_time_modified** (2 bytes): time when currently being load or saved file was last modified.
- 0x40C4 - **DISK_cur_file_date_modified** (2 bytes): date when currently being load or saved file was last modified.
- 0x40C6 - **DISK_cur_file_size_bytes** (2 bytes): size in bytes of file currently being load or saved.
- 0x40C8 - **DISK_cur_file_size_sectors** (1 byte): size in sectors of file currently being load or saved.
- 0x40C9 - **DISK_cur_file_entry_number** (2 bytes): entry number in the BAT, of file currently being load or saved.
- 0x40CB - **DISK_cur_file_1st_sector** (2 bytes): sector number, of the first sector, where the bytes of file currently being load or saved are stored in the **DISK**.
- 0x40CD - **DISK_cur_file_load_addr** (2 bytes): address where the bytes of file currently being load will be stored in **RAM**.
- **CLI**: buffers used by CLI to store temporary data.
 - 0x40CF - **CLI_prompt_addr** (2 bytes): The address of the CLI Prompt subroutine. Programs that need to return control to CLI on exit, MUST jump to the address stored here.
 - 0x40D1 - **CLI_buffer** (6 bytes): generic buffer.
 - 0x40D7 - **CLI_buffer_cmd** (16 bytes): when a user enters a command and its parameters, the command alone is stored here.
 - 0x40E7 - **CLI_buffer_parm1_val** (16 bytes): when a user enters a command and its parameters, the first parameter is stored here.

- 0x40F7 - **CLI_buffer_parm2_val** (16 bytes): when a user enters a command and its parameters, the second parameter is stored here.
- 0x4107 - **CLI_buffer_pgm** (32 bytes): generic buffer.
- 0x4127 - **CLI_buffer_full_cmd** (64 bytes): when a user enters a command and its parameters, the entire line entered by the user is stored here. This is useful for passing parameters to programs called with *run* command.

• RTC

- 0x4167 - **RTC_hour** (1 byte): 24h format, in hexadecimal (0x00-0x17).
- 0x4168 - **RTC_minutes** (1 byte): in hexadecimal (0x00-0x3B).
- 0x4169 - **RTC_seconds** (1 byte): in hexadecimal (0x00-0x3B).
- 0x416A - **RTC_century** (1 byte): 20 part of year 20xx, in hexadecimal (0x14 = 20).
- 0x416B - **RTC_year** (1 byte): xx part of year 20xx, in hexadecimal (e.g. 0x16 = 22). The **RTC** supports until 2079, therefore maximum value is 0x4F.
- 0x416C - **RTC_year4** (2 bytes): four digit year, in hexadecimal (e.g. 0x07E6 = 2022). The **RTC** supports until 2079, therefore maximum value is 0x081F.
- 0x416E - **RTC_month** (1 byte): in hexadecimal (0x00-0x0C).
- 0x416F - **RTC_day** (1 byte): in hexadecimal (0x00-0x1F).
- 0x4170 - **RTC_day_of_the_week** (1 byte): 0x00=Sunday, 0x01=Monday, 0x02=Tuesday, 0x03=Wednesday, 0x04=Thursday, 0x05=Friday, 0x06=Saturday

• Math

- 0x4171 - **MATH_CRC** (2 bytes): CRC-16 CRC.
- 0x4173 - **MATH_polynomial** (2 bytes): CRC-16 Polynomial.

• Generic

- 0x4175 - **SD_images_num** (1 byte): number of Disk Image Files found by **ASMDC**.
- 0x4175 - **DISK_current** (1 byte): current **DISK** unit active. All disk operations will be on this **DISK**.

- 0x4177 - **DISK_status** (1 byte): status of the **FDD**.
 - * Low Nibble (0x00 if all OK)
 - bit 0 = not used.
 - bit 1 = not used.
 - bit 2 = set if last command resulted in error.
 - bit 3 = not used.
 - * High Nibble: error code of last operation.
- 0x4177 - **DISK_status** (1 byte): status of the **SD card**.
 - * Low Nibble (0x00 if all OK)
 - bit 0 = set if **SD card** was not found.
 - bit 1 = set if Disk Image File was not found.
 - bit 2 = set if last command resulted in error.
 - bit 3 = not used.
 - * High Nibble: number of Disk Image Files found.
- 0x4178 - **DISK_file_type** (1 byte): File Type when creating (*save*) next file.
- 0x4179 - **DISK_loadsave_addr** (2 bytes): see [Read data from DISK](#) and [Write data to DISK](#).
- 0x417B - **tmp_addr1** (2 bytes): temporary storage for an address.
- 0x417D - **tmp_addr2** (2 bytes): temporary storage for an address.
- 0x417F - **tmp_addr3** (2 bytes): temporary storage for an address.
- 0x4181 - **tmp_byte** (1 byte): temporary storage for a byte.
- 0x4182 - **tmp_byte2** (1 byte): temporary storage for a byte.

• VDP

- 0x4183 - **NMI_enable**: Enable (1) / Disable (0) the execution of the [NMI subroutine](#).
- 0x4184 - **NMI_usr_jump**: Enable (1) / Disable (0) the user configurable *BIOS_NMI JP* jump of the [NMI subroutine](#).
- 0x4185 - **VDP_cur_mode**:

- * 0 = Text Mode
- * 1 = Graphics I Mode
- * 2 = Graphics II Mode
- * 3 = Multicolour Mode
- 0x4186 - **VDP_cursor_x** (1 byte): Current horizontal position of the cursor on the **VDP** screen.
- 0x4187 - **VDP_cursor_y** (1 byte): Current vertical position of the cursor on the **VDP** screen.
- 0x4188 - **VDP_PTRNTAB_addr** (2 bytes): Address of current Mode's Pattern Table.
- 0x418A - **VDP_NAMETAB_addr** (2 bytes): Address of current Mode's Name Table.
- 0x418C - **VDP_COLRTAB_addr** (2 bytes): Address of current Mode's Colour Table.
- 0x418E - **VDP_SPRPTAB_addr** (2 bytes): Address of current Mode's Sprite Pattern Table.
- 0x4190 - **VDP_SPRATAB_addr** (2 bytes): Address of current Mode's Sprite Attribute Table.
- 0x4192 - **VDP_jiffy_byte1** (1 byte): [Jiffy Counter's](#) byte 1.
- 0x4193 - **VDP_jiffy_byte2** (1 byte): [Jiffy Counter's](#) byte 2.
- 0x4194 - **VDP_jiffy_byte3** (1 byte): [Jiffy Counter's](#) byte 3.

1.2.3 DISK Buffer

Read and Write operations on **DISK** are done Sector by Sector (i.e 512 Bytes).

When loading a file, dzOS asks **ASMDC** for the first 512 bytes of the file, and stores it in this buffer. After the bytes are moved to **RAM**, dzOS asks **ASMDC** for the next 512 bytes, and so on until the file is read entirely.

When saving a file, dzOS copies the first 512 bytes of the file from **RAM** to this buffer. After sending the bytes to **ASMDC**, dzOS copies the next 512 bytes of the file, and so on until the file is saved entirely.

When doing a *cat* of a **DISK**, dzOS asks **ASMDC** for the first 512 bytes of the BAT, and stores it in this buffer. After the list of files is shown on the screen, dzOS asks **ASMDC** for the next 512 bytes, and so on until the entire catalogue has been shown.

2 I/O Map

VDP	0x10	Mode 0 (VRAM)
	0x11	Mode 1 (Register)
ROM / RAM	0x38	ROM Paging
Joystick Ports	0x40	Joystick 1
	0x41	Joystick 2
SIO	0x80	Channel A Control
	0x81	Channel A Data
	0x82	Channel B Control
	0x83	Channel B Data

3 BIOS Jumpblocks

3.1 Non-Maskable Interrupt (NMI)

When the chip used for the generation of the Composite Video (the *Texas Instruments TMS9918A VDP*) is done drawing the screen, it enters the so called *vertical refresh mode* and issues an interrupt that gives the **CPU** a window of 4.3 miliseconds (4300 μ s). This interrupt occurs about every 1/60th second.

But this chip doesn't have the *priority daisy-chain* feature of other Zilog chips, and when raising an interrupt to the **CPU** pin */INT* could create bus contention¹. Therefore, the interrupt pin */INT* of the TMS9918A is connected to the */NMI* pin of the **CPU**.

This means that 1) there is no standard way² to programatically disable these interrupts, and 2) that every 1/60th second the **CPU** will receive a Non-Maskable Interrupt and therefore, store the current Program Counter (PC) in the stack and jump to the location 0x0066.

At this address, dzOS contains a small piece of code that allows programs to enable and disable a jump to their own subroutine. For example, a video game playing a tune will need to update the **PSG** in an interrupt basis.

This code works as follows:

- All **CPU** registers are saved (with *PUSH*).
- The **Jiffy Counter** is incremented.
- If the flag *NMI_usr_jump* is enabled (1), the subroutine jumps to whatever address is in bytes 2 and 3 of *BIOS_NMI_JP*
- If the flag is disabled (0), **CPU** registers are restored, and the subroutine ends.

The end of your subroutine MUST be a *jp F_BIOS_NMI_END*. This is the part that restores the previously saved **CPU** registers and ends the subroutine with *RETN*. Otherwise the system will certainly crash.

When writing a subroutine that will be called at each interrupt, remember that the window given for **CPU** time is 4.3 miliseconds (4300 μ s). The

¹Bus contention occurs when all devices communicate directly with each other through a single shared channel (Address and Data buses), and more than one device attempts to place values on the channel at the same time.

²By design the **CPU** doesn't offer an instruction to enable/disable this type of interrupts, hence are called *non-maskable*. But this has been implemented programatically within dzOS, and therefore NMI can be enabled/disabled via the funtions [F_BIOS_VDP_EI](#) and [F_BIOS_VDP_DI](#)

current NMI routine takes 35.81 μ s. After this window, the **VDP** will start drawing again in the screen.

3.1.1 F_BIOS_NMI_END

Action	Performs <i>POP</i> instructions for all CPU registers. Reads the VDP Status Register , to acknowledge the interrupt and allow more to happen, and performs a return from non maskable interrupt (<i>RETN</i>).
Entry	None
Exit	None
Destroys	Restores CPU registers AF, BC,DE, HL, IX and IY to the values they had before the NMI was triggered.
Calls	F_BIOS_VDP_READ_STATREG

3.1.2 BIOS_NMI_JP

This is the start address of three bytes corresponding to the instruction *jp BIOS_NMI_END*. The first byte (*C3*) **MUST** not be changed. The next two bytes are the ones a program can change to make the interrupt jump to a desired subroutine.

3.2 General Routines

3.2.1 F_BIOS_WBOOT

Action	Warm Boot. Executed after SIO/2 initialisation, or after a <i>reset</i> command
Entry	None
Exit	None
Destroys	None
Calls	<i>jp</i> F_KRN_START

3.2.2 F_BIOS_SYSHALT

Action	Halts the computer.
Entry	None
Exit	Disables both Maskable and Non-Maskable interrupts, and then executes a <i>halt</i> command.
Destroys	None
Calls	None

3.3 Serial Routines

3.3.1 F_BIOS_SERIAL_INIT

Action	Initialises SIO/2 : sets Channels A and B as 115,000 bps, 8N1, Interrupt in all characters Configures the interrupt vector to 0x60 Sets the CPU to Interrupt Mode 2 Enables Interrupts
Entry	None
Exit	None
Destroys	A, HL
Calls	<i>jp</i> F_BIOS_WBOOT

3.3.2 F_BIOS_SERIAL_CONIN_A

Action	Reads a character from the SIO/2 Channel A
Entry	None
Exit	A = character read
Destroys	A
Calls	None

3.3.3 F_BIOS_SERIAL_CONIN_B

Action	Reads a character from the SIO/2 Channel B
Entry	None
Exit	A = character read
Destroys	A
Calls	None

3.3.4 F_BIOS_SERIAL_CONOUT_A

Action	Sends a character to the SIO/2 Channel A
Entry	A = character to be send
Exit	None
Destroys	None
Calls	None

3.3.5 F_BIOS_SERIAL_CONOUT_B

Action	Sends a character to the SIO/2 Channel B
Entry	A = character to be send
Exit	None
Destroys	None
Calls	None

3.4 DISK Routines

3.4.1 F_BIOS_SD_BUSY_WAIT

Action	Calls ASMDC to check if the DISK is busy, and loops until it is not busy.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.2 F_BIOS_SD_GET_STATUS

Action	Calls ASMDC to check the status of the SD Card module.
Entry	None
Exit	<i>SD_status</i> bit 0 = set if SD card was not found bit 1 = set if image file was not found bit 2 = set if last command resulted in error
Destroys	A
Calls	F_BIOS_SD_BUSY F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.3 F_BIOS_SD_PARK_DISKS

Action	Tells ASMDC to close the Image File
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SD_BUSY F_BIOS_SERIAL_CONOUT_B

3.4.4 F_BIOS_SD_MOUNT_DISKS

Action	Tells ASMDC to open the Image File
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SD_BUSY F_BIOS_SERIAL_CONOUT_B

3.4.5 F_BIOS_DISK_READ_SEC

Action	Reads a Sector (512 bytes), from the DISK and places the bytes into the CF_BUFFER_START
Entry	E = sector address LBA 0 (bits 0-7) D = sector address LBA 1 (bits 8-15) C = sector address LBA 2 (bits 16-23) B = sector address LBA 3 (bits 24-27) BC are not used (set to zero), because max sector is 65,535
Exit	CF_BUFFER_START contains the 512 bytes read
Destroys	A, B, HL, DISK_BUFFER_START
Calls	F_BIOS_SD_BUSY F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.6 F_BIOS_DISK_WRITE_SEC

Action	Writes a Sector (512 bytes), from the DISK_BUFFER_START into the DISK
Entry	E = sector address LBA 0 (bits 0-7) D = sector address LBA 1 (bits 8-15) C = sector address LBA 2 (bits 16-23) B = sector address LBA 3 (bits 24-27) BC are not used (set to zero), because max sector is 65,535
Exit	DISK_BUFFER_START contains the 512 bytes written
Destroys	A, HL, DISK_BUFFER_START
Calls	F_BIOS_SD_BUSY F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.7 F_BIOS_FDD_BUSY_WAIT

Action	Calls ASMDC to check if the FDD is busy, and loops until it is not busy.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.8 F_BIOS_FDD_CHANGE

Action	Tells the ASMDC that the current DISK for operations is now the FDD .
Entry	None
Exit	DISK_status is updated
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B

3.4.9 F_BIOS_FDD_LOWLVL_FORMAT

Action	Tells the ASMDC to low-level format a DISK in the FDD . This function does not set up any file system. It just fills with 0xF6 all bytes of all sectors.
Entry	None
Exit	A = 0x00 if everything OK. Bit 2 set if command resulted in error.
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.10 F_BIOS_FDD_MOTOR_ON

Action	Tells the ASMDC to switch the FDD motor on. It is a recommended practice to switch the motor on and off manually if multiple sectors are to read or written.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B

3.4.11 F_BIOS_FDD_MOTOR_OFF

Action	Tells the ASMDC to switch the FDD motor off. It is a recommended practice to switch the motor on and off manually if multiple sectors are to read or written.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B

3.4.12 F_BIOS_FDD_CHECK_DISKIN

Action	Asks the ASMDC to check if a Floppy Disk is inside the FDD .
Entry	None
Exit	A = 0x00 yes / 0xFF no
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.4.13 F_BIOS_FDD_CHECK_WPROTECT

Action	Asks the ASMDC to check if the Floppy Disk is write protected.
Entry	None
Exit	A = 0x00 yes / 0xFF no
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.5 Real-Time Clock Routines

3.5.1 F_BIOS_RTC_GET_TIME

Action	Gets the current time from the ASMDC , and stores hour, minutes and seconds as hexadecimal values in SYSVAR s.
Entry	None
Exit	RTC_hour, RTC_minutes, RTC_seconds
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.5.2 F_BIOS_RTC_GET_DATE

Action	Gets the current date from the ASMDC , and stores day, month, year and day of the week as hexadecimal values in SYSVAR s.
Entry	None
Exit	RTC_day, RTC_month, RTC_year, RTC_day_of_the_week
Destroys	A, HL
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.5.3 F_BIOS_RTC_SET_TIME

Action	Tells ASMDC to store a new hour, minutes and seconds.
Entry	RTC_hour, RTC_minutes, RTC_seconds
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B

3.5.4 F_BIOS_RTC_SET_DATE

Action	Tells ASMDC to store a new day, month, year and day of the week.
Entry	RTC_day, RTC_month, RTC_year, RTC_day_of_the_week
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B

3.5.5 F_BIOS_CHECK_BATTERY

Action	Asks the ASMDC if the battery is healthy or has to be replaced.
Entry	None
Exit	A = 0x0A (Healthy) / 0x00 (Dead)
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.6 NVRAM Routines

3.6.1 F_BIOS_NVRAM_DETECT

Action	Asks the ASMDC if the NVRAM is present.
Entry	None
Exit	length (in bytes) of the NVRAM , or 0xFF if not detected.
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_B F_BIOS_SERIAL_CONIN_B

3.7 VDP Routines

3.7.1 F_BIOS_VDP_SET_ADDR_WR

Action	Set a VRAM address for writting.
Entry	HL = address to be set
Exit	None
Destroys	C, H
Calls	None

3.7.2 F_BIOS_VDP_SET_ADDR_RD

Action	Set a VRAM address for reading.
Entry	HL = address to be read
Exit	None
Destroys	A, C
Calls	None

3.7.3 F_BIOS_VDP_SET_REGISTER

Action	Set a value to a VDP register.
Entry	A = register number, B = value to set
Exit	None
Destroys	C
Calls	None

3.7.4 F_BIOS_VDP_EI

Action	Enable VDP Interrupts. This is independent of the value (bit 5) in the VDP Register 1 . What this does is that the NMI subroutine reads the VDP Status Register again in each run, and therefore it does allow more interrupts to happen.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_VDP_READ_STATREG

3.7.5 F_BIOS_VDP_DI

Action	Disable VDP Interrupts. This is independent of the value (bit 5) in the VDP Register 1 . What this does is that the NMI subroutine does not read the VDP Status Register anymore, and therefore does not allow more interrupts to happen. IMPORTANT: Disabling VDP Interrupts will stop the Jiffy Counter .
Entry	None
Exit	None
Destroys	A
Calls	None

3.7.6 F_BIOS_VDP_READ_STATREG

Action	Read the read-only VDP Status Register . IMPORTANT: Reading the VDP Status Register clears (acknowledges) the VDP Interrupt. This is already done by the BIOS' NMI subroutine, so this function MUST not be used, unless NMI subroutines have been disabled with F_BIOS_VDP_DI
Entry	None
Exit	A = Status Register byte.
Destroys	A, C
Calls	None

3.7.7 F_BIOS_VDP_VRAM_CLEAR

Action	Set all cells of the VRAM (0x0000- 0x3FFF) to zero.
Entry	None
Exit	None
Destroys	A, BC, D, HL
Calls	F_BIOS_VDP_SET_ADDR_WR

3.7.8 F_BIOS_VDP_VRAM_TEST

Action	Set a value to each VRAM cell and then reads it back. If the value is not the same, something went wrong.
Entry	None
Exit	C Flag set if an error occurred.
Destroys	A, BC, D, HL
Calls	F_BIOS_VDP_SET_ADDR_WR F_BIOS_VDP_SET_ADDR_RD

3.7.9 F_BIOS_VDP_SET_MODE_G2

Action	Set VDP to <i>Graphics II Bit-mapped Mode</i> display.
Entry	None
Exit	None
Destroys	A, BC, D, HL
Calls	F_BIOS_VDP_SET_ADDR_WR F_BIOS_VDP_SET_REGISTER

3.7.10 F_BIOS_VDP_SHOW_DZ_LOGO

Action	Show dastaZ80 logo on the Low Resolution Display .
Entry	None
Exit	None
Destroys	A, BC, DE, HL, IX
Calls	F_BIOS_VDP_SET_ADDR_WR

3.7.11 F_BIOS_VDP_BYTE_TO_VRAM

Action	Writes a byte to currently pointed VRAM cell.
Entry	A = byte to be written.
Exit	None
Destroys	C
Calls	None

3.7.12 F_BIOS_VDP_VRAM_TO_BYTE

Action	Read a byte from VRAM .
Entry	None
Exit	A = read byte.
Destroys	A, C
Calls	None

3.7.13 F_BIOS_VDP_JIFFY_COUNTER

Action	Increments the Jiffy Counter .
Entry	None
Exit	None
Destroys	A, IX, VDP_jiffy_byte1, VDP_jiffy_byte2, VDP_jiffy_byte3
Calls	None

3.7.14 F_BIOS_VDP_VBLANK_WAIT

Action	Test <i>Status Register</i> for <i>Interrupt Flag</i> (0x80) and loop until flag is raised.
Entry	None
Exit	None
Destroys	A
Calls	F_BIOS_VDP_READ_STATREG

3.7.15 F_BIOS_VDP_LDIR_VRAM

Action	Block transfer from RAM to VRAM .
Entry	BC = Block length (total number of bytes to copy) HL = Start address of VRAM DE = Start address of RAM
Exit	None
Destroys	A, BC, DE, HL, tmp_byte
Call	F_KRN_DIV1616 F_BIOS_VDP_SET_ADDR_WR F_BIOS_VDP_BYTE_TO_VRAM

3.7.16 F_BIOS_VDP_CHAROUT_ATXY

Action	Print a character in the Low Resolution display , at the <i>VDP_cursor_X</i> , <i>VDP_cursor_Y</i> position.
Entry	A = Character to be printed, in Hexadecimal ASCII.
Exit	None
Destroys	A, BC, DE, HL, IX, VDP_cursor_x, VDP_cursor_y
Call	F_BIOS_VDP_SET_ADDR_WR F_BIOS_VDP_BYTE_TO_VRAM

3.8 Dual Joystick Routines

3.8.1 F_BIOS_JOYS_GET_STAT

Action	Get status of Joysticks.
Entry	A = Joystick Port to get status from (1=JOY1, 2=JOY2).
Exit	A 0x00 = None 0x01 = Up 0x02 = Down 0x04 = Left 0x08 = Right 0x10 = Fire
Destroys	A, C
Calls	None

4 Kernel Jumpblocks

4.1 General Routines

4.1.1 F_KRN_SYSHALT

Action	Prepares the computer for a <i>HALT</i> .
Entry	None.
Exit	None
Destroys	A, HL
Calls	F_BIOS_SD_PARK_DISKS F_KRN_SERIAL_WRSTRCLR

4.2 Serial Routines

4.2.1 F_KRN_SERIAL_SETFGCOLR

Action	Set the colour that will be used for the foreground (text). The colour will remain until a different one is set.
Entry	A = Colour number (as listed in Appendixes section)
Exit	None
Destroys	B, DE
Calls	F_BIOS_SERIAL_CONOUT_A <i>jp</i> F_KRN_SERIAL_SEND_ANSI_CODE

4.2.2 F_KRN_SERIAL_WRSTR

Action	Outputs a string, terminated with Carriage Return to the CONSOLE .
Entry	HL = address in MEMORY where the first character of the string to be output is.
Exit	None
Destroys	A, HL
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.3 F_KRN_SERIAL_WRSTRCLR

Action	Outputs a string, terminated with Carriage Return to the CONSOLE , with a specific foreground colour.
Entry	A = Colour number (as listed in Appendixes section) HL = address in MEMORY where the first character of the string to be output is.
Exit	None
Destroys	B, DE
Calls	F_KRN_SERIAL_SETFGCOLR <i>jp</i> F_KRN_SERIAL_WRSTR

4.2.4 F_KRN_SERIAL_WR6DIG_NOLZEROS

Action	Outputs to the CONSOLE a string of ASCII characters representing a number, without outputting the leading zeros. (.e.g. 30 30 31 32 30 34 is 001204, but the output will be 1024)
Entry	IX = address in MEMORY where the ASCII characters are stored.
Exit	None
Destroys	A, B, DE, IX
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.5 F_KRN_SERIAL_RDCHARECHO

Action	Reads with echo. Reads a character from the SIO/2 Channel A, and outputs it to the CONSOLE .
Entry	None
Exit	A = read character.
Destroys	None
Calls	F_BIOS_SERIAL_CONIN_A F_BIOS_SERIAL_CONOUT_A

4.2.6 F_KRN_SERIAL_EMPTYLINES

Action	Outputs <i>n</i> number of empty lines to the CONSOLE .
Entry	B = number (<i>n</i>) of empty lines to output.
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.7 F_KRN_SERIAL_PRN_NIBBLE

Action	Outputs a single hexadecimal nibble in hexadecimal notation.
Entry	A = nibble to output. Nibble will be the less significant 4 bits of the byte.
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.8 F_KRN_SERIAL_PRN_BYTE

Action	Outputs a single hexadecimal byte in hexadecimal notation.
Entry	A = byte to output.
Exit	None
Destroys	A
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.9 F_KRN_SERIAL_PRN_BYTES

Action	Outputs n number of bytes as ASCII characters.
Entry	B = number (n) of bytes to output. HL = address in MEMORY where the first byte to output is.
Exit	None
Destroys	A, HL
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.10 F_KRN_SERIAL_PRN_WORD

Action	Outputs the 4 hexadecimal digits of a word in hexadecimal notation.
Entry	HL = word to be output.
Exit	None
Destroys	A
Calls	F_KRN_SERIAL_PRN_BYTE

4.2.11 F_KRN_SERIAL_SEND_ANSI_CODE

Action	Writes an ANSI code to the SIO/2 Channel A.
Entry	DE = address in MEMORY where the first byte of ANSI escape code is. B = number of bytes in the ANSI escape code.
Exit	None
Destroys	A, DE
Calls	F_BIOS_SERIAL_CONOUT_A

4.2.12 F_KRN_SERIAL_CLR_SIOCHA_BUFFER

Action	Clear (sets to zeros) the SIO Channel A Buffer.
Entry	None
Exit	None
Destroys	A, B, HL, SIO_CHA_BUFFER_USED, SIO_CHA_IN_PTR, SIO_CHA_RD_PTR
Calls	None

4.3 DZFS (file system) Routines

4.3.1 F_KRN_DZFS_READ_SUPERBLOCK

Action	Reads 512 bytes from Sector 0 (corresponding to the DZFS <i>Superblock</i>) into the disk buffer in MEMORY . If the <i>Superblock</i> does not contain the correct DZFS signature, <code>DISK_is_formatted</code> is set to 0x00. Otherwise, is set to 0x01.
Entry	None
Exit	None
Destroys	A, DE, <code>DISK_is_formatted</code>
Calls	F_BIOS_SD_READ_SEC

4.3.2 F_KRN_DZFS_READ_BAT_SECTOR

Action	Reads a BAT Sector from DISK into MEMORY .
Entry	<code>DISK_cur_sector</code> holds the sector number for the BAT.
Exit	<code>DISK Buffer</code> contains the BAT sector.
Destroys	HL
Calls	F_KRN_DZFS_SEC_TO_BUFFER

4.3.3 F_KRN_DZFS_BATENTRY_TO_BUFFER

Action	Extracts the data of a BAT entry from the <code>DISK Buffer</code> in MEMORY and populates the values into System variables.
Entry	A = BAT entry number to extract data from.
Exit	<code>DISK BAT System Variables</code> are populated. See RAM Memory Map for details.
Destroys	A, BC, DE, HL, IX, <code>tmp_addr1</code>
Calls	F_KRN_MULTIPLY816_SLOW

4.3.4 F_KRN_DZFS_SEC_TO_BUFFER

Action	Loads a Sector (512 bytes) from the DISK and copies the bytes into the <code>DISK Buffer</code> in MEMORY .
Entry	HL = Sector number to load.
Exit	<code>DISK Buffer</code> contains the bytes of Sector loaded.
Destroys	DE, HL
Calls	F_BIOS_SD_READ_SEC

4.3.5 F_KRN_DZFS_GET_FILE_BATENTRY

Action	Gets the BAT's entry number of a specified filename.
Entry	HL = Address where the filename to check is stored
Exit	BAT Entry values are stored in the SYSVARS. DE = \$0000 if filename found. Otherwise, whatever value had at start.
Destroys	A, B, DE, HL, tmp_byte, tmp_addr2, tmp_addr3
Calls	F_KRN_DZFS_SEC_TO_BUFFER F_KRN_DZFS_BATENTRY_TO_BUFFER F_KRN_STRLENMAX F_KRN_STRCMP

4.3.6 F_KRN_DZFS_LOAD_FILE_TO_RAM

Action	Load a file from DISK . Copies the bytes stored in the DISK into MEMORY , at the specified MEMORY address in the BAT.
Entry	DE = 1st sector number in the DISK . IX = file length in sectors.
Exit	None
Destroys	BC, DE, HL, IX, tmp_addr1
Calls	F_BIOS_SD_READ_SEC

4.3.7 F_KRN_DZFS_DELETE_FILE

Action	Marks a file as deleted. The mark is done by changing the first character of the filename to 0x7E (~)
Entry	DE = BAT Entry number.
Exit	None
Destroys	A, DE, HL,
Calls	F_KRN_MULTIPLY816_SLOW F_KRN_DZFS_SECTOR_TO_SD

4.3.8 F_KRN_DZFS_CHGATTR_FILE

Action	Changes the attributes (RHSE) of a file.
Entry	DE = BAT Entry number. A = attributes mask byte.
Exit	None
Destroys	DE, HL,
Calls	F_KRN_MULTIPLY816_SLOW F_KRN_DZFS_SECTOR_TO_SD

4.3.9 F_KRN_DZFS_RENAME_FILE

Action	Changes the name of a file.
Entry	<p>IY = MEMORY address where the new filename is stored.</p> <p>DE = BAT Entry number.</p>
Exit	None
Destroys	A, BC, DE, HL, IY
Calls	F_KRN_MULTIPLY816_SLOW F_KRN_DZFS_SECTOR_TO_SD

4.3.10 F_KRN_DZFS_FORMAT_DISK

Action	Formats a DISK with DZFS.
Entry	HL = MEMORY address where the disk label is stored.
Exit	None
Destroys	A, BC, DE, HL, IX, IY, tmp_addr1, tmp_byte
Calls	F_KRN_SERIAL_WRSTR F_KRN_DZFS_CALC_SN F_KRN_RTC_GET_DATE F_BIOS_RTC_GET_TIME F_KRN_BCD_TO_ASCII F_KRN_BIN_TO_BCD4 F_KRN_BIN_TO_BCD6 F_KRN_DZFS_SECTOR_TO_SD F_KRN_SETMEMRNG F_BIOS_SERIAL_CONOUT_A F_BIOS_SD_PARK_DISKS F_BIOS_SD_MOUNT_DISKS

4.3.11 F_KRN_DZFS_CALC_SN

Action	Calculates the Serial Number (4 bytes) for a DISK .
Entry	IX = MEMORY address where the serial number will be stored.
Exit	None
Destroys	A, BC, DE, HL, IX
Calls	F_BIOS_RTC_GET_DATE F_BIOS_RTC_GET_TIME F_KRN_MULTIPLY816_SLOW

4.3.12 F_KRN_DZFS_SECTOR_TO_DISK

Action	Calls the BIOS subroutine that will store the data (512 bytes) currently in DISK Buffer in MEMORY , to the DISK .
Entry	DISK_cur_sector = the sector number in the DISK that will be written.
Exit	None
Destroys	BC, DE
Calls	F_BIOS_SD_WRITE_SEC

4.3.13 F_KRN_DZFS_GET_BAT_FREE_ENTRY

Action	Get number of available BAT entry.
Entry	None
Exit	DISK_cur_file_entry_number = entry number.
Destroys	A, IY, CF_cur_sector, CF_cur_file_entry_number
Calls	F_KRN_DZFS_READ_BAT_SECTOR F_KRN_DZFS_BATENTRY_TO_BUFFER

4.3.14 F_KRN_DZFS_ADD_BAT_ENTRY

Action	Adds a BAT entry into the DISK .
Entry	DE = BAT entry number. DISK_cur_sector = Sector number where the BAT Entry is in the DISK . DISK_BUFFER_START = Sector (512 bytes) containing the BAT where the entry is. DISK BAT = BAT Entry data that will be saved to DISK .
Exit	None
Destroys	A, BC, DE, HL
Calls	F_KRN_MULTIPLY816_SLOW

4.3.15 F_KRN_DZFS_CREATE_NEW_FILE

Action	Creates a new file (and its corresponding BAT Entry) in the DISK , from bytes stored in MEMORY .
Entry	HL = MEMORY address of the first byte to be stored. BC = number of bytes to be stored in the DISK . IX = MEMORY address where the filename is stored.
Exit	None
Destroys	A, BC, DE, HL, IX, tmp_addr1, tmp_addr2, tmp_addr3, tmp_byte
Calls	F_KRN_DZFS_GET_BAT_FREE_ENTRY F_KRN_DIV1616 F_KRN_MULTIPLY1616 F_KRN_COPYMEM512 F_KRN_CLEAR_MEMAREA F_KRN_CLEAR_DISKBUFFER F_KRN_DZFS_SECTOR_TO_SD F_BIOS_SD_BUSY_WAIT F_KRN_SERIAL_WRSTRCLR F_KRN_DZFS_CALC_FILETIME F_KRN_DZFS_CALC_FILEDATE F_KRN_DZFS_SEC_TO_BUFFER F_KRN_DZFS_ADD_BAT_ENTRY

4.3.16 F_KRN_DZFS_CALC_FILETIME

Action	Packs current Real-Time Clock time into two bytes, which is the format used to store times (created/modified) for files in the DISK . The formula used is: $2048 * hours + 32 * minutes + seconds/2$
Entry	None
Exit	HL = RTC time
Destroys	A, DE, HL
Calls	F_BIOS_RTC_GET_TIME

4.3.17 F_KRN_DZFS_CALC_FILEDATE

Action	Packs current Real-Time Clock date into two bytes, which is the format used to store dates (created/modified) for files in the DISK . The formula used is: $512 * (year - 2000) + month * 32 + day$
Entry	None
Exit	HL = RTC date
Destroys	A, DE, HL
Calls	F_BIOS_RTC_GET_DATE

4.3.18 F_KRN_DZFS_SHOW_DISKINFO_SHORT

Action	Outputs to the CONSOLE some information of the DISK : volume label, serial number, date/time creation.
Entry	None
Exit	None
Destroys	A, BC, DE, HL
Calls	F_KRN_SERIAL_WRSTRCLR F_KRN_SERIAL_PRN_BYTE F_KRN_SERIAL_PRN_BYTES F_BIOS_SERIAL_CONOUT_A F_KRN_SERIAL_EMPTYLINES

4.3.19 F_KRN_DZFS_SHOW_DISKINFO

Action	Outputs to the CONSOLE all information of the DISK : volume label, serial number, date/time creation, file system ID, number of partitions, number of bytes per sector, number of sectors per block.
Entry	None
Exit	None
Destroys	A, BC, DE, HL, tmp_addr1
Calls	F_KRN_DZFS_SHOW_DISKINFO_SHORT F_KRN_SERIAL_WRSTRCLR F_KRN_SERIAL_PRN_BYTE F_KRN_SERIAL_PRN_BYTES F_BIOS_SERIAL_CONOUT_A F_KRN_SERIAL_EMPTYLINES

4.3.20 F_KRN_DZFS_CHECK_FILE_EXISTS

Action	Checks if a specified filename exists in the DISK . The filename MUST be terminated by a zero.
Entry	HL = MEMORY address where the filename to check is stored.
Exit	Z Flag set if filename is not found.
Destroys	A, DE, tmp_addr3
Calls	F_KRN_DZFS_GET_FILE_BATENTRY

4.4 Math Routines

4.4.1 F_KRN_MULTIPLY816_SLOW

Action	Multiplies an 8-bit number by a 16-bit number (HL = A * DE). It does a slow multiplication by adding the multiplier to itself as many times as multiplicand (e.g. 8 * 4 = 8+8+8+8).
Entry	A = Multiplicand DE = Multiplier
Exit	HL = Product
Destroys	B, HL
Calls	None

4.4.2 F_KRN_MULTIPLY1616

Action	Multiplies two 16-bit numbers (HL = HL * DE)
Entry	HL = Multiplicand DE = Multiplier
Exit	HL = Product
Destroys	A, BC, DE, HL
Calls	None

4.4.3 F_KRN_DIV1616

Action	Divides two 16-bit numbers (BC = BC / DE, HL = remainder)
Entry	BC = Dividend DE = Divisor
Exit	BC = Quotient HL = Remainder
Destroys	A, BC, HL
Calls	None

4.4.4 F_KRN_CRC16.INI

Action	Initialises the CRC to 0 and the polynomial to the appropriate bit pattern, to generate a CRC-16/BUYPASS1 ³ .
Entry	None
Exit	MATH_CRC = 0 (initial CRC value) MATH_polynomial = CRC polynomial
Destroys	HL
Calls	None

4.4.5 F_KRN_CRC16.GEN

Action	Combines the previous CRC with the CRC generated from the current data byte, to generate a CRC-16/BUYPASS1 ⁴ .
Entry	A = current data byte. MATH_CRC = previous CRC MATH_polynomial = CRC polynomial
Exit	MATH_CRC = CRC with current data byte included
Destroys	A, BC, DE, HL
Calls	None

4.5 String manipulation Routines

4.5.1 F_KRN_IS_PRINTABLE

Action	Checks if a character is a printable ASCII character.
Entry	A = character to check.
Exit	C Flag is set if character is printable.
Destroys	None
Calls	None

4.5.2 F_KRN_IS_NUMERIC

Action	Checks if a character is numeric (0, 1, 2, 3, 4, 5, 6, 7, 8 or 9).
Entry	A = character to check.
Exit	C Flag is set if character is numeric.
Destroys	None
Calls	None

4.5.3 F_KRN_TOUPPER

Action	Converts a charcater to uppercase (e.g. <i>a</i> is converted to <i>A</i>).
Entry	A = character to convert.
Exit	A = uppercased character.
Destroys	None
Calls	None

4.5.4 F_KRN_STRCMP

Action	Compares two strings.
Entry	A = length of string 1. HL = MEMORY address where the first byte of string 1 is located. B = length of string 2. DE = MEMORY address where the first byte of string 2 is located.
Exit	if str1 = str 2, Z Flag set and C Flag not set. if str1 != str 2 and str1 longer than str2, Z Flag not set and C Flag not set. if str1 != str 2 and str1 shorter than str2, Z Flag not set and C Flag set.
Destroys	A, BC, DE,HL
Calls	None

4.5.5 F_KRN_STRCPY

Action	Copies <i>n</i> characters from string 1 to string 2.
Entry	HL = MEMORY address where the first byte of string 1 is located. DE = MEMORY address where the first byte of string 2 is located. B = number of characters to copy.
Exit	None
Destroys	A, DE, HL
Calls	None

4.5.6 F_KRN_STRLEN

Action	Gets the length of a string that is terminated with a specified character.
Entry	HL = MEMORY address where the first byte of the string is located. A = terminating character.
Exit	B = length of the string.
Destroys	BC, HL
Calls	None

4.5.7 F_KRN_STRLENMAX

Action	Gets the length of a string that is terminated with a specified character, but only check up to a maximum of characters.
Entry	HL = MEMORY address where the first byte of the string is located. A = terminating character. B = maximum length to be checked.
Exit	B = length of the string.
Destroys	BC, DE, HL
Calls	None

4.5.8 F_KRN_INSTR

Action	Locates the first occurrence of a character within a string.
Entry	HL = MEMORY address where the first byte of the string is located. B = character to search in string. D = terminating character.
Exit	E = position of character in string. Carry Flag = Set if character was found.
Destroys	A, C, E
Calls	None

4.6 Conversion Routines

4.6.1 F_KRN_ASCIIADR_TO_HEX

Action	Convert an address (or any 2 bytes) from hex ASCII to its hexadecimal value (e.g. 32 35 37 30 are converted into 2570).
Entry	IX = MEMORY address where the first byte is located.
Exit	HL = hexadecimal converted value.
Destroys	HL
Calls	F_KRN_ASCII_TO_HEX

4.6.2 F_KRN_ASCII_TO_HEX

Action	Converts two ASCII characters (representing two hexadecimal digits) ; to one byte in hexadecimal (e.g. 0x33 and 0x45 are converted into 3E).
Entry	H = Most significant ASCII digit. L = Less significant ASCII digit.
Exit	A = Converted value.
Destroys	A, BC
Calls	None

4.6.3 F_KRN_HEX_TO_ASCII

Action	Converts one byte in hexadecimal to two ASCII printable characters (e.g. 0x3E is converted into 33 and 45, which are the ASCII values of 3 and E).
Entry	A = Byte to convert.
Exit	H = Most significant ASCII digit. L = Less significant ASCII digit.
Destroys	A, BC, HL
Calls	None

4.6.4 F_KRN_BCD_TO_BIN

Action	Converts a byte of BCD to a byte of hexadecimal (e.g. 12 is converted into 0x0C).
Entry	A = BCD.
Exit	A = Hexadecimal.
Destroys	A, BC
Calls	None

4.6.5 F_KRN_BIN_TO_BCD4

Action	Converts a byte of unsigned integer hexadecimal to 4-digit BCD (e.g. 0x80 is converted into 0128).
Entry	A = Unsigned integer to convert.
Exit	H = Hundreds digits. L = Tens digits.
Destroys	A, BC, HL
Calls	None

4.6.6 F_KRN_BIN_TO_BCD6

Action	Converts two bytes of unsigned integer hexadecimal to 6-digit BCD (e.g. 0xFFFF is converted into 065535).
Entry	HL = Unsigned integer to convert.
Exit	C = Thousands digits. D = Hundreds digits. E = Tens digits.
Destroys	A, BC, DE, HL
Calls	None

4.6.7 F_KRN_BCD_TO_ASCII

Action	Converts 6-digit BCD to hexadecimal ASCII string (e.g. 512 is converted into 30 30 30 35 31 32).
Entry	DE = MEMORY address where the converted string will be stored. C = first two digits of the 6-digit BCD to convert. H = next two digits of the 6-digit BCD to convert. L = last two digits of the 6-digit BCD to convert.
Exit	None
Destroys	A, DE
Calls	None

4.6.8 F_KRN_BITEXTRACT

Action	Extracts a group of bits from a byte and returns the group in the LSB position.
Entry	E = byte from where to extract bits. D = number of bits to extract. A = start extraction at bit number.
Exit	A = extracted group of bits
Destroys	A, BC, DE, HL
Calls	None

4.6.9 F_KRN_BIN_TO_ASCII

Action	Converts a 16-bit signed binary number (-32768 to 32767) to ASCII data (e.g. 32767 is converted into 33 32 37 36 37).
Entry	D = High byte of value to convert. E = Low byte of value to convert.
Exit	CLI_buffer_pgm = converted ASCII data. First byte us the length.
Destroys	A, BC, DE, HL, CLI_buffer_pgm
Calls	None

4.6.10 F_KRN_DEC_TO_BIN

Action	Converts an ASCII string consisting of the length of the number (in bytes), a possible ASCII - or + sign, and a series of ASCII digits to two bytes of binary data. Note that the length is an ordinary binary number, not an ASCII number. (e.g. 33 32 37 36 37 is converted into 7FFF).
Entry	HL = MEMORY address where the string to be converted is.
Exit	HL = converted bytes.
Destroys	A, BC, DE, HL, tmp_byte
Calls	None

4.6.11 F_KRN_PKEDDATE_TO_DMY

Action	Extracts day, month and year from a packed date (used by DZFS to store dates).
Entry	HL = packed date.
Exit	A = day. B = month. C = year.
Destroys	A, BC, HL, tmp_addr1
Calls	None

4.6.12 F_KRN_PKEDTIME_TO_HMS

Action	Extracts hour, minutes and seconds from a packed time (used by DZFS to store times).
Entry	HL = packed time.
Exit	A = hour. B = minutes. C = seconds.
Destroys	A, BC, HL, tmp_addr1
Calls	None

4.7 MEMORY Routines

4.7.1 F_KRN_SETMEMRNG

Action	Sets (changes) a value in a MEMORY position range.
Entry	HL = MEMORY start position (first byte). BC = number of bytes to set. A = value to set.
Exit	None
Destroys	BC, HL
Calls	None

4.7.2 F_KRN_COPYMEM512

Action	Copies bytes from one area of MEMORY to another, in group of 512 bytes (i.e. max. 512 bytes). If less than 512 bytes are to be copied, the rest will be filled with zeros.
Entry	HL = MEMORY origin position (from where to copy the bytes). DE = MEMORY destination position (to where to copy the bytes). BC = number of bytes to copy (MUST be less or equal to 512).
Exit	None
Destroys	A, BC, DE, HL
Calls	None

4.7.3 F_KRN_SHIFT_BYTES_BY1

Action	Moves bytes (by one) to the right and replaces first byte with bytes counter.
Entry	HL = MEMORY address of last byte to move. BC = number of bytes to move.
Exit	None
Destroys	A, DE, HL
Calls	None

4.7.4 F_KRN_CLEAR_MEMAREA

Action	Clears (with zeros) a number of bytes, starting at a specified MEMORY address. Maximum 256 bytes can be cleared.
Entry	IX = MEMORY address of first byte to clear. B = number of bytes to clear.
Exit	None
Destroys	A, BC, IX
Calls	None

4.7.5 F_KRN_CLEAR_DISKBUFFER

Action	Clears (with zeros) the MEMORY area of the DISK buffer.
Entry	None
Exit	None
Destroys	BC, IX
Calls	F_KRN_CLEAR_MEMAREA

4.8 Real-Time Clock Routines

4.8.1 F_KRN_RTC_GET_DATE

Action	Calls the BIOS function to get date from the RTC, and then calculates the year in four digits.
Entry	None
Exit	RTC_year4
Destroys	A, DE, HL
Calls	None F_KRN_MULTIPLY816_SLOW

4.8.2 F_KRN_RTC_SHOW_TIME

Action	Sends to the Serial Channel A the values of hour, minutes and seconds from SYSVARS, as hh:mm:ss
Entry	None
Exit	None
Destroys	A, BC, DE, tmp_addr1
Calls	F_KRN_BIN_TO_BCD4 F_KRN_BCD_TO_ASCII F_BIOS_SERIAL_CONOUT_A

4.8.3 F_KRN_RTC_SHOW_DATE

Action	Sends to the Serial Channel A the values of day, month, year (4 digits) and day of the week (3 letters) from SYSVARS, as dd/mm/yyyy www
Entry	None
Exit	None
Destroys	A, BC, DE, tmp_addr1
Calls	F_KRN_BIN_TO_BCD4 F_KRN_BIN_TO_BCD6 F_KRN_BCD_TO_ASCII F_BIOS_SERIAL_CONOUT_A

4.8.4 F_KRN_RTC_SET_TIME

Action	Converts ASCII values to Hexadecimal, RTC_hour, RTC_minutes, RTC_seconds and calls the BIOS function to change time via ASMDC .
Entry	IX = MEMORY address where the new time is stored in ASCII format.
Exit	None
Destroys	A, HL, RTC_hour, RTC_minutes, RTC_seconds
Calls	F_KRN_ASCII_TO_HEX F_KRN_BCD_TO_BIN F_BIOS_RTC_SET_TIME

4.8.5 F_KRN_RTC_SET_DATE

Action	Converts ASCII values to Hexadecimal, RTC_year, RTC_month, RTC_day, RTC_day_of_the_week, and calls the BIOS function to change date via ASMDC .
Entry	IX = MEMORY address where the new date is stored in ASCII format.
Exit	None
Destroys	A, HL, RTC_year, RTC_month, RTC_day, RTC_day_of_the_week
Calls	F_KRN_ASCII_TO_HEX F_KRN_BCD_TO_BIN F_BIOS_RTC_SET_DATE

5 dastaZ80 File System (DZFS)

In summary, a file system is a layer of abstraction to store, retrieve and update a set of files.

A file system manages access to the data and the metadata of the files, and manages the available space of the device, dividing the storage area into units of storage and keeping a map of every storage unit of the device.

DZFS main goal is to be very simple to implement. As the free **MEMORY** (i.e. **RAM** - OS - System variables and buffers) of the dastaZ80 is about 55,952 bytes, it makes no sense to have files bigger than that, as will not fit. Therefore, DZFS defines that *a Block can store only a single file*.

dastaZ80 access the **DISK** via Logical Block Addressing (LBA), which is a particularly simple linear addressing schema, in which each sector is assigned a unique number rather than referring to a cylinder, head, and sector (CHS) to access the disk.

A typical LBA scheme uses a 28-bit value that allows up to 8.4 GB of data storage capacity. DZFS schema is as follows:

LBA 3	LBA 2	LBA 1	LBA 0
XXXX	XXXX XXXX	BBBB BBBB	BBSS SSSS

Where:

- S is Sector (6 bits)
- B is Block (10 bits)
- X not used (12 bits)

5.1 DZFS characteristics

- **Bytes per Sector:** 512
- **Sectors per Block:** 64
- **Bytes per Block:** 32,768 (64 * 512). This also defines the maximum size of a file and the BAT maximum size.
- **Bytes per BAT entry:** 32
- **BAT entries:** 1024 (32,768 / 32). This also defines the maximum number of files per **DISK**.
- **Maximum bytes per File:** 1 Block (32,768 bytes)
- **Maximum bytes per DISK:** 1024 Blocks (1 Block = 1 File) * 32,768 bytes per Block = 33,554,432 bytes (33.5 MB)

5.2 DISK anatomy

A **DISK** is divided into areas:

- **Superblock** = 512 bytes (1 Sector)
- **Block Allocation Table (BAT)** = 1 Block (64 Sectors = 32,768 bytes)
- **Data Area** = 1023 Blocks (65,472 Sectors = 33,521,664 bytes)

5.2.1 Superblock

The first 512 bytes on the **DISK** contain fundamental information about the geometry, and is used by the OS to know how to access every other information on the **DISK**. On IBM PC-compatibles, this is known as the *Master Boot Record* or *MBR* for short. In DZFS, it is called *Superblock*, as it is an orphan sector that doesn't belong to any block.

Offset	Length (bytes)	Description	Example
0x00	2	Signature. Used to check that this is a Superblock. Set to 0xABBA	AB BA
0x02	1	Not used	00
0x03	8	File System Identifier. ASCII values for human-readable. Padded with spaces.	DZFSV1
0x0B	4	Volume Serial Number	35 2A 15 F2
0x0F	1	Not used.	00
0x10	16	Volume Label. ASCII values. Padded with spaces.	dastaZ80 Main
0x20	8	Volume Date Creation. ASCII values (ddmmyyyy).	03102022
0x28	6	Volume Time Creation. ASCII values (hhmmss).	142232
0x2E	2	Bytes per Sector (in Hexadecimal little-endian)	00 02
0x30	1	Sectors per Block (in Hexadecimal)	40
0x31	1	Not used.	00
0x32 - 0x64	51	Copyright notice (ASCII value)	Copyright 2022David Asta The MIT License (MIT)

Offset	Length (bytes)	Description	Example
0x65 0x1FF	- 411	Not used (filled with 0x00)	00 00 00 00 00 00 00

5.2.2 Block Allocation Table (BAT)

The BAT is an area of 32 bytes on the **DISK** used to store the details about the files saved in the Data Area, and is comprised of file descriptors called *entry*. Each entry holds information about a single file.

For simplicity, each entry works also as index. The first entry describes the first file on the **DISK**, the second entry describes the second file, and so on.

Offset	Length (bytes)	Description	Example
0x00	14	Filename Padded with spaces at the end. (only allowed A to Z and 0 to 9. No spaces allowed. Cannot start with a number.) First character also indicates 00=available, 7E=deleted (will appear as ~)	46 49 4C 45 30 30 30 30 31 20 20 20 20 20
0x0E	14	Attributes (0=Inactive / 1=Active) Bit 0 = Read Only Bit 1 = Hidden Bit 2 = System Bit 3 = Executable Bit 4-7 = File Type (see below)	Read Only, Sys- tem file, Ex- ecutable = 1101 = 0D
0x0F	2	Time created 5 bits for hour (binary number 0-23) 6 bits for minutes (binary number 0-59) 5 bits for seconds (binary number seconds / 2)	F5 9A
0x11	2	Date created 7 bits for year since 2000 (max. is year 2127)	69 1B

Offset	Length (bytes)	Description	Example
		4 bits for month (binary number 0-12) 5 bits for day (binary number 0-31)	
0x13	2	Time last modified (same formula as Time created)	F5 9A
0x15	2	Date last modified (same formula as Date created)	69 1B
0x17	2	File size in bytes (little-endian)	26 00
0x19	1	File size in sectors (little-endian)	01
0x1A	2	Entry number (little-endian)	00 00
0x1C	2	1st Sector (where the file data starts) It is calculated when the file is created. The formula is: $65 + 64 * \text{entry_number}$	41 00
0x1E	2	Load address (The start address little-endian where it will be loaded in RAM)	68 25

Bits 4-7	File Type	Description
0x00	USR	User defined
0x01	EXE	Executable binary
0x02	BIN	Binary (non-executable) data
0x03	BAS	BASIC code
0x04	TXT	Plain ASCII Text file
0x05		Not used
0x06		Not used
0x07		Not used
0x08		Not used
0x09		Not used
0x0A		Not used
0x0B		Not used
0x0C		Not used
0x0D		Not used
0x0E		Not used
0x0F		Not used

5.2.3 Data Area

The Data Area is the area of the **DISK** used to store file data (e.g. programs, documents).

It is divided into Blocks of 64 Sectors each.

5.3 How Volume Serial Number is calculated

Calculated by combining the date and time at the point of format:

- first byte is calculated as follows:
 - day + milliseconds (converted to hexadecimal)
 - e.g. $3 + 50 = 53$ (0x35)
- second byte is calculated as follows:
 - month + seconds (converted to hexadecimal)
 - e.g. $10 + 32 = 42$ (0x2A)
- last two bytes are calculated as follows:
 - (hours [if pm + 12] * 256) + minutes + year (converted to hexadecimal)
 - e.g. $(2 + 12 = 14 * 256 = 3584) + 22 + 2012 = 5618$ (0x150xF2)

5.4 How Dates (creation/last modified) are calculated

Dates (day, month, 4-digit year) are converted into two bytes as follows:

- Remove century from year (e.g. $2013 - 2000 = 13$)
- Convert resulting number to hexadecimal (e.g. $13 = 0x0D$)
- Bitwise Shift Left 9 positions (e.g. $0x0D \ll 9 = 0x1A00$)
- Convert month to hexadecimal (e.g. $11 = 0x0B$)
- Bitwise Shift Left 5 positions (e.g. $0x0B \ll 5 = 0x0160$)
- Add converted month to converted year (e.g. $0x1A00 + 0x0160 = 0x1B60$)
- Convert day to hexadecimal (e.g. $9 = 0x09$)
- Add converted day to the sum of converted month and converted year (e.g. $0x1B60 + 0x09 = 0x1B69$)

5.5 How Times (creation/last modified) are calculated

Times (hours, minutes, seconds) are converted into two bytes as follows:

- Convert hours to hexadecimal (e.g. $19 = 0x13$)
-
- Bitwise Shift Left 3 positions (e.g. $0x13 \ll 3 = 0x98$)

- Convert minutes to hexadecimal (e.g. $23 = 0x17$)
- Bitwise Shift Left 5 positions (e.g. $0x17 \ll 5 = 0x02E0$)
- Logical OR most significant byte (MSB) of converted minutes with less significant byte (LSB) of converted hours (e.g. $0x02 \vee 0x98 = 0x9A$)
- Logical OR LSB of converted minutes with MSB of converted hours (e.g. $0xE0 \vee 0x00 = 0xE0$)
- Convert seconds to hexadecimal (e.g. $42 = 0x2A$)
- Divide the converted seconds by 2 (e.g. $0x2A / 2 = 0x15$)
- Add converted seconds to ORed converted hours and minutes (e.g. $0x9AE0 + 0x15 = 0x9AF5$)

5.6 Block Number, Sector Number and Addresses

To locate files in a Disk Image File it is useful to know how Blocks and Sector Numbers relate to the Address in the disk.

Given a Sector Number (*SecNum*), multiply it by the number of Bytes per Sector (512) to obtain the address where the data will start.

Below is provided a table for quick reference:

Block	SecNum	Address
0	1 (0x0000)	0x00000200
1	65 (0x0041)	0x00008200
2	129 (0x0081)	0x00010200
3	193 (0x00C1)	0x00018200
4	257 (0x0101)	0x00020200
5	321 (0x0141)	0x00028200
6	385 (0x0181)	0x00030200
7	449 (0x01C1)	0x00038200
8	513 (0x0201)	0x00040200
9	577 (0x0241)	0x00048200
10	641 (0x0281)	0x00050200
11	705 (0x02C1)	0x00058200
12	705 (0x0301)	0x00060200
13	833 (0x0341)	0x00068200
14	897 (0x0381)	0x00070200
15	961 (0x03C1)	0x00078200
16	1025 (0x0401)	0x00080200
17	1089 (0x0441)	0x00088200
18	1153 (0x0481)	0x00090200
19	1217 (0x04C1)	0x00098200
20	1281 (0x0501)	0x000A0200
21	1345 (0x0541)	0x000A8200
22	1409 (0x0581)	0x000B0200
23	1473 (0x05C1)	0x000B8200
...
1023	65473 (0xFFC1)	0x01FF8200

6 How To

6.1 Read data from DISK

Given `DISK_is_formatted` is equal to `0xFF` (i.e. **DISK** is formatted with DZFS file system), call `F_KRN_DZFS_LOAD_FILE_TO_RAM` with `DE` equal to first sector (512 bytes) to read and `IX` equal to how many sectors to read.

Read bytes will be copied into **MEMORY**, following these rules:

- if `DISK_loadsave_addr` \neq 0, load bytes to this address.
- if `DISK_loadsave_addr` = 0,
 - if `DISK_cur_file_load_addr` \neq 0, load bytes to this address.
 - if `DISK_cur_file_load_addr` = 0, load bytes to start of Free RAM (0x4420).

6.2 Write data to DISK

Given `DISK_is_formatted` is equal to `0xFF` (i.e. **DISK** is formatted with DZFS file system):

- Store the filename (in ASCII) somewhere in **MEMORY**.
- call `F_KRN_DZFS_GET_FILE_BATENTRY`, with `HL` equal to the **MEMORY** address where the filename is stored. If a file with the specified filename does not exist, flag `z` will be set to indicate that it is OK to save the file.
- call `F_KRN_DZFS_CREATE_NEW_FILE`, with:
 - `HL` equal to the address in **MEMORY** of first byte to be stored.
 - `BC` equal to the total number of bytes to be stored.
 - `IX` equal to the address in **MEMORY** where the filename is stored.
 - `DISK_loadsave_addr` equal to:
 - * zero, will use the address in **MEMORY** of first byte as the load address when loading the file (i.e. `DISK_loadsave_addr`).
 - * non zero, will use this number as the load address when loading the file (i.e. `DISK_loadsave_addr`).

6.3 Convert between HEX and DEC and ASCII

In many situations your programs will need to convert between different number notations (hexadecimal, decimal, ASCII). For example, all charac-

ters typed by the user are read by the function `F_BIOS_SERIAL_CONIN_A`, which stores the ASCII value of the pressed key in the A register. In order to do manipulations of data, our program will need to convert this ASCII data into either hexadecimal or decimal notation.

Take as an example the CLI command for saving files to disk (*save*). As shown in the *dastaZ80 User's Manual* section 5.3 *Disk Commands*, this command takes two parameters: `<start_address>`, which is expressed in hexadecimal, and `<number_of_bytes>`, which is expressed in decimal. But in both cases, `F_BIOS_SERIAL_CONIN_A` will give us (in the A register) the ASCII representation of the numbers typed by the user.

Before we can set a pointer to the memory address specified by `<start_address>`, and set our counter to `<number_of_bytes>`, we need to convert those ASCII numbers into hexadecimal and decimal respectively.

The Kernel, offers a series of functions to help the programmer with the conversions:

- `F_KRN_ASCHIADR_TO_HEX`: Converts ASCII 4 chars to HEX 2 bytes. (e.g. 32 35 37 30 to 0x2570)
- `F_KRN_ASCII_TO_HEX`: Converts ASCII 2 chars to HEX 1 byte. (e.g. 33 45 to 0x3E)
- `KRN_HEX_TO_ASCII`: Converts HEX 1 byte to ASCII 2 chars. (e.g. 0x3E to 33 45)
- `F_KRN_BCD_TO_BIN`: Converts a byte of BCD to a byte of hexadecimal. (e.g. 12 is converted into 0x0C).
- `F_KRN_BIN_TO_BCD4`: Converts HEX 1 byte to DEC 4 digits. (e.g. 0x80 to 0128)
- `F_KRN_BIN_TO_BCD6`: Converts HEX 2 bytes to DEC 6 digits. (e.g. 0xFFFF to 065535)
- `F_KRN_BCD_TO_ASCII`: Converts DEC 6 digits to ASCII 6 chars. (e.g. 512 to 30 30 30 35 31 32)
- `F_KRN_BIN_TO_ASCII`: Converts HEX 2 bytes to ASCII string. (e.g. 0x7FFF to 33 32 37 36 37)
- `F_KRN_DEC_TO_BIN`: Converts HEX 2 bytes to ASCII string. (e.g. 33 32 37 36 37 to 0x7FFF)

6.4 Develop software for dzOS

6.4.1 Available RAM

Programs can be loaded from disk to any area of **RAM**. Nevertheless, addresses below 0x4420 SHOULD not be used, at these contain the Operating System's variables. Modifying these without the proper care will result in undesired behaviour, system crash or even lost of data on the disk. Therefore, taking in consideration that the free RAM area starts at 0x4420 and ends at 0xFFFF, the programmer can load programs of maximum 48,095 bytes (48 KB).

6.4.2 Storing your variables

Variables for programs can be store anywhere in the free **RAM** space.

The OS is having its own internal variables that can be accessed by the user. Also, some variables are used only by CLI and therefore could be re-used during the execution of a program.

Refer to the section [System Variables \(SYSVARS\)](#) on this guide to know the exact locations.

- The **DISK Superblock** and **DISK BAT** areas can be re-used if you are not using **DISK** routines.
- The **CLI** area can safely be re-used in your program, as the CLI is not running meanwhile your program is.
- The **RTC** area can be re-used if you are not calling any **RTC** routines.
- The **Math** area can be re-used if you are not calling any **Math** routines.
- The **SIO**, **Generic** and **VDP** areas MUST not be touched.

All in all, you may end up having some extra 700 bytes here.

6.4.3 Receiving parameters from CLI

When a user types a command in CLI, the entered command is stored in an area of 64 bytes in the [System Variables \(SYSVARS\)](#) called *CLI_buffer_full_cmd*. From there, you can read the full command, which will be the name of your binary program, and the parameter or parameters.

6.4.4 Returning to CLI

If your program allows the user to return to CLI, it must then jump to the loop subroutine known as (CLI Prompt). The address of this subroutine is

stored in the [System Variables \(SYSVARS\)](#)' *CLI_prompt_addr*.

Simply make your program to load the value stored at that location and jump (*jp*) to it.

6.4.5 Developing with Z80 Assembler

In order for dzOS to know where to load the program in **RAM**, the executable code must provide the load address. For compatibility with SDCC ⁵, we will store it in the bytes 3 and 4 of the executable.

For programs developed in Z80 Assembler, add the following at the top of the source code:

```
.ORG      $4420                                ; start of code at
                                                ; start of free RAM
jp        $4425                                ; first instruction
                                                ; must jump to the
                                                ; executable code
.BYTE     $20 , $44                            ; load address
                                                ; (values must be
                                                ; same as .org above)

.ORG      $4425                                ; start of program
                                                ; (must be same as jp above)

; your program here
; your program here
; your program here
```

The first *.ORG* (*.ORG \$4420*) indicates the start address used for creating the binary file after compilation.

0x4420 is where the Free **RAM** starts, giving you 48 KB for your program. Programs **SHOULD** not be loaded at a lower address, for the reason explained before.

The first instruction **MUST** be a jump (*jp*) instruction to the actual executable code (i.e. your program code) The *.BYTE* instruction just inserts the two bytes after the jump instruction. The values **MUST** be in hexadecimal little-endian format.

Because the *jp* instruction in Z80 is translated as *C3 nn nn* (where *nn* are the bytes where to jump), this will use the first three bytes (0x00, 0x01,

⁵Small Device C Compiler (SDCC) is a retargettable, optimizing Standard C (ANSI C89, ISO C99, ISO C11) compiler suite that targets (amongst others) the Zilog Z80 based MCUs. (<http://sdcc.sourceforge.net/>)

0x02) in the binary, therefore we store the load address at bytes 3 and 4 and your program can start just after, at byte 0x05.

Once assembled, the binary will be loaded by dzOS at the load address, and when executed, the first thing that will happen is a *jp* instruction and then the execution will continue from the executable code of your program.

If your program allows the user to return to CLI, add the following on your source code:

```
ld      HL, (CLI_prompt_addr)    ; return control
jp      (HL)                    ; to CLI
```

For convenience, two files are provided in the Github repository⁶: *_header.inc* and *_template.asm*

6.4.6 Developing with SDCC

In the Github repository, there is a file (*crt0.s* that sets:

- the start address for the binary at 0x4420
- the values 0x20 and 0x44 in the binary at bytes 5 and 6.
- first instruction of your program to be started located at 0x4425

Therefore, by using this file all programs will be loaded at the correct address.


⁶<https://github.com/dasta400/dzSoftware>

7 Appendixes

7.1 ANSI Terminal colours

- ANSI_COLR_BLK - Black
- ANSI_COLR_RED - Red
- ANSI_COLR_GRN - Green
- ANSI_COLR_YLW - Yellow
- ANSI_COLR_BLU - Blue
- ANSI_COLR_MGT - Magenta
- ANSI_COLR_CYA - Cyan
- ANSI_COLR_WHT - White

7.2 VDP Composite colours



- VDP_COLR_TRNSP - Transparent
- VDP_COLR_BLACK - Black
- VDP_COLR_M_GRN - Medium Green
- VDP_COLR_L_GRN - Light Green
- VDP_COLR_D_BLU - Dark Blue
- VDP_COLR_L_BLU - Light Blue
- VDP_COLR_D_RED - Dark Red
- VDP_COLR_CYAN - Cyan
- VDP_COLR_M_RED - Medium Red
- VDP_COLR_L_RED - Light Red
- VDP_COLR_D_YLW - Dark Yellow
- VDP_COLR_L_YLW - Light Yellow
- VDP_COLR_D_GRN - Dark Green
- VDP_COLR_MGNTA - Magenta
- VDP_COLR_GREY - Grey
- VDP_COLR_WHITE - White

7.3 Jiffy Counter

A *Jiffy* is the time between two ticks of the system timer interrupt. On the dastaZ80, this timer is generated by the TMS9918A (**VDP**) at roughly each 1/60th second.

The counter is made of 3 bytes. Byte 1 is incremented in each **VDP** interrupt. Once it rolls over to zero (256 increments), the byte 2 is incremented. Once the byte 2 rolls over, the byte 3 is incremented. Once the three bytes together (24-bit) reach the value 0x4F1A00, the three bytes are initialised to zero.

0x4F1A00 (5,184,000 in decimal) is the number of jiffies in 24 hours: 24 hours x 60 minutes in an hour x 60 seconds in a minute x 60 jiffies in a second.

IMPORTANT: This counter **MUST** not be interpreted as an accurate clock, because when transferring data to the **VRAM** the OS disables the [NMI](#)⁷, and therefore the counter stops for a while.

7.4 OS Boot Sequence

After power on or after pressing the **RESET** button:

- **Bootstrap**
 - Copy contents of the ROM into High RAM (0x8000 - 0xFFFF).
 - Disable ROM chip and enable Low RAM (0x0000 - 0x7FFF). Therefore, all **MEMORY** is RAM from now on.
 - Copy the copy of ROM into High RAM to Low RAM. Bootstrap code is not copied.
 - Transfer control to BIOS (jp F_BIOS_SERIAL_INIT).
- **Initialise SIO/2 (F_BIOS_SERIAL_INIT)**
 - Initialise SIO/2.
 - * Set Channel A as 115,000 bps, 8N1, Interrupt in all received characters.
 - * Set Channel B as 115,000 bps, 8N1, Interrupt in all received characters.
 - * Set Interrupt Vector to 0x60.

⁷It is also highly recommended that in your programs you also disable the [NMI](#) when copying large amounts of data. Otherwise, the process will be interrupted 60 times per second, and therefore slow it down.

- Set CPU to Interrupt Mode 2.
- `jp F_BIOS_WBOOT`
- **BIOS Boot** (`F_BIOS_WBOOT`)
 - Set SIO/2 Channel A as primary I/O.
 - Transfer control to Kernel (`jp F_KRN_START`).
- **Kernel Boot** (`F_KRN_START`)
 - Display dzOS welcome message.
 - Display dzOS release version.
 - Display Kernel version.
 - Display available **RAM**.
 - Initialise **VDP**.
 - * Test write/read **VRAM**.
 - * Set **Low Resolution Display** as *Graphics II Bit-mapped Mode*.
 - * Show dastaZ80 Logo in the **Low Resolution Display**.
 - Initialise **FDD**.
 - Initialise **SD Card**.
 - * Detect **SD Card**.
 - * Display number of available Disk Image Files.
 - * Display disk unit and name of each Disk Image File.
 - Initialise **Real-Time Clock (RTC)**.
 - * Detect **RTC**.
 - * Display current date and time.
 - * Display **RTC**'s battery status.
 - * Detect **NVRAM**.
 - Initialise **SYSVARS**.
 - * Set show deleted files with *cat* command as OFF.
 - * Set default File Type as 0 (USR = User defined).
 - * Set default loadsave address to 0x0000 (i.e. will save/load starting from Free RAM (0x4420)).

- Set default **DISK** as 1 (i.e. first Disk Image File in the **SD card**).
- Transfer control to Command-line Interpreter (CLI) (`jp F_CLI_START`).
- **CLI** (`F_CLI_START`)
 - Display CLI version.
 - Clear command buffers
 - Display prompt (`>`).
 - Read command entered by user.
 - Parse command.
 - Execute corresponding subroutine.
 - Loop back to Display prompt.

7.5 dzOS Programming Style

When writing dzOS and software for dzOS, the following style has been followed:

- All CPU registers are written in uppercase (e.g. *A*, *BC*, *DE*, *HL*).
- All CPU flags are written in lowercase (e.g. *z*, *nz*, *c*, *nc*, *m*, *p*).
- All assembly mnemonics are written in lowercase (e.g. *ld A,0*).
- Labels for subroutines that will be public (i.e. called via a Jumpblock) are written in uppercase.
- No mnemonics are written in the same line as a label.
- Public subroutines contain comments specifying:
 - Short description.
 - Input CPU registers or variables (SYSVARS).
 - Output CPU registers or variables (SYSVARS).
- All hexadecimal values are written with a dollar sign as prefix.
- Tabs are written as 4 spaces.
- Mnemonics start after 2 tabs (8 spaces).
- When possible, comments are written in column 41. Otherwise in next closest tab.
- Source code is heavily commented. Mostly on each line.

- *The Telemark Assembler (TASM) specific:*
 - *.BYTE* is used instead of *.DB*
 - *.WORD* is used instead of *.DW*

References

- [1] David Asta. *dastaZ80 User's Manual*, 2022.
- [2] David Asta. *dastaZ80 Technical Reference Manual*, 2022.
- [3] David Asta. dzos github repository. <https://github.com/dasta400/dzOS>, 2022.